


**SIEMENS**



# SINAMICS

## SINAMICS G120 low voltage converters

Chassis and wall/panel mounted devices with CU230P-2 Control Units

Operating instructions

Edition

04/2015

Answers for industry.

## Modified behavior when commissioning the drive

With firmware V4.7 SP3, the commissioning Wizard has been revised and standardized for the following inverters:

- SINAMICS G120 with PM240, PM240-2 or PM330 Power Module
- SINAMICS G120C

The SINAMICS application classes *Standard Drive Control*, *Dynamic Drive Control* and *Expert* have been newly developed. The commissioning Wizard sets the application class depending on the particular inverter:

- *Standard Drive Control* for SINAMICS G120C and SINAMICS G120 with Power Module PM240, PM240-2 up to frame size FSD
- *Dynamic Drive Control* for SINAMICS G120 with PM240, PM240-2 Power Modules from frame size FSD and with PM330 Power Modules
- *Expert* for SINAMICS G120 with PM230, PM250 and PM260 Power Modules

Motor data identification (MotID) is permanently set for *Standard Drive Control*. After the commissioning Wizard has been exited, the inverter responds to the first ON command as follows:

1. The inverter carries out a MotID with the motor at a standstill. The duration of the MotID, when compared to firmware V4.7, was shortened to approx.  $\frac{1}{3}$ .
2. The inverter accelerates the motor to the specified setpoint. The second ON command after the MotID is not necessary for *Standard Drive Control*.

For *Dynamic Drive Control*, a MotID is also set as default with the motor at a standstill. The default setting can be changed:

- In addition, you can also select the MotID with rotating measurement. The inverter optimizes the closed-loop speed control based on the results of the rotating measurement.
- You can select as to whether, after the MotID, the motor immediately accelerates to the specified setpoint, or a second ON command is required.

To a large extent, *Expert* corresponds to the commissioning Wizard for firmware < V4.7 SP3.

A MotID is not set as default. You can select the following:

- No MotID, MotID with measurement with the motor at a standstill or MotID with rotating measurement
- After the MotID, the motor immediately accelerates to the specified setpoint, or only after a second ON command.

The following commissioning tools support the new commissioning wizard:

- STARTER from 4.4 SP1 or higher
- Startdrive from V13 SP1 and higher with Hardware Support Package V4.7 SP3
- IOP from V1.6 and higher
- BOP-2

# SIEMENS

## SINAMICS

### SINAMICS G120P Converter with CU230P-2 Control Units

#### Operating Instructions

#### Changes in this manual

---

Fundamental safety instructions	1
Introduction	2
Description	3
Installing	4
Commissioning	5
Advanced commissioning	6
Backing up data and series commissioning	7
Corrective maintenance	8
Alarms, faults and system messages	9
Technical data	10
Appendix	A

Edition 04/2015, Firmware V4.7 SP3

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.
 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.
 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.
<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Changes in this manual

## Changes with respect to the Manual, Edition 04/2014

New hardware	In Chapter
<p>New PM240-2, FSD ... FSE Power Modules</p> <p>Revised PM230 Power Module with new Article numbers supported:</p> <ul style="list-style-type: none"> <li>• IP55 degree of protection: 6SL3223-0DE . . . . <b>G</b> .</li> <li>• IP20 degree of protection and Push Through: 6SL321 . - 1NE . . . . <b>G</b> .</li> </ul>	<p>Power Modules in degree of protection IP20 and with push-through system (Page 28)</p> <p>Installing Power Modules (Page 56)</p> <p>Technical data, PM240-2 (Page 388)</p>

New functions in firmware V4.7 SP3	In Chapter
<p>When using PM240, PM240-2 and PM330 Power Modules: Application classes "Standard drive control" and "Dynamic drive control" to simplify setting the motor control.</p>	<p>Starting basic commissioning (Page 127)</p> <p>Commissioning (Page 115)</p> <p>Motor control (Page 219)</p>
<p>PM330 Power Module, frame size HX is supported</p>	<p>Power Module (Page 28)</p>
<p>Reluctance motors are supported</p>	<p>Motor series that are supported (Page 45)</p>
<p>Automatic setting of the PID technology controller (autotuning)</p>	<p>PID technology controller (Page 266)</p>
<p>The sign of the system deviation for the additional, free technology controller can be switched over.</p> <p>A new parameter defines the sign of the system deviation matching the particular application, e.g. for cooling or heating applications.</p>	<p>Free technology controllers (Page 271)</p>
<p>Temperature sensors extended to include DIN-Ni1000 for analog inputs AI 2 and AI 3.</p>	<p>Analog inputs (Page 159)</p>
<p>Automatic switchover of the real time clock from daylight saving time (summer time) to standard time (winter time).</p>	<p>Real time clock (RTC) (Page 281)</p>
<p>Load torque monitoring extended to include the following functions:</p> <ul style="list-style-type: none"> <li>• Protection against blocking, leakage and dry running operation in pump applications</li> <li>• Protection against blocking and broken belts in fan applications</li> </ul>	<p>System protection (Page 273)</p>
<p>Line contactor control using a digital output of the inverter to save energy when the motor is switched off</p>	<p>Line contactor control (Page 264)</p>
<p>Improved motor data identification for PM330 Power Modules</p>	<p>Setting is not required for the user</p>

<b>New functions in firmware V4.7 SP3</b>	<b>In Chapter</b>
Fast flying restart for PM330 Power Modules: The "Flying restart" function does not have to wait for the motor demagnetization time, and identifies the motor speed without requiring a search operation.	Setting is not required for the user
New or revised default settings of the interfaces: p0015 macros 110, 112 and 120	Default setting of the interfaces (Page 88)
Communication expansion via Modbus: Adjustable parity bit, access to parameters and analog inputs	See "Fieldbuses" Function Manual, Manuals for the Control Unit ( <a href="http://support.automation.siemens.com/WW/view/en/30563628/133300">http://support.automation.siemens.com/WW/view/en/30563628/133300</a> )
Extending communication via BACnet: Access to parameters and analog inputs	See "Fieldbuses" Function Manual, Manuals for the Control Unit ( <a href="http://support.automation.siemens.com/WW/view/en/30563628/133300">http://support.automation.siemens.com/WW/view/en/30563628/133300</a> )
The bus error LED for communication via USS and Modbus can be switched off	Operating states indicated on LEDs (Page 348)

You can find an overview of all new and modified functions in firmware V4.7 SP3 in Section New and extended functions (Page 431).

<b>Corrections</b>	<b>In Chapter</b>
Minimum operating temperature: -10 °C (and not 0 °C)	Technical data for CU230P-2 (Page 369)

<b>Revised descriptions</b>	<b>In Chapter</b>
Terminal strips, factory setting and default settings of the terminal strips	Terminal strips (Page 84)
Startdrive commissioning tool added	Commissioning with a PC (Page 135)
Manual speed control optimization	Optimizing the speed controller (Page 229)

# Table of contents

	Changes in this manual.....	5
<b>1</b>	<b>Fundamental safety instructions .....</b>	<b>13</b>
1.1	General safety instructions .....	13
1.2	Safety instructions for electromagnetic fields (EMF) .....	17
1.3	Handling electrostatic sensitive devices (ESD) .....	17
1.4	Industrial security .....	18
1.5	Residual risks of power drive systems.....	19
<b>2</b>	<b>Introduction.....</b>	<b>21</b>
2.1	About the Manual.....	21
2.2	Guide through the manual .....	22
<b>3</b>	<b>Description.....</b>	<b>25</b>
3.1	Identifying the converter.....	25
3.2	Control Units .....	27
3.3	Power Module .....	28
3.3.1	Power Modules in degree of protection IP20 and with push-through system .....	28
3.3.2	Power Module in IP55 degree of protection / UL Type 12.....	31
3.4	Components for the Power Modules .....	32
3.4.1	Accessories for installation and shielding .....	32
3.4.2	Line filter .....	33
3.4.3	Line reactor .....	34
3.4.4	Output reactor .....	37
3.4.5	Sine-wave filter .....	41
3.4.6	dv/dt filter .....	42
3.4.7	Braking Module and braking resistor .....	42
3.5	Motor series that are supported.....	45
3.6	Tools to commission the converter .....	46
<b>4</b>	<b>Installing .....</b>	<b>47</b>
4.1	Overview of the inverter installation.....	47
4.2	Connecting inverters in compliance with EMC .....	48
4.2.1	EMC-compliant connection of the converter.....	48
4.2.2	Avoiding electromagnetic influence (EMI) .....	48
4.2.3	Amount the shield plate onto the Power Module .....	51
4.3	Installing reactors, filters and braking resistors .....	54
4.4	Installing Power Modules.....	56
4.4.1	Dimensions, hole drilling templates, minimum clearances, tightening torques .....	58
4.4.2	Digital inputs and outputs on the PM330 Power Module.....	66

4.5	Connecting the line supply, motor and converter components.....	69
4.5.1	Permissible line supplies.....	69
4.5.2	Connecting the inverter.....	73
4.5.3	Connecting a braking resistor.....	77
4.6	Installing Control Unit.....	79
4.6.1	Overview of the interfaces.....	82
4.6.2	Fieldbus interface allocation.....	83
4.6.3	Terminal strips.....	84
4.6.4	Factory setting of the interfaces.....	86
4.6.5	Default setting of the interfaces.....	88
4.6.6	Wiring terminal strips.....	106
4.6.7	Connecting the inverter to the fieldbus.....	107
4.6.7.1	PROFINET.....	108
4.6.7.2	PROFIBUS.....	112
<b>5</b>	<b>Commissioning.....</b>	<b>115</b>
5.1	Commissioning guidelines.....	115
5.2	Preparing for commissioning.....	116
5.2.1	Collecting motor data.....	116
5.2.2	Factory setting of the converter control.....	116
5.2.3	Defining additional requirements for the application.....	118
5.3	Commissioning using a BOP-2 operator panel.....	119
5.3.1	Starting basic commissioning.....	119
5.3.2	Basic commissioning with application classes.....	127
5.3.2.1	Starting basic commissioning.....	127
5.3.2.2	Standard Drive Control.....	129
5.3.2.3	Dynamic Drive Control.....	131
5.4	Commissioning with a PC.....	135
5.4.1	Creating a project.....	136
5.4.2	Transfer inverters connected via USB into the project.....	136
5.4.3	Go online and start the configuration wizards.....	139
5.4.4	Standard Drive Control.....	141
5.4.5	Dynamic Drive Control.....	142
5.4.6	Configuration for experts.....	143
5.4.7	Identify motor data.....	146
5.5	Restoring the factory setting.....	148
<b>6</b>	<b>Advanced commissioning.....</b>	<b>151</b>
6.1	Overview of the inverter functions.....	151
6.2	Inverter control.....	153
6.2.1	Switching the motor on and off.....	153
6.2.2	Adapt the default setting of the terminal strip.....	155
6.2.2.1	Digital inputs.....	156
6.2.2.2	Digital outputs.....	158
6.2.2.3	Analog inputs.....	159
6.2.2.4	Analog outputs.....	163
6.2.3	Inverter control using digital inputs.....	166
6.2.4	Two-wire control: method 1.....	167
6.2.5	Two-wire control, method 2.....	168

6.2.6	Two-wire control, method 3 .....	169
6.2.7	Three-wire control, method 1 .....	170
6.2.8	Three-wire control, method 2 .....	171
6.2.9	Running the motor in jog mode (JOG function) .....	172
6.2.10	Control via PROFIBUS or PROFINET with the PROFIdrive profile .....	173
6.2.10.1	Control and status word 1 .....	175
6.2.10.2	Control and status word 3 .....	178
6.2.10.3	NAMUR message word .....	180
6.2.10.4	Data structure of the parameter channel .....	180
6.2.10.5	Examples of the parameter channel .....	184
6.2.10.6	Extend telegrams and change signal interconnection .....	185
6.2.10.7	Configuring the IP interface .....	187
6.2.10.8	Slave-to-slave communication .....	187
6.2.10.9	Acyclically reading and writing inverter parameters .....	188
6.2.11	Control via additional fieldbuses .....	189
6.2.11.1	Modbus RTU .....	189
6.2.11.2	USS .....	192
6.2.11.3	CANopen .....	195
6.2.11.4	BACnet MS/TP .....	196
6.2.11.5	Ethernet/IP .....	199
6.2.11.6	P1 .....	200
6.2.12	Switching over the inverter control (command data set) .....	201
6.3	Setpoints .....	203
6.3.1	Analog input as setpoint source .....	204
6.3.2	Specifying the setpoint via the fieldbus .....	205
6.3.3	Motorized potentiometer as setpoint source .....	206
6.3.4	Fixed speed as setpoint source .....	208
6.4	Setpoint calculation .....	211
6.4.1	Overview of setpoint processing .....	211
6.4.2	Invert setpoint .....	212
6.4.3	Enable direction of rotation .....	213
6.4.4	Skip frequency bands and minimum speed .....	214
6.4.5	Speed limitation .....	215
6.4.6	Ramp-function generator .....	216
6.5	Motor control .....	219
6.5.1	V/f control .....	219
6.5.1.1	Characteristics of U/f control .....	221
6.5.1.2	Optimizing motor starting .....	224
6.5.2	Vector control with speed controller .....	227
6.5.2.1	Overview .....	227
6.5.2.2	Optimizing the speed controller .....	229
6.6	Protection functions .....	231
6.6.1	Inverter temperature monitoring .....	231
6.6.2	Motor temperature monitoring using a temperature sensor .....	234
6.6.3	Protecting the motor by calculating the motor temperature .....	236
6.6.4	Overcurrent protection .....	238
6.6.5	Limiting the maximum DC link voltage .....	239
6.7	Application-specific functions .....	241
6.7.1	Unit changeover .....	241
6.7.1.1	Changing over the motor standard .....	242

6.7.1.2	Changing over the unit system .....	243
6.7.1.3	Changing over process variables for the technology controller .....	243
6.7.1.4	Switching units with STARTER.....	244
6.7.2	Calculating the energy saving.....	246
6.7.3	Electrically braking the motor.....	248
6.7.3.1	DC braking .....	249
6.7.3.2	Compound braking.....	252
6.7.3.3	Dynamic braking .....	254
6.7.3.4	Braking with regenerative feedback to the line .....	255
6.7.4	Flying restart – switching on while the motor is running .....	256
6.7.5	Automatic switch-on.....	258
6.7.6	Kinetic buffering (Vdc min control) .....	262
6.7.7	Line contactor control.....	264
6.7.8	PID technology controller .....	266
6.7.9	Free technology controllers.....	271
6.7.10	System protection .....	273
6.7.10.1	No-load monitoring, blocking protection, stall protection .....	274
6.7.10.2	Load monitoring .....	276
6.7.11	Real time clock (RTC).....	281
6.7.12	Time switch (DTC) .....	283
6.7.13	Essential service mode .....	284
6.7.14	Multi-zone control.....	288
6.7.15	Bypass .....	291
6.7.16	Cascade control and hibernation mode .....	296
6.7.16.1	Cascade control .....	296
6.7.16.2	Hibernation mode.....	300
6.7.17	Free function blocks.....	305
6.7.17.1	Further information.....	305
6.8	Switchover between different settings .....	306
<b>7</b>	<b>Backing up data and series commissioning .....</b>	<b>309</b>
7.1	Backing up and transferring settings using a memory card.....	310
7.1.1	Saving setting on memory card .....	311
7.1.2	Transferring the setting from the memory card.....	314
7.1.3	Safely remove the memory card.....	318
7.2	Saving settings on a PC.....	320
7.3	Saving settings on an operator panel .....	323
7.4	Other ways to back up settings.....	324
7.5	Write and know-how protection.....	325
7.5.1	Write protection .....	325
7.5.2	Know-how protection .....	326
7.5.2.1	Settings for know-how protection.....	328
7.5.2.2	Generating an exception list for know-how protection .....	330
<b>8</b>	<b>Corrective maintenance .....</b>	<b>331</b>
8.1	Replacing inverter components .....	331
8.1.1	Overview of replacing converter components.....	331
8.1.2	Replace Control Unit.....	332
8.1.3	Replacing the Control Unit without data backup.....	335
8.1.4	Replacing the Control Unit with know-how protection active.....	336

8.1.5	Replacing a Power Module .....	338
8.2	Firmware upgrade and downgrade .....	339
8.2.1	Upgrading the firmware .....	340
8.2.2	Firmware downgrade .....	342
8.2.3	Correcting an unsuccessful firmware upgrade or downgrade .....	344
8.3	If the converter no longer responds .....	345
<b>9</b>	<b>Alarms, faults and system messages .....</b>	<b>347</b>
9.1	Operating states indicated on LEDs .....	348
9.2	System runtime .....	351
9.3	Alarms .....	352
9.4	Faults .....	355
9.5	List of alarms and faults .....	360
9.6	Identification & maintenance data (I&M) .....	367
<b>10</b>	<b>Technical data .....</b>	<b>369</b>
10.1	Technical data for CU230P-2 .....	369
10.2	Technical data, Power Modules .....	372
10.2.1	Technical data, PM230 .....	373
10.2.1.1	General data, PM230 - IP20 .....	373
10.2.1.2	Power-dependent data, PM230, IP20 .....	375
10.2.1.3	General data, PM230, IP55 .....	382
10.2.1.4	Power-dependent data, PM230, IP55 .....	383
10.2.2	Technical data, PM240-2 .....	388
10.2.2.1	General data, PM240-2 - 200 V .....	388
10.2.2.2	Power-dependent data, PM240-2 - 200 V .....	390
10.2.2.3	General data, PM240-2 - 400V .....	395
10.2.2.4	Power-dependent data, PM240-2 - 400 V .....	397
10.2.2.5	General data, PM240-2 - 690 V .....	403
10.2.2.6	Power-dependent data, PM240-2 - 690 V .....	404
10.2.3	Technical data, PM240 .....	406
10.2.3.1	General data, PM240 .....	407
10.2.3.2	Power-dependent data, PM240 .....	408
10.2.4	Technical data, PM250 .....	414
10.2.4.1	General data, PM250 .....	415
10.2.4.2	Power-dependent data, PM250 .....	416
10.2.5	Technical data, PM260 .....	419
10.2.5.1	General data, PM260 .....	420
10.2.5.2	Power-dependent data, PM260 .....	421
10.2.6	PM330 technical data .....	422
10.2.6.1	PM330 general data .....	422
10.2.6.2	Power-dependent data, PM330 .....	424
10.2.7	Data regarding the power loss in partial load operation .....	427
10.3	Restrictions for special ambient conditions .....	428
<b>A</b>	<b>Appendix .....</b>	<b>431</b>
A.1	New and extended functions .....	431

A.2	Parameter .....	437
A.3	Handling the BOP 2 operator panel .....	440
A.3.1	Changing settings using BOP-2.....	441
A.3.2	Changing indexed parameters.....	442
A.3.3	Directly entering the parameter number and value.....	442
A.3.4	A parameter cannot be changed.....	443
A.4	The device trace in STARTER.....	444
A.5	Interconnecting signals in the converter .....	447
A.5.1	Fundamentals .....	447
A.5.2	Example .....	449
A.6	Manuals and technical support .....	451
A.6.1	Manuals for your inverter .....	451
A.6.2	Configuring support.....	452
A.6.3	Product Support .....	453
A.7	Mistakes and improvements .....	453
<b>Index</b>	.....	<b>455</b>

# Fundamental safety instructions

## 1.1 General safety instructions



### DANGER

#### Danger to life due to live parts and other energy sources

Death or serious injury can result when live parts are touched.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Generally, six steps apply when establishing safety:

1. Prepare for shutdown and notify all those who will be affected by the procedure.
2. Disconnect the machine from the supply.
  - Switch off the machine.
  - Wait until the discharge time specified on the warning labels has elapsed.
  - Check that it really is in a no-voltage condition, from phase conductor to phase conductor and phase conductor to protective conductor.
  - Check whether the existing auxiliary supply circuits are de-energized.
  - Ensure that the motors cannot move.
3. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water.
4. Isolate or neutralize all hazardous energy sources by closing switches, grounding or short-circuiting or closing valves, for example.
5. Secure the energy sources against switching on again.
6. Ensure that the correct machine is completely interlocked.

After you have completed the work, restore the operational readiness in the inverse sequence.



### WARNING

#### Danger to life through a hazardous voltage when connecting an unsuitable power supply

Touching live components can result in death or severe injury.

- Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV- (Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.



**! WARNING**

**Danger to life when live parts are touched on damaged devices**

Improper handling of devices can cause damage.

For damaged devices, hazardous voltages can be present at the enclosure or at exposed components; if touched, this can result in death or severe injury.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- Do not use any damaged devices.



**! WARNING**

**Danger to life through electric shock due to unconnected cable shields**

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

- As a minimum, connect cable shields and the conductors of power cables that are not used (e.g. brake cores) at one end at the grounded housing potential.



**! WARNING**

**Danger to life due to electric shock when not grounded**

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

- Ground the device in compliance with the applicable regulations.



**! WARNING**

**Danger to life due to electric shock when opening plug connections in operation**

When opening plug connections in operation, arcs can result in severe injury or death.

- Only open plug connections when the equipment is in a no-voltage state, unless it has been explicitly stated that they can be opened in operation.

**! WARNING**

**Danger to life due to fire spreading if housing is inadequate**

Fire and smoke development can cause severe personal injury or material damage.

- Install devices without a protective housing in a metal control cabinet (or protect the device by another equivalent measure) in such a way that contact with fire is prevented.
- Ensure that smoke can only escape via controlled and monitored paths.

 **WARNING****Danger to life through unexpected movement of machines when using mobile wireless devices or mobile phones**

Using mobile wireless devices or mobile phones with a transmit power > 1 W closer than approx. 2 m to the components may cause the devices to malfunction, influence the functional safety of machines therefore putting people at risk or causing material damage.

- Switch the wireless devices or mobile phones off in the immediate vicinity of the components.

 **WARNING****Danger to life due to the motor catching fire in the event of insulation overload**

There is higher stress on the motor insulation through a ground fault in an IT system. If the insulation fails, it is possible that death or severe injury can occur as a result of smoke and fire.

- Use a monitoring device that signals an insulation fault.
- Correct the fault as quickly as possible so the motor insulation is not overloaded.

 **WARNING****Danger to life due to fire if overheating occurs because of insufficient ventilation clearances**

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

- Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

 **WARNING****Danger of an accident occurring due to missing or illegible warning labels**

Missing or illegible warning labels can result in accidents involving death or serious injury.

- Check that the warning labels are complete based on the documentation.
- Attach any missing warning labels to the components, in the national language if necessary.
- Replace illegible warning labels.

<b>NOTICE</b>
<b>Device damage caused by incorrect voltage/insulation tests</b>
Incorrect voltage/insulation tests can damage the device.
<ul style="list-style-type: none"><li>• Before carrying out a voltage/insulation check of the system/machine, disconnect the devices as all converters and motors have been subject to a high voltage test by the manufacturer, and therefore it is not necessary to perform an additional test within the system/machine.</li></ul>

 <b>WARNING</b>
<b>Danger to life when safety functions are inactive</b>
Safety functions that are inactive or that have not been adjusted accordingly can cause operational faults on machines that could lead to serious injury or death.
<ul style="list-style-type: none"><li>• Observe the information in the appropriate product documentation before commissioning.</li><li>• Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.</li><li>• Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.</li><li>• Perform a function test.</li><li>• Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.</li></ul>

**Note**

**Important safety notices for Safety Integrated functions**

If you want to use Safety Integrated functions, you must observe the safety notices in the Safety Integrated manuals.

 <b>WARNING</b>
<b>Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization</b>
As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.
<ul style="list-style-type: none"><li>• Protect the parameterization (parameter assignments) against unauthorized access.</li><li>• Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).</li></ul>

## 1.2 Safety instructions for electromagnetic fields (EMF)



### WARNING

#### **Danger to life from electromagnetic fields**

Electromagnetic fields (EMF) are generated by the operation of electrical power equipment such as transformers, converters or motors.

People with pacemakers or implants are at a special risk in the immediate vicinity of these devices/systems.

- Ensure that the persons involved are the necessary distance away (minimum 2 m).

## 1.3 Handling electrostatic sensitive devices (ESD)

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



### NOTICE

#### **Damage through electric fields or electrostatic discharge**

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g. conductive foam rubber or aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
  - Wearing an ESD wrist strap
  - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

## 1.4 Industrial security

### Note

#### Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (<http://www.siemens.com/industrialsecurity>).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (<http://support.automation.siemens.com>).

### WARNING

#### **Danger as a result of unsafe operating states resulting from software manipulation**

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.  
You will find relevant information and newsletters at this address (<http://support.automation.siemens.com>).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.  
You will find further information at this address (<http://www.siemens.com/industrialsecurity>).
- Make sure that you include all installed products into the holistic industrial security concept.

## 1.5 Residual risks of power drive systems

The control and drive components of a drive system are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety instructions on the components and in the associated technical user documentation.

When assessing the machine's risk in accordance with the respective local regulations (e.g., EC Machinery Directive), the machine manufacturer must take into account the following residual risks emanating from the control and drive components of a drive system:

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware and/or software errors in the sensors, control system, actuators, and cables and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Parameterization, programming, cabling, and installation errors
  - Use of wireless devices/mobile phones in the immediate vicinity of the control system
  - External influences/damage
2. In the event of a fault, exceptionally high temperatures, including an open fire, as well as emissions of light, noise, particles, gases, etc. can occur inside and outside the inverter, e.g.:
  - Component failure
  - Software errors
  - Operation and/or environmental conditions outside the specification
  - External influences/damage

Inverters of the Open Type/IP20 degree of protection must be installed in a metal control cabinet (or protected by another equivalent measure) such that contact with fire inside and outside the inverter is not possible.

3. Hazardous shock voltages caused by, for example,
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly

---

**Note**

The components must be protected against conductive contamination (e.g. by installing them in a control cabinet with degree of protection IP54 according to IEC 60529 or NEMA 12).

Assuming that conductive contamination at the installation site can definitely be excluded, a lower degree of cabinet protection may be permitted.

---

For more information about residual risks of the components in a drive system, see the relevant sections in the technical user documentation.

# Introduction

## 2.1 About the Manual

### Who requires the operating instructions and what for?

These operating instructions primarily address fitters, commissioning engineers and machine operators. The operating instructions describe the devices and device components and enable the target groups being addressed to install, connect-up, set, and commission the converters safely and in the correct manner.

### What is described in the operating instructions?

These operating instructions provide a summary of all of the information required to operate the converter under normal, safe conditions.

The information provided in the operating instructions has been compiled in such a way that it is sufficient for all standard applications and enables drives to be commissioned as efficiently as possible. Where it appears useful, additional information for entry level personnel has been added.

The operating instructions also contain information about special applications. Since it is assumed that readers already have a sound technical knowledge of how to configure and parameterize these applications, the relevant information is summarized accordingly. This relates, e.g. to operation with fieldbus systems and safety-related applications.

### What is the meaning of the symbols in the manual?



An operating instruction starts here.



This concludes the operating instruction.



The subsequent text is applicable for an operator panel.



The following text applies if you are using a PC with STARTER.



Symbol for inverter functions.

See also: Overview of the inverter functions (Page 151).

## 2.2 Guide through the manual

Section	In this section you will find answers to the following questions:
Description (Page 25)	<ul style="list-style-type: none"> <li>• How is the inverter marked?</li> <li>• What components make up the inverter?</li> <li>• What optional components are available for the inverter?</li> <li>• What is the purpose of the optional components?</li> <li>• Which motors can be fed from the inverter?</li> <li>• What commissioning tools are there?</li> </ul>
Installing (Page 47)	<ul style="list-style-type: none"> <li>• Which sequence is recommended when installing the inverter?</li> <li>• What does EMC-compliant installation actually mean?</li> <li>• What options are available to install optional components below the inverter?</li> <li>• What are the inverter dimensions?</li> <li>• What mounting and installation materials are required when installing the inverter?</li> <li>• To which line supplies can the inverter be connected?</li> <li>• How is the inverter connected to the line supply?</li> <li>• How is the braking resistor connected to the inverter?</li> <li>• Which terminals and fieldbus interfaces does the inverter have?</li> <li>• What are the interface functions?</li> </ul>
Commissioning (Page 115)	<ul style="list-style-type: none"> <li>• Which motor data are required for commissioning</li> <li>• How is the inverter set in the factory?</li> <li>• What is the commissioning procedure?</li> <li>• How do you restore the inverter factory settings?</li> </ul>
Advanced commissioning (Page 151)	<ul style="list-style-type: none"> <li>• Which functions are included in the inverter hardware?</li> <li>• How do the functions interoperate with one another?</li> <li>• How are the functions set?</li> </ul>
Backing up data and series commissioning (Page 309)	<ul style="list-style-type: none"> <li>• Why is it necessary to back up the inverter settings?</li> <li>• What options are available to back up the settings?</li> <li>• How does the data backup function?</li> <li>• How do you prevent the inverter settings from being changed?</li> <li>• How do you prevent the inverter settings from being read out?</li> </ul>
Corrective maintenance (Page 331)	<ul style="list-style-type: none"> <li>• How do you replace inverter components?</li> <li>• How do you change the firmware version of the inverter?</li> </ul>
Alarms, faults and system messages (Page 347)	<ul style="list-style-type: none"> <li>• What is the meaning of the LEDs provided on the inverter?</li> <li>• How does the system runtime you respond?</li> <li>• How does the inverter save alarms and faults?</li> <li>• What do the inverter alarms and faults mean?</li> <li>• How are inverter faults resolved?</li> <li>• Which I&amp;M data are saved in the inverter?</li> </ul>

Section	In this section you will find answers to the following questions:
Technical data (Page 369)	<ul style="list-style-type: none"><li>• What is the inverter technical data?</li><li>• What do "High Overload" and "Low Overload" mean?</li></ul>
Appendix (Page 431)	<ul style="list-style-type: none"><li>• What are the new functions of the current firmware?</li><li>• What are the most important inverter parameters?</li><li>• How is the inverter operated using the BOP-2 operator panel?</li><li>• How does the device trace function in STARTER?</li><li>• How can signal interconnections be changed in the inverter firmware?</li><li>• What does "BiCo technology" mean?</li><li>• Where can you find additional manuals and information about the inverter?</li></ul>



## Description

### Use for the intended purpose

The inverter described in this manual is a device to control a three-phase motor. The inverter is designed for installation in electrical installations or machines.

It has been approved for industrial and commercial use on industrial networks. Additional measures have to be taken when connected to public grids.


The technical specifications and information about connection conditions are indicated on the rating plate and in the operating instructions.

### 3.1 Identifying the converter

#### Main components of the inverter

Each SINAMICS G120 inverter comprises a Control Unit and a Power Module.

- The Control Unit controls and monitors the connected motor.
- The Power Module provides the connections for line supply and motor.



The following data is provided on the Power Module type plate (①):

- Designation: e.g. Power Module 240
- Technical data: Voltage and current
- Article number: e.g. 6SL3224-0BE13-7UA0
- Version: e.g. A02

The following data can be found on the Control Unit type plate (②):

- Designation: e.g. Control Unit CU240E-2 DP-F
- Article number: e.g. 6SL3244-0BB13-1PA0
- Version: e.g. A02 (hardware)

### **Further inverter components**

The following components are available so that you can adapt the inverter to different applications and ambient conditions:

- Line filter (Page 33)
- Line reactor (Page 34)
- Output reactor (Page 37)
- Sine-wave filter (Page 41)
- dv/dt filter (Page 42)
- Braking Module and braking resistor (Page 42)
- Basic Operator Panel 2 (BOP-2) (Page 46)
- Intelligent Operator Panel (IOP) (Page 46)

## 3.2 Control Units

The Control Units differ with regard to the type of fieldbus.

	Designation	Article number	Fieldbus
	CU230P-2 HVAC	6SL3243-0BB30-1HA3	USS, Modbus RTU, BACnet MS/TP, P1
	CU230P-2 DP	6SL3243-0BB30-1PA3	PROFIBUS DP
	CU230P-2 PN	6SL3243-0BB30-1FA0	PROFINET IO, EtherNet/IP
	CU230P-2 CAN	6SL3243-0BB30-1CA3	CANopen
	CU230P-2 BT <sup>1)</sup>	6SL3243-6BB30-1HA3	USS, Modbus RTU, BACnet MS/TP, P1

<sup>1)</sup> Exclusive version for Siemens IC BT

## Memory cards

Table 3- 1 Memory cards to back up inverter settings

Scope of delivery	Article number
Memory card without firmware	6SL3054-4AG00-2AA0
Memory card with firmware V4.6	6SL3054-7EG00-2BA0
Memory card with firmware V4.7	6SL3054-7EH00-2BA0
Memory card with firmware V4.7 SP3	6SL3054-7TB00-2BA0

## Shield connection kit for the Control Unit

The shield connection kit is an optional component. The shield connection kit comprises the following components:

- Shield plate
- Elements for optimum shield support and strain relief of the signal and communication cables

Table 3- 2 Article Nos.

Shield connection kit 1 for the CU230P-2 Control Units with all fieldbus interfaces except for PROFINET.	6SL3264-1EA00-0FA0
Shield connection kit 3 for the CU230P-2 and CU240E-2 Control Units with PROFINET interface.	6SL3264-1EA00-0HB0

### 3.3 Power Module

Important data on the Power Modules is provided in this section. Further information is contained in the hardware installation manuals listed in Section Manuals for your inverter (Page 451).

All power data refers to rated values or to power for operation with low overload (LO).

#### Which Power Module can I use with the Control Unit?

You can operate the CU230P-2 Control Unit with the following Power Modules:

- PM230
- PM240
- PM250
- PM330
- PM240-2
- PM260

#### 3.3.1 Power Modules in degree of protection IP20 and with push-through system



Figure 3-1 Power Module with degree of protection IP20 examples



Figure 3-2 Power Modules with the push-through system FSA ... FSC

### PM230, 3 AC 400 V - pump and fan applications

The PM230 Power Module is available without a filter or with integrated class A line filter.

- Article number range:
- IP20: 6SL3210-1NE...
  - Push Through: 6SL3211-1NE...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF	
Power range (kW), IP20	0.37 ... 3	4 ... 7.5	11 ... 18.5	22 ... 37	45 ... 55	75 ... 90	
Power range (kW), PT	3	7.5	18.5	---	---	---	

### PM330, 3 AC 400 V - pump, fan and compressor applications

The PM330 Power Module is available as an unfiltered device with IP20 degree of protection. External line filters are available as an option, see Section

Article number range: 6SL3310-1PE...

Frame size	GX	HX					
Power range (kW)	160 ... 250	315 ... 400					

**PM240-2 - for standard applications**

The PM240-2 Power Module is available without a filter or with an integrated class A line filter. The PM240-2 permits dynamic braking via an external braking resistor.

**1 AC / 3 AC 200 V**

Article number range:

- IP20: 6SL3210-1PB..., 6SL3210-1PC...
- Push Through: 6SL3211-1PB...

Frame size	FSA	FSB	FSC	FSD	FSE		
Power range (kW), IP20	0.55 ... 0.75	1.1 ... 2.2	3.0 ... 4.0	11 ... 18.5	22 ... 30		
Power range (kW), PT	0.75	2.2	4.0	---	---		

**3 AC 400 V**

Article number range:

- IP20: 6SL3210-1PE...
- Push Through: 6SL3211-1PE...

Frame size	FSA	FSB	FSC	FSD	FSE		
Power range (kW), IP20	0.55 ... 3.0	4.0 ... 7.5	11 ... 15	18.5 ... 37	45 ... 55		
Power range (kW), PT	3.0	7.5	15	---	---		

**3 AC 600 V**

Article number range:

- IP20: 6SL3210-1PH...
- Push Through: 6SL3211-1PH...

Frame size	FSA	FSB	FSC	FSD	FSE		
Power range (kW), IP20	---	---	---	11 ... 37	45 ... 55		
Power range (kW), PT	---	---	---	---	---		

**PM240, 3 AC 400 V - for standard applications**

The PM240 Power Module is available without a filter or with an integrated class A line filter with degree of protection IP20. The PM240 allows dynamic braking via an external braking resistor.

Article number range: 6SL3224-0BE... and 6SL3224-0XE...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF	GX
Power range (kW)	0.37 ... 1.5	2.2 ... 4	7.5 ... 15	18.5 ... 30	37 ... 45	55 ... 132	160 ... 250

### PM250, 3 AC 400 V - Applications with energy recovery

The PM250 Power Module is available without a filter or with an integrated class A line filter with degree of protection IP20. The PM250 permits dynamic braking with energy recovery into the line supply.

Article number range, IP20: 6SL3225-0BE ...

Frame size	FSC	FSD	FSE	FSF			
Power range (kW)	7.5 ... 15	18.5 ... 30	37 ... 45	55 ... 90			


### PM260, 3 AC 690 V - Applications with energy recovery

The PM260 Power Module is available without a filter or with an integrated class A line filter with degree of protection IP20. A sine-wave filter is fitted to the motor. The PM260 permits dynamic braking with energy recovery into the line supply.

Article number range, IP20: 6SL3225-0BH...

Frame size	FSD	FSF					
Power range (kW)	11 ... 18.5	30 ... 55					

## 3.3.2 Power Module in IP55 degree of protection / UL Type 12



### PM230, 3 AC 400 V, degree of protection IP55 / UL Type 12

Frame size		FSA	FSB	FSC	FSD	FSE	FSF
Power range (kW)	Filter Class A	0.37 ... 3	4 ... 7.5	11 ... 18.5	22 ... 30	37 ... 45	55 ... 90
	Filter Class B	0.37 ... 3	4 ... 7.5	11 ... 15	18.5 ... 30	37 ... 45	55 ... 90

The Power Module PM230 IP55/UL Type 12 is suitable for installation close to the motor.

Article number range: 6SL3223-0DE...

### 3.4 Components for the Power Modules

#### 3.4.1 Accessories for installation and shielding

##### Shield connection kit

Establish the shield and strain relief for the power connections using the shield connection kit.

The shield connection kit comprises a shield plate and serrated strips with screws.




Table 3-3 Article numbers for the shield connection kit

Frame size	PM240, PM250, PM340 Power Modules	PM260	PM230, PM240-2
FSA	6SL3262-1AA00-0BA0	-	The shield connection kit is included in the scope of delivery
FSB	6SL3262-1AB00-0DA0	-	
FSC	6SL3262-1AC00-0DA0	-	
FSD	6SL3262-1AD00-0DA0	6SL3262-1FD00-0CA0	
FSE	6SL3262-1AD00-0DA0	-	
FSF	6SL3262-1AF00-0DA0	6SL3262-1FF00-0CA0	

##### Adapter for mounting on DIN mounting rails for PM240, PM250 and PM260

You can use the adapter for rail mounting to mount the Power Module onto two mounting rails with a center-to-center distance of 100 mm.

Frame size	Article numbers for adapters for mounting on DIN mounting rails
FSA	6SL3262-1BA00-0BA0
FSB	6SL3262-1BB00-0BA0

### 3.4.2 Line filter

With a line filter, the inverter can achieve a higher radio interference class. An external filter is not required for inverters with integrated line filter.

Adjacent examples of line filters.

The line filter corresponds to Class A or B according to EN55011: 2009.



for PM240  
FSA



for PM240 GX

#### NOTICE

##### The line filter is damaged when operated on inadmissible line supplies

The line filter is only suitable for operation on TN or TT line systems with a grounded neutral point. The line filter is damaged if operated on all other line supplies.

- For inverters equipped with line filter, only connect to TN or TT line systems with a grounded neutral point.

#### External line filters for PM240

Power Module		Power	Line filter, class A
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0, 6SL3224-0BE17-5UA0, 6SL3224-0BE21-1UA0, 6SL3224-0BE21-5UA0	0.37 kW ... 1.5 kW	6SE6400-2FA00-6AD0
FSF	6SL3224-0BE38-8UA0, 6SL3224-0BE41-1UA0	110 kW ... 132 kW	6SL3203-0BE32-5AA0
GX	6SL3224-0XE41-3UA0, 6SL3224-0XE41-6UA0	160 kW ... 200 kW	6SL3000-0BE34-4AA0
	6SL3224-0XE42-0UA0	250 kW	6SL3000-0BE36-0AA0

Power Module		Power	Line filter, class B
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0, 6SL3224-0BE17-5UA0, 6SL3224-0BE21-1UA0, 6SL3224-0BE21-5UA0	0.37 kW ... 1.5 kW	6SE6400-2FB00-6AD0
FSB	6SL3224-0BE22-2AA0, 6SL3224-0BE23-0AA0, 6SL3224-0BE24-0AA0	2.2 kW ... 4.0 kW	6SL3203-0BE21-6SA0
FSC	6SL3224-0BE25-5UA0, 6SL3224-0BE27-5UA0, 6SL3224-0BE31-1UA0	7.5 kW ... 15.0 kW	6SL3203-0BD23-8SA0

**External line filters for PM250**

Power Module		Power	Line filter, class B
FSC	6SL3225-0BE25-5AA0, 6SL3225-0BE27-5AA0, 6SL3225-0BE31-1AA0	7.5 kW ... 15.0 kW	6SL3203-0BD23-8SA0

**External line filters for PM330**

Power Module		Power	Line filter according to EN 61800-3 Category C2
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0	160 kW ... 200 kW	6SL3000-0BE33-1AA0
	6SL3310-1PE34-6AA0	250 kW	6SL3000-0BE35-0AA0
HX	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW ... 400 kW	6SL3760-0MR00-0AA0

**3.4.3 Line reactor**

The line reactor supports the overvoltage protection, smoothes the harmonics in the line supply and bridges commutation dips. For the Power Modules subsequently listed, a line reactor is suitable in order to dampen the specified effects.

Adjacent examples of line reactors.



NOTICE
<p><b>Damage to the inverter as a result of a missing line reactor</b></p> <p>Depending on the Power Module and line supply, if a line reactors is not used, this can result in damage to the inverter and other components in the electrical plant or system.</p> <ul style="list-style-type: none"> <li>• PM240 or PM240-2: Install a line reactor if the relative short-circuit voltage of the line supply is below 1%</li> <li>• PM330: You must install a line reactor dependent on the relative short-circuit power (fault level) of the line supply. You can find additional information in Catalog D35.</li> </ul>

## Line reactors for PM240

Power Module		Power	Line reactor
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0	0.37 kW ... 0.55 kW	6SE6400-3CC00-2AD3
	6SL3224-0BE17-5UA0, 6SL3224-0BE21-1UA0	0.75 kW ... 1.1 kW	6SE6400-3CC00-4AD3
	6SL3224-0BE21-5UA0	1.5 kW	6SE6400-3CC00-6AD3
FSB	6SL3224-0BE22-2□A0, 6SL3224-0BE23-0□A0	2.2 kW ... 3.0 kW	6SL3203-0CD21-0AA0
	6SL3224-0BE24-0□A0	4.0 kW	6SL3203-0CD21-4AA0
FSC	6SL3224-0BE25-5□A0, 6SL3224-0BE27-5□A0	7.5 kW ... 11.0 kW	6SL3203-0CD22-2AA0
	6SL3224-0BE31-1□A0	15.0 kW	6SL3203-0CD23-5AA0
	FSD	6SL3224-0BE31-5□A0, 6SL3224-0BE31-8□A0	18.5 kW ... 22 kW
6SL3224-0BE32-2□A0		30 kW	6SL3203-0CD25-3AA0
FSE		6SL3224-0BE33-0□A0, 6SL3224-0BE33-7□A0	37 kW ... 45 kW
FSF	6SL3224-0BE34-5□A0, 6SL3224-0BE35-5□A0	55 kW ... 75 kW	6SE6400-3CC11-2FD0
	6SL3224-0BE37-5□A0	90 kW	6SE6400-3CC11-7FD0
	6SL3224-0BE38-8UA0	110 kW	6SL3000-0CE32-3AA0
	6SL3224-0BE41-1UA0	132 kW	6SL3000-0CE32-8AA0
GX	6SL3224-0XE41-3UA0	160 kW	6SL3000-0CE33-3AA0
	6SL3224-0XE41-6UA0, 6SL3224-0XE42-0UA0	200 kW ... 250 kW	6SL3000-0CE35-1AA0

## Line reactors for PM240-2, 200 V

Power Module		Power	Line reactor
FSA	6SL3210-1PB13-0□L0, 6SL3210-1PB13-8□L0	0.55 kW ... 0.75 kW	6SL3203-0CE13-2AA0
FSB	6SL3210-1PB15-5□L0, 6SL3210-1PB17-4□L0, 6SL321□-1PB21-0□L0	1.1 kW ... 2.2 kW	6SL3203-0CE21-0AA0
FSC	6SL3210-1PB21-4□L0, 6SL321□-1PB21-8□L0	3 kW ... 4 kW	6SL3203-0CE21-8AA0
	6SL321□-1PC22-2□L0, 6SL3210-1PC22-8□L0	5.5 kW ... 7.5 kW	6SL3203-0CE23-8AA0

## Line reactors for PM240-2, 400 V

Power Module		Power	Line reactor
FSA	6SL3210-1PE11-8□L1, 6SL3210-1PE12-3□L1, 6SL3210-1PE13-2□L1	0.55 kW ... 1.1 kW	6SL3203-0CE13-2AA0
FSB	6SL3210-1PE14-3□L1, 6SL321□-1PE16-1□L1, 6SL321□-1PE18-0□L1	1.5 kW ... 3 kW	6SL3203-0CE21-0AA0
FSC	6SL3210-1PE21-1□L0, 6SL3210-1PE21-4□L0, 6SL321□-1PE21-8□L0	4 kW ... 7.5 kW	6SL3203-0CE21-8AA0
	6SL3210-1PE22-7□L0, 6SL321□-1PE23-3□L0	11 kW ... 15 kW	6SL3203-0CE23-8AA0

## Line reactors for PM330

Power Module		Power	Line reactor
GX	6SL3310-1PE33-0AA0	160 kW	6SL3000-0CE33-3AA0
	6SL3310-1PE33-7AA0	200 kW	6SL3000-0CE35-1AA0
	6SL3310-1PE34-6AA0	250 kW	
HX	6SL3310-1PE35-8AA0	315 kW	6SL3000-0CE36-3AA0
	6SL3310-1PE36-6AA0	355 kW	6SL3000-0CE37-7AA0
	6SL3310-1PE37-4AA0	400 kW	

### 3.4.4 Output reactor

Output reactors reduce the voltage stress on the motor windings and the load placed on the inverter as a result of capacitive recharging currents in the cables. An output reactor is required for shielded motor cables longer than 50 m or unshielded motor cables longer than 100 m.



for PM240 FSA, FSB

for GX

#### NOTICE

##### The output reactor is damaged if the inverter pulse frequency is too high

The output reactors are designed for pulse frequencies of 4 kHz. The output reactor can overheat if the inverter is operated with pulse frequencies > 4 kHz. Excessively high temperatures damage the output reactor.

- Operate the inverter with an output reactor with a maximum pulse frequency of 4 kHz.

#### Power Module PM330 requirements:

An output reactor is required for a motor cable length longer than

- 100 m shielded
- 200 m unshielded

The maximum pulse frequency with an output reactor is 4 kHz.

#### Output reactors for PM230 Power Modules (IP20)

Power Module		Power	Output reactor
FSA	6SL3210-1NE11-3□L0, 6SL3210-1NE11-7□L0, 6SL3210-1NE12-2□L0, 6SL3210-1NE13-1□L0, 6SL3210-1NE14-1□L0, 6SL3210-1NE15-8□L0	0.37 kW ... 2.2 kW	6SL3202-0AE16-1CA0
	6SL3210-1NE17-7□L0	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3210-1NE21-0□L0, 6SL3210-1NE21-3□L0, 6SL3210-1NE21-8□L0	4.0 kW ... 7.5 kW	6SL3202-0AE21-8CA0
	6SL3210-1NE22-6□L0, 6SL3210-1NE23-2□L0, 6SL3210-1NE23-8□L0	11.0 kW ... 18.5 kW	6SL3202-0AE23-8CA0
	6SL3210-1NE24-5□L0	22 kW	6SE6400-3TC03-8DD0

## 3.4 Components for the Power Modules

Power Module		Power	Output reactor
	6SL3210-1NE26-0□L0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3210-1NE27-5□L0	37 kW	6SE6400-3TC08-0ED0
	6SL3210-1NE28-8□L0	45 kW	6SE6400-3TC07-5ED0
FSF	6SL3210-1NE31-1□L0	55 kW	6SE6400-3TC14-5FD0
	6SL3210-1NE31-5□L0	75 kW	6SE6400-3TC15-4FD0

## Output reactors for PM230 push-through Power Modules

Power Module		Power	Output reactor
FSA	6SL3211-1NE17-7□L0	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3211-1NE21-8□L0	7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3211-1NE23-8□L0	18.5 kW	6SL3202-0AE23-8CA0

## Output reactors for PM230 Power Modules (IP55/UL Type 12)

Power Module		Power	Output reactor
FSA	6SL3223-0DE13-7□A0, 6SL3223-0DE15-5□A0, 6SL3223-0DE17-5□A0, 6SL3223-0DE21-1□A0, 6SL3223-0DE21-5□A0, 6SL3223-0DE22-2□A0	0.37 kW ... 2.2 kW	6SL3202-0AE16-1CA0
	6SL3223-0DE23-0□A0	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3223-0DE24-0□A0, 6SL3223-0DE25-5□A0, 6SL3223-0DE27-5□A0,	4.0 kW ... 7.5 kW	6SL3202-0AE21-8CA0
	6SL3223-0DE31-1□A0, 6SL3223-0DE31-5□A0, 6SL3223-0DE31-8□A0	11.0 kW ... 18.5 kW	6SL3202-0AE23-8CA0
	6SL3223-0DE32-2□A0	22 kW	6SE6400-3TC03-8DD0
FSD	6SL3223-0DE33-0□A0	30 kW	6SE6400-3TC05-4DD0
	6SL3223-0DE33-7□A0	37 kW	6SE6400-3TC08-0ED0
FSE	6SL3223-0DE34-5□A0	45 kW	6SE6400-3TC07-5ED0
	6SL3223-0DE35-5□A0	55 kW	6SE6400-3TC14-5FD0
FSF	6SL3223-0DE37-5□A0	75 kW	6SE6400-3TC15-4FD0
	6SL3223-0DE38-8□A0	90 kW	6SE6400-3TC14-5FD0

## Output reactors for PM240 Power Module

Power Module		Power	Output reactor
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0, 6SL3224-0BE17-5UA0, 6SL3224-0BE21-1UA0, 6SL3224-0BE21-5UA0	0.37 kW ... 1.5 kW	6SE6400-3TC00-4AD2
FSB	6SL3224-0BE22-2□A0, 6SL3224-0BE23-0□A0, 6SL3224-0BE24-0□A0	2.2 kW ... 4.0 kW	6SL3202-0AE21-0CA0
FSC	6SL3224-0BE25-5□A0, 6SL3224-0BE27-5□A0, 6SL3224-0BE31-1□A0	7.5 kW ... 15.0 kW	6SL3202-0AJ23-2CA0
FSD	6SL3224-0BE31-5□A0	18.5 kW	6SE6400-3TC05-4DD0
	6SL3224-0BE31-8□A0	22 kW	6SE6400-3TC03-8DD0
	6SL3224-0BE32-2□A0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3224-0BE33-0□A0	37 kW	6SE6400-3TC08-0ED0
	6SL3224-0BE33-7□A0	45 kW	6SE6400-3TC07-5ED0
FSF	6SL3224-0BE34-5□A0	55 kW	6SE6400-3TC14-5FD0
	6SL3224-0BE35-5□A0	75 kW	6SE6400-3TC15-4FD0
	6SL3224-0BE37-5□A0	90 kW	6SE6400-3TC14-5FD0
	6SL3224-0BE38-8UA0	110 kW	6SL3000-2BE32-1AA0
	6SL3224-0BE41-1UA0	132 kW	6SL3000-2BE32-6AA0
GX	6SL3224-0XE41-3UA0	160 kW	6SL3000-2BE33-2AA0
	6SL3224-0XE41-6UA0	200 kW	6SL3000-2BE33-8AA0
	6SL3224-0XE42-0UA0	250 kW	6SL3000-2BE35-0AA0

## Output reactors for PM250 Power Module

Power Module		Power	Output reactor
FSC	6SL3225-0BE25-5□A0, 6SL3225-0BE27-5□A0, 6SL3225-0BE31-1□A0	7.5 kW ... 15.0 kW	6SL3202-0AJ23-2CA0
FSD	6SL3225-0BE31-5□A0	18,5 kW	6SE6400-3TC05-4DD0
	6SL3225-0BE31-8□A0	22 kW	6SE6400-3TC03-8DD0
	6SL3225-0BE32-2□A0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3225-0BE33-0□A0	37 kW	6SE6400-3TC08-0ED0
	6SL3225-0BE33-7□A0	45 kW	6SE6400-3TC07-5ED0
FSF	6SL3225-0BE34-5□A0	55 kW	6SE6400-3TC14-5FD0
	6SL3225-0BE35-5□A0	75 kW	6SE6400-3TC15-4FD0
	6SL3225-0BE37-5□A0	90 kW	6SE6400-3TC14-5FD0

## Output reactors for PM240-2 Power Modules, 200 V

Power Module		Power	Output reactor
FSA	6SL3210-1PB13-0□L0, 6SL321□-1PB13-8□L0	0.55 kW ... 0.75 kW	6SL3202-0AE16-1CA0
	FSB	6SL3210-1PB15-5□L0	
	6SL3210-1PB17-4□L0	1.5 kW	6SL3202-0AE18-8CA0
FSB	6SL321□-1PB21-0□L0	2.2 kW	6SL3202-0AE21-8CA0
FSC	6SL3210-1PB21-4□L0, 6SL321□-1PB21-8□L0	3 kW ... 4 kW	6SL3202-0AE23-8CA0
	6SL321□-1PC22-2□L0, 6SL3210-1PC22-8□L0	5.5 kw ... 7.5 kW	

## Output reactors for PM240-2 Power Module, 400 V

Power Module		Power	Output reactor
FSA	6SL3210-1PE11-8□L1, 6SL3210-1PE12-3□L1, 6SL3210-1PE13-2□L1, 6SL3210-1PE14-3□L1, 6SL3210-1PE16-1□L1	0.55 kW ... 2.2 kW	6SL3202-0AE16-1CA0
	6SL321□-1PE18-0UL1	3 kW	
FSB	6SL3210-1PE21-1□L0, 6SL3210-1PE21-4□L0, 6SL321□-1PE21-8□L0	4 kW ... 7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3210-1PE22-7□L0, 6SL321□-1PE23-3□L0	11 kW ... 15 kW	6SL3202-0AE23-8CA0

## Output reactors for PM330 Power Module

Power Module		Power	Output reactor
GX	6SL3310-1PE33-0AA0	160 kW	6SL3000-2BE33-2AA0
	6SL3310-1PE33-7AA0	200 kW	6SL3000-2BE33-8AA0
	6SL3310-1PE34-6AA0	250 kW	6SL3000-2BE35-0AA0
HX	6SL3310-1PE35-8AA0	315 kW	6SL3000-2AE36-1AA0
	6SL3310-1PE36-6AA0	355 kW	6SL3000-2AE38-4AA0
	6SL3310-1PE37-4AA0	400 kW	

### 3.4.5 Sine-wave filter

The sine-wave filter at the inverter output limits the voltage rate-of-rise and the peak voltages at the motor winding. The maximum permissible length of motor feeder cables is increased to 300 m.

The following applies when using a sine-wave filter:

- Operation is only permissible with pulse frequencies of 4 kHz up to 8 kHz.  
For Power Modules with a power rating starting at 110 kW and higher (as stamped on the type plates), only 4 kHz is permissible.
- The inverter power is reduced by 5%.
- The maximum output frequency of the inverter is 150 Hz at 380 V to 480 V.
- Operation and commissioning may only be performed with the motor connected, as the sine-wave filter is not no-load proof.
- An output reactor is superfluous.



for FSF

#### Sine-wave filter for PM240 Power Module

Power Module		Power	Sine-wave filter
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0, 6SL3224-0BE17-5UA0	0.37 kW ... 0.75 kW	6SL3202-0AE20-3SA0
	6SL3224-0BE21-1UA0, 6SL3224-0BE21-5UA0	1.1 kW ... 1.5 kW	6SL3202-0AE20-6SA0
FSB	6SL3224-0BE22-2□A0, 6SL3224-0BE23-0□A0	2.2 kW ... 3.0 kW	6SL3202-0AE21-1SA0
	6SL3224-0BE24-0□A0	4.0 kW	6SL3202-0AE21-4SA0
FSC	6SL3224-0BE25-5□A0	7.5 kW	6SL3202-0AE22-0SA0
	6SL3224-0BE27-5□A0, 6SL3224-0BE31-1□A0	11.0 kW ... 15.0 kW	6SL3202-0AE23-3SA0
FSD	6SL3224-0BE31-5□A0, 6SL3224-0BE31-8□A0	18.5 kW ... 22 kW	6SL3202-0AE24-6SA0
	6SL3224-0BE32-2□A0	30 kW	6SL3202-0AE26-2SA0
FSE	6SL3224-0BE33-0□A0, 6SL3224-0BE33-7□A0	37 kW ... 45 kW	6SL3202-0AE28-8SA0
FSF	6SL3224-0BE34-5□A0, 6SL3224-0BE35-5□A0	55 kW ... 75 kW	6SL3202-0AE31-5SA0
	6SL3224-0BE37-5□A0	90 kW	6SL3202-0AE31-8SA0
	6SL3224-0BE38-8UA0, 6SL3224-0BE41-1UA0	110 kW ... 132 kW	6SL3000-2CE32-3AA0
GX	6SL3224-0XE41-3UA0	160 kW	6SL3000-2CE32-8AA0
	6SL3224-0XE41-6UA0	200 kW	6SL3000-2CE33-3AA0
	6SL3224-0XE42-0UA0	250 kW	6SL3000-2CE34-1AA0

### Sine-wave filter for PM250 Power Module

Power Module		Power	Sine-wave filter
FSC	6SL3225-0BE25-5□A0	7.5 kW	6SL3202-0AE22-0SA0
	6SL3225-0BE27-5□ A0, 6SL3225-0BE31-1□A0	11.0 kW ... 15.0 kW	6SL3202-0AE23-3SA0
FSD	6SL3225-0BE31-5□A0, 6SL3225-0BE31-8□A0	18.5 kW ... 22 kW	6SL3202-0AE24-6SA0
	6SL3225-0BE32-2□A0	30 kW	6SL3202-0AE26-2SA0
FSE	6SL3225-0BE33-0□A0, 6SL3225-0BE33-7□A0	37 kW ... 45 kW	6SL3202-0AE28-8SA0
FSF	6SL3225-0BE34-5□A0, 6SL3225-0BE35-5□A0	55 kW ... 75 kW	6SL3202-0AE31-5SA0
	6SL3225-0BE37-5□A0	90 kW	6SL3202-0AE31-8SA0

### 3.4.6 dv/dt filter

#### dv/dt filter for PM330 Power Module

A du/dt filter plus VPL (Voltage Peak Limiter) limits the voltage rate of rise du/dt and the voltage peaks at the motor. A du/dt filter plus VPL allows standard motors with standard insulation and without insulated bearings to be operated at the inverter.

Power Module		Power	du/dt filter plus VPL	du/dt filter compact plus VPL
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0, 6SL3310-1PE34-6AA0	160 kW ... 250 kW	6SL3000-2DE35-0AA0	6SL3000-2DE35-0EA0
	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW ... 400 kW	6SL3000-2DE38-4AA0	6SL3000-2DE38-4EA0

### 3.4.7 Braking Module and braking resistor

The braking resistor allows loads with a high moment of inertia to be quickly braked.

Inverters with power up to 132 kW have an integrated Braking Module that controls the braking resistor.

A Braking Module is available as option for inverters with more power.

An example for a braking resistor is shown at the side.



## Braking resistors for PM240

Power Modules		Power	Braking Module	Braking resistor
FSA	6SL3224-0BE13-7UA0, 6SL3224-0BE15-5UA0, 6SL3224-0BE17-5UA0, 6SL3224-0BE21-1UA0, 6SL3224-0BE21-5UA0	0.37 kW ... 1.5 kW	---	6SE6400-4BD11-0AA0
FSB	6SL3224-0BE22-2□A0, 6SL3224-0BE23-0□A0, 6SL3224-0BE24-0□A0	2.2 kW ... 4.0 kW	---	6SL3201-0BE12-0AA0
FSC	6SL3224-0BE25-5□A0, 6SL3224-0BE27-5□A0 6SL3224-0BE31-1□A0	7.5 kW ... 15.0 kW	---	6SE6400-4BD16-5CA0
FSD	6SL3224-0BE31-5□A0, 6SL3224-0BE31-8□A0, 6SL3224-0BE32-2□A0	18.5 kW ... 30 kW	---	6SE6400-4BD21-2DA0
FSE	6SL3224-0BE33-0□A0, 6SL3224-0BE33-7□A0	37 kW ... 45 kW	---	6SE6400-4BD22-2EA1
FSF	6SL3224-0BE34-5□A0, 6SL3224-0BE35-5□A0, 6SL3224-0BE37-5□A0	55 kW ... 90 kW	---	6SE6400-4BD24-0FA0
	6SL3224-0BE38-8UA0, 6SL3224-0BE41-1UA0	110 kW ... 132 kW	---	6SE6400-4BD26-0FA0
GX	6SL3224-0XE41-3UA0	160 kW	---	6SL300-1BE31-3AA0
	6SL3224-0XE41-6UA0, 6SL3224-0XE42-0UA0	200 kW ... 250 kW	6SL3300- 1AE32-5AA0	6SL3000-1BE32-5AA0

## Braking resistors for PM240-2, 200 V

Power Module		Power	Braking resistor
FSA	6SL3210-1PB13-0□L0, 6SL3210-1PB13-8□L0	0.55 kW ... 0.75 kW	GWHS 167-60x30-K
FSB	6SL3210-1PB15-5□L0, 6SL3210-1PB17-4□L0, 6SL3210-1PB21-0□L0	1.1 kW ... 2.2 kW	GWHS 217-60x30-K
FSC	6SL3210-1PB21-4□L0, 6SL3210-1PB21-8□L0	3 kW ... 4 kW	GWHS 337-60x30-K
	6SL3210-1PC22-2□L0, 6SL3210-1PC22-8□L0	5.5 kW ... 7.5 kW	GWHS 337-120x30-K
FSD	6SL3210-1PC24-2□L0, 6SL3210-1PC25-4□L0	11 kW ... 15 kW	6SE6400-4BC18-0DA0
	6SL3210-1PC26-8□L0	18.5 kW	6SE6400-4BC21-2EA0
FSE	6SL3210-1PC28-8□L0	22 kW	
	6SL3210-1PC31-1□L0	30 kW	6SE6400-4BC22-5FA0

## Braking resistors for PM240-2, 400 V

Power Module		Power	Braking resistor
FSA	6SL3210-1PE11-8□L1, 6SL3210-1PE12-3□L1, 6SL3210-1PE13-2□L1, 6SL3210-1PE14-3□L1	0.55 kW ... 1.5 kW	6SL3201-0BE14-3AA0
	6SL321□-1PE16-1□L1, 6SL321□-1PE18-0□L1	2.2 kW ... 3.0 kW	6SL3201-0BE21-0AA0
FSB	6SL3210-1PE21-1□L0, 6SL3210-1PE21-4□L0, 6SL321□-1PE21-8□L0	4 kW ... 7.5 kW	6SL3201-0BE21-8AA0
FSC	6SL3210-1PE22-7□L0, 6SL321□-1PE23-3□L0	11 kW ... 15 kW	6SL3201-0BE23-8AA0
FSD	6SL3210-1PE23-8□L0, 6SL3210-1PE24-5□L0	18.5 kW ... 22 kW	6SE6400-4BD21-2DA0
	6SL3210-1PE26-0□L0, 6SL3210-1PE27-5□L0	30 kW ... 37 kW	6SE6400-4BD22-2EA0
FSE	6SL3210-1PE28-8□L0, 6SL3210-1PE31-1□L0	45 kW ... 55 kW	6SE6400-4BD24-0FA0

## Braking resistors for PM240-2, 690 V

Power Module		Power	Braking resistor
FSD	6SL3210-1PH21-4□L0, 6SL3210-1PH22-0□L0, 6SL3210-1PH22-3□L0, 6SL3210-1PH22-7□L0, 6SL3210-1PH23-5□L0, 6SL3210-1PH24-2□L0	11 kW ... 37 kW	type R16
FSE	6SL3210-1PH25-2□L0, 6SL3210-1PH26-2□L0	45 kW ... 55 kW	type R26

## Braking Modules and braking resistors for PM330

Power Module		Power	Braking Module	Power	Braking resistor
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0, 6SL3310-1PE34-6AA0	160 kW ... 250 kW	6SL3760- 1AE32-6AA0	50 kW	6SE7032- 5FS87-2DC0
HX	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW ... 400 kW			



### 3.5 Motor series that are supported

The inverter is designed for the following motor series:

<p><b>SIMOTICS GP, SIMOTICS SD IEC motors</b></p>  <p>1LG6, 1LA7, 1LA9 and 1LE1 standard induction motors</p> <p>Multi-motor drives are permissible, i.e. multiple motors operated on one inverter. See also: Multi-motor drive (<a href="http://support.automation.siemens.com/WW/view/en/84049346">http://support.automation.siemens.com/WW/view/en/84049346</a>).</p>	<p><b>SIMOTICS M main motors</b></p>  <p>1PH8 induction motors</p>
<p><b>SIMOTICS FD IEC motors</b></p>  <p>1LM1, 1LQ1, 1LL1 squirrel cage induction motors for inverter operation. 1LP1, 1LH1, 1LN1</p>	<p><b>SIMOTICS GP, SIMOTICS SD reluctance motors</b></p>  <p>1FP1 reluctance motors</p>
<p><b>Motors from other manufacturers</b></p> <p>Standard induction motors</p> <p>Synchronous motors (on request)</p>	

### 3.6 Tools to commission the converter

The following tools are used to commission, troubleshoot and control the inverter, as well as to back up and transfer the inverter settings.

Operator panels		Article number
 <p>BOP-2 (Basic Operator Panel) - for snapping onto the inverter</p> <ul style="list-style-type: none"> <li>Two-line display</li> <li>Guided basic commissioning</li> </ul>	 <p>Door mounting kit for IOP/BOP-2</p> <ul style="list-style-type: none"> <li>For installation of the BOP-2 or IOP in a control cabinet door.</li> <li>Degree of protection with IOP: IP54 or UL Type 12</li> <li>Degree of protection with BOP-2: IP55</li> </ul>	<p>BOP-2: 6SL3255-0AA00-4CA1</p> <p>IOP with European languages: 6SL3255-0AA00-4JA1</p> <p>IOP with Chinese: 6SL3255-0AA00-4JC1</p> <p>Door mounting kit: 6SL3256-0AP00-0JA0</p>
 <p>IOP (Intelligent Operator Panel) - for snapping onto the inverter</p> <ul style="list-style-type: none"> <li>Plain text display</li> <li>Menu-based operation and application wizards</li> </ul>		
	<p>For mobile use of the IOP: IOP handheld with power supply unit and rechargeable batteries as well as RS232 connection cable</p> <p>If you are using your own connection cable, carefully note the maximum permissible length of 5 m.</p>	6SL3255-0AA00-4HA0
PC tools		
  <p>You can access the inverter with STARTER or Startdrive either via a USB connection or via PROFIBUS/PROFINET.</p>	<p>STARTER</p> <p>System requirements and download: STARTER (<a href="http://support.automation.siemens.com/WW/view/en/26233208">http://support.automation.siemens.com/WW/view/en/26233208</a>)</p> <p>Help regarding operation: STARTER videos (<a href="http://www.automation.siemens.com/mcms/mc-drives/en/low-voltage-inverter/sinamics-g120/videos/Pages/videos.aspx">http://www.automation.siemens.com/mcms/mc-drives/en/low-voltage-inverter/sinamics-g120/videos/Pages/videos.aspx</a>)</p>	<p>STARTER on DVD: 6SL3072-0AA00-0AG0</p>
	<p>Startdrive</p> <p>System requirements and download: Startdrive (<a href="http://support.automation.siemens.com/WW/view/en/68034568">http://support.automation.siemens.com/WW/view/en/68034568</a>)</p> <p>Help regarding operation: Tutorial (<a href="http://support.automation.siemens.com/WW/view/en/73598459">http://support.automation.siemens.com/WW/view/en/73598459</a>)</p>	<p>Startdrive on DVD: 6SL3072-4CA02-1XG0</p>
	<p>SINAMICS PC Inverter Connection Kit 2</p> <p>Contains the correct USB cable (3 m) to connect a PC to the inverter.</p>	6SL3255-0AA00-2CA0

## Installing

### 4.1 Overview of the inverter installation

#### Installing the inverter

##### Precondition

Before installation, please check:


- Are the required inverter components available?
  - Power Module
  - Control Unit
  - Accessories, e.g. line reactor or braking resistor
- Do you have the necessary tools and small parts/components required to install the inverter?

##### Procedure



To install the inverter, proceed as follows:

1. Install the accessories (reactors, filter or braking resistor) for the Power Module:
  - Installing reactors, filters and braking resistors (Page 54).
2. Install the Power Module.
  - Installing Power Modules (Page 56).
3. Install the Control Unit.
  - Installing Control Unit (Page 79).



- You have installed all of the inverter components, and you can now commission the inverter.

## 4.2 Connecting inverters in compliance with EMC

### 4.2.1 EMC-compliant connection of the converter

EMC-compliant installation of the inverter and motor are required in order to ensure disturbance-free operation of the drive.

Install and operate inverters with IP20 degree of protection in a closed control cabinet.

Inverters with degree of protection IP55 are suitable for installation outside a control cabinet.

An overview of control cabinet installation and cabling can be found in the following section. For further details, refer to the installation instructions of the Power Module.

The EMC-compliant connection of the inverter itself is described in the following sections.

### 4.2.2 Avoiding electromagnetic influence (EMI)

The inverters are designed for operation in industrial environments where high values of EMI are expected. Safe, reliable and disturbance-free operation is only guaranteed if the devices are installed by appropriately trained and qualified personnel.

#### Control cabinet design

- Connect the metallic parts and components of the control cabinet to the frame of the cabinet through a good electrical connection.
  - Side panels
  - Rear panels
  - Cover plate
  - Base plates

Use the largest possible contact area or many individual screw connections.

- Connect the PE busbar and EMC shielding bus to the control cabinet frame using a good electrical connection established through the largest possible surface area.
- Connect all metal enclosures of the devices installed in the control cabinet (such as the inverter and line filter) to the control cabinet frame through a good electrical connection established through the largest possible surface area.

We recommend that these devices are mounted on a bare metal plate with good conducting properties.

- For screw connections onto painted or anodized surfaces, establish a good conductive contact using one of the following methods:
  - Use special (serrated) contact washers that cut through the painted or anodized surface.
  - Remove the insulating coating at the contact locations.
- Equip the following components with interference suppression elements:
  - Coils of contactors
  - Relays
  - Solenoid valves
  - Motor holding brakes

Interference suppression elements include RC elements or varistors for AC-operated coils and freewheeling diodes for DC-operated coils.

Connect the interference suppression element directly at the coil.

### Cable routing and shielding

- Route all inverter power cables (line supply cables, connecting cables between the braking module and the associated braking resistance as well as the motor cables) separately away from signal and data cables. Maintain a minimum clearance of 25 cm. If cables can be separately routed, use metal partitions that have a good electrical connection to the mounting plate.
- Route the cables from the line supply to the line filter separately away from the following cables:
  - Cables between the line filter and inverter
  - Connecting cables between the braking module and associated braking resistor
  - Motor cables
- Signal and data cables as well as filtered line supply cables may only cross non-filtered power cables at right angles.
- Keep all cables as short as possible.
- Always route signal lines, data cables, and the associated potential equalizing cables in parallel with the shortest possible clearance between them
- Use shielded motor cables.
- Route the shielded motor cable separately from the cables to the motor temperature sensors (PTC/KTY).
- Use shielded signal and data cables.
- Connect the shields to the grounded enclosure at both ends with a good electrical connection through the largest possible surface area
- Connect the cable shields as closely as possible to the point where the cable enters the control cabinet.

*4.2 Connecting inverters in compliance with EMC*

- Use EMC shielded busbars for power cables.  
Use the shield connection elements in the inverter for signal and data cables.
- Do not interrupt any cable shields by using intermediate terminals.
- Use the appropriate EMC terminals for cable shields.  
The EMC terminals connect the cable shield with the EMC shielded busbar or with the shield connection element through a large conductive surface.

**Further information**

You can find additional information about the EMC installation guidelines on the Internet:  
EMC installation guideline (<http://support.automation.siemens.com/WW/view/en/60612658>).

### 4.2.3 Amount the shield plate onto the Power Module

#### Shielding with shield plate:

Connect the cable shields to the shield plate through the largest possible surface area using shield clamps.

Depending on the particular Power Module, the shield plate is included in the scope of delivery, or is optionally available as shield connection kit. You can find additional information in Catalogs D11.1 and D35).

#### Shielding without shield plate:

- EMC-compliant shielding can also be implemented without using a shield plate. In this case, you must ensure that the cable shields are connected to the ground potential through the largest possible surface area.

#### Mounting the shield plate, PM230




Figure 4-1 Mounting the shield plate, FSA ... FSC





Figure 4-2 Mounting the shield plate, FSD ... PSF

Example of EMC-compliant wiring with a PM240 Power Module



The terminal cover is not shown in the diagram, so that it is easier to see how the cable is connected.

- ① Line connection cable (unshielded) for Power Modules with integrated line filter.  
If you use an external line filter, you will need a shielded cable between the line filter and the Power Module.
- ② Strain relief
- ③ Line supply connection
- ④ Metal mounting plate (unpainted and with a good electrical conductivity)
- ⑤ Motor connection
- ⑥ Cable shield
- ⑦ Cable clamps for establishing the connection between the shield and the mounting plate through a large surface area
- ⑧ Motor connection cable (shielded)
- ⑨ Shield plate (option)

Figure 4-3 EMC-compliant wiring of a Power Module frame size E as example




Figure 4-4 Shield connection - detail

### EMC-compliant wiring of Power Modules in degree of protection IP55 / UL type 12

The following diagram shows the EMC-compliant installation of Power Modules with degree of protection IP55 / UL type 12.




Figure 4-5 EMC-compliant connection of the Power Module PM230, degree of protection IP55 / UL Type 12

#### Note

You must use a shielded cable if you use the control terminals of the Control Unit. Connect the shield to the gland plate via an EMC screw.

## 4.3 Installing reactors, filters and braking resistors

### Installing reactors, filters and braking resistors

The following supplementary components may be required depending on the Power Modules and the particular application:

- Line reactors
- Filter
- Braking resistors
- Brake Relay

Installing these components is described in the documentation provided. See also Section: Manuals and technical support (Page 451).

### Installing a base component

Reactors, filters and braking resistors are available as base components for the PM240 and PM250 Power Modules, frame sizes FSA, FSB and FSC. You can also install base components next to Power Modules.




Figure 4-6 Available base components

## Installing two base components

You can combine up to two base components. The permissible combination depends on the particular base components and the inverter frame size.





Figure 4-7 Permissible combinations of two base components

## 4.4 Installing Power Modules

### Installing Power Modules

The following is required to correctly install a Power Module:

- Install the Power Module in a control cabinet.
- Install the Power Modules vertically with the line and motor connections facing downwards.



- Comply with the installation regulations specified in the following sections:
  - Minimum clearances to other components
  - Fixing elements
  - Tightening torques for fixing elements

### Installing Power Modules using push-through technology

We recommend that you use the optional mounting frames when installing the Push-Through device in a control cabinet. This mounting frame includes the necessary seals and frame to ensure compliance with degree of protection IP54.

If you do not use the optional mounting frames, then you must ensure that the required degree of protection is complied with using other appropriate measures.

You must mount the inverter on unpainted metal surfaces in order to comply with EMC requirements.

### Procedure




1 Proceed as follows to correctly install the Power Module:

2

1. Prepare the cutout and the mounting holes for the Power Module and the mounting frame corresponding to the dimension drawings of the mounting frame.

Also note that the PT Power Modules must be vertically mounted with the line and motor connections facing downwards.

2. Position the mounting frame at the rear of the control cabinet and attach it to the control cabinet by tightening the corresponding screws by hand.
3. Attach the seal to the inner side of the control cabinet.
4. Fix the inverter, and first tighten all of the fixing screws by hand.
5. Tighten the screws with a torque of 3.5 Nm.



Mounting frame

- You have correctly installed the Power Module.

4.4.1 Dimensions, hole drilling templates, minimum clearances, tightening torques

Dimensions and drilling patterns for the PM230 Power Modules, IP55




Table 4- 1 Dimensions

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height)	c (depth) <sup>1)</sup>	d	e	f
FSA	154	460	249	132	445	11
FSB	180	540	249	158	524	11
FSC	230	620	249	208	604	11
FSD	320	640	329	285	600	17.5
FSE	320	751	329	285	710	17.5
FSF	410	915	416	370	870	17.5







- 1) Depth with
  - BOP-2/blanking cover + 7 mm;
  - IOP + 17 mm

Table 4- 2 Mounting hardware and clearances to other devices

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)		
			Top	Bottom	Lateral
FSA, FSB	M4 screws	2.5	100	100	0 <sup>1)</sup>
FSC	M5 screws	2.5	125	125	0 <sup>1)</sup>
FSD, FSE, FSF	M8 screws	13	300	300	50 <sup>2)</sup>

- 1) Mounting and operation are permissible without lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.
- 2) Mounting up to an ambient temperature of 40 °C in operation without lateral clearance is permissible. For tolerance reasons, we recommend a clearance of approx. 1 mm.

Dimensions and drilling patterns for Power Modules with IP20 degree of protection

Defining the dimensions:	Drilling patterns for the PM230 and PM240-2 Power Modules:	
	<p>FSA</p> 	<p>FSB ... FSF</p> 
Drilling patterns for the PM240, PM250, and PM260 Power Modules:		
<p>FSA</p> 	<p>FSB...FSF</p> 	<p>GX</p> 

Dimensions and drilling patterns for the PM330 Power Modules:




Table 4- 3 Dimensions of the PM230, without/with integrated filter

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	d	e	f
FSA	73	196	165	62,3	186	6
FSB	100	292	165	80	281	6
FSC	140	355	165	120	343	6
FSD	275	419/512	204	235	325/419	11
FSE	275	499/635	204	235	405/451	11
FSF	350	634/934	316	300	598/899	11

- 1) with shield connection kit:  
FSA: + 80 mm; FSB: + 78 mm; FSC: + 77 mm; FSD, FSE, FSF: + 123 mm
- 2) Total depth of the inverter: See below.

Table 4- 4 Mounting hardware and clearances to other devices for PM230

Frame size	Hardware	Tightening torque (Nm)	Cooling air clearances (mm)			
			Top	Bottom	Lateral	Front
FSA, FSB	M4 screws	2,5	80	100	0 <sup>1)</sup>	---
FSC	M5 screws	3	80	100	0 <sup>1)</sup>	---
FSD, FSE	M6 screws	6	300	300	0 <sup>1)</sup>	100
FSF	M8 screws	13	350	350	0 <sup>1)</sup>	100

- 1) mounting without lateral clearance is permissible. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

Table 4- 5 Dimensions for PM330

Frame size	a (width)	b (height)	c (depth)	x
GX	452 mm	1402 mm	328 mm	45 mm
HX	548 mm	1660 mm	393 mm	37 mm

Table 4- 6 Mounting hardware and clearances to other devices for PM330

Frame size	Stock	Tightening torque (Nm)	Clearances (mm)			
			Top <sup>1)</sup>	Bottom <sub>1)</sub>	Lateral	Front
GX	M8 screws	15	200	200	30	30
HX	M8 screws	15	200	200	30	30

<sup>1)</sup> From enclosure upper or lower edge (dimension b)

Table 4- 7 Dimensions for PM240, without/with integrated filter

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	d	e	f
FSA	73	196	165	---	186	6
FSB	153	270	165	133	258	6
FSC	189	334	185	167	323	6
FSD	275	419/512	204	325/419	235	11
FSE	275	499/635	204	405/541	235	11
FSF	350	634/934	316	598/899	300	11
GX	326	1533	547	1506	125	14.5

<sup>1)</sup> with shield connection kit:

FSA: + 80 mm; FSB: + 78 mm; FSC: + 77 mm; FSD, FSE, FSF: + 123 mm

<sup>2)</sup> Total depth of the inverter: See below.

Table 4- 8 Mounting hardware and clearances to other devices for PM240

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)		
			Top	Bottom	Lateral
FSA	M4 screws	2.5	100	100	30 <sup>1)</sup>
FSB	M4 screws	2.5	100	100	40 <sup>1)</sup>
FSC	M5 screws	3	80	100	50 <sup>1)</sup>
FSD, FSE	M6 screws	6	300	300	0 <sup>2)</sup>
FSF	M8 screws	13	350	350	0 <sup>2)</sup>
GX	M8 screws	13	250	150	50

- 1) Can be mounted without any lateral clearance for ambient temperatures of up to 40 °C in operation. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.
- 2) Mounting and operation are permissible without lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.

Table 4- 9 Dimensions for PM240-2

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	d	e	f
FSA	73	196	165	62.3	186	6
FSB	100	292	165	80	281	6
FSC	140	355	165	120	343	6
FSD	200	420	235	170	400	10
FSE	275	500	235	240	475	10

- 1) With shield connection kit: FSA: + 80 mm; FSB: + 78 mm; FSC: + 77 mm
- 2) Total depth of the inverter: See below.

Table 4- 10 Mounting hardware and clearances to other devices for PM240-2

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)			
			Top	Bottom	Lateral	Front
FSA, FSB	M4 screws	2.5	80	100	0 <sup>1)</sup>	0 <sup>2)</sup>
FSC	M5 screws	3.0	80	100	0 <sup>1)</sup>	0 <sup>2)</sup>
FSD	M5 screws	3.0	300	350	0 <sup>1)</sup>	100
FSE	M6 screws	6.0	300	350	0 <sup>1)</sup>	100

- 1) Mounting and operation are permissible without lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.
- 2) Maintain sufficient clearance for the Control Unit and the operator panel.

Table 4- 11 Dimensions for PM250, with/without integrated filter

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	d	e	f
FSC	189	334	185	167	323	6
FSD	275	419/512	204	325/419	235	11
FSE	275	499/635	204	405/541	235	11
FSF	350	634/934	316	598/899	300	11

1) With shield connection kit: FSC: + 77 mm; FSD...FSF: + 123 mm

2) Total depth of the inverter: See below.

Table 4- 12 Mounting hardware and clearances to other devices for PM250

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)		
			Top	Bottom	Lateral
FSC	M5 screws	3	80	100	50 <sup>1)</sup>
FSD, FSE	M6 screws	6	300	300	0 <sup>2)</sup>
FSF	M8 screws	13	350	350	0 <sup>2)</sup>

1) Can be mounted without any lateral clearance for ambient temperatures of up to 40 °C in operation. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

2) Mounting and operation are permissible without lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.

Table 4- 13 Dimensions for PM260, without/with integrated filter

Frame size	Dimensions (mm)			Drilling dimensions		
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	d	e	f
FSD	275	419/512	204	325/419	235	11
FSF	350	634/934	316	598/899	300	11

1) With shield connection kit: + 123 mm

2) Total depth of the inverter: See below.

Table 4- 14 Mounting hardware and clearances to other devices for PM260

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)		
			Top	Bottom	Lateral
FSD	M6 screws	6	300	300	0 <sup>1)</sup>
FSF	M8 screws	13	350	350	0 <sup>1)</sup>

1) Mounting and operation are permissible without any lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.

Dimensions and drilling patterns for Power Modules with through-hole technology




Table 4- 15 Dimensions for PM230 in push-through technology

Frame size	Dimensions (mm)					Drilling dimensions (mm)			Cabinet cutout (mm)	
	a (width)	b (height) <sup>1)</sup>	c (depth) <sup>2)</sup>	T1	T2	e	d	f	g	h
FSA	126	238	171	118	54	103	106	27	88	198
FSB	154	345	171	118	54	147,5	134	34,5	116	304
FSC	200	411	171	118	54	123	174	30,5	156	365

1) With shield connection kit: FSA: +84 mm; FSB: +85 mm; FSC: +89 mm

3) Total depth of the inverter: See below.

Table 4- 16 Mounting hardware and clearances to other devices for PM230 in push-through technology

Frame size	Hardware	Tightening torque (Nm)	Cooling air clearances (mm)		
			Top	Bottom	Lateral
FSA, FSB, FSC	M5 screws	3	80	100	0 <sup>1)</sup>

1) mounting without lateral clearance is permissible. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

Table 4- 17 Dimensions for PM240-2 in push-through technology

Frame size	Dimensions (mm)					Drilling dimensions (mm)			Cabinet cutout (mm)	
	a (width)	b (height) <sup>1</sup> )	c (depth) <sup>2</sup>	T1	T2	e	d	f	g	h
FSA	126	238	171	118	54	103	106	27	88	198
FSB	154	345	171	118	54	147.5	134	34.5	116	304
FSC	200	411	171	118	54	123	174	30.5	156	365

<sup>1)</sup> With shield connection kit: FSA: +84 mm; FSB: +85 mm; FSC: +89 mm

<sup>3)</sup> Total depth of the inverter: See below.


Table 4- 18 Mounting hardware and clearances to other devices for PM240-2 in push-through technology

Frame size	Hardware	Tightening torque (Nm)	Clearances (mm)		
			Top	Bottom	Lateral
FSA, FSB, FSC	M5 screws	3	80	100	0 <sup>1)</sup>

<sup>1)</sup> Mounting and operation are permissible without lateral clearance. For tolerance reasons we recommend a lateral clearance of approx. 1 mm.

**Total depth of the inverter**

**Power Modules frame sizes FSA ... FSF**



- ① Power Module
- ② Control Unit
- ③ Intelligent Operator Panel IOP
- ④ Base components: Filters, reactors or braking resistors

① + ②

As a minimum, the inverter comprises a Power Module and an inserted Control Unit:

Overall depth of the inverter = depth of the Power Module + 60 mm (Control Unit)

① + ② + ③

Inverter with inserted operator panel:

- Overall depth of the inverter = depth of the Power Module + 73 mm (Control Unit + Basic Operator Panel BOP-2)
- Overall depth of the inverter = depth of the Power Module + 82 mm (Control Unit + Intelligent Operator Panel IOP)

① + ② + ③ + ④

Power Module (degree of protection IP20) on a base component:

The overall inverter depth increases by the depth of the base component.

**Power Modules with power ratings from 160 kW (GX)**

For Power Modules with power above 160 kW, the depth of the Power Module corresponds to the overall depth of the inverter.

**4.4.2 Digital inputs and outputs on the PM330 Power Module**

The PM330 Power Module has 4 additional digital inputs and 2 additional digital outputs at terminal strip X9. All of the terminals have a certain function in the factory setting.

Terminal strip X9 is used to connect an external 24 V DC power supply and to connect a main or bypass contactor.

Fault and alarm signals can be connected to the digital inputs. The digital output allows, for example, an external rectifier to be controlled.

The external 24 V DC power supply must be connected if the inverter is connected to the line supply via a main contactor (to start the Control Unit).

The power supply should be located directly next to the inverter (e.g. in the same cabinet) and the cable length to terminal X9 should not exceed 5 m.

Terminal	Name	Meaning	In-put/output	Technical data
1	P24	External power supply	Input	24 V DC (20.1 ... 28.8 V)
2	M	Electronics ground	Reference	Current consumption: max. 2 A
3	External alert	External alarm	Input	Voltage: -3 V ... +30 V
4	External fault	External fault	Input	Current drain:
5	Stop 0	Emergency Stop, Category 0	Input	6.4 mA at 24 V DC 1.3 mA at <5 V
6	Stop 1	Emergency Stop category 1	Input	4 mA at >15 V 8 mA at 30 V Level (including ripple): High level: 15 V ... 30 V Low level: -3 V ... +5 V
7	M		Reference	
8	DC link charged	Enable signal "U <sub>DC</sub> link charged"	Output	Voltage: 24 V DC Max. load current: 500 mA Continuously short-circuit proof The output current is taken from the supply at X9, terminal 1.
9	NC	Not connected		
10	NC	Not connected		
11	Activation line contactor	Line contactor control	Output	Contact type: NO contact Maximum load current: 4 A, 230 V AC, cosφ = 0.6
12	Activation line contactor	Line contactor control	Output	Floating A device to protect against overload and short-circuit is required to supply the unprotected output. Surge suppressors must be connected to the excitation coil of the main contactor (e.g. RC element). To control the main contactor, the following contact characteristic values of the relay according to UL apply: <ul style="list-style-type: none"> <li>• 250 V AC, 10 A (NC and NO), general purpose, 85 °C,</li> <li>• 24 V DC, 10 A (NC and NO), general purpose, 85 °C,</li> <li>• 30 V DC, 8 A (NO), 6 A (NC), general purpose, 85 °C</li> <li>• B300 (NC and NO), pilot duty, 85 °C</li> <li>• R300 (NC and NO), pilot duty, 85 °C</li> <li>• 24 V AC, 2.0 A (NC and NO), pilot duty, 85 °C</li> </ul>

Maximum connection cross section: 2.5 mm<sup>2</sup>

Minimum connection cross section: 0.2 mm<sup>2</sup>

Maximum tightening torque: 0.5 Nm (4.5 ... 5 lb.in)

---

**Note**

**Inputs are low active.**

All signal inputs are low active (wire-break-proof).

---

---

**Note**

If terminals 3 ... 6 are not used, then you must connect 24 V DC to these.  
To do this, use an external power supply or terminal 9 on the Control Unit.

The reference potential is connected to terminal X9:2, 7 and terminal 28 on the Control Unit.

---

---

**Note**

**Line contactor control**

When supplying the main contactor via terminals 11 and 12, separation from the line supply using a control transformer is not required. A 250 V/8 A fuse in compliance with UL must be used as protection.

---

---

**Note**

**Insulated end sleeves**

Insulated end sleeves according to DIN 46228-4 must be used.

---

## 4.5 Connecting the line supply, motor and converter components

### 4.5.1 Permissible line supplies

---

**Note****Restrictions for installation altitudes above 2000 m**

Above an installation altitude of 2000 m, the permissible line supplies are restricted. See also: Restrictions for special ambient conditions (Page 428).

---

**Note****Line requirement**

The machine manufacturer must ensure that in operation the voltage drop between the transformer input terminals and the inverter with rated values is less than 4 %.

---

The inverter is designed for the following power distribution systems according to IEC 60364-1 (2005).

**TN line system**

A TN line system transfers the PE protective conductor to the installed plant or system using a cable.

Generally, in a TN line system the neutral point is grounded. There are versions of a TN line supply with a grounded line the conductor, e.g. with grounded L1.

A TN line system can transfer the neutral conductor N and the PE protective conductor either separately or combined.

**Inverter operated on a TN line system**

- Inverter with integrated or external line filter:
  - Operation on TN line systems with grounded neutral point permissible.
  - Operation on TN line systems with grounded line conductor not permissible.
- Inverter without line filter:
  - Operation on all TN line systems  $\leq 600$  V permissible
  - Operation on TN line systems  $> 600$  V and grounded neutral point permissible.
  - Operation on TN line systems  $> 600$  V and grounded line conductor not permissible.

**Examples for Power Modules connected to a TN line supply**




Figure 4-8 TN line supply with separate transfer of N and PE and with a grounded neutral point

## TT line system

In a TT line system, the transformer grounding and the installation grounding are independent of one another.

There are TT line supplies where the neutral conductor N is either transferred – or not.

### Inverter operated on a TT line system

- Inverter with integrated or external line filter:
  - Operation on TT line systems with grounded neutral point permissible.
  - Operation on TT line systems without grounded neutral point not permissible.
- Inverter without line filter:
  - Operation on all TT line systems permissible.

### Examples for Power Modules connected to a TT line supply




Figure 4-9 TT line system with neutral conductor N and with grounded neutral point

## IT system

In an IT line system, all of the conductors are insulated with respect to the PE protective conductor – or connected to the PE protective conductor through an impedance.

There are IT line supplies where the neutral conductor N is either transferred – or not.

### Inverter operated on an IT line system

- Inverters with integrated line filter:
  - Operation on IT line systems not permissible.
- Inverter without line filter:
  - Operation on all IT line systems permissible.

### Example of a Power Module connected to an IT line system




Figure 4-10 IT line supply where the neutral conductor N is transferred and with impedance with respect to the PE protective conductor

### Behavior of the inverter when a ground fault occurs

In some instances, even for a ground fault, the inverter should still remain functional. In cases such as these, you must install an output reactor. This prevents an overcurrent trip or damage to the drive.

### Special measures for PM330 Power Modules

When connected to an IT line supply, you must open the connection to the basic interference suppression board of the Power Module. You can find additional information on the Internet: Hardware installation manual for PM330 Power Modules (<https://support.industry.siemens.com/cs/ww/en/view/90580072/64282054155>).

### 4.5.2 Connecting the inverter




Figure 4-11 Connecting the PM230 IP20 and push-through Power Module




Figure 4-12 Connecting the PM230 IP55 Power Module




Figure 4-13 Connecting the PM240, PM240-2 IP20 and push-through Power Modules

4.5 Connecting the line supply, motor and converter components

PM240 and PM240-2 Power Modules are available with and without integrated Class A line filters. For higher EMC requirements you need an external Class B line filter.




Figure 4-14 Connecting the PM250 Power Module




Figure 4-15 Connecting the PM260 Power Module




Figure 4-16 Connecting the PM330 Power Module



 <b>DANGER</b>
-------------------------------------------------------------------------------------------------

<b>Danger to life as a result of a hazardous voltage at the motor connections</b>
-----------------------------------------------------------------------------------

<p>As soon as the inverter is connected to the line supply, the motor connections of the inverter may carry dangerous voltages. When the motor is connected to the inverter, there is danger to life through contact with the motor terminals if the terminal box is open.</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

- |                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>• Close the terminal box of the motor before connecting the inverter to the line supply.</li> </ul> |
|--------------------------------------------------------------------------------------------------------------------------------------------|

### Connecting the line supply cable to the converter

#### Procedure



1  
2

To connect the converter to the supply system, proceed as follows:

1. If available, open the terminal covers of the converter.
2. Connect the line supply to terminals U1/L1, V1/L2, and W1/L3.
3. Connect the protective conductor of the line supply to terminal PE of the converter.
4. If available, close the terminal covers of the converter.



You have connected the line supply cable to the converter.

### Connecting the motor cable to the converter

#### Procedure



1  
2

To connect the motor cable to the converter, proceed as follows:

1. If available, open the terminal covers of the converter.
2. Connect the motor to terminals U2, V2, and W2.  
Carefully observe the regulations for EMC-compliant wiring:  
Connecting inverters in compliance with EMC (Page 48)
3. Connect the protective conductor of the motor to the  terminal of the converter.
4. If available, close the terminal covers of the converter.



You have therefore connected the motor line to the converter.

### Connecting a motor cable to an induction motor

**Procedure**



To connect the motor cable to an induction motor proceed as follows:

1. Open the motor terminal box.
2. Connect the motor in either a star or delta connection.
3. If you are using a shielded motor cable, you must do the following:
  - Expose the shield of the motor cable in the area of the cable entry in the terminal box.
  - Attach the cable shield to the motor terminal box using a suitable screw connection.
4. Close the motor terminal box.



You have connected the motor cable to the induction motor.

Depending on your application, you can operate the motor in the star or delta connection (Y/ $\Delta$ ).

**Examples for operating the converter and motor on a 400 V line supply**

Assumption: The motor rating plate states 230/400 V  $\Delta$ /Y.

Case 1: A motor is normally operated between standstill and its rated speed (i.e. a speed corresponding to the line frequency). In this case, you need to connect the motor in Y. Operating the motor above its rated speed is only possible in field weakening, i.e. the motor torque available is reduced above the rated speed.

Case 2: If you want to operate the motor with the "87 Hz characteristic", you need to connect the motor in  $\Delta$ .


With the 87 Hz characteristic, the motor's power output increases. The 87 Hz characteristic is mainly used with geared motors.

Before you connect the motor, ensure that the motor has the appropriate connection for your application:

### Motor is connected in the star or delta configuration

With SIEMENS motors, you will see a diagram of both connection methods on the inside of the cover of the terminal box:

- Star connection (Y)
- Delta connection ( $\Delta$ )



## 4.5.3 Connecting a braking resistor


**! WARNING**

Danger to life due to fire spreading because of an unsuitable or improperly installed braking resistor

Fire and smoke development can cause severe personal injury or material damage.

Using an unsuitable braking resistor can cause fires and smoke to develop. Possible consequences are severe personal injury or material damage.

- Only use braking resistors that are approved for the inverter.
- Install the braking resistor in accordance with regulations.
- Monitor the temperature of the braking resistor.


**! CAUTION**
**Risk of burns due to touching hot surfaces**

The temperature of braking resistors increases substantially during operation.

- Do not touch the braking resistor during operation.

**Procedure**


1 To connect the braking resistor and monitor the temperature of the braking resistor, proceed as follows:

1. Connect the braking resistor to terminals R1 and R2 of the inverter.
2. Ground the braking resistor directly to the control cabinet's grounding bar. The braking resistor must not be grounded via the PE terminals on the inverter.
3. If you have to fulfill EMC requirements, observe the rules for shielding.




Figure 4-17 Braking resistor directly connected to the inverter (example: temperature monitoring via DI 3)

4.5 Connecting the line supply, motor and converter components

4. Connect the temperature monitoring of the braking resistor (terminals T1 and T2 at the braking resistor) to a free digital input in the inverter.
5. When commissioning the inverter, define the function this digital input as external fault.

■ You have connected the braking resistor and ensured that temperature monitoring is set up.

**Connecting a braking resistor to a PM330 Power Module**

To connect a braking resistor to a PM330 Power Module, you require an external Braking Module.

- Connect Braking Module at the DCP and DCN terminals of the Power Module.
- Connect the external braking resistor at terminals G and H of the Braking Module.

You can find additional information on the Internet: Hardware installation manual for PM330 Power Modules

(<https://support.industry.siemens.com/cs/ww/en/view/90580072/64282054155>).

## 4.6 Installing Control Unit


### Plugging the Control Unit onto an IP20 Power Module FSA ... FSF

#### Procedure



1 Proceed as follows to plug the Control Unit onto a Power Module:

1. Locate the lugs at the rear of the Control Unit in the matching recesses of the Power Module.
2. Press the Control Unit onto the Power Module until you hear it latch into place.




- You have now plugged the Control Unit onto the Power Module.

To remove the Control Unit, press on the release button on the Power Module and withdraw the Control Unit.

### Plugging the Control Unit onto a PM330 Power Module

To plug the Control Unit onto a PM330 Power Module, you must open the left-hand housing flap of the Power Module.

Press the release button on the Power Module to withdraw the Control Unit.



**Note**

**Failure of the inverter as a result of the Control Unit overtemperature**

The Control Unit can overheat when the housing flap is open in operation. To protect itself against damage, the Control Unit switches off the drive when an overtemperature condition occurs.

- When the inverter is operational, close the housing flap of the Power Module.


**Installing a Control Unit in an IP55 Power Module FSA ... FSC**



**1 Procedure**

Proceed as follows to install a Control Unit in a IP55 Power Module FSA ... FSC:

1. Release the screws that are used to retain the cover of the Power Module.
2. Remove the cover.
3. Locate the lugs at the rear of the Control Unit in the matching recesses of the Power Module.
4. Mount the Control Unit onto the Power Module so that it audibly snaps into place.



5. Wire the Control Unit and the Power Module.
6. Insert the adapter to extend the interface to the operator panel into the Control Unit.
7. Attach the cover to the Power Module. Ensure that none of the seals are damaged in order to guarantee the IP55 degree of protection.
8. Tighten the fixing screws of the cover with a torque of 1.5 Nm.

■ You have installed a Control Unit in an IP55 Power Module FSA ... FSC.

To remove the Control Unit from the Power Module, with the cover removed, press the release lever.


## Installing a Control Unit in an IP55 Power Module FSD ... FSF

### Procedure




Proceed as follows to install a Control Unit in a IP55 Power Module FSD ... FSF:

1. Open the Power Module door using the key supplied.
2. Locate the lugs at the rear of the Control Unit in the matching recesses of the Power Module.
3. Mount the Control Unit onto the Power Module so that it audibly snaps into place.
4. Insert the connecting cable between the Control Unit and Operator Panel into the Control Unit.



5. Attach the connecting cable as shown using the fixing bracket provided.
6. Wire the Control Unit and the Power Module.
7. Check that all of the seals are undamaged.
8. Close the cabinet door.




■ You have installed a Control Unit in an IP55 Power Module FSD ... FSF.

To remove the Control Unit from the Power Module, with the door open, press the release lever located directly above the Control Unit.

### 4.6.1 Overview of the interfaces

#### Interfaces at the front of the Control Unit

To access the interfaces at the front of the Control Unit, you must lift the Operator Panel (if one is being used) and open the front doors.



- ① Memory card slot
- ② Selecting the fieldbus address:
  - CU230P-2 DP
  - CU230P-2 CAN
  - CU230P-2 HVAC
  - CU230P-2 BT

Bit 6 (64)	<input type="checkbox"/>
Bit 5 (32)	<input type="checkbox"/>
Bit 4 (16)	<input type="checkbox"/>
Bit 3 (8)	<input type="checkbox"/>
Bit 2 (4)	<input type="checkbox"/>
Bit 1 (2)	<input type="checkbox"/>
Bit 0 (1)	<input type="checkbox"/>
On	Off
- ③ Terminal strips
- ④ Fieldbus interfaces at the lower side
- ⑤ Status LED
 

<input type="checkbox"/>	RDY
<input type="checkbox"/>	BF
<input type="checkbox"/>	---
<input type="checkbox"/>	LNK1 (PROFINET)
<input type="checkbox"/>	LNK2 (PROFINET)
- ⑥ USB interface for connection to a PC
- ⑦ Switch for AI0 and AI1 (U/I)
 

AI1	<input type="checkbox"/>
AI0	<input type="checkbox"/>
I	U

  - I 0/4 mA ... 20 mA
  - U -10/0 V ... 10 V
- ⑧ Switch for AI2 (current/temperature)
 





Temp	<input type="checkbox"/>
I	
- ⑨ Connection to the operator panel

Table 4- 19 Number of inputs and outputs

Digital inputs DI	Digital outputs DO	Analog inputs AI	Analog outputs AO	Input for motor temperature sensor
6	3	4	2	1


## 4.6.2 Fieldbus interface allocation

### Interfaces at the lower side of the CU230P-2 Control Unit

CU230P-2 PN	CU230P-2 DP	CU230P-2 CAN	CU230P-2 HVAC
 <p>X150 X150 P1 P2</p>	 <p>X127 Socket</p>	 <p>X126 OFF ON Connector Bus termination</p>	 <p>X128 OFF ON Bus termination</p>
<p>Pin</p> <ul style="list-style-type: none"> <li>1 RX+, receive data +</li> <li>2 RX-, receive data -</li> <li>3 TX+. Transmit data +</li> <li>4 ---</li> <li>5 ---</li> <li>6 TX-, transmit data -</li> <li>7 ---</li> <li>8 ---</li> </ul>	<p>Pin</p> <ul style="list-style-type: none"> <li>1 Shield, ground connection</li> <li>2 ---</li> <li>3 RxD/TxD-P, receive and transmit (B/B')</li> <li>4 CNTR-P, control signal</li> <li>5 DGND, reference potential for data (C/C')</li> <li>6 VP, supply voltage</li> <li>7 ---</li> <li>8 RxD/TxD-N, receive and transmit (A/A')</li> <li>9 ---</li> </ul>	<p>Pin</p> <ul style="list-style-type: none"> <li>1 ---</li> <li>2 CAN_L, CAN signal (dominant low)</li> <li>3 CAN_GND, CAN ground</li> <li>4 ---</li> <li>5 (CAN_SHLD), optional shield</li> <li>6 (GND), optional ground</li> <li>7 CAN_H, CAN signal (dominant high)</li> <li>8 ---</li> <li>9 ---</li> </ul>	<p>Pin</p> <ul style="list-style-type: none"> <li>1 0 V, reference potential</li> <li>2 RS485P, receive and transmit (+)</li> <li>3 RS485N, receive and transmit (-)</li> <li>4 Cable shield</li> <li>5 ---</li> </ul>

### 4.6.3 Terminal strips

#### Terminal strips with wiring example



<sup>1)</sup> The following applies to systems compliant with UL: Maximum current, 3 A 30 V DC or 2 A 250 V AC

- GND** All terminals labelled with reference potential "GND" are connected internally in the inverter.
- DI COM** Reference potential "DI COM" is electrically isolated from "GND". The Control Unit is delivered with a jumper between terminals 28 and 69.  
→ If, as shown above, you wish to use the 24-V supply from terminal 9 as supply for the digital inputs, then it is mandatory that this jumper is used.


**Terminals 31, 32** Reference potential "GND IN" is electrically isolated from "GND". When an optional 24 V power supply is connected at terminals 31, 32, even when the Power Module is disconnected from the line supply, the Control Unit remains in operation. As a consequence, the Control Unit maintains fieldbus communication, for example.

- Only connect power supplies according to SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) at terminals 31, 32.
- If you use a common external power supply for terminals 31, 32 and the digital input, then you must connect "GND" and "GND IN" with one another.

**Terminals 3, 4 and 10, 11:** You may use the internal 10 V power supply or an external power supply for the analog inputs.  
→ When you use the internal 10 V power supply, you must connect AI 0 or AI 1 with "GND".


Figure 4-18 Wiring the digital inputs with p-switching contacts and an internal 24 V power supply (terminal 9)

### Additional options for wiring the digital inputs



You must remove the jumper between terminals 28 and 69 if it is necessary to have electrical isolation between the external power supply and the internal inverter power supply.

Connecting P-switching contacts with an external power supply



Remove the jumper between terminals 28 and 69.

Connecting M-switching contacts with an external power supply

#### Note

When a contact switching to M is connected, a ground fault at the digital input can lead to the input being unintentionally controlled.


### 4.6.4 Factory setting of the interfaces

#### Factory interface settings

The factory setting of the interfaces depends on the Control Unit.

#### Control Units with USS or CANopen interface

The fieldbus interface is not active.



--- No function.

DO x: p073x

AO 0: p0771[0]

DI x: r0722.x


AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]

Figure 4-19 Factory setting of the CU230P-2 HVAC and CU230P-2 CAN Control Units

#### Control Units with PROFIBUS or PROFINET interface

The function of the fieldbus interface and digital inputs DI 0, DI 1 depends on DI 3.



--- No function.

DO x: p073x

AO 0: p0771[0]

DI x: r0722.x

Speed setpoint (main setpoint): p1070[0] = 2050[1]

Figure 4-20 Factory setting of the CU230P-2 DP and CU230P-2 PN Control Units

### Changing the function of the terminals

The function of the terminals marked in color in the two diagrams above, can be set.

In order not to have to successively change terminal for terminal, several terminals can be jointly set using default settings ("p0015 Macro drive unit").


The terminal settings made in the factory described above correspond to the following default settings:

- Default setting 12 (p0015 = 12): "Standard I/O with analog setpoint"
- Default setting 7 (p0015 = 7): "Fieldbus with data set switchover"

### 4.6.5 Default setting of the interfaces

#### Default setting 7: "Fieldbus with data set switchover"

Factory setting for inverters with PROFIBUS or PROFINET interface




DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 3: r0722.3

Speed setpoint (main setpoint): p1070[0] = 2050[1]

Jog 1 speed setpoint: p1058, factory setting: 150 rpm

Jog 2 speed setpoint: p1059, factory setting: -150 rpm

Designation in BOP-2: FB cdS

**Default setting 9: "Standard I/O with MOP"**

DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, ..., DI 3: r0722.3


Motorized potentiometer, setpoint after the ramp-function generator: r1050

Speed setpoint (main setpoint): p1070[0] = 1050

Designation in BOP-2: Std MoP

**Default setting 12: "Standard I/O with analog setpoint"**

Factory setting for inverters with USS, Modbus, BACnet, MS/TP or P1 interface




DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, ..., DI 2: r0722.2    AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]


Designation in BOP-2: Std ASP

Default setting 14: "Process industry with fieldbus"



DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, ..., DI 5: r0722.5  
 Motorized potentiometer, setpoint after the ramp-function generator: r1050  
 Speed setpoint (main setpoint): p1070[0] = 2050[1], p1070[1] = 1050  
 Designation in BOP-2: Proc Fb

**Default setting 15: "Process industry"**




DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 5: r0722.5      AI 0: r0755[0]

Motorized potentiometer, setpoint after the ramp-function generator: r1050

Speed setpoint (main setpoint): p1070[0] = 755[0], p1070[1] = 1050

Designation in BOP-2: Proc

**Default setting 17: "2-wire (forward/backward 1)"**



DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 2: r0722.2      AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]

Designation in BOP-2: 2-wlrE 1

**Default setting 18: "2-wire (forward/backward 2)"**

—	5 DI 0	ON/OFF1 clockwise
—	6 DI 1	ON /OFF counterclockwise
—	7 DI 2	Acknowledge fault
↕	3 AI 0+	Speed setpoint
⊗	18 DO 0	Fault
	19	
	20	
⊗	21 DO 1	Alarm
	22	
⊗	12 AO 0	Speed actual value
⊗	26 AO 1	Current actual value

DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 2: r0722.2      AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]

Designation in BOP-2: 2-wlrE 2

**Default setting 19: "3-wire (enable/forward/backward)"**

—	5 DI 0	Enable / OFF1
—	6 DI 1	ON clockwise
—	7 DI 2	ON counterclockwise
—	16 DI 4	Acknowledge fault
↕	3 AI 0+	Speed setpoint
⊗	18 DO 0	Fault
	19	
	20	
⊗	21 DO 1	Alarm
	22	
⊗	12 AO 0	Speed actual value
⊗	26 AO 1	Current actual value

DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 4: r0722.4      AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]

Designation in BOP-2: 3-wlrE 1


**Default setting 20: "3-wire (enable/on/reverse)"**

5	DI 0	Enable / OFF1
6	DI 1	ON
7	DI 2	Reversing
16	DI 4	Acknowledge fault
3	AI 0+	Speed setpoint
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value
26	AO 1	Current actual value

DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 0: r0722.0, ..., DI 4: r0722.4      AI 0: r0755[0]

Speed setpoint (main setpoint): p1070[0] = 755[0]

Designation in BOP-2: 3-wlrE 2

**Default setting 21: "USS fieldbus"**



7	DI 2	Acknowledge fault
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value
26	AO 1	Current actual value

DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]      DI 2: r0722.2

Speed setpoint (main setpoint): p1070[0] = 2050[1]


Designation in BOP-2: FB USS

Default setting 22: "CAN fieldbus"



DO 0: p0730, DO 1: p0731      AO 0: p0771[0], AO 1: p0771[1]    DI 2: r0722.2  
Speed setpoint (main setpoint): p1070[0] = 2050[1]  
Designation in BOP-2: FB CAN

## Default setting 101: "Universal application"




DO 0: p0730, ..., DO 2: p0732    AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, ..., DI 5: r0722.5    AI 0: r0755[0]

Additional settings:

- Fixed speed setpoint 1: p1001 = 800 rpm
- Fixed speed setpoint 2: p1002 = 1000 rpm
- Fixed speed setpoint 3: p1003 = 1200 rpm
- If several of the DI 3 ... DI 5 = high, the inverter adds the corresponding fixed speeds.
- Fixed speed setpoint 15 for essential service mode (ESM): p1015 = 1500 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F 6PA

**Default setting 103: "Pump pressure control"**




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0 AI 0: r0755[0]  
 p0732 p0771[1]

Additional settings:

- Differential pressure control using the technology controller
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 50 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1, p2285 ( $T_I$ ) = 30 s, p2274 ( $T_D$ ) = 0 s
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F dPc

### Default setting 104: "ESM stairwell pressure control"




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0 AI 0: r0755[0]  
 p0732 p0771[1]

Additional settings:

- Pressure control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 40 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1.2, p2285 ( $T_I$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 30 %
  - Technology controller output signal start value p2302 = 35 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F Stw

**Default setting 105: "Fan pressure control + ESM with fixed setpoint"**




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0, DI 1: AI 0: r0755[0]  
 p0732 p0771[1] r0722.1

Additional settings:

- Pressure control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Fixed speed setpoint 15 for essential service mode (ESM): p1015 = 1350 rpm
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 40 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1.1, p2285 ( $T_I$ ) = 35 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 20 %
  - Technology controller output signal start value p2302 = 50 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F Pc5

### Default setting 106: "Cooling tower with active sensor + hibernation"




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0 AI 0: r0755[0]  
 p0732 p0771[1]

Additional settings:

- Temperature control using the technology controller
- Analog inputs smoothing time constant: p0753 = 100 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 26 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1.2, p2285 ( $T_I$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller system deviation inversion: p2306 = 1
- Default setting hibernation mode:
  - Activated: p2398 = 1
  - Start speed: p2390 = 50 rpm
  - Delay time: p2391 = 60 s
  - Restart value with technology controller: p2392 = 1 %
  - Restart speed relative w/o technology controller: p2393 = 100 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F ctF1

### Default setting 107: "Cooling tower with LG-Ni1000 sensor + hibernation"




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0 AI 3: r0755[3]  
 p0732 p0771[1]

Additional settings:


- Temperature control using the technology controller
- Analog inputs smoothing time constant: p0753 = 100 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 26 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -100 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1.2, p2285 ( $T_I$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 20 %
  - Technology controller system deviation inversion: p2306 = 1
- Default setting hibernation mode:
  - Activated: p2398 = 1
  - Start speed: p2390 = 50 rpm
  - Delay time: p2391 = 60 s
  - Restart value with technology controller: p2392 = 1 %
  - Restart speed relative w/o technology controller: p2393 = 100 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F ctF2


### Default setting 108: "USS fieldbus"




### Default setting 109: "Modbus RTU field"



**Default setting 110: "BACnet MS/TP fieldbus"**



**Default setting 111: "Fixed setpoints"**




DO 0: p0730, ..., DO 2: p0732    AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, ..., DI 3: r0722.3  
 Additional settings:

- Fixed speed setpoint 1: p1001 = 300 rpm
- Fixed speed setpoint 2: p1002 = 600 rpm
- Fixed speed setpoint 3: p1003 = 900 rpm
- Fixed speed setpoint 4: p1004 = 1200 rpm
- If several of the DI 0 ... DI 3 = high, the inverter adds the corresponding fixed speeds.
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F\_F55

### Default setting 112: "CO<sub>2</sub> sensor, 2 PID setpoints"




DO 0: p0730, ..., DO 2: p0732    AO 0: p0771[0], AO 1: p0771[1]    DI 0: r0722.0, DI 2: r0722.2    AI 0: r0755[0]

Additional settings:

- CO<sub>2</sub> control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 50 %
  - Fixed value 3: p2203 = 10 %
  - Technology controller setpoint 1: p2253 = r2224 (active fixed value)
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Technology controller system deviation inversion: p2306 = 1
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F\_CO2

**Default setting 113: "Temperature-dependent pressure setpoint"**




DO 0: p0730, ..., DO 2: AO 0: p0771[0], AO 1: DI 0: r0722.0 AI 0: r0755[0], AI 2: p0732 p0771[1] r0755[2]

Additional settings:

- Temperature control using the technology controller
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Upper and lower limits, setpoint: p20229 = 0.5 , p20230 = 0.2
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 % , p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Technology controller minimum limiting p2292 = 20 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in BOP-2: P\_F\_tP5

**Default setting 114: "P1 fieldbus"****Default setting 120: "PID settings for pumps and fans"**

The default setting restores the function of the terminal strip to the factory setting.

Technology controller setting:

- Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
- Ramp-up/down time for controller output: p2293 = 30 s
- Actual value upper limit: p2267 = 120%
- Actual value filter time constant: p2265 = 10 s

Designation in    P\_F\_PID

BOP-2:

### 4.6.6 Wiring terminal strips



**! WARNING**

**Danger to life as a result of hazardous voltages when connecting an unsuitable power supply**

Death or serious injury can result when live parts are touched in the event of a fault.

- For all connections and terminals of the electronic boards, only use power supplies that provide PELV (Protective Extra Low Voltage) or SELV (Safety Extra Low Voltage) output voltages.

In order to install the inverter in compliance with UL, you may only connect the DO 0 and DO 2 relay outputs of the Control Unit using copper wires approved for 75 °C.



**! DANGER**

**Danger to life as a result of a hazardous voltage at the Control Unit**

If the insulation is damaged on the lines that are connected to the terminals DO 0 and DO 2, parts of the Control Unit may still be connected to the power supply. When connecting higher voltages at terminals DO 0 and DO 2, there is a risk of electric shock when touching the Control Unit.

- Only connect dangerous voltages using cables with double insulation at relay outputs DO 0 and DO 2 of the Control Unit.

**NOTICE**

**Damage to the inverter when using long signal cables**

Using long cables at the inverter's digital inputs and 24 V power supply can lead to overvoltage during switching operations. Overvoltages can damage the inverter.

- If you use cables of more than 30 m at the digital inputs and 24 V power supply, connect an overvoltage protection element between the terminal and the associated reference potential.  
We recommend using the Weidmüller overvoltage protection terminal with designation MCZ OVP TAZ DIODE 24VDC.

Table 4- 20 Permissible cable and wiring options

Solid or finely-stranded conductor	Finely-stranded conductor with non-insulated conductor end sleeve	Finely-stranded conductor with partially insulated conductor end sleeve
Cables with twin end sleeves are not permissible.		

### Wiring the terminal strip in compliance with EMC

- If you use shielded cables, then you must connect the shield to the mounting plate of the control cabinet or with the shield support of the inverter through a good electrical connection and a large surface area.  
See also: EMC installation guideline  
(<http://support.automation.siemens.com/WW/view/en/60612658>)
- Use the shield connection plate of the Control Unit to connect the shield and as strain relief, see also: Control Units (Page 27).

## 4.6.7 Connecting the inverter to the fieldbus

### Fieldbus interfaces of the Control Units

The Control Units are available in different versions for communication with higher-level controls with the fieldbus interfaces listed as follows:


Fieldbus	Profiles		S7 communication <sup>1)</sup>	Control Unit
	PROFIdrive	PROFInergy <sup>1)</sup>		
PROFIBUS DP (Page 112)	✓	---	✓	CU230P-2 DP
PROFINET IO (Page 108)	✓	✓	✓	CU230P-2 PN
EtherNet/IP <sup>1)</sup>	---	---	---	
USS <sup>1)</sup>	---	---	---	CU230P-2 HVAC
Modbus RTU <sup>1)</sup>	---	---	---	
BACnet MS/TP <sup>1)</sup>	---	---	---	
P1 <sup>1)</sup>	---	---	---	
CANopen <sup>1)</sup>	---	---	---	CU230P-2 CAN

<sup>1)</sup> Information on the these fieldbuses, profiles and communication types can be found in the Fieldbuses Function Manual, also see Section: Manuals for your inverter (Page 451).


### 4.6.7.1 PROFINET

You can either communicate via Ethernet using the inverter, or integrate the inverter in a PROFINET network.

- The inverter as an Ethernet station (Page 451)



- PROFINET IO operation (Page 109)



In PROFINET IO operation, the inverter supports the following functions:

- RT
- IRT  
The inverter transmits the clock synchronism but does not support clock synchronism.
- MRP  
Media redundancy, impulsed with 200 ms  
Requirement: Ring topology
- MRPD  
Media redundancy, impulse-free  
Requirement: IRT and the ring topology created in the control
- Diagnostic alarm  
in accordance with the fault classes specified in the PROFIdrive profile. See Activating diagnostics via the control (Page 111).
- Device replacement without removable medium  
Requirement: Topology created in the control
- Shared device  
only in the case of control units with fail-safe functions (see Safety function manual)

Further information on PROFINET can be found on the Internet using the following links:

- General information about PROFINET can be found at Industrial Communication (<http://www.automation.siemens.com/mcms/automation/en/industrial-communications/profinet/Pages/Default.aspx>).
- The configuration of the functions is described in the PROFINET system description (<http://support.automation.siemens.com/WW/view/en/19292127>) manual.

This manual describes the control of the inverter using primary control. How to access the inverter as an Ethernet station is described in the Fieldbus function manual (Page 451) in the section "The inverter as an Ethernet station".

### What do you need for communication via PROFINET?

Check the communication settings using the following table. If you answer "Yes" to the questions, you have correctly set the communication settings and can control the inverter via the fieldbus.

Questions	Answer/description	Example
Is the inverter correctly connected to the bus network?	See: Integrating inverters into PROFINET (Page 110)	
Do the IP address and device name in the inverter and controller match?	See Configuring communication to the control (Page 110)	Refer to manuals for your inverter, fieldbus function manual (Page 451)
Is the same telegram set in the inverter as in the higher-level controller?	Setting the telegram in the control	
Are the signals that the inverter and the controller exchange via PROFINET correctly interconnected?	Interconnection in the inverter in conformance with PROFIdrive, see: Control via PROFIBUS or PROFINET with the PROFIdrive profile (Page 173)	

## Integrating inverters into PROFINET

### Procedure



To connect the inverter to a control via PROFINET, proceed as follows:

1. Integrate the inverter in the bus system (e.g. ring topology) of the control using PROFINET cables and the two PROFINET sockets X150-P1 and X150-P2.

The position of the sockets and the pin assignment can be found in Section Overview of the interfaces (Page 82).

The maximum permitted cable length from the previous station and to the subsequent one is 100 m.

2. Externally supply the inverter with 24 V DC through terminals 31 and 32.

The external 24 V supply is only required if communications with the control should also run when the mains voltage is switched off.

- You have connected the inverter to the control using PROFINET.

## Configuring communication to the control

### Configuring the communication using SIMATIC S7 control

You have the following options, if the inverter is not included in the hardware library:

- Install the most up to date STARTER version
- Install the GSDML of the inverter using "Tools/Install GSDML file" in HW Config.

Additional information on this topic is provided in the "Fieldbuses" Function Manual, also see Manuals for your inverter (Page 451).

### Configuring the communication using a non-Siemens control

1. Import the device file (GSDML) of the inverter into the engineering tool for your control system.
2. Configure the communication.

## Installing GSDML

### Procedure


-  1 To install the GSDML of the inverter into the configuring tool of your control system, proceed as follows:
- 2
1. Save the GSDML to your PC .
    - From the Internet: GSDML (<http://support.automation.siemens.com/WW/view/en/22339653/133100>).
    - From your inverter:  
Insert a memory card into the inverter.  
Set p0804 = 12.  
The inverter writes the GSDML as zipped file (\*.zip) into directory /SIEMENS/SINAMICS/DATA/CFG on the memory card.
  2. Unzip the GSDML file to a folder on your computer.
  3. Import the GSDML into the configuring tool of your control system.
- You have now installed the GSDML.

## Activating diagnostics via the control

The converter provides the functionality to transmit fault and alarm messages (diagnostic messages) to the higher-level control according to the PROFIdrive error classes.

You must select the functionality in the higher-level control (see Manuals for your inverter (Page 451)) and activate it by booting up.

4.6.7.2 PROFIBUS



The PROFIBUS DP interface has the following functions:

- Cyclic communication
- Acyclic communication
- Diagnostic alarms

General information on PROFIBUS DP can be found on the Internet at the following links:

- Information about PROFIBUS DP ([http://www.automation.siemens.com/net/html\\_76/support/printkatalog.htm](http://www.automation.siemens.com/net/html_76/support/printkatalog.htm)).
- PROFIBUS user organization (<http://www.profibus.com/downloads/installation-guide/>).

What do you need for communication via PROFIBUS?

Check the communication settings using the following table. If you answer "Yes" to the questions, you have correctly set the communication settings and can control the inverter via the fieldbus.

Questions	Description	Examples
Is the inverter correctly connected to the PROFIBUS?	See Section: Integrating inverters into PROFIBUS (Page 113).	---
Have you configured the communication between the inverter and the higher-level controller?	See Section: Configuring the communication using SIMATIC S7 control (Page 113)	See Manuals for your inverter (Page 451)
Do the addresses in the inverter and the higher-level controller match?	See Section: Setting the address (Page 113).	
Is the same telegram set in the higher-level controller and in the inverter?	Setting the telegram in the control	
Are the signals that the inverter and the controller exchange via PROFIBUS correctly interconnected?	Adapt the interconnection of the signals in the controller to the inverter. The interconnection in the inverter in conformance with PROFIdrive is provided in Section: Control via PROFIBUS or PROFINET with the PROFIdrive profile (Page 173).	

## Integrating inverters into PROFIBUS

### Procedure



To connect the inverter to a control via PROFIBUS DP, proceed as follows:

1. Integrate the inverter into the bus system (e.g. line topology) of the control using PROFIBUS cables via socket X126.

The position of the sockets and the pin assignment can be found in Section Overview of the interfaces (Page 82).

The maximum permitted cable length to the previous station and the subsequent one is 100 m at a baud rate of 12 Mbit/s.

2. Externally supply the inverter with 24 V DC through terminals 31 and 32.

The external 24 V supply is only required if communications with the control should also run when the line voltage is switched off.

- You have now connected the inverter to the control using PROFIBUS DP.

## Configuring the communication using SIMATIC S7 control

- If the inverter is listed in the hardware library of HW-Config, you can configure the communication in the SIMATIC control.
- If the inverter is not listed in the hardware library, you can either install the newest STARTER version or install the GSD of the inverter through "Extras/GSD-Install file" in HW-Config. See also GSD (<http://support.automation.siemens.com/WW/view/en/22339653/133100>).

When you have installed the GSD, configure the communication in the SIMATIC control.

## Setting the address

Bit 6 (64)	■
Bit 5 (32)	■
Bit 4 (16)	■
Bit 3 (8)	■
Bit 2 (4)	■
Bit 1 (2)	■
Bit 0 (1)	■
On	Off

Example:

	■
	■
	■
8	■
	■
2	■
	■
= 10	■
On	Off

You set the PROFIBUS address of the inverter using the address switch on the Control Unit, in parameter p0918 or in STARTER.

In parameter p0918 (factory setting: 126) or in STARTER, you can only set the address, if all address switches are set to "OFF" (0) or "ON" (1).

If you have specified a valid address with the address switches, this address will always be the one that takes effect and parameter p0918 cannot be changed.

Valid address range: 1 ... 125

The positions of the address switches are described in Section: Overview of the interfaces (Page 82).

**Procedure**



To change the bus address, proceed as follows:

1. Set the address using one of the subsequently listed options:
  - using the address switch
  - from an operator panel using parameter p0918
  - in STARTER using screen form "Control Unit/Communication/PROFIBUS" – or using the expert list in parameter p0918

After you have changed the address in STARTER, carry out RAM to ROM ()

2. Switch off the inverter supply voltage.
3. Wait until all LEDs on the inverter go dark.
4. Switch on the inverter supply voltage again.

Your settings become active after switching on.




You have now changed the bus address.

## Commissioning

### 5.1 Commissioning guidelines

#### Overview



1. Define the requirements of your application placed on the drive.  
→ (Page 116) .
2. Reset the inverter when required to the factory setting.  
→ (Page 148) .
3. Check whether the factory setting of the inverter is already sufficient for your application.
4. When commissioning the drive, set the following:
  - The closed-loop motor control
  - The inputs and outputs
  - The fieldbus interface
5. When required, adapt the drive  
→ (Page 151).
6. Back up your settings  
→ (Page 309).

## 5.2 Preparing for commissioning


### 5.2.1 Collecting motor data

Before starting commissioning, you must know the following data:

- Which motor is connected to the inverter?

Note down the Article No. of the motor and the motor's nameplate data.

If available, note down the motor code on the motor's nameplate.



- In which region of the world is the motor to be used?

- Europe IEC: 50 Hz [kW]
- North America NEMA: 60 Hz [hp] or 60 Hz [kW]

- How is the motor connected?

Pay attention to the connection of the motor (star connection [Y] or delta connection [Δ]). Note the appropriate motor data for connecting.

### 5.2.2 Factory setting of the converter control

#### Motor

In the factory, the inverter is set for an induction motor matching the rated power of the Power Module.


#### Inverter control

You can find the factory setting of the inverter control in Chapter: Factory setting of the interfaces (Page 86)

### Switching the motor on and off

The inverter is set in the factory as follows:

- After the ON command, the motor accelerates within the ramp-up time (referred to 1500 rpm) to its speed setpoint.
- After the OFF1 command, the motor brakes down to standstill with the ramp-down time.
- The negative direction of rotation is inhibited



- Ramp-up time:
- With PM330 Power Modules: 20 s
  - For all other Power Modules: 10 s
- Ramp-down time:
- With PM230 and PM330 Power Modules: 30 s
  - For all other Power Modules: 10 s

Figure 5-1 Switching on, switching off and reversing the motor in the factory setting

### Traverse the motor in the jog mode

For an inverter with PROFIBUS or PROFINET interface, operation can be switched over using digital input DI 3. The motor is either switched on and off via the fieldbus – or operated in the jog mode via its digital inputs.

For a control command at the respective digital input, the motor rotates with  $\pm 150$  rpm. The same ramp-up and ramp-down times as described above apply.




Figure 5-2 Jogging the motor in the factory setting

### Operate the motor in the factory setting

For basic applications, you can try to operate the drive with a rated power < 18.5 kW without any other commissioning steps. Check whether the control quality of the drive without commissioning is adequate for the requirements of the application.

We recommend that you configure the drive with the precise motor data.

### 5.2.3 Defining additional requirements for the application

#### What speed limits should be set (minimum and maximum speed)?

- Minimum speed - factory setting 20 % of the rated speed  
The minimum speed is the lowest motor speed independent of the speed setpoint.
- Maximum speed - factory setting 1500 [rpm]  
The inverter limits the motor speed to this value.

#### What motor ramp-up time and ramp-down time are needed for the application?

The ramp-up and ramp-down time define the maximum motor acceleration when the speed setpoint changes. The ramp-up and ramp-down time is the time between motor standstill and the maximum speed, or between the maximum speed and motor standstill.

- Ramp-up time - factory setting depending on the Power Module, 10 seconds or 20 seconds
- Ramp-down time - factory setting depending on the Power Module, 10 seconds or 30 seconds

## 5.3 Commissioning using a BOP-2 operator panel

### Plugging on an operator panel

#### Procedure



1 To plug an Operator Panel on the Control Unit, proceed as follows:

2

1. Locate the lower edge of the Operator Panel into the matching recess of the Control Unit.
2. Press the Operator Panel onto the inverter until you hear the latching mechanism engage.



- You have plugged an operator panel onto the Control Unit.  
The operator panel is ready for operation when you connect the inverter to the power supply.

### 5.3.1 Starting basic commissioning

#### Carry out basic commissioning

#### Preconditions



SP 000.0	1/min
0.0	1/min

- The power supply is switched on.
- The operator panel displays setpoints and actual values.

**Procedure**



Proceed as follows to carry out basic commissioning:

1.  Press the ESC key.
2.  Press one of the arrow keys until the BOP-2 displays the "SETUP" menu.
3.   In the "SETUP" menu, press the OK key to start basic commissioning.
4.   If you wish to restore all of the parameters to the factory setting before the basic commissioning:
  - 4.1. Switch over the display using an arrow key: nO → YES
  - 4.2. Press the OK key.
5.   Whether the inverter displays this commissioning step depends on the Power Module being used:
  - PM230 Power Module:  
The inverter skips this step.
  - PM240 or PM240-2 Power Modules:  
Select one of the two application classes:
    - Standard Drive Control
    - Dynamic Drive Control  
See also: Basic commissioning with application classes (Page 127).
    - When selecting application class "EXPERT", follow this handling instruction.
  - Power Module PM330:  
Select application class "Dynamic Drive Control" or select "EXPERT" and then follow these instructions.  
  
See also: Basic commissioning with application classes (Page 127).
6.   Motor standard
 

KW / 50HZ	IEC
HP / 60HZ	NEMA
KW / 60HZ	IEC 60 Hz
7. Overload capability and supply voltage of the inverter
  - 7.1.   Overload capability
 

HIGH OVL	Load cycle with "High Overload"
LOW OVL	Load cycle with "Low Overload"
  - 7.2.   Inverter supply voltage

## 8. Enter the motor data:

- 8.1.  Motor type  
Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.
- |           |                                               |
|-----------|-----------------------------------------------|
| INDUCT    | Third-party induction motor                   |
| SYNC      | Third-party synchronous motor                 |
| RELUCT    | Third-party reluctance motor                  |
| 1L... IND | 1LE1, 1LG6, 1LA7, 1LA9 induction motors       |
| 1LE1 IND  | 1LE1□9 with motor code on the rating plate    |
| 100       |                                               |
| 1PH8 IND  | Induction motor                               |
| 1FP1      | Reluctance motor                              |
| 1F... SYN | 1FG1, 1FK7 synchronous motor, without encoder |
- 8.2.  If you have selected a motor type > 100, then you must enter the motor code:  
With the correct motor code, the inverter assigns the motor data the following values.  
If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.
- 8.3.  87 Hz motor operation  
The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).
- 8.4.  Rated voltage
- 8.5.  Rated current
- 8.6.  Rated power
- 8.7.  Rated frequency
- 8.8.  Rated speed
- 8.9.  Motor cooling
- |        |                    |
|--------|--------------------|
| SELF   | Natural cooling    |
| FORCED | Forced-air cooling |
| LIQUID | Liquid cooling     |
| NO FAN | Without fan        |

9. Application and control mode



Select the application:

- VEC STD      In all applications, which do not fit the other setting options.
- PUMP FAN    Applications involving pumps and fans
- SLVC 0HZ    Applications with short ramp-up and ramp-down times. However, this setting is not suitable for hoisting gear and cranes/lifting gear.
- PUMP 0HZ    Setting only for steady-state operation with slow speed changes. We recommend setting VEC STD if load surges in operation cannot be ruled out.



The selection option depends on the Power Module being used. There is no selection option for PM230 Power Modules.



Select the control mode:

- VF LIN      U/f control with linear characteristic
- VF LIN F    Flux current control (FCC)
- VF QUAD    U/f control with square law characteristic
- SPD N EN    Vector control without encoder

## Selecting the suitable control mode

Control mode	U/f control or flux current control (FCC)	Vector control
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Power Modules that can be operated	No restrictions	
Application examples	<ul style="list-style-type: none"> <li>Pumps, fans, and compressors with flow characteristic</li> </ul>	<ul style="list-style-type: none"> <li>Pumps and compressors with displacement machines</li> </ul>
Closed-loop control characteristics	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: 100 ms ... 200 ms</li> <li>Typical correction time after a load surge: 500 ms</li> <li>The control mode is suitable to address the following requirements: <ul style="list-style-type: none"> <li>Motor power ratings &lt; 45 kW</li> <li>Ramp-up time 0 → Rated speed (dependent on the rated motor power): 1 s (0.1 kW) ... 10 s (45 kW)</li> <li>Applications with increasing load torque without load surges</li> </ul> </li> <li>The control mode is insensitive with respect to inaccurate motor data settings</li> </ul> 	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: &lt; 100 ms</li> <li>Typical correction time after a load surge: 200 ms</li> <li>The vector control controls and limits the motor torque</li> <li>Torque accuracy that can be achieved: <math>\pm 5\%</math> for 15 % ... 100 % of the rated speed</li> <li>We recommend vector control for the following applications: <ul style="list-style-type: none"> <li>Motor power ratings &gt; 11 kW</li> <li>For load surges 10 % ... &gt;100 % of the rated motor torque</li> </ul> </li> <li>The vector control is necessary for a ramp-up time 0 → Rated speed (dependent on the rated motor power): &lt; 1 s (0.1 kW) ... &lt; 10 s (250 kW).</li> </ul> 
Max. output frequency	550 Hz	240 Hz
Torque control	Without torque control	Torque control with higher-level speed control
Commissioning	<ul style="list-style-type: none"> <li>Contrary to vector control, no speed controller has to be set</li> </ul>	

10. MAc PAR  
P15 OK Select the default setting for the interfaces of the inverter that is suitable for your application. You will find the available default settings in Section: Default setting of the interfaces (Page 88)
  
  11. MIN HZ  
P1080 OK Minimum and maximum motor speed
  12. MAX HZ  
P1082 OK
- 
- 
13. AI SCALE  
P758 OK Scaling of analog input 0
  14. RAMP UP  
P1120 OK Motor ramp-up time
  15. RAMP DWN  
P1121 OK Motor ramp-down time
- 
- 
16. OFF3 RP  
P1135 OK Ramp-down time for the OFF3 command
  17. MOT ID  
P1900 OK Motor data identification  
 Select the method which the inverter uses to measure the data of the connected motor:
    - OFF Motor data is not measured.
    - STIL ROT Recommended setting: Measure the motor data at standstill and with the motor rotating.
    - STILL Measure the motor data at standstill.  
 Select this setting if one of the following cases is applicable:
      - You have selected the control mode "SPD N EN". However, the motor cannot rotate freely – for example, if the traversing range is mechanically limited.
      - You have selected U/f control as control mode, e.g. "VF LIN" or "VF QUAD".
    - ROT Measuring the motor data while it is rotating.
- 
18. FINISH OK Complete the basic commissioning:
    - 18.1. Switch over the display using an arrow key: nO → YES
    - 18.2. Press the OK key.



You have entered all of the data that is necessary for the basic commissioning of your inverter.

## Identifying the motor data and optimizing the closed-loop control

The inverter has several techniques to automatically identify the motor data and optimize the speed control.

To start the motor data identification routine, you must switch-on the motor via the terminal strip, fieldbus or from the operator panel.

 <b>WARNING</b>
<p><b>Risk of death due to machine motion while motor data identification is active</b></p> <p>For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to its rated speed. Secure dangerous machine parts before starting motor data identification:</p> <ul style="list-style-type: none"> <li>• Before switching on, ensure that nobody is working on the machine or located within its working area.</li> <li>• Secure the machine's work area against unintended access.</li> <li>• Lower hanging/suspended loads to the floor.</li> </ul>

### Preconditions

- In the basic commissioning, you have selected a motor data identification method, e.g. measuring the motor data at standstill

After basic commissioning has been completed, the inverter outputs alarm A07991.

	This is symbol in the BOP-2 indicates an active alarm.
-------------------------------------------------------------------------------------	--------------------------------------------------------

- The motor has cooled down to the ambient temperature.  
An excessively high motor temperature falsifies the motor data identification results.

**Procedure when using the BOP-2 operator panel**



To start the motor data identification, proceed as follows:

1.  =>  Press the HAND/AUTO key. The BOP-2 displays the symbol for manual operation.
2.  Switch on the motor.
3.  The motor data identification takes several seconds.  
Wait until the inverter switches off the motor after motor data identification has been completed.
-  If you have also selected a rotating measurement in addition to the motor data identification, then the inverter again issues the alarm A07991.
4.  Switch the motor on again in order to optimize the rotating measurement.
5.  Wait until the inverter switches off the motor after completion of the optimization. The optimization time depends on the rated motor power: 20 s ... 2 min.
6.  Switch the inverter control from HAND to AUTO.

 You have now completed motor data identification.

## 5.3.2 Basic commissioning with application classes

### 5.3.2.1 Starting basic commissioning

#### Carry out basic commissioning

##### Preconditions




- The power supply is switched on.
- The operator panel displays setpoints and actual values.

##### Procedure





Proceed as follows to carry out basic commissioning:

1.  Press the ESC key.
2.  Press one of the arrow keys until the BOP-2 displays the "SETUP" menu.
3.  In the "SETUP" menu, press the OK key to start basic commissioning.
4.  If you wish to restore all of the parameters to the factory setting before the basic commissioning:
  - 4.1. Switch over the display using an arrow key: nO → YES
  - 4.2. Press the OK key.
5.  When selecting an application class, the inverter assigns the motor control with the appropriate default settings:
 







STANDARD	→ Standard Drive Control (Page 129)
DYNAMIC	→ Dynamic Drive Control (Page 131)
EXPERT	If you select this setting or if no application class is listed: → Starting basic commissioning (Page 119)

Select a suitable application class



When selecting an application class, the inverter appropriately sets the closed-motor control.

Application class	Standard Drive Control	Dynamic Drive Control
<b>Motors that can be operated</b>	Induction motors	Induction, synchronous and reluctance motors
<b>Power Modules that can be operated</b>	PM240, PM240-2	PM240, PM240-2, PM330
<b>Application examples</b>	<ul style="list-style-type: none"> <li>Pumps, fans, and compressors with flow characteristic</li> </ul>	<ul style="list-style-type: none"> <li>Pumps and compressors with displacement machines</li> </ul>
<b>Properties</b>	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: 100 ms ... 200 ms</li> <li>Typical correction time after a load surge: 500 ms</li> <li>Standard Drive Control is suitable for the following requirements:                             <ul style="list-style-type: none"> <li>Motor power ratings &lt; 45 kW</li> <li>Ramp-up time 0 → Rated speed (dependent on the rated motor power): 1 s (0.1 kW) ... 10 s (45 kW)</li> <li>Applications with constant load torque without load surges</li> </ul> </li> <li>Standard Drive Control is insensitive with respect to imprecise setting of the motor data</li> </ul> 	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: &lt; 100 ms</li> <li>Typical correction time after a load surge: 200 ms</li> <li>Dynamic Drive Control controls and limits the motor torque</li> <li>Torque accuracy that can be achieved: ± 5 % for 15 % ... 100 % of the rated speed</li> <li>We recommend Dynamic Drive Control for the following applications:                             <ul style="list-style-type: none"> <li>Motor power ratings &gt; 11 kW</li> <li>For load surges 10 % ... &gt;100 % of the rated motor torque</li> </ul> </li> <li>Dynamic Drive Control is necessary for a ramp-up time 0 → rated speed (dependent on the rated motor power): &lt; 1 s (0.1 kW) ... &lt; 10 s (250 kW).</li> </ul> 
<b>Max. output frequency</b>	550 Hz	240 Hz
<b>Torque control</b>	Without torque control	Speed control with lower-level torque control
<b>Commissioning</b>	<ul style="list-style-type: none"> <li>Contrary to "Dynamic Drive Control", a speed controller does not have to be set</li> <li>When compared to "Configuration for experts"                             <ul style="list-style-type: none"> <li>Simplified commissioning using pre-assigned motor data</li> <li>Fewer parameters</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>Fewer parameters when compared to "Configuration for experts"</li> </ul>

## 5.3.2.2 Standard Drive Control

6.  Motor standard  
 KW 50HZ IEC  
 HP 60HZ NEMA  
 KW 60HZ IEC 60 Hz
7.  Supply voltage for the inverter
8. Enter the motor data:
- 8.1.  Motor type  
 Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.  
 INDUCT Third-party induction motor  
 SYNC Third-party synchronous motor  
 RELUCT Third-party reluctance motor  
 1L... IND 1LE1, 1LG6, 1LA7, 1LA9 induction motors  
 1LE1 IND 100 1LE1□9 with motor code on the rating plate  
 1PH8 IND Induction motor  
 1FP1 Reluctance motor  
 1F... SYN 1FG1, 1FK7 synchronous motor, without encoder
- 8.2.  If you have selected a motor type > 100, then you must enter the motor code:  
 With the correct motor code, the inverter assigns the motor data the following values.  
 If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.
- 8.3.  87 Hz motor operation  
 The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).
- 8.4.  Rated voltage
- 8.5.  Rated current
- 8.6.  Rated power
- 8.7.  Rated frequency
- 8.8.  Rated speed
- 8.9.  Motor cooling  
 SELF Natural cooling  
 FORCED Forced-air cooling  
 LIQUID Liquid cooling  
 NO FAN Without fan

9. TEC APPL  
P501 OK Select the application:  
 VEC STD Constant load: Typical applications include belt conveyor drives.  
 PUMP FAN Speed-dependent load: Typical applications include pumps and fans.
  
  10. MAc PAR  
P15 OK Select the default setting for the interfaces of the inverter that is suitable for your application. You will find the available default settings in Section: Default setting of the interfaces (Page 88)
  
  11. MIN HZ  
P1080 OK Minimum/maximum frequency of the motor
  12. MAX HZ  
P1082 OK
  
  13. AI SCALE  
P758 OK Scaling of analog input 0
  
  14. RAMP UP  
P1120 OK Motor ramp-up time.
  15. RAMP DWN  
P1121 OK Motor ramp-down time
  
  16. OFF3 RP  
P1135 OK Ramp-down time for the OFF3 command
  
  17. FINISH OK Complete the basic commissioning:
    - 17.1. Switchover the display using an arrow key: nO → YES
    - 17.2. Press the OK key.
- You have entered all of the data that is necessary for the basic commissioning of your inverter.



## 5.3.2.3 Dynamic Drive Control

6.  Motor standard  
 KW 50HZ IEC  
 HP 60HZ NEMA  
 KW 60HZ IEC 60 Hz
7.  Supply voltage for the inverter
8. Enter the motor data:
- 8.1.  Motor type  
 Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.  
 INDUCT Third-party induction motor  
 SYNC Third-party synchronous motor  
 RELUCT Third-party reluctance motor  
 1L... IND 1LE1, 1LG6, 1LA7, 1LA9 induction motors  
 1LE1 IND 100 1LE1□9 with motor code on the rating plate  
 1PH8 IND Induction motor  
 1FP1 Reluctance motor  
 1F... SYN 1FG1, 1FK7 synchronous motor, without encoder
- 8.2.  If you have selected a motor type > 100, then you must enter the motor code:  
 With the correct motor code, the inverter assigns the motor data the following values.  
 If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.
- 8.3.  87 Hz motor operation  
 The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).
- 8.4.  Rated voltage
- 8.5.  Rated current
- 8.6.  Rated power
- 8.7.  Rated frequency
- 8.8.  Rated speed
- 8.9.  Motor cooling  
 SELF Natural cooling  
 FORCED Forced-air cooling  
 LIQUID Liquid cooling  
 NO FAN Without fan

9.

Select the application:

OP LOOP Recommended setting for standard applications.

CL LOOP Recommended setting for applications with short ramp-up and ramp-down times. This setting is not suitable for hoisting gear and cranes/lifting gear.

HVY LOAD Recommended setting for applications with a high break loose torque.

The BOP-2 does not display this step for a PM330 Power Module.


10.

Select the default setting for the interfaces of the inverter that is suitable for your application. You will find the available default settings in Section: Default setting of the interfaces (Page 88)

10.

11.

Minimum and maximum frequency of the motor



12.


Scaling of analog input 0

13.

Motor ramp-up time.

14.

Motor ramp-down time



15.

Ramp-down time for the OFF3 command

16.

Motor data identification

Select the method which the inverter uses to measure the data of the connected motor:

OFF No measurement of motor data.

ST RT OP Recommended setting: Measure the motor data at standstill and with the motor rotating.

STILL OP Measure the motor data at standstill.

Select this setting if the motor cannot freely rotate, e.g. for a mechanically limited traversing range.

17.

Complete the basic commissioning:

17.1. Switchover the display using an arrow key: nO → YES

17.2. Press the OK key.



You have entered all of the data that is necessary for the basic commissioning of your inverter.

## Identifying the motor data and optimizing the closed-loop control

The inverter has several techniques to automatically identify the motor data and optimize the speed control.

To start the motor data identification routine, you must switch-on the motor via the terminal strip, fieldbus or from the operator panel.

 <b>WARNING</b>
<p><b>Risk of death due to machine motion while motor data identification is active</b></p> <p>For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to its rated speed. Secure dangerous machine parts before starting motor data identification:</p> <ul style="list-style-type: none"> <li>• Before switching on, ensure that nobody is working on the machine or located within its working area.</li> <li>• Secure the machine's work area against unintended access.</li> <li>• Lower hanging/suspended loads to the floor.</li> </ul>

### Preconditions

- In the basic commissioning, you have selected a motor data identification method, e.g. measuring the motor data at standstill

After basic commissioning has been completed, the inverter outputs alarm A07991.

	This is symbol in the BOP-2 indicates an active alarm.
-------------------------------------------------------------------------------------	--------------------------------------------------------

- The motor has cooled down to the ambient temperature.  
An excessively high motor temperature falsifies the motor data identification results.

**Procedure when using the BOP-2 operator panel**



To start the motor data identification, proceed as follows:

1.  =>  Press the HAND/AUTO key. The BOP-2 displays the symbol for manual operation.
2.  Switch on the motor.
3.  The motor data identification takes several seconds.  
Wait until the inverter switches off the motor after motor data identification has been completed.
-  If you have also selected a rotating measurement in addition to the motor data identification, then the inverter again issues the alarm A07991.
4.  Switch the motor on again in order to optimize the rotating measurement.
5.  Wait until the inverter switches off the motor after completion of the optimization. The optimization time depends on the rated motor power: 20 s ... 2 min.
6.  Switch the inverter control from HAND to AUTO.

 You have now completed motor data identification.


## 5.4 Commissioning with a PC

### PC-based commissioning tools

STARTER and Startdrive are PC tools to commission Siemens inverters. The graphic user interface supports you when commissioning your inverter. Most of the inverter functions are available in screen forms.

The screen forms that are shown in this manual show generally valid examples. The number of setting options available in screen forms depends on the particular inverter type.

### Preconditions for commissioning



You can access the inverter with STARTER or Startdrive either via a USB connection or via the fieldbus.

System requirements and download:

- STARTER download (<http://support.automation.siemens.com/WW/view/en/10804985/133100>)
- Startdrive (<http://support.automation.siemens.com/WW/view/en/88851265>)

Help for operation and for the functions of the commissioning tools:

- STARTER videos (<http://www.automation.siemens.com/mcms/mc-drives/en/low-voltage-inverter/sinamics-g120/videos/Pages/videos.aspx>)
- Startdrive tutorial (<http://support.automation.siemens.com/WW/view/en/73598459>)

### Overview of basic commissioning

Basic commissioning using a PC essentially consists of the following steps:

1. Creating a project
2. Integrate an inverter into the project
3. Go online and start basic commissioning
4. Carry out basic commissioning
5. Identify motor data

Steps 1-5 are described below.

### 5.4.1 Creating a project

#### Creating a project

**Procedure**

- ➔ 1 In order to create a new project, proceed as follows:
- 2
  - 1. In the menu, select "Project" → "New...".
  - 2. Specify a name of your choice for the project.
- You have created a new project.

### 5.4.2 Transfer inverters connected via USB into the project

#### Transferring inverters connected via USB to the project

**Procedure**

- ➔ 1 Proceed as follows to transfer an inverter connected via USB to your project:
- 2
  - 1. Switch on the inverter supply voltage.
  - 2. First insert a USB cable into your PC and then into the inverter.
  - 3. The PC operating system installs the USB driver when you are connecting the inverter and PC together for the first time.
    - Windows 7 installs the driver automatically.
    - For Windows XP you must acknowledge several system messages.
  - 4. Start the commissioning software.
  - 5. Select the "Accessible nodes".




Figure 5-3 "Accessible nodes" in STARTER




Figure 5-4 "Accessible nodes" in Startdrive

- When the USB interface is appropriately set, then the "Accessible nodes" screen form shows the inverters that can be accessed.




Figure 5-5 Inverters found in STARTER




Figure 5-6 Inverters found in Startdrive

If you have not correctly set the USB interface, then the following "No additional nodes found" message is displayed. In this case, follow the description below.

- Proceed as follows:


With STARTER	With Startdrive
<ul style="list-style-type: none"> <li>Select the inverter <input checked="" type="checkbox"/>.</li> <li>Press the "Accept" button.</li> </ul>	<ul style="list-style-type: none"> <li>Accept the inverter into the project using the menu:</li> <li>"Online - Upload device as new station (hardware and software)"</li> </ul>

- You have transferred an inverter accessible via the USB interface into your project.

### Setting the USB interface in STARTER

#### Procedure

- ➔ 1 Proceed as follows to set the USB interface in STARTER:
1. Set the "Access point" to "DEVICE (STARTER, Scout)" and the "PG/PC interface" to "S7USB".
  2. Press the "Update" button.



- You have set the USB interface.  
STARTER now shows the inverters connected via USB.

### 5.4.3 Go online and start the configuration wizards

#### Procedure with STARTER



Proceed as follows to start configuration of the inverter:


1. Select your project and go online: .
2. In the following screen form, select the inverter with which you wish to go online.
3. Download the hardware configuration found online in your project (PG or PC).



Significance of the symbol in front of the inverter:

- (A) The inverter is online.
- (B) The inverter is offline

4. When you are online, double-click on "Control Unit".
5. Start the configuration wizards:




- You have started to configure the inverter.

#### Procedure with Startdrive



Proceed as follows to start configuration of the inverter:

1. Select your project and go online: .
2. In the following screen form, select the inverter with which you wish to go online.
3. Once you are online, select "Commissioning" → "Commissioning Wizard":



- You have started to configure the inverter.

### Configuring the drive

#### Procedure





To configure the drive, proceed as follows:

1.  Application class
  - When selecting an application class, the inverter assigns the motor control with the appropriate default settings:
    - [1] Standard Drive Control (Page 141)
    - [2] Dynamic Drive Control (Page 142)
    - [0] Expert - or if no application class is listed:
      - Configuration for experts (Page 143)

#### Select a suitable application class

When selecting an application class, the inverter appropriately sets the closed-motor control.

Application class	Standard Drive Control	Dynamic Drive Control
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Power Modules that can be operated	PM240, PM240-2	PM240, PM240-2, PM330
Application examples	<ul style="list-style-type: none"> <li>• Pumps, fans, and compressors with flow characteristic</li> </ul>	<ul style="list-style-type: none"> <li>• Pumps and compressors with displacement machines</li> </ul>
Properties	<ul style="list-style-type: none"> <li>• Typical correction time after a speed change: 100 ms ... 200 ms</li> <li>• Typical correction time after a load surge: 500 ms</li> <li>• Standard Drive Control is suitable for the following requirements:                             <ul style="list-style-type: none"> <li>– Motor power ratings &lt; 45 kW</li> <li>– Ramp-up time 0 → Rated speed (dependent on the rated motor power): 1 s (0.1 kW) ... 10 s (45 kW)</li> <li>– Applications with constant load torque without load surges</li> </ul> </li> <li>• Standard Drive Control is insensitive with respect to imprecise setting of the motor data</li> </ul> 	<ul style="list-style-type: none"> <li>• Typical correction time after a speed change: &lt; 100 ms</li> <li>• Typical correction time after a load surge: 200 ms</li> <li>• Dynamic Drive Control controls and limits the motor torque</li> <li>• Torque accuracy that can be achieved: ± 5 % for 15 % ... 100 % of the rated speed</li> <li>• We recommend Dynamic Drive Control for the following applications:                             <ul style="list-style-type: none"> <li>– Motor power ratings &gt; 11 kW</li> <li>– For load surges 10 % ... &gt;100 % of the rated motor torque</li> </ul> </li> <li>• Dynamic Drive Control is necessary for a ramp-up time 0 → rated speed (dependent on the rated motor power): &lt; 1 s (0.1 kW) ... &lt; 10 s (250 kW).</li> </ul> 

Application class	Standard Drive Control	Dynamic Drive Control
Max. output frequency	550 Hz	240 Hz
Torque control	Without torque control	Speed control with lower-level torque control
Commissioning	<ul style="list-style-type: none"> <li>• Contrary to "Dynamic Drive Control", a speed controller does not have to be set</li> <li>• When compared to "Configuration for experts" <ul style="list-style-type: none"> <li>– Simplified commissioning using preassigned motor data</li> <li>– Fewer parameters</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Fewer parameters when compared to "Configuration for experts"</li> </ul>

#### 5.4.4 Standard Drive Control

##### Procedure for application class [1]: Standard Drive Control

2.  Defaults of the setpoint Select the I/O configuration to preassign the inverter interfaces.  
The possible configurations are listed in Sections: Factory setting of the interfaces (Page 86) and Default setting of the interfaces (Page 88).
3.  Drive setting Set the applicable motor standard and the inverter supply voltage.
4.  Motor Select your motor.
5.  Motor data Enter the motor data according to the rating plate of your motor.  
If you have selected a motor based on its article number, the data has already been entered.
6.  Important parameters Set the most important parameters to suit your application.
7.  Drive functions Select the application:
  - [0] Constant load: Typical applications include conveyor drives
  - [1] Speed-dependent load: Typical applications include pumps and fans

You have now configured the inverter.

## 5.4.5 Dynamic Drive Control

### Procedure for application class [2]: Dynamic Drive Control

2.  Defaults of the setpoint Select the I/O configuration to preassign the inverter interfaces.  
The possible configurations are listed in Sections: Factory setting of the interfaces (Page 86) and Default setting of the interfaces (Page 88).
3.  Drive setting Set the applicable motor standard and the inverter supply voltage.
4.  Motor Select your motor.
5.  Motor data Enter the motor data according to the rating plate of your motor.  
If you have selected a motor based on its article number, the data has already been entered.
6.  Important parameters Set the most important parameters to suit your application.
7.  Drive functions Application:
  - [0]: Recommended setting for standard applications.
  - [1]: Recommended setting for applications with ramp-up and ramp-down times < 10 s. This setting is not suitable for hoisting gear and cranes.
  - [5] Recommended setting for applications with a high break loose torque.Motor identification:
  - [11]: Recommended setting. After an ON command, the inverter identifies the motor data – and with a new ON command, optimizes the speed controller.
  - [12]: After an ON command, the inverter identifies the motor data at standstill. Recommended setting if the motor cannot freely rotate, e.g. for a mechanically limited traversing path.

You have now configured the inverter.

## 5.4.6 Configuration for experts

### Procedure without application class or for the application class [0]: Expert

2.  Control structure Select the control mode.
3.  Defaults of the setpoint Select the I/O configuration to preassign the inverter interfaces.  
The possible configurations are listed in Sections: Factory setting of the interfaces (Page 86) and Default setting of the interfaces (Page 88).
4.  Drive setting Set the applicable motor standard and the inverter supply voltage.  
Select the application for the inverter:
  - "[0] Load cycle with high overload for applications requiring a high dynamic performance, e.g. conveyor systems.
  - "[1] Load cycle with low overload ..." for applications that do not require a high dynamic performance, e.g. pumps or fans.
  - [6], [7]: Load cycles for applications with encoderless 1FK7 synchronous motors.
5.  Motor Select your motor.
6.  Motor data Enter the motor data according to the rating plate of your motor.  
If you have selected a motor based on its article number, the data has already been entered.
7.  Important parameters Set the most important parameters to suit your application.
8.  Drive functions Application:
  - [0]: In all applications that do not fall under [1] ... [3]
  - [1]: Applications involving pumps and fans
  - [2]: Applications with short ramp-up and ramp-down times. However, this setting is not suitable for hoisting gear and cranes/lifting gear.
  - [3]: Setting only for steady-state operation with slow speed changes. We recommend setting [1] if load surges in operation cannot be ruled out.


Motor identification:

  - [1]: Recommended setting. After an ON command, the inverter identifies the motor data – and with a new ON command, optimizes the speed controller.
  - [2]: After an ON command, the inverter identifies the motor data at standstill. Recommended setting for the following cases:
    - You have selected "Speed control" as control mode, however the motor cannot freely rotate, e.g. for mechanically limited traversing sections.
    - You have set "V/f control" as control mode.
  - [3]: This setting only makes sense after the motor identification [2]. The inverter optimizes the speed controller at the next ON command.


Calculating the motor parameters: Select "Complete calculation".

- 9. Set the check mark for "RAM to ROM (save data in the drive)" to save your data in the inverter so that it is not lost when the power fails.

Select "Finish".





Complete the configuration in STARTER



Complete the configuration in Startdrive

- You have now configured the inverter.

## Selecting the suitable control mode

Control mode	U/f control or flux current control (FCC)	Vector control
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Power Modules that can be operated	No restrictions	
Application examples	<ul style="list-style-type: none"> <li>Pumps, fans, and compressors with flow characteristic</li> </ul>	<ul style="list-style-type: none"> <li>Pumps and compressors with displacement machines</li> </ul>
Closed-loop control characteristics	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: 100 ms ... 200 ms</li> <li>Typical correction time after a load surge: 500 ms</li> <li>The control mode is suitable to address the following requirements: <ul style="list-style-type: none"> <li>Motor power ratings &lt; 45 kW</li> <li>Ramp-up time 0 → Rated speed (dependent on the rated motor power): 1 s (0.1 kW) ... 10 s (45 kW)</li> <li>Applications with increasing load torque without load surges</li> </ul> </li> <li>The control mode is insensitive with respect to inaccurate motor data settings</li> </ul> 	<ul style="list-style-type: none"> <li>Typical correction time after a speed change: &lt; 100 ms</li> <li>Typical correction time after a load surge: 200 ms</li> <li>The vector control controls and limits the motor torque</li> <li>Torque accuracy that can be achieved: ± 5 % for 15 % ... 100 % of the rated speed</li> <li>We recommend vector control for the following applications: <ul style="list-style-type: none"> <li>Motor power ratings &gt; 11 kW</li> <li>For load surges 10 % ... &gt;100 % of the rated motor torque</li> </ul> </li> <li>The vector control is necessary for a ramp-up time 0 → Rated speed (dependent on the rated motor power): &lt; 1 s (0.1 kW) ... &lt; 10 s (250 kW).</li> </ul> 
Max. output frequency	550 Hz	240 Hz
Torque control	Without torque control	Torque control with higher-level speed control
Commissioning	<ul style="list-style-type: none"> <li>Contrary to vector control, no speed controller has to be set</li> </ul>	

### 5.4.7 Identify motor data

#### Identify motor data

**! WARNING**

**Danger to life from machine movements while motor data identification is in progress**

The stationary measurement can turn the motor a number of revolutions. The rotating measurement accelerates the motor up to the rated speed. Secure dangerous machine parts before starting motor data identification:

- Before switching on, ensure that nobody is working on the machine or located within its working area.
- Secure the machine's working area against unintended access.
- Lower suspended loads to the floor.

#### Preconditions

- You selected a method of motor data identification during basic commissioning, e.g. measurement of the motor data while the motor is stationary.

When basic commissioning is complete, the inverter issues alarm A07991.

- The motor has cooled down to the ambient temperature.

An excessively high motor temperature distorts the results of motor data identification.

#### Procedure with STARTER



To initiate motor data identification and optimize the motor control, proceed as follows:

1. Open the control panel.





Figure 5-7 Control panel

2. Assume master control for the inverter.
3. Set the "Enable signals"

4. Switch on the motor.

The inverter starts the motor data identification. This measurement can take several minutes. After the measurement, the inverter switches off the motor.

5. Relinquish the master control after the motor data identification.


6. Press button  (RAM to ROM).

 You have completed the motor data identification.

### Procedure with Startdrive

 1 To initiate motor data identification and optimize the motor control, proceed as follows:

1. Open the control panel.



2. Assume master control for the inverter.

3. Set the "Drive enables"

4. Switch on the motor.

The inverter starts the motor data identification. This measurement can take several minutes. After the measurement, the inverter switches off the motor.

5. Relinquish the master control after the motor data identification.

6. Save the settings in the inverter (RAM → EEPROM):



 You have completed the motor data identification.

### Self-optimization of the speed control

If you have selected not only motor data identification but also rotating measurement with self-optimization of the speed control, you must switch on the motor again as described above and wait for the optimization run to finish.

## 5.5 Restoring the factory setting


There are cases where something goes wrong when commissioning a drive system e.g.:

- The line voltage was interrupted during commissioning and you were not able to complete commissioning.
- You got confused during the commissioning and you can no longer understand the individual settings that you made.
- You do not know whether the inverter was already operational.

In cases such as these, reset the inverter to the factory settings.


### Restore the factory inverter settings

#### Procedure with STARTER



Proceed as follows to reset the inverter to factory settings:


1. Select your drive.
2. Go online.
3. Open "Drive Navigator".



4. Select the "Commissioning" button.
5. Press the "Factory setting" button.
6.  In the screen form, select "After loading copy RAM to ROM".
7. Start the reset.
8. Wait until the inverter has been reset to the factory setting.

You have reset the inverter to factory settings.


#### Procedure with Startdrive



Proceed as follows to reset the inverter to factory settings:

1. Go online.
2. Select "Commissioning".
3. Select "Backing up/reset".
4. Select "All parameters are reset".

5. Press the "Start" button.



6. Wait until the inverter has been reset to the factory setting.

- You have reset the inverter to factory settings.

#### Procedure with the BOP-2 operator panel



Proceed as follows to reset the inverter to factory settings:

1. In the "Options" menu, select the "DRVRESET" entry
2. Confirm the reset using the OK key.
3. Wait until the inverter has been reset to the factory setting.

- You have reset the inverter to factory settings.



## Advanced commissioning

### 6.1 Overview of the inverter functions






Figure 6-1 Overview of inverter functions

6.1 Overview of the inverter functions

Functions relevant to all applications	Functions required in special applications only	
<p>The functions that you require in each application are shown in a dark color in the function overview above.</p> <p>In the quick commissioning, the parameters of these functions are assigned an appropriate basic setting, so that in many cases the motor can be operated without having to assign any other parameters.</p>	<p>The functions whose parameters you only need to adapt when actually required are shown in white in the function overview above.</p>	
 <p><b>Inverter control</b> is responsible for all of the other inverter functions. Among other things, it defines how the inverter responds to commands from the higher-level control system.</p> <p>Inverter control (Page 153)</p>		<p>The <b>protection functions</b> prevent damage to the motor, inverter and driven load, e.g. using temperature monitoring or torque monitoring.</p> <p>Protection functions (Page 231)</p>
 <p>The <b>commands</b> from the higher-level control are sent to the inverter via digital inputs or the fieldbus. The inverter returns its <b>status signals</b> to the outputs of the Control Unit or to the fieldbus.</p> <p>Adapt the default setting of the terminal strip (Page 155)</p>  <p>Connecting the inverter to the fieldbus (Page 107)</p>		<p>Functions <b>suitable for the application</b> permit, for example, a higher-level closed-loop pressure or temperature control using the technology controller.</p> <p>Further, the inverter provides solution options specifically for applications in the area of pumps, fans and climate control systems (HVAC).</p> <p>Application-specific functions (Page 241)</p>
 <p>You must define a <b>setpoint</b>, which defines the motor speed, for example.</p> <p>Setpoints (Page 203)</p>		
 <p>The <b>setpoint processing</b> uses a ramp-function generator to prevent speed steps occurring and to limit the speed to a permissible maximum value.</p> <p>Setpoint calculation (Page 211)</p>		
 <p>The <b>motor closed-loop control</b> ensures that the motor follows the speed setpoint. You can select either vector control or U/f control.</p> <p>Motor control (Page 219)</p>		


## 6.2 Inverter control

### 6.2.1 Switching the motor on and off



After switching the supply voltage on, the converter normally goes into the "ready to start" state. In this state, the converter waits for the command to switch-on the motor:

- The converter switches on the motor with the ON command. The converter changes to the "Operation" state.
- The converter brakes the motor after the OFF1 command. The converter switches off the motor once standstill has been reached. The converter is again "ready to start".



### Converter states and commands for switching the motor on and off

In addition to the OFF1 command, there are other commands that are used to switch off the motor:

- OFF2 - the converter immediately switches off the motor without first braking it.
- OFF3 - this command means "quick stop". After OFF3, the converter brakes the motor with the OFF3 ramp-down time. After reaching standstill, the converter switches off the motor.

The command is frequently used for exceptional operating situations where it is necessary to brake the motor especially quickly. Collision protection is a typical application for this function.

- Block operation - The inverter switches the motor off.
- Enable operation - The inverter switches the motor on.





Figure 6-2 Internal sequence control of the converter when the motor is switched on and off

The abbreviations S1 ... S5b to identify the converter states are defined in the PROFIdrive profile.

Converter status	Explanation
S1	In this state, the converter does not respond to the ON command. The converter goes into this state under the following conditions: <ul style="list-style-type: none"> <li>• ON was active when switching on the converter. Exception: When the automatic start function is active, ON must be active after switching on the power supply.</li> <li>• OFF2 or OFF3 is selected.</li> </ul>
S2	This state is required to switch on the motor.
S3	The converter waits for the operating enable.
S4	The motor is switched on.
S51	The motor was switched off with OFF1 and brakes with the ramp-down time of the ramp-function generator.
S52	The motor was switched off with OFF3 and brakes with the OFF3 ramp-down time, or at the current limit.

## 6.2.2 Adapt the default setting of the terminal strip

This chapter describes how you adapt the function of individual digital and analog inputs and outputs of the inverter.




<sup>1)</sup> When using the PM330 Power Module, the inverter also has terminals on the Control Unit via 4 digital inputs DI and 2 digital outputs DO on the Power Module.

Figure 6-3 Internal interconnection of the inputs and outputs

6.2.2.1 Digital inputs

Changing the function of a digital input



To change the function of a digital input, you must interconnect the status parameter of the digital input with a binector input of your choice.

See also Section: Interconnecting signals in the converter (Page 447).

Binector inputs are marked with "BI" in the parameter list of the List Manual.

1) When using the PM330 Power Module, the inverter has 4 additional digital inputs.

Table 6- 1 Binector inputs (BI) of the inverter (selection)

BI	Significance	BI	Significance
p0810	Command data set selection CDS bit 0	p1036	Motorized potentiometer, setpoint, lower
p0840	ON/OFF1	p1055	Jog bit 0
p0844	OFF2	p1056	Jog bit 1
p0848	OFF3	p1113	Setpoint inversion
p0852	Enable operation	p1201	Flying restart enable signal source
p0855	Unconditionally release holding brake	p2103	1. Acknowledge faults
p0856	Enable speed controller	p2106	External fault 1
p0858	Unconditionally close holding brake	p2112	External alarm 1
p1020	Fixed speed setpoint selection bit 0	p2200	Technology controller enable
p1021	Fixed speed setpoint selection bit 1	p3330	Two/three-wire control, control command 1
p1022	Fixed speed setpoint selection bit 2	p3331	Two/three-wire control, control command 2
p1023	Fixed speed setpoint selection bit 3	p3332	Two/three-wire control, control command 3
p1035	Motorized potentiometer, setpoint, raise		

A complete list of the binector outputs is provided in the List Manual.

Changing the function of a digital input - Example




To acknowledge fault messages of the inverter using digital input DI 1, you must interconnect DI1 with the command to acknowledge faults (p2103): Set p2103 = 722.1.

## Advanced settings

You can debounce the digital input signal using parameter p0724.

For more information, please see the parameter list and the function block diagrams 2220 f of the List Manual.

## Analog inputs as digital inputs



To use an analog input as additional digital input, you must interconnect the corresponding status parameter r0722.11 or r0722.12 with a binector input of your choice.

You may operate the analog input as digital input with 10 V or with 24 V.

### NOTICE


#### Destruction of the analog input as a result of the excessively high input current

The 10 V or 24 V voltage source will destroy the analog input if the operating mode selector switch is set to "Current input" (I).

- Set the operating mode selector switch of the analog input to voltage (U).

6.2.2.2 Digital outputs

Changing the function of a digital output



To change the function of a digital output, you must interconnect the digital output with a binector output of your choice.

See also Section: Interconnecting signals in the converter (Page 447).

Binector outputs are marked with "BO" in the parameter list of the List Manual.

1) When using the PM330 Power Module, the inverter has 2 additional digital outputs. The function of the two additional digital outputs is fixed and cannot be modified:


- DO 0 (X9.8): Inverter DC link is charged
- DO 1 (X9.11, X9.12): Close main contactor

Table 6- 2 Binector outputs (BO) of the inverter (selection)

0	Deactivating digital output	r0052.9	Process data control
r0052.0	Drive ready	r0052.10	f_actual >= p1082 (f_max)
r0052.1	Drive ready for operation	r0052.11	Alarm: Motor current/torque limit
r0052.2	Drive running	r0052.12	Brake active
r0052.3	Drive fault active	r0052.13	Motor overload
r0052.4	OFF2 active	r0052.14	Motor CW rotation
r0052.5	OFF3 active	r0052.15	Inverter overload
r0052.6	Closing lockout active	r0053.0	DC braking active
r0052.7	Drive alarm active	r0053.2	f_actual > p1080 (f_min)
r0052.8	Setpoint/actual value discrepancy	r0053.6	f_actual ≥ setpoint (f_setpoint)

The complete list of binector outputs is provided in the List Manual.

Changing the function of a digital output - Example



To output inverter fault messages via digital output DO 1, you must interconnect DO1 with the fault messages: Set p0731 = 52.3.


## Advanced settings

You can invert the signal of the digital output using parameter p0748.

For more information, please see the parameter list and the function block diagrams 2230 f of the List Manual.

### 6.2.2.3 Analog inputs

#### Overview



Changing the function of an analog input:

1. Define the analog input type using parameter p0756[x] and the switch on the inverter.
2. Define the function of the analog input by interconnecting parameter p0755[x] with a connector input CI of your choice.

See also Section: Interconnecting signals in the converter (Page 447).


#### Defining the analog input type

The variable speed drive offers a series of default settings, which you can select using parameter p0756:

<b>AI 0</b>	Unipolar voltage input	0 V ... +10 V	p0756[0] =	0
	Unipolar voltage input monitored:	+2 V ... +10 V		1
	Unipolar current input	0 mA ... +20 mA		2
	Unipolar current input monitored	+4 mA ... +20 mA		3
	Bipolar voltage input (factory setting)	-10 V ... +10 V		4
<b>AI 1</b>	Unipolar voltage input	0 V ... +10 V	p0756[1] =	0
	Unipolar voltage input monitored:	+2 V ... +10 V		1
	Unipolar current input	0 mA ... +20 mA		2
	Unipolar current input monitored	+4 mA ... +20 mA		3
	Bipolar voltage input (factory setting)	-10 V ... +10 V		4
<b>AI 2</b>	Unipolar current input (factory setting)	0 mA ... +20 mA	p0756[2] =	2
	Unipolar current input monitored	+4 mA ... +20 mA		3
	Temperature sensor	LG-Ni1000		6
	Temperature sensor	Pt1000		7
	No sensor connected	---		8
Temperature sensor	DIN-Ni1000 (6180 ppm / K)		10	
<b>AI 3</b>	Temperature sensor	LG-Ni1000	p0756[3] =	6
	Temperature sensor	Pt1000		7
	No sensor connected (factory setting)	---		8
	Temperature sensor	DIN-Ni1000 (6180 ppm / K)		10

In addition, you must also set the switch associated with the analog input. You can find the switch on the Control Unit behind the front doors.

- The DIP switch for AI0 and AI1 (current / voltage) on the Control Unit behind the lower front door.
- The DIP switch for AI2 (temperature / current) on the Control Unit behind the upper front door.



### Permissible measuring range of the temperature sensors

LG-Ni1000, DIN-Ni1000	- 88 °C ... 165 °C
Pt1000	- 88 °C ... 240 °C

For values outside the permissible measuring range, the inverter outputs Alarm A03520 "Temperature sensor fault".

### Characteristics

If you change the analog input type using p0756, then the inverter automatically selects the appropriate scaling of the analog input. The linear scaling characteristic is defined using two points (p0757, p0758) and (p0759, p0760). Parameters p0757 ... p0760 are assigned to an analog input via their index, e.g. parameters p0757[0] ... p0760[0] belong to analog input 0.




Figure 6-4 Examples for scaling characteristics

Parameter	Description
p0757	x coordinate of the 1st Characteristic point [V or mA]
p0758	y coordinate of the 1st Characteristic point [% of p200x] p200x are the parameters of reference variables, e.g. p2000 is the reference speed
p0759	x coordinate of the 2nd Characteristic point [V or mA]
p0760	y coordinate of the 2nd Characteristic point [% of p200x]
p0761	Wire breakage monitoring response threshold

## Adapting the characteristic

You must define your own characteristic if none of the default types match your particular application.

### Example


The inverter should convert a 6 mA ... 12 mA signal into the value range -100 % ... 100 % via analog input 0. The wire break monitoring of the inverter should respond when 6 mA is fallen below.

### Precondition

You have set analog input 0 as a current input ("I") via the DIP switch on the Control Unit.



### Procedure



Set the following parameters to set the analog input as current input with monitoring:

1. Set p0756[0] = 3  
This means that you define analog input 0 as current input with wire breakage monitoring.
2. Set p0757[0] = 6.0 (x1)
3. Set p0758[0] = -100.0 (y1)
4. Set p0759[0] = 12.0 (x2)
5. Set p0760[0] = 100.0 (y2)

## Defining the function of an analog input


You define the analog input function by interconnecting a connector input of your choice with parameter p0755. Parameter p0755 is assigned to the particular analog input based on its index, e.g. parameter p0755[0] is assigned to analog input 0.

Table 6- 3 Connector inputs (CI) of the inverter (selection)

CI	Significance	CI	Significance
p1070	Main setpoint	p1522	Torque limit, upper
p1075	Supplementary setpoint	p2253	Technology controller setpoint 1
p1503	Torque setpoint	p2264	Technology controller actual value
p1511	Supplementary torque 1		

A complete list of the connector inputs is provided in the List Manual.

**Defining the function of an analog input - example**



To enter a supplementary setpoint via analog input AI 0, you must interconnect AI 0 with the signal source for the supplementary setpoint:  
Set p1075 = 755[0].


**Advanced settings**

**Signal smoothing**

When required, you can smooth the signal, which you read-in via an analog input, using parameter p0753.

For more information, see the parameter list and in the function block diagrams 9566 ff of the List Manual.

**Skip frequency band**



Interferences in the cable can corrupt small signals of a few millivolts. To be able to enter a setpoint of exactly 0 V via an analog input, you must specify a skip frequency band.

Skip frequency band of the analog input


p0764[0]	<b>Skip frequency band of the analog input AI 0</b> (factory setting: 0)
p0764[1]	<b>Skip frequency band of the analog input AI 1</b> (factory setting: 0)

**Using an analog input as digital input**

An analog input can also be used as digital input. See also Section: Digital inputs (Page 156).

### 6.2.2.4 Analog outputs

#### Overview



Changing the function of an analog output:

1. Define the analog output type using parameter p0776.
2. Interconnect parameter p0771 with a connector output of your choice.

See also Section: Interconnecting signals in the converter (Page 447).

Connector outputs are marked with "CO" in the parameter list of the List Manual.

#### Defining the analog output type

The inverter offers a series of default settings, which you can select using parameter p0776:

AO 0	Current output (factory setting) Voltage output Current output	0 mA ... +20 mA 0 V ... +10 V +4 mA ... +20 mA	p0776[0] =	0 1 2
AO 1	Current output (factory setting) Voltage output Current output	0 mA ... +20 mA 0 V ... +10 V +4 mA ... +20 mA	p0776[1] =	0 1 2

#### Characteristics

If you change the analog output type, then the inverter automatically selects the appropriate scaling of the analog output. The linear scaling characteristic is defined using two points (p0777, p0778) and (p0779, p0780).




Figure 6-5 Examples for scaling characteristics

Parameters p0777 ... p0780 are assigned to an analog output via their index, e.g. parameters p0777[0] ... p0770[0] belong to analog output 0.

Table 6- 4 Parameters for the scaling characteristic

Parameter	Description
p0777	<b>x coordinate of the 1st Characteristic point [% of p200x]</b> p200x are the parameters of the reference variables, e.g. p2000 is the reference speed.
p0778	<b>y coordinate of the 1st Characteristic point [V or mA]</b>
p0779	<b>x coordinate of the 2nd Characteristic point [% of p200x]</b>
p0780	<b>y coordinate of the 2nd Characteristic point [V or mA]</b>


### Setting the characteristic

You must define your own characteristic if none of the default types match your particular application.

#### Example:

Via analog output 0, the inverter should convert a signal in the value range 0 % ... 100 % into an output signal 6 mA ... 12 mA.

#### Procedure



Set the following parameters to set the characteristic to match the example:

1. Set p0776[0] = 2  
This defines analog output 0 as a current output.
2. Set p0777[0] = 0.0 (x1)
3. Set p0778[0] = 6.0 (y1)
4. Set p0779[0] = 100.0 (x2)
5. Set p0780[0] = 12.0 (y2)

### Defining the function of an analog output

You define the analog output function by interconnecting parameter p0771 with a connector output of your choice. Parameter p0771 is assigned to the particular analog output via its index, e.g. parameter p0771[0] is assigned to analog output 0.


Table 6- 5 Connector outputs (CO) of the inverter (selection)

CO	Meaning	CO	Meaning
r0021	Actual frequency	r0026	Actual DC-link voltage
r0024	Output actual frequency	r0027	Output current
r0025	Output actual frequency		

A complete list of the connector outputs is provided in the List Manual.

For more information, please see the parameter list and the function block diagrams 2261 of the List Manual.

### Defining the function of an analog output - example



To output the inverter output current via analog output 0, you must interconnect AO 0 with the signal for the output current: Set p0771 = 27.

### Advanced settings

You can manipulate the signal that you output via an analog output, as follows:






- Absolute-value generation of the signal (p0775)
- Signal inversion (p0782)

Additional information is provided in the parameter list of the List Manual.

### 6.2.3 Inverter control using digital inputs

Five different methods are available for controlling the motor via digital inputs.

Table 6- 6 Two-wire control and three-wire control

Behavior of the motor	Control commands	Typical application
 <p>Clockwise rotation   Stop   Counter-clockwise rotation   Stop</p>		
	<p><b>Two-wire control, method 1</b></p> <ol style="list-style-type: none"> <li>1. Switching the motor on and off (ON/OFF1).</li> <li>2. Reverse the motor direction of rotation.</li> </ol>	<p>Local control in conveyor systems.</p>
	<p><b>Two-wire control, method 2 and two-wire control, method 3</b></p> <ol style="list-style-type: none"> <li>1. Switch the motor on and off (ON/OFF1), clockwise rotation.</li> <li>2. Switch the motor on and off (ON/OFF1), counter-clockwise rotation.</li> </ol>	<p>Traction drives with control via joystick</p>
	<p><b>Three-wire control, method 1</b></p> <ol style="list-style-type: none"> <li>1. Enable signal for switching the motor on and off (OFF1).</li> <li>2. Switch on the motor (ON), clockwise rotation.</li> <li>3. Switch on the motor (ON), counter-clockwise rotation.</li> </ol>	<p>Traction drives with control via joystick</p>
	<p><b>Three-wire control, method 2</b></p> <ol style="list-style-type: none"> <li>1. Enable signal for switching the motor on and off (OFF1).</li> <li>2. Switch on motor (ON).</li> <li>3. Reverse the motor direction of rotation.</li> </ol>	<p>-</p>

Reversing is disabled in the factory setting. To use the "Reverse" function, you must release the negative rotational direction, see Section Enable direction of rotation (Page 213).

## 6.2.4 Two-wire control: method 1

You switch the motor on and off using a control command (ON/OFF1) while the other control command reverses the motor direction of rotation.




Figure 6-6 Two-wire control, method 1

Table 6-7 Function table

ON/OFF1	Reversing	Function
0	0	OFF1: The motor stops.
0	1	OFF1: The motor stops.
1	0	ON: Clockwise motor rotation.
1	1	ON: Counter-clockwise motor rotation.

Parameter	Description		
p0015 = 12	<b>Macro drive unit</b>		
	Controlling the motor using the digital inputs of the inverter:	DI 0	DI 1
		ON/OFF1	Reversing
<b>Advanced setting</b>			
Interconnecting control commands with digital inputs of your choice.			
p0840[0 ... n] = 722.x	<b>BI: ON/OFF1 (ON/OFF1)</b> Example: p0840[0] = 722.3 ⇒ if CDS 0 (index[0]) is selected, the inverter receives its ON/OFF1 command via DI 3.		
p1113[0 ... n] = 722.x	<b>BI: Setpoint inversion (reversing)</b>		

### 6.2.5 Two-wire control, method 2

You switch the motor on and off using a control command (ON/OFF1) and at the same time select clockwise motor rotation. You also use the other control command to switch the motor on and off, but in this case you select counter-clockwise rotation for the motor.

The inverter only accepts a new control command when the motor is at a standstill.




Figure 6-7 Two-wire control, method 2

Table 6-8 Function table

ON/OFF1 clockwise rotation	ON/OFF1 counter-clockwise rotation	Function
0	0	OFF1: The motor stops.
1	0	ON: Clockwise motor rotation.
0	1	ON: Counter-clockwise motor rotation.
1	1	ON: The motor direction of rotation is based on the signal that assumes status "1" first.

Parameter	Description		
p0015 = 17	<b>Macro drive unit</b>		
	Controlling the motor using the digital inputs of the inverter:	DI 0	DI 1
		ON/OFF1 clockwise rotation	ON/OFF1 counter-clockwise rotation
<b>Advanced setting</b>			
Interconnecting control commands with digital inputs of your choice.			
p3330[0 ... n] = 722.x	<b>BI: 2/3 wire control command 1</b> (ON/OFF1 clockwise rotation)		
p3331[0 ... n] = 722.x	<b>BI: 2/3 wire control command 2</b> (ON/OFF1 counter-clockwise rotation) Example: p3331[0] = 722.0 ⇒ if CDS 0 (index[0]) is selected, the inverter receives its ON/OFF1 counter-clockwise command via DI 0.		

## 6.2.6 Two-wire control, method 3

You switch the motor on and off using a control command (ON/OFF1) and at the same time select clockwise motor rotation. You also use the other control command to switch the motor on and off, but in this case you select counter-clockwise rotation for the motor.

Unlike method 2, the inverter will accept the control commands at any time, regardless of the motor speed.




Figure 6-8 Two-wire control, method 3

Table 6-9 Function table

ON/OFF1 clockwise rotation	ON/OFF1 counter-clockwise rotation	Function
0	0	OFF1: The motor stops.
1	0	ON: Clockwise motor rotation.
0	1	ON: Counter-clockwise motor rotation.
1	1	OFF1: The motor stops.

Parameter	Description		
p0015 = 18	<b>Macro drive unit</b>		
	Controlling the motor using the digital inputs of the inverter:	DI 0 ON/OFF1 clockwise rotation	DI 1 ON/OFF1 counter-clockwise rotation
<b>Advanced setting</b> Interconnecting control commands with digital inputs of your choice.			
p3330[0 ... n] = 722.x	<b>BI: 2/3 wire control command 1</b> (ON/OFF1 clockwise rotation)		
p3331[0 ... n] = 722.x	<b>BI: 2/3 wire control command 2</b> (ON/OFF1 counter-clockwise rotation) Example: p3331[0] = 722.0 ⇒ if CDS 0 (index[0]) is selected, the inverter receives its ON/OFF1 counter-clockwise command via DI 0.		

### 6.2.7 Three-wire control, method 1

With one control command, you enable the two other control commands. You switch the motor off by withdrawing the enable (OFF1).

You switch the motor's direction of rotation to clockwise rotation with the positive edge of the second control command. If the motor is still switched off, switch it on (ON).

You switch the motor's direction of rotation to counter-clockwise rotation with the positive edge of the third control command. If the motor is still switched off, switch it on (ON).




Figure 6-9 Three-wire control, method 1

Table 6- 10 Function table

Enable / OFF1	ON clockwise rotation	ON counter-clockwise rotation	Function
0	0 or 1	0 or 1	OFF1: The motor stops.
1	0→1	0	ON: Clockwise motor rotation.
1	0	0→1	ON: Counter-clockwise motor rotation.
1	1	1	OFF1: The motor stops.

Parameter	Description			
p0015 = 19	<b>Macro drive unit</b>			
	Controlling the motor using the digital inputs of the inverter:	DI 0	DI 1	DI 2
		Enable / OFF1	ON clockwise rotation	ON counter-clockwise rotation
<b>Advanced setting</b>				
Interconnecting control commands with digital inputs of your choice (DI x).				
p3330[0 ... n] = 722.x	<b>BI: 2/3 wire control command 1</b> (enable/OFF1)			
p3331[0 ... n] = 722.x	<b>BI: 2/3 wire control command 2</b> (ON clockwise rotation)			
p3332[0 ... n] = 722.x	<b>BI: 2/3 wire control command 3</b> (ON counter-clockwise rotation)			
	Example: p3332[0] = 722.0 ⇒ if CDS 0 (index[0]) is selected, the inverter receives its ON counter-clockwise command via DI 0.			

## 6.2.8 Three-wire control, method 2

With one control command, you enable the two other control commands. You switch the motor off by withdrawing the enable (OFF1).

You switch on the motor with the positive edge of the second control command (ON).

The third control command defines the motor's direction of rotation (reversing).




Figure 6-10 Three-wire control, method 2

Table 6- 11 Function table

Enable / OFF1	ON	Reversing	Function
0	0 or 1	0 or 1	OFF1: The motor stops.
1	0→1	0	ON: Clockwise motor rotation.
1	0→1	1	ON: Counter-clockwise motor rotation.

Parameter	Description			
p0015 = 20	<b>Macro drive unit</b>			
	Controlling the motor using the digital inputs of the inverter:	DI 0	DI 1	DI 2
		Enable / OFF1	ON	Reversing
<b>Advanced setting</b>				
Interconnecting control commands with digital inputs of your choice (DI x).				
p3330[0 ... n] = 722.x	<b>BI: 2/3 wire control command 1 (enable/OFF1)</b>			
p3331[0 ... n] = 722.x	<b>BI: 2/3 wire control command 2 (ON)</b> Example: p3331[0] = 722.0 ⇒ if CDS 0 (index[0]) is selected, the inverter receives its ON command via DI 0.			
p3332[0 ... n] = 722.x	<b>BI: 2/3 wire control command 3 (reversing)</b>			

### 6.2.9 Running the motor in jog mode (JOG function)

The "Jog" function is typically used to slowly move a machine part, e.g. a conveyor belt.

With the "Jog" function, you switch the motor on and off using a digital input. When the motor is switched on, it accelerates to the jogging setpoint. There are two different setpoints available, e.g. for motor counter-clockwise rotation and clockwise rotation.

The same ramp-function generator acts on the setpoint as for the ON/OFF1 command.





Figure 6-11 Behavior of the motor when "jogging"

The inverter must be ready to start before you issue the "Jog" control command. If the motor is already switched on, then the "Jog" command has no effect.



#### Jog settings

Parameter	Description	
p1058	Jogging 1 speed setpoint (factory setting 150 rpm)	
p1059	Jogging 2 speed setpoint (factory setting -150 rpm)	
p1082	Maximum speed (factory setting 1500 rpm)	
p1110	<b>Inhibit negative direction</b>	
	=0: Negative direction of rotation is enabled	=1: Negative direction of rotation is inhibited
p1111	<b>Inhibit positive direction</b>	
	=0: Positive direction of rotation is enabled	=1: Positive direction of rotation is inhibited
p1113	<b>Setpoint inversion</b>	
	=0: Setpoint is not inverted	=1: Setpoint is inverted
p1120	Ramp-function generator ramp-up time (factory setting 10 s)	
p1121	Ramp-function generator ramp-down time (factory setting 10 s)	
p1055 = 722.0	Jog bit 0: Select jogging 1 via digital input 0	
p1056 = 722.1	Jog bit 1: Select jogging 2 via digital input 1	



Interconnection of the process data




Figure 6-13 Interconnection of the send words




Figure 6-14 Interconnection of the receive words

The telegrams use - with the exception of telegram 999 (free interconnection) - the word-by-word transfer of send and receive data (r2050/p2051).

If you require an individual telegram for your application (e.g. for transferring double words), you can adjust one of the predefined telegrams via parameters p0922 and p2079. For details, please refer to the List Manual, function diagrams 2420 and 2472.

### 6.2.10.1 Control and status word 1

#### Control word 1 (STW1)

Bit	Significance		Explanation	Signal inter-connection in the inverter
	Telegram 20	All other telegrams		
0	0 = OFF1		The motor brakes with the ramp-down time p1121 of the ramp-function generator. The inverter switches off the motor at standstill.	p0840[0] = r2090.0
	0 → 1 = ON		The inverter goes into the "ready" state. If, in addition bit 3 = 1, then the inverter switches on the motor.	
1	0 = OFF2		Switch off the motor immediately, the motor then coasts down to a standstill.	p0844[0] = r2090.1
	1 = No OFF2		The motor can be switched on (ON command).	
2	0 = Quick stop (OFF3)		Quick stop: The motor brakes with the OFF3 ramp-down time p1135 down to standstill.	p0848[0] = r2090.2
	1 = No quick stop (OFF3)		The motor can be switched on (ON command).	
3	0 = Inhibit operation		Immediately switch-off motor (cancel pulses).	p0852[0] = r2090.3
	1 = Enable operation		Switch-on motor (pulses can be enabled).	
4	0 = Disable RFG		The inverter immediately sets its ramp-function generator output to 0.	p1140[0] = r2090.4
	1 = Do not disable RFG		The ramp-function generator can be enabled.	
5	0 = Stop RFG		The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5
	1 = Enable RFG		The output of the ramp-function generator follows the setpoint.	
6	0 = Inhibit setpoint		The inverter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	p1142[0] = r2090.6
	1 = Enable setpoint		Motor accelerates with the ramp-up time p1120 to the setpoint.	
7	0 → 1 = Acknowledge faults		Acknowledge fault. If the ON command is still active, the inverter switches to "closing lockout" state.	p2103[0] = r2090.7
8, 9	Reserved			

Bit	Significance		Explanation	Signal inter-connection in the inverter
	Telegram 20	All other telegrams		
10	0 = No control via PLC		Inverter ignores the process data from the fieldbus.	p0854[0] = r2090.10
	1 = Control via PLC		Control via fieldbus, inverter accepts the process data from the fieldbus.	
11	1 = Direction reversal		Invert setpoint in the inverter.	p1113[0] = r2090.11
12	Not used			
13	--- <sup>1)</sup>	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13
14	--- <sup>1)</sup>	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14
15	CDS bit 0	Reserved	Changes over between settings for different operation interfaces (command data sets).	p0810 = r2090.15

<sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

## Status word 1 (ZSW1)

Bit	Significance		Comments	Signal inter-connection in the inverter
	Telegram 20	All other telegrams		
0	1 = Ready to start		Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready		Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the inverter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled		Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active		The inverter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive		Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive		Quick stop is not active.	p2080[5] = r0899.5
6	1 = Closing lockout active		It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active		Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range		Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested		The automation system is requested to accept the inverter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded		Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = current or torque limit reached	1 = torque limit reached	Comparison value for current or torque has been reached or exceeded.	p2080[11] = r0056.13 / r1407.7
12	--- <sup>1)</sup>	1 = Holding brake open	Signal to open and close a motor holding brake.	p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature		--	p2080[13] = r2135.14
14	1 = Motor rotates clockwise		Internal inverter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counterclockwise		Internal inverter actual value < 0	
15	1 = CDS display	0 = Alarm, inverter thermal overload		p2080[15] = r0836.0 / r2135.15

<sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

6.2.10.2 Control and status word 3

Control word 3 (STW3)

Bit	Significance	Explanation	Signal interconnection in the inverter <sup>1)</sup>
	Telegram 350		
0	1 = fixed setpoint bit 0	Selects up to 16 different fixed setpoints.	p1020[0] = r2093.0
1	1 = fixed setpoint bit 1		p1021[0] = r2093.1
2	1 = fixed setpoint bit 2		p1022[0] = r2093.2
3	1 = fixed setpoint bit 3		p1023[0] = r2093.3
4	1 = DDS selection bit 0	Changes over between settings for different motors (drive data sets).	p0820 = r2093.4
5	1 = DDS selection bit 1		p0821 = r2093.5
6	Not used		
7	Not used		
8	1 = technology controller enable	--	p2200[0] = r2093.8
9	1 = enable DC braking	--	p1230[0] = r2093.9
10	Not used		
11	1 = Enable droop	Enable or inhibit speed controller droop.	p1492[0] = r2093.11
12	1 = torque control active 0 = speed control active	Changes over the control mode for vector control.	p1501[0] = r2093.12
13	1 = no external fault 0 = external fault is active (F07860)	--	p2106[0] = r2093.13
14	Not used		
15	1 = CDS bit 1	Changes over between settings for different operation interfaces (command data sets).	p0811[0] = r2093.15

<sup>1)</sup> If you switch from telegram 350 to a different one, then the inverter sets all interconnections p1020, ... to "0". Exception: p2106 = 1.

## Status word 3 (ZSW3)

Bit	Significance	Description	Signal interconnection in the inverter
0	1 = DC braking active	--	p2051[3] = r0053
1	1 = $ n_{act}  > p1226$	Absolute current speed > stationary state detection	
2	1 = $ n_{act}  > p1080$	Absolute actual speed > minimum speed	
3	1 = $i_{act} \geq p2170$	Actual current $\geq$ current threshold value	
4	1 = $ n_{act}  > p2155$	Absolute actual speed > speed threshold value 2	
5	1 = $ n_{act}  \leq p2155$	Absolute actual speed < speed threshold value 2	
6	1 = $ n_{act}  \geq r1119$	Speed setpoint reached	
7	1 = DC link voltage $\leq p2172$	Actual DC link voltage $\leq$ threshold value	
8	1 = DC link voltage > p2172	Actual DC link voltage > threshold value	
9	1 = ramp-up or ramp-down completed	Ramp-function generator is not active.	
10	1 = technology controller output at the lower limit	Technology controller output $\leq p2292$	
11	1 = technology controller output at the upper limit	Technology controller output > p2291	
12	Not used		
13	Not used		
14	Not used		
15	Not used		

6.2.10.3 NAMUR message word

Fault word according to the VIK-NAMUR definition (MELD\_NAMUR)

Table 6- 13 Fault word according to the VIK-NAMUR definition and interconnection with parameters in the inverter

Bit	Significance	P no.
0	1 = Control Unit signals a fault	p2051[5] = r3113
1	1 = line fault: Phase failure or inadmissible voltage	
2	1 = DC link overvoltage	
3	1 = Power Module fault, e.g. overcurrent or overtemperature	
4	1 = inverter overtemperature	
5	1 = ground fault/phase fault in the motor cable or in the motor	
6	1 = motor overload	
7	1 = communication error to the higher-level control system	
8	1 = fault in a safety-relevant monitoring channel	
10	1 = fault in the internal inverter communication	
11	1 = line fault	
15	1 = other fault	

6.2.10.4 Data structure of the parameter channel

Structure of the parameter channel

The parameter channel consists of four words. 1. and 2nd word transfer the parameter number and index as well as the type of job (read or write) The 3rd and 4th word contains the parameter contents. The parameter contents can be 16-bit values (such as baud rate) or 32-bit values (e.g. CO parameters).

Bit 11 in the 1st word is reserved and is always assigned 0.

Parameter channel							
PKE (1st word)			IND (2nd word)			PWE (3rd and 4th words)	
15 ... 12	11	10 ... 0	15 ... 8	7 ... 0	15 ... 0	15 ... 0	
AK	S P M	PNU	Subindex	Page index	PWE 1	PWE 2	

You can find examples of telegrams at the end of this section.

## Request and response IDs

Bits 12 ... 15 of the 1st word of the parameter channel contain the request and response identifier.

Table 6- 14 Request identifiers, control → inverter

Request identifier	Description	Response identifier	
		positive	negative
0	No request	0	7 / 8
1	Request parameter value	1 / 2	7 / 8
2	Change parameter value (word)	1	7 / 8
3	Change parameter value (double word)	2	7 / 8
4	Request descriptive element <sup>1)</sup>	3	7 / 8
6 <sup>2)</sup>	Request parameter value (field) <sup>1)</sup>	4 / 5	7 / 8
7 <sup>2)</sup>	Change parameter value (field, word) <sup>1)</sup>	4	7 / 8
8 <sup>2)</sup>	Change parameter value (field, double word) <sup>1)</sup>	5	7 / 8
9	Request number of field elements	6	7 / 8

<sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

<sup>2)</sup> The following request IDs are identical: 1 ≡ 6, 2 ≡ 7 3 ≡ 8.  
We recommend that you use identifiers 6, 7, and 8.

Table 6- 15 Response identifiers, inverter → control

Response identifier	Description
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
3	Transfer descriptive element <sup>1)</sup>
4	Transfer parameter value (field, word) <sup>2)</sup>
5	Transfer parameter value (field, double word) <sup>2)</sup>
6	Transfer number of field elements
7	Inverter cannot process the request. In the most significant word of the parameter channel, the inverter sends an error number to the control, refer to the following table.
8	No master controller status / no authorization to change parameters of the parameter channel interface

<sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

<sup>2)</sup> The required element of the indexed parameter is specified in IND (2nd word).

Table 6- 16 Error numbers for response identifier 7

No.	Description
00 hex	<b>Illegal parameter number</b> (access to a parameter that does not exist)
01 hex	<b>Parameter value cannot be changed</b> (change request for a parameter value that cannot be changed)
02 hex	<b>Lower or upper value limit exceeded</b> (change request with a value outside the value limits)
03 hex	<b>Incorrect subindex</b> (access to a subindex that does not exist.)
04 hex	<b>No array</b> (access with a subindex to non-indexed parameters)
05 hex	<b>Incorrect data type</b> (change request with a value that does not match the data type of the parameter)
06 hex	<b>Setting not permitted, only resetting</b> (change request with a value not equal to 0 without permission)
07 hex	<b>Descriptive element cannot be changed</b> (change request to a descriptive element error value that cannot be changed)
0B hex	<b>No master control</b> (change request but with no master control, see also p0927.)
0C hex	<b>Keyword missing</b>
11 hex	<b>Request cannot be executed due to the operating state</b> (access is not possible for temporary reasons that are not specified)
14 hex	<b>Inadmissible value</b> (change request with a value that is within the limits but which is illegal for other permanent reasons, i.e. a parameter with defined individual values)
65 hex	<b>Parameter number is currently deactivated</b> (depending on the mode of the inverter)
66 hex	<b>Channel width is insufficient</b> (communication channel is too small for response)
68 hex	<b>Illegal parameter value</b> (parameter can only assume certain values)
6A hex	<b>Request not included / task is not supported</b> (the valid request identifications can be found in table "Request identifications controller → inverter")
6B hex	<b>No change access for a closed-loop controller that is enabled.</b> (The operating state of the inverter prevents a parameter change.)
86 hex	<b>Write access only for commissioning (p0010 = 15)</b> (operating status of the inverter prevents a parameter change)
87 hex	<b>Know-how protection active, access locked</b>
C8 hex	<b>Change request below the currently valid limit</b> (change request to a value that lies within the "absolute" limits, but is however below the currently valid lower limit)
C9 hex	<b>Change request above the currently valid limit</b> (example: a parameter value is too large for the inverter power)
CC hex	<b>Change request not permitted</b> (change is not permitted as the access code is not available)

## Offset and page index of the parameter numbers

- Parameter numbers < 2000 PNU = parameter number.  
Write the parameter number into the PNU (PKE bit 10 ... 0).
- Parameter numbers ≥ 2000 PNU = parameter number - offset.  
Write the parameter number minus the offset into the PNU (PKE bit 10 ... 0).  
Write the offset in the page index (IND bit 7 ... 0).

Parameter number	Offset	Page index								
		Hex	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0000 ... 1999	0	0 hex	0	0	0	0	0	0	0	0
2000 ... 3999	2000	80 hex	1	0	0	0	0	0	0	0
6000 ... 7999	6000	90 hex	1	0	0	1	0	0	0	0
8000 ... 9999	8000	20 hex	0	0	1	0	0	0	0	0
10000 ... 11999	10000	A0 hex	1	0	1	0	0	0	0	0
20000 ... 21999	20000	50 hex	0	1	0	1	0	0	0	0
30000 ... 31999	30000	F0 hex	1	1	1	1	0	0	0	0
60000 ... 61999	60000	74 hex	0	1	1	1	0	1	0	0

## Indexed parameters

For indexed parameters, you must write the index as hex value into the subindex (IND bit 15 ... 8).

## Parameter contents

Parameter contents can be parameter values or connectors.

Table 6- 17 Parameter values in the parameter channel

PWE, 3rd word	PWE, 4th word	
Bit 15 ... 0	Bit 15 ... 8	Bit 7 ... 0
0	0	8-bit value
0	16-bit value	
32-bit value		

Table 6- 18 Connectors in the parameter channel

PWE, 3rd word	PWE, 4th word	
Bit 15 ... 0	Bit 15 ... 10	Bit 9 ... 0
Number of the connector	3F hex	The index or bit field number of the connector



**Write request: Assign digital input 2 with the function ON/OFF1 (p0840[1] = 722.2)**

In order to link digital input 2 with ON/OFF1, you must assign parameter p0840[1] (source, ON/OFF1) the value 722.2 (DI 2). To do this, you must fill the telegram of the parameter channel as follows:

- PKE, bit 12 ... 15 (AK): = 7 hex (change, parameter value (field, word))
- PKE, bit 0 ... 10 (PNU): = 348 hex (840 = 348 hex, no offset, as 840 < 1999)
- IND, bit 8 ... 15 (subindex): = 1 hex (CDS1 = index1)
- IND, bit 0 ... 7 (page index): = 0 hex (offset 0  $\triangleq$  0 hex)
- PWE1, bit 0 ... 15: = 2D2 hex (722 = 2D2 hex)
- PWE2, bit 10 ... 15: = 3F hex (drive object - for SINAMICS G120, always 63 = 3f hex)
- PWE2, bit 0 ... 9: = 2 hex (index of parameter (DI 2 = 2))

Parameter channel							
PKE, 1st word		IND, 2nd word		PWE1 - high, 3rd word		PWE2 - low, 4th word	
15 ... 12	11 ... 10	15 ... 8	7 ... 0	15 ... 0		15 ... 10	9 ... 0
AK	Parameter number	Subindex	Page index	Parameter value		Drive Object	Index
011110	01101001000	00000001	00000000	00000010	11011010010	1111111	000000010

Figure 6-17 Telegram, to assign DI 2 with ON/OFF1

**"Reading and writing parameters" application example**

See: Reading and writing parameters via PROFIBUS

(<http://support.automation.siemens.com/WW/view/en/8894584>).

**6.2.10.6 Extend telegrams and change signal interconnection**

When you have selected a telegram, the inverter interconnects the corresponding signals with the fieldbus interface. Generally, these interconnections are protected so that they cannot be changed. With the appropriate inverter settings, these interconnections can be changed.

**Extend telegram**

Every telegram can be extended, by "attaching" additional signals.

**Procedure**

1 Proceed as follows to extend a telegram:

1. Using STARTER or an operator panel, set parameter p0922 = 999.
2. Set parameter p2079 to the appropriate value of the corresponding telegram.
3. Interconnect additional PZD send words and PZD receive words with signals of your choice via parameters r2050 and p2051.

■ You have extended the telegram.

Parameter	Description
p0922	<b>PROFIdrive telegram selection</b>
	999: Free telegram (message frame) configuration
p2079	<b>PROFIdrive PZD telegram selection extended</b>
	1: Standard telegram 1, PZD-2/2
	20: Standard telegram 20, PZD-2/6
	350: SIEMENS telegram 350, PZD-4/4
	352: SIEMENS telegram 352, PZD-6/6
	353: SIEMENS telegram 353, PZD-2/2, PKW-4/4
354: SIEMENS telegram 354, PZD-6/6, PKW-4/4	
r2050[0...11]	<b>PROFIdrive PZD receive word</b> Connector output to interconnect the PZD (setpoints) in the word format received from the PROFIdrive controller.
p2051[0...16]	<b>PROFIdrive PZD send word</b> Selection of the PZD (actual values) in the word format to be sent to the PROFIdrive controller.

Selection of the PZD (actual values) in the word format to be sent to the PROFIdrive controller. For further information refer to the function block diagrams 2468 and 2470 of the List Manual.

### Freely selecting the signal interconnection of the telegram

The signals in the telegram can be freely interconnected.

#### Procedure



- 1 Proceed as follows to change the signal interconnection of a telegram:
  1. Using STARTER or an operator panel, set parameter p0922 = 999.
  2. Using STARTER or an operator panel, set parameter p2079 = 999.
  3. Interconnect additional PZD send words and PZD receive words with signals of your choice via parameters r2050 and p2051.
- You have freely interconnected the signals transferred in the telegram.

Parameter	Description
p0922	<b>PROFIdrive telegram selection</b>
	999: Free telegram (message frame) configuration
p2079	<b>PROFIdrive PZD telegram selection extended</b>
	999: Free telegram (message frame) configuration
r2050[0...11]	<b>PROFIdrive PZD receive word</b> Connector output to interconnect the PZD (setpoints) in the word format received from the PROFIdrive controller.
p2051[0...16]	<b>PROFIdrive PZD send word</b> Selection of the PZD (actual values) in the word format to be sent to the PROFIdrive controller.

For further information refer to the function block diagrams 2468 and 2470 of the List Manual.

### 6.2.10.7 Configuring the IP interface

#### Configure communication with STARTER

STARTER provides a screen form to set the communication with the control system.

Open the dialog screen form "Control\_Unit/Communication/Commissioning interface" and activate the "Configure IP interfaces" tab

Commissioning interfaces | IP interface configuration

PROFINET onboard / X150

DHCP mode: [0] DHCP off

Device name:

Device address:

Standard gateway:

Subnet mask:

Activation: [0] No function

 For G devices, the settings only take effect after Power OFF -> ON!

- Set the DHCP mode to 0 (factory setting).
- Enter the device name, address, gateway and the address for the subnet mask.
- In the Activation field select "[2] Save and activate configuration".
- To activate the settings, you must switch off the inverter power supply and then switch on again.

You can also enter or read out data using the expert list. You can find the corresponding parameters in the number range r8909 ... p8925

### 6.2.10.8 Slave-to-slave communication

"Direct data exchange" is sometimes called "slave-to-slave communication" or "data exchange broadcast". Here, slaves exchange data without any direct involvement of the master.

You can find more information in: "Manuals for your inverter in the fieldbus function manual (Page 451)".

### **6.2.10.9 Acyclically reading and writing inverter parameters**

The inverter supports the writing and reading of parameters via acyclic communication:

- For PROFIBUS: Up to 240 bytes per write or read request via data set 47
- For PROFINET: Write or read requests via B02E hex and B02F hex

You will find more information on acyclic communication in the Fieldbus Function Manual; see also section: Manuals for your inverter (Page 451).

## 6.2.11 Control via additional fieldbuses

### 6.2.11.1 Modbus RTU

#### Settings for Modbus RTU

Parameter	Explanation		
p2020	<b>Fieldbus interface baudrate</b> (Factory setting: 7)	5: 4800 baud 6: 9600 baud 7: 19200 baud 8: 38400 baud 9: 57600 baud	10: 76800 baud 11: 93750 baud 12: 115200 baud 13: 187500 baud
p2021	<b>Fieldbus interface address</b> (Factory setting: 1) Valid USS addresses: 1 ... 247. The parameter is only active if address 0 is set at the Control Unit address switch. A change only becomes effective after the inverter power supply has been switched off and switched on again.		
p2024	<b>Fieldbus interface times</b> (Factory setting: [0] 1000 ms, [2] 0 ms)	[0] Maximum permissible telegram processing time of the Modbus slave [2] dead time between two telegrams	
r2029	<b>Fieldbus interface error statistics</b>	[0] number of error-free telegrams [1] number of rejected telegrams [2] number of framing errors [3] number of overrun errors	[4] number of parity errors [5] number of starting character errors [6] number of checksum errors [7] number of length errors
p2030 = 2	<b>Fieldbus interface protocol selection:</b> Modbus RTU		
p2031	<b>Fieldbus interface Modbus parity</b> (Factory setting: 2)	0: No parity 1: Odd parity 2: Even parity	
p2040	<b>Fieldbus interface monitoring time</b> (Factory setting: 100 ms) p2040 = 0: The monitoring is deactivated		

## Control word 1 (STW1)

Bit	Meaning	Explanation	Signal inter-connection in the inverter
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The inverter switches off the motor at standstill.	p0840[0] = r2090.0
	0 → 1 = ON	The inverter goes into the "ready" state. If, in addition bit 3 = 1, then the inverter switches on the motor.	
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	p0844[0] = r2090.1
	1 = No OFF2	The motor can be switched on (ON command).	
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 ramp-down time p1135 down to standstill.	p0848[0] = r2090.2
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).	
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	p0852[0] = r2090.3
	1 = Enable operation	Switch-on motor (pulses can be enabled).	
4	0 = Disable RFG	The inverter immediately sets its ramp-function generator output to 0.	p1140[0] = r2090.4
	1 = Do not disable RFG	The ramp-function generator can be enabled.	
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.	
6	0 = Inhibit setpoint	The inverter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	p1142[0] = r2090.6
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.	
7	0 → 1 = Acknowledge faults	Acknowledge fault. If the ON command is still active, the inverter switches to "closing lockout" state.	p2103[0] = r2090.7
8, 9	Reserved		
10	0 = No control via PLC	Inverter ignores the process data from the fieldbus.	p0854[0] = r2090.10
	1 = Control via PLC	Control via fieldbus, inverter accepts the process data from the fieldbus.	
11	1 = Direction reversal	Invert setpoint in the inverter.	p1113[0] = r2090.11
12	Reserved		
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14
15	Reserved		

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal inter-connection in the inverter
0	1 = Ready to start	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the inverter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The inverter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Closing lockout active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the inverter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor over-temperature	--	p2080[13] = r2135.14
14	1 = Motor rotates clockwise	Internal inverter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counter-clockwise	Internal inverter actual value < 0	
15	0 = Alarm, inverter thermal overload		p2080[15] = r2135.15

<sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

## Further information

You can find additional information about Modbus RTU in the "Fieldbuses" Function Manual: Manuals for the Control Unit

(<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

## 6.2.11.2 USS

## Settings for USS

Parameter	Explanation		
p2020	<b>Fieldbus interface baudrate</b> (Factory setting: 8)	4: 2400 baud 5: 4800 baud 6: 9600 baud 7: 19200 baud 8: 38400 baud	9: 57600 baud 10: 76800 baud 11: 93750 baud 12: 115200 baud 13: 187500 baud
p2021	<b>Fieldbus interface address</b> (Factory setting: 0) Valid USS addresses: 0 ... 30. The parameter is only active if address 0 is set at the Control Unit address switch. A change only becomes effective after the inverter power supply has been switched off and switched on again.		
p2022	<b>Fieldbus interface USS PZD number</b> (Factory setting: 2)		
p2023	<b>Fieldbus interface USS PKW number</b> (Factory setting: 127)	0: PKW 0 words 3: PKW 3 words 4: PKW 4 words 127: PKW variable	
p2024	<b>Fieldbus interface times</b> (Factory setting: [0] 1000 ms, [1] 0 ms, [2] 0 ms)	[0] Maximum permissible telegram processing time of the Modbus slave [1] Character delay time [2] dead time between two telegrams	
r2029	<b>Fieldbus interface error statistics</b>	[0] number of error-free telegrams [1] number of rejected telegrams [2] number of framing errors [3] number of overrun errors	[4] number of parity errors [5] number of starting character errors [6] number of checksum errors [7] number of length errors
p2030 = 1	<b>Fieldbus interface protocol selection: USS</b>		
p2031	<b>Fieldbus interface Modbus parity</b> (Factory setting: 2)	0: No parity 1: Odd parity 2: Even parity	
p2040	<b>Fieldbus interface monitoring time</b> (Factory setting: 100 ms) p2040 = 0: The monitoring is deactivated		

## Control word 1 (STW1)

Bit	Meaning	Explanation	Signal inter-connection in the inverter
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The inverter switches off the motor at standstill.	p0840[0] = r2090.0
	0 → 1 = ON	The inverter goes into the "ready" state. If, in addition bit 3 = 1, then the inverter switches on the motor.	
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	p0844[0] = r2090.1
	1 = No OFF2	The motor can be switched on (ON command).	
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 ramp-down time p1135 down to standstill.	p0848[0] = r2090.2
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).	
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	p0852[0] = r2090.3
	1 = Enable operation	Switch-on motor (pulses can be enabled).	
4	0 = Disable RFG	The inverter immediately sets its ramp-function generator output to 0.	p1140[0] = r2090.4
	1 = Do not disable RFG	The ramp-function generator can be enabled.	
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.	
6	0 = Inhibit setpoint	The inverter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	p1142[0] = r2090.6
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.	
7	0 → 1 = Acknowledge faults	Acknowledge fault. If the ON command is still active, the inverter switches to "closing lockout" state.	p2103[0] = r2090.7
8, 9	Reserved		
10	0 = No control via PLC	Inverter ignores the process data from the fieldbus.	p0854[0] = r2090.10
	1 = Control via PLC	Control via fieldbus, inverter accepts the process data from the fieldbus.	
11	1 = Direction reversal	Invert setpoint in the inverter.	p1113[0] = r2090.11
12	Reserved		
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14
15	Reserved		

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal inter-connection in the inverter
0	1 = Ready to start	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the inverter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The inverter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Closing lockout active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the inverter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature	--	p2080[13] = r2135.14
14	1 = Motor rotates clockwise	Internal inverter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counterclockwise	Internal inverter actual value < 0	
15	0 = Alarm, inverter thermal overload		p2080[15] = r2135.15

- 1) If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

## Further information

You can find additional information about USS in the "Fieldbuses" Function Manual: Manuals for the Control Unit (<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

## 6.2.11.3 CANopen

## The most important settings for CANopen

Parameter	Explanation			
p8620	<b>CAN Node ID</b> (Factory setting: 126) Valid USS addresses: 1 ... 247. The parameter is only active if address 0 is set at the Control Unit address switch. A change only becomes effective after the inverter power supply has been switched off and switched on again.			
p8622	<b>CAN Bit rate</b> (Factory setting: 6)	0: 1 Mbit/s 1: 800 kbit/s 2: 500 kbit/s	3: 250 kbit/s 4: 125 kbit/s 5: 50 kbit/s	6: 20 kbit/s 7: 10 kbit/s
p8700 ... p8707	<b>CAN Receive PDO n</b> (n = 1 ... 8)	[0] = COB-ID of the PDO [1] = Transmission Type of the PDO		
p8710 ... p8717	<b>CAN Receive Mapping for RPDO n</b> (n = 1 ... 8)	[0] = Mapped object 1 ... [3] = Mapped object 4		
p8720 ... p8727	<b>CAN Transmit PDO n</b> (n = 1 ... 8)	[0] = COB-ID of the PDO [1] = Transmission Type of the PDO [2] = Inhibit Time (in 100 µs) [3] = reserved [4] = Event Timer (in ms)		
p8730 ... p8737	<b>CAN Transmit Mapping for TPDO n</b> (n = 1 ... 8)	[0] = Mapped object 1 ... [3] = Mapped object 4		
p8744	<b>CAN PDO Mapping Konfiguration</b> (Factory setting: 2)	1: Predefined connection set 2: Free PDO mapping		
r8784	<b>CAN status word</b>	.00 Ready to switch on .01 Ready .02 Operation enabled .03 Fault active .04 No coast down active .05 No fast stop active .06 Switching-on inhibited active .07 Alarm active	.08 Can be freely interconnected (p8785) .09 Control requested .10 Target reached .11 Torque limit reached .12 Velocity equal to zero .14 Can be freely interconnected (p8786) .15 Can be freely interconnected (p8787)	
r8795	<b>CAN control word</b>	.00 ON/OFF1 .01 Do not activate coast down .02 Do not activate quick stop .03 Enable operation .04 Enable ramp-function generator .05 Freeze ramp-function generator continuation	.06 Enable speed setpoint .07 Acknowledge fault .08 Stop .11 Can be freely interconnected ... .15 Can be freely interconnected	

## Further information

You can find additional information about CANopen in the "Fieldbuses" Function Manual: Manuals for the Control Unit

(<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

6.2.11.4 BACnet MS/TP

Settings for BACnet MS/TP

Parameter	Explanation		
p2020	<b>Fieldbus interface baudrate</b> (Factory setting: 6)	6: 9600 baud 7: 19200 baud	8: 38400 baud 10: 76800 baud
p2021	<b>Fieldbus interface address</b> (Factory setting: 1) Valid USS addresses: 0 ... 127. The parameter is only active if address 0 is set at the Control Unit address switch. A change only becomes active after the inverter power supply is switched off and switched on again.		
p2024	<b>Fieldbus interface times</b>	[0] maximum permissible processing time (APDU timeout)	
p2025	<b>Fieldbus SS BACnet settings</b>	[0] = device object instance number [1] = info maximum number frames [2] = APDU number of retries [3] = maximum master address	
p2026	<b>Fieldbus interface BACnet COV increment</b> Change in value at which point the inverter sends and UnConfirmedCOVNotification or and ConfirmedCOVNotification.		
r2029	<b>Fieldbus interface error statistics</b>	[0] number of error-free telegrams [1] number of rejected telegrams [2] number of framing errors [3] number of overrun errors	[4] number of parity errors [5] number of starting character errors [6] number of checksum errors [7] number of length errors
p2030 = 5	<b>Fieldbus interface protocol selection</b> p0015 = 110 sets p2013 = 5 → BACnet MS/TP		

Control word 1 (STW1)

Bit	Meaning	Explanation	BACNet	Signal inter-connection in the inverter
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The inverter switches off the motor at standstill.	BV20	p0840[0] = r2090.0
	0 → 1 = ON	The inverter goes into the "ready" state. If, in addition bit 3 = 1, then the inverter switches on the motor.		
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	BV27	p0844[0] = r2090.1
	1 = No OFF2	The motor can be switched on (ON command).		

Bit	Meaning	Explanation	BACNet	Signal inter-connection in the inverter
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 ramp-down time p1135 down to standstill.	BV28	p0848[0] = r2090.2
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).		
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	BV26	p0852[0] = r2090.3
	1 = Enable operation	Switch-on motor (pulses can be enabled).		
4	0 = Disable RFG	The inverter immediately sets its ramp-function generator output to 0.	BV26	p1140[0] = r2090.4
	1 = Do not disable RFG	The ramp-function generator can be enabled.		
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	BV26	p1141[0] = r2090.5
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.		
6	0 = Inhibit setpoint	The inverter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	BV26	p1142[0] = r2090.6
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.		
7	0 → 1 = Acknowledge faults	Acknowledge fault. If the ON command is still active, the inverter switches to "closing lockout" state.	BV22	p2103[0] = r2090.7
8, 9	Reserved		N/A	---
10	0 = No control via PLC	Inverter ignores the process data from the fieldbus.	BV93	p0854[0] = r2090.10
	1 = Control via PLC	Control via fieldbus, inverter accepts the process data from the fieldbus.		
11	1 = Direction reversal	Invert setpoint in the inverter.	BV21	p1113[0] = r2090.11
12	Reserved		N/A	---
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	N/A	p1035[0] = r2090.13
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	N/A	p1036[0] = r2090.14
15	Reserved		N/A	---

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal interconnection in the inverter
0	1 = Ready to start	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the inverter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The inverter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Closing lockout active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the inverter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature	--	p2080[13] = r2135.14
14	1 = Motor rotates clockwise	Internal inverter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counterclockwise	Internal inverter actual value < 0	
15	0 = Alarm, inverter thermal overload		p2080[15] = r2135.15

- 1) If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

## Further information

You can find additional information about BACnet MS/TP in the "Fieldbuses" Function Manual: Manuals for the Control Unit

(<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

## 6.2.11.5 Ethernet/IP

## Settings for Modbus RTU

Parameter	Explanation		
p2030 = 10	<b>Fieldbus interface protocol selection:</b> Ethernet/IP		
p8920	<b>PN Name of Station</b>		
p8921	<b>PN IP address</b> (Factory setting: 0)		
p8922	<b>PN default gateway</b> (factory setting: 0)		
p8923	<b>PN Subnet Mask</b> (Factory setting: 0)		
p8924	<b>PN DHCP mode</b> (Factory setting: 0)	0: DHCP off 2: DHCP on, identification based on MAC address 3: DHCP on, identification based on Name of Station	
p8925	<b>PN interface configuration</b> (Factory setting: 0)	0: No function 1: Reserved 2: Save the configuration and activate 3: Delete configuration	
p8980	<b>Ethernet/IP profile</b> (Factory setting: 0) A change only becomes effective after the inverter power supply has been switched off and switched on again.	0: SINAMICS 1: ODVA AC/DC	
p8982	<b>Ethernet/IP ODVA speed scaling</b> (Factory setting: 128) A change only becomes effective after the inverter power supply has been switched off and switched on again.		
	123: 32	127: 2	131: 0.125
	124: 16	128: 1	132: 0.0625
	125: 8	129: 0.5	133: 0.03125
	126: 4	130: 0.25	

## Further information

You can find additional information about USS in the "Fieldbuses" Function Manual: Manuals for the Control Unit (<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

## 6.2.11.6 P1

## Settings for P1

Parameter	Explanation		
p2020	<b>Fieldbus interface baudrate</b> (Factory setting: 5)	5: 4800 baud 6: 9600 baud 7: 19200 baud	
p2021	<b>Fieldbus interface address</b> (Factory setting: 99) Valid USS addresses: 1 ... 99. The parameter is only active if address 0 is set at the Control Unit address switch. A change only becomes effective after the inverter power supply has been switched off and switched on again.		
p2024	<b>Fieldbus interface times</b> (Factory setting: [0] 1000 ms, [1] 0 ms, [2] 0 ms)	[0] Maximum permissible telegram processing time of the Modbus slave [1] Character delay time [2] dead time between two telegrams	
r2029	<b>Fieldbus interface error statistics</b>	[0] number of error-free telegrams [1] number of rejected telegrams [2] number of framing errors [3] number of overrun errors	[4] number of parity errors [5] number of starting character errors [6] number of checksum errors [7] number of length errors
p2030 = 1	<b>Fieldbus interface protocol selection:</b> USS		
p2040	<b>Fieldbus interface monitoring time</b> (Factory setting: 100 ms) p2040 = 0: The monitoring is deactivated		

## Further information

You can find additional information about P1 in the "Fieldbuses" Function Manual: Manuals for the Control Unit (<http://support.automation.siemens.com/WW/view/en/30563628/133300>).

### 6.2.12 Switching over the inverter control (command data set)


In some applications, it must be possible to switch over the master control for operating the inverter.

Example: The motor is to be operable either from a central control via the fieldbus or from a local control box via the terminal strip.

#### Command data set (CDS)

This means that you can set the inverter control in various ways and toggle between the settings. For instance, as described above, the inverter can either be operated via a fieldbus or via the terminal strip.

The settings in the inverter, which are assigned to a specific master control, are termed the command data set.



You select the command data set using parameter p0810. To do this, you must interconnect parameter p0810 with a control command of your choice, e.g. a digital input.




Figure 6-18 Example: Switching over the control via terminal strip to control via PROFIBUS or PROFINET


An overview of all the parameters that belong to the command data sets is provided in the List Manual.

**Note**

It takes approximately 4 ms to toggle between command data sets.

**Advanced settings**

To change the number of command data sets in STARTER, you must open your STARTER project offline.




- ① You can edit command data sets if, in the STARTER project tree, you select "Configuration".
- ② If you require more than two command data sets, then add command data sets using this button or remove them.
- ③, To simplify commissioning several command data sets, under the "Command data sets" tab
- ④ there is a copy function.

Figure 6-19 Editing command data sets in STARTER

Parameter	Description
p0010 = 15	<b>Drive commissioning: Data sets</b>
p0170	<b>Number of command data sets</b> (factory setting: 2) p0170 = 2, 3, or 4
p0010 = 0	<b>Drive commissioning: Ready</b>
r0050	<b>Displaying the number of the CDS that is currently active</b>
p0809[0]	<b>Number of the command data set to be copied (source)</b>
p0809[1]	<b>Number of the command data set to which the data is to be copied (target)</b>
p0809[2] = 1	<b>Copying is started</b> Once copying has been completed, the inverter sets p0809[2] to 0.
p0810	<b>Command data set selection CDS bit 0</b>
p0811	<b>Command data set selection CDS bit 1</b>
r0050	<b>Displaying the number of the CDS that is currently active</b>

## 6.3 Setpoints



The inverter receives its main setpoint from the setpoint source. The main setpoint generally specifies the motor speed.




Figure 6-20 Setpoint sources for the inverter

You have the following options when selecting the source of the main setpoint:

- Inverter analog input.
- Inverter fieldbus interface.
- Motorized potentiometer simulated in the inverter.
- Fixed setpoints saved in the inverter.

You have the same selection options when selecting the source of the supplementary setpoint.

Under the following conditions, the inverter switches from the main setpoint to other setpoints:

- When the technology controller is active and appropriately interconnected, its output specifies the motor speed.
- When jogging is active.
- When controlling from an operator panel or the STARTER PC tool.

### 6.3.1 Analog input as setpoint source

#### Interconnecting an analog input

If you have selected a pre-assignment without a function of the analog input, then you must interconnect the parameter of the main setpoint with an analog input.




Figure 6-21 Example: Analog input 0 as setpoint source

Table 6- 19 Setting with analog input 0 as setpoint source

Parameter	Remark
p1070 = 755[0]	<b>Main setpoint</b> Interconnect the main setpoint with analog input 0
p1075 = 755[0]	<b>Additional setpoint</b> Interconnect the additional setpoint with analog input 0

You must adapt the analog input to the connected signal, e.g.  $\pm 10$  V or 4 ... 20 mA. You will find additional information in the section: Analog inputs (Page 159).

## 6.3.2 Specifying the setpoint via the fieldbus

### Interconnecting the fieldbus with the main setpoint



Figure 6-22 Fieldbus as setpoint source

Most standard telegrams receive the speed setpoint as a second process data PZD2.

Table 6- 20 Setting the fieldbus as setpoint source

Parameter	Remark
p1070 = 2050[1]	<b>Main setpoint</b> Interconnect the main setpoint with process data PZD2 from the fieldbus.
p1075 = 2050[1]	<b>Additional setpoint</b> Interconnect the additional setpoint with process data PZD2 from the fieldbus.

### 6.3.3 Motorized potentiometer as setpoint source

The "Motorized potentiometer" function emulates an electromechanical potentiometer. The output value of the motorized potentiometer can be set with the "higher" and "lower" control signals.

#### Interconnecting the motorized potentiometer (MOP) with the setpoint source




Figure 6-23 Motorized potentiometer as setpoint source




Figure 6-24 Function chart of the motorized potentiometer

Table 6- 21 Basic setup of motorized potentiometer

Parameter	Description
p1035	<b>Motorized potentiometer setpoint higher</b>
p1036	<b>Motorized potentiometer setpoint lower</b>
Interconnect these commands with signals of your choice.	
p1040	<b>MOP start value</b> (factory setting: 0 rpm) Defines the start value [rpm] that is effective when the motor is switched on.
p1047	<b>MOP ramp-up time</b> (factory setting: 10 s)
p1048	<b>MOP ramp-down time</b> (factory setting: 10 s)
r1050	<b>Motorized potentiometer setpoint after the ramp-function generator</b>
p1070 = 1050	<b>Main setpoint</b>

Table 6- 22 Extended setup of motorized potentiometer

Parameter	Description
p1030	<b>MOP configuration</b> (factory setting: 00110 bin)
.00	Storage active = 0: After the motor has been switched on, the setpoint = p1040 = 1: After the motor has switched off, the inverter saves the setpoint. After the motor has switched on, the setpoint = the stored value
.01	Automatic mode, ramp-function generator active (1-signal via BI: p1041) = 0: Ramp-up/ramp-down time = 0 = 1: With ramp-function generator In manual mode (p1041 = 0), the ramp-function generator is always active.
.02	Initial rounding active 1: With initial rounding. Using the initial rounding function it is possible to enter very small setpoint changes
.03	Storage in NVRAM active 1: If bit 00 = 1, the setpoint is retained during a power failure
.04	Ramp-function generator always active 1: The inverter also calculates the ramp-function generator when the motor is switched off
p1037	<b>MOP maximum speed</b> (factory setting: 0 rpm) Automatically pre-assigned when commissioning
p1038	<b>MOP minimum speed</b> (factory setting: 0 rpm) Automatically pre-assigned when commissioning
p1039	<b>Motorized potentiometer, inversion</b> (factory setting: 0) Signal source for inverting the minimum speed / velocity or maximum speed / velocity
p1041	<b>Motorized potentiometer, manual/automatic</b> (factory setting: 0) Signal source for switchover from manual to automatic
p1043	<b>Motorized potentiometer, accept setting value</b> (factory setting: 0) Signal source for accepting the setting value. The motorized potentiometer accepts the setting value p1044 on signal change p1043 = 0 → 1.
p1044	<b>MOP setting value</b> (factory setting: 0) Signal source for the setting value.

For more information about the motorized potentiometer, refer to function diagram 3020 in the List Manual.

### 6.3.4 Fixed speed as setpoint source

In many applications after switching on the motor, all that is needed is to run the motor at a constant speed or to switch between different speeds.

Example: After it has been switched on, a conveyor belt only runs with two different velocities.

#### Interconnecting the fixed speeds with a main setpoint




Figure 6-25 Fixed speeds as setpoint source

Table 6- 23 Setting the fixed speed as a setpoint source

Parameter	Remark
p1070 = 1024	<b>Main setpoint</b> Interconnecting the main setpoint with fixed speeds.

#### Select fixed setpoint by direct or binary selection

The converter distinguishes between two methods for selecting the fixed setpoints:

1. Direct selection:

You set 4 different fixed setpoints. By adding one or more of the four fixed setpoints, up to 16 different resulting setpoints are obtained.




Figure 6-26 Simplified function diagram for directly selecting fixed setpoints

Additional information about direct selection can be found in function diagram 3011 in the List Manual.

## 2. Binary selection:

You set 16 different fixed setpoints. You precisely select one of these 16 fixed setpoints by a combination of four selection bits.




Figure 6-27 Simplified function diagram for binary selection of the setpoints

Additional information about binary selection can be found in function diagram 3010 in the List Manual.

## Parameter for setting the fixed setpoints

Parameter	Description
p1001	<b>Fixed speed setpoint 1</b> (factory setting: 0 rpm)
p1002	<b>Fixed speed setpoint 2</b> (factory setting: 0 rpm)
...	...
p1015	<b>Fixed speed setpoint 15</b> (factory setting: 0 rpm)
p1016	<b>Speed fixed setpoint mode</b> (factory setting: 1)
	1: Direct 2: Binary
p1020	<b>Speed fixed setpoint selection bit 0</b> (factory setting: 0)
p1021	<b>Speed fixed setpoint selection bit 1</b> (factory setting: 0)
p1022	<b>Speed fixed setpoint selection bit 2</b> (factory setting: 0)
p1023	<b>Speed fixed setpoint selection bit 3</b> (factory setting: 0)
r1024	<b>Fixed speed setpoint effective</b>
r1025.0	<b>Fixed speed setpoint status</b>
	1 signal   Fixed speed setpoint is selected

**Example: Select two fixed setpoints directly**

The motor should operate at different speeds as follows:

- The signal on digital input 0 switches the motor on and accelerates it to 300 rpm.
- The signal at digital input 1 accelerates the motor to 2000 rpm.
- The signals at the two digital inputs accelerate the motor to 2300 rpm.

Table 6- 24 Settings for the example


Parameter	Description
p1001 = 300.000	<b>Fixed speed setpoint 1</b> [rpm]
p1002 = 2000.000	<b>Fixed speed setpoint 2</b> [rpm]
p0840 = 722.0	<b>ON/OFF1:</b> Switch on motor with digital input 0
p1070 = 1024	<b>Main setpoint:</b> Interconnect the main setpoint with the fixed speed setpoint.
p1020 = 722.0	<b>Speed fixed setpoint selection Bit 0:</b> Interconnect fixed setpoint 1 with digital input 0 (DI 0).
p1021 = 722.1	<b>Fixed speed setpoint selection bit 1:</b> Interconnects fixed setpoint 2 with digital input 1 (DI 1).
p1016 = 1	<b>Fixed speed setpoint mode:</b> Select direct selection of the fixed setpoints.

Table 6- 25 Resulting fixed setpoints for the example above

Fixed setpoint selected by	Resulting setpoint
DI 0 = 0	Motor stops
DI 0 = 1 and DI 1 = 0	300 rpm
DI 0 = 1 and DI 1 = 1	2300 rpm

## 6.4 Setpoint calculation

### 6.4.1 Overview of setpoint processing



The setpoint can be modified as follows using the setpoint processing:

- Invert setpoint to reverse the motor direction of rotation (reversing).
- Inhibit positive or negative direction of rotation, e.g. for conveyor belts, pumps or fans.
- Skip frequency bands to prevent mechanical resonance effects.

The skip frequency band at speed = 0 results in a minimum speed after switching on the motor.

- Limit to a maximum speed to protect the motor and mechanical system.
- Ramp-function generator to accelerate and brake the motor with an optimum torque.





Figure 6-28 Setpoint processing in the converter

### 6.4.2 Invert setpoint

The inverter provides an option to invert the setpoint sign using a bit. As an example, the setpoint inversion is shown through a digital input.




In order to invert the setpoint through the digital input DI 1, connect the parameter p1113 with a binary signal, e.g. the digital input 1.

Table 6- 26 Examples of settings to invert the setpoint

Parameter	Remark
p1113 = 722.1	<b>Setpoint inversion</b> Digital input 1 = 0: Setpoint remains unchanged. Digital input 1 = 1: Inverter inverts the setpoint.
p1113 = 2090.11	Invert setpoint via control word 1, bit 11.

### 6.4.3 Enable direction of rotation

In the factory setting of the inverter, the negative direction of rotation of the motor is inhibited.



If you want to permanently enable the negative direction of rotation, then set parameter p1110 to 0.

Set parameter p1111 = 1 to permanently inhibit the positive direction of rotation.

Table 6- 27 Examples of settings to inhibit the direction of rotation

Parameter	Remark
p1110 = 1	<b>Inhibit negative direction</b> Negative direction is permanently inhibited.
p1110 = 722.3	<b>Inhibit negative direction</b> Digital input 3 = 0: Negative direction of rotation is enabled. Digital input 3 = 1: Negative direction of rotation is inhibited.


### 6.4.4 Skip frequency bands and minimum speed

#### Skip frequency bands

The converter has four skip frequency bands that prevent continuous motor operation within a specific speed range. You can find additional information in function diagram 3050 of the List Manual, see also: Manuals for your inverter (Page 451).

#### Minimum speed

The converter prevents continuous motor operation at speeds < minimum speed.




Speeds where the absolute value is less than the minimum speed are only possible during motor operation when accelerating or braking.

Table 6- 28 Setting the minimum speed

Parameter	Description
p1080	<b>Minimum speed</b> (factory setting: 0 rpm)
p1106	CI: Minimum speed signal source (factory setting: 0) Dynamic specification of the minimum speed

## 6.4.5 Speed limitation

The maximum speed limits the speed setpoint range for both directions of rotation.



The converter generates a message (fault or alarm) when the maximum speed is exceeded. If you must limit the speed depending on the direction of rotation, then you can define speed limits for each direction.

Table 6- 29 Parameters for the speed limitation

Parameter	Description
p1082	<b>Maximum speed</b> (factory setting: 1500 rpm)
p1083	<b>Speed limit, positive direction of rotation</b> (factory setting: 210,000 rpm)
p1085	<b>CI: Speed limit, positive direction of rotation</b> (factory setting: 1083)
p1086	<b>Speed limit, negative direction of rotation</b> (factory setting: -210,000 rpm)
p1088	<b>CI: Speed limit, negative direction of rotation</b> (factory setting: 1086)



### 6.4.6 Ramp-function generator

The ramp-function generator in the setpoint channel limits the rate change of the speed setpoint (acceleration). A reduced acceleration reduces the accelerating torque of the motor. As a consequence, the motor reduces the stress on the mechanical system of the driven machine.

The extended ramp-function generator not only limits the acceleration, but by rounding the setpoint, also acceleration changes (jerk). This means that the motor does not suddenly generate a torque.

#### Extended ramp-function generator

The ramp-up and ramp-down times of the extended ramp-function generator can be set independently of each other. The optimum times that you select depend on your particular application in question and can range from just a few 100 ms (e.g. for belt conveyor drives) to several minutes (e.g. for centrifuges).



Initial and final rounding permit smooth, jerk-free acceleration and braking.

The ramp-up and ramp-down times of the motor are increased by the rounding times:

- Effective ramp-up time =  $p1120 + 0.5 \times (p1130 + p1131)$ .
- Effective ramp-down time =  $p1121 + 0.5 \times (p1130 + p1131)$ .

Table 6- 30 Additional parameters to set the extended ramp-function generator

Parameter	Description	
p1120	<b>Ramp-function generator, ramp-up time</b> (factory setting depends on the Power Module) Duration of acceleration (in seconds) from zero speed to maximum speed P1082	
p1121	<b>Ramp-function generator, ramp-down time</b> (factory setting depends on the Power Module) Braking time in seconds from the maximum speed down to standstill	
p1130	<b>Ramp-function generator initial rounding time</b> (Factory setting depends on the Power Module) Initial rounding for extended ramp-function generator. The value applies for ramp up and ramp down.	
p1131	<b>Ramp-function generator final rounding time</b> (Factory setting depends on the Power Module) Final rounding for extended ramp-function generator. The value applies for ramp up and ramp down.	
p1134	<b>Ramp-function rounding type</b> (factory setting: 0) 0: Continuous smoothing 1: Discontinuous smoothing	
p1135	<b>OFF3 ramp-down time</b> (factory setting depends on the Power Module)	
p1136	<b>OFF3 initial rounding time</b> (Factory setting depends on the Power Module) Initial rounding time for OFF3 for an extended ramp-function generator.	
p1137	<b>OFF3 final rounding time</b> (factory setting: 0 s) Final rounding for OFF3 for the extended ramp-function generator.	

You can find more information in function diagram 3070 and in the parameter list of the List Manual.

## Setting the extended ramp-function generator

### Procedure



Proceed as follows to set the extended ramp-function generator:

1. Enter the highest possible speed setpoint.
2. Switch on the motor.
3. Evaluate your drive response.
  - If the motor accelerates too slowly, then reduce the ramp-up time.

An excessively short ramp-up time means that the motor will reach its current limiting when accelerating, and will temporarily not be able to follow the speed setpoint. In this case, the drive exceeds the set time.
  - If the motor accelerates too fast, then extend the ramp-up time.
  - Increase the initial rounding if the acceleration is jerky.
  - We recommend that you set the final rounding to the same value as the initial rounding.
4. Switch off the motor.
5. Evaluate your drive response.
  - If the motor decelerates too slowly, then reduce the ramp-down time.

The minimum ramp-down time that makes sense depends on your particular application. Depending on the Power Module used, for an excessively short ramp-down time, the converter either reaches the motor current, or the DC link voltage in the converter becomes too high. Depending on the converter setting, the real braking time exceeds the set ramp-down time, or the converter goes into a fault condition when braking.
  - Extend the ramp-down time if the motor is braked too quickly or the converter goes into a fault condition when braking.
6. Repeat steps 1 ... 5 until the drive behavior meets the requirements of the machine or plant.



You have set the extended ramp-function generator.

## 6.5 Motor control



The inverter has two alternative methods to control (closed loop) the motor speed:


- U/f control
- Vector control with speed controller

### 6.5.1 V/f control

#### Overview of the U/f control

The U/f control is a closed-loop speed control with the following characteristics:

- The inverter controls the output voltage using the V/f characteristic
- The output frequency is essentially calculated from the speed setpoint and the number of pole pairs of the motor
- The slip compensation corrects the output frequency depending on the load and thus increases the speed accuracy
- Not using a PI controller prevents the speed control from becoming unstable
- In applications in which greater speed accuracy is required, a closed-loop control with load-dependent voltage boost can be selected (flux current control, FCC)



- 1) In the U/f control variant, "flux current control (FCC)," the inverter controls the motor current (starting current) at low speeds

Figure 6-29 Simplified function diagram of the U/f control

One function not shown in the simplified function diagram is the resonance damping for damping mechanical oscillations. You will find the complete function diagrams 6300 et seq. in the List Manual.

For operation of the motor with U/f control, you must set at least the subfunctions shown with a gray background in the figure to adapt them to your application:

- V/f characteristic
- Voltage boost

### Default setting after selecting the application class Standard Drive Control

Selecting application class Standard Drive Control adapts the structure and the setting options of the U/f control as follows:

- Starting current closed-loop control: At low speeds, a controlled motor current reduces the tendency of the motor to oscillate.
- With increasing speed, transition from closed-loop starting current control into U/f control with voltage boost depending on the load.
- Soft starting is not possible.
- Fewer parameters





Figure 6-30 Default setting of the U/f control after selecting Standard Drive Control

The complete function diagrams 6850 ff. for application class Standard Drive Control are provided in the List Manual.

### 6.5.1.1 Characteristics of U/f control

The inverter has different U/f characteristics.



- ① The voltage boost of the characteristic optimizes motor starting
- ② With flux current control (FCC), the inverter compensates the voltage drop across the stator resistance of the motor

Figure 6-31 U/f characteristics of the inverter

The inverter increases its output voltage up to the maximum output voltage. The line voltage defines the maximum inverter output voltage.

If the inverter has reached its maximum output voltage, then it can only increase its output frequency. From this point onwards, the motor is operated in field weakening; this means that the available torque linearly decreases with increasing speed.

The value of the output voltage at the rated motor frequency also depends on the following variables:

- Ratio between the inverter size and the motor size
- Line voltage
- Line impedance
- Actual motor torque

The maximum possible output voltage as a function of the input voltage is provided in the technical data, also see Section Technical data, Power Modules (Page 372).

Table 6- 31 Linear and parabolic characteristics

Requirement	Application examples	Remark	Characteristic	Parameter
The required torque is independent of the speed	Eccentric-worm pump, compressor	-	Linear	p1300 = 0
		The inverter equalizes the voltage drops across the stator resistance. Recommended for motors less than 7.5 kW. Precondition: You have set the motor data according to the rating plate and have performed the motor identification after the basic commissioning.	Linear with Flux Current Control (FCC)	p1300 = 1
The required torque increases with the speed	Centrifugal pumps, radial fans, axial fans, compressors	Lower losses in the motor and inverter than for a linear characteristic.	Parabolic	p1300 = 2

Table 6- 32 Characteristics for special applications


Requirement	Application examples	Remark	Characteristic	Parameter
Applications with a low dynamic response and constant speed	Centrifugal pumps, radial fans, axial fans	The ECO mode results in additional energy saving when compared to the parabolic characteristic. If the speed setpoint is reached and remains unchanged for 5 seconds, the inverter again reduces its output voltage.	ECO mode	p1300 = 4 (linear characteristic ECO) or p1300 = 7 (parabolic characteristic ECO)

Additional information on V/f characteristics can be found in the parameter list and in the function diagrams 6300 ff of the List Manual.

## Characteristics after selecting the application class Standard Drive Control

Selecting application class Standard Drive Control reduces the number of characteristics and the setting options:

- A linear and a parabolic characteristic are available.
- Selecting a technological application defines the characteristic.
- The following cannot be set - ECO mode, FCC, the programmable characteristic and a specific voltage setpoint.



- ① The closed-loop starting current control optimizes the speed control at low speeds  
 ② The inverter compensates the voltage drop across the motor stator resistance

Figure 6-32 Characteristics after selecting Standard Drive Control

Table 6- 33 Linear and parabolic characteristics

Requirement	Application examples	Remark	Characteristic	Parameter
The required torque is independent of the speed	Conveyor belts, roller conveyors, chain conveyors, eccentric worm pumps, compressors, extruders, centrifuges, agitators, mixers	-	Linear	p0501 = 0
The required torque increases with the speed	Centrifugal pumps, radial fans, axial fans	Lower losses in the motor and inverter than for a linear characteristic.	Parabolic	p0501 = 1

Additional information on the characteristics can be found in the parameter list and in the function diagrams 6851 ff of the List Manual.

### 6.5.1.2 Optimizing motor starting

#### Setting the voltage boost for U/f control

After selection of the V/f characteristic, no further settings are required in most applications.


In the following circumstances, the motor cannot accelerate to its speed setpoint after it has been switched on:

- Load moment of inertia too high
- Load torque too large
- Ramp-up time p1120 too short

To improve the starting behavior of the motor, the V/f characteristic can be raised at low speeds.

The inverter raises the voltage in accordance with the starting currents p1310 ... p1312.

The adjacent diagram shows the resulting voltage boost using a linear characteristic as an example.



#### Requirements

- Set the ramp-up time of the ramp-function generator to a value 1 s (< 1 kW) ... 10 s (> 10 kW), depending on the power rating of the motor .
- Increase the starting current in steps of ≤ 5 %. Excessively high values in p1310 ... p1312 can cause the motor to overheat and switch off (trip) the inverter due to overcurrent.

If the message A07409 appears, you must not increase any of the parameters.

#### Procedure



Proceed as follows to set the voltage boost:

1. Switch off the motor with a setpoint of just a few revolutions per minute.
2. Check whether the motor rotates smoothly.
3. If the motor rotates eccentrically or even stops, increase the voltage boost p1310 until the motor rotates smoothly.
4. Accelerate the motor to the maximum speed with maximum load.
5. Check whether the motor is following the setpoint.
6. If necessary, increase the voltage boost p1311 until the motor accelerates without problem.

In applications with a high break loose torque, you must additionally set parameter p1312 higher to achieve a satisfactory response.

You have set the voltage boost.

Parameter	Description
p1310	<b>Starting current (voltage boost) permanent</b> (factory setting 50 %) Compensates for voltage drops caused by long motor cables and the ohmic losses in the motor.
p1311	<b>Starting current (voltage boost) when accelerating</b> (factory setting 0 %) Provides additional torque when the motor accelerates.
p1312	<b>Starting current (voltage boost) when starting</b> (factory setting 0 %) Provides additional torque, however, only when the motor accelerates for the first time after it has been switched on ("break loose torque").

You will find more information on this function in the parameter list and in function diagram 6301 in the List Manual.

### Starting current (boost) after selecting the application class Standard Drive Control

After selecting application class Standard Drive Control, in most applications, and no additional settings have to be made.

At standstill, the inverter ensures that at least the rated motor magnetizing current flows. Magnetizing current p0320 approximately corresponds to the no-load current at 50 % ... 80 % of the rated motor speed.


In the following situations, after it has been switched on, the motor cannot accelerate up to its speed setpoint:

- Excessively high load moment of inertia
- Excessively high load torque
- Ramp-up time p1120

The current can be increased at low speeds to improve the starting behavior of the motor.

The inverter boosts the voltage corresponding to the starting currents p1310 ... p1312.

The adjacent diagram shows the voltage boost using a linear characteristic as example.



**Requirements**

- Depending on the rated power of the motor, set the ramp-up time of the ramp-function generator to a value of 1 s (< 1 kW) ... 10 s (> 10 kW).
- Increase the starting current in steps of ≤ 5 %. Excessively high values in p1310 ... p1312 can cause the motor to overheat and switch off (trip) the inverter due to overcurrent.

When message A07409 is displayed, it is not permissible that you further increase the value of any of the parameters.

**Procedure**



Proceed as follows to set the voltage boost:

1. Switch on the motor with a setpoint of a few revolutions per minute.
2. Check whether the motor rotates smoothly.
3. If the motor does not rotate smoothly, or even remains stationary, increase the voltage boost p1310 until the motor runs smoothly.
4. Accelerate the motor to the maximum speed with maximum load.
5. Check that the motor follows the setpoint.
6. When required, increase the voltage boost p1311 until the motor accelerates without any problem.

In applications with a high break loose torque, you must also increase parameter p1312 in order to achieve a satisfactory motor response.



You have set the voltage boost.

Parameter	Description
p1310	<b>Starting current (voltage boost) permanent</b> (Factory setting 50 %) Compensates voltage losses as a result of long motor cables and the ohmic losses in the motor. After commissioning, depending on the motor power rating and the technological application p0501, the inverter sets p1310.
p1311	<b>Starting current (voltage boost) when accelerating</b> (Factory setting 0%) Provides additional torque when the motor accelerates. After commissioning, depending on the motor power rating and the technological application p0501, the inverter sets p1311.
p1312	<b>Starting current (voltage boost) when starting</b> (Factory setting 0%) Provides additional torque, however, only when the motor accelerates for the first time after it has been switched on ("break loose torque").


You can find more information about this function in the parameter list and in function diagram 6851 of the List Manual.

## 6.5.2 Vector control with speed controller

### 6.5.2.1 Overview

#### Overview

The vector control comprises closed-loop current control and a higher-level closed-loop speed control.



1) For induction motors

Figure 6-33 Simplified function diagram for sensorless vector control with speed controller

All of the function block diagrams 6020 ff. for vector control are provided in the List Manual:

Using the motor model, the inverter calculates the following closed-loop control signals from the measured phase currents and the output voltage:

- Current component  $I_d$
- Current component  $I_q$
- Speed actual value

The setpoint of the current component  $I_d$  (flux setpoint) is obtained from the motor data. For speeds above the rated speed, the inverter reduces the flux setpoint along the field weakening characteristic.

When the speed setpoint is increased, the speed controller responds with a higher setpoint for the current component  $I_q$  (torque setpoint). The closed-loop control responds to a higher torque setpoint by adding a higher slip frequency to the output frequency. Also in the motor, the higher output frequency results in a higher slip, which is proportional to the accelerating

torque.  $I_q$  and  $I_d$  controllers keep the motor flux constant using the output voltage, and adjust the matching current component  $I_q$  in the motor.

In order to achieve a satisfactory controller response, as a minimum, you must match the subfunctions having a gray background as shown in the diagram above with your particular application.

- **Motor and current model:** In the basic commissioning, correctly set the motor data from the rating plate corresponding to the connection type (Y/ $\Delta$ ), and carry out a motor data identification routine at standstill.
- **Speed limits and torque limits:** In the basic commissioning, set the maximum speed (p1082) and current limit (p0640) to match your particular application. When completing the basic commissioning, the inverter calculates the torque and power limits corresponding to the current limit. The actual torque limits are obtained from the converted current and power limits and the set torque limits.
- **Speed controller:** Start the rotating measurement of the motor data identification. You must manually optimize the controller if the rotating measurement is not possible.

### Default settings after selecting the application class Dynamic Drive Control

Selecting application class Dynamic Drive Control adapts the structure of the vector control and reduces the setting options:

	Vector control after selecting the application class Dynamic Drive Control	Vector control without selecting an application class
Hold or set the integral component of the speed controller	Not possible	Possible
Acceleration model for precontrol	Default setting	Can be activated
Motor data identification at standstill or with rotating measurement	Shortened, with optional transition into operation	Complete


## 6.5.2.2 Optimizing the speed controller

### Optimum control response - post optimization not required

Preconditions for assessing the controller response:

- The moment of inertia of the load is constant and does not depend on the speed
- The inverter does not reach the set torque limits during acceleration
- You operate the motor in the range 40 % ... 60 % of its rated speed

If the motor exhibits the following response, the speed control is well set and you do not have to adapt the speed controller manually:



The speed setpoint (broken line) increases with the set ramp-up time and rounding.

The actual value follows the setpoint without overshooting.

### Control optimization required

In some cases, the self-optimization result is not satisfactory or self-optimization is not possible because the motor cannot rotate freely.

In these cases, you must optimize the closed-loop speed control manually. The following parameters influence the response of the speed control:

- p1496            Acceleration pre-control scaling
- p0342           Ratio between the total and motor moment of inertia
- p1470           P gain  $K_P$
- p1472           Integration time (integral time)  $T_I$
- p1452           Speed controller actual speed value smoothing time (without encoder)

### Optimizing the speed controller

#### Requirements

- Torque precontrol is active: p1496 = 100 %.
- The load moment of inertia is constant and independent of the speed.
- The inverter requires 10 % ... 50 % of the rated torque to accelerate.

When necessary, adapt the ramp-up and ramp-down times of the ramp-function generator (p1120 and p1121).

- You have prepared the trace function in STARTER or Startdrive to be able to trace the speed setpoint and the speed actual value.

**Procedure**



To optimize the speed controller, proceed as follows:

1. Switch on the motor.
2. Enter a speed setpoint of approximately 40 % of the rated speed.
3. Wait until the actual speed has stabilized.
4. Increase the setpoint up to a maximum of 60 % of the rated speed.
5. Monitor the associated characteristic of the setpoint and actual speed.
6. Optimize the controller by adapting the ratio of the moments of inertia of the load and motor (p0342):

	<p>Initially, the actual speed follows the setpoint speed; however, it then overshoots the setpoint speed.</p> <ul style="list-style-type: none"> <li>• Increase p0342</li> </ul>
	<p>Initially, the actual speed exceeds the setpoint speed; however, it does not overshoot but instead approaches the setpoint speed "from below".</p> <ul style="list-style-type: none"> <li>• Reduce p0342</li> </ul>

7. Switch off the motor.
8. Start a new calculation of the speed controller: p0340 = 4.
9. Switch on the motor.
10. Over the complete speed range check whether the speed control responds satisfactorily with the optimized settings.

■ You have optimized the speed controller.

When necessary, set the ramp-up and ramp-down times of the ramp-function generator (p1120 and p1121) back to the value before optimization.

**Mastering critical applications**

The drive control can become unstable for drives with a high load moment of inertia and gearbox backlash or a coupling between the motor and load that can possibly oscillate. In this case, we recommend the following settings:

- Increase the smoothing of speed actual value p1452.
- Increase the integral time:  $T_I \geq 4 \times p1452$ .
- If the closed-loop speed control no longer has an adequate dynamic performance after these measures, then increase the P gain  $K_P$  step-by-step.

## 6.6 Protection functions



The frequency inverter offers protective functions against overtemperature and overcurrent for both the frequency inverter as well as the motor. Further, the frequency inverter protects itself against an excessively high DC link voltage when the motor is regenerating.

### 6.6.1 Inverter temperature monitoring

The inverter temperature is essentially defined by the following effects:

- The ambient temperature
- The ohmic losses increasing with the output current
- Switching losses increasing with the pulse frequency

#### Monitoring types

The inverter monitors its temperature using the following monitoring types:

- I<sup>2</sup>t monitoring (alarm A07805, fault F30005)
- Measuring the chip temperature of the Power Module (alarm A05006, fault F30024)
- Measuring the heat sink temperature of the Power Module (alarm A05000, fault F30004)

#### Inverter response to thermal overload

Parameter	Description
r0036	<p><b>Power unit overload I<sup>2</sup>t [%]</b></p> <p>The I<sup>2</sup>t monitoring calculates the inverter utilization based on a current reference value defined in the factory.</p> <ul style="list-style-type: none"> <li>• Actual current &gt; reference value: r0036 becomes higher.</li> <li>• Actual current &lt; reference value: r0036 becomes lower or remains = 0.</li> </ul>
r0037	<p><b>Power unit temperatures [°C]</b></p>
p0290	<p><b>Power unit overload response</b></p> <p>Factory setting and the ability to be changed depends on the hardware. The dependency is described in the List Manual.</p> <p>A thermal overload is present if the inverter temperature is greater than that specified in p0292.</p> <p>You define how the inverter responds if there is a risk of thermal overload using this parameter. The details are described below.</p>
p0292	<p><b>Power unit temperature warning threshold</b> (factory setting: Heat sink [0] 5 °C, power semiconductor [1] 15 °C)</p> <p>The value is set as a difference to the shutdown temperature.</p>
p0294	<p><b>Power unit warning at I<sup>2</sup>t overload</b> (factory setting: 95 %)</p>

### Overload response for p0290 = 0

The inverter responds depending on the control mode that has been set:

- In vector control, the inverter reduces the output current.
- In U/f control, the inverter reduces the speed.

Once the overload condition has been removed, the inverter re-enables the output current or speed.

If the measure cannot prevent an inverter thermal overload, then the inverter switches off the motor with fault F30024.

### Overload response for p0290 = 1

The inverter immediately switches off the motor with fault F30024.

### Overload response for p0290 = 2

We recommend this setting for drives with square-law torque characteristic, e.g. fans.

The inverter responds in two stages:

1. If you operate the inverter with increased pulse frequency setpoint p1800, then the inverter reduces its pulse frequency starting at p1800.

In spite of the temporarily reduced pulse frequency, the base load output current remains unchanged at the value that is assigned to p1800.




Figure 6-34 Derating characteristic and base load output current for overload

Once the overload condition has been removed, the inverter increases the pulse frequency back to the pulse frequency setpoint p1800.

2. If it is not possible to temporarily reduce the pulse frequency, or the risk of thermal overload cannot be prevented, then stage 2 follows:
  - In vector control, the inverter reduces its output current.
  - In U/f control, the inverter reduces the speed.

Once the overload condition has been removed, the inverter re-enables the output current or speed.

If both measures cannot prevent a power unit thermal overload, then the inverter switches off the motor with fault F30024.

### Overload response for p0290 = 3

If you operate the inverter with increased pulse frequency, then the inverter reduces its pulse frequency starting at the pulse frequency setpoint p1800.

In spite of the temporarily reduced pulse frequency, the maximum output current remains unchanged at the value that is assigned to the pulse frequency setpoint. Also see p0290 = 2.

Once the overload condition has been removed, the inverter increases the pulse frequency back to the pulse frequency setpoint p1800.

If it is not possible to temporarily reduce the pulse frequency, or the measure cannot prevent a power unit thermal overload, then the inverter switches off the motor with fault F30024.

### Overload response for p0290 = 12

The inverter responds in two stages:

1. If you operate the inverter with increased pulse frequency setpoint p1800, then the inverter reduces its pulse frequency starting at p1800.

There is no current derating as a result of the higher pulse frequency setpoint.

Once the overload condition has been removed, the inverter increases the pulse frequency back to the pulse frequency setpoint p1800.

2. If it is not possible to temporarily reduce the pulse frequency, or the risk of inverter thermal overload cannot be prevented, then stage 2 follows:

- In vector control, the inverter reduces the output current.
- In U/f control, the inverter reduces the speed.

Once the overload condition has been removed, the inverter re-enables the output current or speed.

If both measures cannot prevent a power unit thermal overload, then the inverter switches off the motor with fault F30024.

### Overload response for p0290 = 13

We recommend this setting for drives with high starting torque, e.g. horizontal conveyors or extruders.

If you operate the inverter with increased pulse frequency, then the inverter reduces its pulse frequency starting at the pulse frequency setpoint p1800.

There is no current derating as a result of the higher pulse frequency setpoint.

Once the overload condition has been removed, the inverter increases the pulse frequency back to the pulse frequency setpoint p1800.

If it is not possible to temporarily reduce the pulse frequency, or the measure cannot prevent a power unit thermal overload, then the inverter switches off the motor with fault F30024.

### Special feature for PM330

For PM330, the overload response is permanently set to p0290 = 2. It cannot be changed.

## 6.6.2 Motor temperature monitoring using a temperature sensor

### Connecting the temperature sensor

It is permissible to use one of the following sensors to protect the motor against overtemperature:

- Temperature switch (e.g. bimetallic switch)
- PTC sensor
- KTY84 sensor



Connect the temperature sensor of the motor to terminals 14 and 15 of the inverter.

### Temperature switch



The converter interprets a resistance  $\geq 100 \Omega$  as being an opened temperature switch and responds according to the setting for p0610.

### PTC sensor



The converter interprets a resistance  $> 1650 \Omega$  as being an overtemperature and responds according to the setting for p0610.

The converter interprets a resistance  $< 20 \Omega$  as being a short-circuit and responds with alarm A07015. If the alarm is present for longer than 100 milliseconds, the converter shuts down with fault F07016.

### KTY84 sensor

#### NOTICE

#### Motor overheating due to incorrectly connected KTY sensor

If a KTY sensor is connected with incorrect polarity, the motor can become damaged due to overheating, as the converter cannot detect a motor overtemperature condition.

- Connect the KTY sensor with the correct polarity.



Using a KTY sensor, the converter monitors the motor temperature and the sensor itself for wire-break or short-circuit:

- Temperature monitoring:  
The converter uses a KTY sensor to evaluate the motor temperature in the range from  $-48^\circ \text{C} \dots +248^\circ \text{C}$ .  
Use the p0604 or p0605 parameter to set the temperature for the alarm and fault threshold.
  - Overtemperature alarm (A07910):  
- motor temperature  $> p0604$  and  $p0610 = 0$

- Overtemperature fault (F07011):  
The converter switches off with fault in the following cases:
  - motor temperature > p0605
  - motor temperature > p0604 and p0610 ≠ 0
- Sensor monitoring (A07015 or F07016):
  - Wire-break:  
The converter interprets a resistance > 2120 Ω as a wire-break and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.
  - Short-circuit:  
The converter interprets a resistance < 50 Ω as a short-circuit and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.

### Setting parameters for the temperature monitoring

Parameter	Description
p0335	<b>Specify the motor cooling</b> 0: Natural cooling - with fan on the motor shaft (factory setting) 1: Forced ventilation - with a separately driven fan 2: Liquid cooling 128: No fan
p0601	<b>Motor-temperature sensor type</b> 0: No sensor (factory setting) 1: PTC (→ p0604) 2: KTY84 (→ p0604, p0605) 4: Temperature switch
p0604	<b>Motor temperature alarm threshold</b> (factory setting 130° C)
p0605	<b>Motor temperature fault threshold</b> (factory setting 145° C) Setting for KTY84 sensor. The parameter has no significance for a PTC sensor.
p0610	<b>Motor overtemperature response</b> (factory setting: 12) Determines the behavior as soon as the motor temperature reaches the warning threshold p0604. 0: Alarm (A07910), no fault. 1: Alarm (A07910); the converter reduces the current limit and starts the timer. Shutdown with fault (F07011). 2: Alarm (A07910); the converter starts the timer. Shutdown with fault (F07011). 12: As for 2, but the converter considers the last shutdown temperature to calculate the motor temperature.
p0640	<b>Current limit</b> (input in A)

Additional information on the motor temperature monitoring can be found in function diagram 8016 of the List Manual.

### 6.6.3 Protecting the motor by calculating the motor temperature

The converter calculates the motor temperature based on a thermal motor model.

#### Requirements

The inverter can only calculate a realistic motor temperature if the following requirements are met:

- Perform basic commissioning
- In the basic commissioning, set the motor data via the motor code, the motor Article No., or according to the motor nameplate.
- Check the value of the motor mass (P0344). The inverter calculates the p0344 based on the basic commissioning.

#### Settings

Table 6- 34 Parameters for temperature acquisition without using a temperature sensor

Parameter	Description
p0601	<b>Motor temperature sensor type</b> (factory setting: 0) 0: No sensor
p0604	<b>Mot_temp_mod 2/KTY Warning threshold</b> (factory setting: 130 °C) Threshold for monitoring the motor temperature.. After exceeding the threshold, the converter reports fault F07011.
p0605	<b>Mot_temp_mod 1/2 threshold</b> (factory setting: 145 °C) Threshold for monitoring the motor temperature with motor temperature model 1, 2, or KTY. Motor temperature model 1 (p0612.0 = 1): Alarm threshold - If the alarm threshold is exceeded, the inverter reports alarm A07012. Motor temperature model 2 (p0612.1 = 1) or KTY: Fault threshold - If the fault threshold is exceeded, the inverter reports fault F07011.
p0610	<b>Motor overtemperature response</b> (factory setting: 12) Determines the behavior as soon as the motor temperature reaches the warning threshold p0604.
	0: Warning (A07910), no fault.
	1: Warning (A07910); current limit will be reduced and timer started. Shutdown with fault (F07011).
	2: Warning (A07910); timer is started. Shutdown with fault (F07011).
12: As for 2 but the last shutdown temperature is used to calculate the motor temperature (factory setting).	
p0611	<b>I2t motor model thermal time constant</b> (factory setting: 0 s) The parameter is only effective for synchronous motors. On selecting a motor from the motor list (p0301), the converter sets up the parameter value automatically.
p0612	<b>Mot_temp_mod activation</b>

Parameter	Description	
	.00	1 signal: Activate motor temperature model 1 (I2t) for permanently excited synchronous motors
	.01	1 signal: Activate motor temperature model 2 for asynchronous motors
	.02	1 signal: Activate motor temperature model 3 for 1FK7 encoderless synchronous motors p0612.02 cannot be set for every inverter.
	.09	1 signal: Activate motor temperature model 2 expansions
p0614	<b>Thermal resistance adaptation reduction factor</b> (factory setting: 30 %) Derating factor for overtemperature of the thermal adaptation of the stator and rotor resistance	
p0615	<b>Mot_temp_mod 1 (I2t) Interference threshold</b> (factory setting: 180 °C) Interference threshold for monitoring the motor temperature in motortemperature model 1. After exceeding the interference threshold, the converter reports fault F07011.	
p0621	<b>Identification of stator resistance (Rs) when switched on again</b> (factory setting: 0) The converter measures the current stator resistance and from this calculates the current motor temperature as the start value of the thermal motor model.	
	0:	No Rs identification
	1:	Rs identification on first switching on the motor
	2:	Rs identification each time the motor is switched on
p0622	<b>Motor excitation time for Rs_ident on switching on again</b> The converter sets the parameter value to the corresponding result of the motor data identification.	
p0625	<b>Motor ambient temperature during commissioning</b> (factory setting: 20 °C) Enter the ambient motor temperature in °C at the instant that the motor data is acquired.	

More information on temperature calculation can be found in function plans 8016 and 8017 and the list manual.

## 6.6.4 Overcurrent protection

The vector control ensures that the motor current remains within the set torque limits.

If you use U/f control, you cannot set any torque limits. The U/f control prevents too high a motor current by influencing the output frequency and the motor voltage (I-max controller).

### I\_max controller

#### Requirements

The torque of the motor must decrease at lower speeds, which is the case, for example, with fans.

The load must not drive the motor continuously, e.g. when lowering hoisting gear.

#### Function

The I-max controller influences the output frequency and the motor voltage.

If the motor current reaches the current limit during acceleration, the I-max controller extends the acceleration operation.

If the load of the motor is so large during stationary operation that the motor current reaches the current limit, the I-max controller reduces the speed and the motor voltage until the motor current is in the permissible range again.

If the motor current reaches the current limit during deceleration, the I-max controller extends the deceleration operation.

### Settings

You only have to change the factory settings of the I-max controller if the drive tends to oscillate when it reaches the current limit or if it is shut down due to overcurrent.

Table 6- 35 I-max controller parameters

Parameter	Description
p0305	<b>Rated motor current</b>
p0640	<b>Motor current limit</b>
p1340	<b>Proportional gain of the I-max controller for speed reduction</b>
p1341	<b>Integral time of the I-max controller for speed reduction</b>
r0056.13	<b>Status: I-max controller active</b>
r1343	<b>Speed output of the I-max controller</b> Shows the amount to which the I-max controller reduces the speed.

For more information about this function, see function diagram 6300 in the List Manual.

## 6.6.5 Limiting the maximum DC link voltage

### How does the motor generate overvoltage?

An induction motor operates as a generator if it is driven by the connected load. A generator converts mechanical energy into electrical energy. The electrical energy flows back into the inverter. If the inverter cannot dissipate the electrical energy, for example in a braking resistor, then the DC link voltage  $V_{dc}$  increases in the inverter.

Above a critical DC-link voltage both the inverter and the motor will be damaged. Before the voltage can reach critical levels, however, the inverter switches the motor off with the fault message "DC-link overvoltage".

### Protecting the motor and inverter against overvoltage

The  $V_{dc\_max}$  control avoids an excessively high DC link voltage, assuming that the application permits this. The  $V_{dc\_max}$  control increases the ramp-down time of the motor when braking, so that the motor feeds back only as little energy to the inverter as is covered by the losses in the inverter.

The  $V_{dc\_max}$  control is not suitable for applications where the motor is continuously in the generator mode. This includes, for example, cranes or applications involving braking large moments of inertia. Further information on inverter braking methods can be found in Section Electrically braking the motor (Page 248).

The  $V_{dc\_max}$  control is only possible with the PM230, PM240, PM240-2 and PM330 Power Modules. The  $V_{dc\_max}$  control is not required if you use a braking resistor.

PM250 Power Modules feed back regenerative energy into the line supply. Therefore, the  $V_{dc\_max}$  control is not required for a PM250 Power Module.

## Parameters of the Vdc\_max control

The parameters differ depending on the motor control mode.

Parameter for V/f control	Parameter for vector control	Description
p1280 = 1	p1240 = 1	<b>Vdc controller configuration</b> (Factory setting: 1) 1: Vdc controller is enabled
r1282	r1242	<b>Vdc_max control activation level</b> DC link voltage value above which the Vdc_max control is activated
p1283	p1243	<b>Vdc_max control dynamic factor</b> (factory setting: 100 %) Scaling control parameters p1290, p1291 and p1292
p1284	---	<b>Vdc_max controller time threshold</b> Setting the monitoring time of the Vdc_max controller.
p1290	p1250	<b>Vdc_max control proportional gain</b> (factory setting: 1)
p1291	p1251	<b>Vdc_max control integral time</b> (factory setting p1291: 40 ms, p1251: 0 ms)
p1292	p1252	<b>Vdc_max control rate time</b> (factory setting p1292: 10 ms, p1252: 0 ms)
p1294	p1254	<b>Vdc_max control automatic ON level sensing</b> (Factory setting, dependent on the Power Module) Automatically sense switch-on levels of the Vdc_max control. 0: Automatic detection disabled 1: Automatic detection enabled
p0210	p0210	<b>Unit supply voltage</b> If p1254 or p1294 = 0, the inverter uses this parameter to calculate the switch-in thresholds of the Vdc_max control. Set this parameter to the actual value of the input voltage.

For more information about this function, see the List Manual (function diagrams 6320 and 6220).

## 6.7 Application-specific functions



The inverter offers a series of functions that you can use depending on your particular application, e.g.:

- Switching over units
- Calculating the energy saving for fluid flow machines
- Braking functions
- Automatic restart and flying restart
- Basic process control functions
- Essential service mode
- Multi-zone control
- Bypass
- Cascade control
- Hibernation mode
- Logical and arithmetic functions using function blocks that can be freely interconnected

Refer to the following sections for detailed descriptions.

### 6.7.1 Unit changeover

#### Description

Using the unit switchover function, you can switch over parameters and process variables for input and output to an appropriate system of units: US units, SI units or relative variables as a %.

Independent of this, you can define the units for process variables or change over to percentage values.

Specifically, you have the following options:

- Changing over the motor standard (Page 242) IEC/NEMA
- Changing over the unit system (Page 243)
- Changing over process variables for the technology controller (Page 243)

The motor standard, the unit system as well as the process variables can only be changed offline.

### Restrictions for the unit changeover function

- The values on the rating plate of the inverter or motor cannot be displayed as percentage values.
- Using the unit changeover function several times (for example, percent → physical unit 1 → physical unit 2 → percent) may lead to the original value being changed by one decimal place as a result of rounding errors.
- If the unit is changed over into percent and the reference value is then changed, the percentage values relate to the new reference value.

Example:

- For a reference speed of 1500 rpm, a fixed speed of 80% corresponds to a speed of 1200 rpm.
- If the reference speed is changed to 3000 rpm, then the value of 80% is kept and now means 2400 rpm.

### Reference variables for unit changeover

- p2000 Reference frequency/speed
- p2001 Reference voltage
- p2002 Reference current
- p2003 Reference torque
- r2004 Reference power
- p2006 Reference temperature

#### 6.7.1.1 Changing over the motor standard

You change over the motor standard using p0100. The following applies:

- p0100 = 0: IEC motor (50 Hz, SI units)
- p0100 = 1: NEMA motor (60 Hz, US units)
- p0100 = 2: NEMA motor (60 Hz, SI units)

The parameters listed below are affected by the changeover.

Table 6- 36 Variables affected by changing over the motor standard

P no.	Designation	Unit for p0100 =		
		0*)	1	2
r0206	Power Module rated power	kW	HP	kW
p0307	Rated motor power	kW	HP	kW
p0316	Motor torque constant	Nm/A	lbf ft/A	Nm/A
r0333	Rated motor torque	Nm	lbf ft	Nm
p0341	Motor moment of inertia	kgm <sup>2</sup>	lb ft <sup>2</sup>	kgm <sup>2</sup>
p0344	Motor weight (for thermal motor type)	kg	Lb	kg
r1969	Speed_cont_opt moment of inertia determined	kgm <sup>2</sup>	lb ft <sup>2</sup>	kgm <sup>2</sup>

\*) Factory setting

### 6.7.1.2 Changing over the unit system

You change over the unit system using p0505. The following selection options are available:

- p0505 = 1: SI units (factory setting)
- p0505 = 2: SI units or % relative to SI units
- p0505 = 3: US units
- p0505 = 4: US units or % relative to US units

---

#### Note

##### Special features

The percentage values for p0505 = 2 and for p0505 = 4 are identical. For internal calculation and for the output of physical variables, it is, however, important whether the conversion is made to SI or US units.

In the case of variables for which changeover to % is not possible, the following applies:  
p0505 = 1  $\triangleq$  p0505 = 2 and p0505 = 3  $\triangleq$  p0505 = 4.

In the case of variables whose units are identical in the SI system and US system, and which can be displayed as a percentage, the following applies:  
p0505 = 1  $\triangleq$  p0505 = 3 and p0505 = 2  $\triangleq$  p0505 = 4.

##### Parameters affected by changeover

The parameters affected by changing over the unit system are grouped according to unit. An overview of the unit groups and the possible units can be found in the List Manual in the Section "Unit group and unit selection".

---

### 6.7.1.3 Changing over process variables for the technology controller

---

#### Note

We recommend that the units and reference values of the technology controller are coordinated and harmonized with one another during commissioning.

Subsequent modification in the reference variable or the unit can result in incorrect calculations or displays.

---

### Changing over process variables of the technology controller

You change over the process variables of the technology controller using p0595. For physical values, you define the reference variable in p0596.

The parameters affected by changing over units of the technology controller belong to unit group 9\_1. For details, please refer to the section titled "Unit group and unit choice" in the List Manual.

### Switching the process variables of the additional technology controller 0

The process variables of the additional technology controller 0 switch over via p11026. You define the reference variable for absolute units in p11027.

The parameters affected by the unit switchover of the additional technology controller 0 belong to units group 9\_2. Details can be found in the Parameter Manual, under the section entitled "units group and unit selection".

### Switching the process variables of the additional technology controller 1

The process variables of the additional technology controller 1 switch over via p11126. You define the reference variable for absolute units in p11127.

The parameters affected by the unit switchover of the additional technology controller 1 belong to units group 9\_3. Details can be found in the Parameter Manual, under the section entitled "units group and unit selection".

### Switching the process variables of the additional technology controller 2

The process variables of the additional technology controller 2 switch over via p11226. You define the reference variable for absolute units in p11227.

The parameters affected by the unit switchover of the additional technology controller 2 belong to units group 9\_4. Details can be found in the Parameter Manual, under the section entitled "units group and unit selection".


## 6.7.1.4 Switching units with STARTER

### Precondition

The inverter must be in the offline mode in order to change over the units.

STARTER shows whether you change settings online in the inverter or change offline in the PC (**Online mode** / **Offline mode**).

You switch over the mode using the adjacent buttons in the menu bar.




### Procedure



To change over the units, proceed as follows:


1. Select the configuration
2. Select the "Units" tab in the configuration screen form to change over the units.
3. Change the system of units
4. Select process variables of the technology controller
5. Select process variables of the additional technology controller 0
6. Select process variables of the additional technology controller 1

7. Select process variables of the additional technology controller 2
8. Adapt to the line supply (motor standard)



9. Save your settings.
10. Go online.
 

The inverter signals that offline, other units and process variables are set than in the inverter itself.
11. Accept these settings in the inverter.



You have changed over the units.


### 6.7.2 Calculating the energy saving

#### Background

Fluid flow machines, which mechanically control the flow rate using valves or throttle flaps, operate with a constant speed corresponding to the line frequency. The lower the flow rate, the poorer the system efficiency. The machine has the poorest efficiency when the valve or throttle flaps are completely closed. Further, undesirable effects can occur, for example the formation of vapor bubbles in liquids (cavitation) or the temperature of the medium being pumped can increase.

The converter controls the flow rate by appropriately varying the speed of the fluid flow machine. As a consequence, the fluid flow machine has the optimum efficiency for each flow rate, and draws less electric power in the partial load range than for closed-loop control concepts based on valves and throttle flaps.

#### Function



The converter calculates the energy saving from the flow characteristic associated with a mechanical flow control and the measured electric power that is drawn.

The calculation is suitable for centrifugal pumps, fans, radial and axial compressors, for instance.

Parameter	Description						
p3320 ... p3329	<p><b>Flow characteristic</b></p> <p>(Speed, power)</p> <p>① (p3320, p3321) ② (p3322, p3323) ③ (p3324, p3325) ④ (p3326, p3327) ⑤ (p3328, p3329)</p> <p>Factory setting of the flow characteristic</p> <p>To set the characteristic, you require the following data from the machine manufacturer for each speed interpolation point:</p> <ul style="list-style-type: none"> <li>• The flow rate of the fluid-flow machine associated with the 5 selected converter speeds</li> <li>• The power drawn at constant speed associated with the five flow rates corresponds to the line frequency and mechanical throttling of the flow rate.</li> </ul>						
r0039	<p><b>Energy display [kWh]</b></p> <table border="1"> <tr> <td>[0]</td> <td><b>Energy balance</b> Energy usage since the last reset</td> </tr> <tr> <td>[1]</td> <td>Energy drawn since the last reset</td> </tr> <tr> <td>[2]</td> <td>Energy fed back since the last reset</td> </tr> </table>	[0]	<b>Energy balance</b> Energy usage since the last reset	[1]	Energy drawn since the last reset	[2]	Energy fed back since the last reset
[0]	<b>Energy balance</b> Energy usage since the last reset						
[1]	Energy drawn since the last reset						
[2]	Energy fed back since the last reset						
p0040	<p><b>Reset energy consumption display</b></p> <p>A signal change 0 → 1 sets r0039[0...2] = 0, r0041 = 0 and r0042 = 0.</p>						
r0041	<p><b>Energy consumption saved (kWh)</b></p> <p>Energy saved referred to 100 operating hours.</p> <p>For less than 100 operating hours, the inverter interpolates the energy saving to 100 operating hours.</p>						
r0042	<p><b>CO: Process energy display [1 Δ 1 Wh]</b></p> <p>For display as process variable. Enable with p0043.</p> <table border="1"> <tr> <td>[0]</td> <td><b>Energy balance</b> Energy consumption since the last reset.</td> </tr> <tr> <td>[1]</td> <td>Energy drawn since the last reset</td> </tr> <tr> <td>[2]</td> <td>Energy fed back since the last reset.</td> </tr> </table>	[0]	<b>Energy balance</b> Energy consumption since the last reset.	[1]	Energy drawn since the last reset	[2]	Energy fed back since the last reset.
[0]	<b>Energy balance</b> Energy consumption since the last reset.						
[1]	Energy drawn since the last reset						
[2]	Energy fed back since the last reset.						
p0043	<p><b>BI: Enable energy usage display</b></p> <p>1 signal: Process energy display is active in r0042.</p>						

### 6.7.3 Electrically braking the motor

#### Braking with the motor in generating mode

If the motor brakes the connected load electrically, it will convert the kinetic energy of the motor to electrical energy. The electrical energy  $E$  released on braking the load is proportional to the moment of inertia  $J$  of the motor and load and to the square of the speed  $n$ . The motor attempts to pass the energy on to the inverter.

#### Main features of the braking functions

##### DC braking

DC braking prevents the motor from transferring braking energy to the inverter. The inverter impresses a DC current into the motor, therefore braking the motor. The motor converts braking energy  $E$  of the load into heat.

- *Advantage:* The motor brakes the load without the inverter having to process regenerative power.
- *Disadvantages:* significant increase in the motor temperature; no defined braking characteristics; no constant braking torque; no braking torque at standstill; braking energy is lost as heat; does not function when the power fails



##### Compound braking

One version of DC braking. The inverter brakes the motor with a defined ramp-down time and superimposes a DC current on the output current.

##### Dynamic braking

Using a braking resistor, the inverter converts the electrical energy into heat.


- *Advantages:* defined braking response; motor temperature does not increase any further; constant braking torque
- *Disadvantages:* Braking resistor required; braking energy  $E$  is lost in the form of heat



### Braking with regenerative feedback into the line supply

The inverter feeds electrical energy back into the line supply (energy recovery).

- *Advantages:* Constant braking torque; the braking energy is not completely converted into heat, but regenerated into the line supply; is suitable for all applications; continuous regenerative operation is possible - e.g. when lowering a suspended load
- *Disadvantage:* Does not function for a power failure



### Which Power Module permits which braking technique?

Electrical braking methods	Power Modules that can be used
DC braking, compound braking	PM240, PM330
Dynamic braking	PM240, PM330
Braking with regenerative feedback into the line supply	PM250, PM260

#### 6.7.3.1 DC braking

DC braking is used for applications without regenerative feedback into the line supply, where the motor can be more quickly braked by impressing a DC current than along a braking ramp.

Typical applications for DC braking include:


- Centrifuges
- Saws
- Grinding machines
- Conveyor belts

### Function

NOTICE
<p><b>Motor damage caused by overheating</b></p> <p>The motor can overheat if it is braked for long periods of time or frequently using DC braking. This may damage the motor.</p> <ul style="list-style-type: none"> <li>• Monitor the motor temperature.</li> <li>• If the motor gets too hot during operation you must select another braking method or give the motor more time to cool down.</li> </ul>

With DC braking, the inverter outputs an internal OFF2 command for the time that it takes to de-energize the motor p0347 - and then impresses the braking current for the duration of the DC braking.

The DC-braking function is possible only for induction motors.



**DC braking when falling below a starting speed**

1. The motor speed has exceeded the starting speed.
2. The inverter activates the DC braking as soon as the motor speed falls below the starting speed.

**DC braking when a fault occurs**

1. A fault occurs, which initiates DC braking as response.
2. The motor brakes along the down ramp to the speed for the start of DC braking.
3. DC braking starts.

### DC braking initiated by a control command

1. The higher-level control issues the command for DC braking, e.g. using DI3: p1230 = 722.3.
2. DC braking starts.

If the higher-level control withdraws the command during DC braking, the inverter interrupts DC braking and the motor accelerates to its setpoint.

### DC braking when the motor is switched off

1. The higher-level control switches off the motor (OFF1 or OFF3).
2. The motor brakes along the down ramp to the speed for the start of DC braking.
3. DC braking starts.

## Settings for DC braking

Parameter	Description
p0347	<b>Motor de-excitation time</b> (calculated after the basic commissioning) The inverter can trip due to an overcurrent during DC braking if the de-excitation time is too short.
p1230	<b>DC braking activation</b> (factory setting: 0) Signal source to activate DC braking <ul style="list-style-type: none"> <li>• 0 signal: Deactivated</li> <li>• 1 signal: Active</li> </ul>
p1231	<b>Configuring DC braking</b> (factory setting: 0)
	0   No DC braking
	4   General release for DC braking
	5   DC braking for OFF1/OFF3
14   DC braking below the starting speed	
p1232	<b>DC braking braking current</b> (factory setting 0 A)
p1233	<b>DC braking duration</b> (factory setting 1 s)
p1234	<b>DC braking start speed</b> (factory setting 210000 rpm)
r1239	<b>DC braking status word</b>
	.08   DC braking active
	.10   DC braking ready
	.11   DC braking selected
	.12   DC braking selection internally locked
.13   DC braking for OFF1/OFF3	

Table 6- 37 Configuring DC braking as a response to faults

Parameter	Description
p2100	<b>Set fault number for fault response</b> (factory setting 0) Enter the fault number for which DC braking should be activated, e.g. p2100[3] = 7860 (external fault 1).
p2101 = 6	<b>Fault response setting</b> (factory setting 0) Assigning the fault response: p2101[3] = 6.
The fault is assigned an index of p2100. Assign the same index of p2100 or p2101 to the fault and fault response. The inverter's List Manual lists in the "Faults and alarms" list the possible fault responses for every fault. The "DCBRAKE" entry means that it is permissible to set DC braking as response for this particular fault.	

### 6.7.3.2 Compound braking

Typical applications for compound braking include:

- Centrifuges
- Saws
- Grinding machines
- Horizontal conveyors

For these applications, the motor is normally operated with a constant speed, and is only braked down to standstill after longer periods of time.

#### Principle of operation




Figure 6-35 Motor brakes with and without active compound braking

Compound braking prevents the DC-link voltage increasing above a critical value. The inverter activates compound braking depending on the DC-link voltage. Above a DC-link voltage threshold (r1282), the inverter adds a DC current to the motor current. The DC current brakes the motor and prevents an excessive increase in the DC-link voltage.

**Note**

Compound braking is possible only with the U/f control.

Compound braking does not operate in the following cases:

- The "flying restart" function is active
- DC braking is active
- Vector control is selected

**Setting and enabling compound braking**

Parameter	Description
p3856	<p><b>Compound braking current (%)</b></p> <p>With the compound braking current, the magnitude of the DC current is defined, which is additionally generated when stopping the motor for operation with U/f control to increase the braking effect.</p> <p>p3856 = 0 Compound braking locked</p> <p>p3856 = 1 ... 250 Current level of the DC braking current as a % of the rated motor current (p0305)</p> <p>Recommendation: <math>p3856 &lt; 100\% \times (r0209 - r0331) / p0305 / 2</math></p>
r3859.0	<p><b>Compound-braking status word</b></p> <p>r3859.0 = 1: Compound braking is active</p>

NOTICE
<p><b>Motor damage from overheating with compound braking</b></p> <p>The motor will overheat if braking lasts too long or the motor is braked too often. This may damage the motor.</p> <p>Monitor the motor temperature. If the motor gets too hot during operation you must select another braking method or give the motor more time to cool down.</p>

### 6.7.3.3 Dynamic braking

Typical applications for dynamic braking include:

- Horizontal conveyors
- Vertical and inclined conveyors
- Hoisting gear

For these applications, dynamic motor behavior with different speeds or continuous change of direction is required.

#### Principle of operation



<b>! CAUTION</b>
<b>Burns when touching a hot braking resistor</b>
A braking resistor reaches high temperatures during operation. Touching the braking resistor may result in burns.
<ul style="list-style-type: none"><li>• Do not touch a braking resistor during operation.</li></ul>

The inverter controls the braking chopper depending on its DC-link voltage. The DC-link voltage increases as soon as the inverter absorbs the regenerative power when braking the motor. The braking chopper converts this power into heat in the braking resistor. This prevents the DC-link voltage from increasing above the limit value  $U_{DC\ link, max}$ .




Figure 6-36 Simplified representation of dynamic braking with respect to time

## Set dynamic braking

Parameter	Description		
p0219	<p><b>Braking power of the braking resistor</b> (factory setting: 0 kW) Set the braking power of the braking resistor.</p> <p><b>Example:</b> In your particular application, the motor brakes every 10 seconds. In so doing, the braking resistor must handle a braking power of 1 kW for 2 s. Use a braking resistor with a continuous rating of <math>1 \text{ kW} \times 2 \text{ s} / 10 \text{ s} = 0.2 \text{ kW}</math>, and set the maximum braking power to: <math>p0219 = 1 \text{ (kW)}</math>.</p> <p>Under certain circumstances, for low braking power ratings, the inverter extends the ramp-down time of the motor.</p> <p>For <math>p0219 &gt; 0</math>, the inverter deactivates the VDC_max controller.</p>		
p0844	<p><b>No coast down/coast down (OFF2) signal source 1</b></p> <table border="1" style="width: 100%;"> <tr> <td style="width: 30%;"><math>p0844 = 722.x</math></td> <td>Monitor the overtemperature of the braking resistor with digital input x of the inverter.</td> </tr> </table>	$p0844 = 722.x$	Monitor the overtemperature of the braking resistor with digital input x of the inverter.
$p0844 = 722.x$	Monitor the overtemperature of the braking resistor with digital input x of the inverter.		

### 6.7.3.4 Braking with regenerative feedback to the line

The typical applications for braking with energy recovery (regenerative feedback into the line supply) are as follows:

- Hoist drives
- Centrifuges
- Unwinders

For these applications, the motor must brake for longer periods of time.

The inverter can feed back up to 100% of its rated power into the line supply (referred to "High Overload" base load, see section Technical data, Power Modules (Page 372)).

### Setting the braking with regenerative feedback to the line

Parameter	Description
<b>Limiting the regenerative feedback for U/f control (<math>p1300 &lt; 20</math>)</b>	
p0640	<p><b>Motor series overload factor</b> (factory setting: 0.00 A, default for basic commissioning) It is only possible to limit the regenerative power with V/f control by limiting the motor current.</p> <p>If the current exceeds this value for longer than 10 s, the inverter shuts down the motor with fault F07806.</p>
<b>Limiting feedback with vector control (<math>p1300 \geq 20</math>)</b>	
p1531	<p><b>Power limit, generating</b> (factory setting: -0.01 kW) The inverter calculates the parameter based on the basic commissioning or with <math>p0340 = 5</math>.</p>

### 6.7.4 Flying restart – switching on while the motor is running

If you switch on the motor while it is still rotating, without the "Flying restart" function, there is a high probability that a fault will occur as a result of overcurrent (F30001 or F07801). Examples of applications involving an unintentionally rotating motor directly before switching on:

- The motor rotates after a brief line interruption.
- A flow of air turns the fan impeller.
- A load with a high moment of inertia drives the motor.

#### Principle of operation

The "Flying restart" function comprises the following steps:

1. After the on command, the inverter impresses the search current in the motor and increases the output frequency.
2. When the output frequency reaches the actual motor speed, the inverter waits for the motor excitation build up time.
3. The inverter accelerates the motor to the actual speed setpoint.




Figure 6-37 Principle of operation of the "flying restart" function

#### Setting "flying restart" function

Parameter	Description	
p1200	<b>Flying restart operating mode</b> (factory setting: 0)	
	0	Flying restart is disabled
	1	Flying restart is enabled, search for the motor in both directions, start in the direction of the setpoint
	4	Flying restart is enabled, search for the motor only in the direction of the setpoint

#### No "Flying restart" function for group drives

It is not permissible that you enable the "Flying restart" function if the inverter is simultaneously driving several motors.

Exception: a mechanical coupling ensures that all of the motors always operate with the same speed.

Table 6- 38 Advanced settings

<b>Parameter</b>	<b>Description</b>
p0346	<b>Motor excitation build up time</b> Wait time between switching on the motor and enabling the ramp-function generator.
p0347	<b>Motor de-excitation time</b> Within the motor de-excitation time, after an OFF command, the inverter prevents the induction motor from being switched on again. When using a reluctance motor, the inverter ignores the motor de-excitation time.
p1201	<b>Flying restart enable signal source</b> (factory setting: 1) Defines a control command, e.g. a digital input, which enables the flying restart function.
p1202	<b>Flying restart search current</b> (Factory setting depends on the Power Module) Defines the search current with respect to the magnetizing current (r0331), which flows in the motor during the flying restart.
p1203	<b>Flying restart search current factor</b> (Factory setting depends on the Power Module) The value influences the speed with which the output frequency is changed during the flying restart. A higher value results in a longer search time. If the inverter does not find the motor, reduce the search speed (increase p1203).

### 6.7.5 Automatic switch-on

The automatic restart includes two different functions:

- The inverter automatically acknowledges faults.
- After a fault occurs or after a power failure, the inverter automatically switches-on the motor again.

The inverter interprets the following events as power failure:

- The inverter signals fault F30003 (DC-link undervoltage), as the line supply voltage of the inverter has briefly failed.
- The inverter power supply has failed for a long enough time so that the inverter has been switched-off.

 <b>WARNING</b>
<p><b>Danger to life as a result of machine parts unexpectedly starting</b></p> <p>When the "automatic restart" function is active (p1210 &gt; 1), the motor automatically starts after a power failure. Unexpected movement of machine parts can result in serious injury and material damage.</p> <ul style="list-style-type: none"> <li>• Block off hazardous areas within the machine to prevent inadvertent access.</li> </ul>

### Setting the automatic restart function

If it is possible that the motor is still rotating for a longer period of time after a power failure or after a fault, then in addition, you must activate the "flying restart" function, see Flying restart – switching on while the motor is running (Page 256).

Using p1210, select the automatic restart mode that best suits your application.





Figure 6-38 Automatic restart modes

The principle of operation of the other parameters is explained in the following diagram and in the table below.



<sup>1)</sup> The inverter automatically acknowledges faults under the following conditions:

- p1210 = 1 or 26: Always.
- p1210 = 4 or 6: If the command to switch-on the motor is available at a digital input or via the fieldbus (ON/OFF1 = 1).
- p1210 = 14 or 16: Never.

<sup>2)</sup> The inverter attempts to automatically switch the motor on under the following conditions:

- p1210 = 1: Never.
- p1210 = 4, 6, 14, 16, or 26: If the command to switch-on the motor is available at a digital input or via the fieldbus (ON/OFF1 = 1).

<sup>3)</sup> If, after a flying restart and magnetization ( $r0056.4 = 1$ ) no fault occurs within one second, then the start attempt was successful.

Figure 6-39 Time response of the automatic restart

## Parameter for setting the automatic restart

Parameter	Explanation
p1210	<p><b>Automatic restart mode</b> (factory setting: 0)</p> <p>0: Disable automatic restart.            1: Acknowledge all faults without restarting.            4: Restart after power failure without further restart attempts.            6: Restart after fault with further restart attempts.            14: Restart after power failure after manual acknowledgement.            16: Restart after fault after manual acknowledgement.            26: Acknowledgement of all faults and restart with ON/OFF1 = 1 command.</p>
p1211	<p><b>Automatic restart start attempts</b> (factory setting: 3)</p> <p>This parameter is only effective for the settings p1210 = 4, 6, 14, 16, 26.</p> <p>You define the maximum number of start attempts using p1211. After each successful acknowledgement, the inverter decrements its internal counter of start attempts by 1.</p> <p>p1211 = 0 or 1: The inverter only tries to start once. After an unsuccessful start attempt, the inverter issues fault F07320.</p> <p>p1211 = n, n &gt; 1: The inverter tries to start n-times. The inverter outputs fault F07320 if the nth starting attempt was unsuccessful.</p> <p>The inverter sets the start attempt counter back again to the value of p1211, if one of the following conditions is fulfilled:</p> <ul style="list-style-type: none"> <li>• After a successful start attempt, the time in p1213[1] has expired.</li> <li>• After fault F07320, switch off the motor (OFF1) and acknowledge the fault.</li> <li>• You change the start value p1211 or the mode p1210.</li> </ul>
p1212	<p><b>Automatic restart wait time start attempt</b> (factory setting: 1.0 s)</p> <p>This parameter is only effective for the settings p1210 = 4, 6, 26.</p> <p>Examples for setting this parameter:</p> <ol style="list-style-type: none"> <li>1. After a power failure, a certain time must elapse before the motor can be switched-on, e.g. because other machine components are not immediately ready. In this case, set p1212 longer than the time, after which all of the fault causes have been removed.</li> <li>2. In operation, the inverter develops a fault condition. The lower you select p1212, then the sooner the inverter attempts to switch-on the motor again.</li> </ol>
p1213[0]	<p><b>Automatic restart monitoring time for restart</b> (factory setting: 60 s)</p> <p>This parameter is only effective for the settings p1210 = 4, 6, 14, 16, 26.</p> <p>With this monitoring function, you limit the time in which the inverter may attempt to automatically switch-on the motor again.</p> <p>The monitoring function starts when a fault is identified and ends with a successful start attempt. If the motor has not successfully started after the monitoring time has expired, fault F07320 is signaled.</p> <p>Set the monitoring time longer than the sum of the following times:</p> <ul style="list-style-type: none"> <li>+ p1212</li> <li>+ Time that the inverter requires to start the motor on the fly.</li> <li>+ Motor magnetizing time (p0346)</li> <li>+ 1 second</li> </ul> <p>You deactivate the monitoring function with p1213 = 0.</p>

Parameter	Explanation
p1213[1]	<p><b>Automatic restart monitoring time to reset the fault counter</b> (factory setting: 0 s)</p> <p>This parameter is only effective for the settings p1210 = 4, 6, 14, 16, 26.</p> <p>Using this monitoring time, you prevent that faults, which continually occur within a certain time period, are automatically acknowledged each time.</p> <p>The monitoring function starts with a successful start attempt and ends after the monitoring time has expired.</p> <p>If, during the monitoring time p1213[1], the inverter made more successful starting attempts than defined in p1211, the inverter interrupts the automatic restart function and signals fault F07320. To switch on the motor again you must acknowledge the fault and switch on the inverter (ON/OFFS1 = 1).</p>

Additional information is provided in the parameter list of the List Manual.

### Advanced settings

If you wish to suppress the automatic restart function for certain faults, then you must enter the appropriate fault numbers in p1206[0 ... 9].

Example: p1206[0] = 07331 ⇒ No restart for fault F07331.

Suppressing the automatic restart only functions for the setting p1210 = 6, 16 or 26.

 <b>WARNING</b>
<p><b>Danger to life if an OFF command has no effect.</b></p> <p>When the inverter is only controlled via the fieldbus interface, the motor restarts with the setting p1210 = 6, 16, 26 – even if the communication link is currently interrupted. When communication is interrupted, the control system cannot switch off the motor.</p> <ul style="list-style-type: none"><li>• Enter the fault number of the communication error in parameter p1206. Example: Fault number F01910 means: Communication via PROFIBUS failed. Set p1206[n] = 1910 (n = 0 ... 9).</li></ul>

### 6.7.6 Kinetic buffering (V<sub>dc</sub> min control)

Kinetic buffering increases the drive availability. The kinetic buffering utilizes the kinetic energy of the load to buffer line dips and failures. During a line dip, the inverter keeps the motor in the switched-on state for as long as possible. One second is a typical, maximum buffer time.

#### Preconditions

The following prerequisites must be fulfilled to practically use the "kinetic buffering" function:

- The driven load has a sufficiently high inertia.
- The application allows a motor to be braked during a power failure.

#### Function

When the line supply dips or is interrupted, the DC link voltage in the inverter decreases. At an adjustable threshold, kinetic buffering intervenes (V<sub>DC min</sub> control). The V<sub>DC min</sub> control forces the load to go into slightly regenerative operation. As a consequence, the inverter covers its power loss and the losses in the motor with the kinetic energy of the load. The load speed decreases; however, during kinetic buffering, the DC voltage remains constant. After the line supply returns, the inverter immediately resumes normal operation.




Figure 6-40 Principle mode of operation of kinetic buffering

Parameter	Description
r0056.15	<b>Status word closed-loop control</b>
	0 signal $V_{DC\ min}$ controller is not active
	1 signal $V_{DC\ min}$ controller is active (kinetic buffering)
p0210	<b>Device supply voltage</b> (factory setting: 400 V)
p1240	<b><math>V_{DC}</math> controller configuration</b> (factory setting: 1)
	0      Inhibit $V_{DC}$ controller
	1      Enable $V_{DC\ max}$ controller
	2      Enable $V_{DC\ min}$ controller (kinetic buffering)
3      Enable $V_{DC\ min}$ controller and $V_{DC\ max}$ controller	
p1245	<b><math>V_{DC\ min}</math> controller activation level</b> (kinetic buffering) (factory setting: 76 %)
r1246	<b><math>V_{DC\ min}</math> controller activation level[V]</b> $r1246 = p1245 \times \sqrt{2} \times p0210$
p1247	<b><math>V_{DC\ min}</math> controller dynamic factor</b> (factory setting: 300 %)
p1255	<b><math>V_{DC\ min}</math> controller time threshold</b> (factory setting: 0 s) Maximum duration of the kinetic buffering. If kinetic buffering lasts longer than that specified in the parameter value, the inverter outputs fault F7406. A value of 0 deactivates the monitoring.
p1257	<b><math>V_{DC\ min}</math> controller speed threshold</b> (factory setting: 50 rpm) When fallen below, the inverter outputs fault F7405.

## 6.7.7 Line contactor control

The line contactor control is used to switch on and switch off the power supply voltage for the inverter via a digital output of the inverter. Precondition is an external 24 V power supply for the inverter CU.

You can monitor when the line contactor opens and closes using the feedback signal contact of the contactor.

The function has the advantage that you only switch on the line voltage for the inverter briefly before the motor must be switched on. If the motor is switched off, after an adjustable wait time, the line voltage for the inverter is switched off again.

This means that you reduce the inverter losses for the times when the motor is not operational.

### Activate line contactor control

You activate the line contactor control by interconnecting the signal source of a digital output of the inverter (depending on the particular inverter, p0730 ... p0741) with the signal to control the line contactor (r0863.1). For example: p0732 = 863.1.

#### Line contactor control without monitoring - factory setting:

In the factory setting, the function for a line contactor without feedback signal contact is set. The feedback signal is linked with the signal to control the line contactor: p0860 = 863.1.

For an OFF1, the line contactor opens after the delay time setting in p0867.

#### Line contactor control with monitoring:

If you use a line contactor with feedback signal contact, activate the feedback signal by linking the parameter for the feedback signal - p0860 -with the inverted signal of a digital input: p0860 = 723.x.

If monitoring is active, when switching off or switching on, message F07300 is output, if, after the time set in p0861 no feedback signal is received via r723.x.

In addition for inverters with STO: Sequence control via p0869

Using p0869, you set whether the line contactor immediately opens for an STO signal, or only after the time set in p0867 has expired.




Figure 6-41 Line contactor control with monitoring

### Parameter to set the line contactor control

Parameter	Explanation
p0860	<b>Line contactor feedback signal</b> <ul style="list-style-type: none"> <li>p0860 = 863.1: No feedback signal</li> <li>p0860 = 723.x: Feedback signal via DIx</li> </ul>
p0861	<b>Line contactor monitoring time</b> (Factory setting: 100 ms) Fault F07300 is output if, for an activated feedback signal, no feedback signal is received via the selected digital input after the time set here has expired.
r0863.1	<b>Drive coupling status/control word</b> Bit to activate the line contactor control: Assign 863.1 to DO x, Example: Control line contactor via digital output DO 2: p0732 = 863.1
p0867	<b>Main contactor holding time after OFF1</b> (Factory setting: 50 ms) Time where, after an OFF1, the main contactor remains closed.
p0869	<b>Sequence control configuration</b> <ul style="list-style-type: none"> <li>p0689 = 0: Line contactor opens immediately for an STO</li> <li>p0689 = 1: For an STO, the line contactor opens after the time set in p0867 has expired</li> </ul>

### Line contactor control for PM330 Power Modules

For a PM330, you can connect a line contactor without requiring any additional parameterization via terminals X9.11 and X9.12. See Digital inputs and outputs on the PM330 Power Module (Page 66).

### 6.7.8 PID technology controller

The technology controller controls process variables, e.g. pressure, temperature, level or flow.





Figure 6-42 Example: Technology controller as a level controller

### Simplified representation of the technology controller

The technology controller is implemented as a PID controller (controller with proportional, integral, and derivative action).



- ① The inverter uses the start value when all the following conditions are simultaneously satisfied:
- The technology controller supplies the main setpoint (p2251 = 0).
  - The ramp-function generator output of the technology controller has not yet reached the start value.

Figure 6-43 Simplified representation of the technology controller

The settings required as a minimum are marked in gray in the function diagram: Interconnect setpoint and actual values with signals of your choice, set the ramp-function generator and controller parameters  $K_P$ ,  $T_I$  and  $T_d$ .

You will find information on the following PID controller topics in the Internet at: FAQ (<http://support.automation.siemens.com/WW/view/en/92556266>)

- Setpoint value specification: Analog value or fixed setpoint
- Setpoint channel: Scaling, ramp-function generator and filter
- Actual value channel: Filter, limiting and signal processing
- PID controller Principle of operation of the D component, inhibiting the I component and the control sense
- Enable, limiting the controller output and fault response

### Setting the technology controller

Parameter	Remark
p2200	<b>BI: Technology controller enable</b> (factory setting: 0) 1 signal: Technology controller is enabled.
r2294	<b>CO: Technology controller output signal</b> To interconnect the main speed setpoint with the technology controller output, set p1070 = 2294.
p2253	<b>CI: Technology controller setpoint 1</b> (factory setting: 0) Setpoint for the technology controller. Example: p2253 = 2224: The inverter interconnects the fixed setpoint p2201 with the setpoint of the technology controller. p2220 = 1: The fixed setpoint p2201 is selected.
p2264	<b>CI: Technology controller actual value</b> (factory setting: 0) Technology controller actual value.
p2257, p2258	<b>Technology controller ramp-up time and ramp-down time</b> (factory setting: 1 s)
p2274	<b>Technology controller differentiation time constant <math>T_d</math></b> (factory setting: 0.0 s) The differentiation improves the rise time for very slow controlled variables, e.g. a temperature control.
p2280	<b>Technology controller proportional gain <math>K_P</math></b> (factory setting: 1,0)
p2285	<b>Technology controller integration time (integral time) <math>T_I</math></b> (factory setting: 30 s)

Advanced settings

Parameter	Remark
<b>Limiting the output of the technology controller</b>	
In the factory setting, the output of the technology controller is limited to $\pm$ maximum speed. You must change this limit, depending on your particular application. Example: The output of the technology controller supplies the speed setpoint for a pump. The pump should only run in the positive direction.	
p2297	<b>CI: Technology controller maximum limiting signal source</b> (factory setting: 1084)
p2298	<b>CI: Technology controller minimum limiting signal source</b> (factory setting: 2292)
p2291	<b>CO: Technology maximum limiting</b> (factory setting: 100 %)
p2292	<b>CO: Technology minimum limiting</b> (factory setting: 0 %)
<b>Manipulating the actual value of the technology controller</b>	
p2267	<b>Technology controller upper limit actual value</b> (factory setting: 100 %)
p2268	<b>Technology controller lower limit actual value</b> (factory setting: -100 %)
p2269	<b>Technology controller gain actual value</b> (factory setting: 100 %)
p2271	<b>Technology controller actual value inversion (sensor type)</b>
	0: No inversion
	1: Inversion actual value signal If the actual value decreases with increasing motor speed, then p2271 must be set = 1.
p2270	<b>Technology controller actual value function</b>
	0: No function
	1: $\sqrt{\quad}$
	2: $x^2$
	3: $x^3$

For further information refer to the function block diagrams 7950 ff of the List Manual.

Autotuning of the PID controller

Requirements

The PID technology controller must be set the same as when used in subsequent operation:

- The actual value is interconnected.
- Scalings, filter and ramp-function generator have been set.
- The PID technology controller has been enabled (p2200 = 1 signal)

Procedure



Proceed as follows to auto tune the PID controller:

1. Set p2350 to a value of your choice.
2. Set offset p2355. The slower the controlled variable responds, the higher p2350 must be.
3. Switch on the motor.

The inverter signals Alarm A07444.


4. Wait until alarm A07444 goes away.

The inverter has recalculated parameters p2280, p2274 and p2285.

If the inverter signals fault F07445, then increase p2354 and repeat the autotuning.

5. Back up the calculated values so that they are protected against power failure, e.g. using the BOP-2: OPTIONS → RAM-ROM.

■ You have auto tuned the PID controller.

Parameter	Remark	
p2350	<b>PID Autotune Enable</b> (Factory setting: 0)	
	0: No function	
	1: Autotuning based on the "Ziegler Nichols" technique. The controlled variable follows the setpoint relatively quickly after a step-like setpoint change, however with some overshoot.	
	2: Faster controller setting than setting 1, with a higher overshoot of the controlled variable.	
	3: Slower controller setting than setting 1. Overshoot of the controlled variable is, to a large extent, avoided.	
4: The autotuning only optimizes the P and I component of the PID controller.		
p2354	<b>PID tuning timeout length</b> (Factory setting: 240 s) Max. wait time until the autotuning must have identified the control loop oscillating.	
p2355	<b>PID tuning offset</b> (Factory setting: 5 %) Offset and deviation for autotuning	

**Setting the technology controller without autotuning (manual)**

**Procedure**



Proceed as follows to manually set the technology controller:

1. Temporarily set the ramp-up and ramp-down times of the ramp-function generator (p2257 and p2258) to zero.
2. Enter a setpoint step and monitor the associated actual value, e.g. with the trace function of STARTER.

The slower the response of the process to be controlled, the longer you must monitor the controller response. Under certain circumstances (e.g. for a temperature control), you need to wait several minutes until you can evaluate the controller response.

	<p>Optimum controller response for applications that do not permit any overshoot. The actual value approaches the setpoint without any significant overshoot.</p>
	<p>Optimum controller behavior for fast correction and quick compensation of disturbance components. The actual value approaches the setpoint and slightly overshoots, maximum 10% of the setpoint step.</p>
	<p>The actual value only slowly approaches the setpoint.</p> <ul style="list-style-type: none"> <li>• Increase the proportional component <math>K_P</math> and reduce the integration time <math>T_I</math>.</li> </ul>
	<p>Actual value only slowly approaches the setpoint with slight oscillation.</p> <ul style="list-style-type: none"> <li>• Increase the proportional component <math>K_P</math> and reduce the rate time <math>T_d</math> (differentiating time).</li> </ul>
	<p>The actual value quickly approaches the setpoint, but overshoots too much.</p> <ul style="list-style-type: none"> <li>• Decrease the proportional component <math>K_P</math> and increase the integration time <math>T_I</math>.</li> </ul>

3. Set the ramp-up and ramp-down times of the ramp-function generator back to their original value.




You have now manually set the technology controller.

## 6.7.9 Free technology controllers

### Additional PID controller

The inverter has three additional technology controllers.

When compared to the main PID technology controller, the free technology controllers have somewhat fewer setting options, see also PID technology controller (Page 266).



n = 0 Free technology controller 0

n = 1 Free technology controller 1

n = 2 Free technology controller 2

Figure 6-44 Simplified function chart of the additional PID technology controller, n = 0 ... 2

You can find the complete function diagram 7030 in the List Manual.

The additional technology controllers allow several process variables to be simultaneously controlled using one inverter. An example is a HVAC system with heating and cooling valves to process the air:

- The main controller controls the speed of the fan drive.
- The additional technology controllers control the cooling and heating via the two analog outputs available.

## Parameter using the free technology controller 0 as example

Parameter	Remark	
p11000	<b>BI: Free tec_ctrl 0 enable</b> (Factory setting: 0)	
	1 signal:	Technology controller is enabled.
p11053	<b>CI: Free tec_ctrl 0 setpoint signal source</b> (Factory setting: 0)	
p11057, p11058	<b>Free tec_ctrl 0 setpoint ramp-up time and ramp-down time</b> (Factory setting: 1 s)	
p11063	<b>Free tec_ctrl 0 error signal inversion</b> (Factory setting: 0 s)	
	0:	No inversion
	1:	Inversion p11063 must be set = 1 if the actual value decreases with increasing motor speed.
p11064	<b>CI: Free tec_ctrl 0 actual value signal source</b> (Factory setting: 0)	
p11065	<b>Free tec_ctrl 0 actual value smoothing time constant</b> (Factory setting: 0 s)	
p11067	<b>Free tec_ctrl 0 actual value upper limit</b> (Factory setting: 100 %)	
p11068	<b>Free tec_ctrl 0 actual value lower limit</b> (Factory setting: -100 %)	
p11071	<b>Free tec_ctrl 0 actual value inversion</b> (Factory setting: 0)	
	0:	No inversion
	1:	Inversion
p11074	<b>Free tec_ctrl 0 differentiation time constant (<math>T_d</math>)</b> (Factory setting: 0 s)	
p11080	<b>Free tec_ctrl 0 proportional gain (<math>K_P</math>)</b> (Factory setting: 1.0)	
p11085	<b>Free tec_ctrl 0 integral time (<math>T_i</math>)</b> (Factory setting: 30 s)	
p11091	<b>CO: Free tec_ctrl 0 maximum limit</b> (Factory setting: 100 %)	
p11092	<b>CO: Free tec_ctrl 0 minimum limit</b> (Factory setting: 0 %)	
r11094	<b>CO: Free tec_ctrl 0 output signal</b>	

You can find the complete parameter list in the List Manual.

## 6.7.10 System protection

In many applications, monitoring the motor speed and torque provides information about the plant or system status. By setting the appropriate responses in the case of faults, failures and damage to the plant or system can be avoided.

Examples:

- For fans or conveyor belts, an excessively low torque can mean a broken drive belt.
- For pumps, an excessively low torque down to zero speed can mean an inadmissible operating state.
- For extruders and mixers, excessively high torque can mean overload or a blocked machine.

### System protection functions

The inverter offers the following options of monitoring the motor load torque and speed:

- No-load monitoring
- Blocking protection
- Stall protection
- Load monitoring

No-load monitoring, blocking protection and stall protection require just a few settings. However, the load monitoring is a function that offers a wide range of different setting options – which in turn demands that you have good knowledge of the system.

### 6.7.10.1 No-load monitoring, blocking protection, stall protection

#### No-load monitoring

##### Principle of operation

If the motor current is below the value of p2179 for the time set in p2180, using bit 11 of status word 1 for monitoring functions (r2197.11), the converter outputs the "Output load not available" message.

Applications: Fans and conveyor belts

##### Settings

Parameters	Description
p2179	<b>Output load detection current limit</b> (factory setting: 0 A) p2179 = 0: No load detection deactivated
p2180	<b>Output load detection delay time</b> (factory setting: 2000 ms)

#### Stall protection

##### Principle of operation

If the speed lies below the value of p2175 for the time set in p2177, and the converter is operating at the current or torque limit, using bit 6 of status word 2 for monitoring functions (r2198.6), the converter outputs the "Motor blocked" message.

The converter goes to the current or torque limit if the setpoint speed is significantly higher than the actual speed.

Applications: Extruders and mixers

##### Settings

Parameters	Description
p2175	<b>Motor blocked speed threshold</b> (factory setting: 120 rpm) p2175 = 0: Blocking protection deactivated
p2177	<b>Motor blocked delay time</b> (factory setting: 3 s)

## Stall protection

### Principle of operation

If the value in r1746 exceeds the value of p1745 for the time set in p2178, using bits 7 of status word 2, for monitoring functions (r2198.7) the converter outputs the "Motor stalled" message.

Applications: General system protection

### Settings

Parameters	Description
p1745	<b>Motor model fault threshold value stall detection</b> (factory setting: 5 %) If the motor stalls too early with this setting, then using the trace function you have the option of determining a better value. To do this, set p1745 = 100.
p2178	<b>Motor stalled delay time</b> (factory setting: 0.01 s)

For blocking protection below the current/torque limit, see paragraph "Monitoring pumps/fans" in the Section Load monitoring (Page 276).

### 6.7.10.2 Load monitoring

The load monitoring comprises the following components:

- Load failure monitoring
- Monitoring for torque deviation
- Pump monitoring
- Fan monitoring

If the load monitoring detects load failure, then the converter always goes into a fault condition and outputs fault F07936. For a torque and speed deviation, as response, you can either set an alarm or a fault. Details are provided in the following descriptions.

#### Settings

Table 6- 39 Setting options for load monitoring

Parameters	Description
p2193	<b>Load monitoring configuration</b> (factory setting: 1) 0: Monitoring deactivated 1: Monitoring, torque and load failure 3: Monitoring, load failure 4: Pump monitoring 5: Fan monitoring

### Load failure monitoring

#### Principle of operation

Using this function, the inverter monitors the speed or velocity of a machine component. The inverter evaluates whether an encoder signal is present. If the encoder signal fails for a time that can be adjusted, then the inverter signals a fault.

Examples of how the function can be used:

- Gearbox monitoring for traction drives and hoisting gear
- Drive belt monitoring for fans and conveyor belts
- Blocking protection for pumps and conveyor belts




Figure 6-45 Function plan and time response of load-interruption monitoring


## Settings

Parameter	Description
p2192	<b>Load monitoring delay time</b> (factory setting 10 s) After the motor is switched on, if the "LOW" signal is present at the associated digital input for longer than this time, the inverter signals a load failure (F07936).
p2193 = 3	<b>Load monitoring configuration</b> see Table 6-39 Setting options for load monitoring (Page 276)
p3232 = 722.x	<b>Load monitoring failure detection</b> (factory setting: 1) Connect the load monitoring to a DI x digital input of your choice.

For more information, see the List Manual (the parameter list and function diagram 8013).

## Monitoring for torque deviation

Based on the envelope curve shown below and dependent on the speed, the torque is monitored against a lower and upper torque. The inverter linearly interpolates the intermediate values.



### Principle of operation

The inverter monitors the motor torque for speeds between threshold value 1 and threshold value 3.

If the torque lies outside the envelope curve for longer than the time set in p2192, then the response defined in p2181 is initiated.

The torque is not monitored for speeds between 0 and speed threshold 1 (p2182) - as well as between speed threshold 3 (p2184 and the maximum speed (p1082).

**Settings**

Parameters	Description
p2181	<b>Load monitoring response</b> Response when evaluating the load monitoring. Setting options see Response options for the load monitoring (Page 280)
p2182	<b>Load monitoring speed threshold 1</b>
p2183	<b>Load monitoring speed threshold 2</b>
p2184	<b>Load monitoring speed threshold 3</b>
p2185	<b>Load monitoring torque threshold 1, upper</b>
p2186	<b>Load monitoring torque threshold 1, lower</b>
p2187	<b>Load monitoring torque threshold 2, upper</b>
p2188	<b>Load monitoring torque threshold 2, lower</b>
p2189	<b>Load monitoring torque threshold 3, upper</b>
p2190	<b>Load monitoring torque threshold 3, lower</b>
p2192	<b>Load monitoring delay time</b> Delay time for the message "Leave torque monitoring tolerance band"
p2193 = 1	<b>Load monitoring configuration</b> (factory setting: 1) see Table 6-39 Setting options for load monitoring (Page 276)


**Monitoring, pump/fan**

The monitoring functions for pumps and fans are similar. The blocking protection applies equally to both applications.

For pumps, there is also a leakage monitoring function.

**Principle of operation**

Within speed thresholds 1 and 3, the inverter monitors the torque and the speed for pumps and fans.



If the torque or the speed moves, for longer than the time set in p2192, in the ranges of blockage, leakage or dry running protection/belt breakage, then the response defined in p2181 is realized.

### **Restrictions and general constraints for blocking protection depending on the motor type and control mode**

The following preconditions must be satisfied in order that the blockage monitoring is active for pumps and fans:

- The following applies for application class "Standard Drive Control" (p0096 = 1) or "Expert" (p0096 = 0) and U/f control (p1300 < 10):

Speed actual value > p2182 and > 10 % rated speed. A torque actual value r0080 is only calculated in this range.

When the I<sub>max</sub> control is active (when reaching the current limit) the blocking protection intervenes according to the description in No-load monitoring, blocking protection, stall protection (Page 274)

- For vector control (p1300 = 20) or application class "Dynamic Drive Control" (p0096 = 2), the following always applies:

- Speed setpoint > p1755 switchover speed, motor model
- Speed actual value > p2182 speed threshold 1

In addition, the following applies:

- for induction motors (operated with the vector control)
  - p1750.6 = 1 (when the motor is blocked, the closed-loop control does not change into the open-loop controlled mode) or p2192 < 1 s
- for synchronous and reluctance motors (operated with vector control)
  - p2182 > p1755 switchover speed, motor model
  - With this method, a complete blockage is not detected

**Settings**


Parameters	Description
p2165	<b>Load monitoring blocking monitoring threshold, upper</b>
p2168	<b>Load monitoring blocking monitoring torque threshold</b>
p2181	<b>Load monitoring response</b> Response when evaluating the load monitoring. Setting options, see Table 6-40 Response options for load monitoring (Page 280)
p2182	<b>Load monitoring speed threshold 1</b>
p2183	<b>Load monitoring speed threshold 2</b>
p2184	<b>Load monitoring speed threshold 3</b>
p2186	<b>Load monitoring torque threshold 1, lower</b>
p2188	<b>Load monitoring torque threshold 2, lower</b>
p2190	<b>Load monitoring torque threshold 3, lower</b>
p2191	<b>Load monitoring torque threshold, no load</b>
p2192	<b>Load monitoring delay time</b>
p2193 = 3	<b>Load monitoring configuration</b> see Table 6-39 Setting options for load monitoring (Page 276)

Table 6- 40 Response options for load monitoring

p2181 = 0	Load monitoring deactivated (factory setting)
p2181 = 1	A07920 for torque/speed too low
p2181 = 2	A07921 for torque/speed too high
p2181 = 3	A07922 for torque/speed out of tolerance
p2181 = 4	F07923 for torque/speed too low
p2181 = 5	F07924 for torque/speed too high
p2181 = 6	F07925 for torque/speed out of tolerance
p2181 = 7	Pump/fan load monitoring as alarm
p2181 = 8	Pump/fan load monitoring as fault

The settings in p2193 for pumps/fans (p2193 = 4 or 5) are only permissible with the settings for load monitoring for pumps/fans (p2181 = 7 or 8)

## 6.7.11 Real time clock (RTC)



The real time clock is the basis for time-dependent process controls, e.g.:

- To reduce the temperature of a heating control during the night
- Increase the pressure of a water supply at certain times during the day

### Function and settings

The real time clock starts as soon as the Control Unit power supply is switched on for the first time. The real time clock comprises the time in a 24 hour format and the date in the "day, month, year" format.

After a Control Unit power supply interruption, the real time clock continues to run for approx. five days.

If you wish to use the real time clock, you must set the time and date once when commissioning.

If you restore the inverter factory setting, the real time clock is not reset.

Parameter	Real time clock (RTC)
p8400	<b>RTC time</b> (Factory setting: 0)
	[0] Hour (0 ... 23)
	[1] Minute (0 ... 59)
	[2] Second (0 ... 59)
p8401	<b>RTC date</b> (Factory setting: 1.1.1970)
	[0] Tag: 1 ... 31.
	[1] Month 1 (January) ... 12 (December)
	[2] Year: 1970 ... 9999
p8402	<b>RTC daylight saving time setting</b>
	[0] Difference between daylight saving time and standard time (factory setting: 0 h)
	[1] Start of month (factory setting: 3), 1 (January) ... 12 (December)
	[2] Start of week of month (factory setting: 6) 1: Tag 1 ... 7, 2: Tag 8 ... 14, 3: Tag 15 ... 21, 4: Tag 22 ... 28, 6: Last seven days of the month
	[3] Start of weekday (factory setting: 7), 1 (Monday) ... 7 (Sunday)
	[4] Start of hour (factory setting: 2)
	[5] End month (factory setting: 10)
	[6] End week of month (factory setting: 6) 1: Tag 1 ... 7, 2: Tag 8 ... 14, 3: Tag 15 ... 21, 4: Tag 22 ... 28, 6: Last seven days of the month
	[7] End weekday (factory setting: 7), 1 (Monday) ... 7 (Sunday)
	[8] End hour (factory setting: 3)
r8403	<b>RTC daylight saving time difference actual</b> [hours] Displays the actual difference between standard time and daylight saving time.

Parameter	Real time clock (RTC)
r8404	RTC weekday, 1: Monday ... 7: Sunday
p8405	RTC activate/deactivate alarm A01098 (Factory setting: 1) Alarm for non synchronous time, e.g. after a longer power supply interruption.
	0: No alarm
	1: Alarm A01098

**Accept the real time clock in the alarm and fault buffer**

Using the real time clock, you can track the sequence of alarms and faults over time. When an appropriate message occurs, the inverter converts the real time clock into the UTC time format (Universal Time Coordinated):

Date, time ⇒ 01.01.1970, 0:00 + d (days) + m (milliseconds)

The inverter takes the number "d" of the days and the number "m" of the milliseconds in the alarm and fault times of the alarm and/or fault buffer, see also: Alarms, faults and system messages (Page 347).

**Converting UTC into RTC**

An RTC can again be calculated in the UTC format from the saved fault or alarm time. In the Internet, you will find programs to convert from UTC into RTC, e.g.:  
UTC to RTC (<http://unixtime-converter.com/>)

**Example:**

Saved as alarm time in the alarm buffer:

r2123[0] = 2345 [ms]  
r2145[0] = 14580 [days]

Number of seconds = 2345 / 1000 + 14580 × 86400 = 1259712002  
Converting this number of seconds in RTC provides the date: 02.12.2009, 01:00:02.

The times specified for alarms and faults always refer to standard time.

## 6.7.12 Time switch (DTC)

The "time switch" (DTC) function, along with the real time clock in the inverter, offers the option of controlling when signals are switched on and off.

### Examples:

- Switching temperature control from day to night mode.
- Switching a process control from weekday to weekend.

### Principle of operation of the time switch (DTC)

The inverter has three independently adjustable time switches. The time switch output can be interconnected with every binector input of your inverter, e.g. with a digital output or a technology controller's enable signal.




Figure 6-46 Example of the response of the time switch.

### Settings for the example with DTC1

- Enable parameterization of the DTC: p8409 = 0.  
As long as the parameterization of the DTC is enabled, the inverter holds the output of all three DTC (r84x3, x = 1, 2, 3; r84x3.0 normal, r84x3.1 inverted status message) at LOW.
- Activate/deactivate the week day
  - p8410[0] = 0 Monday
  - p8410[1] = 1 Tuesday
  - p8410[2] = 1 Wednesday
  - p8410[3] = 0 Thursday
  - p8410[4] = 1 Friday
  - p8410[5] = 1 Saturday
  - p8410[6] = 0 Sunday
- Setting switching times:
  - ON: p8411[0] = 20 (hh), p8411[1] = 0 (MM)
  - OFF: p8412[0] = 10 (hh), p8412[1] = 0 (MM)
- Enable the setting: p8409 = 1.  
The inverter re-enables the DTC output.

Additional information is provided in the parameter list of the List Manual.

### 6.7.13 Essential service mode

In the **Essential Service Mode (ESM)**, the inverter attempts to operate the motor for as long as possible in spite of irregular ambient conditions.

Example: When a fire occurs, evacuation routes must be kept open by extracting the smoke.

In the "essential service mode" the inverter does not switch off the motor when faults develop, but instead responds as follows:

- The inverter ignores faults, which do not directly result in the destruction of the inverter or the motor.
- The inverter attempts to automatically acknowledge faults, which cannot be ignored, using the automatic restart function.
- For faults that cannot be acknowledged, it is possible to switch over the motor to line operation using the bypass function.

---

#### Note

##### Warranty is lost in the essential service mode

If you activate the essential service mode, all of the warranty claims associated with the inverter become null and void. The essential service mode can have the following effects:

- Exceptionally high temperatures inside and outside the inverter
  - Open fire inside and outside the inverter
  - Emissions of light, noise, particles or gases
- 

The inverter logs the essential service mode, and the faults that occur while in essential service mode in a password-protected memory. This data is only accessible for the service and repair organization.

### Special features of essential service mode

#### Priority

When the emergency service mode is selected, the inverter deactivates all functions, which switch off the motor to save energy, e.g. PROFlenergy or the hibernation mode.

#### Starting and ending the essential service mode

The inverter starts the essential service mode with  $p3880 = 1$ , and exits the essential service mode with  $p3880 = 0$ .

#### Automatic restart in the essential service mode

In the essential service mode, the inverter operates with the "Restart after fault with additional start attempts" setting ( $p1210 = 6$ ). We recommend that you set the automatic restart function, also for normal operation, to a value  $p1210 \neq 0$ .

In the essential service mode, the inverter ignores the settings in  $p1206$  (faults without automatic restart).

The inverter carries out the maximum number of restart attempts set in p1211 corresponding to the settings in p1212 and p1213. If these attempts are not successful, then the inverter goes into a fault condition with F07320.

#### **Speed setpoint in the essential service mode**

p3881 defines the speed setpoint in the essential service mode. If you have defined an analog input as setpoint source using p3881, then for wire breakage, the inverter can switch over to setpoint p3882.

#### **Bypass and essential service mode**

- If, when activating the essential service mode, bypass operation is active, inverter operation is selected internally in order to ensure that the setpoint is entered via the source intended for the essential service mode.
- If faults are still present after the number of start attempts parameterized in p1211, then the inverter goes into a fault condition with F07320. In this case, there is an option of switching over to bypass operation and then directly connecting the motor to the line supply.

#### **Application example**

To improve the air circulation in the stairwells, the ventilation control creates a slight underpressure in the building. With this control, a fire would mean that smoke would enter into the stairwell. This would then mean that the stairway would be blocked as escape or evacuation route.

Using the essential service mode function, the ventilation switches over to the control of an overpressure. This prevents the propagation of smoke in the stairwell, thereby keeping the stairs free as an evacuation route.

## Commissioning the extended service mode

### Procedure



1 Proceed as follows to commission the essential service mode:

**1. Interconnect a free digital input as signal source for the essential service mode.**

Example, DI 3: Set p3880 = 722.3.

It is not permissible to interconnect the digital input to select the essential service mode with other functions.

**2. Using p3881, set the setpoint source for the essential service mode**

**Option 1:**

- P3881 = 0: Last recognized setpoint (factory setting) or
- p3881 = 1: Fixed setpoint 15 or
- p3881 = 2: Analog setpoint or
- p3881 = 3: Fieldbus

**Option 2:**

- p3881 = 4: Technology controller
- Using p3884, set the source for the essential service mode setpoint.  
If you cannot connect a setpoint in p3884, then the inverter takes technology setpoint 1 that has been connected (p2253).

**3. Using p3882, set the source for the alternative setpoint.**

- p3882 = 0: Last recognized setpoint (factory setting)
- p3882 = 1: Fixed speed setpoint which is defined in p1015
- p3882 = 2: Maximum speed (value of p1082)

**4. Parameterize the source to select the direction of rotation for the essential service mode.**

**Option 1:** Extended service mode setpoint via p3881 = 0, 1, 2, 3:

Using p3883, invert the direction of rotation for the essential service mode. To do this, interconnect p3883 with a digital input, e.g. with digital input 4 (DI4): Set p3883 = 722.4  
The following applies:

- p3883 = 0 → normal direction of rotation in the essential service mode,
- p3883 = 1 → inverted direction of rotation in the essential service mode,

**Option 2:** Essential service mode via technology controller (p3881 = 4)

If you enter the setpoint for the essential service mode via the technology controller, then the direction of rotation of the essential service mode setpoint is always valid.

**5. Switchover to bypass operation - option**

If the inverter is not in a position to acknowledge active faults using the automatic restart, then it goes into a fault condition with fault F07320, and does not make any other attempts to restart.

You must make the following settings if you still wish to operate the motor in this situation:

- Set p1266 = 3889.10  
This means that you control switching over bypass operation with status bit 10 of the status word for the essential service mode (r3889). This bit goes to 1, if the automatic restart was interrupted.
- Ensure that the direction of rotation does not change when switching over to bypass operation.
- Set p1267.0 = 1. This sets the switchover to bypass, independent of the speed, activated using control signal p1266.
- Make other settings for "Switch over to bypass (Page 291)".

You have commissioned the essential service mode.

**Application example**

An application example for the essential service mode can be found on the Internet:  
<http://support.automation.siemens.com/WW/view/de/63969509>  
(<http://support.automation.siemens.com/WW/view/en/63969509>)

### 6.7.14 Multi-zone control

Multi-zone control is used to control quantities such as pressure or temperature via the technology setpoint deviation. The setpoints and actual values are fed in via the analog inputs as current (0 ... 20 mA) or voltage (0 ... 10 V) or as a percentage via temperature-dependent resistances (LG-Ni1000 / Pt1000 / DIN-Ni1000, 0° C = 0%; 100° C= 100%).

#### Control variants for multi-zone control

There are three control variants for multi-zone control, which are selected via p31021:

- **One setpoint and one, two or three actual values**

The actual value for the control can be calculated as mean value, maximum value or minimum value by the inverter. You can find all of the setting options in the parameter list in parameter p31022.

- Average value: The deviation from the setpoint of the average value of two or three actual values is controlled.
- Minimum value: The deviation from the setpoint of the smallest actual value is controlled.
- Maximum value: The deviation from the setpoint of the highest actual value is controlled.

- **Two setpoint / actual value pairs as maximum value control (cooling)**

The maximum value control compares two setpoint / actual value pairs and controls the actual value which has the largest deviation upwards from its associated setpoint. No control takes place if both actual values lie below their setpoints.

In order to avoid frequent changeover, the inverter only switches over if the deviation of the controlled setpoint / actual value pair is more than two percent lower than the deviation of the uncontrolled value pair.

- **Two setpoint / actual value pairs as minimum value control (heating)**

The maximum value control compares two setpoint / actual value pairs and controls the actual value which has the largest deviation upwards from its associated setpoint. The control pauses if both actual values lie above their setpoints.

The control only switches over if the deviation of the controlled setpoint / actual value pair is more than two percent lower than the deviation of the uncontrolled value pair.

#### Switching from day to night mode

You can modify the setpoints for day and night mode individually. You have the following opportunities to switch from day to night mode:

- Signal via the digital input DI 4
- via p31025 with the aid of free components and the real time clock

**Note**

If you activate the multi-zone control, the inverter switches its analog inputs as sources for the setpoint and current value of the technology controller (refer to table).

Table 6- 41 Parameters to set the multi-zone control:

Parameter	Description	
p2200	<b>Technology controller enable</b>	
p2251	<b>Set technology controller as main setpoint</b>	
p31020	<b>Multi-zone control interconnection</b> (factory setting = 0) A subsequent parameterization is performed by activating or deactivating the multi-zone control.	
	Subsequent connection for p31020 = 1 (activate multi-zone control)	Subsequent connection for p31020 = 0 (deactivate multi-zone control)
	p31023[0] = 755[0] (AI0) p31023[2] = 755[1] (AI1) p31026[0] = 755[2] (AI2) p31026[1] = 755[3] (AI3) p2253 = 31024 (setpoint output technology controller) p2264 = 31027 (actual value output technology controller)	p31023[0] = 0 p31023[2] = 0 p31026[0] = 0 p31026[1] = 0 p2253 = 0 p2264 = 0
p31021	<b>Configuration of multi-zone control</b> <ul style="list-style-type: none"> <li>• 0 = Setpoint 1 / several actual values (factory setting)</li> <li>• 1 = Two zones / maximum value setting</li> <li>• 2 = Two zones / minimum value setting</li> </ul>	
p31022	<b>Processing of actual values for multi-zone control</b> (only for p31021 = 0) Possible values: 0 ... 11 (factory setting = 0)	
p31023[0 ... 3]	<b>Setpoints for multi-zone control</b> Parameters for selecting the source for setpoints in multi-zone control (factory setting = 0)	
r31024	<b>Multi-zone control setpoint output for technology controller</b> CO parameters	
p31025	<b>Switching from day to night mode for multi-zone control</b> Parameters for selection of the source for switching between day and night operation by the multi-zone control (default setting = 0)	
p31026[0 ... 2]	<b>Actual values for multi-zone control</b> Parameters for selecting the source for actual values of the multi-zone control (factory setting = 0)	
r31027	<b>Multi-zone control actual value output for the technology controller</b> CO parameters	

**Note**

If you deactivate the multi-zone control, the inverter resets the switch on its analog inputs to the default setting.

**Example**

In an open plan office, temperature sensors (Lg-Ni1000) are installed in three different places. The inverter receives the measured values and temperature setpoint via its analog inputs. A range from 8 °C ... 30 °C is permissible as setpoint temperature. The average temperature should be 16 °C overnight.

**Settings**

p2200[0] = 1	Technology controller enable
p2251 = 0	Technology closed-loop controller as main setpoint
p2900[0] = 16	Temperature setpoint overnight as a fixed percentage value
p31020 = 1	Activate multi-zone control
p31021 = 0	Multi-zone control with one setpoint and three actual values
p31022 = 7	Three actual values, one setpoint. The actual value of the closed-loop control is the average value of three actual values.
p31023[0] = 755[0]	Temperature setpoint via analog input AI 0
p0756[0] = 0	Select analog input type (voltage input 0 ... 10 V)
p0757[0] = 0 / p0758[0] = 8	Lower value = 8 °C (0 V $\triangleq$ 8 °C)
p0759[0] = 10 / p0760[0] = 30	Upper value = 30 °C (10 V $\triangleq$ 30 °C)
p31023[1] = 2900	p31023[1] interconnect with the value from p2900 for the reduction overnight
p31026[0]= 755.2	Temperature actual value 1 via analog input 2 as a percentage value
p0756[2] = 6	Analog input type (temperature sensor LG-Ni1000)
p0757[2] = 0 / p0758[2] = 0	Lower value of the scaling characteristic
p0759[2] = 100 / p0760[2] = 100	Upper value of the scaling characteristic
p31026[1] = 755[3]	Temperature actual value 2 via analog input AI 3 as a &
p0756[3] = 6	Select analog input type (temperature sensor LG-Ni1000)
p0757[3] = 0 / p0758[3] = 0	Lower value of the scaling characteristic
p0759[3] = 100 / p0760[3] = 100	Upper value of the scaling characteristic
p31026[2] = 755[1]	Temperature actual value 3 via a temperature sensor with current output (0 mA ... 20 mA) via analog input AI 1
p0756[1] = 2	Analog input type (current input 0 ... 20 mA)
p0757[1] = 0 / p0758[1] = 0	Lower value of the scaling characteristic (0 mA $\triangleq$ 0 °C)
p0759[1] = 20 / p0760[1] = 100	Upper value of the scaling characteristic (20 mA $\triangleq$ 100%)
p31025 = 722.4	Switchover from day to night using digital input DI 4

You will find more information about this multi-zone control in the parameter list and in function diagram 7032 of the List Manual.

## 6.7.15 Bypass

The bypass function switches the motor from inverter operation+ to line system operation. The following options are possible:

- Bypass function when activating via a control signal (p1267.0 = 1)
- Bypass function depending on the speed (p1267.1 = 1)

The inverter controls two contactors via its digital outputs. The inverter analyses the feedback signals from the contactors via its digital inputs. If using direct connection logic (high level = ON), both contactors should be NO contacts.




Figure 6-47 Bypass circuit for control using the inverter

### Note

Flying restart must be activated for the bypass function (p1200 = 1 or 4).

### Note

#### Bypass mode in the essential service mode

The special features for bypass mode in the essential service mode are described in Section Essential service mode (Page 284).

### **Changeover operation between line and inverter operation**

When switching over to direct online operation, contactor K1 is opened after the inverter pulses have been inhibited. The system then waits for the de-energization time of the motor and then contactor K2 is closed so that the motor is connected directly to the line.

When the motor is switched to the line supply, an equalizing current flows that must be taken into account when the protective equipment is selected and dimensioned.

When changing over to inverter operation, initially contactor K2 must be opened and after the de-excitation time, contactor K1 is closed. The inverter then captures the rotating motor and the motor is operated on the inverter.

### Bypass function when activating via a control signal (p1267.0 = 1)

The state of the bypass contactors is evaluated when the inverter is switched on. If the automatic restart function is active (p1210 = 4) and an ON command (r0054.0 = 1) as well as the bypass signal (p1266 = 1) are still present at power up, then after power up, the inverter goes into the "ready and bypass" state (r899.0 = 1 and r0046.25 = 1) and the motor continues to run directly connected to the line supply.




Figure 6-48 Bypass control independent of the speed via a control signal (p1267.0 = 1)

**Bypass function is dependent on the speed (p1267.1 = 1)**

With this function, changeover to line operation is realized corresponding to the following diagram, if the setpoint lies above the bypass threshold.

If the setpoint falls below the bypass threshold, the motor is captured by the inverter and operates in inverter operation.




Figure 6-49 Switchover behavior from inverter to line operation dependent on the speed

**General properties of the bypass function**

- The two motor contactors must be designed for switching under load.
- Contactor K2 must be designed for switching an inductive load.
- Contactors K1 and K2 must be mutually interlocked so that they cannot close at the same time.

**Switch off motor in bypass mode**

- In bypass mode the motor no longer responds to the OFF1 command, but rather only to OFF2 and OFF3.
- If you cut off power to the inverter in bypass mode, the bypass contactor opens and the motor coasts down. If you want to operate the motor even when the inverter is switched off, the signal for the bypass contactor must come from the superior controller.

### Temperature monitoring and overload protection in bypass mode

- If the motor is running in bypass mode, while the inverter is in the "ready and bypass" state (r899.0 = 1 and r0046.25 = 1), then the motor temperature monitoring via the temperature sensor is active.
- Install the overload protection for the motor bypass mode.

### Parameters for setting the bypass function

Parameter	Description
p1260	<b>Bypass configuration</b> Activating the bypass function
r1261	<b>Bypass control/status word</b> Control and feedback signals for the bypass function.
p1262	<b>Bypass dead time</b> Changeover time for contactors. This should be longer than the motor's de-magnetizing time!
p1263	<b>Debypass delay time</b> Delay time for switching back to inverter operation.
p1264	<b>Bypass delay time</b> Delay time for switching to bypass mode.
p1265	<b>Bypass speed threshold</b> Speed threshold for switching to bypass mode.
p1266	<b>Bypass control command</b> Signal source for switching to bypass mode.
p1267	<b>Bypass changeover source configuration</b> Switch to bypass mode using speed threshold or control signal.
p1269	<b>Bypass switch feedback</b> Signal source for contactor feedback for bypass mode.
p1274	<b>Bypass switch monitoring time</b> Monitoring time setting for bypass contactors.

For more information, see the parameter descriptions and function diagram 7035 in the List Manual.

## 6.7.16 Cascade control and hibernation mode

The cascade control and hibernation mode are both suitable for controlling different pressures and flow rates.

If both control versions are enabled, additional conditions must be observed when switching on the motor using the cascade control function. You can find details on this topic in Section Cascade control (Page 296), under "Additional conditions when the hibernation mode is enabled".

It is not possible to activate the hibernation mode as long as a motor is directly operated from the line supply using the cascade control function.

### 6.7.16.1 Cascade control

Cascade control is suitable for applications that require simultaneous operation of up to four motors as a function of the load. Here, for example, significantly fluctuating pressures or flow rates are equalized.

Depending on the PID variance, the inverter's cascade control switches up to three other motors on or off via contactors or motor starters.

#### Operating principle

- **Connecting external motors**

If the main drive is run at maximum speed and the deviation on the technology controller input continues to increase, the control also switches the external motors on the line system. At the same time, the main drive is ramped down to the switch-on/switch-off speed (p2378) to keep the total output power as constant as possible. The technology controller is deactivated while ramping down to the switch-on/switch-off speed.

- **Disconnecting external motors**

If the main drive is running at minimum speed and the deviation on the technology controller input continues to decrease, the control disconnects the external motors M1 to M3 from the line system. The main drive is simultaneously ramped-up to the switch-on/switch-off speed to keep the total output power as constant as possible.

To avoid frequent activation/deactivation of the uncontrolled motors, you must specify a time in p2377 which must have elapsed before the inverter can switch a further motor on or off. After the time set in p2377 has elapsed, a further motor will be activated immediately if the PID deviation is greater than the value set in p2376. If, after p2377 has elapsed, the PID deviation is smaller than p2376 but greater than 2373, the timer p2374 is started before the uncontrolled motor is activated.

The motors are deactivated in the same way.




Figure 6-50 Conditions for activating/deactivating an uncontrolled motor

### Controlling the activation and deactivation of motors

Use p2371 to determine the order of activation/deactivation for the individual external motors.

Table 6- 42 Order of activation for external motors depending on setting in p2371

p2371	Significance	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5	Stage 6
0	Cascade control deactivated	---					
1	One motor can be activated	M1					
2	Two motors can be activated	M1	M1+M2				
3	Two motors can be activated	M1	M2	M1+M2			
4	Three motors can be activated	M1	M1+M2	M1+M2+M3			
5	Three motors can be activated	M1	M3	M1+M3	M1+M2+M3		
6	Three motors can be activated	M1	M2	M1+M2	M2+M3	M1+M2+M3	
7	Three motors can be activated	M1	M1+M2	M3	M1+M3	M1+M2+M3	
8	Three motors can be activated	M1	M2	M3	M1+M3	M2+M3	M1+M2+M3

Table 6- 43 Order of deactivation for external motors depending on setting in p2371

p2371	Activated motors	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5	Stage 6
1	M1	M1					
2	M1+M2	M1+M2	M1				
3	M1+M2	M1+M2	M2	M1			
4	M1+M2+M3	M1+M2+M3	M1+M2	M1			
5	M1+M2+M3	M1+M2+M3	M3+M1	M3	M1		
6	M1+M2+M3	M1+M2+M3	M3+M2	M2+M1	M2	M1	
7	M1+M2+M3	M1+M2+M3	M3+M1	M3	M2+M1	M1	
8	M1+M2+M3	M1+M2+M3	M3+M2	M3+M1	M3	M2	M1

If you are using motors of the same power rating, you can use p2372 to define whether the motors are to be activated/deactivated following the setting specified in p2371 (p2372 = 0) or based on the operating hours (p2372 = 1, 2 ,3. Details see parameter list).

**Parameters to set and activate the cascade control:**

p0730 = r2379.0	<b>Signal source for digital output 0</b> Control external motor 1 via DO 0
p0731 = r2379.1	<b>Signal source for digital output 1</b> Control external motor 2 via DO 1
p0732 = r2379.2	<b>Signal source for digital output 2</b> Control external motor 3 via DO 2
p2200 = 1	<b>Technology controller release</b> Activate technology controller
p2251 = 0	<b>Technology controller mode</b> Technology controller as main speed setpoint
p2370	<b>Cascade control - enable</b> signal source for cascade control on/off
p2371	<b>Cascade control - activate the configuration</b> for the cascade control and define the switch-in sequence
p2372	<b>Cascade control - motor selection mode</b> Define automatic motor switch-on
p2373	<b>Cascade control - switch-in threshold</b> Define switch-on threshold
p2374	<b>Cascade control - switch-in delay</b> Define delay time
p2375	<b>Cascade control - deactivation delay</b> Define the delay time for deactivating the cascade control
p2376	<b>Cascade control - overcontrol threshold</b> Define overcontrol threshold
p2377	<b>Cascade control - interlock time</b> Define interlock time
p2378	<b>Cascade control - connect/disconnect speed</b> Defining the speed for the main drive after connecting/disconnecting a motor
r2379	<b>Cascade control - status word</b>

p2380	<b>Cascade control - operating hours</b>
p2381	<b>Cascade control - maximum time for continuous mode</b>
p2382	<b>Cascade control - absolute operating time limit</b>
p2383	<b>Cascade control - switch-off sequence</b> Define switch-off sequence for an OFF command
p2384	<b>Cascade control - motor switch-on delay</b> Define motor switch-on delay
p2385	<b>Cascade control - connect hold time</b> Define speed hold time after connecting an external motor
p2386	<b>Cascade control - motor switch-off delay</b> Define motor switch-off delay
p2387	<b>Cascade control - switch-off speed hold time</b> Define speed hold time after disconnecting an external motor

---

**Note**

**Technology controller as main setpoint**

To use the technology controller as main setpoint for the cascade control, interconnect the main setpoint with the technology controller output (p2251 = 0, p2200 = 1)

---

For more information, see the parameter descriptions and function diagram 7036 in the List Manual.

**Additional conditions when the hibernation mode is enabled**

In order that the cascade control and hibernation mode functions operate without any conflict, you must parameterize the cascade control so that the following conditions are satisfied.

- p2392 < p2373  
The restart value of the hibernation mode (p2392) must be lower than the activation threshold for the cascade control (p2373)
- p2373 < p2376  
The activation threshold for the cascade control (p2373) must be less than the overcontrol threshold for the cascade control (p2376).
- It is not permissible that the main drive is in the hibernation mode.
- The actual speed must be higher than the restart speed for the hibernation mode (p1080 + p2390) \* 1.05.
- The value for the activation delay of the cascade control (p2374) must be longer than the power-up time from the hibernation mode (t<sub>y</sub>).

$$\text{with } t_y = ((p1080 + p2390) * 1.05 * p1120 * p1139) / p1082$$

### 6.7.16.2 Hibernation mode

Pressure and temperature controls involving pumps and fans are typical applications for the hibernation mode.

The hibernation mode saves energy, reduces mechanical wear and noise.

#### Function

If the plant/system conditions permit it, the inverter switches off the motor and switches it on again when there is a demand from the process.

The hibernation mode starts as soon as the motor speed drops below the hibernation mode start speed. The inverter switches off the motor after an adjustable time. If, during this time, the speed setpoint increases above the hibernation mode start speed due to pressure or temperature changes, the inverter exits the hibernation mode.

In the hibernation mode the motor is switched off, but the inverter continues to monitor the speed setpoint or technology controller deviation.

- **For an external setpoint input (without technology controller), the inverter monitors the speed setpoint** and switches on the motor again as soon as the setpoint increases above the restart speed.

In the factory setting, the inverter monitors the positive speed setpoint. The inverter switches on the motor as soon as the setpoint exceeds the restart speed.

If you also want to monitor the negative speed setpoint, you have to monitor the setpoint amount. To do this, set p1110 = 0.

Additional setting options are described in the List Manual, in function diagrams 3030 and 3040 as well as in the associated parameter descriptions.

- **When the setpoint is input from the technology controller, the inverter monitors the technology controller deviation (r2273)** and switches on the motor again if the deviation of the technology controller exceeds the hibernation mode restart value (p2392).

In the factory setting, the inverter monitors the positive deviation of the technology controller. The inverter switches on the motor as soon as the technology controller deviation is higher than the hibernation mode restart value (p2392).

You must monitor the absolute value of the deviation to switch on the motor again for a negative technology controller deviation.

Set p2298 = 2292 and set the minimum threshold in p2292.

**Note**

**Hibernation mode after switching on the inverter**

After switching the inverter on, a waiting period starts in the inverter. The waiting period is at most the following times:

- p1120 (ramp-up time)
- p2391 (hibernation mode delay time)
- 20 s

If the motor does not reach the hibernation mode start speed within this wait time, the inverter activates the hibernation mode and switches off the motor.

Additional setting options are provided in the List Manual in function block diagram 7038 and in the associated parameter descriptions.

If you want to prevent frequent activation and deactivation, before deactivation you still have to set a short speed boost. The boost is deactivated with p2394 = 0.

To avoid tank deposits, particularly where liquids are involved, it is possible to exit the hibernation mode after an adjustable time (p2396) has expired and switch to normal operation.

The settings required for the respective variant can be found in the following tables.

**Activating the hibernation mode with setpoint input via the internal technology controller**

With this operating mode you have to set the technology controller as the setpoint source (p2200) and use the output of the technology controller as the main setpoint (p2251). The boost can be deactivated.




Figure 6-51 Hibernation mode using the technology setpoint as main setpoint with boost

Activating the hibernation mode with external setpoint input

With this operating mode, an external source – e.g. a temperature sensor – inputs the main setpoint.




Figure 6-52 Hibernation mode using an external setpoint with boost




Figure 6-53 Hibernation mode using an external setpoint without boost

## Setting the hibernation mode

Parameter	Description	Via tech. setpoint	Via external setpoint
p1080	<b>Minimum speed</b> 0 (factory setting) ... 19500 rpm. Lower limit of the motor speed is independent of the speed setpoint.	✓	✓
p1110	<b>Block negative direction</b> Parameter to block the negative direction	-	✓
p2200	<b>Technology controller enable</b> 0: Technology controller deactivated (factory setting), 1: Technology controller activated	✓	-
p2251 = 1	<b>Technology controller mode</b> 0: Technology controller as main setpoint (factory setting), 1: Technology controller as supplementary setpoint	✓	-
p2298	<b>Technology controller minimum limiting</b> Parameter for the minimum limiting of the technology controller	✓	-
p2398	<b>Hibernation mode</b> 0: Hibernation mode inhibited (factory setting) 1: Hibernation mode enabled	✓	✓
p2390	<b>Hibernation mode start speed</b> 0 (factory setting) ... 21,000 rpm. As soon as this speed is fallen below, the hibernation mode delay time starts and switches off the motor once it expires. The hibernation mode start speed is calculated as follows: Start speed = p1080 + p2390 p1080 = minimum speed p2390 = hibernation mode start speed	✓	✓
p2391	<b>Hibernation mode delay time</b> 0 ... 3599 s (factory setting 120). The hibernation mode delay time starts as soon as the output frequency of the inverter drops below the hibernation mode start speed p2390. If the output frequency increases above this threshold during the delay time, the hibernation mode delay time is interrupted. Otherwise, the motor is switched off after the delay time has expired (if necessary, after a short boost).	✓	✓
p2392	<b>Hibernation mode restart value (as a %)</b> Is required if the technology controller is used as the main setpoint. As soon as the technology controller deviation (r2273) exceeds the hibernation restart value, the inverter switches to normal operation and the motor starts up with a setpoint of 1.05 * (p1080 + p2390). As soon as this value is reached, the motor continues to operate with the setpoint of the technology controller (r2260).	✓	-

Parameter	Description	Via tech. setpoint	Via external setpoint
p2393	<p><b>Hibernation mode restart speed (rpm)</b>            Required for external setpoint input. The motor starts as soon as the setpoint exceeds the restart speed. The restart speed is calculated as follows:            Restart speed = p1080 + p2390 + p2393            p1080 = minimum speed            p2390 = hibernation mode start speed            p2393 = hibernation mode restart speed</p>	-	✓
p2394	<p><b>Hibernation mode boost duration</b>            0 (factory setting) ... 3599 s. Before the inverter switches over into the hibernation mode, the motor is accelerated for the time set in p2394 according to the acceleration ramp, however, as a maximum to the speed set in p2395.</p>	✓	✓
p2395	<p><b>Hibernation mode boost speed</b>            0 (factory setting) ... 21000 rpm. Before the inverter switches over into the hibernation mode, the motor is accelerated for the time set in p2394 according to the acceleration ramp, however, as a maximum to the speed set in p2395.</p> <p><b>Caution:</b>            The boost may not result in any overpressure or overrun.</p>	✓	✓
p2396	<p><b>Maximum hibernation mode shutdown time</b>            0 (factory setting) to 863,999 s. At the latest when this time expires, the inverter switches to normal operation and accelerates up to the start speed (p1080 + p2390). If the inverter is switched to normal operation in advance, the shutdown time is reset to the value set in this parameter.            With p2396 = 0, automatic changeover to normal operation after a certain time is deactivated.</p>	✓	✓

---

### Note

Activate the motorized potentiometer as ramp-function generator to use the motorized potentiometer of the inverter as setpoint for the hibernation mode.

- Motorized potentiometer: p1030.4 = 1
  - Technology motorized potentiometer: p2230. = 1.
-

## Status of the hibernation mode

Parameter	Description
r2273	<b>Display of the setpoint/actual value deviation of the technology controller</b>
r2397	<b>Actual hibernation mode output speed</b> Actual boost speed before the pulses are inhibited or the actual start speed after restart.
r2399	<b>Hibernation mode status word</b> 00 Hibernation mode enabled (p2398 <> 0) 01 Hibernation mode active 02 Hibernation mode delay time active 03 Hibernation mode boost active 04 Hibernation mode motor switched off 05 Hibernation mode motor switched off, cyclic restart active 06 Energy-saving mode motor restarts 07 Hibernation mode supplies the total setpoint of the ramp-function generator 08 Hibernation mode bypasses the ramp-function generator in the setpoint channel

### 6.7.17 Free function blocks

The free function blocks permit configurable signal processing in the inverter.

The following free function blocks are available:

- AND, OR, XOR, and NOT logic
- RSR (RS flip-flop), DSR (D flip-flop) flip-flops
- Timers MFP (pulse generator), PCL (pulse shortening), PDE (ON delay), PDF (OFF delay), and PST (pulse stretching)
- ADD (adder), SUB (subtractor), MUL (multiplier), DIV (divider), AVA (absolute value generated), NCM (comparator), and PLI (polyline) arithmetic functions
- LIM (limiter), PT1 (smoothing), INT (integrator), DIF (differentiator) controllers
- NSW (analog) BSW (binary) switches
- LVM limit value monitoring

The number of free function blocks in the inverter is limited. You can only use a function block once. The inverter has 3 adders, for instance. If you have already configured three adders, then no other adders are available.

#### 6.7.17.1 Further information

#### Example

You can find an example for using the free function blocks in Chapter Interconnecting signals in the converter (Page 447).

#### Application description for the free function blocks

See also: FAQ (<http://support.automation.siemens.com/WW/view/en/85168215>)

## 6.8 Switchover between different settings

There are applications that require different inverter settings.

**Example:**

You connect different motors to one inverter. Depending on the particular motor, the inverter must operate with the associated motor data and the appropriate ramp-function generator.

### Drive data sets (DDS)

You can set several inverter functions differently and then switch over between the different settings.

The associated parameters are indexed (index 0, 1, 2, or 3). Using control commands select one of the four indexes and therefore one of the four saved settings.

The settings in the inverter with the same index are called the drive data set.




Figure 6-54 Switching over between different settings using drive data sets (DDS)

Using parameter p0180 you can define the number of drive data sets (1 ... 4).

Table 6- 44 Selecting the number of **drive data sets**

Parameter	Description
p0010 = 15	<b>Drive commissioning:</b> Data sets
p0180	<b>Drive data sets (DDS) number</b> (factory setting: 1)
p0010 = 0	<b>Drive commissioning:</b> Ready

Table 6- 45 Parameters for switching the drive data sets:

Parameter	Description
p0820[0...n]	<b>Drive data set selection DDS bit 0</b>
p0821[0...n]	<b>Drive data set selection DDS bit 1</b>
	If you use several command data sets CDS, then you must set this parameter for each CDS. The parameters are assigned to a CDS through their index: CDS0: p0820[0], p0821[0] CDS1: p0820[1], p0821[1] ...
p0826	<b>Motor changeover, motor number</b> Each drive data set is assigned a motor number: p0826[0] = motor number for drive data set 0. ... p0826[3] = motor number for drive data set 3. If you operate the same motor with different drive data sets, then you must enter the same motor number in every index of parameter p0826. In this particular case, you can also switch over between the different drive data sets in operation. If you operate different motors on one inverter, then you must number the motors in parameter p0826. In this case, you may only switch over the drive data sets in the "ready for operation" state with the motor switched-off. The switchover time is approx. 50 ms.
r0051	<b>Displaying the number of the DDS that is currently effective</b>

For an overview of all the parameters that belong to the drive data sets and can be switched, see the List Manual.

Table 6- 46 Parameters for copying the drive data sets

Parameter	Description
p0819[0]	<b>Source drive data set</b>
p0819[1]	<b>Target drive data set</b>
p0819[2] = 1	<b>Start copy operation</b>

For more information, see the List Manual (the parameter list and function diagram 8565).



# Backing up data and series commissioning

## External data backup

After commissioning, your settings are saved in the converter so that they are protected against power failure.

We recommend that you additionally back up the settings on a storage medium outside the converter. Without backup, your settings could be lost if the converter developed a defect (see also Replace Control Unit (Page 332)).

The following storage media are available for your settings:

- Memory card
- PG/PC
- Operator panel

---

### Note

#### Data backup using operator panels with USB connection with the PG/PC is not possible

If the converter is connected to a PG/PC via a USB cable, you can save any data on the memory card using an operator panel.

- Before you save data to the memory card using an operator panel, disconnect the USB connection between the PG/PC and converter.
- 

## Carrying out series commissioning

Series commissioning is the commissioning of several identical drives.

### Precondition

The Control Unit to which the settings are transferred has the same article number and the same or a higher firmware version as the source Control Unit.

### Overview

You must proceed as follows to carry out series commissioning:

1. Commission the first converter.
2. Back up the settings of the first converter to an external storage medium.
3. Transfer the settings of the first converter to another converter via the storage medium.

## 7.1 Backing up and transferring settings using a memory card

### What memory cards do we recommend?

You will find the recommended memory cards in section: Technical data for CU230P-2 (Page 369).

### Using memory cards from other manufacturers

The inverter only supports memory cards up to 2 GB. SDHC cards (SD High Capacity) and SDXC cards (SD Extended Capacity) are not permitted.

If you use other SD or MMC memory cards, then you must format the memory card as follows:

- MMC: Format FAT 16
  - Insert the card into your PC's card reader.
  - Command to format the card:  
format x: /fs:fat (x: Drive code of the memory card on your PC)
- SD: Format FAT 16 or FAT 32
  - Insert the card into your PC's card reader.
  - Command to format the card:  
format x: /fs:fat or format x: /fs:fat32 (x: Drive code of the memory card on your PC.)

### Functional restrictions with memory cards from other manufacturers

The following functions are either not possible – or only with some restrictions – when using memory cards from other manufacturers:

- Licensing functions is only possible using the recommended memory cards.
- Know-how protection is only possible with one of the recommended memory cards.
- Under certain circumstances, memory cards from other manufacturers do not support writing or reading data from/to the inverter.

### 7.1.1 Saving setting on memory card

We recommend that you insert the memory card before switching on the inverter. The inverter always also backs up its settings on an inserted card.

If you wish to back up the inverter settings on a memory card, you have two options:

#### Automatically backing up

##### Preconditions


- The inverter power supply has been switched off.
- No USB cable is inserted in the inverter.

##### Procedure



Proceed as follows to automatically back up your settings:

1. Insert an empty memory card into the inverter.
2. Switch on the operating voltage of the inverter.



- After the power supply has been switched on, the inverter copies its changed settings to the memory card.

##### Note

If the memory card is not empty, then the inverter accepts the data from the memory card. This data then overwrites the data in the inverter.

- Only use empty memory cards when automatically backing up your settings for the first time.


### Manually backing up

#### Preconditions

- The inverter power supply has been switched on.
- No memory card is inserted in the inverter.





#### Procedure with STARTER



Proceed as follows to back up your settings on a memory card:

1. Go online.
2. Press the "Copy RAM to ROM" button .
3. In your drive, select "Drive Navigator".



4. Select the "Commissioning" button.

5. Select the button to transfer the settings to the memory card.
6. Select the settings as shown in the diagram and start the data backup.
7. Wait until STARTER signals that the data backup has been completed.
8. Close the screen forms.


■ You have backed up the settings of the inverter on the memory card.

### Procedure with Startdrive



Proceed as follows to back up the inverter settings to a memory card:

1. Go online.
2. Select "Online & diagnostics".



3. Select "Backing up/reset".
4. Back up the settings to the EEPROM of the inverter.
5. Select the settings as shown in the diagram.
6. Start data transfer
7. Wait until Startdrive has signaled that the data backup has been completed.


■ You have backed up the inverter settings to a memory card.

**Procedure with BOP-2**



Proceed as follows to back up your settings on a memory card:

1. If a USB cable is inserted in the inverter, withdraw it.
2. Go to the "OPTIONS" menu.
3. In the "OPTIONS" menu, select "TO CARD".
4. Set the number of your data backup. You can back up 99 different settings on the memory card.
5. Start data transfer with OK.
6. Wait until the inverter has backed up the settings to the memory card.



- You have backed up the settings of the inverter on the memory card.

**7.1.2 Transferring the setting from the memory card**

**Automatically transferring**

**Precondition**


The inverter power supply has been switched off.

**Procedure**



Proceed as follows to automatically transfer your settings:

1. Insert the memory card into the inverter.
2. Then switch on the inverter power supply.




- If there is valid parameter data on the memory card, then the inverter accepts the data from the memory card.


## Manually transferring

### Preconditions

- The inverter power supply has been switched on.
- No memory card is inserted in the inverter.




### Procedure with STARTER



Proceed as follows to transfer settings from a memory card to the inverter:

1. Go online and in your drive, select the "Drive Navigator".
2. Select the "Commissioning" button.
3. Select the button to transfer the data from the memory card to the inverter.
4. Select the settings as shown in the diagram and start the data backup.



5. Wait until STARTER signals that the data backup has been completed.

7.1 Backing up and transferring settings using a memory card

- 6. Close the screen forms.
- 7. Go offline.
- 8. Switch off the inverter power supply.
- 9. Wait until all LEDs on the inverter are dark.
- 10. Switch on the inverter power supply again.

Your settings become effective after switching on.



■ You have now transferred your settings from a memory card to the inverter.

**Procedure with Startdrive**



Proceed as follows to transfer settings from a memory card to the inverter:

- 1. Go online.
- 2. Select "Online & diagnostics".
- 3. Select "Backing up/reset".



- 4. Select the settings as shown in the diagram.
- 5. Start data transfer
- 6. Wait until Startdrive has signaled that the data transfer has been completed.
- 7. Go offline.
- 8. Switch off the inverter power supply.
- 9. Wait until all LEDs on the inverter are dark.
- 10. Switch on the inverter power supply again.

Your settings become effective after switching on.

■ You have now transferred your settings from a memory card to the inverter.



Proceed as follows to transfer the settings from a memory card to the inverter

1. If a USB cable is inserted in the inverter, withdraw it.
2. Go to the menu level "OPTIONS".
3. In the "OPTIONS" menu, select "FROM CRD".
4. Set the number of your data backup. You can back up 99 different settings on the memory card.
5. Start data transfer with OK.
6. Wait until the inverter has transferred the settings from the memory card.
7. Switch off the inverter power supply.
8. Wait until all LEDs on the inverter are dark.
9. Switch on the inverter power supply again.

■ You have transferred the settings from the memory card to the inverter.

EXTRAS

FROM CRD

PARAM SET 1

ESC / OK

CLONING

FROM CRD -dOnE-

### 7.1.3 Safely remove the memory card

#### NOTICE

##### Data loss from improper handling of the memory card

If you remove the memory card when the converter is switched on without implementing the "safe removal" function you may destroy the file system on the memory card. The data on the memory card are lost. The memory card will only function again after formatting.


- Only remove the memory card using the "safe removal" function.

#### Procedure with STARTER



To safely remove the memory card, proceed as follows:

1. Go online.
2. In the Drive Navigator select the following screen form:




3. Click on the button to safely remove the memory card.

STARTER will tell you whether you can remove the memory card from the inverter.



- You have now safely removed the memory card from the inverter.

**Procedure with Startdrive**



To safely remove the memory card, proceed as follows:

1. In the Drive Navigator select the following screen form:



2. Click on the button to safely remove the memory card.

Startdrive will tell you whether you can remove the memory card from the inverter.

- You have now safely removed the memory card from the inverter.


**Safely removing a memory card using the BOP-2**

**Procedure**



To safely remove the memory card using BOP-2, proceed as follows:

1. Go to parameter p9400. If a memory card is correctly inserted, then p9400=1.
2. Set p9400 = 2.
3. The inverter sets p9400 = 3 or p9400 = 100.
  - p9400 = 3: You may remove the memory card from the inverter.
  - p9400 = 100: It is not permissible that you remove the memory card. Wait for several seconds and then set p9400 = 2 again.
4. Remove the memory card. After removing the memory card, p9400 = 0.



- You have now safely removed the memory card using BOP-2.


## 7.2 Saving settings on a PC

You can transfer the inverter settings to a PG/PC, or vice versa, the data from a PG/PC to the inverter.

### Requirements

- The inverter power supply has been switched on.
- You have installed one of the commissioning tools STARTER or Startdrive to your PG/PC.

Additional information regarding commissioning tools is provided in Section: Tools to commission the converter (Page 46).



### Inverter → PC/PG

#### Procedure with STARTER



To back up the settings with STARTER, proceed as follows:

1. Go online: .
2. Click the "Download project to PG" button: .
3. Save the project: .
4. Wait until STARTER reports that data backup has been completed.
5. Go offline: .

- You have backed up the settings with STARTER.

#### Procedure with Startdrive



To back up the settings with Startdrive, proceed as follows:

1. Go online.
2. Select "Online" > "Upload device to PG/PC."
3. Back up the project with "Project" > "Save."
4. Wait until Startdrive reports that data backup has been completed.
5. Go offline.

- You have backed up the settings with Startdrive.

## PC/PG → inverter

**Procedure**

- ➔ 1 To transfer the settings, proceed as follows:
- 2 1. Go online with STARTER : .
  2. Select the button "Download project to target system": .
  3. To save the data in the inverter, select the "Copy RAM to ROM" button: .
  4. Go offline with STARTER : .
- You have transferred the settings.

**Procedure with Startdrive**

- ➔ 1 To transfer the settings from the PG to the inverter with Startdrive and activate the safety functions, proceed as follows:
- 2 1. Save the project.
  2. Select "Load to device."




Figure 7-1 Activating settings in Startdrive

3. Connect Startdrive online with the drive.
4. Click the "Start safety commissioning" button.
5. Enter the password for the safety functions.  
If the password is the factory default, you are prompted to change the password.  
If you try to set a password that is not permissible, the old password will not be changed.
6. Click the "End safety commissioning" button.
7. Confirm the prompt for saving your settings (copy RAM to ROM).
8. Disconnect the online connection.
9. Switch off the inverter supply voltage.

*7.2 Saving settings on a PC*

10. Wait until all LEDs on the inverter go dark (no voltage condition).

11. Switch on the inverter supply voltage again.

- You have transferred the settings from the PG to the inverter with Startdrive and have activated the safety functions.

## 7.3 Saving settings on an operator panel

You can transfer the inverter settings to the Operator Panel BOP-2 or vice versa, the data from the BOP-2 to the inverter.

### Precondition

The inverter power supply has been switched on.


### Inverter → BOP-2

#### Procedure



To back up the settings on the BOP-2, proceed as follows:

1. Go to the menu level "OPTIONS".
2. In the "OPTIONS" menu, select "TO BOP".
3. Start data transfer with OK.
4. Wait until the inverter has backed up the settings to the BOP-2.



- You have backed up the settings on the BOP-2.

**BOP-2 → inverter**

**Procedure**



To transfer the settings to the inverter, proceed as follows:

1. Go to the menu level "OPTIONS".
2. In the "OPTIONS" menu, select "FROM BOP".
3. Start data transfer with OK.
4. Wait until the inverter has written the settings to the memory card.
 

Your settings become effective after switching on.



- You have transferred the settings to the inverter.

**7.4 Other ways to back up settings**

In addition to the default setting, the inverter has an internal memory for backing up three other settings.

On the memory card, you can back up 99 other settings in addition to the default setting.

You will find additional information on the Internet at: Memory options (<http://support.automation.siemens.com/WW/view/en/43512514>).

Table 7- 1 Operation on the BOP-2

Description	
	The converter writes its setting 0, 10, 11 or 12 to the memory card in accordance with p0802. The file on the memory card is assigned the number according to p0802.
	The converter loads the setting with the number according to p0802 from the memory card and thus overwrites its setting 0, 10, 11 or 12.

## 7.5 Write and know-how protection

The inverter offers the option to protect configured settings from being changed or copied.

Write protection and know-how protection are available for this purpose.

### 7.5.1 Write protection

Write protection prevents inadvertently changing inverter settings. If you are working with a PC tool, such as STARTER, then write protection is only effective online. The offline project is not write-protected.

Write protection is applicable for all user interfaces:

- BOP-2 and IOP operator panels
- STARTER or Startdrive PC tool
- Parameter changes via a fieldbus

The write protection is not password-protected.


### Activate and deactivate write protection

#### Procedure with STARTER



Proceed as follows to activate or deactivate the write protection:

1. Go online.
2. Open the inverter shortcut menu.
3. Activate or deactivate write protection.
4. Press the “Copy RAM to ROM” button to retentively save the settings .



 You have activated or deactivated write protection.

Parameters		
r7760	<b>Write protection/know-how protection status</b>	
	.00	Write protection active
p7761	<b>Write protection</b> (factory setting: 0)	
	0:	Deactivate write protection
	1:	Activate write protection

### Exceptions to write protection

Some functions are excluded from write protection, e.g.:

- Activating/deactivating write protection
- Changing the access level (p0003)
- Saving parameters (p0971)
- Safely removing the memory card (p9400)
- Restoring the factory setting
- Importing settings from an external data backup, e.g. upload from a memory card to the converter.

The individual parameters that are excluded from the write protection, can be found in the List Manual in Chapter "Parameters for write protection and protection of know-how".

---

#### Note

##### Write protection for multimaster fieldbus systems

When using multimaster fieldbus systems (e.g. CAN Bus, BACnet), parameters can be changed in spite of an active write protection. So that write protection is also active when accessing via these fieldbuses, you must additionally set p7762 to 1.

In STARTER, this setting is only possible via the expert list.

---

## 7.5.2 Know-how protection

### Know-how protection

The know-how protection is used to encrypt configuring/engineering know-how, and protect it against being changed or copied.

The settings of the converter are protected by a password.

If the password is lost, only default settings are possible.

The active know-how protection provides the following:

- All setting parameters are invisible.
- Parameters cannot be changed with a commissioning tool, e.g. operator panel or STARTER.
- It is not possible to download the converter settings with the Starter or via a memory card
- It is not possible to use the trace function in the STARTER.
- Deleting the alarm history
- The STARTER dialog screens are disabled. The expert list in the STARTER contains only display parameters.

In the case of active know-how protection, support by technical support personnel is only possible with the consent of the machine manufacturer.

## Copy protection

In conjunction with the copy protection, the converter settings can be coupled only to a single, pre-defined hardware.

Know-how protection with copy protection is only possible using the recommended Siemens card, see also Section: Technical data for CU230P-2 (Page 369)

## List of exceptions

The active know-how protection permits an exception list for parameters to be defined that the customer may access.

If you remove the parameter for the password from the exception list, the know-how protection can only be undone by reverting to the factory settings.

## Actions that are possible during active know-how protection

- Restoring factory settings
- Acknowledging messages
- Displaying messages
- Show message history
- Reading out diagnostic buffer
- Switching to the control panel (complete control panel functionality: Fetch master control, all buttons and setting parameters)
- Upload (only parameters that are accessible even though know-how protection is active)

The individual parameters that are excluded from the know-how protection can be found in the List Manual in Chapter "Parameters for write protection and protection of know-how".

## Commissioning the converter with know-how protection

### Procedure - overview

1. Commission the converter.
2. Create the exception list (Page 330).
3. Activate the know-how protection (Page 328).
4. Save the settings in the converter by copying RAM to ROM with  or via p0971 = 1.
5. Save the project with  on the PG/PC. Also back up any other project-related data (machine type, password, etc.) that may be required for the support of the end customer.

### 7.5.2.1 Settings for know-how protection

#### Activating know-how protection

##### Preconditions

- You are online.  
If you have created a project offline on your computer, you must download it to the inverter and go online.
- You have inserted the recommended Siemens card. See also Section: Technical data for CU230P-2 (Page 369).

##### Procedure




Proceed as follows to activate know-how protection:

1. Select the inverter in the STARTER project and in the shortcut menu select "Know-how protection drive device/activate ..." (see also Write protection (Page 325)).

2. Enter your password. Length of the password: 1 ... 30 characters.

For the password, we recommend that you only use characters from the ASCII character set. If you use any character for the password, then if changes are made to the Windows language settings after activating know-how protection, errors can occur when subsequently checking the password.



3. In this screen form, press the "Copy RAM to ROM" button. This means that you save your settings so that they are protected against power failure.

- You have activated know-how protection.

##### Backing up settings on the memory card

When know-how protection is activated, you can save the settings to the memory card using p0971.

To do this, set p0971 = 1. The data are written to the memory card encrypted. After saving, p0971 is reset to 0.

## Deactivating know-how protection, deleting a password

### Preconditions

- You are online with STARTER.
- You have inserted the recommended Siemens card. See also Section: Technical data for CU230P-2 (Page 369).

### Procedure



1 Proceed as follows to deactivate know-how protection:

1. Select the inverter in the STARTER project, and using the right-hand mouse button, open the dialog window "Know-how protection drive device/deactivate ...".

2. There, select the desired option.

- Temporary status: Know-how protection is active again after switching the power supply off and on.



- Final status: If you select "Copy RAM to ROM", the inverter immediately deletes the password. If you do not select "Copy RAM to ROM", the inverter deletes the password the next time the supply voltage is switched off.

3. Enter the password and exit the screen form with OK.

■ You have deactivated know-how protection.

## Changing the password

Select the inverter in the STARTER project, and open the dialog screen form using the shortcut menu "Know-how protection drive device/change password ...".

### 7.5.2.2 Generating an exception list for know-how protection

Using the exception list, as machine manufacturer you can make individual adjustable parameters accessible to end users although know-how protection is active. You may define the exception list via parameters p7763 and p7764 in the expert list. Specify the number of parameters for the selection list in p7763. Assign the individual indexes to the parameter numbers of the selection list in p7764.

#### Procedure



Proceed as follows to change the number of parameters for the selection list:

1. Save the inverter settings via an upload () on the PC/PG and go offline ()
2. In the project on the PC, set p7763 to the desired value.
3. Save the project.
4. Go online and load the project into the inverter ()
5. Now make the additional settings in p7764.



You have modified the number of parameters for the selection list.

Factory setting for the exception list:

- p7763 = 1 (selection list contains precisely one parameter)
- p7764[0] = 7766 (parameter number for entering the password)

---

#### Note

##### Block access to the inverter as a result of incomplete exception lists

If you remove p7766 from the exception list, you can no longer enter a password and therefore no longer deactivate know-how protection.

In this case to access the inverter again, you have to reset the inverter to the factory settings.

---

## Corrective maintenance




### 8.1 Replacing inverter components

#### 8.1.1 Overview of replacing converter components

##### Permissible replacement of components

In the event of a long-term function fault, you must replace the Power Module or Control Unit. The inverter's Power Module and Control Unit can be replaced independently of each other.

In the following cases you will need to replace the inverter:

Replacing the Power Module		Replacing the Control Unit	
<b>Replacement:</b> <ul style="list-style-type: none"> <li>• Same type</li> <li>• Same power rating</li> </ul>	<b>Replacement:</b> <ul style="list-style-type: none"> <li>• Same type</li> <li>• Same frame size</li> <li>• <i>Higher</i> power rating</li> </ul>	<b>Replacement:</b> <ul style="list-style-type: none"> <li>• Same type</li> <li>• Same firmware version</li> </ul>	<b>Replacement:</b> <ul style="list-style-type: none"> <li>• Same type</li> <li>• <i>higher</i> firmware version (e.g. replace FW V4.2 by FW V4.3)</li> </ul>
			
	Power Module and motor must be adapted to one another (ratio of motor and Power Module rated power > 1/8)	After replacing the Control Unit, you must restore the inverter's settings.	

#### **WARNING**

##### **Risk of injury due to uncontrolled drive motion**

Replacing inverters of different types can result in uncontrolled motion of the drive.

- In all cases that are not permitted according to the table above, recommission the drive after replacing an inverter.

### Special issue relating to communication via PROFINET: Device replacement without removable data storage medium

The inverter supports the PROFINET functionality, replacing the device without data storage medium. After replacing the Control Unit, the inverter is automatically assigned its device name from the IO controller.

Details of the device replacement without removable storage medium can be found in the PROFINET system description (<http://support.automation.siemens.com/WW/view/en/19292127>).

Independent of this, after replacing the inverter, you must transfer the settings of the old inverter to the new inverter.

### Replacing further components

The replacement of further components is described in the hardware installation manual of the associated Power Module.

### 8.1.2 Replace Control Unit



 <b>DANGER</b>
<b>Danger to life as a result of a hazardous voltage at the terminals of the Control Unit</b> 230 V AC may be in place on terminals DO 0 and DO 2 of the control unit's relay output independently of the voltage status of the power module. Touching the contacts may result in an electrical shock.  Comply with the protective measures before you replace the Control Unit
<ol style="list-style-type: none"><li>1. Switch the contacts off-circuit.</li><li>2. Secure the power supply against being unintentionally switched on again.</li><li>3. Check that the cabinet is de-energized.</li></ol>

### Replacing a Control Unit with data backup on a memory card

If you use a memory card with firmware, after the replacement, you obtain a precise copy (firmware and settings) of the replaced Control Unit.

#### Precondition

You have a memory card with the actual settings of the Control unit to be replaced.

#### Procedure



To replace the Control Unit, proceed as follows:

1. Disconnect the line voltage to the Power Module and (if installed) the external 24 V supply or the voltage for the digital outputs of the Control Unit.
2. Remove the signal cables from the Control Unit.

3. Remove the defective Control Unit.
4. Mount the new Control Unit on the Power Module. The new Control Unit must have the same article number and the same or higher firmware version as the Control Unit that was replaced.
5. Remove the memory card from the old Control Unit and insert it in the new Control Unit.
6. Reconnect the signal cables of the Control Unit.
7. Connect up the line voltage again.
8. The inverter loads the settings from the memory card.
9. After loading, check whether the inverter outputs alarm A01028.
  - Alarm A01028:  
The loaded settings are not compatible with the inverter.  
Clear the alarm with p0971 = 1, and recommission the drive.
  - No alarm A01028:  
The inverter accepts the settings that have been loaded.

 You have successfully replaced the Control Unit.

## Replacing a Control Unit with data backup in the PC

### Precondition

You have backed up the actual settings of the Control Unit to be replaced to a PC using STARTER.

### Procedure



To replace the Control Unit, proceed as follows:

1. Disconnect the line voltage to the Power Module and (if installed) the external 24 V supply or the voltage for the digital outputs of the Control Unit.
2. Remove the signal cables of the Control Unit.
3. Remove the defective Control Unit.
4. Mount the new Control Unit on the Power Module.
5. Reconnect the signal cables of the Control Unit.
6. Connect up the line voltage again.
7. Open the right project for the drive in STARTER.
8. Go online and transfer the settings from the PC to the inverter by pressing the  button. The inverter signals faults after the download. Ignore these faults, as they will be automatically acknowledged by the following steps.
9. Save your settings (copy RAM to ROM).

 You have successfully replaced the Control Unit.

## Replacing the Control Unit with data backup in the operator Panel

### Precondition

You have backed up the actual settings of the Control Unit to be replaced to an operator panel.

### Procedure



To replace the Control Unit, proceed as follows:

1. Disconnect the line voltage to the Power Module and (if installed) the external 24 V supply or the voltage for the digital outputs of the Control Unit.
2. Remove the signal cables of the Control Unit.
3. Remove the defective Control Unit.
4. Mount the new Control Unit on the Power Module.
5. Reconnect the signal cables of the Control Unit.
6. Connect up the line voltage again.
7. Plug the Operator Panel into the Control Unit or connect the Operator Panel handheld device with the inverter.
8. Transfer the settings from the Operator Panel to the inverter.
9. Wait until the transfer is complete.
10. After loading, check whether the inverter outputs alarm A01028.
  - Alarm A01028:  
The loaded settings are not compatible with the inverter.  
Clear the alarm with p0971 = 1 and recommission the drive.
  - No alarm A01028: Proceed with the next step.
11. Back up the settings so they are not lost when the power fails:
  - BOP-2 in the menu "EXTRAS" - "RAM-ROM".
  - IOP in the menu "SAVE RAM TO ROM".



You have replaced the Control Unit and transferred the safety function settings from the operator panel to the new Control Unit.

### 8.1.3 Replacing the Control Unit without data backup

If you do not backup the settings, then you must recommission the drive after replacing the Control Unit.

#### Procedure



1  
2

To replace the Control Unit without backed-up settings, proceed as follows:

1. Disconnect the line voltage to the Power Module and (if installed) the external 24 V supply or the voltage for the digital outputs of the Control Unit.
2. Remove the signal cables of the Control Unit.
3. Remove the defective Control Unit.
4. Mount the new Control Unit on the Power Module.
5. Reconnect the signal cables of the Control Unit.
6. Connect up the line voltage again.
7. Recommission the drive.



The Control Unit replacement has been completed after the drive has been successfully commissioned.

## 8.1.4 Replacing the Control Unit with know-how protection active

### Replacing devices with know-how protection without copy protection

In the case of know-how protection without copy protection, the inverter settings can be transferred to another inverter using a memory card.

See also:

- Saving setting on memory card (Page 311)
- Transferring the setting from the memory card (Page 314)

### Replacing devices with know-how protection with copy protection

The know-how protection with copy protection prevents the inverter settings from being copied and passed on. This function is predominantly used by machine manufacturers.

If know-how protection with copy protection is active, the inverter cannot be replaced as described in "Replace Control Unit (Page 332)."

However, to allow the inverter to be replaced, you must use a Siemens memory card, and the machine manufacturer must have an identical machine that he uses as sample.

There are two options for replacing the device:

#### **Option 1: The machine manufacturer only knows the serial number of the new inverter**

- The end customer provides the machine manufacturer with the following information:
  - For which machine must the inverter be replaced?
  - What is the serial number (r7758) of the new inverter?
- The machine manufacturer goes online on the sample machine.
  - deactivates the know-how protection, see Settings for know-how protection (Page 328)
  - enters the serial number of the new inverter in p7759
  - enters the serial number of the inserted memory card as reference serial number in p7769
  - activates the know-how protection with copy protection ("Copy RAM to ROM" must be activated!), see Settings for know-how protection (Page 328)
  - writes the configuration with p0971 = 1 to the memory card
  - sends the memory card to the end customer
- The end customer inserts the memory card and switches on the inverter.

When powering up, the inverter checks the serial numbers of the card and when there is a match, the inverter goes into the "ready to start" state.

If the numbers do not match, then the inverter signals fault F13100 (no valid memory card).

**Option 2: The machine manufacturer knows the serial number of the new inverter and the serial number of the memory card**

- The end customer provides the machine manufacturer with the following information:
  - For which machine must the inverter be replaced?
  - What is the serial number (r7758) of the new inverter?
  - What is the serial number of the memory card?
- The machine manufacturer goes online on the sample machine.
  - deactivates the know-how protection, see Settings for know-how protection (Page 328)
  - enters the serial number of the new inverter in p7759
  - enters the serial number of the customer's memory card as reference serial number in p7769
  - activates the know-how protection with copy protection ("Copy RAM to ROM" must be activated!), see Settings for know-how protection (Page 328)
  - writes the configuration with p0971 = 1 to the memory card
  - copies the encrypted project from the card to his PC
  - for example, sends it by e-mail to the end customer
- The end customer copies the project to the Siemens memory card that belongs to the machine, inserts it in the inverter and switches on the inverter.

When powering up, the inverter checks the serial numbers of the card and when there is a match, the inverter goes into the "ready to start" state.

If the numbers do not match, then the inverter signals fault F13100 (no valid memory card).

### 8.1.5 Replacing a Power Module

#### Procedure



Proceed as follows to exchange a Power Module:

1. Switch off the supply voltage to the Power Module.  
You do not have to switch off an external 24 V power supply for the Control Unit if one is being used.



<b>! DANGER</b>
<b>Danger to life from hazardous voltage at the inverter terminals</b>
After the power supply has been switched off, it takes up to 5 min. until the capacitors in the inverter have discharged so that the remaining voltage is non-hazardous.
<ul style="list-style-type: none"><li>• Check the voltage at the inverter connections, before removing the connection cables.</li></ul>

2. Remove the connecting cables of the Power Module.
3. Remove the Control Unit from the Power Module.
4. Replace the old Power Module with the new Power Module.
5. Mount the Control Unit onto the new Power Module.
6. Connect up the new Power Module using the connecting cables.

<b>NOTICE</b>
<b>Material damage when interchanging the motor connecting cables</b>
The direction in which the motor rotates switches if you exchange the two phases of the motor line.
<ul style="list-style-type: none"><li>• Connect the three phases of the motor lines in the right order.</li><li>• After exchanging the power module check the direction in which the motor rotates.</li></ul>

7. Switch on the line supply and, if being used, the 24 V supply of the Control Unit.



You have successfully replaced the Power Module.

## 8.2 Firmware upgrade and downgrade




Figure 8-1 Overview of the firmware upgrade and firmware downgrade

You will find more information in the Internet at: Download  
<https://support.industry.siemens.com/cs/ww/en/view/67364620>

### 8.2.1 Upgrading the firmware

When upgrading the firmware, you replace the inverter firmware by a later version. Only update the firmware to a later version if you require the expanded functional scope of the newer version.

#### Precondition

- The firmware version of your inverter is at least V4.5.
- Inverter and memory card have different firmware versions.

#### Procedure




Proceed as follows to upgrade the inverter firmware to a later version:

1. Switch off the inverter power supply.
2. Wait until all LEDs on the inverter are dark.

3. Insert the card with the matching firmware into the inverter slot until it latches into place.

4. Switch on the inverter power supply again.
5. The inverter transfers the firmware from the memory card into its memory.

The transfer takes approximately 5 ... 10 minutes. While data is being transferred, the LED RDY on the inverter stays red. The LED BF flashes orange with a variable frequency.




6. At the end of the transfer, the LED RDY and BF slowly flash red (0.5 Hz).


#### Power supply failure during transfer

The inverter firmware will be incomplete if the power supply fails during the transfer.


- Start again with step 1 of the instructions.



7. Switch off the inverter power supply.  
8. Wait until all LEDs on the inverter are dark.
- Decide whether you will withdraw the memory card from the inverter:
- You leave the memory card in the inverter:
    - ⇒ If the memory card still does not have a data backup of the inverter settings, in step 9 the inverter writes its settings to the memory card.
    - ⇒ If the memory card already includes a data backup, the inverter imports the settings from the memory card in step 9.
  - You remove the memory card: ⇒ The inverter retains its settings.



9. Switch on the inverter power supply again.  
10. If the firmware upgrade was successful, after several seconds the inverter LED RDY turns green.
- If the memory card is still inserted, depending on the previous content of the memory card, one of the two following cases has occurred:
- The memory card contains a data backup: ⇒ The inverter has taken the settings from the memory card.
  - There was no data back up on the memory card: ⇒ The inverter has written its settings to the memory card.



You have upgraded the inverter firmware.

### 8.2.2 Firmware downgrade

When downgrading the firmware, you replace the inverter firmware by an older version. Only downgrade the firmware to an older version if, after replacing an inverter, you require the same firmware in all of your inverters.

#### Precondition

- The firmware version of your inverter is at least V4.6.
- Inverter and memory card have different firmware versions.
- You have backed up your settings on the memory card, in an operator panel or in a PC.

#### Procedure



Proceed as follows to downgrade the inverter firmware to an older version:


1. Switch off the inverter power supply.
2. Wait until all LEDs on the inverter are dark.

3. Insert the card with the matching firmware into the inverter slot until it latches into place.

4. Switch on the inverter power supply again.
5. The inverter transfers the firmware from the memory card into its memory.

The transfer takes approximately 5 ... 10 minutes.

While data is being transferred, the LED RDY on the inverter stays red. The LED BF flashes orange with a variable frequency.




6. At the end of the transfer, the LED RDY and BF slowly flash red (0.5 Hz).

**Power supply failure during transfer**

The inverter firmware will be incomplete if the power supply fails during the transfer.


- Start again with Step 1 of these instructions.



7. Switch off the inverter power supply.  
8. Wait until all LEDs on the inverter are dark.

Decide whether you will withdraw the memory card from the inverter:


- The memory card contains a data backup: ⇒ The inverter has taken the settings from the memory card.
- There was no data backup on the memory card: ⇒ The inverter has the factory settings.



9. Switch on the inverter power supply again.  
10. If the firmware downgrade was successful, after several seconds the inverter LED RDY turns green.

If the memory card is still inserted, depending on the previous content of the memory card, one of the two following cases has occurred:

- The memory card contains a data backup: ⇒ The inverter has taken the settings from the memory card.
- There was no data backup on the memory card: ⇒ The inverter has the factory settings.



11. If the memory card did not contain a data backup of the inverter settings, then you must transfer your settings to the inverter from another data backup.

See also Section: Backing up data and series commissioning (Page 309).

■ You have replaced the inverter's firmware by an older version.

### 8.2.3 Correcting an unsuccessful firmware upgrade or downgrade

How does the inverter signal an unsuccessful upgrade or downgrade?



The inverter signals an unsuccessful firmware upgrade or downgrade by a quickly flashing LED RDY and the lit LED BF.

#### Correcting an unsuccessful upgrade or downgrade

You can check the following to correct an unsuccessful firmware upgrade or downgrade:

- Does the firmware version of your inverter fulfill the preconditions?
  - For an upgrade, as a minimum V4.5.
  - For a downgrade, as a minimum V4.6.
- Have you correctly inserted the card?
- Does the card contain the correct firmware?
- Repeat the appropriate procedure.

## 8.3 If the converter no longer responds

### If the inverter no longer responds

For example, when loading an incorrect file from the memory card, the inverter can go into a state where it can no longer respond to commands from the operator panel or from a higher-level control system. In this case, you must reset the inverter to its factory setting and recommission it. This inverter state is manifested in two different ways:

#### Case 1

- The motor is switched off.
- You cannot communicate with the inverter, either via the operator panel or other interfaces.
- The LEDs flicker and after 3 minutes the inverter has still not powered up.

#### Procedure



Proceed as follows to restore the inverter factory settings:

1. Remove the memory card if one is inserted in the inverter.
2. Switch off the inverter power supply.
3. Wait until all LEDs on the inverter go dark. Then switch on the inverter power supply again.
4. Repeat steps 2 and 3 as often as required until the inverter outputs fault F01018:
5. Set p0971 = 1.
6. Switch off the inverter power supply.
7. Wait until all LEDs on the inverter go dark. Then switch on the inverter power supply again.

The inverter now powers up with the factory settings.

8. Recommission the inverter.

■ You have restored the inverter factory settings.

**Case 2**

- The motor is switched off.
- You cannot communicate with the inverter, either via the operator panel or other interfaces.
- The LEDs flash and are dark - this process is continually repeated.

**Procedure**



Proceed as follows to restore the inverter factory settings:

1. Remove the memory card if one is inserted in the inverter.
2. Switch off the inverter power supply.
3. Wait until all LEDs on the inverter go dark. Then switch on the inverter power supply again.
4. Wait until the LEDs flash orange.
5. Repeat steps 2 and 3 as often as required until the inverter outputs fault F01018.
6. Now set  $p0971 = 1$ .
7. Switch off the inverter power supply.
8. Wait until all LEDs on the inverter go dark. Then switch on the inverter power supply again.

The inverter now powers up with the factory settings.

9. Recommission the inverter.

You have restored the inverter factory settings.

**The motor cannot be switched-on**

If the motor cannot be switched-on, then check the following:

- Is a fault present?  
If there is, then remove the fault cause and acknowledge the fault.
- Has the inverter been completely commissioned  $p0010 = 0$ ?  
If not, the inverter is e.g. still in a commissioning state.
- Is the inverter reporting the "ready to start" status ( $r0052.0 = 1$ )?
- Is the inverter missing some enable signals ( $r0046$ )?
- How does the inverter receive its setpoint and commands?  
Digital inputs, analog inputs or fieldbus?

# Alarms, faults and system messages

The converter has the following diagnostic types:

- LED

The LED at the front of the converter immediately informs you about the most important converter states.

- Alarms and faults

The converter signals alarms and faults via

- the fieldbus
- the terminal strip with the appropriate setting
- a connected operator panel, or
- STARTER

Alarms and faults have a unique number.

- Identification & maintenance data (I&M)

If requested, the converter sends data to the higher-level control via PROFIBUS or PROFINET:

- Converter-specific data
- Plant-specific data

## 9.1 Operating states indicated on LEDs

The LED RDY (Ready) is temporarily orange after the power supply voltage is switched-on. As soon as the color of the LED RDY changes to either red or green, the LEDs signal the inverter state.

### Signal states of the LED

In addition to the signal states "on" and "off" there are two different flashing frequencies:




Table 9- 1 Inverter diagnostics

LED		Explanation
RDY	BF	
GREEN - on	Not relevant	There is presently no fault
GREEN - slow		Commissioning or reset to factory settings
RED - on	YELLOW - variable frequency	Firmware update in progress
RED - slow	RED - slow	Inverter waits until the power supply is switched off and switched on again after a firmware update
RED - fast	Not relevant	There is presently a fault
RED - fast	RED - fast	Incorrect memory card or unsuccessful firmware update

Table 9- 2 Communication diagnostics via PROFINET

LNK LED	Explanation
GREEN - on	The communication via PROFINET is in order.
GREEN - slow	Device naming is active.
Off	No communication via PROFINET.

Table 9- 3 Communication diagnostics via RS485

LED		Explanation
BF	RDY	
off	Not relevant	Data exchange between the inverter and control system is active
RED - slow	RED - slow	Inverter waits until the power supply is switched off and switched on again after a firmware update
	All other states	The bus is active, however the inverter is not receiving any process data
RED - fast	RED - fast	Incorrect parameterization, incorrect memory card or firmware update unsuccessful
	All other states	No bus connection available
YELLOW - variable frequency	RED - on	Firmware update in progress

**Communication via Modbus or USS:**

If the fieldbus monitoring is deactivated with p2040 = 0, the BF-LED remains dark, independent of the communication state.

Table 9- 4 Communication diagnostics via PROFIBUS DP

LED		Explanation
BF	RDY	
GREEN - on	Not relevant	Data exchange between the inverter and control system is active
off		PROFIBUS interface is not being used.
RED - slow	RED - slow	Inverter waits until the power supply is switched off and switched on again after a firmware update
	All other states	Bus fault - configuration fault
RED - fast	RED - fast	Incorrect memory card or unsuccessful firmware update
	All other states	Bus error - no data exchange - inverter searches for baud rate - no connection
YELLOW - variable frequency	RED - on	Firmware update in progress

**LED BF display for CANopen**

In addition to the signal states "on" and "off" there are three different flashing frequencies:




Table 9- 5 Communication diagnostics via CANopen

LED		Explanation
BF	RDY	
GREEN - on	Not relevant	Data is being exchanged between the inverter and control ("Operational")
GREEN - fast		Bus state "Pre-Operational"
GREEN - single flash		Bus state "Stopped"
RED - on		No bus
RED - single flash		Alarm - limit reached
RED - double flash		Error event in control (Error Control Event)
RED - slow	RED - slow	Inverter waits until the power supply is switched off and switched on again after a firmware update
RED - fast	RED - fast	Incorrect memory card or unsuccessful firmware update
YELLOW - variable frequency	RED - on	Firmware update in progress

## 9.2 System runtime

By evaluating the system runtime of the inverter, you can decide when you should replace components subject to wear in time before they fail - such as fans, motors and gear units.

### Principle of operation

The system runtime is started as soon as the Control Unit power supply is switched-on. The system runtime stops when the Control Unit is switched off.

The system runtime comprises r2114[0] (milliseconds) and r2114[1] (days):

System runtime = r2114[1] × days + r2114[0] × milliseconds

If r2114[0] has reached a value of 86,400,000 ms (24 hours), r2114[0] is set to the value 0 and the value of r2114[1] is increased by 1.

Parameter	Description
r2114[0]	System runtime (ms)
r2114[1]	System runtime (days)

You cannot reset the system runtime.

## 9.3 Alarms

Alarms have the following properties:

- They do not have a direct effect in the converter and disappear once the cause has been removed
- They do not need have to be acknowledged
- They are signaled as follows
  - Status display via bit 7 in status word 1 (r0052)
  - At the Operator Panel with a Axxxxx
  - Via STARTER, if you click on TAB ■ at the bottom left of the STARTER screen

In order to pinpoint the cause of an alarm, there is a unique alarm code and also a value for each alarm.

### Alarm buffer

For each incoming alarm, the converter saves the alarm, alarm value and the time that the alarm was received.

	Alarm code	Alarm value		Alarm time received		Alarm time removed	
1. Alarm	r2122[0]	r2124[0]	r2134[0]	r2145[0]	r2123[0]	r2146[0]	r2125[0]
		I32	Float	Days	ms	Days	ms

Figure 9-1 Saving the first alarm in the alarm buffer

r2124 and r2134 contain the alarm value - important for diagnostics - as "fixed point" or "floating point" number.

The alarm times are displayed in r2145 and r2146 (in complete days) as well as in r2123 and r2125 (in milliseconds referred to the day of the alarm).

The converter uses an internal time calculation to save the alarm times. More information on the internal time calculation can be found in Chapter Real time clock (RTC) (Page 281).

As soon as the alarm has been removed, the converter writes the associated instant in time into parameters r2125 and r2146. The alarm remains in the alarm buffer even if the alarm has been removed.

If an additional alarm is received, then this is also saved. The first alarm is still saved. The alarms that have occurred are counted in p2111.

	Alarm code	Alarm value		Alarm time received		Alarm time, resolved	
1st alarm	r2122[0]	r2124[0]	r2134[0]	r2145[0]	r2123[0]	r2146[0]	r2125[0]
2nd alarm	[1]	[1]	[1]	[1]	[1]	[1]	[1]

Figure 9-2 Saving the second alarm in the alarm buffer

The alarm buffer can contain up to eight alarms. If an additional alarm is received after the eighth alarm - and none of the last eight alarms have been removed - then the next to last alarm is overwritten.

	Alarm code	Alarm value		Alarm time received		Alarm time, resolved	
1st alarm	r2122[0]	r2124[0]	r2134[0]	r2145[0]	r2123[0]	r2146[0]	r2125[0]
2nd alarm	[1]	[1]	[1]	[1]	[1]	[1]	[1]
3rd alarm	[2]	[2]	[2]	[2]	[2]	[2]	[2]
4th alarm	[3]	[3]	[3]	[3]	[3]	[3]	[3]
5th alarm	[4]	[4]	[4]	[4]	[4]	[4]	[4]
6th alarm	[5]	[5]	[5]	[5]	[5]	[5]	[5]
7th alarm	[6]	[6]	[6]	[6]	[6]	[6]	[6]
Last alarm	[7]	[7]	[7]	[7]	[7]	[7]	[7]

Figure 9-3 Complete alarm buffer

### Emptying the alarm buffer: Alarm history

The alarm history traces up to 56 alarms.

The alarm history only takes alarms that have been removed from the alarm buffer. If the alarm buffer is completely filled - and an additional alarm occurs - then the converter shifts all alarms that have been removed from the alarm buffer into the alarm history. In the alarm history, alarms are also sorted according to the "alarm time received", however, when compared to the alarm buffer, in the inverse sequence:

- The youngest alarm is in index 8
- The second youngest alarm is in index 9
- etc.




Figure 9-4 Shifting alarms that have been removed into the alarm history

9.3 Alarms

Any alarms that have not been removed remain in the alarm buffer. The converter sorts the alarms and closes gaps between the alarms.

If the alarm history is filled up to index 63, each time a new alarm is accepted in the alarm history, the oldest alarm is deleted.

Parameters of the alarm buffer and the alarm history

Parameter	Description
r2122	<b>Alarm code</b> Displays the numbers of alarms that have occurred
r2123	<b>Alarm time received in milliseconds</b> Displays the time in milliseconds when the alarm occurred
r2124	<b>Alarm value</b> Displays additional information about the alarm
r2125	<b>Alarm time removed in milliseconds</b> Displays the time in milliseconds when the alarm was removed
p2111	<b>Alarm counter</b> Number of alarms that have occurred after the last reset When setting p2111 = 0, all of the alarms that have been removed from the alarm buffer [0...7] are transferred into the alarm history [8...63]
r2145	<b>Alarm time received in days</b> Displays the time in days when the alarm occurred
r2132	<b>Actual alarm code</b> Displays the code of the alarm that last occurred
r2134	<b>Alarm value for float values</b> Displays additional information about the alarm that occurred for float values
r2146	<b>Alarm time removed in days</b> Displays the time in days when the alarm was removed

Extended settings for alarms

Parameter	Description
You can change up to 20 different alarms into a fault or suppress alarms:	
p2118	<b>Setting the message number for the message type</b> Selection of the alarms for which the message type should be changed
p2119	<b>Setting the message type</b> Setting the message type for the selected alarm 1: Fault 2: Alarm 3: No message

You will find details in function diagram 8075 and in the parameter description of the List Manual.

## 9.4 Faults

A fault indicates a severe fault during inverter operation.

The inverter signals a fault as follows:

- At the operator panel with Fxxxx
- At the inverter using the red LED RDY
- In bit 3 of status word 1 (r0052)
- Via STARTER

To delete a message, you must resolve the cause of the fault and acknowledge the fault.

Every fault has a unique fault code and also a fault value. You need this information to determine the cause of the fault.

### Fault buffer of actual values

The inverter saves the time, fault code and fault value for every fault it receives.

	Fault code		Fault value		Fault time received		Fault time removed	
1st fault	r0945[0]	r0949[0]	r2133[0]	r2130[0]	r0948[0]	r2136[0]	r2109[0]	
		l32	Float	Days	ms	Days	ms	

Figure 9-5 Saving the first fault in the fault buffer

r0949 and r2133 contain the fault value - important for diagnostics - as "fixed point" or "floating point" number.

The "fault time received" is in parameter r2130 (in complete days) as well as in parameter r0948 (in milliseconds referred to the day of the fault). The "fault time removed" is written to parameters r2109 and r2136 when the fault has been acknowledged.

The inverter uses its internal time calculation to save the fault times. More information on the internal time calculation can be found in Chapter Real time clock (RTC) (Page 281).

If an additional fault occurs before the first fault has been acknowledged, then this is also saved. The first alarm remains saved. The fault cases that have occurred are counted in p0952. A fault case can contain one or several faults.

	Fault code		Fault value		Fault time received		Fault time removed	
1st fault	r0945[0]	r0949[0]	r2133[0]	r2130[0]	r0948[0]	r2136[0]	r2109[0]	
2nd fault	[1]	[1]	[1]	[1]	[1]	[1]	[1]	[1]

Figure 9-6 Saving the second fault in the fault buffer

9.4 Faults

The fault buffer can accept up to eight actual faults. The next to last fault is overwritten if an additional fault occurs after the eighth fault.

	Fault code	Fault value		Fault time received		Fault time removed	
1st fault	r0945[0]	r0949[0]	r2133[0]	r2130[0]	r0948[0]	r2136[0]	r2109[0]
2nd fault	[1]	[1]	[1]	[1]	[1]	[1]	[1]
3rd fault	[2]	[2]	[2]	[2]	[2]	[2]	[2]
4th fault	[3]	[3]	[3]	[3]	[3]	[3]	[3]
5th fault	[4]	[4]	[4]	[4]	[4]	[4]	[4]
6th fault	[5]	[5]	[5]	[5]	[5]	[5]	[5]
7th fault	[6]	[6]	[6]	[6]	[6]	[6]	[6]
Last fault	[7]	[7]	[7]	[7]	[7]	[7]	[7]



Figure 9-7 Complete fault buffer

**Acknowledgement**

You have multiple options to acknowledge a fault, e.g.:

- PROFIdrive control word 1, bit 7 (r2090.7)
- Acknowledge via the operator panel
- Switch-off the inverter power supply and switch-on again.

Faults detected during the inverter-internal monitoring of hardware and firmware can be acknowledged only by switching the supply voltage off and on again. The list of faults in the List Manual contains a note on this limited acknowledgment possibility.

**Emptying the fault buffer: Fault history**

The fault history can contain up to 56 faults.

The acknowledgment has no effect as long as none of the causes for the faults in the buffer have been removed. If at least one of the faults in the fault buffer has been removed (the cause of the fault has been removed) and you acknowledge the faults, then the following happens:

1. The inverter accepts all faults from the fault buffer in the first eight memory locations of the fault history (indexes 8 ... 15).
2. The inverter deletes the faults that have been removed from the fault buffer.
3. The inverter writes the time of acknowledgment of the faults that have been removed into parameters r2136 and r2109 (fault time removed).




Figure 9-8 Fault history after acknowledging the faults

After acknowledgment, the faults that have not been removed are located in the fault buffer as well as in the fault history. For these faults, the "fault time coming" remains unchanged and the "fault time removed" remains empty.

If less than eight faults were shifted or copied into the fault history, the memory locations with the higher indexes remain empty.

The inverter shifts the values previously saved in the fault history by eight indexes. Faults, which were saved in indexes 56 ... 63 before the acknowledgment, are deleted.

### Deleting the fault history

If you wish to delete all faults from the fault history, set parameter p0952 to zero.

## Parameters of the fault buffer and the fault history

Parameter	Description
r0945	<b>Fault code</b> Displays the numbers of faults that have occurred
r0948	<b>Fault time received in milliseconds</b> Displays the time in milliseconds when the fault occurred
r0949	<b>Fault value</b> Displays additional information about the fault
p0952	<b>Fault cases, counter</b> Number of fault cases that have occurred since the last acknowledgment. The fault buffer is deleted with p0952 = 0.
r2109	<b>Fault time removed in milliseconds</b> Displays the time in milliseconds when the fault occurred
r2130	<b>Fault time received in days</b> Displays the time in days when the fault occurred
r2131	<b>Actual fault code</b> Displays the code of the oldest fault that is still active
r2133	<b>Fault value for float values</b> Displays additional information about the fault that occurred for float values
r2136	<b>Fault time removed in days</b> Displays the time in days when the fault was removed

## Extended settings for faults

Parameter	Description
You can modify the motor fault response for up to 20 different fault codes:	
p2100	<b>Setting the fault number for fault response</b> Selecting the faults for which the fault response should be changed
p2101	<b>Setting, fault response</b> Setting the fault response for the selected fault
You can modify the acknowledgement type for up to 20 different fault codes:	
p2126	<b>Setting the fault number for the acknowledgment mode</b> Selection of the faults for which the acknowledgment type should be changed
p2127	<b>Setting, acknowledgment mode</b> Setting the acknowledgment type for the selected fault 1: Can only be acknowledged using POWER ON 2: IMMEDIATE acknowledgment after removing the fault cause
You can change up to 20 different faults into an alarm, or suppress faults:	
p2118	<b>Setting the message number for the message type</b> Selection of the message for which the message type should be changed
p2119	<b>Setting the message type</b> Setting the message type for the selected fault 1: Fault 2: Alarm 3: No message

You will find details in function diagram 8075 and in the parameter description of the List Manual.

## 9.5 List of alarms and faults

Axxxxx Alarm

Fyyyyy: Fault

Table 9- 6 Faults, which can only be acknowledged by switching the inverter off and on again

Number	Cause	Remedy
F01000	Software fault in CU	Replace CU.
F01001	Floating Point Exception	Switch CU off and on again.
F01015	Software fault in CU	Upgrade firmware or contact technical support.
F01018	Power-up aborted more than once	After this fault is output, the inverter powers up with the factory settings. Remedy: Back up factory setting with p0971=1. Switch CU off and on again. Recommission the inverter.
F01040	Parameters must be saved	Save parameters (p0971). Switch CU off and on again.
F01044	Loading of memory data card defective	Replace memory card or CU.
F01105	CU: Insufficient memory	Reduce number of data records.
F01205	CU: Time slice overflow	Contact technical support.
F01250	CU hardware fault	Replace CU.
F01512	An attempt has been made to establish an conversion factor for scaling which is not present	Create scaling or check transfer value.
F01662	CU hardware fault	Switch CU off and on again, upgrade firmware, or contact technical support.
F30022	Power Module: Monitoring $U_{CE}$	Check or replace the Power Module.
F30052	Incorrect Power Module data	Replace Power Module or upgrade CU firmware.
F30053	Error in FPGA data	Replace the Power Module.
F30662	CU hardware fault	Switch CU off and on again, upgrade firmware, or contact technical support.
F30664	CU power up aborted	Switch CU off and on again, upgrade firmware, or contact technical support.
F30850	Software fault in Power Module	Replace Power Module or contact technical support.

Table 9- 7 The most important alarms and faults

Number	Cause	Remedy
F01018	Power-up aborted more than once	<ol style="list-style-type: none"> <li>1. Switch the module off and on again.</li> <li>2. After this fault has been output, the module is booted with the factory settings.</li> <li>3. Recommission the inverter.</li> </ol>
A01028	Configuration error	<p>Explanation: Parameterization on the memory card has been created with a different type of module (Article number, MLFB).</p> <p>Check the module parameters and recommission if necessary.</p>
F01033	Switching over units: Reference parameter value invalid	Set the value of the reference parameter not equal to 0.0 (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).
F01034	Switching over units: Calculation of the parameter values after reference value change unsuccessful	Select the value of the reference parameter so that the parameters involved can be calculated in the per unit notation (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).
A01053	System overload measured	<p>The maximum computing power of the control unit was exceeded. The following measures reduce the load on the control unit:</p> <ul style="list-style-type: none"> <li>• Use only one data record (CDS and DDS)</li> <li>• Only use the safety features of the basic functions</li> <li>• Deactivate the technology controller</li> <li>• Use the simple ramp-function generator rather than the extended ramp-function generator</li> <li>• Do not use any free function components</li> <li>• Reduce the sampling time of the free function blocks</li> </ul>
F01054	System limit exceeded	
F01122	Frequency at the probe input too high	Reduce the frequency of the pulses at the probe input.
A01590	Motor maintenance interval lapsed	Carry out maintenance and reset the maintenance interval (p0651).
A01900	PROFIBUS: Configuration telegram faulty	<p>Explanation: A PROFIBUS master is attempting to establish a connection with a faulty configuration telegram.</p> <p>Check the bus configuration on the master and slave side.</p>
A01910 F01910	Setpoint timeout	<p>The alarm is generated when p2040 ≠ 0 ms and one of the following causes is present:</p> <ul style="list-style-type: none"> <li>• The bus connection is interrupted</li> <li>• The Modbus master is switched off</li> <li>• Communications error (CRC, parity bit, logical error)</li> <li>• An excessively low value for the fieldbus monitoring time (p2040)</li> </ul>
A01920	PROFIBUS: Cyclic connection interrupt	<p>Explanation: The cyclic connection to PROFIBUS master is interrupted.</p> <p>Establish the PROFIBUS connection and activate the PROFIBUS master with cyclic operation.</p>
F03505	Analog input, wire break	<p>Check the wiring for interruptions.</p> <p>Check the level of the injected signal.</p> <p>The input current measured by the analog input can be read out in r0752.</p>
A03520	Temperature sensor fault	Check that the sensor is connected correctly.

## 9.5 List of alarms and faults

Number	Cause	Remedy
A05000 A05001 A05002 A05004 A05006	Power Module overtemperature	Check the following: - Is the ambient temperature within the defined limit values? - Are the load conditions and duty cycle configured accordingly? - Has the cooling failed?
F06310	Supply voltage (p0210) incorrectly set	Check the set supply voltage and if required change (p0210). Check the line voltage.
F07011	Motor overtemperature	Reduce the motor load. Check the ambient temperature. Check the wiring and connection of the sensor.
A07012	I2t Motor Module overtemperature	Check and if necessary reduce the motor load. Check the motor's ambient temperature. Check the thermal time constant p0611. Check the overtemperature fault threshold p0605.
A07015	Motor temperature sensor alarm	Check that the sensor is connected correctly. Check the parameter assignment (p0601).
F07016	Motor temperature sensor fault	Make sure that the sensor is connected correctly. Check the parameterization (p0601). Deactivate the motor temperature sensor fault evaluation (p0607 = 0).
F07086 F07088	Switching over units: Parameter limit violation	Check the adapted parameter values and if required correct.
F07320	Automatic restart aborted	Increase the number of restart attempts (p1211). The actual number of start attempts is shown in r1214. Increase the wait time in p1212 and/or monitoring time in p1213. Connect an ON command (p0840). Increase the monitoring time of the power unit or switch off (p0857). Reduce the wait time for resetting the fault counter p1213[1] so that fewer faults are registered in the time interval.
A07321	Automatic restart active	Explanation: The automatic restart (AR) is active. During voltage recovery and/or when remedying the causes of pending faults, the drive is automatically switched back on.
F07330	Search current measured too low	Increase the search current (p1202), check the motor connection.
A07353	DC quantity control deactivated	The controller to suppress DC components in the motor current was at its limit and deactivated itself. <ul style="list-style-type: none"> <li>• Increase the integral time p3858 of the DC quantity controller</li> <li>• Decrease the gain p3857 of the DC quantity controller</li> </ul>
A07400	DC-link voltage maximum controller active	If it is not desirable that the controller intervenes: <ul style="list-style-type: none"> <li>• Increase the ramp-down times.</li> <li>• Deactivate the Vdc_max control (p1240 = 0 for vector control, p1280 = 0 for U/f control).</li> </ul>
A07409	U/f control, current limiting controller active	The alarm automatically disappears after one of the following measures: <ul style="list-style-type: none"> <li>• Increase the current limit (p0640).</li> <li>• Reduce the load.</li> <li>• Slow down the ramp-ups for the setpoint speed.</li> </ul>

Number	Cause	Remedy
F07426	Technology controller actual value limited	<ul style="list-style-type: none"> <li>Adapt the limits to the signal level (p2267, p2268).</li> <li>Check the actual value scaling (p2264).</li> </ul>
F07801	Motor overcurrent	<p>Check the current limits (p0640).</p> <p>Vector control: Check the current controller (p1715, p1717).</p> <p>U/f control: Check the current limiting controller (p1340 ... p1346).</p> <p>Increase the acceleration ramp (p1120) or reduce the load.</p> <p>Check the motor and motor cables for short-circuit and ground fault.</p> <p>Check the motor regarding the star/delta connection and rating plate parameterization.</p> <p>Check the power unit / motor combination.</p> <p>Select the flying restart function (p1200) if switched to rotating motor.</p>
A07805	Drive: Power unit overload I2t	<ul style="list-style-type: none"> <li>Reduce the continuous load.</li> <li>Adapt the load cycle.</li> <li>Check the assignment of rated currents of the motor and power unit.</li> </ul>
F07806	Regenerative power limit exceeded	<p>Increase the deceleration ramp.</p> <p>Reduce the driving load.</p> <p>Use a power unit with higher energy recovery capability.</p> <p>For vector control, the regenerative power limit in p1531 can be reduced until the fault is no longer activated.</p>
F07807	Short-circuit detected	<ul style="list-style-type: none"> <li>Check the inverter connection on the motor side for any phase-phase short-circuit.</li> <li>Rule out that line and motor cables have been interchanged.</li> </ul>
A07850 A07851 A07852	External alarm 1 ... 3	<p>The signal for "external alarm 1" has been triggered.</p> <p>Parameters p2112, p2116 and p2117 determine the signal sources for the external alarm 1... 3.</p> <p>Remedy: Remove the causes of these alarms.</p>
F07860 F07861 F07862	External fault 1 ... 3	Remove the external causes for this fault.
F07900	Motor blocked	<p>Check that the motor can run freely.</p> <p>Check the torque limits (r1538 and r1539).</p> <p>Check the parameters of the "Motor blocked" message (p2175, p2177).</p>
F07901	Motor overspeed	<p>Activate the precontrol for the speed limiting controller (p1401 bit 7 = 1).</p> <p>Increase the hysteresis for overspeed signal p2162.</p>
F07902	Motor stalled	<p>Check whether the motor data has been set correctly and perform a motor identification.</p> <p>Check the current limits (p0640, r0067, r0289). If the current limits are too low, the drive cannot be magnetized.</p> <p>Check whether motor cables are disconnected during operation.</p>
A07903	Motor speed deviation	<p>Increase p2163 and/or p2166.</p> <p>Increase the torque, current and power limits.</p>

9.5 List of alarms and faults

Number	Cause	Remedy
A07910	Motor overtemperature	Check the motor load. Check the motor's ambient temperature. Check the KTY84 sensor. Check the overtemperatures of the thermal model (p0626 ... p0628).
A07920	Torque/speed too low	The torque deviates from the torque/speed envelope curve. <ul style="list-style-type: none"> <li>• Check the connection between the motor and the load.</li> <li>• Adapt the parameterization corresponding to the load.</li> </ul>
A07921	Torque/speed too high	
A07922	Torque/speed out of tolerance	
F07923	Torque/speed too low	<ul style="list-style-type: none"> <li>• Check the connection between the motor and the load.</li> <li>• Adapt the parameterization corresponding to the load.</li> </ul>
F07924	Torque/speed too high	
A07927	DC braking active	Not required
A07980	Rotary measurement activated	Not required
A07981	No enabling for rotary measurement	Acknowledge pending faults. Establish missing enables (see r00002, r0046).
A07991	Motor identification activated	Switch on the motor and identify the motor data.
F08501	Setpoint timeout	<ul style="list-style-type: none"> <li>• Check the PROFINET connection.</li> <li>• Set the controller into the RUN mode.</li> <li>• If the fault occurs repeatedly, check the monitoring time set p2044.</li> </ul>
F08502	Monitoring time, sign-of-life expired	<ul style="list-style-type: none"> <li>• Check the PROFINET connection.</li> </ul>
F08510	Send configuration data not valid	<ul style="list-style-type: none"> <li>• Check the PROFINET configuration</li> </ul>
A08511	Receive configuration data not valid	
A08526	No cyclic connection	<ul style="list-style-type: none"> <li>• Activate the controller with cyclic operation.</li> <li>• Check the parameters "Name of Station" and "IP of Station" (r61000, r61001).</li> </ul>
A08565	Consistency error affecting adjustable parameters	Check the following: <ul style="list-style-type: none"> <li>• IP address, subnet mask or default gateway is not correct.</li> <li>• IP address or station name used twice in the network.</li> <li>• Station name contains invalid characters.</li> </ul>
F08700	Communications error	A CAN communications error has occurred. Check the following: <ul style="list-style-type: none"> <li>• Bus cable</li> <li>• Baud rate (p8622)</li> <li>• Bit timing (p8623)</li> <li>• Master</li> </ul> Start the CAN controller manually with p8608 = 1 after the cause of the fault has been resolved!
F13100	Know-how protection: Copy protection error	The know-how protection and the copy protection for the memory card are active. An error occurred when checking the memory card. <ul style="list-style-type: none"> <li>• Insert a suitable memory card and switch the inverter supply voltage temporarily off and then on again (POWER ON).</li> <li>• Deactivate the copy protection (p7765).</li> </ul>

Number	Cause	Remedy
F13101	Know-how protection: Copy protection cannot be activated	Insert a valid memory card.
F30001	Overcurrent	<p>Check the following:</p> <ul style="list-style-type: none"> <li>• Motor data, if required, carry out commissioning</li> <li>• Motor connection method (Y / Δ)</li> <li>• U/f operation: Assignment of rated currents of motor and Power Module</li> <li>• Line quality</li> <li>• Make sure that the line commutating reactor is connected properly</li> <li>• Power cable connections</li> <li>• Power cables for short-circuit or ground fault</li> <li>• Power cable length</li> <li>• Line phases</li> </ul> <p>If this doesn't help:</p> <ul style="list-style-type: none"> <li>• U/f operation: Increase the acceleration ramp</li> <li>• Reduce the load</li> <li>• Replace the power unit</li> </ul>
F30002	DC-link voltage overvoltage	<p>Increase the ramp-down time (p1121).  Set the rounding times (p1130, p1136).  Activate the DC-link voltage controller (p1240, p1280).  Check the line voltage (p0210).  Check the line phases.</p>
F30003	DC-link voltage undervoltage	Check the line voltage (p0210).
F30004	Inverter overtemperature	<p>Check whether the inverter fan is running.  Check whether the ambient temperature is in the permissible range.  Check whether the motor is overloaded.  Reduce the pulse frequency.</p>
F30005	I <sub>2t</sub> inverter overload	<p>Check the rated currents of the motor and Power Module.  Reduce the current limit p0640.  When operating with U/f characteristic: Reduce p1341.</p>
F30011	Line phase failure	<p>Check the inverter's input fuses.  Check the motor feeder cables.</p>
F30015	Motor cable phase failure	<p>Check the motor cables.  Increase the ramp-up or ramp-down time (p1120).</p>
F30021	Ground fault	<ul style="list-style-type: none"> <li>• Check the power cable connections.</li> <li>• Check the motor.</li> <li>• Check the current transformer.</li> <li>• Check the cables and contacts of the brake connection (a wire might be broken).</li> </ul>
F30027	Time monitoring for DC link pre-charging	<p>Check the supply voltage at the input terminals.  Check the line voltage setting (p0210).</p>
F30035	Overtemperature, intake air	<ul style="list-style-type: none"> <li>• Check whether the fan is running.</li> </ul>

9.5 List of alarms and faults

Number	Cause	Remedy
F30036	Overtemperature, inside area	<ul style="list-style-type: none"> <li>• Check the fan filter elements.</li> <li>• Check whether the ambient temperature is in the permissible range.</li> </ul>
F30037	Rectifier overtemperature	See F30035 and, in addition: <ul style="list-style-type: none"> <li>• Check the motor load.</li> <li>• Check the line phases</li> </ul>
A30049	Internal fan defective	Check the internal fan and if required replace.
F30059	Internal fan defective	Check the internal fan and if required replace.
A30502	DC-link overvoltage	<ul style="list-style-type: none"> <li>• Check the unit supply voltage (p0210).</li> <li>• Check the dimensioning of the line reactor.</li> </ul>
A30920	Temperature sensor fault	Check that the sensor is connected correctly.
A50001	PROFINET configuration error	A PROFINET controller is attempting to establish a connection with an incorrect configuration telegram. Check whether "Shared Device" is activated (p8929 = 2).
A50010	PROFINET name of station invalid	Correct name of station (p8920) and activate (p8925 = 2).
A50020	PROFINET: Second controller missing	"Shared Device" is activated (p8929 = 2). However, only the connection to a PROFINET controller is available.
For further information, please refer to the List Manual.		

For further information, please refer to the List Manual.

## 9.6 Identification & maintenance data (I&M)

### I&M data

The inverter supports the following identification and maintenance (I&M) data.

I&M data	Format	Explanation	Associated parameters	Example for the content
I&M0	u8[64] PROFIBUS u8[54] PROFINET	Inverter-specific data, read only	-	See below
I&M1	Visible String [32]	Plant/system identifier	p8806[0 ... 31]	"ak12- ne.bo2=fu1"
	Visible String [22]	Location code	p8806[32 ... 53]	"sc2+or45"
I&M2	Visible String [16]	Date	p8807[0 ... 15]	"2013-01-21 16:15"
I&M3	Visible String [54]	Any comment	p8808[0 ... 53]	-
I&M4	Octet String[54]	Check signature to track changes for Safety Integrated. This value can be changed by the user. The test signature is reset to the value generated by the machine is p8805 = 0 is used.	p8809[0 ... 53]	Values of r9781[0] and r9782[0]

When requested, the inverter transfers its I&M data to a higher-level control or to a PC/PG with installed STEP 7, STARTER or TIA-Portal.

### I&M0

Designation	Format	Example for the content	Valid for PROFINET	Valid for PROFIBUS
Manufacturer-specific	u8[10]	00 ... 00 hex	---	✓
MANUFACTURER_ID	u16	42d hex (=Siemens)	✓	✓
ORDER_ID	Visible String [20]	„6SL3246-0BA22-1FA0“	✓	✓
SERIAL_NUMBER	Visible String [16]	„T-R32015957“	✓	✓
HARDWARE_REVISION	u16	0001 hex	✓	✓
SOFTWARE_REVISION	char, u8[3]	„V“ 04.70.19	✓	✓
REVISION_COUNTER	u16	0000 hex	✓	✓
PROFILE_ID	u16	3A00 hex	✓	✓
PROFILE_SPECIFIC_TYPE	u16	0000 hex	✓	✓
IM_VERSION	u8[2]	01.02	✓	✓
IM_SUPPORTED	bit[16]	001E hex	✓	✓



## Technical data

### 10.1 Technical data for CU230P-2

Feature	Data / explanation												
Article Nos.	<table border="0"> <tr> <td>CU230P-2 CAN</td> <td>With CANopen interface</td> <td rowspan="4">Article numbers: See Section Control Units (Page 27)</td> </tr> <tr> <td>CU230P-2 HVAC</td> <td>With RS485 interface for the following protocols:</td> </tr> <tr> <td>CU230P-2 BT</td> <td> <ul style="list-style-type: none"> <li>• USS</li> <li>• Modbus RTU</li> <li>• BACnet MS/TP</li> <li>• P1</li> </ul> </td> </tr> <tr> <td>CU230P-2 DP</td> <td>With PROFIBUS interface</td> </tr> <tr> <td>CU230P-2 PN</td> <td>With PROFINET interface</td> <td></td> </tr> </table>	CU230P-2 CAN	With CANopen interface	Article numbers: See Section Control Units (Page 27)	CU230P-2 HVAC	With RS485 interface for the following protocols:	CU230P-2 BT	<ul style="list-style-type: none"> <li>• USS</li> <li>• Modbus RTU</li> <li>• BACnet MS/TP</li> <li>• P1</li> </ul>	CU230P-2 DP	With PROFIBUS interface	CU230P-2 PN	With PROFINET interface	
CU230P-2 CAN	With CANopen interface	Article numbers: See Section Control Units (Page 27)											
CU230P-2 HVAC	With RS485 interface for the following protocols:												
CU230P-2 BT	<ul style="list-style-type: none"> <li>• USS</li> <li>• Modbus RTU</li> <li>• BACnet MS/TP</li> <li>• P1</li> </ul>												
CU230P-2 DP	With PROFIBUS interface												
CU230P-2 PN	With PROFINET interface												
Operating voltage	<p>You have two options for the Control Unit power supply:</p> <ul style="list-style-type: none"> <li>• Supply from the Power Module</li> <li>• External supply via terminals 31 and 32 with 20.4 V ... 28.8 V DC. Use a power supply with protective extra low voltage (PELV according to EN 61800-5-1), Class 2. The 0 V of the power supply must be connected to the PE of the plant/system through a low-ohmic connection.</li> </ul>												
Current consumption	<p>Max 0.5 A The current consumption can be higher if the Control Unit supplies external components.</p>												
Power loss	5.0 W												
Output voltages	<p>+24 V out (terminal 9), 18 V ... 28.8 V, max. 100 mA +10 V out (terminals 1 and 35), 9.5 V ... 10.5 V, max. 10 mA</p>												
Setpoint resolution	0.01 Hz												
Digital inputs	<table border="0"> <tr> <td>6 (DI 0 ... DI 5)</td> <td> <ul style="list-style-type: none"> <li>• Low &lt; 5V, high &gt; 11V</li> <li>• Electrically isolated</li> <li>• 30 V maximum input voltage</li> <li>• 5.5 mA current consumption</li> <li>• SIMATIC-compatible</li> <li>• PNP/NPN switchable</li> <li>• 10 ms response time for debounce time p0724 = 0.</li> </ul> </td> </tr> </table>	6 (DI 0 ... DI 5)	<ul style="list-style-type: none"> <li>• Low &lt; 5V, high &gt; 11V</li> <li>• Electrically isolated</li> <li>• 30 V maximum input voltage</li> <li>• 5.5 mA current consumption</li> <li>• SIMATIC-compatible</li> <li>• PNP/NPN switchable</li> <li>• 10 ms response time for debounce time p0724 = 0.</li> </ul>										
6 (DI 0 ... DI 5)	<ul style="list-style-type: none"> <li>• Low &lt; 5V, high &gt; 11V</li> <li>• Electrically isolated</li> <li>• 30 V maximum input voltage</li> <li>• 5.5 mA current consumption</li> <li>• SIMATIC-compatible</li> <li>• PNP/NPN switchable</li> <li>• 10 ms response time for debounce time p0724 = 0.</li> </ul>												

Feature	Data / explanation
Analog inputs	4 (AI 0 ... AI 3) <ul style="list-style-type: none"> <li>• Differential inputs</li> <li>• 12-bit resolution</li> <li>• 13 ms response time</li> <li>• AI 0 and AI 1 can be switched over:                             <ul style="list-style-type: none"> <li>– 0 V ... 10 V or -10 V ... +10 V (voltage &lt; 35 V)</li> <li>– 0 mA ... 20 mA (120 Ω input resistance, voltage &lt; 10 V, current &lt; 80 mA)</li> </ul> </li> <li>• If AI 0 and AI 1 are configured as supplementary digital inputs: Voltage &lt; 35 V, low &lt; 1.6 V, high &gt; 4.0 V, 13 ms ± 1 ms response time for debounce time p0724 = 0.</li> <li>• AI 2 can be switched over:                             <ul style="list-style-type: none"> <li>– 0 V ... 10 V or -10 V ... +10 V (voltage &lt; 35 V)</li> <li>– 0 mA ... 20 mA (voltage &lt; 10 V, current &lt; 80 mA)</li> <li>– Temperature sensor Pt1000/LG-Ni1000/DIN-Ni1000 (characteristics: See below)</li> </ul> </li> <li>• AI 3:                             <ul style="list-style-type: none"> <li>Temperature sensor Pt1000/LG-Ni1000/DIN-Ni1000 (characteristics: See below)</li> </ul> </li> </ul>
Digital outputs /relay outputs	3 (DO 0 ... DO 2) <ul style="list-style-type: none"> <li>• DO 0, DO 2: 30 VDC 5 A / 250 VAC, 2 A <sup>1)</sup></li> <li>• DO 1: 30 V DC 0.5 A</li> <li>• 2 ms update time</li> </ul>
Analog outputs	2 (AO 0 ... AO 1) <ul style="list-style-type: none"> <li>• 0 V ... 10 V or 0 mA ... 20 mA</li> <li>• Reference potential: "GND"</li> <li>• 16-bit resolution</li> <li>• 4 ms update time</li> </ul>
Motor temperature sensor	PTC <ul style="list-style-type: none"> <li>• Short-circuit monitoring &lt; 20Ω</li> <li>• Overtemperature 1650Ω</li> </ul>
	KTY84 <ul style="list-style-type: none"> <li>• Short-circuit monitoring &lt; 50 Ω</li> <li>• Wire breakage: &gt; 2120 Ω</li> </ul>
	Temperature switch with isolated contact
USB interface	Mini-B
Dimensions (W × H × D)	73mm × 199mm × 50mm    Depth when mounting on the Power Module
Memory card (optional)	Slot for SD or MMC memory cards, see also Section: Control Units (Page 27)
Weight	0.61kg
Operating temperature	-10 °C ... 60 °C    CU230P-2 HVAC, CU230P-2 CAN and CU230P-2 DP Without inserted operator panel
	-10 °C ... 55 °C    CU230P-2 PN without inserted operator panel
	0° C ... 50° C    With inserted BOP-2 or IOP operator panel
	Observe any possible restrictions regarding the operating temperature as a result of the Power Module.

Feature	Data / explanation
Storage temperature	- 40° C ... 70° C
Relative humidity	< 95% Condensation is not permissible.

1) The following applies to systems complying with UL: A maximum of 3 A 30 VDC or 2 A 250 VAC may be connected via terminals 18 / 20 (DO 0 NC) and 23 / 25 (DO 2 NC).




Figure 10-1 Temperature sensor characteristic of analog inputs AI 2 and AI 3

**Note**

**Short-term voltage dips in the external 24 V supply ( $\leq 3$  ms and  $\leq 95\%$  of the rated voltage)**

When the mains voltage of the inverter is switched off, the inverter responds to short-term voltage dips in the external 24 V supply with fault F30074. Communication via fieldbus, however, remains in effect in this case.

## 10.2 Technical data, Power Modules

### Overload capability of the inverter

Overload capability is the property of the inverter to temporarily supply a current that is higher than the rated current to accelerate a load. Two typical load cycles are defined to clearly demonstrate the overload capability: "Low Overload" and "High Overload"

Table 10- 1 Load cycles and typical applications:

"Low Overload" load cycle	"High Overload" load cycle
<p>The "Low Overload" load cycle assumes a uniform base load with low requirements placed on brief accelerating p phases. Typical applications when designing according to "Low Overload" include:</p> <ul style="list-style-type: none"> <li>• Pumps, fans and compressors</li> <li>• Wet or dry blasting technology</li> <li>• Mills, mixers, kneaders, crushers, agitators</li> <li>• Basic spindles</li> <li>• Rotary kilns</li> <li>• Extruders</li> </ul>	<p>The "High Overload" load cycle permits, for reduced base load, dynamic accelerating phases. Typical applications when designing according to "High Overload" include:</p> <ul style="list-style-type: none"> <li>• Horizontal and vertical conveyor technology (conveyor belts, roller conveyors, chain conveyors)</li> <li>• Centrifuges</li> <li>• Escalators/moving stairways</li> <li>• Lifters/Lowerers</li> <li>• Elevators</li> <li>• Gantry cranes</li> <li>• Cable railways</li> <li>• Storage and retrieval machines</li> </ul>

### Definitions

- **Base load**

Constant load between the accelerating phases of the drive

Low Overload	High Overload
<ul style="list-style-type: none"> <li>• <b>LO base load input current</b> Permissible input current for a "Low Overload" load cycle</li> <li>• <b>LO base load output current</b> Permissible output current for a "Low Overload" load cycle</li> <li>• <b>LO base load power</b> Rated power based on the LO base load output current</li> </ul>	<ul style="list-style-type: none"> <li>• <b>HO base load input current</b> Permissible input current for a "High Overload" load cycle</li> <li>• <b>HO base load output current</b> Permissible output current for a "High Overload" load cycle</li> <li>• <b>HO base load power</b> Rated power based on the HO base load output current</li> </ul>

If not specified otherwise, the power and current data in the technical data always refer to a load cycle according to Low Overload.

We recommend the "SIZER" engineering software to select the inverter. You will find additional information about SIZER on the Internet at: Download SIZER (<http://support.automation.siemens.com/WW/view/en/10804987/130000>).

## 10.2.1 Technical data, PM230

### Typical inverter load cycles




Figure 10-2 Duty cycles, "High Overload" and "Low Overload"

### 10.2.1.1 General data, PM230 - IP20

Property	Version
Line voltage	380 V ... 480 V 3-ph. AC $\pm 10\%$
Output voltage	0 V 3-ph. AC ... input voltage x 0.95 (max.)
Input frequency	50 Hz ... 60 Hz, $\pm 3$ Hz
Output frequency	0 Hz ... 550 Hz, depending on the control mode
Power factor $\lambda$	0.9
Line impedance	$U_k \leq 1\%$ , no line reactor permitted
Inrush current	< LO base load input current
Pulse frequency (factory setting)	4 kHz The pulse frequency can be increased in 2 kHz steps up to 16 kHz (up to 8 kHz for 55 kW and 75 kW). An increase in the pulse frequency results in a lower output current.
Electromagnetic compatibility	Devices with filters in compliance with EN 61800-3: 2004 are suitable for Category C2 environments.
Braking methods	DC braking
Degree of protection	IP20 built-in units      IP20 when mounted in a control cabinet PT devices                      IP54 on the control cabinet wall
Operating temperature at	LO base load power without derating      0 °C ... +40 °C

Technical data

10.2 Technical data, Power Modules

Property	Version
	HO base load power without derating 0 °C ... +50 °C
	LO/HO base load power with derating: Up to 60° C
	Details - (Page 428).
Storage temperature	-40 °C ... +70 °C
Relative humidity	< 95% - condensation not permissible
Pollution	Protected according to pollution degree 2 to EN 61800-5-1: 2007
Environmental requirements	Protected against damaging chemical substances according to environmental class 3C2 to EN 60721-3-3; 1995
Shock and vibration	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2 to EN 60721-3-1: 1997</li> <li>• Transport in the transport packaging according to Class 2M3 to EN 60721-3-2: 1997</li> <li>• Vibration during operation according to Class 3M2 to EN 60721-3-3: 1995</li> </ul>
Installation altitude	without derating: up to 1000 m above sea level For details, see Restrictions for special ambient conditions (Page 428) with derating: up to 4000 m above sea level
Permissible short-circuit current	Frame size D ... F: 65 kA <sup>1)</sup>
Overvoltage category	Supply circuits: Overvoltage category III Non-supply circuits: Overvoltage category II
Standards	UL <sup>1),2)</sup> , CE, C-tick The drive only satisfies the UL requirements when UL-certified fuses are used.

<sup>1)</sup> If fuse-protected with a listed Class J or 3NE1 fuse, rated voltage 600 VAC with the rated current of the specific inverter.

<sup>2)</sup> UL available soon for frame sizes D ... F

### 10.2.1.2 Power-dependent data, PM230, IP20

**Note**

The values for Low Overload (LO) are identical with those of the rated values.

Table 10- 2 PM230, IP20, frame sizes A, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE11-3UL1	...1NE11-7UL1	...1NE12-2UL1
Article No. - with filter	6SL3210...	...1NE11-3AL1	...1NE11-7AL1	...1NE12-2AL1
LO base load power		0.37 kW	0.55 kW	0.75 kW
LO base load input current		1.3 A	1.8 A	2.3 A
LO base load output current		1.3 A	1.7 A	2.2 A
HO base load power		0.25 kW	0.37 kW	0.55 kW
HO base load input current		0.9 A	1.3 A	1.8 A
HO base load output current		0.9 A	1.3 A	1.7 A
Fuse according to IEC		3NE1 813-0	3NE1 813-0	3NE1 813-0
Fuse according to UL		AJT2 / 3NE1 813-0	AJT4 / 3NE1 813-0	AJT4 / 3NE1 813-0
Power loss		0.04 kW	0.04 kW	0.05 kW
Required cooling air flow		1.5 l/s	1.5 l/s	4.5 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in
Weight without filter		1.4 kg	1.4 kg	1.4 kg
Weight with filter		1.6 kg	1.6 kg	1.6 kg

Table 10- 3 PM230, IP20, frame sizes A, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE13-1UL1	...1NE14-1UL1	...1NE15-8UL1
Article No. - with filter	6SL3210...	...1NE13-1AL10	...1NE14-1AL1	...1NE15-8AL1
LO base load power		1.1 kW	1.5 kW	2.2 kW
LO base load input current		3.2 A	4.2 A	6.1 A
LO base load output current		3.1 A	4.1 A	5.9 A
HO base load power		0.75 kW	1.1 kW	1.5 kW
HO base load input current		2.3 A	3.2 A	4.2 A
HO base load output current		2.2 A	3.1 A	4.1 A
Fuse according to IEC		3NE1 813-0	3NE1 813-0	3NE1 813-0
Fuse according to UL		AJT6 / 3NE1 813-0	AJT6 / 3NE1 813-0	AJT10 / 3NE1 813-0
Power loss		0.06 kW	0.07 kW	0.08 kW
Required cooling air flow		4.5 l/s	4.5 l/s	4.5 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1.5 ... 2.5 mm <sup>2</sup> 16 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in
Weight without filter		1.4 kg	1.4 kg	1.4 kg
Weight with filter		1.6 kg	1.6 kg	1.6 kg

Table 10- 4 PM230, IP20, frame sizes A, 3 AC 380 V ... 480 V

<b>Article No. - without filter</b>	<b>6SL3210...</b>	<b>...1NE17-7UL1</b>
<b>Article No. - with filter</b>	<b>6SL3210...</b>	<b>...1NE17-7AL1</b>
LO base load power		3 kW
LO base load input current		8.0 A
LO base load output current		7.7 A
HO base load power		2.2 kW
HO base load input current		6.1 A
HO base load output current		5.9 A
Fuse according to IEC		3NE1 813-0
Fuse according to UL		AJT10 / 3NE1 813-0
Power loss		0.11 kW
Required cooling air flow		4.5 l/s
Cross section of line and motor cables		1.5 ... 2.5 mm <sup>2</sup> 16 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in
Weight without filter		1.4 kg
Weight with filter		1.6 kg

Table 10- 5 PM230, PT, frame sizes A, 3 AC 380 V ... 480 V

<b>Article No. - without filter</b>	<b>6SL3211...</b>	<b>...1NE17-7UL1</b>
<b>Article No. - with filter</b>	<b>6SL3211...</b>	<b>...1NE17-7AL1</b>
LO base load power		3 kW
LO base load input current		8.0 A
LO base load output current		7.7 A
HO base load power		2.2 kW
HO base load input current		6.1 A
HO base load output current		5.9 A
Fuse according to IEC		3NE1 813-0
Fuse according to UL		AJT10 / 3NE1 813-0
Power loss		0.11 kW
Required cooling air flow		4.5 l/s
Cross section of line and motor cables		1.5 ... 2.5 mm <sup>2</sup> 16 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in
Weight without filter		1.7 kg
Weight with filter		1.9 kg

Table 10- 6 PM230, IP20, frame sizes B, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3210...	...1NE21-0UL1	...1NE21-3UL1	...1NE21-8UL1
Article No. - with filter	6SL3210...	...1NE21-0AL1	...1NE21-3AL1	...1NE21-8AL1
LO base load power		4 kW	5.5 kW	7.5 kW
LO base load input current		10.5 A	13.6 A	18.6 A
LO base load output current		10.2 A	13.2 A	18 A
HO base load power		3 kW	4 kW	5.5 kW
HO base load input current		8.0 A	10.5 A	13.6 A
HO base load output current		7.7 A	10.2 A	13.2 A
Fuse according to IEC		3NE1 813-0	3NE1 814-0	3NE1 815-0
Fuse according to UL		AJT15 / 3NE1 813-0	AJT20 / 3NE1 814-0	AJT25 / 3NE1 815-0
Power loss		0.12 kW	0.15 kW	0.22 kW
Required cooling air flow		9.2 l/s	9.2 l/s	9.2 l/s
Cross section of line and motor cables		1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG	1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG	1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG
Tightening torque for line and motor cables		0.6 Nm / 5 lbf in	0.6 Nm / 5 lbf in	0.6 Nm / 5 lbf in
Weight without filter		2.8 kg	2.8 kg	2.8 kg
Weight with filter		3 kg	3 kg	3 kg

Table 10- 7 PM230, PT, frame sizes B, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3211...	...1NE21-8UL1
Article No. - with filter	6SL3211...	...1NE21-8AL1
LO base load power		7.5 kW
LO base load input current		18.6 A
LO base load output current		18 A
HO base load power		5.5 kW
HO base load input current		13.6 A
HO base load output current		13.2 A
Fuse according to IEC		3NE1 815-0
Fuse according to UL		AJT25 / 3NE1 815-0
Power loss		0.22 kW
Required cooling air flow		9.2 l/s
Cross section of line and motor cables		1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG
Tightening torque for line and motor cables		0.6 Nm / 5 lbf in
Weight without filter		3.4 kg
Weight with filter		3.6 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 8 PM230, IP20, frame sizes C, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE22-6UL1	...1NE23-2UL1	...1NE23-8UL1
Article No. - with filter	6SL3210...	...1NE22-6AL1	...1NE23-2AL1	...1NE23-8AL1
LO base load power		11 kW	15 kW	18.5 kW
LO base load input current		26.9 A	33.1 A	39.2 A
LO base load output current		26 A	32 A	38 A
HO base load power		7.5 kW	11 kW	15 kW
HO base load input current		18.6 A	26.9 A	33.1 A
HO base load output current		18 A	26 A	32 A
Fuse according to IEC		3NE1 803-0	3NE1 817-0	3NE1 817-0
Fuse according to UL		AJT35 / 3NE1 803-0	AJT45 / 3NE1 817-0	AJT50 / 3NE1 817-0
Power loss		0.3 kW	0.35 kW	0.45 kW
Required cooling air flow		18.5 l/s	18.5 l/s	18.5 l/s
Cross section of line and motor cables		6 ...16 mm <sup>2</sup> 10 ... 6 AWG	6 ...16 mm <sup>2</sup> 10 ... 6 AWG	6 ...16 mm <sup>2</sup> 10 ... 6 AWG
Tightening torque for line and motor cables		1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in
Weight without filter		4.5 kg	4.5 kg	4.5 kg
Weight with filter		5.1 kg	5.1 kg	5.1 kg

Table 10- 9 PM230, PT, frame sizes C, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3211...	...1NE23-8UL1
Article No. - with filter	6SL3211...	...1NE23-8AL1
LO base load power		18.5 kW
LO base load input current		39.2 A
LO base load output current		38 A
HO base load power		15 kW
HO base load input current		33.1 A
HO base load output current		32 A
Fuse according to IEC		3NE1 817-0
Fuse according to UL		AJT50 / 3NE1 817-0
Power loss		0.45 kW
Required cooling air flow		18.5 l/s
Cross section of line and motor cables		6 ...16 mm <sup>2</sup> 10 ... 6 AWG
Tightening torque for line and motor cables		1.5 Nm / 13 lbf in
Weight without filter		5.4 kg
Weight with filter		6 kg

Table 10- 10 PM230, IP20, frame sizes D, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE24-5UL0	...1NE26-0UL0
Article No. - with filter	6SL3210...	...1NE24-5AL0	...1NE26-0AL0
LO base load power		22 kW	30 kW
LO base load input current		42 A	56 A
LO base load output current		45 A	60 A
HO base load power		18.5 kW	22 kW
HO base load input current		36 A	42 A
HO base load output current		38 A	45 A
Fuse according to IEC		3NE1818-0	3NE1820-0
Fuse according to UL		3NE1818-0	3NE1820-0
Power loss		0.52 kW	0.68 kW
Required cooling air flow		80 l/s	80 l/s
Cross section of line and motor cables		16 ... 35 mm <sup>2</sup> 5 ... 2 AWG	16 ... 35 mm <sup>2</sup> 5 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight without filter		11 kg	11 kg
Weight with filter		14 kg	14 kg

Table 10- 11 PM230, IP20, frame sizes E, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE27-5UL0	...1NE28-8UL0
Article No. - with filter	6SL3210...	...1NE27-5AL0	...1NE28-8AL0
LO base load power		37 kW	45 kW
LO base load input current		70 A	84 A
LO base load output current		75 A	90 A
HO base load power		30 kW	37 kW
HO base load input current		56 A	70 A
HO base load output current		60 A	75 A
Fuse according to IEC		3NE1021-0	3NE1022-0
Fuse according to UL		3NE1021-0	3NE1022-0
Power loss		0.99 kW	1.2 kW
Required cooling air flow		80 l/s	80 l/s
Cross section of line and motor cables		25 ... 50 mm <sup>2</sup> 3 ... 1-1/0 AWG	25 ... 50 mm <sup>2</sup> 3 ... 1-1/0 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight without filter		15 kg	15 kg
Weight with filter		22 kg	22 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 12 PM230, IP20, frame sizes F, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210...	...1NE31-1UL0	...1NE31-5UL0
Article No. - with filter	6SL3210...	...1NE31-1AL0	...1NE31-5AL0
LO base load power		55 kW	75 kW
LO base load input current		102 A	135 A
LO base load output current		110 A	145 A
HO base load power		45 kW	55 kW
HO base load input current		84 A	102 A
HO base load output current		90 A	110 A
Fuse according to IEC		3NE1224-0	3NE1225-0
Fuse according to UL		3NE1224-0	3NE1225-0
Power loss		1.4 kW	1.9 kW
Required cooling air flow		150 l/s	150 l/s
Cross section of line and motor cables		35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG
Tightening torque for line and motor cables		13 Nm / 115 lbf in	13 Nm / 115 lbf in
Weight without filter		33 kg	33 kg
Weight with filter		48 kg	48 kg

## Current reduction depending on pulse frequency

Table 10- 13 Current reduction depending on the pulse frequency<sup>1)</sup>

LO base load	Output base-load current at a pulse frequency of							
	2 kHz	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
kW	A	A	A	A	A	A	A	A
0.37	--	1.30	1.11	0.91	0.78	0.65	0.59	0.52
0.55	--	1.70	1.45	1.19	1.02	0.85	0.77	0.68
0.75	--	2.20	1.87	1.54	1.32	1.10	0.99	0.88
1.1	--	3.10	2.64	2.17	1.86	1.55	1.40	1.24
1.5	--	4.10	3.49	2.87	2.46	2.05	1.85	1.64
2.2	--	5.90	5.02	4.13	3.54	2.95	2.66	2.36
3.0	--	7.70	6.55	5.39	4.62	3.85	3.47	3.08
4.0	--	10.20	8.67	7.14	6.12	5.10	4.59	4.08
5.5	--	13.20	11.22	9.24	7.92	6.60	5.94	5.28
7.5	--	18.00	15.30	12.60	10.80	9.00	8.10	7.20
11.0	--	26.00	22.10	18.20	15.60	13.00	11.70	10.40
15.0	--	32.00	27.20	22.40	19.20	16.00	14.40	12.80
18.5	--	38.00	32.30	26.60	22.80	19.00	17.10	15.20
22	--	45.00	38.25	31.50	27.00	22.50	20.25	18.00
30	--	60.00	51.00	42.00	36.00	30.00	27.00	24.00
37	--	75.00	63.75	52.50	45.00	37.50	33.75	30.00
45	--	90.00	76.50	63.00	54.00	45.00	40.50	36.00
55	--	110.0	93.50	77.00	66.00	55.00	49.50	44.00
75	--	145.0	123.3	101.5	--	--	--	--

<sup>1)</sup> The permissible motor cable length also depends on the cable type and the selected pulse frequency.

### 10.2.1.3 General data, PM230, IP55

Feature	Version
Line voltage	380°V°...°480°V 3-ph.°AC ±°10%
Output voltage	0 V 3-ph. AC ... input voltage x 0.95 (max.)
Input frequency	50 Hz ... 60 Hz, ± 3 Hz
Output frequency	0 Hz ... 550 Hz, depending on the control mode
Power factor λ	0.9
Line impedance	U <sub>k</sub> ≤ 1%, no line reactor permitted
Starting current	Less than the input current
Pulse frequency (factory setting)	4 kHz The pulse frequency can be increased in 2 kHz steps up to 16 kHz (up to 8 kHz for 75 kW and 90 kW). An increase in the pulse frequency results in a lower output current.
Electromagnetic compatibility	<b>Conducted interference:</b> The Power Modules correspond to Categories C1 and C2 of the second environment according to IEC61800-3. <b>Radiated interference:</b> The Power Modules comply with Category C2 of the second environment according to IEC61800-3.
Braking methods	DC braking
Degree of protection	FSA ... FSC IP55 / UL Type 12 FSD ... FSF IP55 / UL Type 12 in preparation Note: For the end cover plate, you must use the relevant bolting plates for the cable glands and the corresponding cable glands and seals to achieve the degree of protection UP55 (UL type 12). Degree of protection IP54 / UL Type 12 is reached if an IOP is inserted.
Operating temperature	for operation with LO base load power      -10 °C ... +40 °C; with derating up to 60° C for operation with HO base load power      -10 °C °... +50 °C; with derating up to 60° C Derating see Restrictions for special ambient conditions (Page 428)
Storage temperature	-40 °C ... +70 °C
Relative humidity	< 95% - condensation not permissible
Contamination	Protected from contact with dangerous parts, dust, spray water and water jets
Environmental requirements	Protected against damaging chemical substances according to environmental class 3C2 to EN 60721-3-3: 1995
Shock and vibration	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2 to EN 60721-3-1: 1997</li> <li>• Transport in the transport packaging according to Class 2M3 to EN 60721-3-2: 1997</li> <li>• Vibration during operation according to Class 3M2 to EN 60721-3-3: 1995</li> </ul>
Installation altitude	without derating:      up to 1000 m above sea level with derating:          up to 4000 m above sea level Derating see Restrictions for special ambient conditions (Page 428)
Rated short-circuit current	When fused using a type J or 3NE1 fuse, rated voltage 480 V AC with the rated current of the specific inverter. FSA ... FSC: 40 kA FSD ... FSF: 65 kA

### 10.2.1.4 Power-dependent data, PM230, IP55

**Note**

The values for Low Overload (LO) are identical with those of the rated values.

Table 10- 14 PM230, IP55, frame sizes A, 3-ph. 380 V AC... 480 V

Order No. - with filter, Class A	6SL3223-...	...0DE13-7AA1	...0DE15-5AA1	...0DE17-5AA1
Order No. - with filter Class B	6SL3223-...	...0DE13-7BA1	...0DE15-5BA1	...0DE17-5BA1
LO base load power		0.37 kW	0.55 kW	0.75 kW
LO base load input current		1.3 A	1.8 A	2.3 A
LO base load output current		1.3 A	1.7 A	2.2 A
HO base load power		0.25 kW	0.37 kW	0.55 kW
HO base load input current		0.9 A	1.3 A	1.8 A
HO base load output current		0.9 A	1.3 A	1.7 A
Fuse according to IEC		3NA3803	3NA3803	3NA3803
Fuse according to UL		10 A, Class J	10 A, Class J	10 A, Class J
Power loss		0.06 kW	0.06 kW	0.06 kW
Required cooling air flow		7 l/s	7 l/s	7 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in
Weight		4.3 kg	4.3 kg	4.3 kg

Table 10- 15 PM230, IP55, frame sizes A, 3-ph. 380 V AC... 480 V

Order No. - with filter, Class A	6SL3223-...	...0DE21-1AA1	...0DE21-5AA1	...0DE22-2AA1
Order No. - with filter Class B	6SL3223-...	...0DE21-1BA1	...0DE21-5BA1	...0DE22-2BA1
LO base load power		1.1 kW	1.5 kW	2.2 kW
LO base load input current		3.2 A	4.2 A	6.1 A
LO base load output current		3.1 A	4.1 A	5.9 A
HO base load power		0.75 kW	1.1 kW	1.5 kW
HO base load input current		2.3 A	3.2 A	4.2 A
HO base load output current		2.2 A	3.1 A	4.1 A
Fuse according to IEC		3NA3803	3NA3803	3NA3803
Fuse according to UL		10 A, Class J	10 A, Class J	10 A, Class J
Power loss		0.07 kW	0.08 kW	0.1 kW
Required cooling air flow		7 l/s	7 l/s	7 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in
Weight		4.3 kg	4.3 kg	4.3 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 16 PM230, IP55, frame sizes A, 3-ph. 380 V AC... 480 V

Order No. - with filter, Class A	6SL3223-...	...0DE23-0AA1
Order No. - with filter Class B	6SL3223-...	...0DE23-0BA1
LO base load power		3 kW
LO base load input current		8.0 A
LO base load output current		7.7 A
HO base load power		2.2 kW
HO base load input current		6.1 A
HO base load output current		5.9 A
Fuse according to IEC		3NA3803
Fuse according to UL		10 A, Class J
Power loss		0.12 kW
Required cooling air flow		7 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4.4 lbf in
Weight		4.3 kg

Table 10- 17 PM230, IP55, frame sizes B, 3-ph. 380 V AC... 480 V

Order No. - with filter, Class A	6SL3223-...	...0DE24-0AA1	...0DE25-5AA1	...0DE27-5AA1
Order No. - with filter Class B	6SL3223-...	...0DE24-0BA1	...0DE25-5BA1	...0DE27-5BA1
LO base load power		4 kW	5.5 kW	7.5 kW
LO base load input current		10.5 A	13.6 A	18.6 A
LO base load output current		10.2 A	13.2 A	18 A
HO base load power		3 kW	4 kW	5.5 kW
HO base load input current		8.0 A	10.5 A	13.6 A
HO base load output current		7.7 A	10.2 A	13.2 A
Fuse according to IEC		3NA3805	3NA3807	3NA3810
Fuse according to UL		16 A, Class J	25 A, Class J	35 A, Class J
Power loss		0.14 kW	0.18 kW	0.24 kW
Required cooling air flow		9 l/s	9 l/s	9 l/s
Cross section of line and motor cables		2.5 ... 6 mm <sup>2</sup> 14 ... 10 AWG	4 ... 6 mm <sup>2</sup> 12 ... 10 AWG	4 ... 6 mm <sup>2</sup> 12 ... 10 AWG
Tightening torque for line and motor cables		0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in	0.5 Nm / 4.4 lbf in
Weight		6.3 kg	6.3 kg	6.3 kg

Table 10- 18 PM230, IP55, frame sizes C, 3-ph. 380 V AC... 480 V

Order No. - with filter, Class A	6SL3223-...	...0DE31-1AA1	...0DE31-5AA1	...0DE31-8AA1
Order No. - with filter Class B	6SL3223-...	...0DE31-1BA1	...0DE31-5BA1	---
LO base load power		11 kW	15 kW	18.5 kW
LO base load input current		26.9 A	33.1 A	39.2 A
LO base load output current		26 A	32 A	38 A
HO base load power		7.5 kW	11 kW	15 kW
HO base load input current		18.6 A	26.9 A	33.1 A
HO base load output current		18 A	26 A	32 A
Fuse according to IEC		3NA3814	3NA3820	3NA3820
Fuse according to UL		40 A, Class J	50 A, Class J	50 A, Class J
Power loss		0.32 kW	0.39 kW	0.46 kW
Required cooling air flow		20 l/s	20 l/s	20 l/s
Cross section of line and motor cables		6 ... 16 mm <sup>2</sup> 10 ... 5 AWG	10 ... 16 mm <sup>2</sup> 7 ... 5 AWG	10 ... 16 mm <sup>2</sup> 7 ... 5 AWG
Tightening torque for line and motor cables		1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in
Weight		9.5 kg	9.5 kg	9.5 kg

Table 10- 19 PM230, IP55, Frame Sizes D, 3 AC 380 V ... 480 V

Order No. - with filter, Class A	6SL3223-...	-	...0DE32-2AA0	...0DE33-0AA0
Order No. - with filter Class B	6SL3223-...	...0DE31-8BA0	...0DE32-2BA0	...0DE33-0BA0
LO base load power		18.5 kW	22 kW	30 kW
LO base load input current		39.2 A	42 A	56 A
LO base load output current		38 A	45 A	60 A
HO base load power		15 kW	18.5 kW	22 kW
HO base load input current		33.1 A	36 A	42 A
HO base load output current		32 A	38 A	45 A
Fuse according to IEC		3NA3820	3NA3822	3NA3824
Fuse according to UL		50 A, Class J	63 A, Class J	80 A, Class J
Power loss		0.46 kW	0.52 kW	0.68 kW
Required cooling air flow		20 l/s	39 l/s	39 l/s
Cross section of line and motor cables		10 ... 35 mm <sup>2</sup> 7 ... 2 AWG	16 ... 35 mm <sup>2</sup> 5 ... 2 AWG	16 ... 35 mm <sup>2</sup> 5 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight		30.2 kg	30.2 kg	30.2 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 20 PM230, IP55, Frame Sizes E, 3 AC 380 V ... 480 V

<b>Order No. - with filter, Class A</b>	<b>6SL3223-...</b>	<b>...0DE33-7AA0</b>	<b>...0DE34-5AA0</b>
<b>Order No. - with filter Class B</b>	<b>6SL3223-...</b>	<b>...0DE33-7BA0</b>	<b>...0DE34-5BA0</b>
LO base load power		37 kW	45 kW
LO base load input current		70 A	84 A
LO base load output current		75 A	90 A
HO base load power		30 kW	37 kW
HO base load input current		56 A	70 A
HO base load output current		60 A	75 A
Fuse according to IEC		3NA3830	3NA3832
Fuse according to UL		100 A, Class J	125 A, Class J
Power loss		0.99 kW	1.2 kW
Required cooling air flow		39 l/s	39 l/s
Cross section of line and motor cables		25 ... 50 mm <sup>2</sup> 3 ... 1 AWG	25 ... 50 mm <sup>2</sup> 3 ... 1 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight		35.8 kg	35.8 kg

Table 10- 21 PM230, IP55, Frame Sizes F, 3 AC 380 V ... 480 V

<b>Order No. - with filter, Class A</b>	<b>6SL3223-...</b>	<b>...0DE35-5AA0</b>	<b>...0DE37-5AA0</b>	<b>...0DE38-8AA0</b>
<b>Order No. - with filter Class B</b>	<b>6SL3223-...</b>	<b>...0DE35-5BA0</b>	<b>...0DE37-5BA0</b>	<b>...0DE38-8BA0</b>
LO base load power		55 kW	75 kW	90 kW
LO base load input current		102 A	135 A	166 A
LO base load output current		110 A	145 A	178 A
HO base load power		45 kW	55 kW	75 kW
HO base load input current		84 A	102 A	135 A
HO base load output current		90 A	110 A	145 A
Fuse according to IEC		3NA3836	3NA3140	3NA3144
Fuse according to UL		160 A, Class J	200 A, Class J	250 A, Class J
Power loss		1.4 kW	1.9 kW	2.3 kW
Required cooling air flow		117 l/s	117 l/s	117 l/s
Cross section of line and motor cables		35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG
Tightening torque for line and motor cables		13 Nm / 115 lbf in	13 Nm / 115 lbf in	13 Nm / 115 lbf in
Weight		70.0 kg	70.0 kg	70.0 kg

## Current reduction depending on pulse frequency

Table 10- 22 Current reduction depending on the pulse frequency<sup>1)</sup>

LO base load	Output base-load current at a pulse frequency of							
	2 kHz	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
kW	A	A	A	A	A	A	A	A
0.37	--	1.30	1.11	0.91	0.78	0.65	0.59	0.52
0.55	--	1.70	1.45	1.19	1.02	0.85	0.77	0.68
0.75	--	2.20	1.87	1.54	1.32	1.10	0.99	0.88
1.1	--	3.10	2.64	2.17	1.86	1.55	1.40	1.24
1.5	--	4.10	3.49	2.87	2.46	2.05	1.85	1.64
2.2	--	5.90	5.02	4.13	3.54	2.95	2.66	2.36
3.0	--	7.70	6.55	5.39	4.62	3.85	3.47	3.08
4.0	--	10.20	8.67	7.14	6.12	5.10	4.59	4.08
5.5	--	13.20	11.22	9.24	7.92	6.60	5.94	5.28
7.5	--	18.00	15.30	12.60	10.80	9.00	8.10	7.20
11.0	--	26.00	22.10	18.20	15.60	13.00	11.70	10.40
15.0	--	32.00	27.20	22.40	19.20	16.00	14.40	12.80
18.5	--	38.00	32.30	26.60	22.80	19.00	17.10	15.20
22	--	45.00	38.25	31.50	27.00	22.50	20.25	18.00
30	--	60.00	51.00	42.00	36.00	30.00	27.00	24.00
37	--	75.00	63.75	52.50	45.00	37.50	33.75	30.00
45	--	90.00	76.50	63.00	54.00	45.00	40.50	36.00
55	--	110.0	93.50	77.00	66.00	55.00	49.50	44.00
75	--	145.0	123.3	101.5	--	--	--	--

<sup>1)</sup> The permissible motor cable length also depends on the cable type and the selected pulse frequency.

## 10.2.2 Technical data, PM240-2

### Typical inverter load cycles




Figure 10-3 "Low Overload" and "High Overload" load cycles

### 10.2.2.1 General data, PM240-2 - 200 V

Property	Version
Line voltage	FSA ... FSC 200 V ... 240 V 1-ph. AC $\pm 10\%$ for LO base load power 0.55 kW ... 4 kW for HO base load power 0.37 kW ... 3 kW
	200 V ... 240 V 3-ph. AC $\pm 10\%$ for LO base load power 0.55 kW ... 7.5 kW for HO base load power 0.37 kW ... 5.5 kW
	FSD ... FSE 200 V ... 240 V 3-ph. AC $-20\% / +10\%$
Output voltage	3 AC 0 V ... 0.95 x input voltage (max.)
Input frequency	50 Hz ... 60 Hz, $\pm 3$ Hz
Output frequency	0 ... 550 Hz, depending on the control mode
Line impedance	FSA ... FSC: $U_k \geq 2\%$ , for lower values, we recommend a line reactor, or a Power Module with the next higher power rating. Not applicable for FSD and FSE
Power factor $\lambda$	FSA ... FSC 0.7 without line reactor for $U_k \geq 2\%$ 0.85 with line reactor for $U_k < 2\%$ FSD ... FSE 0.95 line reactor is not required
Inrush current	< LO base load input current
Overvoltage category acc. to EN 60664-1	The inverter insulation is designed for surge voltages according to overvoltage Category III.
Pulse frequency	4 kHz (factory setting), Can be set in 2 kHz steps in the range from 2 kHz ... 16 kHz. If you increase the pulse frequency, the inverter reduces the maximum output current.
Short-circuit current rating (SCCR)	$\leq 65$ kA rms
Electromagnetic compatibility	Devices with integrated filter are suitable for Category C2 environments according to IEC/EN 61800-3.
Braking methods	DC braking, compound braking, dynamic braking with integrated braking chopper

Property	Version						
Degree of protection according to EN 60529	<table border="0"> <tr> <td>Chassis devices</td> <td>IP20</td> <td>Must be installed in a control cabinet</td> </tr> <tr> <td>PT devices</td> <td>IP20, IP54</td> <td>Must be installed in a control cabinet at the control cabinet panel</td> </tr> </table>	Chassis devices	IP20	Must be installed in a control cabinet	PT devices	IP20, IP54	Must be installed in a control cabinet at the control cabinet panel
Chassis devices	IP20	Must be installed in a control cabinet					
PT devices	IP20, IP54	Must be installed in a control cabinet at the control cabinet panel					
Ambient temperature for	<table border="0"> <tr> <td>LO base load power without derating:</td> <td>-20 °C ... +40 °C</td> </tr> <tr> <td>HO base load power without derating:</td> <td>-20 °C ... +50 °C</td> </tr> <tr> <td>LO/HO base load power with derating:</td> <td>-20 °C ... + 60° C</td> </tr> </table> <p>Details see Section Restrictions for special ambient conditions (Page 428). For the maximum permissible ambient temperature, also observe the permissible ambient temperatures for the Control Unit and possibly operator panel (IOP or BOP-2) .</p>	LO base load power without derating:	-20 °C ... +40 °C	HO base load power without derating:	-20 °C ... +50 °C	LO/HO base load power with derating:	-20 °C ... + 60° C
LO base load power without derating:	-20 °C ... +40 °C						
HO base load power without derating:	-20 °C ... +50 °C						
LO/HO base load power with derating:	-20 °C ... + 60° C						
Ambient conditions according to EN 60721-3-3	<table border="0"> <tr> <td>FSA ... FSC</td> <td>Protected against damaging chemical substance, according to environmental Class 3C2</td> </tr> <tr> <td>FSD ... FSE</td> <td>Protected against damaging chemical substance, according to environmental Class 3C3</td> </tr> </table>	FSA ... FSC	Protected against damaging chemical substance, according to environmental Class 3C2	FSD ... FSE	Protected against damaging chemical substance, according to environmental Class 3C3		
FSA ... FSC	Protected against damaging chemical substance, according to environmental Class 3C2						
FSD ... FSE	Protected against damaging chemical substance, according to environmental Class 3C3						
Temperature during storage according to EN 60721-3-3	-40 °C ... +70 °C						
Cooling air	clean and dry air						
Relative humidity	< 95% - condensation not permissible						
Pollution according to EN 61800-5-1	suitable for environments with degree of pollution 2						
Shocks and vibration according to EN 60721-3-1	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2</li> <li>• Transport in the transport packaging according to Class 2M3</li> <li>• Vibration in operation according to Class 3M2</li> </ul>						
Installation altitude	<table border="0"> <tr> <td>without derating</td> <td>up to 1000 m above sea level</td> </tr> <tr> <td>with derating</td> <td>up to 4000 m above sea level</td> </tr> </table> <p>Details see Section Restrictions for special ambient conditions (Page 428).</p>	without derating	up to 1000 m above sea level	with derating	up to 4000 m above sea level		
without derating	up to 1000 m above sea level						
with derating	up to 4000 m above sea level						
Approvals	<table border="0"> <tr> <td>FSA ... FSC</td> <td>cULus, CE, C-tick, KCC</td> </tr> <tr> <td>FSD ... FSE</td> <td>cULus, CE, C-tick, SEMI F47, KCC, WEEE, RoHS, EAC</td> </tr> </table>	FSA ... FSC	cULus, CE, C-tick, KCC	FSD ... FSE	cULus, CE, C-tick, SEMI F47, KCC, WEEE, RoHS, EAC		
FSA ... FSC	cULus, CE, C-tick, KCC						
FSD ... FSE	cULus, CE, C-tick, SEMI F47, KCC, WEEE, RoHS, EAC						

### 10.2.2.2 Power-dependent data, PM240-2 - 200 V

Table 10- 23 PM240-2, IP20, frame sizes A, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210...	...1PB13-0UL0	...1PB13-8UL0
Article No. - with filter	6SL3210...	...1PB13-0AL0	...1PB13-8AL0
LO base load power		0.55 kW	0.75 kW
LO base load input current 1 AC		7.5 A	9.6 A
LO base load input current 3 AC		4.2 A	5.5 A
LO base load output current		3.2 A	4.2 A
HO base load power		0.37 kW	0.55 kW
HO base load input current 1 AC		6.6 A	8.4 A
HO base load input current 3 AC		3.0 A	4.2 A
HO base load output current		2.3 A	3.2 A
Fuse according to IEC		3NA3 803 (10 A)	3NA3 805 (16 A)
Fuse according to UL		15 A Class J	15 A Class J
Power losses without filter		0.04 kW	0.04 kW
Power losses with filter		0.04 kW	0.04 kW
Required cooling air flow		5 l/s	5 l/s
Weight without filter		1.4 kg	1.4 kg
Weight with filter		1.6 kg	1.6 kg

Table 10- 24 PM240-2, PT, frame sizes A, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3211...	...1PB13-8UL0
Article No. - with filter	6SL3211...	...1PB13-8AL0
LO base load power		0.75 kW
LO base load input current 1 AC		9.6 A
LO base load input current 3 AC		5.5 A
LO base load output current		4.2 A
HO base load power		0.55 kW
HO base load input current 1 AC		8.4 A
HO base load input current 3 AC		4.2 A
HO base load output current		3.2 A
Fuse according to IEC		3NA3 805 (16 A)
Fuse according to UL		15 A Class J
Power losses without filter		0.04 kW
Power losses with filter		0.04 kW
Required cooling air flow		5 l/s
Weight without filter		1.8 kg
Weight with filter		2.0 kg

Table 10- 25 PM240-2, IP20, frame sizes B, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210...	...1PB15-5UL0	...1PB17-4UL0	...1PB21-0UL0
Article No. - with filter	6SL3210...	...1PB15-5AL0	...1PB17-4AL0	...1PB21-0AL0
LO base load power		1.1 kW	1.5 kW	2.2 kW
LO base load input current 1 AC		13.5 A	18.1 A	24.0 A
LO base load input current 3 AC		7.8 A	9.7 A	13.6 A
LO base load output current		6 A	7.4 A	10.4 A
HO base load power		0.75 kW	1.1 kW	1.5 kW
HO base load input current 1 AC		11.8 A	15.8 A	20.9 A
HO base load input current 3 AC		5.5 A	7.8 A	9.7 A
HO base load output current		4.2 A	6 A	7.4 A
Fuse according to IEC		3NE 1814-0 (20 A)	3NE 1815-0 (25 A)	3NE 1803-0 (35 A)
Fuse according to UL		35 A Class J	35 A Class J	35 A Class J
Power losses without filter		0.05 kW	0.07 kW	0.12 kW
Power losses with filter		0.05 kW	0.07 kW	0.12 kW
Required cooling air flow		9.2 l/s	9.2 l/s	9.2 l/s
Weight without filter		2.8 kg	2.8 kg	2.8 kg
Weight with filter		3.1 kg	3.1 kg	3.1 kg

Table 10- 26 PM240-2, PT, frame sizes B, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3211...	...1PB21-0UL0
Article No. - with filter	6SL3211...	...-1PB21-0AL0
LO base load power		2.2 kW
LO base load input current 1 AC		24.0 A
LO base load input current 3 AC		13.6 A
LO base load output current		10.4 A
HO base load power		1.5 kW
HO base load input current 1 AC		20.9 A
HO base load input current 3 AC		9.7 A
HO base load output current		7.4 A
Fuse according to IEC		3NE 1803-0 (35 A)
Fuse according to UL		35 A Class J
Power losses without filter		0.12 kW <sup>1)</sup>
Power losses with filter		0.12 kW <sup>1)</sup>
Required cooling air flow		9.2 l/s
Weight without filter		3.4 kg
Weight with filter		3.7 kg

1) approx. 0.08 through the heatsink

Technical data

10.2 Technical data, Power Modules

Table 10- 27 PM240-2, IP 20, frame sizes C, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210...	...1PB21-4UL0	...1PB21-8UL0
Article No. - with filter	6SL3210...	...1PB21-4AL0	...1PB21-8AL0
LO base load power		3 kW	4 kW
LO base load input current 1 AC		35.9 A	43.0 A
LO base load input current 3 AC		17.7 A	22.8 A
LO base load output current		13.6 A	17.5 A
HO base load power		2.2 kW	3 kW
HO base load input current 1 AC		31.3 A	37.5 A
HO base load input current 3 AC		13.6 A	17.7 A
HO base load output current		10.4 A	13.6 A
Fuse according to IEC		3NE 1817-0 (50 A)	3NE 1818-0 (63 A)
Fuse according to UL		50 A Class J	50 A Class J
Power losses without filter		0.14 kW	0.18 kW
Power losses with filter		0.14 kW	0.18 kW
Required cooling air flow		18.5 l/s	18.5 l/s
Weight without filter		5.0 kg	5.0 kg
Weight with filter		5.2 kg	5.2 kg

Table 10- 28 PM240-2, PT, frame sizes C, 1 AC / 3 AC 200 V ... 240 V

Article No. - without filter	6SL3211...	...1PB21-8UL0
Article No. - with filter	6SL3211...	...1PB21-8AL0
LO base load power		4 kW
LO base load input current 1 AC		43.0 A
LO base load input current 3 AC		22.8 A
LO base load output current		17.5 A
HO base load power		3 kW
HO base load input current 1 AC		37.5 A
HO base load input current 3 AC		17.7 A
HO base load output current		13.6 A
Fuse according to IEC		3NE 1818-0 (63 A)
Fuse according to UL		50 A Class J
Power losses without filter		0.18 kW <sup>1)</sup>
Power losses with filter		0.18 kW <sup>1)</sup>
Required cooling air flow		18.5 l/s
Weight without filter		5.9 kg
Weight with filter		6.2 kg

1) approx. 0.09 through the heatsink

Table 10- 29 PM240-2, IP 20, frame sizes C, 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210...	...1PC22-2UL0	...1PC22-8UL0
Article No. - with filter	6SL3210...	...1PC22-2AL0	...1PC22-8AL0
LO base load power		5.5 kW	7.5 kW
LO base load input current		28.6 A	36.4 A
LO base load output current		22.0 A	28.0 A
HO base load power		4 kW	5.5 kW
HO base load input current		22.8 A	28.6 A
HO base load output current		17.5 A	22.0 A
Fuse according to IEC		3NE 1802-0 (40 A)	3NE 1817-0 (50 A)
Fuse according to UL		50 A Class J	50 A Class J
Power losses without filter		0.2 kW	0.26 kW
Power losses with filter		0.2 kW	0.26 kW
Required cooling air flow		18.5 l/s	18.5 l/s
Weight without filter		5.0 kg	5.0 kg
Weight with filter		5.2 kg	5.2 kg

Table 10- 30 PM240-2, IP20, FSD, 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210-...	...1PC24-2UL0	...1PC25-4UL0	...1PC26-8UL0
LO base load power		11 kW	15 kW	18.5 kW
LO base load input current		40 A	51 A	64 A
LO base load output current		42 A	54 A	68 A
HO base load power		7.5 kW	11 kW	15 kW
HO base load input current		36 A	43 A	56 A
HO base load output current		35 A	42 A	54 A
Siemens fuse according to IEC/UL		3NE1818-0 / 63A	3NE1 820-0 / 80A	3NE1 021-0 / 100A
Fuse according to IEC/UL, Class J		60 A	80A	90 A
Power loss		0.42 kW	0.57 kW	0.76 kW
Required cooling air flow		55 l/s	55 l/s	55 l/s
Weight		17 kg	17 kg	17 kg

Table 10- 31 PM240-2, IP20, FSE, 3 AC 200 V ... 240 V

Article No. - without filter	6SL3210-...	...1PC28-8UL0	...1PC31-1UL0
LO base load power		22 kW	30 kW
LO base load input current		76 A	98 A
LO base load output current		80 A	104 A
HO base load power		18.5 kW	22 kW
HO base load input current		71 A	83 A
HO base load output current		68 A	80 A
Siemens fuse according to IEC/UL		3 NE1 021-0 / 100A	3 NE1 224-0 / 160A
Fuse according to IEC/UL, Class J		100 A	150 A
Power loss		0.85 kW	1.20 kW
Required cooling air flow		83 l/s	83 l/s
Weight		26 kg	26 kg

Current derating depending on the pulse frequency

Current derating depending on the pulse frequency <sup>1)</sup> for 200 V devices

Article number	LO base load output current for a pulse frequency of ... [A]						
	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
6SL3210-1PB13-0□L0	<b>3.2</b>	2.6	2.1	1.8	1.5	1.4	1.2
6SL321□-1PB13-8□L0	<b>4.2</b>	3.3	2.7	2.3	2.0	1.8	1.6
6SL3211-1PB15-5□L0	<b>6.0</b>	4.7	3.9	3.3	2.8	2.5	2.2
6SL3210-1PB17-4□L0	<b>7.4</b>	6.3	5.2	4.4	3.7	3.3	3.0
6SL321□-1PB21-0□L0	<b>10.4</b>	8.8	7.3	6.2	5.2	4.7	4.2
6SL3210-1PB21-4□L0	<b>13.6</b>	11.6	9.5	8.2	6.8	6.1	5.4
6SL321□-1PB21-8□L0	<b>17.5</b>	14.9	12.3	10.5	8.8	7.9	7.0
6SL3210-1PC22-2□L0	<b>22.0</b>	18.7	15.4	13.2	11.0	9.9	8.8
6SL3210-1PC22-8□L0	<b>28.0</b>	23.8	19.6	16.8	14.0	12.6	11.2
6SL3210-1PC24-2□L0	<b>42</b>	35.7	29.4	25.2	21.0	18.9	16.8
6SL3210-1PC25-4□L0	<b>54</b>	45.9	37.8	32.4	27.0	24.3	21.6
6SL3210-1PC26-8□L0	<b>68</b>	57.8	47.6	40.8	34.0	30.6	27.2
6SL3210-1PC28-8□L0	<b>80</b>	68.0	56.0	48.0	40.0	36.0	32.0
6SL3210-1PC31-1□L0	<b>104</b>	88.4	72.8	62.4	52.0	46.8	41.6
<sup>1)</sup> The permissible motor cable length also depends on the cable type and the selected pulse frequency.							

### 10.2.2.3 General data, PM240-2 - 400V

Property	Version
Line voltage	FSA ... FSC 380 V ... 480 V 3-ph. AC $\pm$ 10 %
	FSD ... FSE 3 AC 380 V ... 480 V -20 %, +10 %
Output voltage	3 AC 0 V ... 0.95 x input voltage (max.)
Input frequency	50 Hz ... 60 Hz, $\pm$ 3 Hz
Output frequency	0 ... 550 Hz, depending on the control mode
Line impedance	$U_k \geq 1$ %, for lower values, we recommend a line reactor, or a Power Module with the next higher power rating.
Power factor $\lambda$	FSA ... FSC 0.7 without line reactor for $U_k \geq 1$ % 0.85 with line reactor for $U_k < 1$ %
	FSD ... FSE 0.95 (line reactor not required)
Inrush current	< LO base load input current
Overvoltage category acc. to EN 60664-1	The inverter insulation is designed for surge voltages according to overvoltage Category III.
Pulse frequency	4 kHz (factory setting) Can be adjusted in 2 kHz steps in the range from 2 kHz ... 16 kHz. Restriction: from a LO base load power of 55 kW up to 8 kHz. The output current is reduced if you increase the pulse frequency.
Short-circuit current rating (SCCR)	$\leq 65$ kA rms
Electromagnetic compatibility according to IEC/EN 61800-3	Devices with integrated filter are suitable for Category C2 environments.
Braking methods	DC braking, compound braking, dynamic braking with integrated braking chopper
Degree of protection according to EN 60529	Chassis devices IP20 Must be installed in a control cabinet
	PT devices IP20, IP54 Must be installed in a control cabinet at the control cabinet panel
Ambient temperature for	LO base load power without derating: -20 °C ... +40 °C
	HO base load power without derating: -20 °C ... +50 °C
	LO/HO base load power with derating: -20 °C ... +60 °C
	Details see Section Power-dependent data, PM240-2 - 400 V (Page 397). For the maximum permissible ambient temperature, also observe the permissible ambient temperatures for the Control Unit and possibly operator panel (IOP or BOP-2) .
Ambient conditions according to EN 60721-3-3	FSA ... FSC: Protected against damaging chemical substance, according to environmental Class 3C2
	FSD ... FSE Protected against damaging chemical substance, according to environmental Class 3C3
Temperature during storage according to EN 60721-3-3	-40 °C ... +70 °C
Cooling air	clean and dry air
Relative humidity	< 95% - condensation not permissible
Pollution according to EN 61800-5-1	suitable for environments with degree of pollution 2

*Technical data*

*10.2 Technical data, Power Modules*

---

<b>Property</b>	<b>Version</b>
Shocks and vibration according to EN 60721-3-1	<ul style="list-style-type: none"><li>• Long-term storage in the transport packaging according to Class 1M2</li><li>• Transport in the transport packaging according to Class 2M3</li><li>• Vibration in operation according to Class 3M2</li></ul>
Installation altitude	without derating: up to 1000 m above sea level with derating: up to 4000 m above sea level Details see Section Restrictions for special ambient conditions (Page 428).
Approvals	FSA ... FSC cULus, CE, C-tick, KCC FSD ... FSE cULus, CE, C-tick, SEMI F47, KCC, WEEE, RoHS, EAC

---

### 10.2.2.4 Power-dependent data, PM240-2 - 400 V

Table 10- 32 PM240-2, IP20, frame sizes A, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3210...	...1PE11-8UL1	...1PE12-3UL1	...1PE13-2UL1
Article No. - with filter	6SL3210...	...1PE11-8AL1	...1PE12-3AL1	...1PE13-2AL1
LO base load power		0.55 kW	0.75 kW	1.1 kW
LO base load input current		2.3 A	2.9 A	4.1 A
LO base load output current		1.7 A	2.2 A	3.1 A
HO base load power		0.37 kW	0.55 kW	0.75 kW
HO base load input current		2.0 A	2.6 A	3.3 A
HO base load output current		1.3 A	1.7 A	2.2 A
Fuse according to IEC		3NA3 804 (4 A)	3NA3 804 (4 A)	3NA3 801 (6 A)
Fuse according to UL		10 A Class J	10 A Class J	15 A Class J
Power loss		0.04 kW	0.04 kW	0.04 kW
Required cooling air flow		5 l/s	5 l/s	5 l/s
Weight without filter		1.3 kg	1.3 kg	1.3 kg
Weight with filter		1.5 kg	1.5 kg	1.5 kg

Table 10- 33 PM240-2, IP20, frame sizes A, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3210...	...1PE14-3UL1	...1PE16-1UL1	...1PE18-0UL1
Article No. - with filter	6SL3210...	...1PE14-3AL1	...1PE16-1AL1	...1PE18-0AL1
LO base load power		1.5 kW	2.2 kW	3.0 kW
LO base load input current		5.5 A	7.7 A	10.1 A
LO base load output current		4.1 A	5.9 A	7.7 A
HO base load power		1.1 kW	1.5 kW	2.2 kW
HO base load input current		4.7 A	6.1 A	8.8 A
HO base load output current		3.1 A	4.1 A	5.9 A
Fuse according to IEC		3NA3 803 (10 A)	3NA3 803 (10 A)	3NA3 805 (16 A)
Fuse according to UL		20 A Class J	30 A Class J	30 A Class J
Power loss		0.07 kW	0.1 kW	0.12 kW
Required cooling air flow		5 l/s	5 l/s	5 l/s
Weight without filter		1.4 kg	1.4 kg	1.4 kg
Weight with filter		1.6 kg	1.6 kg	1.6 kg

10.2 Technical data, Power Modules

Table 10- 34 PM240-2, PT, frame sizes A, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3211...	...1PE18-0UL1
Article No. - with filter	6SL3211...	...1PE18-0AL1
LO base load power		3.0 kW
LO base load input current		10.1 A
LO base load output current		7.7 A
HO base load power		2.2 kW
HO base load input current		8.8 A
HO base load output current		5.9 A
Fuse according to IEC		3NA3 805 (16 A)
Fuse according to UL		30 A Class J
Power loss without filter		0.12 kW <sup>1)</sup>
Required cooling air flow		7 l/s
Weight without filter		1.8 kg
Weight with filter		2.0 kg

1) approx. 0.1 kW through the heatsink

Table 10- 35 PM240-2, IP20, frame sizes B, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3210...	...1PE21-1UL0	...1PE21-4UL0	...1PE21-8UL0
Article No. - with filter	6SL3210...	...1PE21-1AL0	...1PE21-4AL0	...1PE21-8AL0
LO base load power		4.0 kW	5.5 kW	7.5 kW
LO base load input current		13.3 A	17.2 A	22.2 A
LO base load output current		10.2 A	13.2 A	18.0 A
HO base load power		3.0 kW	4.0 kW	5.5 kW
HO base load input current		11.6 A	15.3 A	19.8 A
HO base load output current		7.7 A	10.2 A	13.2 A
Fuse according to IEC		3NE 1814-0 (20 A)	3NE 1815-0 (25 A)	3NE 1803-0 (35 A)
Fuse according to UL		35 A Class J	35 A Class J	35 A Class J
Power loss		0.11 kW	0.15 kW	0.2 kW
Required cooling air flow		9.2 l/s	9.2 l/s	9.2 l/s
Weight without filter		2.9 kg	2.9 kg	3.0 kg
Weight with filter		3.1 kg	3.1 kg	3.2 kg

Table 10- 36 PM240-2, PT, frame sizes B, 3-ph. 380 V AC... 480 V

<b>Article No. - without filter</b>	<b>6SL3211...</b>	<b>...1PE21-8UL0</b>
<b>Article No. - with filter</b>	<b>6SL3211...</b>	<b>...1PE21-8AL0</b>
LO base load power		7.5 kW
LO base load input current		22.2 A
LO base load output current		18.0 A
HO base load power		5.5 kW
HO base load input current		19.8 A
HO base load output current		13.7 A
Fuse according to IEC		3NE 1803-0 (35 A)
Fuse according to UL		35 A Class J
Power loss		0.2 kW <sup>1)</sup>
Required cooling air flow		9.2 l/s
Weight without filter		3.6 kg
Weight with filter		3.9 kg

1) approx. 0.16 kW through the heatsink;

Table 10- 37 PM240-2, IP20, frame sizes C, 3-ph. 380 V AC... 480 V

<b>Article No. - without filter</b>	<b>6SL3210...</b>	<b>...1PE22-7UL0</b>	<b>...1PE23-3UL0</b>
<b>Article No. - with filter</b>	<b>6SL3210...</b>	<b>...1PE22-7AL0</b>	<b>...1PE23-3AL0</b>
LO base load power		11.0 kW	15.0 kW
LO base load input current		32.6 A	39.9 A
LO base load output current		26.0 A	32.0 A
HO base load power		7.5 kW	11.0 kW
HO base load input current		27.0 A	36.0 A
HO base load output current		18.0 A	26.0 A
Fuse according to IEC		3NE 1817-0 (50 A)	3NE 1817-0 (50 A)
Fuse according to UL		50 A Class J	50 A Class J
Power loss		0.3 kW	0.37 kW
Required cooling air flow		18.5 l/s	18.5 l/s
Weight without filter		4.7 kg	4.8 kg
Weight with filter		5.3 kg	5.4 kg

10.2 Technical data, Power Modules

Table 10- 38 PM240-2, PT, frame sizes C, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3211...	...1PE23-3UL0
Article No. - with filter	6SL3211...	...1PE23-3AL0
LO base load power		15.0 kW
LO base load input current		39.9 A
LO base load output current		32.0 A
HO base load power		11.0 kW
HO base load input current		36.0 A
HO base load output current		26.0 A
Fuse according to IEC		3NE 1817-0 (50 A)
Fuse according to UL		50 A Class J
Power loss		0.37 kW <sup>1)</sup>
Required cooling air flow		18.5 l/s
Weight without filter		5.8 kg
Weight with filter		6.3 kg

1) approx. 0.3 kW through the heatsink;

Table 10- 39 PM240-2, IP20, FSD, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210-...	...1PE23-8UL0	...1PE24-5UL0	...1PE26-0UL0
Article No. - with filter	6SL3210-...	...1PE23-8AL0	...1PE24-5AL0	...1PE26-0AL0
LO base load power		18.5 kW	22 kW	30 kW
LO base load input current		36 A	42 A	57 A
LO base load output current		38 A	45 A	60 A
HO base load power		15 kW	18.5 kW	22 kW
HO base load input current		33 A	38 A	47 A
HO base load output current		32 A	38 A	45 A
Siemens fuse according to IEC/UL		3NE1 818-0 / 63 A	3NE1 820-0 / 80 A	3NE1 021-0 / 100A
Fuse according to IEC/UL, Class J		60 A	70 A	90 A
Power loss without filter		0.55 kW	0.68 kW	0.76 kW
Power loss with filter		0.56 kW	0.68 kW	0.77 kW
Required cooling air flow		55 l/s	55 l/s	55 l/s
Weight without filter		16 kg	16 kg	17 kg
Weight with filter		17.5 kg	17.5 kg	18.5 kg

Table 10- 40 PM240-2, IP20, FSD, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210-...	...1PE27-5UL0
Article No. - with filter	6SL3210-...	...1PE27-5AL0
LO base load power		37 kW
LO base load input current		70 A
LO base load output current		75 A
HO base load power		30 kW
HO base load input current		62 A
HO base load output current		60 A
Siemens fuse according to IEC/UL	3NE1 021-0 / 100 A	
Fuse according to IEC/UL, Class J	100 A	
Power loss without filter		1.01 kW
Power loss with filter		1.02 kW
Required cooling air flow		55 l/s
Weight without filter		17 kg
Weight with filter		18.5 kg

Table 10- 41 PM240-2, IP20, FSE, 3 AC 380 V ... 480 V

Article No. - without filter	6SL3210-...	...1PE28-8UL0	...1PE31-1UL0
Article No. - with filter	6SL3210-...	...1PE28-8AL0	...1PE31-1AL0
LO base load power		45 kW	55 kW
LO base load input current		86 A	104 A
LO base load output current		90 A	110 A
HO base load power		37 kW	45 kW
HO base load input current		78 A	94 A
HO base load output current		75 A	90 A
Siemens fuse according to IEC/UL	3NE1 022-0 / 125A		3NE1 224-0 / 160A
Fuse according to IEC/UL, Class J	125 A		150 A
Power losses without filter		1.19 kW	1.54 kW
Power losses with filter		1.2 kW	1.55 kW
Required cooling air flow		83 l/s	83 l/s
Weight without filter		26kg	26 kg
Weight with filter		28 kg	28 kg

Current derating depending on the pulse frequency <sup>1)</sup> for 400 V devices

Article number	LO base load output current for a pulse frequency of ... [A]						
	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
6SL3210-1PE11-8□L1	<b>1.7</b>	1.4	1.2	1.0	0.9	0.8	0.7
6SL3210-1PE12-3□L1	<b>2.2</b>	1.9	1.5	1.3	1.1	1.0	0.9
6SL3211-1PE13-2□L1	<b>3.1</b>	2.6	2.2	1.9	1.6	1.4	1.2
6SL3210-1PE14-3□L1	<b>4.1</b>	3.5	2.9	2.5	2.1	1.8	1.6
6SL3210-1PE16-1□L1	<b>5.9</b>	5.0	4.1	3.5	3.0	2.7	2.4
6SL321□-1PE18-0□L1	<b>7.7</b>	6.5	5.4	4.6	3.9	3.5	3.1
6SL3210-1PE21-1□L0	<b>10.2</b>	8.7	7.1	6.1	5.1	4.6	4.1
6SL3210-1PE21-4□L0	<b>13.2</b>	11.2	9.2	7.9	6.6	5.9	5.3
6SL321□-1PE21-8□L0	<b>18.0</b>	15.3	12.6	10.8	9.0	8.1	7.2
6SL3210-1PE22-7□L0	<b>26.0</b>	22.1	18.2	15.6	13.0	11.7	10.4
6SL321□-1PE23-3□L0	<b>32.0</b>	27.2	22.4	19.2	16	14.4	12.8
6SL3210-1PE23-8□L0	<b>38</b>	32.3	26.6	22.8	19.0	17.1	15.2
6SL3210-1PE24-5□L0	<b>45</b>	38.3	31.5	27.0	22.5	20.3	18.0
6SL3210-1PE26-0□L0	<b>60</b>	51.0	42.0	36.0	30.0	27.0	24.0
6SL3210-1PE27-5□L0	<b>75</b>	63.8	52.5	45.0	37.5	33.8	30.0
6SL3210-1PE28-8□L0	<b>90</b>	76.5	63.0	54.0	45.0	40.5	36.0
6SL3210-1PE31-1□L0	<b>110</b>	93.5	77.0	66.0	55.0	49.5	44.0
<sup>1)</sup> The permissible motor cable length also depends on the cable type and the selected pulse frequency.							

### 10.2.2.5 General data, PM240-2 - 690 V

Property	Version
Line voltage	3 AC 500 V ... 690 V -20% ... +10 %
Output voltage	3 AC 0 V ... 0.95 x input voltage (max.)
Input frequency	50 Hz ... 60 Hz, ± 3 Hz
Output frequency	0 ... 550 Hz, depending on the control mode
Power factor λ	> 0.9
Inrush current	< LO base load input current
Overvoltage category acc. to EN 60664-1	The inverter insulation is designed for surge voltages according to overvoltage Category III.
Pulse frequency	2 kHz (factory setting), can be adjusted to 4 kHz The output current is reduced if you increase the pulse frequency.
Short-circuit current rating (SCCR)	≤ 65 kA rms
Electromagnetic compatibility according to IEC/EN 61800-3	Devices with integrated filter are suitable for Category C2 environments.
Braking methods	DC braking, compound braking, dynamic braking with integrated braking chopper
Degree of protection according to EN 60529	IP20; must be installed in a control cabinet
Ambient temperature for	LO base load power without derating: -20 °C ... +40 °C HO base load power without derating: -20 °C ... +50 °C LO/HO base load power with derating: -20 °C ... + 60 °C Details see Section Restrictions for special ambient conditions (Page 428). For the maximum permissible ambient temperature, also observe the permissible ambient temperatures for the Control Unit and possibly operator panel (IOP or BOP-2) .
Ambient conditions according to EN 60721-3-3	Protected against damaging chemical substance, according to environmental Class 3C3
Temperature during storage according to EN 60721-3-3	-40 °C ... +70 °C
Cooling air	clean and dry air
Relative humidity	< 95% - condensation not permissible
Pollution according to EN 61800-5-1	suitable for environments with degree of pollution 2
Shocks and vibration according to EN 60721-3-1	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2</li> <li>• Transport in the transport packaging according to Class 2M3</li> <li>• Vibration in operation according to Class 3M2</li> </ul>
Installation altitude	without derating: up to 1000 m above sea level with derating: up to 4000 m above sea level Details see Section Restrictions for special ambient conditions (Page 428).
Approvals	cULus, CE, C-tick, SEMI F47, KCC, WEEE, RoHS, EAC

### 10.2.2.6 Power-dependent data, PM240-2 - 690 V

Table 10- 42 PM240-2, IP20, FSD, 3 AC 500 V ... 690 V

Article No. - without filter	6SL3210-...	...1PH21-4UL0	...1PH22-0UL0	...1PH22-3UL0
Article No. - with filter	6SL3210-...	...1PH21-4AL0	...1PH22 -0AL0	...1PH22 -3AL0
LO base load power		11 kW	15 kW	18.5 kW
LO base load input current		14 A	18 A	22 A
LO base load output current		14 A	19 A	23 A
HO base load power		7.5 kW	11 kW	15 kW
HO base load input current		11 A	14 A	20 A
HO base load output current		11 A	14 A	19 A
Siemens fuse according to IEC/UL		3NE1 815-0 / 25 A	3NE1 815-0 / 25 A	3NE1 803-0 / 32 A
Fuse according to IEC/UL, Class J		20 A	25 A	30 A
Power loss without filter		0.32 kW	0.41 kW	0.48 kW
Power loss with filter		0.32 kW	0.41 kW	0.48 kW
Required cooling air flow		55 l/s	55 l/s	55 l/s
Weight without filter		17 kg	17 kg	17 kg
Weight with filter		18.5 kg	18.5 kg	18.5 kg

Table 10- 43 PM240-2, IP20, FSD, 3 AC 500 V ... 690 V

Article No. - without filter	6SL3210-...	...1PH22-7UL0	...1PH23-5UL0	...1PH24-2UL0
Article No. - with filter	6SL3210-...	...1PH22 -7AL0	...1PH23 -5AL0	...1PH24 -2AL0
LO base load power		22 kW	30 kW	37 kW
LO base load input current		25 A	33 A	40 A
LO base load output current		27A	35 A	42 A
HO base load power		18.5 kW	22 kW	30 kW
HO base load input current		24 A	28 A	36 A
HO base load output current		23 A	27 A	35 A
Siemens fuse according to IEC/UL		3NE1 803 / 35 A	3NE1 817 / 50 A	3NE1 818 / 63 A
Fuse according to IEC/UL, Class J		35 A	45 A	60 A
Power loss without filter		0.56 kW	0.72 kW	0.88kW
Power loss with filter		0.56 kW	0.73kW	0.88 kW
Required cooling air flow		55 l/s	55 l/s	55 l/s
Weight without filter		17 kg	17 kg	17 kg
Weight with filter		18.5 kg	18.5 kg	18.5 kg

Table 10- 44 PM240-2, IP20, FSE, 3 AC 500 V ... 690 V

Article No. - without filter	6SL3210-...	...1PH25-2UL0	...1PH26-2UL0
Article No. - with filter	6SL3210-...	...1PH25-2AL0	...1PH26 -2AL0
LO base load power		45 kW	55 kW
LO base load input current		50 A	59 A
LO base load output current		52 A	62A
HO base load power		37 kW	45 kW
HO base load input current		44 A	54 A
HO base load output current		42 A	52 A
Siemens fuse according to IEC/UL		3NA1 820 / 80A	3NE1 820 / 80A
Fuse according to IEC/UL, Class J		80 A	80 A
Power loss without filter		1.00 kW	1.21 kW
Power loss with filter		1.00 kW	1.22 kW
Required cooling air flow		83 l/s	83 l/s
Weight without filter		26 kg	26 kg
Weight with filter		28 kg	28 kg

**Current derating depending on the pulse frequency <sup>1)</sup> for 690 V devices**

Article number	LO base load output current for a pulse frequency of ... [A]	
	2 kHz	4 kHz
6SL3210-1PH21-4□L0	14	8.4
6SL3210-1PH22-0□L0	19	11.4
6SL3210-1PH22-3□L0	23	13.8
6SL3210-1PH22-7□L0	27	16.2
6SL3210-1PH23-5□L0	35	21
6SL3210-1PH24-2□L0	42	25.2
6SL3210-1PH25-2□L0	52	31.2
6SL3210-1PH26-2□L0	62	37.2

<sup>1)</sup> The permissible motor cable length also depends on the cable type and the selected pulse frequency.

10.2.3 Technical data, PM240

Typical inverter load cycles




Figure 10-4 "High Overload" and "Low Overload" load cycles

### 10.2.3.1 General data, PM240

Property	Version		
Line voltage	380 V ... 480 V 3-ph. AC $\pm$ 10 %		
Output voltage	0 V 3-ph. AC ... input voltage x 0.95 (max.)		
Input frequency	50 Hz ... 60 Hz, $\pm$ 3 Hz		
Output frequency	0 Hz ... 550 Hz, depending on the control mode		
Power factor $\lambda$	0.7 ... 0.85		
Inrush current	< LO base load input current		
Pulse frequency (factory setting)	4 kHz for 0.37 kW ... 90 kW 2 kHz for 110 kW ... 250 kW Can be set in 2 kHz steps in the range from 2 kHz ... 16 kHz. If you increase the pulse frequency, the inverter reduces the maximum output current.		
Electromagnetic compatibility	The devices are suitable for environments, Categories C1 and C2 according to IEC/EN 61800-3: 2004.		
Braking methods	DC braking, compound braking, dynamic braking with integrated braking chopper		
Degree of protection	IP20 chassis units		
Ambient operating temperature	0 °C ... +40 °C	LO base load power	0.37 kW ... 250 kW
		HO base load power	132 kW ... 200 kW
	0 °C ... +50 °C	HO base load power	0.37 kW ... 110 kW
	Up to 60° C	with derating, see also Restrictions for special ambient conditions (Page 428)	
Storage temperature	-40 °C ... +70 °C		
Pollution	Protected according to pollution degree 2 to EN 61800-5-1: 2007		
Relative humidity	< 95% - condensation not permissible		
Environmental requirements	Protected against damaging chemical substances according to environmental class 3C2 to EN 60721-3-3; 1995		
Shock and vibration	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2 to EN 60721-3-1: 1997</li> <li>• Transport in the transport packaging according to Class 2M3 to EN 60721-3-2: 1997</li> <li>• Vibration during operation according to Class 3M2 to EN 60721-3-3: 1995</li> </ul>		
Installation altitude	up to 1000 m above sea level	0.37 kW ... 132 kW	
	up to 2000 m above sea level	160 kW ... 250 kW	
	up to 4000 m above sea level	with derating, see also Restrictions for special ambient conditions (Page 428)	
Standards	UL, cUL, CE, C-tick, SEMI F47 The drive only satisfies the UL requirements when UL-certified fuses are used.		

### 10.2.3.2 Power-dependent data, PM240

**Note**

The given input currents are valid for operation without a line reactor for a line voltage of 400 V with  $V_k = 1\%$  referred to the rated power of the inverter. If a line reactor is used, the specified values are reduced by a few percent.

**Note**

The values for Low Overload (LO) are identical with those of the rated values.

Table 10- 45 PM240, IP20, frame sizes A, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE13-7UA0	...0BE15-5UA0	...0BE17-5UA0
LO base load power		0.37 kW	0.55 kW	0.75 kW
LO base load input current		1.6 A	2.0 A	2.5 A
LO base load output current		1.3 A	1.7 A	2.2 A
HO base load power		0.37 kW	0.55 kW	0.75 kW
HO base load input current		1.6 A	2.0 A	2.5 A
HO base load output current		1.3 A	1.7 A	2.2 A
Fuse according to UL (from SIEMENS)		3NE1813-0, 16 A	3NE1813-0, 16 A	3NE1813-0, 16 A
Fuse according to UL (Class J, K-1 or K-5)		10 A	10 A	10 A
Power loss		0.097 kW	0.099 kW	0.102 kW
Required cooling air flow		4.8 l/s	4.8 l/s	4.8 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in
Weight		1.2 kg	1.2 kg	1.2 kg

Table 10- 46 PM240, IP20, frame sizes A, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE21-1UA0	...0BE21-5UA0
LO base load power		1.1 kW	1.5 kW
LO base load input current		3.9 A	4.9 A
LO base load output current		3.1 A	4.1 A
HO base load power		1.1 kW	1.5 kW
HO base load input current		3.8 A	4.8 A
HO base load output current		3.1 A	4.1 A
Fuse according to UL (from SIEMENS)		3NE1813-0, 16 A	3NE1813-0, 16 A
Fuse according to UL (Class J, K-1 or K-5)		10 A	10 A
Power loss		0.108 kW	0.114 kW
Required cooling air flow		4.8 l/s	4.8 l/s
Cross section of line and motor cables		1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG	1 ... 2.5 mm <sup>2</sup> 18 ... 14 AWG
Tightening torque for line and motor cables		0.5 Nm / 4 lbf in	0.5 Nm / 4 lbf in
Weight		1.1 kg	1.1 kg

Table 10- 47 PM240, IP20, frame sizes B, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE22-2UA0	...0BE23-0UA0	...0BE24-0UA0
Article No. - with filter	6SL3224-...	...0BE22-2AA0	...0BE23-0AA0	...0BE24-0AA0
LO base load power		2.2 kW	3 kW	4 kW
LO base load input current		7.6 A	10.2 A	13.4 A
LO base load output current		5.9 A	7.7 A	10.2 A
HO base load power		2.2 kW	3 kW	4 kW
HO base load input current		7.6 A	10.2 A	13.4 A
HO base load output current		5.9 A	7.7 A	10.2 A
Fuse according to UL (from SIEMENS)		3NE1813-0, 16 A	3NE1813-0, 16 A	3NE1814-0, 20 A
Fuse according to UL (Class J, K-1 or K-5)		16 A	16 A	20 A
Power loss		0.139 kW	0.158 kW	0.183 kW
Required cooling air flow		24 l/s	24 l/s	24 l/s
Cross section of line and motor cables		1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG	1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG	1.5 ... 6 mm <sup>2</sup> 16 ... 10 AWG
Tightening torque for line and motor cables		1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in	1.5 Nm / 13 lbf in
Weight		4.3 kg	4.3 kg	4.3 kg

Table 10- 48 PM240, IP20, frame sizes C, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE25-5UA0	...0BE27-5UA0	...0BE31-1UA0
Article No. - with filter	6SL3224-...	...0BE25-5AA0	...0BE27-5AA0	...0BE31-1AA0
LO base load power		7.5 kW	11 kW	15 kW
LO base load input current		21.9 A	31.5 A	39.4 A
LO base load output current		18 A	25 A	32 A
HO base load power		5.5 kW	7.5 kW	11 kW
HO base load input current		16.7 A	23.7 A	32.7 A
HO base load output current		13.2 A	19 A	26 A
Fuse according to UL (from SIEMENS)		3NE1814-0, 20 A	3NE1814-0, 20 A	3NE1803-0, 35 A
Fuse according to UL (Class J, K-1 or K-5)		20 A	20 A	35 A
Power loss		0.240 kW	0.297 kW	0.396 kW
Required cooling air flow		55 l/s	55 l/s	55 l/s
Cross section of line and motor cables		4 ... 10 mm <sup>2</sup> 12 ... 8 AWG	4 ... 10 mm <sup>2</sup> 12 ... 8 AWG	4 ... 10 mm <sup>2</sup> 12 ... 8 AWG
Tightening torque for line and motor cables		2.3 Nm / 20 lbf in	2.3 Nm / 20 lbf in	2.3 Nm / 20 lbf in
Weight without filter		6.5 kg	6.5 kg	6.5 kg
Weight with filter		7 kg	7 kg	7 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 49 PM240, IP20, frame sizes D, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE31-5UA0	...0BE31-8UA0	...0BE32-2UA0
Article No. - with filter	6SL3224-...	...0BE31-5AA0	...0BE31-8AA0	...0BE32-2AA0
LO base load power		18.5 kW	22 kW	30 kW
LO base load input current		46 A	53 A	72 A
LO base load output current		38 A	45 A	60 A
HO base load power		15 kW	18.5 kW	22 kW
HO base load input current		40 A	46 A	56 A
HO base load output current		32 A	38 A	45 A
Fuse according to UL (SIEMENS)		3NE1817-0	3NE1818-0	3NE1820-0
Fuse according to UL (Class J)		---	---	---
Power loss		0.44 kW 0.42 kW	0.55 kW 0.52 kW	0.72 kW 0.69 kW
Required cooling air flow		22 l/s	22 l/s	39 l/s
Cross section of line and motor cables		10 ... 35 mm <sup>2</sup> 7 ... 2 AWG	10 ... 35 mm <sup>2</sup> 7 ... 2 AWG	16 ... 35 mm <sup>2</sup> 5 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight without filter		13 kg	13 kg	13 kg
Weight with filter		16 kg	16 kg	16 kg

Table 10- 50 PM240, IP20, frame sizes E, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE33-0UA0	...0BE33-7UA0
Article No. - with filter	6SL3224-...	...0BE33-0AA0	...0BE33-7AA0
LO base load power		37 kW	45 kW
LO base load input current		88 A	105 A
LO base load output current		75 A	90 A
HO base load power		30 kW	37 kW
HO base load input current		73 A	90 A
HO base load output current		60 A	75 A
Fuse according to UL (SIEMENS)		3NE1021-0	3NE1022-0
Fuse according to UL (Class J)		---	---
Power losses without filter		0.99 kW	1.2 kW
Power losses with filter		1.04 kW	1.2 kW
Required cooling air flow		22 l/s	39 l/s
Cross section of line and motor cables		25 ... 35 mm <sup>2</sup> 3 ... 2 AWG	25 ... 35 mm <sup>2</sup> 3 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight without filter		16 kg	16 kg
Weight with filter		23 kg	23 kg

Table 10- 51 PM240, IP20, frame sizes F, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE34-5UA0	...0BE35-5UA0	...0BE37-5UA0
Article No. - with filter	6SL3224-...	...0BE34-5AA0	...0BE35-5AA0	...0BE37-5AA0
LO base load power		55 kW	75 kW	90 kW
LO base load input current		129 A	168 A	204 A
LO base load output current		110 A A	145 A	178 A
HO base load power		45 kW	55 kW	75 kW
HO base load input current		108 A	132 A	169 A
HO base load output current		90 A	110 A	145 A
Fuse according to UL (SIEMENS)		3NE1224-0	3NE1225-0	3NE1227-0
Fuse according to UL (Class J)		150 A, 600 V	200 A, 600 V	250 A, 600 V
Power losses without filter		1.4 kW	1.9 kW	2.3 kW
Power losses with filter		1.5 kW	2.0 kW	2.4 kW
Required cooling air flow		94 l/s	94 l/s	117 l/s
Cross section of line and motor cables		35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	70 ... 120 mm <sup>2</sup> 2/0 ... 4/0 AWG	95 ... 120 mm <sup>2</sup> 3/0 ... 4/0 AWG
Tightening torque for line and motor cables		13 Nm / 115 lbf in	13 Nm / 115 lbf in	13 Nm / 115 lbf in
Weight without filter		36 kg	36 kg	36 kg
Weight with filter		52 kg	52 kg	52 kg

Table 10- 52 PM240, IP20, frame sizes F, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0BE38-8UA0	...0BE41-1UA0
LO base load power		110 kW	132 kW
LO base load input current		234 A	284 A
LO base load output current		205 A	250 A
HO base load power		90 kW	110 kW
HO base load input current		205 A	235 A
HO base load output current		178 A	205 A
Fuse according to UL (SIEMENS)		3NE1227-0	3NE1230-0
Fuse according to UL (Class J)		300 A, 600 V	400 A, 600 V
Power loss		2.4 kW	2.5 kW
Required cooling air flow		117 l/s	117 l/s
Cross section of line and motor cables		95 ... 120 mm <sup>2</sup> 3/0 ... 4/0 AWG	95 ... 120 mm <sup>2</sup> 3/0 ... 4/0 AWG
Tightening torque for line and motor cables		13 Nm / 115 lbf in	13 Nm / 115 lbf in
Weight		39 kg	39 kg

Technical data

10.2 Technical data, Power Modules

Table 10- 53 PM240 frame sizes GX, 3-ph. 380 V AC... 480 V

Article No. - without filter	6SL3224-...	...0XE41-3UA0	...0XE41-6UA0	...0XE42-0UA0
LO base load power		160 kW	200 kW	240 kW
LO base load input current		297 A	354 A	442 A
LO base load output current		302 A	370 A	477 A
HO base load power		132 kW	160 kW	200 kW
HO base load input current		245 A	297 A	354 A
HO base load output current		250 A	302 A	370 A
Fuse according to UL (SIEMENS)		3NE1333-2	3NE1333-2	3NE1436-2
Fuse according to UL (Class J)		---	---	---
Power loss,		3.9 kW	4.4 kW	5.5 kW
Required cooling air flow		360 l/s	360 l/s	360 l/s
Cross section of line and motor cables		95 ... 2 x 240 mm <sup>2</sup> 3/0 ... 2 x 600 AWG	120 ... 2 x 240 mm <sup>2</sup> 4/0 ... 2 x 600 AWG	185 ... 2 x 240 mm <sup>2</sup> 6/0 ... 2 x 600 AWG
Tightening torque for line and motor cables		14 Nm / 120 lbf in	14 Nm / 120 lbf in	14 Nm / 120 lbf in
Weight		176 kg	176 kg	176 kg

**Relationship between pulse frequency and output base-load current reduction**

LO base load	Output base-load current at pulse frequency of							
	2 kHz	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
<b>kW</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
0.37	--	1.30	1.11	0.91	0.78	0.65	0.59	0.52
0.55	--	1.70	1.45	1.19	1.02	0.85	0.77	0.68
0.75	--	2.20	1.87	1.54	1.32	1.10	0.99	0.88
1.1	--	3.10	2.64	2.17	1.86	1.55	1.40	1.24
1.5	--	4.10	3.49	2.87	2.46	2.05	1.85	1.64
2.2	--	5.90	5.02	4.13	3.54	2.95	2.66	2.36
3.0	--	7.70	6.55	5.39	4.62	3.85	3.47	3.08
4.0	--	10.20	8.67	7.14	6.12	5.10	4.59	4.08
7.5	--	18.00	16.20	13.30	11.40	9.50	8.60	7.60
11.0	--	25.00	22.10	18.20	15.60	13.00	11.70	10.40
15.0	--	32.00	27.20	22.40	19.20	16.00	14.40	12.80
18.5	--	38.00	32.30	26.60	22.80	19.00	17.10	15.20
22	--	45.00	38.25	31.50	27.00	22.50	20.25	18.00
30	--	60.00	52.70	43.40	37.20	31.00	27.90	24.80
37	--	75.00	63.75	52.50	45.00	37.50	33.75	30.00
45	--	90.00	76.50	63.00	54.00	45.00	40.50	36.00
55	--	110.0	93.50	77.00	--	--	--	--
75	--	145.0	123.3	101.5	--	--	--	--
90	--	178.0	151.3	124.6	--	--	--	--
110	205.0	178.0	--	--	--	--	--	--
132	250.0	205.0	--	--	--	--	--	--
160	302.0	250.0	--	--	--	--	--	--
200	370.0	302.0	--	--	--	--	--	--
250	477.0	370.0	--	--	--	--	--	--

### 10.2.4 Technical data, PM250

#### Typical inverter load cycles




Figure 10-5 Load cycles "Low Overload" and "High Overload"

### 10.2.4.1 General data, PM250

Property	Version	
Line voltage	380 V ... 480 V 3-ph. AC $\pm$ 10 %	
Output voltage	0 V 3-ph. AC ... input voltage x 0.87 (max.)	
Input frequency	47 Hz ... 63 Hz	
Power factor $\lambda$	0.9	
Inrush current	< LO base load input current	
Pulse frequency (factory setting)	4 kHz The pulse frequency can be adjusted up to 16 kHz in 2 kHz steps. The higher the pulse frequency, the lower the available output current. For details, see Restrictions for special ambient conditions (Page 428).	
Electromagnetic compatibility	The devices comply with EN 61800-3: 2004 suitable for Category C1 and C2 environments.	
Braking methods	DC braking, energy recovery (up to 100% of the output power)	
Degree of protection	IP20 chassis units	
Operating temperature at	LO base load power without derating	0 °C ... +40 °C
	HO base load power without derating	0 °C ... +50 °C
	LO/HO base load power with derating:	Up to 60° C
	For details, see Restrictions for special ambient conditions (Page 428).	
Storage temperature	-40 °C ... +70 °C	
Relative humidity	< 95% - condensation not permissible	
Pollution	Protected according to pollution degree 2 to EN 61800-5-1: 2007	
Environmental requirements	Protected against damaging chemical substances according to environmental class 3C2 to EN 60721-3-3; 1995	
Shock and vibration	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2 to EN 60721-3-1: 1997</li> <li>• Transport in the transport packaging according to Class 2M3 to EN 60721-3-2: 1997</li> <li>• Vibration during operation according to Class 3M2 to EN 60721-3-3: 1995</li> </ul>	
Installation altitude	without derating:	up to 1000 m above sea level
	with derating:	up to 4000 m above sea level
For details, see Restrictions for special ambient conditions (Page 428)		
Standards	UL, CE, CE, SEMI F47 The drive only satisfies the UL requirements when UL-certified fuses are used.	

10.2.4.2 Power-dependent data, PM250

**Note**

The values for Low Overload (LO) are identical with those of the rated values.

Table 10- 54 PM250, IP20, frame sizes C, 3 AC 380 V ... 480 V

Article No. - with filter	6SL3225-...	0BE25-5AA0	0BE27-5AA0	0BE31-1AA0
LO base load power		7.5 kW	11 kW	15 kW
LO base load input current		18 A	25 A	32 A
LO base load output current		18 A	25 A	32 A
HO base load power		5.5 kW	7.5 kW	11 kW
HO base load input current		13.2 A	19 A	26 A
HO base load output current		13.2 A	19 A	26 A
Fuse		20 A, Class J	32 A, Class J	35 A, Class J
Power loss		0.24 kW	0.30 kW	0.31 kW
Required cooling air flow		38 l/s	38 l/s	38 l/s
Cross section of line and motor cables		2.5 ... 10 mm <sup>2</sup> 14 ... 8 AWG	4.0 ... 10 mm <sup>2</sup> 12 ... 8 AWG	4.0 ... 10 mm <sup>2</sup> 12 ... 8 AWG
Tightening torque for line and motor cables		2.3 Nm / 20 lbf in	2.3 Nm / 20 lbf in	2.3 Nm / 20 lbf in
Weight		7.5 kg	7.5 kg	7.5 kg

Table 10- 55 PM250, IP20, frame sizes D, 3 AC 380 V ... 480 V

Article No. - with filter	6SL3225-...	0BE31-5AA0	0BE31-8AA0	0BE32-2AA0
LO base load power		18.5 kW	22 kW	30 kW
LO base load input current		36 A	42 A	56 A
LO base load output current		38 A	45 A	60 A
HO base load power		15 kW	18.5 kW	22 kW
HO base load input current		30 A	36 A	42 A
HO base load output current		32 A	38 A	45 A
Fuse according to IEC		3NA3820	3NA3822	3NA3824
Fuse according to UL		50 A, Class J	63 A, Class J	80 A, Class J
Power loss		0.44 kW	0.55 kW	0.72 kW
Required cooling air flow		22 l/s	22 l/s	39 l/s
Cross section of line and motor cables		10 ... 35 mm <sup>2</sup> 7 ... 2 AWG	10 ... 35 mm <sup>2</sup> 7 ... 2 AWG	16 ... 35 mm <sup>2</sup> 6 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight		15 kg	15 kg	16 kg

Table 10- 56 PM250, IP20, frame sizes E, 3 AC 380 V ... 480 V

Article No. - with filter	6SL3225-...	0BE33-0AA0	0BE33-7AA0
LO base load power		37 kW	45 kW
LO base load input current		70 A	84 A
LO base load output current		75 A	90 A
HO base load power		30 kW	37 kW
HO base load input current		56 A	70 A
HO base load output current		60 A	75 A
Fuse according to IEC		3NA3830	3NA3832
Fuse according to UL		100 A, Class J	125 A, Class J
Power loss		1.04 kW	1.2 kW
Required cooling air flow		22 l/s	39 l/s
Cross section of line and motor cables		25 ... 35 mm <sup>2</sup> 3 ... 2 AWG	25 ... 35 mm <sup>2</sup> 3 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight		21 kg	21 kg

Table 10- 57 PM250, IP20, frame sizes F, 3 AC 380 V ... 480 V

Article No. - with filter	6SL3225-...	0BE34-5AA0	0BE35-5AA0	0BE37-5AA0
LO base load power		55 kW	75 kW	90 kW
LO base load input current		102 A	135 A	166 A
LO base load output current		110 A	145 A	178 A
HO base load power		45 kW	55 kW	75 kW
HO base load input current		84 A	102 A	135 A
HO base load output current		90 A	110 A	145 A
Fuse according to IEC		3NA3836	3NA3140	3NA3144
Fuse according to UL		160 A, Class J	200 A, Class J	250 A, Class J
Power loss		1.5 kW	2.0 kW	2.4 kW
Required cooling air flow		94 l/s	94 l/s	117 l/s
Cross section of line and motor cables		35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG	35 ... 120 mm <sup>2</sup> 2 ... 4/0 AWG
Tightening torque for line and motor cables		13 Nm / 115 lbf in	13 Nm / 115 lbf in	13 Nm / 115 lbf in
Weight		51 kg	51 kg	51 kg

**Relationship between pulse frequency and current reduction**

Table 10- 58 Current reduction depending on pulse frequency

Rated Power (LO)	Base load current (LO)	Base load current (LO) at pulse frequency of					
		4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz
kW	A	A	A	A	A	A	A
7.5	18.0	12.5	11.9	10.6	9.20	7.90	6.60
11	25.0	18.1	17.1	15.2	13.3	11.4	9.50
15	32.0	24.7	23.4	20.8	18.2	15.6	12.8
18.5	38.0	32.3	26.6	22.8	19.0	17.1	15.2
22	45.0	38.3	31.5	27.0	22.5	20.3	18.0
30	60.0	51.0	42.0	36.0	30.0	27.0	24.0
37	75.0	63.8	52.5	45.0	37.5	33.8	30.0
45	90.0	76.5	63.0	54.0	45.0	40.5	36.0
55	110	93.5	77.0	--	--	--	--
75	145	123	102	--	--	--	--
90	178	151	125	--	--	--	--

### 10.2.5 Technical data, PM260

#### Typical inverter load cycles




Figure 10-6 Load cycles "Low Overload" and "High Overload"

10.2.5.1 General data, PM260

Property	Version
Line voltage	660 V ... 690 V 3-ph. AC $\pm$ 10% The power units can also be operated with a minimum voltage of 500 V $-10$ %. In this case, the power is linearly reduced.
Input frequency	50 Hz ... 60 Hz, $\pm$ 3 Hz
Power factor $\lambda$	0.9
Inrush current	< LO base load input current
Pulse frequency	16 kHz
Electromagnetic compatibility	The devices comply with EN 61800-3: 2004 suitable for Category C1 and C2 environments.
Braking methods	DC braking, energy recovery (up to 100% of the output power)
Degree of protection	IP20 chassis units
Operating temperature at	LO base load power without derating 0 °C ... +40 °C
	HO base load power without derating 0 °C ... +50 °C
	LO/HO base load power with derating: Up to 60° C
	For details, see Restrictions for special ambient conditions (Page 428).
Storage temperature	-40 °C ... +70 °C
Relative humidity	< 95% - condensation not permissible
Pollution	Protected according to pollution degree 2 to EN 61800-5-1: 2007
Environmental requirements	Protected against damaging chemical substances according to environmental class 3C2 to EN 60721-3-3; 1995
Shock and vibration	<ul style="list-style-type: none"> <li>• Long-term storage in the transport packaging according to Class 1M2 to EN 60721-3-1: 1997</li> <li>• Transport in the transport packaging according to Class 2M3 to EN 60721-3-2: 1997</li> <li>• Vibration during operation according to Class 3M2 to EN 60721-3-3: 1995</li> </ul>
Installation altitude	without derating: up to 1000 m above sea level with derating: up to 4000 m above sea level For details, see Restrictions for special ambient conditions (Page 428)
Standards	CE, C-TICK

### 10.2.5.2 Power-dependent data, PM260

**Note**

The values for Low Overload (LO) are identical with those of the rated values.

Table 10- 59 PM260, IP20, frame sizes D - 3 AC 660 V ... 690 V

Article No. - without filter	6SL3225-...	0BH27-5UA1	0BH31-1UA1	0BH31-5UA1
Article No. - with filter	6SL3225-...	0BH27-5AA1	0BH31-1AA1	0BH31-5AA1
LO base load power		11 kW	15 kW	18.5 kW
LO base load input current		13 A	18 A	22 A
LO base load output current		14 A	19 A	23 A
HO base load power		7.5 kW	11 kW	15 kW
HO base load input current		10 A	13 A	18 A
HO base load output current		10 A	14 A	19 A
Fuse		20 A	20 A	32 A
Power losses without filter				
Power losses with filter				
Required cooling air flow		22 l/s	22 l/s	39 l/s
Cross section of line and motor cables		2.5 ... 16 mm <sup>2</sup> 14 ... 6 AWG	4 ... 16 mm <sup>2</sup> 12 ... 6 AWG	6 ... 16 mm <sup>2</sup> 10 ... 6 AWG
Tightening torque for line and motor cables		1.5 Nm / 53 lbf in	1.5 Nm / 53 lbf in	1.5 Nm / 53 lbf in
Weight without filter		22 kg	22 kg	22 kg
Weight with filter		23 kg	23 kg	23 kg
Sound pressure level		< 64 dB(A)	< 64 dB(A)	< 64 dB(A)

Table 10- 60 PM260, IP20, frame sizes F - 3 AC 660 V ... 690 V

Article No. - without filter	6SL3225-...	0BH32-2UA1	0BH33-0UA1	0BH33-7UA1
Article No. - with filter	6SL3225-...	0BH32-2AA1	0BH33-0AA1	0BH33-7AA1
LO base load power		30 kW	37 kW	55 kW
LO base load input current		34 A	41 A	60 A
LO base load output current		35 A	42 A	62 A
HO base load power		22 kW	30 kW	37 kW
HO base load input current		26 A	34 A	41 A
HO base load output current		26 A	35 A	42 A
Fuse		50 A	50 A	80 A
Power losses without filter				
Power losses with filter				
Required cooling air flow		94 l/s	94 l/s	117 l/s
Cross section of line and motor cables		10 ... 35 mm <sup>2</sup> 8 ... 2 AWG	16 ... 35 mm <sup>2</sup> 6 ... 2 AWG	25 ... 35 mm <sup>2</sup> 4 ... 2 AWG
Tightening torque for line and motor cables		6 Nm / 53 lbf in	6 Nm / 53 lbf in	6 Nm / 53 lbf in
Weight without filter		56 kg	56 kg	56 kg
Weight with filter		58 kg	58 kg	58 kg
Sound pressure level		< 70 dB(A)	< 70 dB(A)	< 70 dB(A)

### 10.2.6 PM330 technical data

#### Permissible inverter overload

The inverters have different load capabilities, "High Overload" and "Low Overload", depending on the expected.




Figure 10-7 Load cycles, "Low Overload" and "High Overload"

#### 10.2.6.1 PM330 general data

Table 10- 61 General technical data

<b>Electrical data</b>	
Line system configurations	Grounded TN/TT systems and non-grounded IT systems
Line requirement	A line reactor (2 % $u_k$ ) must be connected in series
Line voltage	380 V (-10 %) ... 480 V (+10 %)
Line frequency	47 ... 63 Hz
Output frequency	0 ... 100 Hz
Displacement factor $\cos \varphi$ power factor $\lambda$	0.96 0.75 ... 0.93 (with line reactor $u_k = 2\%$ )
Inverter efficiency	> 98 %
Short-circuit current rating per IEC, in conjunction with the specified fuses	160 ... 400 kW: 100 kA
Short-circuit current rating per UL508C (up to 480 VAC), in conjunction with the specified fuses	160 ... 400 kW: 100 kA Can be used on supply systems that cannot supply more than 100 kA symmetrically for a maximum voltage of 480 VAC when they are protected with the listed fuses of type Class J or Class L, or approved semi-conductor fuses specified in the "Technical Data" section of this manual.
Overvoltage category	III according to EN 61800-5-1
<b>Mechanical data</b>	
Degree of protection	IP20
Protection class	according to EN 61800-5-1: Class I (with protective conductor system) and Class III (PELV)
Cooling method	Forced air cooling AF according to EN 60146
Sound pressure level $L_{PA}$ (1 ma)	$\leq 74$ dB(A) <sup>1)</sup>
Touch protection	according to EN 61800-5-1: For the intended purpose

<b>Compliance with standards</b>			
Standards	EN 60146-1-1, EN 61800-2, EN 61800-3, EN 61800-5-1, EN 60204-1, EN 60529, UL508C, CSA 22.2 No. 14-13		
CE marking	To EMC directive No. 2004/108/EC and low-voltage directive No. 2006/95/EC		
Radio interference suppression	In accordance with the EMC product standard for variable-speed drives EN 61800-3, "second environment" <sup>2)</sup> . Application in "first environment" possible with line filters.		
Approval	cULus (File No.: E192450), CE, c-Tick, GOST-R, KC		
<b>Ambient conditions</b>	<b>During storage</b> <sup>3)</sup>	<b>During transport</b> <sup>3)</sup>	<b>During operation</b>
Ambient temperature	-25 ... +55 °C	-25 ... +70 °C from -40 °C for 24 hours	0 ... +40 °C up to + 50 °C with derating
Relative humidity (no condensation) Corresponds to class	<i>5 to 95%</i> 1K4 according to EN 60721-3-1	5 ... 95 % at 40 °C 2K3 according to EN 60721-3-2	5 ... 95 % 3K3 according to EN 60721-3-3
Environmental class / harmful chemical substances	1C2 according to EN 60721-3-1	2C2 according to EN 60721-3-2	3C2 according to EN 60721-3-3
Organic/biological influences	1B1 according to EN 60721-3-1	2B1 according to EN 60721-3-2	3B1 according to EN 60721-3-3
Pollution degree	2 according to EN 61800-5-1		
Installation altitude	Up to 1000 m above sea level without derating, > 1000 m above sea level with derating (see "Derating data")		
<b>Mechanical strength</b>	<b>During storage</b> <sup>3)</sup>	<b>During transport</b> <sup>3)</sup>	<b>During operation</b>
Vibrational load - Displacement - Acceleration	Fc test according to EN 60068-2-6 ±1.5 mm for 5 ... 9 Hz 0.5 g for 9 ... 200 Hz	Fc test according to EN 60068-2-6 ±1.5 mm for 5 ... 9 Hz 0.5 g for 9 ... 200 Hz	Fc test according to EN 60068-2-6 0.075 mm for 10 ... 58 Hz 9.81 ma/s <sup>2</sup> (1 x g) for > 58 ... 200 Hz
Shock load - Displacement - Acceleration		Fc test according to EN 60068-2-6 ±1.5 mm for 5 ... 9 Hz 0.5 g for 9 ... 200 Hz	Test according to EN 60068-2-27 (EA shock type) 49 ma/s <sup>2</sup> (5 x g)/30 ms 147 ma/s <sup>2</sup> (15 x g)/11 ms

Deviations from the defined classes are shown in *italics*.

- 1) maximum sound pressure level, ascertained in the IP20 cabinet
- 2) Standard construction: Devices installed in the switch cabinet with EMC-conform construction, line reactor uk = 2%, shielded motor cable (e.g. Prototflex EMC) with max. 100 m cable length, line perturbations according to EN 61000-2-4: Class 2, THD(U) total = 8 % for typical line conditions (RSC > 30 ... 50); THD(I) total: typically 30 ... 45 % (15 < RSC < 50)
- 3) in transport packaging

### 10.2.6.2 Power-dependent data, PM330

---

#### Note

#### Recommended connection cross-sections

The recommended connection cross-sections are determined for copper cables at 40° C (104° F) ambient temperature and cables with a permitted operating temperature on the conductor for 70° C (laying type C - factor for bundling 0.75 considered) according to DIN VDE 0298-4/08.03).

**Protective conductor cross-section (S: Cross-section of the supply connection phase conductor, MS: Cross-section of the external protective conductor):**

Minimum cross-sections:

- $S < 16 \text{ mm}^2 \rightarrow MS = S$
- $16 \text{ mm}^2 \leq S \leq 35 \text{ mm}^2 \rightarrow MS = 16 \text{ mm}^2$
- $S > 35 \text{ mm}^2 \rightarrow MS = 0.5 \times S$

Recommended cross-sections:

- $MS \geq S$
-

Table 10- 62 PM330 frame sizes GX, 3-ph. 380 VAC... 480 VAC

Article no.	6SL3310...	...1PE33-0AA0	...1PE33-7AA0	...1PE34-6AA0
Rated input current				
- for 380/400 V, 40° C		317 A	375 A	469 A
- for 480 V, 40° C		262 A	314 A	376 A
- for 380/400 V, 50° C		269 A	319 A	399 A
- for 480 V, 50° C		220 A	266 A	319 A
Rated output current $I_N$				
- for 380/400 V, 40° C		300 A	370 A	460 A
- for 480 V, 40° C		245 A	308 A	369 A
- for 380/400 V, 50° C		255 A	315 A	391 A
- for 480 V, 50° C		208 A	262 A	313 A
LO base-load power		160 kW	200 kW	250 kW
LO base-load input current at 400 V		307 A	365 A	459 A
LO base-load output current at 400 V		290 A	360 A	450 A
HO base-load power		132 kW	160 kW	200 kW
HO base-load input current at 400 V		254 A	300 A	375 A
HO base-load output current at 400 V		240 A	296 A	368 A
Fuse according to IEC manufacturer:		3NE1333-2 (450 A/690 V)	3NE1334-2 (500 A/690 V)	3NE1435-2 (560 A/690 V)
Maximum permissible line short-circuit current $I_{kmax}$		Siemens AG	Siemens AG	Siemens AG
Minimum network short-circuit current required $I_{kmin}^{1)}$		> 4.4 kA	> 5.2 kA	> 6.3 kA
Fuse according to UL <sup>2)</sup>		Class J 400 A / 600 V e. B. DF J-400	Class J 500 A / 600 V e. B. DF J-500	Class J 600 A / 600 V e. B. DF J-600
max.power loss, at $I_N$ , 40 °C, 400 V		3.642 kW	4.414 kW	5.125 kW
Required cooling air flow		210 l/s	210 l/s	210 l/s
Maximum connectable cross-section of the line, motor and DC-link cable		2 x 240 mm <sup>2</sup> 2 x 500 kcmil	2 x 240 mm <sup>2</sup> 2 x 500 kcmil	2 x 240 mm <sup>2</sup> 2 x 500 kcmil
Recommended cable cross-section for 380/400 V				
- power cable		2 x 120 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>
- motor cable		2 x 95 mm <sup>2</sup>	2 x 95 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>
Recommended cable cross-section for 480 V				
- power cable		2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>
- motor cable		2 x 70 mm <sup>2</sup>	2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>
Tightening torque for line, motor and ground cable		50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Weight		101 kg	102 kg	107 kg

1) The network supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Note: If the minimum short-circuit current is not reached then the tripping time for the fuses increases, and this may result in consequential damage.

2) When semi-conductor fuses are used, they must be mounted in the same lower-level construction as the inverter.

Table 10- 63 PM330, frame size HX, 3 AC 380 V ... 480 V

Article no.	6SL3310...	...1PE35-8AA0	...1PE36-6AA0	...1PE37-4AA0
Rated input current				
- for 380/400 V, 40° C		597 A	668 A	750 A
- for 480 V, 40° C		497 A	536 A	614 A
- for 380/400 V, 50° C		507 A	568 A	637 A
- for 480 V, 50° C		422 A	456 A	522 A
Rated output current I <sub>N</sub>				
- for 380/400 V, 40° C		585 A	655 A	735 A
- for 480 V, 40° C		487 A	526 A	602 A
- for 380/400 V, 50° C		497 A	557 A	625 A
- for 480 V, 50° C		414 A	447 A	512 A
LO base-load power		315 kW	355 kW	400 kW
LO base-load input current at 400 V		581 A	653 A	734 A
LO base-load output current at 400 V		570 A	640 A	720 A
HO base-load power		250 kW	250 kW	315 kW
HO base-load input current at 400 V		477 A	501 A	562 A
HO base-load output current at 400 V		468 A	491 A	551 A
Fuse according to IEC manufacturer:		3NE1437-2 (710 A/690 V)	3NE1438-2 (800 A/690 V)	3NE1448-2 (850 A/690 V)
Maximum permissible line short-circuit current I <sub>kmax</sub>		Siemens AG ≤ 100 kA	Siemens AG ≤ 100 kA	Siemens AG ≤ 100 kA
Minimum network short-circuit current required I <sub>kmin</sub> <sup>1)</sup>		> 9.0 kA	> 10.0 kA	> 12.0 kA
Fuse according to UL <sup>2)</sup>		Class L 650 A / 600 V e. g. KTU 650	Class L 700 A / 600 V e. g. KTU 700	Class L 800 A / 600 V e. g. KTU 800
max.power loss, at I <sub>N</sub> , 40 °C, 400 V		6.791 kW	7.687 kW	8.385 kW
Required cooling air flow		360 l/s	360 l/s	360 l/s
Maximum connectable cross-section of the line, motor and DC-link cable		4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil
Recommended cable cross-section for 380/400 V				
- power cable		2 x 240 mm <sup>2</sup>	3 x 150 mm <sup>2</sup>	3 x 185 mm <sup>2</sup>
- motor cable		2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 480 V				
- power cable		2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
- motor cable		2 x 150 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
Tightening torque for line, motor and ground cable		50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Weight		155 kg	155 kg	157 kg
Minimum control cabinet size for installation of the Power Module (width x height x depth)		800 mm x 2000 mm x 600 mm		

1) The network supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Note: If the minimum short-circuit current is not reached then the tripping time for the fuses increases, and this may result in consequential damage.

2) When semi-conductor fuses are used, they must be mounted in the same lower-level construction as the inverter.


## 10.2.7 Data regarding the power loss in partial load operation

You can find data regarding power loss in partial load operation in the Internet:

Partial load operation (<http://support.automation.siemens.com/WW/view/en/94059311>)

## 10.3 Restrictions for special ambient conditions


### Current de-rating depending on the ambient operating temperature



The Control Unit and operator panel can restrict the maximum permissible operating ambient temperature of the Power Module.

### Current derating depending on the installation altitude

Above 1000 m above sea level you must reduce the inverter output current as a result of the lower cooling capability of the air.



### Permissible line supplies depending on the installation altitude

- Installation altitude up to 2000 m above sea level
  - Connection to every supply system permitted for the inverter.
- Installation altitudes between 2000 m and 4000 m above sea level
  - Connection to a TN system with grounded neutral point.
  - TN systems with grounded line conductor are not permitted.
  - The TN line system with grounded neutral point can also be supplied using an isolation transformer.
  - The phase-to-phase voltage does not have to be reduced.

---

#### Note

##### 690 V Power Modules

For 690 V Power Modules, the TN line system must be established with grounded neutral point through an isolating transformer.

---



## Appendix

### A.1 New and extended functions

Table A- 1 New functions and function changes in Firmware 4.7 SP3

	Function	SINAMICS								ET 200pro FC-2
		G120						G120D		
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	
1	PM240-2 Power Modules, frame sizes FSD and FSE are supported	-	-	✓	✓	✓	✓	-	-	-
	The Safety Integrated basic function Safe Torque Off (STO) is supported via the terminals of the PM240-2 Power Module, frame sizes FSD and FSE	-	-	-	-	✓	✓	-	-	-
2	Revised PM230 Power Module with new Article numbers supported: <ul style="list-style-type: none"> <li>IP55 degree of protection: 6SL3223-0DE . . . . <b>G</b> .</li> <li>IP20 degree of protection and Push Through: 6SL321 . - 1NE . . . . <b>G</b> .</li> </ul>	-	-	✓	✓	✓	-	-	-	-
	The Safety Integrated basic function Safe Torque Off (STO) is supported with the revised PM230 Power Module	-	-	-	-	✓	-	-	-	-
3	PM330 Power Module, frame size HX is supported	-	-	✓	-	-	-	-	-	-
4	1FP1 reluctance motors are supported	-	-	✓	-	-	-	-	-	-
5	Encoderless 1FK7 synchronous motors are supported	-	✓	-	✓	✓	✓	✓ <sup>1)</sup>	-	-
6	Encoderless 1FG1 geared synchronous motors are supported	-	✓	-	✓	✓	✓	✓	-	-
7	SINAMICS “Standard Drive Control” and “Dynamic Drive Control” application classes to simplify commissioning and increase the degree of ruggedness of the closed-loop motor control. SINAMICS application classes are only available with PM240, PM240-2 and PM330 Power Modules.	-	✓	✓	✓	✓	✓	-	-	-
8	Moment of inertia estimator with moment of inertia precontrol to optimize the speed controller in operation	✓	✓	-	✓	✓	✓	✓	✓	✓
9	Friction torque characteristic with automatic plotting to optimize the speed controller	✓	✓	-	✓	✓	✓	✓	✓	✓
10	Automatic optimization of the technology controller	-	-	✓	✓	✓	-	-	-	-
11	The sign of the system deviation for the additional, free technology controller can be switched over. A new parameter defines the sign of the system deviation matching the particular application, e.g. for cooling or heating applications.	-	-	✓	-	-	-	-	-	-

	Function	SINAMICS									
		G120					G120D				
12	Line contactor control using a digital output of the inverter to save energy when the motor is switched off	✓	✓	✓	✓	✓	✓	✓	✓	✓	-
13	Fast flying restart for PM330 Power Modules: The "Flying restart" function does not have to wait for the motor demagnetization time, and identifies the motor speed without requiring a search operation.	-	-	✓	-	-	-	-	-	-	-
14	Load torque monitoring extended to include the following functions: <ul style="list-style-type: none"> <li>Protection against blocking, leakage and dry running operation in pump applications</li> <li>Protection against blocking and broken belts in fan applications</li> </ul>	-	✓	✓	✓	✓	-	-	-	-	-
15	Automatic switchover of the real time clock from daylight saving time (summer time) to standard time (winter time).	-	-	✓	-	-	-	-	-	-	-
16	New or revised default settings of the interfaces: p0015 macros 110, 112 and 120	-	-	✓	-	-	-	-	-	-	-
17	Expansion of the temperature sensors to include DIN-Ni1000 for analog inputs AI 2 and AI 3	-	-	✓	-	-	-	-	-	-	-
18	Communication via AS-Interface. Default setting of the communication via AS-i: p0015 macros 30, 31, 32 and 34	✓	-	-	-	-	-	-	-	-	-
19	Communication expansion via Modbus: Adjustable parity bit, access to parameters and analog inputs	-	-	✓	-	-	-	-	-	-	-
20	Extending communication via BACnet: Access to parameters and analog inputs	-	-	✓	-	-	-	-	-	-	-
21	The bus error LED for communication via USS and Modbus can be switched off	✓	✓	✓	✓	✓	✓	✓	-	-	-

- <sup>1)</sup> Operation with 1FK7 synchronous motors without encoder has already been released with firmware V4.7 for SINAMICS G120D with CU240D-2 Control Units.

In the preface you can find references to the description of the new functions: Changes in this manual (Page 5).

Table A- 2 New functions and function changes in Firmware 4.7

	Function	SINAMICS							
		G110M	G120C	G120				G120D	
				CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2
1	Supporting the identification & maintenance datasets (I&M1 ... 4)	✓	✓	✓	✓	✓	✓	✓	✓
2	Fall in pulse rate with increased drive power required by the motor <ul style="list-style-type: none"> <li>The inverter temporarily lowers the pulse frequency if required when the motor is started up, and simultaneously increases the current limit.</li> </ul>	✓	✓	✓	✓	✓	✓	✓	✓
3	S7 communication <ul style="list-style-type: none"> <li>Direct data exchange between the inverter and human-machine interface (HMI).</li> <li>Increase in communication performance with the engineering tools and support of the S7 routing</li> </ul>	✓	✓	✓	✓	✓	✓	✓	✓
4	The basic functions of Safety Integrated are unrestrictedly available in all control types with 1FK7 encoderless permanent-field synchronous motors	-	-	-	-	-	-	✓	-
5	Direct selection of the 1FK7 encoderless permanent-field synchronous motors using the Article No. with allocated code number <ul style="list-style-type: none"> <li>It is not necessary to input individual motor data</li> </ul>	-	-	-	-	-	-	✓	-
6	Pulse input as source of setpoint value <ul style="list-style-type: none"> <li>The inverter calculates its speed setpoint from a sequence of pulses at the digital input.</li> </ul>	-	-	-	-	-	✓	-	-
7	Dynamic IP address assignment (DHCP) and temporary device names for PROFINET	✓	✓	✓	-	✓	✓	✓	✓
8	PROFInergy Slave profile 2 and 3	✓	✓	✓	-	✓	✓	✓	✓
9	Uniform behavior for component replacement <ul style="list-style-type: none"> <li>After a component is replaced, an inverter with activated Safety Integrated will report what type of component has been replaced using a unique code.</li> </ul>	✓	✓	-	-	✓	✓	✓	✓
10	Improved direct-component control in PM230 <ul style="list-style-type: none"> <li>Optimized efficiency for pump and fan applications</li> </ul>	-	-	✓	-	-	-	-	-
11	Rounding down of BACnet and macros	-	-	✓	-	-	-	-	-

Table A-3 New functions and function changes in Firmware 4.6.6

	Function	SINAMICS						
		G120C	G120				G120D	
			CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2
1	Support for the new Power Modules <ul style="list-style-type: none"> <li>PM330 IP20 GX</li> </ul>	-	✓	-	-	-	-	-

Table A- 4 New functions and function changes in Firmware 4.6

	Function	SINAMICS						
		G120C	G120				G120D	
			CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2
1	Support for the new Power Modules <ul style="list-style-type: none"> <li>PM240-2 IP20 FSB ... FSC</li> <li>PM240-2 in through-hole technology FSB ... FSC</li> </ul>	-	✓	✓	✓	✓	-	-
2	Support for the new Power Modules <ul style="list-style-type: none"> <li>PM230 in through-hole technology FSD ... FSF</li> </ul>	-	✓	✓	✓	-	-	-
3	Motor data preassignment for the 1LA/1LE motors via code number <ul style="list-style-type: none"> <li>During basic commissioning with the operator panel, set the motor data using a code number</li> </ul>	✓	✓	✓	✓	✓	✓	✓
4	Extension to communication via CANopen <ul style="list-style-type: none"> <li>CAN velocity, ProfilTorque, SDO channel for each axis, system test with CodeSys, suppression of ErrorPassiv alarm</li> </ul>	✓	✓	-	-	✓	-	-
5	Extension to communication via BACnet <ul style="list-style-type: none"> <li>Multistate value objects for alarms, commandable AO objects, objects for configuring the PID controller</li> </ul>	-	✓	-	-	-	-	-
6	Communication via EtherNet/IP	✓	✓	-	✓	✓	✓	✓
7	Skip frequency band for analog input <ul style="list-style-type: none"> <li>A symmetrical skip frequency band can be set for each analog input around the 0 V range.</li> </ul>	✓	✓	✓	✓	✓	✓	-
8	Changing the control of the motor holding brake	✓	-	✓	✓	✓	✓	-
9	Safety function SBC (Safe Brake Control) <ul style="list-style-type: none"> <li>Secure control of a motor holding brake when using the "Safe Brake Module" option</li> </ul>	-	-	-	-	✓	-	-
10	Safety function SS1 (Safe Stop 1) without speed monitoring	-	-	-	-	✓	-	-
11	Straightforward selection of standard motors <ul style="list-style-type: none"> <li>Selection of 1LA... and 1LE... motors with an operator panel using a list containing code numbers</li> </ul>	✓	✓	✓	✓	✓	✓	✓
12	Firmware update via memory card	✓	✓	✓	✓	✓	✓	✓
13	Safety info channel <ul style="list-style-type: none"> <li>BICO source r9734.0...14 for the status bits of the extended safety functions</li> </ul>	-	-	-	✓	✓	✓	✓
14	Diagnostic alarms for PROFIBUS	✓	✓	✓	✓	✓	✓	✓

Table A- 5 New functions and function changes in Firmware 4.5

	Function	SINAMICS					
		G120C	G120			G120D	
	CU230P-2		CU240B-2	CU240E-2	CU240D-2	CU250D-2	
1	Support for the new Power Modules: <ul style="list-style-type: none"> <li>• PM230 IP20 FSA ... FSF</li> <li>• PM230 in a push-through FSA ... FSC</li> </ul>	-	✓	✓	✓	-	-
2	Support for the new Power Modules: <ul style="list-style-type: none"> <li>• PM240-2 IP20 FSA</li> <li>• PM240-2 in push-through FSA</li> </ul>	-	✓	✓	✓	-	-
3	New Control Units with PROFINET support	✓	✓	-	✓	✓	✓
4	Support of the PROFIenergy profile	✓	✓	-	✓	✓	✓
5	Shared device support via PROFINET	✓	✓	-	✓	✓	✓
6	Write protection	✓	✓	✓	✓	✓	✓
7	Know-how protection	✓	✓	✓	✓	✓	✓
8	Adding a second command data set (CDS0 → CDS0 ... CDS1) (All other inverters have four command data sets)	✓	-	-	-	-	-
9	Position control and basic positioner	-	-	-	-	-	✓
10	Support of an HTL encoder	-	-	-	-	✓	✓
11	Support of an SSI encoder	-	-	-	-	-	✓
12	Fail-safe digital output	-	-	-	-	✓	✓

## A.2 Parameter

Parameters are the interface between the firmware of the converter and the commissioning tool, e.g. an Operator Panel.

### Adjustable parameters

Adjustable parameters are the "adjusting screws" with which you adapt the converter to its particular application. If you change the value of an adjustable parameter, then the converter behavior also changes.

Adjustable parameters are shown with a "p" as prefix, e.g. p1082 is the parameter for the maximum motor speed.

### Display parameters

Display parameters allow internal measured quantities of the converter and the motor to be read.

The Operator Panel and STARTER represent display parameters with an "r" prefix, for example, r0027 is the parameter for the converter output current.

### Parameters that in many cases help

Table A- 6    **How to switch to commissioning mode or restore the factory setting**

Parameter	Description
p0010	<b>Commissioning parameters</b> 0: Ready (factory setting) 1: Carry out basic commissioning 3: Carry out motor commissioning 5: Technological applications and units 15: Define number of data sets 30: Factory setting - initiate restore factory settings

Table A- 7    **How to determine the firmware version of the Control Unit**

Parameter	Description
r0018	<b>Firmware version is displayed</b>

Table A- 8    **How to select the command and setpoint sources for the inverter**

Parameter	Description
p0015	Additional information is available in Section Factory setting of the interfaces (Page 86).

Table A- 9 How to set the ramp-up and ramp-down

Parameter	Description
p1080	<b>Minimum speed</b> 0.00 [rpm] factory setting
p1082	<b>Maximum speed</b> 1500.000 [rpm] factory setting
p1120	<b>Ramp-up time</b> 10.00 [s]
p1121	<b>Ramp-down time</b> 10.00 [s]

Table A- 10 This is how you set the closed-loop type

Parameter	Description
p1300	0: U/f control with linear characteristic 1: U/f control with linear characteristic and FCC 2: U/f control with parabolic characteristic 3: U/f control with adjustable characteristic 4: U/f control with linear characteristic and ECO 5: U/f control for drives requiring a precise frequency (textile area) 6: U/f control for drives requiring a precise frequency and FCC 7: U/f control with parabolic characteristic and ECO 19: U/f control with independent voltage setpoint 20: Speed control (without encoder) 22: Torque control (without encoder)

Not all Power Modules offer for selection all the listed control modes. The control modes permitted for your device are offered during the commissioning.


Table A- 11 This is how you optimize the starting behavior of the U/f control for a high break loose torque and overload

Parameter	Description
p1310	<b>Voltage boost to compensate ohmic losses</b> The voltage boost is active from standstill up to the rated speed. It is at its highest at speed 0 and continually decreases as the speed increases. Value of the voltage boost at speed 0 in V: $1.732 \times \text{rated motor current (p0305)} \times \text{stator resistance (r0395)} \times \text{p1310} / 100\%$
p1311	<b>Voltage boost when accelerating</b> The voltage boost is effective from standstill up to the rated speed. It is independent of the speed and has a value in V of: $1.732 \times \text{rated motor current (p0305)} \times \text{stator resistance (p0350)} \times \text{p1311} / 100\%$
p1312	<b>Voltage boost when starting</b> Setting to additionally boost the voltage when starting, however only when accelerating for the first time.

Table A- 12 How to change the inverter pulse frequency

Parameter	Description
p1800	<p><b>Setting the inverter pulse frequency</b></p> <p>The pulse frequency depends on the power unit. You can find the setting limits and the factory setting in Section Technical data, Power Modules (Page 372).</p> <p>If you increase the pulse frequency, the inverter output current decreases (the maximum output current is displayed in r0076).</p> <p>If you use a sine-wave filter, you can only set the pulse frequency to values that are permissible for the filter.</p> <p>When operated with an output reactor, the pulse frequency is limited to a maximum of 4 kHz.</p>

### A.3 Handling the BOP 2 operator panel



1) Status display once the power supply for the inverter has been switched on.

Figure A-1 Menu of the BOP-2




Figure A-2 Other keys and symbols of the BOP-2

Procedure for switching the motor on and off via the operator panel:

1. Press MANUAL AUTO 
2. Master control of the inverter is released via the BOP-2 
3. Switch on motor 
4. Switch off the motor 

## A.3.1 Changing settings using BOP-2

### Changing settings using BOP-2

You can modify the settings of your inverter by changing the values of the its parameters. The inverter only permits changes to "write" parameters. Write parameters begin with a "P", e.g. P45.

The value of a read-only parameter cannot be changed. Read-only parameters begin with an "r", for example: r2.

#### Procedure



1 To change write parameters using the BOP-2, proceed as follows:

1. Select the menu to display and change parameters.  
Press the OK key.

2. Select the parameter filter using the arrow keys.  
Press the OK key.


- STANDARD: The inverter only displays the most important parameters.
- EXPERT: The inverter displays all of the parameters.

3. Select the required number of a write parameter using the arrow keys.  
Press the OK key.

4. Select the value of the write parameter using the arrow keys.  
Accept the value with the OK key.

■ You have now changed a write parameter using the BOP-2.

The inverter saves all the changes made using the BOP-2 so that they are protected against power failure.



### A.3.2 Changing indexed parameters

#### Changing indexed parameters


For indexed parameters, several parameter values are assigned to a parameter number. Each of the parameter values has its own index.

**Procedure**



To change an indexed parameter, proceed as follows:

1. Select the parameter number.
2. Press the OK key.
3. Set the parameter index.
4. Press the OK key.
5. Set the parameter value for the selected index.



■ You have now changed an indexed parameter.

### A.3.3 Directly entering the parameter number and value

#### Directly select the parameter number

The BOP-2 offers the possibility of setting the parameter number digit by digit.

**Precondition**


The parameter number is flashing in the BOP-2 display.

**Procedure**



To select the parameter number directly, proceed as follows:

1. Press the OK button for longer than five seconds.
2. Change the parameter number digit-by-digit.  
If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter number, press the OK button.



■ You have now entered the parameter number directly.

## Entering the parameter value directly

The BOP-2 offers the option of setting the parameter value digit by digit.

### Precondition


The parameter value flashes in the BOP-2 display.

### Procedure



To select the parameter value directly, proceed as follows:

1. Press the OK button for longer than five seconds.
2. Change the parameter value digit-by-digit.  
If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter value, press the OK button.




- You have now entered the parameter value directly.


## A.3.4 A parameter cannot be changed

### When must you not change a parameter?


The converter indicates why it currently does not permit a parameter to be changed:



You have attempted to change a read-only parameter.



You must change to basic commissioning to set this parameter.




You must turn the motor off to set this parameter.

The operating state in which you can change a parameter is provided in the List Manual for each parameter.

## A.4 The device trace in STARTER

### Description

The device trace graphically displays inverter signals with respect to time.



### Signals

In two settings that are independent of one another, using  you can interconnect eight signals each.

## Recording

You can start a measurement as frequently as you require. As long as you do not exit START, the results remain under the "Measurements" tab with data and time. When terminating STARTER or under the "Measurements" tab, you can save the measurement results in the \*.trc format.

If you require more than two settings for your measurements, you can either save the individual settings in the project or export them in \*.clg format, and load or import them, if necessary.

You can record individual bits of a parameter (e.g. r0722. 1) by allocating the relevant bit using "bit track" ()

Using the mathematical function () you can define a curve, for example, the difference between the speed setpoint and the speed actual value.

The device trace shows "individual bits" or "mathematical functions" as signal No. 9.

## Recording cycle and duration

The device trace records data in a CU-dependent basic cycle clock. The maximum recording duration depends on the number of recorded signals and the trace clock cycle.

Proceed as follows to extend the recording duration:

1. Multiply the trace clock cycle by an integral number.
2. Accept the displayed maximum duration using .

Alternatively, you can also specify the measurement period and then calculate the trace clock cycle of STARTER using .

## Trigger (condition to start the device trace)

The device trace starts as soon as you press the  (start trace) button.

Using the button , you can define another trigger to start the device trace.

The pretrigger defines the time in which the signals are traced before the trigger condition. As a consequence, the trigger condition traces itself.

### Example of a bit pattern as trigger:

You must define the pattern and value of a bit parameter for the trigger. To do so, proceed as follows:

Using , select "Trigger to variable - bit pattern"

Using , select the bit parameter

Using , open the screen form in which you set the bits and their values for the start condition



## A.5 Interconnecting signals in the converter

### A.5.1 Fundamentals

The following functions are implemented in the converter:

- Open-loop and closed-loop control functions
- Communication functions
- Diagnosis and operating functions

Every function comprises one or several blocks that are interconnected with one another.




Figure A-4 Example of a block: Motorized potentiometer (MOP)

Most of the blocks can be adapted to specific applications using parameters.

You cannot change the signal interconnection within the block. However, the interconnection between blocks can be changed by interconnecting the inputs of a block with the appropriate outputs of another block.

The signal interconnection of the blocks is realized, contrary to electric circuitry, not using cables, but in the software.




Figure A-5 Example: Signal interconnection of two blocks for digital input 0

## Binectors and connectors

Connectors and binectors are used to exchange signals between the individual blocks:

- Connectors are used to interconnect "analog" signals. (e.g. MOP output speed)
- Binectors are used to interconnect "digital" signals. (e.g. 'Enable MOP up' command)




Figure A-6 Symbols for binector and connector inputs and outputs

Binector/connector outputs (CO/BO) are parameters that combine more than one binector output in a single word (e.g. r0052 CO/BO: status word 1). Each bit in the word represents a digital (binary) signal. This summary reduces the number of parameters and simplifies parameter assignment.

Binector or connector outputs (CO, BO or CO/BO) can be used more than once.

### When must you interconnect signals in the converter?

If you change the signal interconnection in the converter, you can adapt the converter to a wide range of requirements. This does not necessarily have to involve highly complex functions.

Example 1: Assign a different function to a digital input.

Example 2: Switch the speed setpoint from the fixed speed to the analog input.

### How much care is required when you change the signal interconnection?

Always take care when establishing internal signal interconnections. Note which changes you make as you go along since the process of analyzing them later can be quite difficult.

The STARTER commissioning tool offers signals in plain text and simplifies their interconnection.

### Where can you find additional information?

- This manual is sufficient for simple signal interconnections (e.g. assigning a different function to digital inputs).
- The parameter list in the List Manual is sufficient for more complex signal interconnections.
- You can also refer to the function diagrams in the List Manual for complex signal interconnections.

## A.5.2 Example

### Moving a basic control logic into the inverter

A conveyor system is to be configured in such a way that it can only start when two signals are present simultaneously. These could be the following signals, for example:

- The oil pump is running (the required pressure level is not reached, however, until after 5 seconds)
- The protective door is closed

To implement this task, you must insert free function blocks between digital input 0 and the command to switch on the motor (ON/OFF1).




Figure A-7 Example: Signal interconnection for control logic

The signal of digital input 0 (DI 0) is fed through a time block (PDE 0) and is interconnected with the input of a logic block (AND 0). The signal of digital input 1 (DI 1) is interconnected to the second input of the logic block. The logic block output issues the ON/OFF1 command to switch-on the motor.

### Setting the control logic

Parameter	Description
p20161 = 5	The time block is enabled by assigning to runtime group 5 (time slice of 128 ms)
p20162 = 430	Run sequence of the time block within runtime group 5 (processing before the AND logic block)
p20032 = 5	The AND logic block is enabled by assigning to runtime group 5 (time slice of 128 ms)
p20033 = 440	Run sequence of the AND logic block within runtime group 5 (processing after the time block)
p20159 = 5000.00	Setting the delay time [ms] of the time module: 5 seconds
p20158 = 722.0	Connect the status of DI 0 to the input of the time block r0722.0 = Parameter that displays the status of digital input 0.
p20030[0] = 20160	Interconnect the timer block to the 1st input of the AND
p20030[1] = 722.1	Interconnect the status of DI 1 with the 2nd AND input r0722.1 = Parameter that displays the status of digital input 1.
p0840 = 20031	Interconnect the AND output to ON/OFF1

**Explanation of the example using the ON/OFF1 command**

Parameter p0840[0] is the input of the "ON/OFF1" block of the inverter. Parameter r20031 is the output of the AND block. To interconnect ON/OFF1 with the output of the AND block, set p0840 = 20031.




Figure A-8 Interconnecting blocks by setting p0840[0] = 20031

**Principle for interconnecting blocks**

Always interconnect the input (connector or binector input) with the signal source.

## A.6 Manuals and technical support

### A.6.1 Manuals for your inverter

#### Documentation on DVD

SINAMICS Manual Collection, Article number 6SL3097-4CA00-0YGO

Table A- 13 Manuals for your inverter for download

Depth of the information	Manual	Contents	Available languages	Download
++	<b>Compact operating instructions</b> for SINAMICS G120 inverters with CU230P-2; CU240B-2 and CU240E-2 Control Units	Installing the inverter and commissioning.	English, German, Italian, French, Spanish, Chinese	Manuals for the Control Unit ( <a href="http://support.automation.siemens.com/WW/view/en/30563628/133300">http://support.automation.siemens.com/WW/view/en/30563628/133300</a> )
+++	<b>Operating instructions</b>	(this manual)		
+++	<b>Fieldbus function manual</b> for the SINAMICS G120, G120C and G120D inverters	Configuring fieldbuses.	English, German, Chinese	
+++	<b>List Manual</b> for the SINAMICS G120 inverter with the CU230P-2 Control Units	Graphic function block diagrams. List of all parameters, alarms and faults.		
+	<b>Getting Started Guide</b> for the following SINAMICS G120 Power Modules: <ul style="list-style-type: none"> <li>• PM240, PM250 and PM260</li> <li>• PM240-2</li> <li>• PM230</li> </ul>	Installing the Power Module	English	Manuals for the Power Modules ( <a href="http://support.automation.siemens.com/WW/view/en/30563173/133300">http://support.automation.siemens.com/WW/view/en/30563173/133300</a> )
+	<b>Installation Instructions</b> for reactors, filters and braking resistors	Installing components		
+++	<b>Hardware Installation Manual</b> for the following SINAMICS G120 Power Modules: <ul style="list-style-type: none"> <li>• PM230 IP20</li> <li>• PM230 IP55</li> <li>• PM240</li> <li>• PM240-2</li> <li>• PM250</li> <li>• PM260</li> </ul>	Installing power modules, reactors and filters. Maintaining power modules.	English, German	

Depth of the information	Manual	Contents	Available languages	Download
+++	<b>Hardware installation manual for the PM330 Power Module</b> as well as the associated reactors, filters and braking resistors	Installing Power Modules, reactors and filters. Maintaining power modules.	English, German, Italian, French, Spanish, Chinese	Built-in and wall/panel mounting devices SINAMICS G120P ( <a href="http://support.automation.siemens.com/WW/view/en/38797189/133300">http://support.automation.siemens.com/WW/view/en/38797189/133300</a> )
+++	<b>Operating instructions SINAMICS G120P inverter cabinet units</b>	Installing, commissioning and operating cabinet units.	English, German, Italian, French, Spanish, Chinese	SINAMICS G120P Cabinet cabinet units ( <a href="http://support.automation.siemens.com/WW/view/en/82139421/133300">http://support.automation.siemens.com/WW/view/en/82139421/133300</a> )
+++	<b>Operating Instructions</b> for the following Operator Panels: <ul style="list-style-type: none"> <li>• BOP-2</li> <li>• IOP</li> </ul>	Operating Operator Panels, door mounting kit for mounting of IOP.	English, German	Manuals for the inverter accessories ( <a href="http://support.automation.siemens.com/WW/view/en/30563514/133300">http://support.automation.siemens.com/WW/view/en/30563514/133300</a> )
+++	<b>Configuration Manual</b> EMC installation guideline	EMC-compliant control cabinet design, potential equalization and cable routing	English, German, Italian, French, Spanish, Chinese	EMC installation guideline ( <a href="http://support.automation.siemens.com/WW/view/en/60612658">http://support.automation.siemens.com/WW/view/en/60612658</a> )

## A.6.2 Configuring support

Table A- 14 Support when configuring and selecting the inverter

Manual or tool	Contents	Available languages	Download or article number
Catalog D 31	Ordering data and technical information for SINAMICS G inverters	English, German, Italian, French, Spanish	Everything about SINAMICS G120 ( <a href="http://www.siemens.de/sinamics-g120">www.siemens.de/sinamics-g120</a> )
Online catalog (Industry Mall)	Ordering data and technical information for all SIEMENS products	English, German	
SIZER	The overall configuration tool for SINAMICS, MICROMASTER and DYNAVERT T drives, motor starters, as well as SINUMERIK, SIMOTION controls and SIMATIC Technology	English, German, Italian, French	You obtain SIZER on a DVD (Article number: 6SL3070-0AA00-0AG0) and in the Internet: Download SIZER ( <a href="http://support.automation.siemens.com/WW/view/en/10804987/130000">http://support.automation.siemens.com/WW/view/en/10804987/130000</a> )

### A.6.3 Product Support

You can find additional information on the product and more in the Internet under: Product support (<http://www.siemens.com/automation/service&support>).

In addition to our documentation, under this address we offer our complete knowledge base online: You can find the following information:

- Actual product information (Update), FAQ (frequently asked questions), downloads.
- The Newsletter contains the latest information on the products you use.
- The Knowledge Manager (Intelligent Search) helps you find the documents you need.
- Users and specialists from around the world share their experience and knowledge in the Forum.
- You can find your local representative for Automation & Drives via our contact database under "Contact & Partner".
- Information about local service, repair, spare parts and much more can be found under "Services".

## A.7 Mistakes and improvements

If you come across any mistakes when reading this manual or if you have any suggestions for how it can be improved, then please send your suggestions to the following address or by E-mail:

Siemens AG  
Digital Factory  
Motion Control  
Postfach 3180  
91050 Erlangen, Germany

E-mail (<mailto:docu.motioncontrol@siemens.com>)



# Index

## 8

87 Hz characteristic, 76, 76

## A

Acyclic communication, 188  
Additional technology controller 0, 244  
Additional technology controller 1, 244  
Additional technology controller 2, 244  
Adjustable parameters, 437  
Alarm, 282, 347, 352  
Alarm buffer, 282, 352  
Alarm code, 352  
Alarm history, 353  
Alarm time, 282, 352  
Alarm value, 352  
Ambient temperature, 237  
Analog input, 86  
    Function, 155, 161, 162, 165  
Analog output, 86  
    Function, 155, 164  
Application  
    Reading and writing parameters cyclically via  
    PROFIBUS, 185  
Automatic mode, 201  
Automatic restart, 258  
Autotuning, 268

## B

Base components, 54  
Base load, 372  
Base load input current, 372  
Base load output current, 372  
Base load power, 372  
BF (Bus Fault), 348, 348, 349, 349  
BICO block, 447  
Bimetallic switch, 234  
Binectors, 448  
Block, 447  
BOP-2  
    Installing, 119  
    Menu, 440  
    Symbols, 440

Braking  
    Regenerative, 255  
Braking functions, 248  
Braking method, 248, 249  
Braking module, 254  
Braking resistor, 254  
Break loose torque, 438  
Bus fault, 349  
Bus termination, 82, 83  
Bypass, 291

## C

Cascade control, 296, 296, 299  
Catalog, 452  
CDS (Command Data Set), 201  
Centrifuge, 249, 252, 255  
Characteristic  
    Additional, 222  
    Linear, 222, 223  
    parabolic, 222, 223  
    square-law, 222, 223  
Checklist  
    PROFIBUS, 112  
    PROFINET, 109  
Clockwise rotation, 166  
Command Data Set, 201  
Command source, 152  
    Selecting, 437  
Commissioning  
    Accessories, 46  
    Guidelines, 115  
Communication  
    Acyclic, 188  
    Cyclically, 173  
Compound braking, 252, 253  
Compressor, 29, 123, 128, 140, 145  
Configuring support, 452  
Connectors, 448  
Control mode, 438  
Control terminals, 86  
Control Unit, 81  
    Attaching to the Power Module, 80, 81  
    Release button, 80  
Control Units, 25  
Control word  
    Control word 1, 175, 190, 193, 196  
    Control word 3, 178

Control word 3 (STW3), 178  
Controlling the motor, 166  
Conveyor belt, 249  
Conveyor systems, 143  
Correction manual, 453  
Counter-clockwise rotation, 166  
Current derating, 394  
Current input, 160  
Current reduction, 381, 387, 413, 418  
Cyclic communication, 175

## D

Data backup, 309, 314, 320, 323  
Data set 47 (DS), 188  
Data transfer, 314, 320, 323  
Date, 281  
Daylight saving time, 281  
DC braking, 178, 250, 250, 251, 251, 251  
DC-link overvoltage, 239  
DC-link voltage, 239  
Delta connection ( $\Delta$ ), 76, 116  
Derating  
    Installation altitude, 429  
Digital input, 86, 166  
    Function, 155  
Digital output, 86  
    Function, 155, 158  
Dimensions, 59, 60, 64  
DIP switch  
    Analog input, 160  
Direct data exchange, 187  
Direction of rotation, 211, 211  
Direction reversal, 166  
Display parameters, 437  
Door mounting kit, 46  
Download, 314, 321, 323  
Drilling patterns, 59, 60, 64  
Drive Data Set, DDS, 306  
Drive Data Sets, 306  
Drive ES Basic, 46  
DTC (Digital Time Clock), 283  
Dynamic braking, 254

## E

EMC, 48  
Energy recovery, 31  
Energy recovery option, 255  
Energy-saving display, 246  
ESM, 284

Essential Service Mode, 284  
Extruder, 233

## F

Factory assignment, 86  
Factory settings  
    Restoring the, 148  
Fan, 29, 29, 123, 128, 140, 145  
Fans, 143, 232  
Fault, 282, 347, 355  
    Acknowledge, 355, 356  
    Motor, 346  
Fault buffer, 282, 355  
Fault case, 355  
Fault code, 355  
Fault history, 356  
Fault time, 282, 355  
    received, 355  
    removed, 355  
Fault value, 355  
FCC, 219  
FFC (Flux Current Control), 222  
Field weakening, 76  
Fieldbus interfaces, 82, 83  
Firmware downgrade, 342  
Firmware version, 331, 431, 433, 434, 435, 437  
Flow control, 266  
Flux current control, 219  
Flying restart, 256  
Formatting, 310  
Free function blocks, 305  
Functions  
    BOP-2, 440  
    Fan applications, 152  
    Heating/air-conditioning systems, 152  
    HVAC, 152  
    Overview, 151  
    Pump applications, 152  
    Technological, 152

## G

Getting Started, 451  
Grinding machine, 249, 252  
GSDML (Generic Station Description Markup Language), 110

## H

Hardware Installation Manual, 451

High Overload, 372  
 Hoist drive, 255  
 Hoisting gear, 254  
 Horizontal conveyors, 233, 252, 254  
 Hotline, 453

**I**

I\_max controller, 238  
 I2t monitoring, 231  
 Inclined conveyors, 254  
 IND (page index), 183  
 Industry Mall, 452  
 Installation, 47, 47  
 Installation altitude, 429  
 Installing, 56  
 Interfaces, 82  
 Interlock, 449  
 Inverter  
   does not respond, 345  
 Inverter components, 25, 331  
 Inverter control, 152  
 IT system, 69

**J**

JOG function, 172

**K**

Kinetic buffering, 262  
 Know-how protection, 310, 326  
 KTY84 sensor, 234

**L**

LED  
   BF, 348, 348, 349, 349  
   LNK, 348  
   RDY, 348, 348  
 LED (light emitting diode), 347  
 Level control, 266  
 License, 310  
 Line dip, 262  
 Line filter, 33, 34  
 Line supply cable, 75  
 Line supply type, 69  
 Linear characteristic, 222, 223  
 List Manual, 451  
 LNK (PROFINET Link), 348

Load failure, 276  
 Low Overload, 372

**M**

Manual Collection, 451  
 Manual mode, 201  
 Manuals  
   Download, 451  
   Inverter accessories, 451  
   Overview, 451  
 Maximum cable length  
   PROFIBUS, 113  
 Maximum cable lengths  
   PROFINET, 110  
 Maximum current controller, 238  
 Maximum speed, 118, 211, 438  
 MELD\_NAMUR (fault word according to the VIK-Namur definition), 180  
 Memory cards, 27  
 Menu  
   BOP-2, 440  
   Operator panel, 440  
 Minimum speed, 118, 211, 214, 438  
 Mistakes manual, 453  
 MMC (memory card), 310  
 MOP (motorized potentiometer), 206  
 MotID (motor data identification), 124, 132  
 Motor cable, 75  
 Motor control, 152  
 Motor data, 116  
   Identify, 124, 229  
   Identifying, 132  
   measure, 124  
   measuring, 132  
 Motor fault, 346  
 Motor standard, 242  
 Motor temperature, 237  
 Motor temperature sensor, 86, 235  
 Motorized potentiometer, 206  
 Multi-zone control, 288

**N**

Neutral conductor, 69

**O**

OFF1 command, 166  
 OFF3 ramp-down time, 217  
 ON command, 166

Operating instruction, 21  
 Operating instructions, 451  
 Operation, 154  
 Operator panel
 

- BOP-2, 46, 440
- Door mounting kit, 46
- Handheld, 46
- Installing, 119
- IOP, 46
- Menu, 440

 Optimizing the closed-loop speed controller, 229  
 Order number, 25  
 Overload, 238, 438  
 Overload capability, 372  
 Overview
 

- Manuals, 451
- Section, 22

 Overview of the functions, 151  
 Overvoltage, 239, 239

**P**

Page index, 183  
 Parabolic characteristic, 222, 223  
 Parameter channel, 180
 

- IND, 183

 Parameter index, 183  
 Parameter number, 183, 442  
 Parameter types, 437  
 Parameter value, 443  
 Partial load operation, 427  
 PC Connection Kit, 46  
 PELV, 369  
 PID controller, 266  
 PLC functionality, 449  
 Power distribution systems, 69  
 Power failure, 258  
 Power Module, 25  
 Pressure control, 266  
 Procedure, 21  
 Process variables of the technology controller, 243  
 PROFIBUS, 112  
 PROFIdrive, 107  
 PROFlenergy, 107  
 Protection functions, 152  
 Protective conductor, 69  
 PTC sensor, 234  
 Pulse cancelation, 175  
 Pulse enable, 175, 190, 193, 197  
 Pulse
 

- frequency, 232, 233, 381, 387, 394, 413, 418, 439
- suppression, 190, 193, 197

Pump, 29, 29, 123, 128, 140, 143, 145

**Q**

Questions, 453  
 Quick stop, 153

**R**

Radio interference class, 33  
 Ramp-down, 438  
 Ramp-down time, 118, 217, 438  
 Ramp-function generator, 211  
 Ramp-up, 438  
 Rampup time,  
 Ramp-up time, 217  
 RDY (Ready), 348, 348  
 Ready, 154  
 Ready to switch on, 154  
 Real time clock, 281  
 Real Time Clock, 281  
 Regenerative feedback, 255  
 Regenerative operation, 248  
 Reset
 

- Parameter, 148

 Reversing, 211  
 Rounding, 217  
 Rounding OFF3, 217  
 RTC (Real Time Clock), 281, 283

**S**

S7 communication, 107  
 Saw, 249, 252  
 Scaling
 

- Analog input, 160
- Analog output, 163

 SD (memory card), 310
 

- Formatting, 310
- MMC, 310

 Sequence control, 153  
 Series commissioning, 309  
 Setpoint processing, 152, 211  
 Setpoint source, 152
 

- Selecting, 204, 205, 206, 437

 Settling time, 123, 128, 140, 145  
 Short-circuit monitoring, 235  
 Signal interconnection, 447  
 Signal states, 348  
 Sine-wave filter, 41  
 SIZER, 452

Skip frequency band, 162, 211  
 Slip compensation, 219  
 Speed  
   change with BOP-2, 440  
   Limiting, 211  
 Speed control, 227  
 Speed deviation, 276  
 Speed monitoring, 276  
 Square-law characteristic, 222, 223  
 Standard time, 281  
 Star connection (Y), 76  
 Startdrive, 320  
 STARTER, 46, 135, 320  
   Download, 46, 46  
 Starting characteristics  
   Optimization, 224, 225  
 Starting current, 220  
 State overview, 153  
 Status word  
   Status word 1, 177  
   Status word 3, 179  
 Status Word  
   Status word 1, 191, 194, 198  
 Storage medium, 309  
 STW1 (control word 1), 175, 190, 193, 196  
 Subindex, 183  
 Suggestions for improvement manual, 453  
 Support, 453  
 Switch off  
   Motor, 153  
   OFF1 command, 153  
   OFF2 command, 153  
   OFF3 command, 153  
 Switch on  
   Motor, 153  
   ON command, 153  
 Switching on inhibited, 154, 175, 190, 193, 197  
 Switching over units, 241  
 Switching-on a motor with BOP-2, 440  
 Symbols, 21  
 System runtime, 351

## T

Technical data  
   Control Unit, 369  
   General, 422  
 Technology controller, 178, 243, 266  
 Telegram  
   Extending, 185  
 Temperature calculation, 236  
 Temperature monitoring, 231, 236

Temperature sensor, 86  
 Temperature switch, 234  
 Terminal block, 106, 155  
 Terminal strip  
   Factory setting, 86  
 Three-wire control, 166, 166  
 Time, 281  
 Time control, 283  
 Time switch, 283  
 TN line system, 69  
 Torque accuracy, 123, 128, 140, 145  
 Total depth, 66  
 Trace function, 445  
 TT line system, 69  
 Two-wire control, 166, 166  
 Type plate  
   Control Unit, 25  
   Power Module, 25

## U

U/f control, 438  
 Unit system, 243  
 Unwinders, 255  
 Upgrading the firmware, 340  
 Upload, 311, 320, 323  
 USB cable, 46  
 USB interface, 136  
 Use for the intended purpose, 25  
 User interfaces, 82  
 UTC (Universal Time Coordinated), 282

## V

V/f characteristic, 219  
 VDC min controller, 262  
 Vector control, 229, 438  
   Sensorless, 227  
 Version  
   Control Unit, 25  
   Power Module, 25  
 Vertical conveyors, 254  
 Voltage boost, 219, 220, 224, 225, 438  
 Voltage input, 160

## W

Winders, 255  
 Wire-break monitoring, 160, 235  
 Write protection, 325, 325

## **Z**

Ziegler Nichols, 269

ZSW1 (status word 1), 177, 191, 194, 198

ZSW3 (status word 3), 179



## Further information

SINAMICS inverter:  
[www.siemens.com/sinamics](http://www.siemens.com/sinamics)

PROFINET:  
[www.siemens.com/profinet](http://www.siemens.com/profinet)

Siemens AG  
Digital Factory  
Motion Control  
Postfach 3180  
91050 ERLANGEN  
GERMANY

Subject to change without prior notice  
© Siemens AG 2009 - 2015

To obtain additional  
information on the  
SINAMICS G120P  
scan the QR code.

