

SIEMENS

SINUMERIK

SINUMERIK 828D, SINAMICS S120 Machine data and interface signals

Parameter Manual

Preface

Explanation of the machine/
setting data **1**

Machine data **2**

NC setting data **3**

Cycles, machine and setting
data **4**

Interface signals - overview **5**

Interface signals - detailed
description **6**

SINAMICS parameters **7**

Appendix A **A**

Valid for

SINUMERIK 828D control system

Software	version
CNC software	2.7
SINAMICS S120	2.6 SP3




04/2011

6FC5397-4DP40-1BA0

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.
CAUTION
without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.
NOTICE
indicates that an unintended result or situation can occur if the relevant information is not taken into account.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

SINUMERIK documentation

The SINUMERIK documentation is organized in the following categories:

- General documentation
- User documentation
- Manufacturer/service documentation

Additional information

You can find information on the following topics at www.siemens.com/motioncontrol/docu:

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following address:

docu.motioncontrol@siemens.com

My Documentation Manager (MDM)

Under the following link you will find information to individually compile OEM-specific machine documentation based on the Siemens content:

www.siemens.com/mdm

Training

For information about the range of training courses, refer under:

- www.siemens.com/sitrain
SITRAIN - Siemens training for products, systems and solutions in automation technology
- www.siemens.com/sinustrain
SinuTrain - training software for SINUMERIK

FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support. <http://support.automation.siemens.com>

SINUMERIK

You can find information on SINUMERIK under the following link:
www.siemens.com/sinumerik

Target group

This documentation is intended for project engineers, commissioning engineers, machine operators and service and maintenance personnel.

Benefits

The intended target group can use the Parameter Manual to test and commission the system or the plant professionally and safely.

Utilization phase: Installation and commissioning phase

Standard scope

This documentation only describes the functionality of the standard version. Additions or revisions made by the machine manufacturer are documented by the machine manufacturer.

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

For the sake of simplicity, this documentation does not contain all detailed information about all types of the product and cannot cover every conceivable case of installation, operation, or maintenance.

Technical Support

You will find telephone numbers for other countries for technical support in the Internet under <http://www.siemens.com/automation/service&support>

Table of contents

	Preface	3
1	Explanation of the machine/setting data	9
1.1	Structure of the data tables	9
1.2	Meaning of table fields.....	10
1.3	Overview of the data.....	16
2	Machine data	19
2.1	Display machine data	19
2.2	General machine data	22
2.3	Channel-specific machine data	107
2.4	Axis-specific machine data	255
3	NC setting data	379
4	Cycles, machine and setting data	417
5	Interface signals - overview	483
5.1	Addressing ranges.....	483
5.2	User data	486
5.2.1	User data 1	486
5.2.2	User data 2	486
5.2.3	Reading/writing NC data: Job	487
5.2.4	Reading/writing NC data: Result	487
5.2.5	PI service: Job	488
5.2.6	PI service: Result	488
5.3	Retentive data area	488
5.4	User alarm	489
5.4.1	User alarm: Activating	489
5.4.2	Variable for alarm	489
5.4.3	Active alarm response	490
5.4.4	Alarm acknowledgement	490
5.5	Signals from/to HMI	491
5.5.1	Program control signals from HMI (retentive area) (also refer to signals at channel DB3200)	491
5.5.2	Program selection via lists	491
5.5.3	Messenger control command	492
5.5.4	Signals from HMI	492
5.5.5	Signals from PLC	492
5.5.6	Signals to maintenance planners	493
5.5.7	Signals from maintenance planners	494
5.5.8	Signals from operator panel (retentive area)	494

5.5.9	General selection/status signals from HMI (retentive area)	495
5.5.10	General selection/status signals to HMI (retentive area)	495
5.6	Auxiliary function transfer from NC channel	496
5.6.1	Decoded M signals (M0-M99)	497
5.6.2	Transferred T functions	497
5.6.3	Transferred M functions	498
5.6.4	Transferred S functions	498
5.6.5	Transferred D functions	498
5.6.6	Transferred H functions	499
5.7	NCK signals	499
5.7.1	General signals to NCK	499
5.7.2	General signals from NCK	500
5.7.3	Signals at fast inputs and outputs	501
5.7.4	Signals from fast inputs and outputs	502
5.8	Channel signals	503
5.8.1	Signals to NC channel	503
5.8.1.1	Control signals to NC channel	503
5.8.1.2	Control signals to axes in Work	505
5.8.2	Signals from NC channel	506
5.8.2.1	Status signals from NC channel	506
5.8.2.2	Status signals, axes in Work	508
5.8.2.3	Additional status signals from NC channel	509
5.8.2.4	Asynchronous subroutines (ASUBs): Job	510
5.8.2.5	Asynchronous subroutines (ASUBs): Result	510
5.8.2.6	G functions from NCK channel	511
5.9	Axis/spindle signals	511
5.9.1	Transferred M and S functions, axis-specific	511
5.9.2	Signals to axis/spindle	511
5.9.2.1	Common signals to axis/spindle	511
5.9.2.2	Signals to axis	513
5.9.2.3	Signals to spindle	513
5.9.2.4	Signals to PLC axis	514
5.9.2.5	Signals to drive	515
5.9.2.6	Signals to technology functions	515
5.9.3	Signals from axis/spindle	516
5.9.3.1	General signals from axis/spindle	516
5.9.3.2	Signals from axis	517
5.9.3.3	Signals from spindle	518
5.9.3.4	Signals from PLC axis	518
5.9.3.5	Signals from drive	519
5.9.3.6	Signals from technology functions	519
5.9.4	Signals from Weiss spindle	520
5.10	Tool management (TM)	521
5.10.1	User interface, loading, unloading and reloading	521
5.10.1.1	Acknowledgements for loading, unloading and reloading, positioning the magazine	521
5.10.1.2	Jobs for loading, unloading and reloading, positioning the magazine	522
5.10.1.3	Feedback signal	523
5.10.1.4	Job status	524

5.10.2	User interface, tool change	524
5.10.2.1	Preparing and carrying out acknowledgements for tool change	524
5.10.2.2	Prepare jobs for tool change and execute.	525
5.10.2.3	Feedback signal	527
5.10.2.4	Job status	528
5.11	PLC machine data	529
5.11.1	INT values (MD 14510 USER_DATA_INT)	529
5.11.2	HEX values (MD 14512 USER_DATA_HEX)	529
5.11.3	FLOAT values (MD 14514 USER_DATA_FLOAT)	530
5.11.4	User alarm: Configuring (MD 14516 USER_DATA_PLC_ALARM)	530
5.12	Signals, synchronized actions	531
5.12.1	Signals, synchronized actions to channel	531
5.12.2	Signals, synchronized actions from channel	531
5.13	Reading and writing PLC variables	532
5.14	TM functions from NC channel	532
5.14.1	Change signals TM functions	532
5.14.2	Transferred tool management functions	533
5.15	Axis actual values and distances-to-go	533
5.16	TM: User interface, transfer and acknowledgement step tables	534
5.16.1	Constant transfer-step table	534
5.16.2	Variable transfer-step table	535
5.16.3	Acknowledgment step table	536
5.17	Maintenance scheduler: User interface	537
5.17.1	Initial (start) data	537
5.17.2	Actual data	538
5.17.3	Easy Extend Interface	539
5.18	User interface for ctrl energy	540
5.18.1	Energy saving profile	540
5.18.2	SentronPac	542
6	Interface signals - detailed description	543
6.1	General information	543
6.2	User alarm	544
6.2.1	Active alarm response	544
6.3	Signals from/to HMI	545
6.3.1	Program control signals from the HMI	545
6.3.2	Signals from HMI	548
6.3.3	Signals from PLC	550
6.3.4	Signals from operator panel	550
6.3.5	General selection/status signals from HMI	551
6.3.6	General selection/status signals to the HMI	553
6.4	Auxiliary function transfer from NC channel	554
6.5	NCK signals	557
6.5.1	General signals to NCK	557
6.5.2	General signals from NCK	558
6.6	Mode signals	560

6.7	Channelspecific signals	565
6.7.1	Signals to channel	565
6.7.2	Signals from NC channel	585
6.8	Axis/spindlespecific signals	600
6.8.1	Transferred axis-specific M, S functions	600
6.8.2	Signals to axis/spindle	602
6.8.3	Signals from axis/spindle	628
6.9	Tool management functions from the NC channel	653
7	SINAMICS parameters	655
7.1	List of parameters	655
A	Appendix A	657
A.1	Documentation overview	657

Explanation of the machine/setting data

1.1 Structure of the data tables

Standard table

The standard table contains all the important information about the data.

MD number	Identifier			Display filter	Reference	
Units	Name			Data type	Activation	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Expanded table

The expanded table includes data from the standard table plus additional rows with system-specific values.

MD number	Identifier			Display filter	Reference	
Units	Name			Data type	Activation	
Attributes						
-	Dimension	Default value	Minimum value	Maximum value	Protection	Class
<System 1>	-	Default value	-	-	-/-	
<System 2>	-	-	-	-	-1/-	

A minus sign "-" in a field means that the same value as for <System 1> applies for the specified system.

The entry "-/-" in the "Protection" field means that the machine data is not available for the specified system.

Example:

10060	POSTCTRL_SYSCLOCK_TIME_RATIO			N01, N05	G3	
-	Factor for position control cycle			DWORD	POWER ON	
SFCO						
828d-me61	-	2	1	31	0/0	S
828d-me81	-	2	1	31	1/1	M
828d-te61	-	2	1	31	0/0	S
828d-te81	-	1	1	31	0/0	S
828d-me41	-	2	1	31	0/0	S
828d-te41	-	2	1	31	0/0	S

1.2 Meaning of table fields

MD number

The "MD number" field contains the machine data number. This number is displayed in the data lists on the user interface of the control.

Identifier

The "Identifier" field contains the unique alphanumeric identifier of the machine data. The machine data is, for example, addressed by means of this identifier (with an additional label) for programming in the part program.

This identifier is displayed in the data lists on the user interface of the control.

Reference

As a cross reference to the functional description of the data, the "Reference" field contains the short designation of the corresponding submanual of a function manual.

Reference is made to the following submanuals:

- Function Manual Basic Functions, submanuals: A2, A3, B1, B2, D1, F1, G2, H2, K1, K2, N2, P1, P4, R1, S1, V1, W1, Z1
- Function Manual Extended Functions, submanuals: A4, F3, H1, K3, K5, M1, M5, P2, R2, S3, S7, T1, W3, Z2
- Function Manual Drive Functions, submanuals: DB1, DD1, DD2, DE1, DF1, DG1, DL1, DM1, DS1, DÜ1
- Function Manual Tool Management, FBWsl
- Function description, ISO Dialects for SINUMERIK, FBFA
- Programming Manual, PG
- Programming Manual Job Planning, PGA

Units/system of units

Depending on MD10240 \$MN_SCALING_SYSTEM_IS_METRIC, the physical units differ as follows:

MD10240=1	MD10240=0
mm	inch
mm/min	inch/min
m/sec ²	inch/sec ²
m/sec ³	Inch/sec ³
mm/rev.	inch/rev.

If the MD is not based on any physical unit, the field is marked with "-".

Note

The default setting is MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = 1 (metric)

Name

The "Name" field contains the name of the data in plain text.

Activation

The "Activation" field contains the action that must be performed by the user in order for a change to take effect.

Activation		User action
po	POWER ON	Otherwise: <ul style="list-style-type: none"> "Reset(po)" softkey Switch voltage off/on
cf	NEW_CONF	Softkey: "Activate MD"
re	RESET	Otherwise: <ul style="list-style-type: none"> "Reset(po)" softkey Program end reset (M02/M30)
so	IMMEDIATELY	After entering a value

The activation levels are listed according to their priority.

- po = highest priority
- so = lowest priority

Protection

The "Protection" field contains the protection level for reading or writing to the data in the form: Read/write.

Value	Protection level
0 or 10	System
1 or 11	Manufacturer
2 or 12	Service
3 or 13	User
4 or 14	Key-operated switch position 3
5 or 15	Key-operated switch position 2
6 or 16	Key-operated switch position 1
7 or 17	Key-operated switch position 0

The protection level for user data (GUD) is defined with the numbers 10 to 17.

Class

These data class attributes from machine, setting and option data are normally derived from the write access of the corresponding data.

The following data classes are available:

Data class	Write rights	Access right
S (System)	System	Protection level 0 (password: System)
M (Manufacturer)	Manufacturer/Service	Protection levels 1 and 2 (password: Service)
I (Individual) Note: Individual machine data are grouped in this data class, e.g. the leadscrew error compensation values. Depending on the contents, these are accessible via different protection levels.	Manufacturer/Service or User	Protection levels 1 and 2 (password: Service) or Protection level 3 (user password)
U (User)	User	Protection level 3 (password: User) Protection levels 4 and 7 (key-operated switch)

Display filter

The "Display filter" field contains the identifier of the data filter setting that enables the data to be seen. Using the filter setting, the exact data areas required at a given time can be selected for display.

ID	Data area
EXP	Expert mode
Drive machine data	
D00	Display signals
D01	Controller data
D02	Monitoring/limiting functions
D03	Message data
D04	Status data
D05	Motor/power unit
D06	Measuring system
D07	Safety Integrated
D08	Standard machine
General machine data	
N01	Configuration/scaling
N02	Memory configuration
N03	PLC machine data
N04	Drive control
N05	Status data/diagnostics
N06	Monitoring/limiting functions

ID	Data area
N07	Auxiliary functions
N08	Corrections/compensations
N09	Technological functions
N10	I/O configuration
N11	Standard machine
A12	NC language, ISO dialect
Channel-specific machine data	
C01	Configuration
C02	Memory configuration
C03	Initial states
C04	Auxiliary functions
C05	Velocities
C06	Monitoring/limiting functions
C07	Transformations
C08	Corrections/compensations
C09	Technological functions
C10	Standard machine
C11	NC language, ISO dialect
Axis-specific machine data	
A01	Configuration (including memory)
A02	Measuring system
A03	Machine geometry
A04	Velocities / accelerations
A05	Monitoring/limiting functions
A06	Spindle
A07	Controller data
A08	Status data
A09	Corrections/compensations
A10	Technological functions
A11	Standard machine
A12	NC language, ISO dialect
Displaying machine data	
H01	ShopMill
H02	ShopTurn
H03	ManualTurn
H04	Access levels
H05	Standard machine

Default value

The "Default value" field contains the value that is used to preset the machine data. If default values for the channels differ, this is indicated by "/".

Some machine data is preset with different default values, depending on the NCU that is used.

Note

Input via HMI is limited to 10 digits plus decimal point and sign.

System

In the "System" field, the control system is specified for which the data with the correspondingly entered values applies.

The following entries are possible: ·

- Default:
The entered values apply to all SINUMERIK 828D. ·
- Deviations in the value range are entered in the following lines of the table, sorted according to the control versions listed:

828d-me61	Milling technology (milling export) PPU 260/261
828d-me81	Milling technology (milling export) PPU 280/281
828d-me41	Milling technology (milling export) PPU 240/241
828d-te61	Turning technology (turning export) PPU 260/261
828d-te81	Turning technology (turning export) PPU 280/281
828d-te41	Turning technology (turning export) PPU 240/241

If this field is empty, the data is valid for all systems.

Dimension

The "Dimension" field contains the number of elements of a data field.

Range of values

The "Minimum value" and "Maximum value" fields contain the lower limit and upper limit, respectively, of the permissible range of the data.

If the "Minimum value" and "Maximum value" fields contain the string " *** ", an explicit range is not defined for this data. In this case, the range is determined by the specified data type.

SINUMERIK data types

The "Data type" field contains the following data types:

Data type	Range of values
BOOLEAN	Machine data bit (1 or 0)
BYTE	Integer values (-128 to 127)
DOUBLE	Real values ($\pm (2.2 * 10^{-308}$ to $1.8 * 10^{+308})$)
DWORD	Integer values (-2147483648 to +2147483647)
DWORD	Hex values (0 to FFFF FFFF)
STRING	Character string (max. 16 characters) consisting of upper-case letters with digits and underscore
UNSIGNED WORD	Integer values (0 to 65536)
SIGNED WORD	Integer values (-32768 to 32767)
UNSIGNED DWORD	Integer values (0 to 4294967300)
SIGNED DWORD	Integer values (-2147483650 to 2147483649)
WORD	Hex values (0000 to FFFF)
FLOAT DWORD	Real values ($\pm (8.43 \times 10^{-37}$ to $3.37 \times 10^{38})$)
UBYTE	Integer values (0 to 255)
LONG	Integer values (4294967296 to 4294967295)

Attributes

The "Attributes" field contains additional attributes of the data:

Attribute	Meaning
NBUP	No Back UP: The data is not backed up as part of the data backup.
ODLD	Only DownLoad: The data can only be written to via an INI file, archive, or from the part program.
NDLD	No DownLoad: The data can only be written to via the HMI user interface.
SFCO	SaFety COnfiguration: Component of the "Safety Integrated" function
SCAL	SCaling ALarm: Scaling data; when changed, alarm 4070 is displayed
LINK	LINK description: The data describes a link cluster, component of the "NCU Link" function
CTEQ	ConTainer EQual: The data must be the same for all axes in an axis container, component of the "Axis container" function
CTDE	ConTainer DEscription: The data describes an axis container, component of the "Axis container" function

1.3 Overview of the data

Machine and setting data (SINUMERIK)

The machine and setting data are divided into the following areas:

Range	Designation
from 9000 to 9999	Displaying machine data
from 10000 to 18999	General NC machine data
from 19000 to 19999	Reserved
from 20000 to 28999	Channel-specific machine data
from 29000 to 29999	Reserved
from 30000 to 38999	Axis-specific machine data
from 39000 to 39999	Reserved
from 41000 to 41999	General setting data
from 42000 to 42999	Channel-specific setting data
from 43000 to 43999	Axis-specific setting data
from 51000 to 51299	General configuration machine data
from 51300 to 51999	General cycle machine data
from 52000 to 52299	Channel-specific configuration machine data
from 52300 to 52999	Channel-specific cycle machine data
from 53000 to 53299	Axis-specific configuration machine data
from 53300 to 53999	Axis-specific cycle machine data

Data Identifiers

The identifier (designator) specified in the data description is displayed on the HMI user interface. However, if the data is addressed in the parts program, for example, the identifier of the relevant data area must precede the data identifier (designator).

Identifier	Data area
\$MM_	Displaying machine data
\$MN_ / \$SN_ \$MNS_ / \$SNS_	General machine/setting data
\$MC_ / \$SC_ \$MCS_ / \$SCS_	Channel-specific machine/setting data
\$MA_ / \$SA_ \$MAS_ / \$SAS_	Axis-specific machine/setting data

Characters	Meanings
\$	System variables
M	Machine data (first letter)
S	Setting data (first letter)
M, N, C, A, D	Subarea (second letter)
S	Siemens data (third letter)

Note

Axis-specific data can also be addressed with the axis name as an index. The internal axis identifier (AX1, AX2, AX3, etc.) or the identifier specified in MD10000 \$MA_AX_CONF_NAME_TAB can be used as the axis name.

Example: \$MA_JOG_VELO[Y1]=2000

The JOG velocity of axis Y1 is 2000 mm/min.

If the content of a machine data is a STRING (e.g., X1) or a hexadecimal value (e.g., H41), the content must be enclosed in single quotation marks (e.g., 'X1' or 'H41').

Example: \$MN_DRIVE_INVERTER_CODE[0]='H14'

A feed drive (FD) module with a power rating of 9/18 A is inserted in the first slot of the drive bus.

Example: \$MA_FIX_POINT_POS[0,X1]=500.000

The value 500 is assigned to the first fixed point position on axis 1.

Examples:

\$MN_AUXFU_GROUP_SPEC[2]='H41'

Output instant in time of the auxiliary functions of the 3rd auxiliary function group.

\$MN_AXCONF_MACHAX_NAME_TAB[0]='X1'

String "X1" is assigned as name for the first machine axis.

\$MA_REFP_SET_POS[0,X1]=100.00000

A value of 100 mm is assigned to the first reference point of axis X1.

Examples:

Assignment to channel-specific machine data:

```

CHANDATA(1)                ; Selection of the first channel
$MC_CHAN_NAME='CHAN1'      ; Name of the first channel
$MC_AXCONF_GEOAX_NAME_TAB[1]='Y' ; Name of the 2nd geometry axis
                               ; of the first channel 'Y'
R10=33,75                  ; R10 of the first channel

```


Product: Handbuch_Sinumerik, Version: V13.0, Language: eng
Objects:

2.1 Display machine data

Number	Identifier			Display filters	Reference	
Unit	Name			Data type	Active	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

9006	DISPLAY_SWITCH_OFF_INTERVAL			-	-	
-	Time for screen saver			DWORD	PowerOn	
-						
-	-	60	0	180	7/3	M

Description: This machine data defines the time in minutes after which the screen automatically switches to dark if no key has been pressed on the keyboard in the meantime. The value 0 disables automatic light/dark switching.

Note:
The screen is only switched light/dark automatically when IS screen dark = 0.

Related to:
IS screen dark (DB19, ... DBX0.1)

9009	KEYBOARD_STATE			-	-	
-	Keyboard shift behavior at booting			BYTE	PowerOn	
-						
-	-	0	0	2	7/3	M

Description: This machine data defines the Shift behavior (SW-CAPSLOCK) of the keyboard. Basic configuration of the Shift behavior of the keyboard

0: SW-CAPSLOCK OFF
2: SW-CAPSLOCK ON

9032	HMI_MONITOR			-	-	
-	Define PLC data for HMI screen info			STRING	PowerOn	
-						
-	-		-	-	7/1	M

Description: Pointer, with offset, to a PLC data block. This is required to report HMI monitor information to the PLC, e.g active HMI task.

Format: PLC-specific format for specifying a data block with byte offset, e.g. DB60.DBB10 for data block 60, byte 10.

The monitor information reported by the HMI has a maximum length of 8 bytes.

2.1 Display machine data

9056	ALARM_ROTATION_CYCLE	-	-			
-	Rotation cycle time for alarm display	DWORD	PowerOn			
-						
-	-	0	0	10000	7/3	M

Description: Rotation cycle time in the alarm display:
 <500: no rotation in the alarm line
 500 - 10000: cycle duration of alarm rotation in milliseconds
 If a valid cycle time has been set, all alarms are displayed in the alarm line one after the other.
 Each alarm is displayed for the specified time until it is replaced by the next alarm.
 If no alarm is present, cycle alarms or program messages are displayed, if required. However, these do not rotate.

9100	CHANGE_LANGUAGE_MODE	-	-			
-	Language selection mode	BYTE	Immediately			
-						
-	-	1	1	2	7/3	I

Description: Language selection mode is defined:
 1 = directly via selection list
 2 = via setting of the 1st and 2nd language

9102	SHOW_TOOLTIP	-	-			
-	Display tooltip	BYTE	Immediately			
-						
-	-	1	0	1	7/3	U

Description: If the MD has been set to 1, tooltips will be displayed.

9103	TOOLTIP_TIME_DELAY	-	-			
s	Time delay tooltip display	BYTE	Immediately			
-						
-	-	1	0	60	7/3	U

Description: Time delay for display of the tooltips in seconds.

9105	HMI_WIDE_SCREEN	-	-			
-	Display of the HMI as wide screen with OEM area always visible	BYTE	PowerOn			
-						
-	-	0	0	1	7/2	M

Description: Display of the HMI as wide screen. Above the HMI there is a separate application field that is designed by the machine manufacturer.

9106	SERVE_EXTCALL_PROGRAMS	-	-			
-	Process EXTCALL calls	BYTE	PowerOn			
-						
-	-	1	0	1	7/3	M

Description: HMI processes reload requirements of the NC for EXTCALL calls.

9107	DRV_DIAG_DO_AND_COMP_NAMES	-	-			
-	Expanded drive diagnostics: DO and components	BYTE	Immediately			
-						
-	-	0	0	3	7/3	I

Description:

- 0: DO and component type names
- 1: Real DO names and component type names
- 2: DO type names and real component names
- 3: Reale DO names and real component names

9108	ENABLE_EPS_SERVICES	-	-			
-	Activation of ePS Network services	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: If the machine data has been set to 1, the "ePS Network services" softkey appears as the operating area.

9110	ACCESS_HMI_EXIT	-	-			
-	Protection level of exit softkey	BYTE	PowerOn			
-						
-	-	1	0	7	7/2	M

Description: Protection level for the exit softkey (HMI restart) in the operating area menu

9900	MD_TEXT_SWITCH	-	-			
-	Plaintexts instead of MD identifier	BOOLEAN	Immediately			
-						
-	-	0	-	-	7/3	U

Description: If the MD has been set to 1, clear text is displayed on the operator panel instead of the machine data identifiers.

9990	SW_OPTIONS	-	-			
-	Enable HMI software options	DWORD	Immediately			
-						
-	-	0	-	-	1/1	I

Description: Here you can enable the HMI software options

2.2 General machine data

Number	Identifier			Display filters	Reference	
Unit	Name			Data type	Active	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

10000	AXCONF_MACHAX_NAME_TAB			N01, N11	K2,F1,G2,F2,K5,M1	
-	Machine axis name			STRING	PowerOn	
-						
828d-me41	31	MX1,MY1,MZ1,MSP1,MA1...	-	-	2/2	M
828d-me61	31	MX1,MY1,MZ1,MSP1,MA1...	-	-	2/2	M
828d-me81	31	MX1,MY1,MZ1,MSP1,MA1...	-	-	2/2	M
828d-te61	31	MX1,MZ1,MC1,MSP1,MQ1...	-	-	2/2	M
828d-te81	31	MX1,MZ1,MC1,MSP1,MQ1...	-	-	2/2	M
828d-te41	31	MX1,MZ1,MC1,MSP1,MQ1...	-	-	2/2	M

Description: List of the machine axis identifiers.

The name of the machine axis is entered in this MD.

In addition to the fixed, defined machine axis identifiers "AX1", "AX2" ..., user-defined identifiers for the machine axes can also be assigned in this data.

The identifiers defined here can be used parallel to the fixed, defined identifiers for addressing axial data (e.g. MD) and machine axis-related NC functions (reference point approach, axial measurement, travel to fixed stop).

Special cases:

- The input machine axis name must not conflict with the names and assignments of the geometry axes (MD20060 \$MC_AXCONF_GEOAX_NAME_TAB, MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB) or channel axes (MD20080 \$MC_AXCONF_CHANAX_NAME_TAB, MD20070 \$MC_AXCONF_MACHAX_USED).
- The input machine axis name must not be the same as the names for Euler angles (MD10620 \$MN_EULER_ANGLE_NAME_TAB), names for path-relevant orientation (MMD10624 \$MN_ORIPATH_LIFT_VECTOR_TAB), names for normal vectors (MD10630 \$MN_NORMAL_VECTOR_NAME_TAB), names for directional vectors (MD10640 \$MN_DIR_VECTOR_NAME_TAB), names for rotation vectors (MD10642 \$MN_ROT_VECTOR_NAME_TAB), names for intermediate vector components (MD10644 \$MN_INTER_VECTOR_NAME_TAB), names for intermediate circle point coordinates with CIP (MD10660 \$MN_INTERMEDIATE_POINT_NAME_TAB) or the names for interpolation parameters (MD10650 \$MN_IPO_PARAM_NAME_TAB).

- The input machine axis name must not include any of the following reserved address letters:

D Tool offset	(D function)	E Reserved
F Feedrate	(F function)	G Preparatory function
H Auxiliary function	(H function)	L Subroutine call
M Miscellaneous function	(M function)	N Subblock
P Subroutine number of passes		R Arithmetic parameters
S Spindle speed	(S function)	T Tool (T function)

The name must not include any keywords (e.g. DEF, SPOS etc.) or pre-defined identifiers (e.g. ASPLINE, SOFT).

The use of an axis identifier consisting of a valid address letter (A, B, C, I, J, K, Q, U, V, W, X, Y, Z), followed by an optional numerical extension (1-99) gives slightly better block cycle times than a general identifier.

If no identifier is assigned to a machine axis, then the predefined name ("AXn") applies to the nth machine axis.

Related to:

MD20060 \$MC_AXCONF_GEOAX_NAME_TAB (geometry axis name in the channel [GEO-Axisno.]

MD20080 \$MC_AXCONF_CHANAX_NAME_TAB (channel axis name in the channel [Channelaxisno.]

10075	PLC_CYCLE_TIME	N01, N05		-		
-	PLC cycle time	DOUBLE		PowerOn		
-						
-	-	0.0	-	-	1/RO	M

Description: Display of the PLC cycle time (not modifiable !)

It is compiled internally from MD10071 \$MN_IPO_CYCLE_TIME and MD10074 \$MN_PLC_IPO_TIME_RATIO.

10088	REBOOT_DELAY_TIME	EXP		K3		
s	Reboot delay	DOUBLE		Immediately		
-						
-	-	0.2	0.0	1.0	2/2	M

Description: The reboot following PI "_N_IBN_SS" is delayed by the time MD10088 \$MN_REBOOT_DELAY_TIME.

The suppressable NOREADY alarm 2900 is triggered immediately by PI "_N_IBN_SS".

If MD10088 \$MN_REBOOT_DELAY_TIME falls below the MD36620 \$MA_SERVO_DISABLE_DELAY_TIME value of an axis, the axis is decelerated during MD10088 \$MN_REBOOT_DELAY_TIME. The servo enable is then disabled. That is, the full MD36620 \$MA_SERVO_DISABLE_DELAY_TIME is NOT waited.

Alarm 2900 does not become active if MD10088 \$MN_REBOOT_DELAY_TIME = 0.0, and there is no reboot delay.

The NCK waits beyond the stated delay time until the PI has been able to be acknowledged to the HMI. The total delay time may be as much as 2 s.

10136	DISPLAY_MODE_POSITION	N01			-	
-	Display mode for actual position in the WCS	DWORD			Reset	
-						
-	-	1	0	1	1/1	M

Description:

Defines how the position and the distance to go are displayed in the WCS.

0: Display as in software version 5 and earlier

1: At end of block, the actual value display is in principle the same as the programmed end point, irrespective of where the machine actually is (e.g. as a result of the tool radius compensation). The distance to go is the same as the actual distance to be traversed. This means that the displayed actual position has to be the same as the displayed end position minus the distance to go, irrespective of the actual machine position. If the block end points are changed by chamfers, radii, contour definitions, splines or SAR in comparison to the NC program, then these changes are reflected in the display as if they had been programmed. This does not apply to changes resulting from tool radius compensation or smoothing.

10190	TOOL_CHANGE_TIME	N01			BA	
-	Tool changing time for simulation	DOUBLE			PowerOn	
-						
-	-	0.	-	-	1/1	M

Description:

This data defines how much time is estimated for a tool change (only relevant for a simulation).

10192	GEAR_CHANGE_WAIT_TIME	N01			S1	
s	Gear stage change waiting time	DOUBLE			PowerOn	
-						
-	-	10.0	0.0	1.0e5	1/1	M

Description:

External events which trigger reorganization, wait for the end of a gear stage change. GEAR_CHANGE_WAIT_TIME now determines the waiting time for the gear stage change. Time unit in seconds.

When this time expires without the gear stage change having been terminated, the NCK reacts with an alarm.

Among others, the following events will cause reorganization:

User ASUB

Mode change

Delete distance-to-go

Axis replacement

Activate user data

10200	INT_INCR_PER_MM			N01	G2,K3	
-	Calculation resolution for linear positions			DOUBLE	PowerOn	
LINK						
828d-me41	-	100000.	1.0	1.0e9	2/2	M
828d-me61	-	100000.	1.0	1.0e9	2/2	M
828d-me81	-	100000.	1.0	1.0e9	2/2	M
828d-te61	-	1000.	1.0	1.0e9	2/2	M
828d-te81	-	1000.	1.0	1.0e9	2/2	M
828d-te41	-	1000.	1.0	1.0e9	2/2	M

Description:

This MD defines the number of internal increments per millimeter.

The accuracy of the input of linear positions is limited to the calculation accuracy by rounding the product of the programmed value and the calculation accuracy to an integer.

In order to keep the executed rounding easily understandable it is useful to use powers of 10 for the calculation accuracy.

10210	INT_INCR_PER_DEG			N01	G2,K3,R2	
-	Calculation resolution for angular positions			DOUBLE	PowerOn	
LINK						
828d-me41	-	100000.	1.0	1.0e9	2/2	M
828d-me61	-	100000.	1.0	1.0e9	2/2	M
828d-me81	-	100000.	1.0	1.0e9	2/2	M
828d-te61	-	1000.0	1.0	1.0e9	2/2	M
828d-te81	-	1000.0	1.0	1.0e9	2/2	M
828d-te41	-	1000.0	1.0	1.0e9	2/2	M

Description:

This MD defines the number of internal increments per degree.

The accuracy of the input of angular positions is limited to the calculation accuracy by rounding the product of the programmed value and the calculation accuracy to an integer.

In order to keep the executed rounding easily understandable it is useful to use powers of 10 for the calculation accuracy.

10240	SCALING_SYSTEM_IS_METRIC			N01	G2,K3,A3,S1	
-	Basic system metric			BOOLEAN	PowerOn	
SCAL						
-	-	TRUE	-	-	2/2	M

Description:

The MD defines the basic system used by the control for scaling length-dependent physical variables for data input/output.

All corresponding data are stored internally in the basic units of 1 mm, 1 degree and 1 sec.

In the case of access from the interpreter (part program and download), from the operator panel (variable service) or through external communication, scaling takes place in the following units:

MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = 1: scaled in:
mm, mm/min, m/s², m/s³, mm/rev.

MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = 0: scaled in:
inch, inch/min, inch/s², inch/s³, inch/rev.

2.2 General machine data

The selection of the basic system also defines the interpretation of the programmed F value for linear axes:

	metric	inch
G94	mm/min	inch/min
G95	mm/rev.	inch/rev.

If this machine data is changed, a startup is required because otherwise the associated machine data that have physical units would be incorrectly scaled. Proceed as follows:

- MD changed manually

First start up and then enter the associated machine data with physical units.

- MD changed via machine data file

First start up and then reload the machine data file so that the new physical units are taken into account.

If the machine data are altered, alarm 4070 "Scaling machine data altered" is output.

Application example(s):

Setup is in the metric system and then changed over to the inch system.

Special cases, errors:

The factor used for changing from 1 mm to 1 inch can be changed with MD10250 \$MN_SCALING_VALUE_INCH.

10284	DISPLAY_FUNCTION_MASK			EXP, N01	-	
-	BTSS-variable lastBlockNoStr active			DWORD	PowerOn	
-						
-	-	0x0	-	-	1/1	M

Description:

Bit mask for parameterizing various display variables:

BitNo. Hexadec. Meaning with bit set value

Bit0: 0x1

Parameters are assigned to the OPI variable lastBlockNoStr in the SPARP and SPARPP blocks.

Bit1: 0x2

Concerns the OPI variable cmdSpeed in the SPARPP block. If the bit is set, the variable returns the programmed speed even if the spindle is at a standstill or in another mode (positioning mode, axis mode).

Bit2: 0x4

Concerns the OPI variable cmdSpeed in the SPARPP block. (reserved for constant cutting speed)

Bit8: 0x100

Servotrace manages larger numerical values internally. Overruns in data format are avoided. The accuracy may be reduced with large numerical values.

10350	FASTIO_DIG_NUM_INPUTS			N10	A4,TE1	
-	Number of active digital NCK input bytes			BYTE	PowerOn	
-						
-	-	2	1	5	2/2	M

Description: The number of bytes of the digital NCK inputs that can be used on the control are defined in this machine data.

These digital NCK inputs can be read directly by the part program. Moreover, the signal state at the HW inputs can also be changed by the PLC.

If more digital NCK inputs are defined in the machine data than are available in the control hardware, a signal status of 0 is set in the control for the inputs that do not exist in the hardware. The NCK value can be altered by the PLC.

Related to:

NC/PLC interface signal DB2800 DBX0 (Disable the digital NCK inputs 1-8);
NC/PLC interface signal DB2800 DBB1000 (Disable the external digital inputs 9-40)

NC/PLC interface signal DB2800 DBX1 (PLC setting for digital NCK inputs 1-9)

NC/PLC interface signal DB2800 SBB1001 (PLC values for external digital inputs 9-40)

NC/PLC interface signal DB2900 DBX0,4,1000,1004 (Actual value for digital NCK inputs)

10360	FASTIO_DIG_NUM_OUTPUTS			N10	A4,TE8	
-	Number of active digital NCK output bytes			BYTE	PowerOn	
-						
-	-	2	0	5	2/2	M

Description: The number of bytes for digital NCK outputs that can be used on the control are defined in this machine data.

These digital NCK outputs can be set directly by the part program. The PLC is able to

- set the digital outputs to "0" in a defined way with NC/PLC interface signal DB2800 DBX4,1008 (Disable the digital NCK outputs).
- alter the NCK value with NC/PLC interface signal DB2800 DBX5,1009 (Overwrite mask for digital NCK outputs).
- specify a PLC value with NC/PLC interface signal DB2800 DBX7,1011 (Setting mask for digital NCK outputs).

If more digital NCK outputs are defined in the machine data than are available in the control hardware, no alarm is triggered. The signal states specified by the part program can be read by the PLC.

Special cases:

Digital NCK outputs 5 to 8 can be processed only by the PLC (no hardware outputs).

Related to:

NC/PLC interface signal DB2800 DBX4,1008 (Disable the digital NCK outputs)

NC/PLC interface signal DB2800 DBX5,1009 (Overwrite mask for digital NCK outputs)

NC/PLC interface signal DB2800 DBX6,1001 (PLC setting value for digital NCK outputs)

2.2 General machine data

NC/PLC interface signal DB2800 DBX7,1011 (Setting mask for digital NCK outputs)
 NC/PLC interface signal DB2900 DBX4,1004 (Setpoint for digital NCK outputs)

10361	FASTIO_DIG_SHORT_CIRCUIT			N10	A4	
-	Short circuit of digital inputs and outputs			DWORD	PowerOn	
-						
-	10	0,0,0,0,0,0,0,0,0	-	-	1/1	M

Description: Defined short circuits between digital output and input signals of the high-speed NCK I/Os are realized by linking the signals read in from the high-speed NCK I/Os or the PLC interface to defined output signals.
 The output signals always remain unchanged by the link, the inputs that have to be taken into account internally arise from the read inputs and the link. If a plurality of output bits are specified for one input bit in overwrite mode, the last defined assignment in the list determines the result.
 The definition of non-existent or non-activated inputs/outputs is ignored without an alarm.
 Bits 0-7: Number of the input byte to be written (1 - 5)
 Bits 8-15: Bit number within the input byte (1 - 8)
 Link:
 The type of link is selected by adding a hexadecimal number to the input bit number:
 00 Overwrite input identically to output
 A0 Input is AND-gated to the read input with the status of the stated output
 B0 Input is OR-gated to the read input with the status of the stated output
 Bits 16-23: Number of the output byte to be used (1 - 5)
 Bits 24-31: Bit number within the output byte (1 - 8)
 Example:
 \$MN_FASTIO_DIG_SHORT_CIRCUIT[0] = 0x04010302
 Input: 3rd bit of the 2nd byte
 Output: 4th bit of the 1st byte (= 4th onboard NCU output)
 The input status is overwritten by the specified output
 \$MN_FASTIO_DIG_SHORT_CIRCUIT[1] = 0x0705A201
 Input: 2nd bit of the 1st byte (= 2nd onboard NCU input)
 Output: 7th bit of the 5th byte
 The input status is AND-gated with the specified output
 \$MN_FASTIO_DIG_SHORT_CIRCUIT[2] = 0x0103B502
 Input: 5th bit of the 2nd byte
 Output: 1st bit of the 3rd byte
 The input status is OR-gated with the specified output
 Related to:
 MD10350 \$MN_FASTIO_DIG_NUM_INPUTS,
 MD10360 \$MN_FASTIO_DIG_NUM_OUTPUTS.
 References: /FB/, A4, "Digital and Analog NCK I/Os"

10366	HW_ASSIGN_DIG_FASTIN			N10	A4,TE1	
-	Hardware assignment of external digital NCK inputs			DWORD	PowerOn	
-						
-	10	0x00010101,0x00010102	0x0	0x00010102	2/2	M

Description:

For PROFIBUS/PROFINET:

1st + 2nd byte indicate the logical start address of the I/O slot on the PROFIBUS/PROFINET:

Value 0000 means NO active slot

Values 0001..0100 are reserved for the PLC process image (the value of input slots can be read by the NCK without errors; however, output slots are forbidden in this range, and cause an alarm on power up)

1st byte = LowByte of the logical start address

2nd byte = HighByte of the logical start address

3rd byte = 0 = without meaning

4th byte = 5 = segment no. for PROFIBUS/PROFINET

Module no.: 1 ... MD_MAXNUM_SIMO611D_AXES:

Number of the logical slot in which the terminal block with the external I/Os is inserted. The logical slot is assigned to a physical slot by MD13010 \$MN_DRIVE_LOGIC_NR, it is activated by MD13000 \$MN_DRIVE_IS_ACTIVE.

1st + 2nd bytes give the logical start address of the I/O slot on the PROFIBUS

1st byte = low byte

2nd byte = high byte

Value 0000 means NO active slots

Values 0001..007F are reserved for the PLC (NCK can also read the value for input slots without error, but output slots are forbidden in this range and lead to an alarm during startup)

Values 0080..02FF are valid

Values > 02FF are invalid

Example:

HW_ASSIGN_DIGITAL_FASTIN[3] = '05000302'

1st + 2nd byte: 0302 (hex) = logical start address 770 (decimal)

3rd byte: 00 = no significance

4th byte: 05 = ID for PROFIBUS/PROFINET

Related to:

MD10368 \$MN_HW_ASSIGN_DIG_FASTOUT

MD10362 \$MN_HW_ASSIGN_ANA_FASTIN

MD10364 \$MN_HW_ASSIGN_ANA_FASTOUT

10368	HW_ASSIGN_DIG_FASTOUT			N10	A4	
-	Hardware assignment of external digital NCK outputs			DWORD	PowerOn	
-						
-	4	0x00010101,0x00010102	0x0	0x00010102	2/2	M

Description:

For PROFIBUS/PROFINET:

1st + 2nd byte indicate the logical start address of the I/O slot on the PROFIBUS/PROFINET:

Value 0000 means NO active slot

Values 0001..0100 are reserved for the PLC process image (the value of input slots can be read by the NCK without errors; however, output slots are forbidden in this range, and cause an alarm on power up)

1st byte = LowByte of the logical start address

2nd byte = HighByte of the logical start address

3rd byte = 0 = without meaning

4th byte = 5 = segment no. for PROFIBUS/PROFINET

The individual bytes are explained under MD10366 \$MN_HW_ASSIGN_DIG_FASTIN.

[hw] = Index (0 to 3) for addressing the external digital output bytes

Related to:

MD10366 \$MN_HW_ASSIGN_DIG_FASTIN

MD10362 \$MN_HW_ASSIGN_ANA_FASTIN

MD10364 \$MN_HW_ASSIGN_ANA_FASTOUT

10530	COMPAR_ASSIGN_ANA_INPUT_1			N10	A4	
-	Hardware assignment of analog inputs for comparator byte 1			BYTE	PowerOn	
-						
-	8	0,0,0,0,0,0,0	-	-	2/2	M

Description:

This MD assigns analog inputs 1 to 8 to a bit number of comparator byte 1. This input bit of the comparator is set to "1" if the comparison between the applied analog value and the associated threshold value (SD41600 \$SN_COMPAR_THRESHOLD_1 fulfills the condition parameterized in (MD10540 \$MN_COMPAR_TYPE_1).

An analog input can be assigned to a plurality of comparator input bits.

The following generally applies to comparator byte 1:

COMPAR_ASSIGN_ANA_INPUT_1 [b] = n

with index: b = number of comparator input bit (0 to 7)

n = number of analog input (1 to 8)

Example:

```

COMPAR_ASSIGN_ANA_INPUT_1[0] = 1
COMPAR_ASSIGN_ANA_INPUT_1[1] = 2
COMPAR_ASSIGN_ANA_INPUT_1[2] = 1
COMPAR_ASSIGN_ANA_INPUT_1[3] = 3
COMPAR_ASSIGN_ANA_INPUT_1[4] = 3
COMPAR_ASSIGN_ANA_INPUT_1[5] = 1
COMPAR_ASSIGN_ANA_INPUT_1[6] = 1
COMPAR_ASSIGN_ANA_INPUT_1[7] = 1

```

Analog input 1 affects input bits 0, 2, 5, 6 and 7 of comparator byte 1
 Analog input 2 affects input bit 1 of comparator byte 1
 Analog input 3 affects input bits 3 and 4 of comparator byte 1
 Related to:

MD10540 \$MN_COMPAR_TYPE_1
 MD10541 \$MN_COMPAR_TYPE_2

10531	COMPAR_ASSIGN_ANA_INPUT_2	N10	A4
-	Hardware assignment of analog inputs for comparator byte 2	BYTE	PowerOn
-			
-	8	0,0,0,0,0,0,0	-
			2/2
			M

Description: This MD assigns analog inputs 1 to 8 to a bit number of comparator byte 2. This input bit of the comparator is set to "1" if the comparison between the applied analog value and the associated threshold value (SD41601 \$SN_COMPAR_THRESHOLD_2 fulfills the condition parameterized in (MD10541 \$MN_COMPAR_TYPE_2).

An analog input can be assigned to a plurality of comparator input bits. The following generally applies to comparator byte 2:

COMPAR_ASSIGN_ANA_INPUT_2 [b] = n
 with index: b = number of comparator input bit (0 to 7)
 n = number of analog input (1 to 8)

Example:

COMPAR_ASSIGN_ANA_INPUT_2[0] = 1
 COMPAR_ASSIGN_ANA_INPUT_2[1] = 2
 COMPAR_ASSIGN_ANA_INPUT_2[2] = 1
 COMPAR_ASSIGN_ANA_INPUT_2[3] = 3
 COMPAR_ASSIGN_ANA_INPUT_2[4] = 3
 COMPAR_ASSIGN_ANA_INPUT_2[5] = 1
 COMPAR_ASSIGN_ANA_INPUT_2[6] = 1
 COMPAR_ASSIGN_ANA_INPUT_2[7] = 1

Analog input 1 affects input bits 0, 2, 5, 6 and 7 of comparator byte 2

Analog input 2 affects input bit 1 of comparator byte 2

Analog input 3 affects input bits 3 and 4 of comparator byte 2

Related to:

MD10540 \$MN_COMPAR_TYPE_1
 MD10541 \$MN_COMPAR_TYPE_2

10540	COMPAR_TYPE_1	N10	A4
-	Parameterization for comparator byte 1	DWORD	PowerOn
-			
-	0	-	2/2
			M

Description: This MD can be used to make the following settings for the individual output bits (0 to 7) of comparator byte 1:

- Bits 0 to 7: Comparison type mask (for comparator output bits 0 to 7)
 Bit = 1: output bit = 1 if analog value >= threshold value
 Bit = 0: output bit = 1 if analog value < threshold value
 (Threshold value defined by SD41600 \$SN_COMPAR_THRESHOLD_1)
- Bits 8 to 15: Not used (defined to be set to 0)

- Bits 16 to 23: Assignment of a HW output byte for outputting the comparator states (statement of the byte address)
 - Byte = 0: No output via digital NCK outputs
 - Byte = 1: Output via digital onboard NCK outputs (1 to 4)
 - Byte = 2: Output via external digital NCK outputs 9 to 16
 - Byte = 3: Output via external digital NCK outputs 17 to 24
 - Byte = 4: Output via external digital NCK outputs 25 to 32
 - Byte = 5: Output via external digital NCK outputs 33 to 40
- Bits 24 to 31: Inversion mask for the output of the comparator states (bits 0 to 7)
 - Bit = 0: Output bit is not inverted
 - Bit = 1: Output bit is inverted

Related to:

- MD10530 \$MN_COMPAR_ASSIGN_ANA_INPUT_1
- MD10531 \$MN_COMPAR_ASSIGN_ANA_INPUT_2
- SD41600 \$SN_COMPAR_THRESHOLD_1
- SD41601 \$SN_COMPAR_THRESHOLD_2
- MD10360 \$MN_FASTIO_DIG_NUM_OUTPUTS

10541	COMPAR_TYPE_2	N10	A4
-	Parameterization of comparator byte 2	DWORD	PowerOn
-			
-	-	0	-
-			2/2 M

Description:

This MD can be used to make the following settings for the individual output bits (0 to 7) of comparator byte 2:

- Bits 0 to 7: Comparison type mask (for comparator output bits 0 to 7)
 - Bit = 1: output bit = 1 if analog value >= threshold value
 - Bit = 0: output bit = 1 if analog value < threshold value
 (Threshold value defined by SD41601 \$SN_COMPAR_THRESHOLD_2)
- Bits 8 to 15: not used (defined to be set to 0)
- Bits 16 to 23: Assignment of a HW output byte for outputting the comparator states (statement of the byte address)
- Byte = 0: no output via digital NCK outputs
 - Byte = 1: output via digital onboard NCK outputs (1 to 4)
 - Byte = 2: output via external digital NCK outputs 9 to 16
 - Byte = 3: output via external digital NCK outputs 17 to 24
 - Byte = 4: output via external digital NCK outputs 25 to 32
 - Byte = 5: output via external digital NCK outputs 33 to 40
- Bits 24 to 31: Inversion mask for the output of the comparator states (bits 0 to 7)
 - Bit = 0: Output bit is not inverted
 - Bit = 1: Output bit is inverted

Related to:

- MD10530 \$MN_COMPAR_ASSIGN_ANA_INPUT_1
- MD10531 \$MN_COMPAR_ASSIGN_ANA_INPUT_2
- SD41600 \$SN_COMPAR_THRESHOLD_1
- SD41601 \$SN_COMPAR_THRESHOLD_2
- MD10360 \$MN_FASTIO_DIG_NUM_OUTPUTS

10600	FRAME_ANGLE_INPUT_MODE			EXP, N01, N09	K2	
-	Sequence of rotation in FRAME			BYTE	PowerOn	
-						
-	-	1	1	2	1/1	M

Description: FRAME_ANGLE_INPUT_MODE sets how the rotations (ROT and AROT) around the three geometry axes are defined if more than one rotation is programmed in a block. The order in which these rotations are programmed within the block is irrelevant.

The rotations can be set to be calculated according to:

- Euler angle with FRAME_ANGLE_INPUT_MODE = 2

The rotations are calculated according to the Euler angle in the following order:

1. Rotation around Z
2. Rotation around X
3. Rotation around Y

- RPY with FRAME_ANGLE_INPUT_MODE = 1

The rotations are calculated according to the Euler angle in the following order:

1. Rotation around Z
2. Rotation around Y
3. Rotation around X

10602	FRAME_GEOAX_CHANGE_MODE			EXP, N01, N09	K2	
-	Frames when changing geometry axes			BYTE	PowerOn	
-						
-	-	1	0	5	1/1	M

Description: Geometry axes can be switched over in the following states:

- Selection and deselection of transformations
- Switchable geometry axes GEOAX()

The current total frame is then defined as follows:

0: The current total frame is canceled.

1: The current total frame is recalculated when geometry axes are switched over. Translations, scaling and mirroring for the new geometry axes become active. The rotations of the old geometry axes still apply.

2: The current total frame is recalculated when geometry axes are switched over. Translations, scaling and mirroring for the new geometry axes become active. If rotations were active before switching over to the current base frames, current settable frame or programmable frame, switchover is aborted with an alarm.

3: The current total frame is deleted when selecting and deselecting transformations. When the GEOAX() command is entered, the frame is recalculated and translation, scaling and mirroring for the new geometry axes become active. The rotations of the old geometry axes still apply.

10612	MIRROR_TOGGLE			EXP, N01, N09	K2	
-	Mirror toggle			BYTE	PowerOn	
-						
-	-	1	0	1	1/1	M

Description:

Mirror toggle function.

1: Programmed axis values are not evaluated. Toggle switching behavior.

0: Programmed axis values are evaluated.

The axes are mirrored in the case of values not equal to 0 if they are not already mirrored. Mirroring is disabled if the value is 0.

10617	FRAME_SAVE_MASK			EXP	K2	
-	Behavior of frames in SAVE subroutines			DWORD	PowerOn	
-						
-	-	0	0	0x3	1/1	M

Description:

This machine data is used to define which frames are restored with SAVE attribute at return from a subprogram.

Bit 0: Settable frames G54 through G599

Value = 0:

If the same G code is active at subprogram return and subprogram call, the active settable frame is maintained. If not, the settable frame is reactivated when the subprogram is called.

Value = 1:

At subprogram return, the settable frame is reactivated when the subprogram is called.

Bit 1: Basic frame

Value = 0:

The active basic frame is not changed at subprogram return. This is also the case, if a basic frame change is carried out in the subprogram by an operation or by an implicit frame deselection (possibly through TRAF00F).

Value = 1:

At subprogram return, the basic frame is reactivated when the subprogram is called.

10682	CONTOUR_SAMPLING_FACTOR			N01, EXP	-	
-	Contour sampling factor			DOUBLE	Reset	
-						
-	-	1.0	-	-	1/1	M

Description:

This factor defines the maximum time interval in which a curved contour is sampled in the interpolator.

The maximum sampling time results from the set interpolation cycle (see MD10071 \$MN_IPO_CYCLE_TIME), the factor set with this data, and the tolerance set for the geometry axes in MD33100 \$MA_COMPRESS_POS_TOL[[]].

The minimum sampling time cannot be shorter than the time set in MD10680 \$MN_MIN_CONTOUR_SAMPLING_TIME.

10690	DRAW_POS_TRIGGER_TIME	EXP, N01	-
s	Trigger time for IPO event 'DRAW_POS'	DOUBLE	NEW CONF
-			
-	-	0.3	0
		30	1/1
			M

Description: This can be used to set a time within which an IPO event for position output will always be generated. If a value smaller than the current interpolation cycle is entered here, the trigger will only be activated according to the maximum chord length in the case of complex geometries and in the last interpolation cycle in the case of non-complex geometries.

10700	PREPROCESSING_LEVEL	N01, N02	V2, K1
-	Program preprocessing level	BYTE	PowerOn
-			
-	-	0x25	-
			1/1
			M

Description:

Bit 0= 0:
No preprocessing

Bit 0= 1:
The call description of the cycles is formed during control power on. All the programs in the directories `_N_CUS_DIR`, `_N_CMA_DIR` and `_N_CST_DIR` can be called in the part program without `EXTERNAL` declaration. If the parameter interface of a cycle is changed in the control, then this change does not become active until after Power On.

Bit 1=1:
During control power on, all cycles in the directories `_N_CUS_DIR`, `_N_CMA_DIR` and `_N_CST_DIR` are preprocessed to form a process-optimizing compilation. These cycles are then processed more quickly. Changes to the cycle programs do not become active until after the next Power On.

Bit 2=1:
During control power on, the Siemens cycles in the directory `_N_CST_DIR` are preprocessed to form a process-optimizing compilation (from SW 3.5).

Bit 3=1:
During control power on, the user cycles in the directory `_N_CUS_DIR` are preprocessed to form a process-optimizing compilation (from SW 3.5).

Bit 4=1:
Preprocessing the user cycles in the directory `_N_CMA_DIR`

Bit 5=1:
All files marked with `PREPRO` in the `PROG` statement line are preprocessed (from SW 6.4)

Bit 5=0:
During control power on, all cycles in the directories activated by bits 1 to 4 are preprocessed. This also applies to programs that are not marked with `PREPRO`.

Bit 6=1:
The compilation is stored in SRAM if there is inadequate space in DRAM (from SW 7.1).

Memory space is required for preprocessing cycles. Better utilization of memory can be achieved by selective setting of the preprocessing:

The runtime-critical cycles are brought together in one directory. The remaining cycles are in the other directory.

References:
/PG/, "Programming Guide Fundamentals" (`EXTERNAL` declaration)

10702	IGNORE_SINGLEBLOCK_MASK	N01	K1,Z1
-	Prevents stopping at specific blocks in single block mode	DWORD	PowerOn
-			
-	-	0xC013	0
-		0x1FFFF	1/1
			M

Description:

This machine data prevents stopping at certain blocks with single block.

Single block stop can be prevented with the following bits of the mask:

Bit0 = 1

Means that there is no stop in any internal ASUB block. Exception: The single block stop has been explicitly activated by the SBLON command.

There are three different internal ASUBs that are triggered by different events.

- Repos: In the case of the events: change of operating mode to a manual mode (JOG, JOGREF, etc.) unless MODESWITCH_MASK is not set, switch skip block on and off, activate machine data, switch-on overstore, axis replacement, subroutine level abort, switch-on single block, switch dry run feedrate on and off, alarm with compensation block.

- Return: Delete distance-to-go, switchover after TEACH-IN, or deselection of MDI with corresponding MODESWITCH_MASK.

- _N_PROG_EVENT_SPF: Parameterizing MD 20108 \$MC_PROG_EVENT_MASK parameterizes the events whereby _N_PROG_EVENT_SPF is executed.

Bit1 = 1

Means that there is no stop in any user ASUB block. Exception: The single block stop has been explicitly activated via the SBLON command.

User ASUBs are linked to an interrupt channel by the part program command SETINT or via the PI- _N_ASUP__. The interrupt channel is then activated via PLC or the high-speed inputs, and the user ASUBs are retracted.

This disables machine data MD20117 \$MC_IGNORE_SINGLEBLOCK_ASUP. The NCK behavior corresponds to the machine data assignment MD20117 \$MC_IGNORE_SINGLEBLOCK_ASUP= FFFFFFFF.

Bit2 = 1

Means that there is no stop in any intermediate block. Intermediate blocks are generated at, among other events, tool change, ADIS and complicated geometry.

Bit3 = 1

Means that there is no stop in the block search pickup block. The block search pickup block is the 1st block that is loaded into the main run at the start after the search target has been found in the program.

Bit4 = 1

Means that there is no stop in the INIT blocks. INIT blocks are generated from reset immediately after a part program start.

Bit5 = 1

Means that there is no stop in any subprogram block with the parameter DISPLOF.

Bit6 = 1

Means that there is no stop in any block in which the NCK cannot reorganize.

Reorganize is an internal procedure that is needed for mode change after JOG/JOGREF..., switch skip block on and off, activate machine data, axis replacement, switch on overstore, switch on single block, switch dry run feedrate on and off, subroutine level abort, user ASUBs delete distance-

to-go, switchover after TEACH-IN. Reorganize is never needed in Reset state.

Example blocks in which reorganize is impossible:

- Tool change
- 1st block after the Repos procedure
- Block after an ASUB from JOG/aborted

Bit7 = 1

Means that there cannot be a stop in any block in which repositioning is impossible.

Reposition is an internal procedure that is needed for mode change after JOG/JOGREF..., switch skip block on and off, activate machine data, axis replacement, switch on overstore, switch on single block, switch dry run feedrate on and off, subroutine level abort, and possibly user ASUBs. Reposition is never needed in Reset state.

Example blocks in which reposition is impossible:

- G33 + blocks in which reorganize is impossible.

Bit8 = 1

Means that there is no stop in a residual block that does not contain traversing information.

Bit9 = 1

Means that there is no stop in a run in/main run synchronization block (e.g. STOPRE, \$Variable) that is repeated because of an interruption with Reorg (e.g. mode change).

Bit10= 1

Means that there is no stop in a "tool selection block". "Tool selection block" only occurs with tool management (magazine management or TMMG) active. This block gives the corresponding tool change command to the PLC. This block is generally generated by T programming from the part program. Example block "N1010 T="Drill" M6 D1"

Depending on machine data, the "tool selection block" can be held in the interpolator until the PLC has acknowledged the corresponding tool change (see MD20310 \$MC_TOOL_MANAGEMENT_MASK). However the program status remains in "run".

Bit11= 1

The control has to automatically generate implicit GET blocks for the axis replacement function (axis replacement: 2 or more channels control one axis alternately) if no explicit GET(D) has been programmed and the following block wants to traverse the axis. (The other channel had previously used this axis).

An explicitly programmed GET may appear as follows "getd(x1,y1,z1) or get(x1,y1,z1)".

There is no stop at explicit or implicit GET blocks in the single block with this bit 11.

Bit12= 1

There is no stop in the single block type 2 in the SBLON block.

Bit13= 1

If an axis is pulled out in the middle of a block and possibly assigned to another channel, then there is no stop at the PREMATURE end of this block. This block follows a REPOSA in order to traverse it to the end, there is no stop until this end has been reached.

Bit14=1

In a part program line, in which a substitution subroutine is called due to NC language replacement, only one stop is performed under the condition that the subroutine includes PROC attribute SBLOF. It is irrelevant whether the subroutine is called at block start and/or end or whether it is exited with M17 or RET.

Bit15=1

Means that there is no stop in any user ASUB block. Exception: The single block stop has been explicitly activated via the SBLON command. There are three different internal ASUBs that are triggered by different events.

- Repos: In the case of the events: change of operating mode to a manual mode (JOG, JOGREF,...) unless MODESWITCH_MASK is not set, switch skip block on and off, activate machine data, switch-on overstore, axis replacement, subroutine level abort, switch-on single block, switch dry run feedrate on and off, alarm with compensation block.
- Return: Delete distance-to-go, switchover after TEACH-IN, or deselection of MDI with corresponding MODESWITCH_MASK.

Bit16=1

Activating SERUPRO (search run via prog test) prevents stopping at single blocks.

Related to:

MD20117 \$MC_IGNORE_SINGLEBLOCK_ASUP

10704	DRYRUN_MASK			N01	V1	
-	Dry run feedrate activation			BYTE	PowerOn	
-						
-	-	0	0	2	7/2	M

Description:

DRYRUN_MASK == 0

Dryrun can only be switched on or off at the end of the block.

When DRYRUN_MASK = 1 is set, the dry run feedrate can also be activated during program execution (in the part program block).

NOTICE!

After activating dry run feedrate, the axes are stopped for the duration of the reorganization process.

DRYRUN_MASK == 2

Dryrun can be switched on or off in every phase and the axes are not stopped.

NOTICE:

However, the function does not become active until a "later" block in the program execution and this is with the next (implicit) StopRe block.

Related to:

SD42100 \$SC_DRY_RUN_FEED

10706	SLASH_MASK			N01	PG,A2	
-	Activation of block skip			BYTE	PowerOn	
-						
-	-	0	0	2	1/1	M

Description: If SLASH_MASK = 0, skip block can only be activated when stopped at the end of the block
 If SLASH_MASK = 1, skip block can also be activated during program execution.
 NOTICE!
 After activating skip block, the axes are stopped for the duration of the reorganization process.
 If SLASH_MASK = 2, skip block can be activated in every phase.
 Notice!
 However, the function does not become active until a "later" block in the program execution, and this is with the next (implicit) StopRe block.

10707	PROG_TEST_MASK			N01	K1	
-	Program test mode			DWORD	PowerOn	
-						
-	-	0x1	0	0x7	1/1	M

Description: Bit-coded mask for program test
 Bit 0 == 1 Program test cannot be deselected in 'Stopped' program status.
 Bit 1 == 1 Enable to activate the program test using the PI command_N_NCKMOD
 Bit 2 == 1 Activation of program test via VDI using accelerated feed
 Bits 3..31 As yet unused.

10708	SERUPRO_MASK			N01	K1	
-	Search run modes			DWORD	PowerOn	
-						
-	-	0	0	31	1/1	M

Description: Bit-coded mask for block search via program test (abbr. SERUPRO).
 SERUPRO block search is activated with the PI service _N_FINDBL mode parameter == 5.
 SERUPRO means SEarchRUn by PROgram test; in other words, proceed under program test from start of program to search target. Note: Program test does not move any axes.
 Bit 0 == 0
 There is a stop at M0 during the search phase.
 Bit 0 == 1
 There is no stop at M0 during the search phase.
 Bit 1 == 0
 Alarm 16942 aborts the search phase on part programm command START.
 Bit 1 == 1
 Alarm 16942 is switched off.
 NOTICE:
 A start program command might actually start the other channel!

2.2 General machine data

Bit 2 == 0
Switches the function "Group Serupro" off

Bit 2 == 1
Switches the function "Group Serupro" on.
"Group-Serupro" enables a search routine in which the start part program command is changed into a search routine for the other channel.

Bit 3 == 0
Forces all channels that have started SERUPRO to end SERUPRO simultaneously unless they are aborted via Reset or the channel reaches M30 without finding the search target. In other words, all channels that find the search target (including self-acting SERUPRO) terminate SERUPRO simultaneously.

Bit 3 == 1
Switches this function off

Bit 4 == 0
Take external override into account in SERUPRO.

Bit 4 == 1
An external override (sent via PLC signal or MCP) is ignored during SERUPRO.

Bit 5 .. 31
As yet unused.

10709	PROG_SD_POWERON_INIT_TAB	EXP, N01	K1
-	Setting data to be initialized	DWORD	PowerOn
-			
-	30	43200,43202,0,0,0,0,0, 0,0,0,0,0,0,0,0,0,0,0...	2/2 M

Description: Setting data to be initialized:
The values of the programmable SD indicated in this MD are set to their initial values on control power up.
Programmable setting data are:

	(GCODE)
SD42000 \$SC_THREAD_START_ANGLE	SF
SD42010 \$SC_THREAD_RAMP_DISP	DITS/DITE
SD42400 \$SC_PUNCH_DWELLTIME	PDELAYON
SD42800 \$SC_SPIND_ASSIGN_TAB	SETMS
SD43200 \$SA_SPIND_S	S wih G94,G95,G97,G971,G972
SD43202 \$SA_SPIND_CONSTCUT_S	S with G96,G961,G962
SD43210 \$SA_SPIND_MIN_VELO_G25	G25 S
SD43220 \$SA_SPIND_MAX_VELO_G26	G26 S
SD43230 \$SA_SPIND_MAX_VELO_LIMS	LIMS
SD43300 \$SA_ASSIGN_FEED_PER_REV_SOURCE	FPRON
SD43420 \$SA_WORKAREA_LIMIT_PLUS	G26
SD43430 \$SA_WORKAREA_LIMIT_MINUS	G25
SD43700 \$SA_OSCILL_REVERSE_POS1	OSP1
SD43710 \$SA_OSCILL_REVERSE_POS2	OSP2

10712	NC_USER_CODE_CONF_NAME_TAB		EXP, N01, N12	TE1,B1	
-	List of reconfigured NC codes		STRING	PowerOn	
-					
-	200	G58,G59,G505,G58,G506...	-	-	1/0 M

Description: List of identifiers of the NC codes reconfigured by the user.
The list is to be structured as follows:
Even address: Identifier to be changed
Subsequent odd address: New identifier
The following three types of NC codes can be reconfigured:
1. G codes e.g.: G02, G64, ASPLINE...
2. NC addresses e.g.: RND, CHF, ...
3. Pre-defined subprograms e.g.: CONTPRON, ...

10713	M_NO_FCT_STOPRE		EXP, N12, N07	H2	
-	M function with preprocessing stop		DWORD	PowerOn	
-					
-	15	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	-	-	2/2 M

Description: The M functions defined by MD10713 \$MN_M_NO_FCT_STOPRE perform an implicit preprocessing stop.
That is, the interpretation of the next part program line will be stopped until the block with the M function defined in that way has been processed completely
(PLC acknowledgement, motion, etc.).

10714	M_NO_FCT_EOP		EXP, N07	K1,H2	
-	M function for spindle active after reset		DWORD	PowerOn	
-					
-	-	32	-	-	1/1 M

Description: For spindles where a '2' is configured in MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET, no spindle reset is enabled with this M function when the part program is terminated. The spindle therefore remains active after the end of the part program.
Proposal: M32
Restrictions: see MD10715 \$MN_M_NO_FCT_CYCLE
Related to:
MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET
MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE
For external language mode:
MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR

For nibbling:

MD26008 \$MC_NIBBLE_PUNCH_CODE

10715	M_NO_FCT_CYCLE			EXP, N12, N07	H2,K1	
-	M function to be replaced by a subroutine			DWORD	PowerOn	
-						
828d-me41	30	6	-	-	2/2	M
828d-me61	30	6	-	-	2/2	M
828d-me81	30	6	-	-	2/2	M
828d-te61	30	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	-	-	2/2	M
828d-te81	30	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	-	-	2/2	M
828d-te41	30	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	-	-	2/2	M

Description:

M number with which a subprogram is called.

The name of the subprogram is stated in MD10716 \$MN_M_NO_FCT_CYCLE_NAME[n]. If the M function defined with MD10715 \$MN_M_NO_FCT_CYCLE[n] is programmed in a part program block, the subprogram defined in MD10716 \$MNM_NO_FCT_CYCLE_NAME[n] is started at the end of the block. If the M function is programmed again in the subprogram, there is no longer substitution by a subprogram call. MD10715 \$MN_M_NO_FCT_CYCLE[n] acts both in Siemens mode G290 and in external language mode G291.

The subprograms configured with MD10716 \$MN_M_NO_FCT_CYCLE_NAME[n] and MD10717 \$MN_T_NO_FCT_CYCLE_NAME must not be active simultaneously in one block (line of a part program). This means that no more than one M/T function replacement can be active in any one block. Neither an M98 nor a modal subprogram call can be programmed in a block with the M function replacement. Subprogram return and end of part program are also not permitted. Alarm 14016 is output in the event of a conflict.

Restrictions:

M functions with a fixed meaning and configurable M functions are checked for conflicting settings. A conflict is reported with an alarm.

The following M functions are checked:

- M0 to M5,
- M17, M30,
- M19,
- M40 to M45,
- M function for spindle/axis mode switchover according to MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR (default: M70),
- M functions for nibbling/punching as configured in MD26008 \$MC_NIBBLE_PUNCH_CODE if activated by MD26012 \$MC_PUNCHNIB_ACTIVATION.
- M19, M96-M99 for applied external language (MD18800 \$MN_MM_EXTERN_LANGUAGE).

Exception: The M function for the tool change defined by MD22560 \$MC_TOOL_CHANGE_M_CODE.

10716	M_NO_FCT_CYCLE_NAME			EXP, N12, N07	K1	
-	Subroutine name for M function replacement			STRING	PowerOn	
-						
828d-me41	30	L6	-	-	2/2	M
828d-me61	30	L6	-	-	2/2	M
828d-me81	30	L6	-	-	2/2	M
828d-te61	30		-	-	2/2	M
828d-te81	30		-	-	2/2	M
828d-te41	30		-	-	2/2	M

Description:

The machine data contains the name of the cycle. This cycle is called if the M function has been programmed from MD10715 \$MN_M_NO_FCT_CYCLE.

If the M function is programmed in a motion block, the cycle is executed after the motion.

MD10715 \$MN_M_NO_FCT_CYCLE is active in both Siemens mode G290 and in external language mode G291.

If a T number is programmed in the call block, then the programmed T number can be polled in the cycle under the variable \$P_TOOL.

M and T function replacements must not be programmed simultaneously in one block. This means that not more than one M or T function replacement may be active in any one block.

Neither an M98 nor a modal subprogram call may be programmed in a block with M function replacement.

Moreover, neither subprogram return nor part program end are allowed.

Alarm 14016 is issued if there is a conflict.

Related to:

MD10715 \$MN_M_NO_FCT_CYCLE,
MD10717 \$MN_T_NO_FCT_CYCLE_NAME

10717	T_NO_FCT_CYCLE_NAME			EXP, N12, N07	K1	
-	Name of tool-changing cycle for T function replacement			STRING	PowerOn	
-						
828d-me41	-		-	-	2/2	M
828d-me61	-		-	-	2/2	M
828d-me81	-		-	-	2/2	M
828d-te61	-	TCHANGE	-	-	2/2	M
828d-te81	-	TCHANGE	-	-	2/2	M
828d-te41	-	TCHANGE	-	-	2/2	M

Description:

Cycle name for tool change routine on call-up with a T function.

If a T function is programmed in a part program block, the subprogram defined in T_NO_FCT_CYCLE_NAME is called at the end of the block.

The T number programmed can be polled in the cycle via system variables \$C_T / \$C_T_PROG as a decimal value and via \$C_TS / \$C_TS_PROG as a string (only with tool management). MD10717 \$MN_T_NO_FCT_CYCLE_NAME is active both in Siemens mode G290 and in external language mode G291.

MD10716 \$MN_M_NO_FCT_CYCLE_NAME and MD10717 \$MN_T_NO_FCT_CYCLE_NAME must not be active in one block at the same time, i.e. no more than one M/T function replacement can be active per block. Neither an M98 nor a modal subprogram call can be programmed in a block with a T function replacement. Furthermore, neither subprogram return nor part program end are allowed.

Alarm 14016 is output in the event of a conflict.

Related to:

MD10715 \$MN_M_NO_FCT_CYCLE,
MD10716 \$MN_M_NO_FCT_CYCLE_NAME

10718	M_NO_FCT_CYCLE_PAR	EXP, N12, N07	K1
-	M function replacement with parameters	DWORD	PowerOn
-			
-	-	-1	-
-	-	-	-
			2/2
			M

Description: If an M function replacement was configured with MD10715 \$MN_M_NO_FCT_CYCLE[n] / MD10716 \$MN_M_NO_FCT_CYCLE_NAME[n], a parameter transfer via system variable can be specified for one of these M functions using MD10718 \$MN_M_NO_FCT_CYCLE_PAR, in the same way as T function replacement. The parameters stored in the system variables always refer to the part program line where the M function to be replaced was programmed.

The following system variables are available:

\$C_ME : Address extension of the replaced M function
 \$C_T_PROG : TRUE if address T was programmed
 \$C_T : Value of address T (Integer)
 \$C_TE : Address extension of address T
 \$C_TS_PROG : TRUE if address TS was programmed
 \$C_TS : Value of address TS (string, only with tool management)
 \$C_D_PROG : TRUE if address D was programmed
 \$C_D : Value of address D
 \$C_DL_PROG : TRUE if address DL was programmed
 \$C_DL : Value of address DL

10719	T_NO_FCT_CYCLE_MODE	EXP, N12, N07	K1
-	Setting of T function substitution	DWORD	PowerOn
-			
-	-	0	0
-	-	7	7
			2/2
			M

Description: This machine data parameterizes the execution of the replacement subprogram for the tool and tool offset selection.

Bit 0 = 0:

D or DL number is transferred to the replacement subprogram (default value)

Bit 0 = 1:

The D or DL number is not transferred to the replacement subprogram if the following conditions are fulfilled: \$MC_TOOL_CHANGE_MODE = 1 Programming D/DL with T or M function with which the tool change cycle is called, in a part program line.

2.2 General machine data

Bit 1 = 0
 Execution of the replacement subprogram at end of block (default value)

Bit 1 = 1
 Execution of the replacement subprogram at block start

Bit 2 = 0:
 Execution of the replacement subprogram according to the settin of bit 1

Bit 2 = 1:
 Execution of the replacement subprogram at block start and at end of block.

10720	OPERATING_MODE_DEFAULT			N01	H2	
-	Setting of mode after power ON			BYTE	PowerOn	
-						
-	10	7,7,7,7,7,7,7,7	0	12	1/1	M

Description: Default modes of the mode groups after power ON.
 If no mode is selected by the PLC, all the channels associated with mode group n are in the mode preset by OPERATING_MODE_DEFAULT[n -1] after power ON:

- 0 = Automatic mode
- 1 = Automatic mode, submode REPOS
- 2 = MDI mode
- 3 = MDI mode, submode REPOS
- 4 = MDI mode, submode Teach In
- 5 = MDI mode, submode Reference point approach
- 6 = JOG mode
- 7 = JOG mode, submode Reference point approach
- 8 = AUTO mode, submode Teach In
- 9 = AUTO mode, submode Teach In, submode Reference point approach
- 10 = AUTO mode, submode Teach In, submode Repos
- 11 = MDI mode, submode Teach In, submode Reference point approach
- 12 = MDI mode, submode Teach In, submode Repos

10735	JOG_MODE_MASK			EXP, N01	K1	
-	Settings for JOG mode			DWORD	PowerOn	
-						
-	-	0x01	0	0xff	1/1	M

Description: Bit 0:
 Enables JOG in automatic.
 JOG is enabled in automatic when all channels in the mode group are in the RESET state and no channel of the DRF mode group has been selected. The mode group changes internally to JOG with the +/- key and the handwheel, and the axis moves. After the JOG motion has ended, a change back to AUTO is also made internally.

Bit 1:
 Position with AxFrame.
 The function 'JOG to position' considers all axial frames and, in the case of an axis configured as geometry axis, the tool length offset.

Bit 2:

Travel in opposite direction.

The functions 'JOG to position' and 'Approach machine fixed point manually' allow travel in opposite direction, i.e. away from the specified position.

Bit 3:

Tool radius offset.

MD21020 \$MC_WORKAREA_WITH_TOOL_RADIUS is active with JOG motions of the geometry axes.

Bit 4:

Alarm suppression operating range limit in the basic coordinate system in JOG.

Alarms that would be output in JOG when an operating range limit is reached in the basic coordinate system, are suppressed.

Bit 5:

Alarm suppression operating range limit in the workpiece coordinate system in JOG.

Alarms that would be output in JOG when an operating range limit is reached in the workpiece coordinate system, are suppressed.

Bit 6, 7:

JOG of circles:

Bit 7 and bit 6 = 0: traversing the 2nd geometry axis of the active plane to PLUS for radius increase, traversing to MINUS for radius decrease independently of inner or outer machining being active.

Bit 7 = 1 and bit 6 = 0: traversing the 2nd geometry axis of the active plane to PLUS always travels in the direction of the limiting circle. This means that the radius is increased on inner machining and decreased on outer machining.

Bit 7 = 1 and bit 6 = 1: traversing the 2nd geometry axis of the active plane to MINUS always travels in the direction of the limiting circle. This means that the radius is increased on inner machining and decreased on outer machining.

Bits 8-31:

Currently unassigned.

10750	SPRINT_FORMAT_P_CODE			N12	PGA	
-	String coding of the SPRINT format %P			DWORD	PowerOn	
-						
-	-	0	0	2	1/1	M

Description:

Description:

Specification of the character or punched tape code used to code the string which the SPRINT command generates with format control character %P:

0: ASCII

1: ISO (DIN66024)

2: EIA (RS-244)

10751	SPRINT_FORMAT_P_DECIMAL		N12	PGA		
-	Parameterization of the SPRINT format %P		DWORD	PowerOn		
-						
-	-	0	0	1	1/1	M

Description:

Description:

Parameterization of the format description %n.mP of the SPRINT command

Value range:

0: The format specification %n.mP generates a string from a transfer parameter of type REAL or INT consisting of an integer with n + m places. The first n places represent the integer places and the following m places the decimal places of the transfer parameter. Missing decimal places are filled with 0. If there are more than m decimal places, the number is rounded. Missing integer places are filled with spaces.

1: The format specification %n.mP generates a string from a transfer parameter of type REAL or INT that consists of a decimal number with up to n integer places, the decimal point and m decimal places, which are filled with 0 or rounded as necessary.

10760	G53_TOOLCORR		N12	FBFA		
-	Method of operation of G53, G153 and SUPA		DWORD	NEW CONF		
-						
-	-	0	0	3	2/2	M

Description:

With this MD you define whether tool length offset and tool radius offset are also to be suppressed with language commands G53, G153 and SUPA

The machine data is bit-coded.

Bit 0 = 0: G53, G153 and SUPA cause block-by-block suppression of work offsets. The active tool length offset and tool radius offset remain active.

Bit 0 = 1: G53, G153 and SUPA cause block-by-block suppression of work offsets, active tool length offset and tool radius offset. The tool length behavior can be modified with bit 1.

Bit 1 is only evaluated, if the value of bit 0 is 1.

Bit1 = 0: with bit 0 set, the tool length is always suppressed with G53, G153 and SUPA.

Bit1 = 1: with bit 0 set the tool length is only suppressed with G53, G153 and SUPA, if a cutting edge is not selected in the same block (this can also be the cutting edge that is already active).

10804	EXTERN_M_NO_SET_INT		EXP, N12	H2,K1		
-	M function to activate ASUB		DWORD	PowerOn		
-						
-	-	96	-	-	2/2	M

Description:

M function number used to activate an interrupt program (ASUB) in ISO2/3 mode. The interrupt program is always started by the 1st high-speed input of the numerical control.

The M number defined in the machine data replaces M96 in external language mode.

Restrictions: Refer to MD10715 \$MN_M_NO_FCT_CYCLE

Related to:

MD10714 \$MN_M_NO_FCT_EOP,

MD10715 \$MN_M_NO_FCT_CYCLE,

MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR

For nibbling:

\$MC_NIBBLE_PUNCH_CODE

10806	EXTERN_M_NO_DISABLE_INT	EXP, N12	H2,K1
-	M function to deactivate ASUB	DWORD	PowerOn
-			
-	-	97	-
-	-	-	2/2
-	-	-	M

Description: M function number used to deactivate an interrupt program (ASUB) in ISO2/3 mode.

The M number defined in the machine data replaces M97 in external language mode.

Restrictions: refer to MD10715 \$MN_M_NO_FCT_CYCLE

MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR

For nibbling:

MD26008 \$MC_NIBBLE_PUNCH_CODE

10808	EXTERN_INTERRUPT_BITS_M96	EXP, N12	FBFA
-	Activate interrupt program (ASUB)	DWORD	PowerOn
-			
-	-	0	-
-	-	-	2/2
-	-	-	M

Description: Setting the various bits can influence the processing of the interrupt routine activated by M96 P...

Bit 0 = 0,

No interrupt program possible, M96/M97 are normal M functions

Bit 0 = 1,

Using M96/M97 to activate an interrupt program is allowed

2.2 General machine data

Bit 1 = 0,
 Continue processing part program at the final position of the next block after the interrupt block

Bit 1 = 1,
 Continue processing part program from interrupt position

Bit 2 = 0,
 The interrupt signal immediately interrupts the current block and starts the interrupt routine

Bit 2 = 1,
 The interrupt routine will not be started until the end of the block

Bit 3 = 0,
 Interrupt machining cycle at an interrupt signal

Bit 3 = 1,
 Do not start interrupt program until the end of a machining cycle.

10810	EXTERN_MEAS_G31_P_SIGNAL	EXP, N12	FBFA
-	Config. of measuring inputs for G31 P..	BYTE	PowerOn
-			
-	4	1,1,1,1	0
		3	2/2
			M

Description: This machine data defines the assignment of measurement inputs 1 and 2 to the P numbers programmed with G31 P1 (- P4). The machine data is bit-coded. Only bits 0 and 1 are evaluated. For example, if bit 0 = 1 in MD10810 \$MN_EXTERN_MEAS_G31_P_SIGNAL[1], the 1st measurement input is activated with G31 P2. If MD10810 \$MN_EXTERN_MEAS_G31_P_SIGNAL[3]=2, the 2nd measurement input is activated with G31 P4.

Bit 0: = 0, Do not evaluate measurement input 1 with G31 P1 (- P4)
 Bit 0: = 1, Activate measurement input 1 with G31 P1 (- P4)
 Bit 1: = 0, Do not evaluate measurement input 2 with G31 P1 (- P4)
 Bit 1: = 1, Activate measurement input 2 with G31 P1 (- P4)

10812	EXTERN_DOUBLE_TURRET_ON	EXP, N12	FBFA
-	Double turret with G68	BOOLEAN	PowerOn
-			
-	-	FALSE	-
			2/2
			M

Description: This machine data is used to determine whether double-slide machining (channel synchronization for 1st and 2nd channel) is to be started using G68 or whether the second tool of a double turret (= two closely-linked tools at a distance defined in the MD42162 SC_EXTERN_DOUBLE_TURRET_DIST) is to be activated.

FALSE:
 Channel synchronization for double-slide machining

TRUE:
 Load 2nd tool of a double turret (that is, activate \$SC_EXTERN_DOUBLE_TURRET_DISTANCE as additive zero offset and mirroring around Z axis)

10814	EXTERN_M_NO_MAC_CYCLE		EXP, N12	H2,K1	
-	Macro call via M function		DWORD	PowerOn	
-					
-	30	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	-	-	2/2 M

Description: A macro is called with this M number.
The name of the subprogram is stated in MD10815
\$MN_EXTERN_M_NO_MAC_CYCLE_NAME[n].
If the M function specified with MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE[n] is programmed in a part program block, the subprogram defined in MD10815 \$MN_EXTERN_M_NO_MAC_CYCLE_NAME[n] is started. All addresses programmed in the block are written into the corresponding variables.
If the M function is programmed again in the subprogram, there is no longer a replacement by a subprogram call.
MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE[n] is only active in the external language mode G291.
The subprograms configured with MD10815 \$MN_EXTERN_M_NO_MAC_CYCLE_NAME[n] must not be active simultaneously in a block (part program line), i.e. only one M function replacement can become active in any one block. Neither an M98 nor a modal subprogram call may be programmed in the block with the M function replacement.
Subprogram return and the part program end are also not permitted. Alarm 14016 is issued in case of a conflict. Restrictions: see MD10715
\$MN_M_NO_FCT_CYCLE
Related to:
MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE
For external language mode:
MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR
For nibbling:
MD26008 \$MC_NIBBLE_PUNCH_CODE

10815	EXTERN_M_NO_MAC_CYCLE_NAME		EXP, N12	H2	
-	Name of subroutine for M function macro call		STRING	PowerOn	
-					
-	30		-	-	2/2 M

Description: Name of the subprogram started by a call via the M function defined by MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE[n].

10816	EXTERN_G_NO_MAC_CYCLE			EXP, N12	FBFA	
-	Macro call via G function			DOUBLE	PowerOn	
-						
-	50	-1.,-1.,-1.,-1.,-1.,-1.,-1.,-1.,-1.,-1....	-	-	2/2	M

Description:

G number for calling a macro.

The name of the subprogram is stated in MD10817

\$MN_EXTERN_G_NO_MAC_CYCLE_NAME[n].

If the G function specified with MD10816 \$MN_EXTERN_G_NO_MAC_CYCLE[n] is programmed in a part program block, the subprogram defined in MD10817 \$MN_EXTERN_M_NO_MAC_CYCLE_NAME[n] is started. All addresses programmed in the block are written in the corresponding \$C_xx variables.

No subprogram call is executed if a subprogram call is already active via an M/G macro or an M replacement. If a standard G function is programmed in this case, this code is executed. Otherwise, alarm 12470 is issued.

MD10816 \$MN_EXTERN_G_NO_MAC_CYCLE[n] is only active in the external language mode G291.

Only a single subprogram call may be included in any one block. This means that only a single M/G function replacement may be programmed in a block, and no additional subprogram (M98) or cycle call may be included in the block.

Furthermore, a subprogram return and a part program end are not permitted in the same block.

Alarm 14016 is issued in case of a conflict.

10817	EXTERN_G_NO_MAC_CYCLE_NAME			EXP, N12	FBFA	
-	Name of subroutine for G function macro call			STRING	PowerOn	
-						
-	50		-	-	2/2	M

Description:

Name of the subprogram started by call via the G function defined by MD10816 \$MN_EXTERN_G_NO_MAC_CYCLE[n].

10818	EXTERN_INTERRUPT_NUM_ASUP			EXP, N12	FBFA	
-	Interrupt number for ASUB start (M96)			BYTE	PowerOn	
-						
-	-	1	1	8	2/2	M

Description:

Number of the interrupt input starting an asynchronous subprogram activated in ISO mode. (M96 <program number>)

10820	EXTERN_INTERRUPT_NUM_RETRAC			EXP, N12	FBFA	
-	Interrupt number for rapid retraction (G10.6)			BYTE	PowerOn	
-						
-	-	2	1	8	2/2	M

Description:

Number of the interrupt input triggering rapid retraction to the position programmed with G10.6 in ISO mode.

10830	EXTERN_PRINT_DEVICE			EXP, N12	FBFA	
-	Output device for ISOPRINT			STRING	PowerOn	
-						
-	-		-	-	2/2	M

Description:

Path of output device for ISOPRINT

10831	EXTERN_PRINT_MODE			EXP, N12	FBFA	
-	Parameterize output device for ISOPRINT			DWORD	PowerOn	
-						
-	-	0	0	63	2/2	M

Description: Parameterize output device for ISOPRINT
 Bit 0: 0= Synchronous output
 1= Asynchronous output
 Bit 1: 0= Exclusive assignment
 1= Shared assignment
 Bit 2: Output of DC2 (H12) on opening
 Bit 3: Output of DC4 (H14) on closing
 Bit 4: Output string concluded with LF
 Bit 5: Output string concluded with CR + LF

10881	MM_EXTERN_GCODE_SYSTEM			N01, N12	FBFA	
-	ISO_3 Mode: GCodeSystem			DWORD	PowerOn	
-						
828d-me41	-	0	0	2	0/0	S
828d-me61	-	0	0	2	0/0	S
828d-me81	-	0	0	2	0/0	S
828d-te61	-	0	0	2	2/2	M
828d-te81	-	0	0	2	2/2	M
828d-te41	-	0	0	2	2/2	M

Description: Definition of the GCodeSystem to be actively executed in ISO_3 Mod (turning):
 Value = 0 : ISO_3: Code system B
 Value = 1 : ISO_3: Code system A
 Value = 2 : ISO_3: Code system C

10882	NC_USER_EXTERN_GCODES_TAB			N12	FBFA	
-	List of user-specific G commands of an external NC language			STRING	PowerOn	
-						
-	60		-	-	2/2	M

Description: List of G commands of external NC languages which have been reconfigured by the user.
 The implemented G commands are to be taken from the current Siemens documentation for this programming language.
 The list is structured as follows:
 Even address: G command to be changed
 Subsequent odd address: New G command
 Only G codes can be reconfigured, e.g.: G20, G71.

2.2 General machine data

10884	EXTERN_FLOATINGPOINT_PROG			N12	FBFA	
-	Evaluation of programmed values without decimal point			BOOLEAN	PowerOn	
-						
-	-	TRUE	-	-	2/2	M

Description: This MD defines how programmed values without a decimal point are evaluated:
 0: Values without a decimal point are interpreted in internal units. For example, X1000 = 1 mm (for 0.001 mm input resolution) X1000.0 = 1000 mm
 1: Values without decimal point are interpreted as mm, inch or degrees. For example, X1000 = 1000 mm X1000.0 = 1000 mm
 Related to:
 MD10886 \$MN_EXTERN_INCREMENT_SYSTEM

10886	EXTERN_INCREMENT_SYSTEM			N12	FBFA	
-	Incremental system in external language mode			BOOLEAN	PowerOn	
-						
-	-	FALSE	-	-	2/2	M

Description: This machine data is active for external programming languages, that is if MD18800 \$MN_MM_EXTERN_LANGUAGE = 1.
 This machine data specifies which incremental system is active:
 0: Incremental system IS-B = 0.001 mm/degree = 0.0001 inch
 1: Incremental system IS-C = 0.0001 mm/degree = 0.00001 inch
 Related to:
 MD10884 \$MN_EXTERN_FLOATINGPOINT_PROG

10888	EXTERN_DIGITS_TOOL_NO			N12	FBFA	
-	Digits for T number in ISO mode			BYTE	PowerOn	
-						
828d-me41	-	2	0	8	0/0	S
828d-me61	-	2	0	8	0/0	S
828d-me81	-	2	0	8	0/0	S
828d-te61	-	0	0	8	2/2	M
828d-te81	-	0	0	8	2/2	M
828d-te41	-	0	0	8	2/2	M

Description: This machine data is only active when MD10880 \$MN_MM_EXTERN_CNC_SYSTEM == 2.
 Number of digits of the tool number in the programmed T word.
 From the programmed T word, the number of leading digits specified in MD10888 \$MN_EXTERN_DIGITS_TOOL_NO are interpreted as the tool number.
 The following digits address the offset memory.
 Entering a value > 0 in MD \$MN_EXTERN_DIGITS_OFFSET_NO renders MD \$MN_EXTERN_DIGITS_TOOL_NO ineffective.
 \$MN_EXTERN_DIGITS_OFFSET_NO has priority over \$MN_EXTERN_DIGITS_TOOL_NO.

10889	EXTERN_DIGITS_OFFSET_NO			N12	FBFA	
-	Digits for offset number in ISO mode			BYTE	PowerOn	
-						
828d-me41	-	0	0	8	0/0	S
828d-me61	-	0	0	8	0/0	S
828d-me81	-	0	0	8	0/0	S
828d-te61	-	2	0	8	2/2	M
828d-te81	-	2	0	8	2/2	M
828d-te41	-	2	0	8	2/2	M

Description: This machine data is only active when \$MN_MM_EXTERN_CNC_SYSTEM == 2.
Number of digits of the offset number in the programmed T word.
From the programmed T word, the number of leading digits specified in \$MN_EXTERN_DIGITS_OFFSET_NO are interpreted as the offset number.
The following digits address the tool number.

10890	EXTERN_TOOLPROG_MODE			N12	FBFA	
-	Tool change programming for external language			DWORD	PowerOn	
-						
828d-me41	-	0x0	-	-	2/2	M
828d-me61	-	0x0	-	-	2/2	M
828d-me81	-	0x0	-	-	2/2	M
828d-te61	-	0x04	-	-	2/2	M
828d-te81	-	0x04	-	-	2/2	M
828d-te41	-	0x04	-	-	2/2	M

Description: Configuration for programming the tool change in an external programming language:

Bit0=0:

Only active if MD10880 \$MN_MM_EXTERN_CNC_SYSTEM =2: The tool number and offset number are programmed in the T word. \$MN_DIGITS_TOOLNO defines the number of leading digits that form the tool number.

Example:

```
$MN_DIGITS_TOOLNO = 2
T=1234 ; Tool number 12,
        ; Offset number 34
```

Bit0=1:

Only active if MD10880 \$MN_MM_EXTERN_CNC_SYSTEM =2: Only the tool number is programmed in the T word. Offset number = Tool number.
\$MN_DIGITS_TOOLNO is irrelevant.

Example:

```
T=12 ; Tool number 12
        ; Offset number 12
```

Bit1=0:

Only active if MD10880 \$MN_MM_EXTERN_CNC_SYSTEM =2: A leading 0 is added if the number of digits programmed in the T word is the same as that in MD10888 \$MN_EXTERN_DIGITS_TOOL_NO.

Bit1=1:

Only active if MD10880 \$MN_MM_EXTERN_CNC_SYSTEM =2: If the number of digits programmed in the T word is equal to the number of digits defined in MD10888 \$MN_EXTERN_DIGITS_TOOL_NO, the programmed number is both the offset number and the tool number

Bit2=0:

Only active if \$MN_MM_EXTERN_CNC_LANGUAGE =2: ISO T offset selection only with D (Siemens cutting edge number)

Bit2=1:

Only active if \$MN_MM_EXTERN_CNC_LANGUAGE =2: ISO T offset selection only with H (\$TC_DPH[t,d])

Bit6=0:

The offset memories for the tool length and tool radius are linked so that tool length and tool radius are always selected when either H or D is programmed.

Bit6=1:

The offset memories for the tool length and tool radius are not linked, so that the number of the tool length value is selected when H is programmed, and the number of the tool radius value is selected when D is programmed.

Bit7=0:

Only active if \$MN_MM_EXTERN_CNC_SYSTEM =2. If T substitution (\$MN_T_NO_FCT_CYCLE_NAME) is active, the H number programmed in the T word is transferred to the cycle in the variable \$C_D.

Bit7=1:

Only active if \$MN_MM_EXTERN_CNC_SYSTEM =2. If T substitution (\$MN_T_NO_FCT_CYCLE_NAME) is active, the Siemens cutting edge number D corresponding to the H number programmed in the T word is transferred to the cycle in the variable \$C_D.

10900	INDEX_AX_LENGTH_POS_TAB_1	N09	T1
-	Number of positions for indexing axis table 1	DWORD	Reset
-			
-	-	0	0
		60	2/2 M

Description:

The indexing position table is used to assign the axis positions in the valid unit of measurement (mm, inches or degrees) to the indexing positions [n] on the indexing axis. The number of indexing positions used in table 1 is defined by MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1.

These indexing positions must be assigned valid values in table 1. Any indexing positions in the table above the number specified in the machine data are ignored. Up to 60 indexing positions (0 to 59) can be entered in the table. Table length = 0 means that the table is not evaluated. If the length is not equal to 0, then the table must be assigned to an axis with MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB.

If the indexing axis is defined as a rotary axis (MD30300 \$MA_IS_ROT_AX = "1") with modulo 360° (MD30310 \$MA_ROT_IS_MODULO = "1"), the machine data defines the last indexing position after which, with a further traversing movement in the positive direction, the indexing positions begin again at 1.

Special cases:

Alarm 17090 "Value violates upper limit" if values over 60 are entered in MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1.

Related to:

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB (axis is an indexing axis)

MD10910 \$MN_INDEX_AX_POS_TAB_1 (indexing position table 1)

MD30300 \$MA_IS_ROT_AX (rotary axis)

MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis)

10910	INDEX_AX_POS_TAB_1		N09	T1	
mm/inch, degrees	Indexing position table 1		DOUBLE	Reset	
-					
-	60	0.,0.,0.,0.,0.,0.,0.,0., 0.,0.,0.,0....	-	-	2/2 M

Description:

The indexing position table is used to assign the axis positions in the valid unit of measurement (mm, inches or degrees) to the indexing positions [n] on the indexing axis.

[n] = indexing for the entry of the indexing positions in the indexing position table.

Range: 0 y n x 59, where 0 corresponds to the 1st indexing position and 59 to the 60th indexing position.

Note.

Programming with the absolute indexing position (e.g. CAC) starts with indexing position 1. This corresponds to the indexing position with indexing n = 0 in the indexing position table.

The following should be noted when entering the indexing positions:

- Up to 60 different indexing positions can be stored in the table.
- The 1st entry in the table corresponds to indexing position 1; the nth entry corresponds to indexing position n.
- The indexing positions must be entered in the table in ascending order (starting with the negative and going to the positive traversing range) with no gaps between the entries. Consecutive position values must not be identical.
- If the indexing axis is defined as a rotary axis (MD30300 \$MA_IS_ROT_AX = "1") with modulo 360° (MD30310 \$MA_ROT_IS_MODULO = "1"), then the position values are limited to a range of 0° x pos. < 360°.

The number of indexing positions used in the table is defined by MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1.

Entering the value 1 in axial MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB assigns indexing position table 1 to the current axis.

Special cases:

Alarm 17020 "Illegal array index" if over 60 positions are entered in the table.

Related to:

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB (axis is an indexing axis)

MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1 (number of indexing positions used in table 1)

MD30300 \$MA_IS_ROT_AX (rotary axis)

MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis)

2.2 General machine data

10920	INDEX_AX_LENGTH_POS_TAB_2			N09	T1	
-	Number of positions for indexing axis table 2			DWORD	Reset	
-						
-	-	0	0	60	2/2	M

Description:

The indexing position table is used to assign the axis positions in the valid unit of measurement (mm, inches or degrees) to the indexing positions [n] on the indexing axis. The number of indexing positions used in table 2 is defined by MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2.

These indexing positions in table 2 must be assigned valid values. Any indexing positions in the table above the number specified in the machine data are ignored.

Up to 60 indexing positions (0 to 59) can be entered in the table.

Table length = 0 means that the table is not evaluated. If the length is not equal to 0, the table must be assigned to an axis with MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB.

If the indexing axis is defined as a rotary axis (MD30300 \$MA_IS_ROT_AX = "1") with modulo 360° (MD30310 \$MA_ROT_IS_MODULO = "1"), the machine data defines the last indexing position after which, with a further traversing movement in the positive direction, the indexing positions begin again at 1.

Not relevant for tool magazines (revolvers, chain magazines)

Special cases:

Alarm 17090 "Value violates upper limit" if a value over 60 is entered in MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2.

Related to:

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB (axis is an indexing axis)

MD10930 \$MN_INDEX_AX_POS_TAB_2 (indexing position table 2)

MD30300 \$MA_IS_ROT_AX (rotary axis)

MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis)

10930	INDEX_AX_POS_TAB_2			N09	T1	
mm/inch, degrees	Indexing position table 2			DOUBLE	Reset	
-						
-	60	0.,0.,0.,0.,0.,0.,0.,0., 0.,0.,0.,0...	-	-	2/2	M

Description:

The indexing position table is used to assign the axis positions in the valid unit of measurement (mm, inches or degrees) to the indexing positions [n] on the indexing axis.

[n] = indexing for the entry of the indexing positions in the indexing position table.

Range: 0 y n x 59, where 0 corresponds to the 1st indexing position and 59 to the 60th indexing position.

Note:

Programming with the absolute indexing position (e.g. CAC) starts with indexing position 1. This corresponds to the indexing position with indexing n = 0 in the table.

The following should be noted when entering the indexing positions:

- Up to 60 different indexing positions can be stored in the table.
- The 1st entry in the table corresponds to indexing position 1; the nth entry corresponds to indexing position n.
- The indexing positions should be entered in the table in ascending order (starting with the negative and going to the positive traversing range) with no gaps between the entries. Consecutive position values must not be identical.
- If the indexing axis is defined as a rotary axis (MD30300 \$MA_IS_ROT_AX = "1") with modulo 360° (MD30310 \$MA_ROT_IS_MODULO = "1"), then the position values are limited to a range of 0° x pos. < 360°.

The number of indexing positions used in the table is defined by MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2.

Entering the value 1 in axial MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB assigns indexing position table 1 to the current axis.

Special cases:

Alarm 17020 "Illegal array index" if over 60 positions are entered in the table.

Related to:

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB (axis is an indexing axis)

MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2 (number of indexing positions used in table 2)

MD30300 \$MA_IS_ROT_AX (rotary axis)

MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis)

10940	INDEX_AX_MODE			EXP	T1	
-	Settings for indexing position			DWORD	PowerOn	
-						
-	-	0	0	1	2/2	M

Description: Affects the display of indexing positions (AA_ACT_INDEX_AX_POS_NO and aaActIndexAxPosNo).

Bit 0 = 0:

Indexing position display changes on reaching/passing the indexing position (indexing range lies between the indexing positions, compatible behavior).

Bit 0 = 1:

Indexing position display changes on passing the half indexing axis position (indexing range lies quasi symmetrically round the indexing position)

11100	AUXFU_MAXNUM_GROUP_ASSIGN			N01, N07, N02	H2	
-	Number of auxiliary functions distr. amongst aux. fct. groups			DWORD	PowerOn	
-						
-	-	8	1	255	2/2	M

Description: The maximum number of auxiliary functions that can be assigned to a group by AUXFU_ASSIGN_TYPE, AUXFU_ASSIGN_EXTENTION, AUXFU_ASSIGN_VALUE and AUXFU_ASSIGN_GROUP.

This number includes only the user-defined auxiliary functions, not the pre-defined auxiliary functions.

Related to:

MD22010 \$MC_AUXFU_ASSIGN_TYPE[n].

11110	AUXFU_GROUP_SPEC	N07	H2
-	Auxiliary function group specification	DWORD	PowerOn
-			
-	168	0x81,0x21,0x41,0x41, 0x41,0x41,0x41...	2/2 M

Description: Defines the output options for the auxiliary functions belonging to a group. However, the output option of an auxiliary function configured by MD22080 \$MC_AUXFU_PREDEF_SPEC[preIndex] or MD22035 \$MC_AUXFU_ASSIGN_SPEC[auxIndex] has a higher priority.

Bit 0=1"Normal" acknowledgement after an OB1 cycle

Bit 1=1"Quick" acknowledgement with OB40

Bit 2=1No predefined auxiliary function

Bit 3=1No output to PLC

Bit 4=1Spindle response after acknowledgement by the PLC

Bit 5=1Output prior to motion

Bit 6=1Output during motion

Bit 7=1Output at end of block

Bit 8=1No output after block search types 1, 2, 4

Bit 9=1Collection during block search type 5 (SERUPRO)

Bit 10 = 1 No output during block search type 5 (SERUPRO)

Bit 11 = 1Cross-channel auxiliary function (SERUPRO)

Bit 12 = 1Output via synchronized action

Bit 13 = 1 Implicit auxiliary function

Bit 14 = 1 Active M01

Bit 15 = 1 No output during running-in test

Bit 16 = 1 Nibbling off

Bit 17 = 1 Nibbling on

Bit 18 = 1 Nibbling

The MD must be defined for each existing auxiliary function group.

The index [n] corresponds to the auxiliary function group: 0...63

The assignment of individual auxiliary functions to specific groups is defined in channel-specific machine data (AUXFU_PREDEF_TYPE, AUXFU_PREDEF_EXTENTION, AUXFU_PREDEF_VALUE, AUXFU_PREDEF_GROUP, AUXFU_ASSIGN_TYPE, AUXFU_ASSIGN_EXTENTION, AUXFU_ASSIGN_VALUE, AUXFU_ASSIGN_GROUP).

M0, M1, M2, M17 and M30 are assigned to group 1 by default.

The specification of this group (0x81: output duration 1 OB1 pass, output at end of block) must not be changed.

All spindle-specific auxiliary functions (M3, M4, M5, M19, M70) are assigned to group 2 by default.

If several auxiliary functions with different output types (before / during / at end of motion) are programmed in one motion block, then the output of the individual auxiliary functions occurs in accordance with their output types.

All auxiliary functions are output simultaneously in a block without motion.

Default setting:

AUXFU_GROUP_SPEC[0]=81H

AUXFU_GROUP_SPEC[1]=21H

AUXFU_GROUP_SPEC[2]=41H

...

AUXFU_GROUP_SPEC[n]=41H

11120	LUD_EXTENDED_SCOPE	N01	PG
-	Function "program global user data (PUD)" is active	BOOLEAN	PowerOn
-			
-	FALSE	-	2/2 M

Description: Activate function "Program-global user data (PUD)":
 MD = 0: User data of the main program level are only active on this level.
 MD = 1: User data of the main program level are also visible in the subprogram levels.

11140	GUD_AREA_SAVE_TAB	N01	-
-	Additional saving for GUD modules	DWORD	Immediately
-			
-	9	0,0,0,0	1/1 M

Description: This data indicates in which area the contents of the GUD module are also saved.

MD11140 \$MN_GUD_AREA_SAVE_TAB[0] : SGUD_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[1] : MGUD_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[2] : UGUD_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[3] : GUD4_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[4] : GUD5_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[5] : GUD6_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[6] : GUD7_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[7] : GUD8_DEF

MD11140 \$MN_GUD_AREA_SAVE_TAB[8] : GUD9_DEF

BitNo. Hexadec. Meaning when bit is set

Value

0 (LSB) 0x00000001 TOA area

11160	ACCESS_EXEC_CST	N01	-
-	Execution right for /_N_CST_DIR	BYTE	PowerOn
-			
-	7	-	2/2 M

Description: Execution right assigned to the program stored in directory /_N_CST_DIR :

Value 0: Siemens password

Value 1: Machine OEM password

Value 2: Password of setup engineer, service

Value 3: End user password

Value 4: Keyswitch position 3

Value 5: Keyswitch position 2

2.2 General machine data

Value 6: Keyswitch position 1
 Value 7: Keyswitch position 0
 Machine data can only be written with values 0 and 1, and with the corresponding password also active.

11161	ACCESS_EXEC_CMA	N01	-
-	Execution right for /_N_CMA_DIR	BYTE	PowerOn
-			
-	-	7	-
			2/2 M

Description: Execution right assigned to the programs stored in directory /_N_CMA_DIR :
 Value 0: Siemens password
 Value 1: Machine OEM password
 Value 2: Password of setup engineer, service
 Value 3: End user password
 Value 4: Keyswitch position 3
 Value 5: Keyswitch position 2
 Value 6: Keyswitch position 1
 Value 7: Keyswitch position 0
 Machine data can only be written with values 0 and 1, and with the corresponding password also active.

11162	ACCESS_EXEC_CUS	N01	-
-	Execution right for /_N_CUS_DIR	BYTE	PowerOn
-			
-	-	7	-
			3/3 U

Description: Execution right assigned to the programs stored in directory /_N_CUS_DIR :
 Value 0: Siemens password
 Value 1: Machine OEM password
 Value 2: Password of setup engineer, service
 Value 3: End user password
 Value 4: Keyswitch position 3
 Value 5: Keyswitch position 2
 Value 6: Keyswitch position 1
 Value 7: Keyswitch position 0
 Machine data can only be written with values 0, 1 and 2, and with the corresponding password also active.

11165	ACCESS_WRITE_CST	N01	-
-	Write protection for directory /_N_CST_DIR	DWORD	PowerOn
-			
-	-	-1	-
			2/2 M

Description: Set write protection for cycle directory /_N_CST_DIR:
 Assigned to the programs:
 Value -1: Keep the value currently set
 Value 0: Siemens password
 Value 1: Machine OEM password
 Value 2: Password of setup engineer, service
 Value 3: End user password

Value 4: Keyswitch position 3
 Value 5: Keyswitch position 2
 Value 6: Keyswitch position 1
 Value 7: Keyswitch position 0

The machine data can only be written with values 0 and 1, and with the corresponding password also active.

11166	ACCESS_WRITE_CMA		N01		-	
-	Write protection for directory /_N_CMA_DIR		DWORD		PowerOn	
-						
-	-	-1	-	-	2/2	M

Description:

Set write protection for cycle directory /_N_CMA_DIR:

Assigned to the programs:

Value -1: Keep the value currently set

Value 0: Siemens password

Value 1: Machine OEM password

Value 2: Password of setup engineer, service

Value 3: End user password

Value 4: Keyswitch position 3

Value 5: Keyswitch position 2

Value 6: Keyswitch position 1

Value 7: Keyswitch position 0

The machine data can only be written with values 0 and 1, and with the corresponding password also active.

11167	ACCESS_WRITE_CUS		N01		-	
-	Write protection for directory /_N_CUS_DIR		DWORD		PowerOn	
-						
-	-	-1	-	-	3/3	U

Description:

Set write protection for cycle directory /_N_CUS_DIR:

Assigned to the programs:

Value -1: Keep the value currently set

Value 0: Siemens password

Value 1: Machine OEM password

Value 2: Password of setup engineer, service

Value 3: End user password

Value 4: Keyswitch position 3

Value 5: Keyswitch position 2

Value 6: Keyswitch position 1

Value 7: Keyswitch position 0

The machine data can only be written with values 0, 1 and 2, and with the corresponding password also active.

11170	ACCESS_WRITE_SACCESS	N01	-
-	Write protection for _N_SACCESS_DEF	BYTE	PowerOn
-			
-	-	7	-
-	-	-	-
-	-	2/2	M

Description: Set write protection for definition file /_N_DEF_DIR/_N_SACCESS_DEF:
Value 0: Siemens password
Value 1: Machine OEM password
Value 2: Password of setup engineer, service
Value 3: End user password
Value 4: Keyswitch position 3
Value 5: Keyswitch position 2
Value 6: Keyswitch position 1
Value 7: Keyswitch position 0
The machine data can only be written with values 0 and 1, and with the corresponding password also active.

11171	ACCESS_WRITE_MACCESS	N01	-
-	Write protection for _N_MACCESS_DEF	BYTE	PowerOn
-			
-	-	7	-
-	-	-	-
-	-	2/2	M

Description: Set write protection for definition file /_N_DEF_DIR/_N_SACCESS_DEF:
Value 0: Siemens password
Value 1: Machine OEM password
Value 2: Password of setup engineer, service
Value 3: End user password
Value 4: Keyswitch position 3
Value 5: Keyswitch position 2
Value 6: Keyswitch position 1
Value 7: Keyswitch position 0
The machine data can only be written with values 0 and 1, and with the corresponding password also active.

11172	ACCESS_WRITE_UACCESS	N01	-
-	Write protection for _N_UACCESS_DEF	BYTE	PowerOn
-			
-	-	7	-
-	-	-	-
-	-	3/3	U

Description: Set write protection for definition file /_N_DEF_DIR/_N_UACCESS_DEF:
Value 0: Siemens password
Value 1: Machine OEM password
Value 2: Password of setup engineer, service
Value 3: End user password
Value 4: Keyswitch position 3
Value 5: Keyswitch position 2
Value 6: Keyswitch position 1
Value 7: Keyswitch position 0
The machine data can only be written with values 0, 1 and 2, and with the corresponding password also active.

11210	UPLOAD_MD_CHANGES_ONLY			N01, N05	IAD	
-	Machine data backup of changed machine data only			BYTE	Immediately	
-						
-	-	0x00	-	-	2/2	M

Description: Either all data or only those data which differ from the default setting can be set to be output when creating standard archives (ARC) and copying 'NC active data'.

Bit0 (LSB) Effectiveness of the differential upload with INI/TEA files

0: All data are output

1: Only those MDs which have changed in comparison to the compiled values are output

Bit1 is reserved and acts like bit 0

Bit2 Change to an array element

0: Complete array is output

1: Only those elements of an array which have changed are output

Bit3 R parameters (only for INI files)

0: All R parameters are output

1: Only those R parameters not equal to '0' are output

Bit4 Frames (only for INI files)

0: All frames are output

1: Only those frames which are not zero frames are output.

Bit5 Tool data (cutting edge parameters) (only for INI files)

0: All tool data are output

1: Only those tool data not equal to '0' are output.

Bit6 Buffered system variables (\$AC_MARKER[], \$AC_PARAM[] only for INI files)

0: All system variables are output

1: Only those system variables not equal to '0' are output

Bit7 Synchronized actions GUD (for INI files only)

0: All Syna GUD are output

1: Only those Syna GUD not equal to '0' are output

Active: The change in the data becomes active on the start of the upload for the next range.

11240	PROFIBUS_SDB_NUMBER			N01, N05	K4,FBU	
-	SDB number			DWORD	PowerOn	
-						
-	4	0,-1,0,0	-1	7	1/1	M

Description: Number of the system data block (SDB) used for configuring the I/Os.

11241	PROFIBUS_SDB_SELECT			N01, N05	-	
-	SDB source selection			DWORD	PowerOn	
-						
-	-	0	0	3	2/2	M

Description: If MD11240 \$MN_PROFIBUS_SDB_NUMBER > 0, SDBs are loaded directly from the directory:

```
MD11241 $MN_PROFIBUS_SDB_SELECT = 0: /siemens/sinumerik/sdb/...
MD11241 $MN_PROFIBUS_SDB_SELECT = 1: /addon/sinumerik/sdb/...
MD11241 $MN_PROFIBUS_SDB_SELECT = 2: /oem/sinumerik/sdb/...
MD11241 $MN_PROFIBUS_SDB_SELECT = 3: /user/sinumerik/sdb/...
```

11250	PROFIBUS_SHUTDOWN_TYPE			EXP, N01	G3,FBU	
-	PROFIBUS/PROFINET shutdown handling			BYTE	PowerOn	
-						
-	-	0	0	2	2/2	M

Description:

For PROFIBUS/PROFINET only:

Handling of PROFIBUS/PROFINET when shutting down NCK (NCK reset)

Value 0:

The bus is shut down directly from cyclic operation, without 'prewarning'

Value 1:

When shutting down NCK, the bus is changed to the CLEAR state for at least 20 cycles. Then, it is shut down. If this is not possible on the hardware side, the procedure described for value 2 is used instead.

Value 2:

When shutting down NCK, the bus is changed to a state where all drives are sent a zero word as control word1 and control word2 (pseudoclear) for at least 20 cycles. The bus itself remains in the Operate status.

11280	WPD_INI_MODE			N01	IAD	
-	Handling of INI files in workpiece directory			BYTE	PowerOn	
-						
-	-	0	0	1	1/1	M

Description:

Processing mode of INI files in the workpiece directory:

Value = 0:

An INI file, `_N_werkstück_INI`, stored in the workpiece directory is executed on the first NC start after workpiece selection.

Value = 1:

INI files with the names of the selected part program and extensions are executed on the first NC start after workpiece selection

SEA,
GUD,
RPA,
UFR,
PRO,
TOA,
TMA and
CEC
.

11294	SIEM_TRACEFILES_CONFIG			EXP	-	
-	Configuration of the SIEM* trace file			DWORD	PowerOn	
-						
-	-	0	-	-	1/1	M

Description:

Configuration of the tracefiles SIEM*

Bit0:

Additional information about the PDUs sent is to be entered in `_N_SIEMDOMAINSEQ_MPF` for download

Bit1:

Additional information about the PDUs received is to be entered in `_N_SIEMDOMAINSEQ_MPF` for download

Bit2:

Trace of warm start and connection abort in `_N_SIEMDOMAINSEQ_MPF`

Bit4:

Additional information about the PDUs sent is to be entered in `_N_SIEMDOMAINSEQ_MPF` for upload

Bit5:

Additional information about the PDUs received is to be entered in `_N_SIEMDOMAINSEQ_MPF` for upload

11300	JOG_INC_MODE_LEVELTRIGGRD	N01	H1,R1
-	INC and REF in jog mode	BOOLEAN	PowerOn
-			
-	-	TRUE	-
-	-	-	1/1
-	-	-	M

Description:

1: Jog mode for JOG-INC and reference point approach

JOG-INC:

When the traversing key is pressed in the required direction (e.g. +), the axis begins to traverse the set increment. If the key is released before the increment has been completely traversed, the movement is interrupted and the axis stops. If the same key is pressed again, the axis completes the remaining distance-to-go until this is 0.

0: Continuous operation for JOG-INC and reference point approach

JOG-INC:

When the traversing key is pressed (first rising edge) the axis travels the whole set increment. If the same key is pressed again (second rising edge) before the axis has completed traversing the increment, the movement is aborted, i.e. not completed.

The differences in axis travel behavior between the jog mode and continuous operation in incremental traversing are described in detail in the relevant chapters.

For travel behavior in reference point approach see

References: /FB/, R1, "Reference Point Approach"

MD irrelevant for:

Continuous traversing (JOG continuous)

11310	HANDWH_REVERSE	N09	H1
-	Threshold for direction change handwheel	BYTE	PowerOn
-			
-	-	2	-
-	-	-	2/2
-	-	-	M

Description:

Handwheel travel:

Value = 0:

No immediate travel in the opposite direction

Value > 0:

Immediate travel in the opposite direction if the handwheel is turned at least the stated number of pulses in the opposite direction.

Whether this machine data is also active for handwheel travel with DRF depends on bit10 of MD20624 `$MC_HANDWH_CHAN_STOP_COND`.

11320	HANDWH_IMP_PER_LATCH	N09	H1
-	Handwheel pulses per detent position	DOUBLE	PowerOn
-			
-	6	1.,1.,1.,1.,1.,1.	- - 2/2 M

Description:

The connected handwheels are adapted to the control in MD11320 \$MN_HANDWH_IMP_PER_LATCH.

The number of pulses generated by the handwheel for each handwheel detent position has to be entered. The handwheel pulse weighting must be defined separately for each connected handwheel (1 to 3). With this adaptation, each handwheel detent position has the same effect as one press of the traversing key in incremental traversal.

Entering a negative value reverses the direction of rotation of the handwheel.

Related to:

MD31090 \$MA_JOG_INCR_WEIGHT
(weighting of an increment of a machine axis for INC/manual).

11322	CONTOURHANDWH_IMP_PER_LATCH	N09	H1
-	Contour handwheel pulses per detent position	DOUBLE	PowerOn
-			
-	6	1.,1.,1.,1.,1.,1.	- - 2/2 M

Description:

Adaptation factor to the hardware of the contour handwheel:

Enter the number of pulses issued per detent position by the contour handwheel.

Because of this normalization, a detent position of the contour handwheel corresponds to one press of a key with incremental jog processes.

Sign reversal reverses the direction of evaluation.

11330	JOG_INCR_SIZE_TAB	EXP, N09	H1
-	Increment size for INC/handwheel	DOUBLE	PowerOn
-			
-	5	1.,10.,100.,1000.,10000.	- - 1/1 M

Description:

In incremental traversal or handwheel travel, the number of increments to be traversed by the axis can be defined by the user, e.g. via the machine control panel.

In addition to the variable increment size (INCvar), 5 fixed increment sizes (INC...) can also be set.

The increment size for each of these 5 fixed increments is defined collectively for all axes by entering values in JOG_INCR_SIZE_TAB [n]. The default setting is INC1, INC10, INC100, INC1000 and INC10000.

The entered increment sizes are also active for DRF.

The size of the variable increment is defined in SD41010 \$SN_JOG_VAR_INCR_SIZE.

Related to:

MD31090 \$MA_JOG_INCR_WEIGHT (weighting of an increment for INC/manual)

NC/PLC interface signal DB3300 DBX1001.0-4,1005.0-4,1009.0-4
(Geometry axis 1-3 active machine function: INC1; ...;

INC10000)

NC/PLC interface signal DB390x DBX5.0 - .5

(active machine function: INC1; ...; INC10000).

11346	HANDWH_TRUE_DISTANCE	N01	H1,P1,W1
-	Handwheel default path or velocity	BYTE	PowerOn
-			
-	-	6	0
-	-	7	1/1
-	-		M

Description:

Setting the behavior for traversing with the handwheel, contour handwheel and with FDA=0:

Value = 1: (default value)

The default settings of the handwheel are path defaults. No pulses are lost. Residual axis motions occur as a result of the limitation to a maximal permissible velocity.

Value = 0:

The default settings of the handwheel are velocity defaults. The axes stop as soon as the handwheel stops. The motion is immediately braked if no pulses come from the handwheel in an interpolation cycle.

Therefore, only a short residual motion of the axes can occur as a result of the braking ramp. The handwheel pulses do not supply a path default.

Value = 2:

The default settings of the handwheel are velocity defaults. The axes are to stop as soon as the handwheel stops. The motion is immediately braked if no pulses come from the handwheel in an interpolation cycle.

However, in contrast to

value = 0 braking is not along the shortest possible path but to the next possible point in a notional grid.

Each increment in the grid corresponds to a displacement which the selected axis travels per handwheel detent position (see MD31090 \$MA_JOG_INCR_WEIGHT and

MD11330 \$MN_JOG_INCR_SIZE_TAB, MD20620 \$MC_HANDWH_GEOAX_MAX_INCR_SIZE, MD32080 \$MA_HANDWH_MAX_INCR_SIZE). The start of the traversing is taken as the zero point

of the grid.

Value = 3:

The default settings of the handwheel are path defaults. If premature braking is required

on account of settings in other machine data (MD11310 \$MN_HANDWH_REVERSE != 0, MD20624 \$MC_HANDWH_CHAN_STOP_COND, MD32084 \$MA_HANDWH_STOP_COND), then, in

contrast to value = 1 braking is not along the shortest possible path, but to the next possible point in a notional grid (see

value = 2).

2.2 General machine data

Value = 6:

Same as value = 2, but travel does not stop at the last possible grid position in front of a limit, but at the limit.

Value = 7:

Same as value = 3, but travel does not stop at the last possible grid position in front of a limit, but at the limit.

11350	HANDWHEEL_SEGMENT	N09	H1
-	Handwheel segment	BYTE	PowerOn
-			
-	6	2,2,0,0,0,0	- - 1/1 M

Description: Machine data defines which hardware segment the handwheel is connected to:

- 0 = SEGMENT_EMPTY ;no handwheel
- 1 = SEGMENT_840D_HW ;handwheel at 840D HW
- 2 = SEGMENT_8xxD_HW ;handwheel at 802D s1, 828D s1, 808D -HW
- 5 = SEGMENT_PROFIBUS ;handwheel at PROFIBUS
- 7 = SEGMENT_ETHERNET ;handwheel at Ethernet

11351	HANDWHEEL_MODULE	N09	H1
-	Handwheel module	BYTE	PowerOn
-			
-	6	1,1,0,0,0,0	0 6 1/1 M

Description: Machine data specifies the hardware module to which the handwheel is connected.
 (Content dependent on MD11350 \$MN_HANDWHEEL_SEGMENT):

- 0 = no handwheel configured
- \$MN_HANDWHEEL_MODUL =
- 1 ;SEGMENT_840D_HW
- 1 ;SEGMENT_8xxD_HW; 802D s1, 828D s1, 808D -HW
- 1..6 ;SEGMENT_PROFIBUS/PROFINET ;index for MD11353
- \$MN_HANDWHEEL_LOGIC_ADDRESS[(x-1)]
- 1 ;SEGMENT_ETHERNET

11352	HANDWHEEL_INPUT	N09	H1
-	Handwheel connection	BYTE	PowerOn
-			
-	6	1,2,0,0,0,0	0 6 1/1 M

Description: Machine data which is intended to select the handwheels connected to a hardware module:

- 0 = No handwheel configured
- 1..6 = Handwheel connection to HW module/Ethernet interface

11354	HANDWHEEL_FILTER_TIME	N09	-
s	Filter time for handwheel pulses	DOUBLE	PowerOn
-			
-	6	0.0,0.0,0.0,0.0,0.0,0.0	0.0 2.0 1/1 M

Description: The filter time indicates the time during which the pulses from the handwheel are output to the interpolator. The values are incremented internally in interpolation cycles.

In the case of a filter time setting = 0.0, the pulses from the handwheel are output to the interpolator within a single interpolation cycle. This can cause the controlled axis to exhibit jerk during traversing.

Machine data is valid for the following types of handwheel (see 11350 \$MN_HANDWHEEL_SEGMENT):

SEGMENT_ETHERNET:

- Recommended filter time: 0.2 - 0.5 s

11410	SUPPRESS_ALARM_MASK	EXP, N06	D1,M3,K3,S1,V1,W1
-	Mask for support of special alarm outputs	DWORD	PowerOn
-			
828d-me41	-	0x100087	0 0xFFFFFFFF 1/1 M
828d-me61	-	0x100087	0 0xFFFFFFFF 1/1 M
828d-me81	-	0x100087	0 0xFFFFFFFF 1/1 M
828d-te61	-	0x101087	0 0xFFFFFFFF 1/1 M
828d-te81	-	0x101087	0 0xFFFFFFFF 1/1 M
828d-te41	-	0x101087	0 0xFFFFFFFF 1/1 M

Description: Mask for suppressing special alarm outputs

Bit set: The corresponding alarm (warning) is NOT triggered.

Bit 0:

Alarm 15110 "Channel %1 block %2 REORG not possible"

Bit 1:

Alarm 10763 "Channel %1 block %2. The path component of the block in the contour plane is zero"

Bit 2:

Alarm 16924 "Channel %1 Caution: Program testing can modify tool/magazine data"

--> Note: The alarm is only a message alarm

Bit 3:

Alarm 22010 "Channel %1 spindle %2 block %3. Actual gear stage does not correspond to set gear stage"

Bit 4:

Alarm 17188 "Channel %1 D number %2 with tool T nos. %3 and %4 defined"

Alarm 17189 "Channel %1 D number %2 of the tools in magazines/magazine locations %3 and %4 defined". The two alarms are of equal status and are only message alarms.

Bit 5:

Alarm 22071 "TO unit %1 tool %2 duplo no. %3 is active but not in the active wear grouping." The alarm is only a message alarm.

Bit 6:

Alarm 4027 "NOTICE! MD %1 was also changed for the other axes in the axis container %2 "

Alarm 4028 "NOTICE! The axial MDs in the axis container will be aligned on the next runup "

Bit 7:

Alarm 22070 "TO unit %1 please change tool T= %2 to magazine. Repeat data backup". The alarm is only a message alarm.

Bit 8:

Alarm 6411 "Channel %1 tool %2 with duplo no. %3 has reached tool prewarning limit"

Alarm 6413 "Channel %1 tool %2 with duplo no. %3 has reached tool monitoring limit."

The two alarms are only message alarms. They occur during program execution.

Bit 9:

Alarm 6410 "TO unit %1 tool %2 with duplo no. %3 has reached tool prewarning limit ."

Alarm 6412 "TO unit %1 tool %2 with duplo no. %3 has reached tool monitoring limit ".

The two alarms are only message alarms. They occur as a result of an operator action.

Bit10:

Alarm 10604 "channel %1 block %2 "Thread lead increase too high"

Alarm 10605 "channel %1 block %2 "Thread lead decrease too high"

Bit 11:

Alarm 14088 "Channel 51 block %2 axis %3 doubtful position".

Bit 12:

obsolete (Alarm 10607)"

Bit13:

Alarm 10704 " channel %1 block %2 Protection area monitoring is not guaranteed."

Bit14:

Alarm 21701 "Measuring reactivated too soon (<2 IPO cycles)"

Bit15:

Alarm 5000 "Communication order cannot be executed"

Bit16:

Alarm 21600 "Monitoring active for ESR"

Bit17:

Alarm 16945 "Channel %1 action %2<ALNX> is delayed until block end"

Note: The alarm is only a message alarm.

Bit18:

Alarm 10750 "Channel %1 block %2 Activation of the tool radius compensation without tool number"

Bit19: Alarm 17193 "Channel %1 block %2 The active tool ist no longer at tool holder no./spindle no. %3, program %4"

Bit20:

Alarm 2900 "Reboot is delayed"

Bit21:

Alarm 22012 "Channel %1 block %2. Leading axis %3 is in simulation mode"
 Alarm 22013 "Channel %1 block %2. Following axis %3 is in simulation mode"
 Alarm 22014 "Channel %1 block %2. The dynamics of leading axis %3 and following axis %4 are very different"
 Alarm 22040 "Channel%1 Block %3 Spindle %2 not referenced with zero mark" is no longer checked (cyclically) with
 Bit21 set after power ON of the closed loop position control.

Bit22:

Alarm 26080 "Channel %1 retraction position of axis %2 not programmed or invalid"
 Alarm 26081 "Channel %1 single axis trigger axis %2 is triggered, but axis is not PLC controlled"

Bit23:

Alarm 16949 "Correspondence between marks of channel %1 and channel %2 is invalid"

Bit24:

Alarm 16950 "Channel %1 search run with holding block"

Bit25:

Alarm 22016 "Channel %1 block %2 following spindle %3 in range of reduced acceleration capacity"

Bit26:

Alarm 22015 "Channel %1 block %2 following spindle %3 no dynamic response for additional motion"

Bit27:

Alarms 16112 and 22030 "Channel %1 block %2 following spindle %3 impermissible programming"

Bit28:

Alarm 26083 "Channel %1 ESR for PLC controlled axis %2 was triggered"

Bit29:

Alarm 16772 "Channel %1 block %2 axis %3 is following axis, coupling is opened"

Bit30:

Alarm 16600 "Channel %1 block %2 spindle %3 gear stage change not possible"

Bit31:

Alarm 16774 "Channel %1 axis %2 synchronization aborted"

11411	ENABLE_ALARM_MASK			EXP	D1,K1	
-	Activation of warnings			DWORD	Reset	
-						
-	-	0x800	0	0xFFFFFFFF	1/1	M

Description: Mask for generating alarms that are normally suppressed.
 Bit set: Alarms of this alarm group are output.
 Bit not set: Alarms of this alarm group are not output.

2.2 General machine data

```

Bit Hex.Meaning
   value
=====
0:  0x1Alarms that have SHOWALARMAUTO as the alarm response are output.
1:  0x2Alarms that have SHOWWARNING as the alarm response are output.
2:  0x4Alarm 22280 "Thread power up path too short" is output.
3:  0x8Alarms that are triggered by the NCU LINK MODULE are switched on.
4:  0x10Alarm 10883 "Chamfer or rounding must be shortened" allowed.
5:  0x20Alarm 20096 "Brake test aborted" is output.
6:  0x40Alarm 16956 "Program cannot be started because of global start dis-
    able" is output.
    Alarm14005 "Program cannot be started because of program-specific start
    disable" is output. Alarm can only be switched on in channel status RESET,
    in all other channel states it is output without conditions.
7:  0x80Alarm 16957 "Stop delay range is suppressed" is output.
8:  0x100Alarm 1011 fine coding150019 or 150020 "Incorrect axis number in
    the LINK".
9:  0x200Alarm 22033 Diagnostics 1 to 6 for "Track synchronism" (linkages).
10: 0x400Alarm 15122 "PowerOn after Powerfail: %1 data were restored,
    thereof %2 machine data, %3 errors" is output.
11: 0x800Alarms 10722, 10723, 10732 or 10733 are output instead of alarms
    10720, 10721, 10730 or 10731.
12: 0x1000Alarm 22033 diagnostics greater than or equal to 7 for "Track syn-
    chronism" (linkages)

```

11420	LEN_PROTOCOL_FILE			N01	PGA	
-	Size of protocol files (kB)			DWORD	PowerOn	
-						
-	-	100	1	1000000	1/1	M

Description: Blocks from the part program can be stored in a file in the passive file system with the WRITE command. The length of the log file is limited. If this maximum length is exceeded, the WRITE command returns an error (error code 10).

11422	PROTOCOL_FILE_MODE			EXP, N01	PGA	
-	Setting the behavior of the WRITE command			DWORD	PowerOn	
-						
-	-	0	0	0x3	1/1	M

Description: Setting the behavior of the WRITE command for writing to the passive file system

Bit 0 = 0:

The file created with WRITE is stored persistently in the USR area (see \$MM_U_FILE_MEM_SIZE).

The block written with WRITE becomes persistent immediately, i.e. it is stored power failsafe.

WRITE is slowed down by the backup with this setting.

Bit 0 = 1:

The file created with WRITE is stored persistently in the USR area (see \$MM_U_FILE_MEM_SIZE).

The block written with WRITE becomes persistent after a time delay.

WRITES less than one second old may be lost in the event of a power failure.

WRITE runs faster with this setting.

Bit 1: Reserved

11450	SEARCH_RUN_MODE	EXP, N01	K1,TE3,N4,H2,Z1			
-	Parameterization for search run	DWORD	PowerOn			
-						
-	-	0x07	0	0x3F	1/1	M

Description:

The behavior during the action blocks after search run can be affected by the following bits:

Bit 0 = 0:

Machining is stopped after loading of the last action block after search run, the NC/PLC interface signal DB3300 DBX0.6 (last action block active) and alarm 10208 is output.

Bit 0 = 1:

Machining is stopped with the loading of the last action block after search run, and the NC/PLC interface signal DB3300 DBX0.6 (last action block active) is set. Alarm 10208 is not output until the PLC requests it by setting the NC/PLC interface signal DB3200 DBX1.6 (PLC action finished).

Usage:

Starting an ASUB from the PLC after search run.

The message to the operator that another NC start is required in order to continue with the program is not to be displayed until after the end of the ASUB.

Bit1 = 1

Automatic ASUB start after output of the action blocks (see also MD11620 \$MN_PROG_EVENT_NAME). Alarm 10208 is not output until the ASUB has finished.

Bit2 = 0:

Spindle: The auxiliary functions are output in the action blocks

Bit2 = 1:

The output of the auxiliary functions in the action blocks is suppressed. The spindle programming collected by search run can be output at a later point in time (e.g. in an ASUB).

The program data for this are stored in the following system variables:

```
$P_SEARCH_S,
$P_SEARCH_SDIR,
$P_SEARCH_SGEAR,
$P_SEARCH_SPOS,
$P_SEARCH_SPOSMODE.
```

Bit 3 = 1:

The cascaded search run is disabled (default setting: release).

Cascaded search run means that the search run is restarted immediately after finding a search target.

2.2 General machine data

Bit 4:Reserved

Bit 5 = 0:

During block search on a nibbling block the 1st nibbling stroke is not executed.

Bit 5 = 1:

During block search on a nibbling block a punching stroke is triggered at block start (1st nibbling stroke).

11470	REPOS_MODE_MASK	EXP, N01	K1			
-	Repositioning properties	DWORD	PowerOn			
-						
-	-	0x8	0	0xFFFF	1/1	M

Description: This bit mask can be used to set the behavior of the control during repositioning.

Bit no. Meaning when bit set

0 (LSB)

The dwell time is continued in the residual block from where it was interrupted. (If the bit is not set, the dwell time is repeated completely).

1 Reserved

2 When the bit is set, the repositioning of individual axes can be prevented or delayed via the VDI interface.

3 When the bit is set, positioning axes are repositioned in the approach block during search run via program test.

4 As 3, but after every Repos, not only during search run.

5 When the bit is set, changed feeds and spindle speeds already become valid in the residual block, otherwise not until the following block.

6 When the bit is set, neutral axes and positioning spindles are repositioned after SERUPRO as command axes in the approach block.

7 The bit changes the behavior of the VDI-AXIN interface signal "Repos Delay". The level of "Repos Delay" is read if REPOSA is interpreted. Axes that are neither geo nor orientation axes are then excluded from the REPOS, that is REPOS does NOT move these axes.

11500	PREVENT_SYNACT_LOCK	N01, N09, -	S5,FBSY			
-	Protected synchronized actions	DWORD	PowerOn			
-						
-	2	0,0	0	255	2/2	M

Description: First and last IDs of a protected synchronized action area.

Synchronized actions with ID numbers in the protected area can no longer be

- overwritten
- disabled (CANCEL)
- locked (LOCK)

once they have been defined. Furthermore, protected synchronized actions cannot be locked by the PLC (LOCK). They are shown at the interface to the PLC as non-lockable.

Note:

The protection should be suspended while creating the synchronized actions to be protected, as otherwise a Power On will be necessary after every change in order to be able to redefine the logic. There is no area of protected synchronized actions with 0.0. The function is disabled. The values are read as absolute values, and over and under values can be given in any order.

11510	IPO_MAX_LOAD			N01, N05	-	
%	Max. permitted IPO load			DOUBLE	PowerOn	
-						
-	-	0.00	0.0	100.0	2/2	M

Description:

Enable utilization analysis via synchronized actions.

This MD11510 \$MN_IPO_MAX_LOAD sets the IPO computing time (in % of the IPO cycle) after which the variable \$AN_IPO_LOAD_LIMIT is to be set to TRUE. The variable is reset to FALSE if the value falls below this after having once exceeded it.

This diagnostics function is disabled if the machine data is 0.

11550	STOP_MODE_MASK			N01	V1	
-	Defines the stop behavior.			DWORD	PowerOn	
-						
-	-	0	0	0x1	1/1	M

Description:

This MD describes the stop behavior of the NCK under certain conditions:

Bit no. Meaning

Bit 0 == 0 :=

No stop if G codes G331/G332 are active and a path motion or G4 has also been programmed.

Bit 0 == 1 :=

Same behavior as until SW version 6.4, i.e. a stop is possible during G331/G332.

Bits 1.....15

Not assigned

11600	BAG_MASK			N01	K1,Z1	
-	Defines the mode group behavior			DWORD	PowerOn	
-						
-	-	0	0	0x3	1/1	M

Description:

This MD describes the effect of the VDI signals on the channels of a mode group in respect of ASUBs and interrupt routines.

Bit no. Hexadec. Meaning when bit set
value

Bit0: 0x0 Normal response to mode group signals in all channels of the mode group (as SW 3)

All channels switch into a program operating mode on interrupt.

2.2 General machine data

Bit0: 0x1 No response to other mode group VDI signale in the channel in which an interrupt handling (ASUB) is running. (BAG-RESET, BAG-STOP. individual types A and B, mode selection)

Bit1: 0x1 There is an operating mode changeover only in those channels which have received an interrupt request. (Only when bit 0 is set!)

11602	ASUP_START_MASK	N01, -	K1,M3,TE3,TE7
-	Ignore stop conditions for ASUB	DWORD	PowerOn
-			
-	-	0x01	0
		0xf	1/1
			M

Description:

This machine data defines which stop reasons are to be ignored on an ASUB start. The ASUB is started or the following stop reasons are ignored:

Bit 0 :

STOP reason: STOP key, M0 or M01

An ASUB is started immediately if NCK is in RESET status (or JOG mode) (no ASUB can be started in RESET/JOG without this bit).

Bit 1 :

Start allowed even if not all axes have been referenced yet.

Bit 2:

Start allowed even if a read-in disable is active; in other words, the blocks of the ASUB program are loaded and executed immediately. This disables machine data IGNORE_INHIBIT_ASUP. The NCK behavior corresponds to the machine data content of IGNORE_INHIBIT_ASUP== FFFFFFFF.

If the bit is not set:

The ASUB is selected internally but is not processed until the read-in disable is canceled.

The assignment of the machine data IGNORE_INHIBIT_ASUP is evaluated.

If IGNORE_INHIBIT_ASUP = 0 also applies, then an ASUB is triggered internally immediately but the blocks of the ASUB program are not loaded until the read-in disable is canceled.

The path is decelerated immediately when the ASUB is triggered (except with option BLSYNC).

The read-in disable is set once more in the ASUB program.

Bit 3:

Notice:

The following function can always be activated in single-channel systems. Multi-channel systems require bit1 in MD11600 \$MN_BAG_MASK in addition. The function is active o_n_l_y for those ASUBs that were activated from the Abort program status (Reset channel status). The function is not active in multi-channel systems without MD11600 \$MN_BAG_MASK bit1.

If an ASUB is started automatically from JOG, the user may stop in the middle of the ASUB program. JOG mode is displayed continuously for the user. With bit 3 set, the user may jog in this situation. This is not possible without bit 3. In this case mode change is locked with alarm 16927. By pressing the Start key, the user can continue the ASUB program. As long as the ASUB program is running, the user is naturally not able to jog. After ASUB program end the user may jog again.

Bits 4 to 15:Reserved

Related to:

MD11604 \$MN_ASUP_START_PRIO_LEVEL

11604	ASUP_START_PRIO_LEVEL	N01,-	K1,TE3,TE7
-	Priorities from which 'ASUP_START_MASK' is effective	DWORD	PowerOn
-			
-	-	2	0
-		128	1/1
-			M

Description: This machine data defines the ASUB priority from which MD11602 \$MN_ASUP_START_MASK is to be applied. MD11602 \$MN_ASUP_START_MASK is applied from the level specified here up to the highest ASUB priority level 1.

Related to:

MD11602 \$MN_ASUP_START_MASK

11610	ASUP_EDITABLE	N01	K1
-	Activation of a user-specific ASUB program	DWORD	PowerOn
-			
-	-	0	0
-		0x7	2/2
-			M

Description: This MD determines whether user-specific routine: `_N_ASUP_SPF` stored in directory `_N_CUS_DIR/` `_N_CMA_DIR` is to be used to process RET and REPOS. The user ASUB is searched for first in `_N_CUS_DIR`.

Value: Meaning:

0 Routine `_N_ASUP_SPF` is not activated for either RET or REPOS.

Bit0 = 1User-specific routine `_N_ASUP_SPF` is executed for RET, the routine supplied by the system is executed for REPOS.

Bit1 = 1User-specific routine `_N_ASUP_SPF` is executed for REPOS, the routine supplied by the system is executed for RET

Bit0= + bit1 = 3User-specific routine `_N_ASUP_SPF` is executed for both RET and REPOS

Bit2 = 1User ASUB `_N_ASUP_SPF` is searched for first in `_N_CMA_DIR`

Related to:

MD11612 \$MN_ASUP_EDIT_PROTECTION_LEVEL

References:

/IAD/ "Installation and Setup Guide"

2.2 General machine data

11612	ASUP_EDIT_PROTECTION_LEVEL	N01			K1	
-	Protection level of the user-specific ASUB program	DWORD			PowerOn	
-						
-	-	2	0	7	2/2	M

Description: Protection level of the user-specific ASUB program for RET and/or REPOS
 The data is active only if MD11610 \$MN_ASUP_EDITABLE is set to a value other than 0.
 This machine data defines the protection level of the program _N_ASU_CUS.
 MD irrelevant for:
 MD11610 \$MN_ASUP_EDITABLE set to 0
 Related to:
 MD11610 \$MN_ASUP_EDITABLE

11640	ENABLE_CHAN_AX_GAP	N01, N11			K2	
-	Allow channel axis gaps in AXCONF_MACHAX_USED	DWORD			PowerOn	
-						
-	-	0x0	0	0x1	2/2	M

Description: Bit0 = 1
 Machine data allows configuration of channel axis gaps in the MD20070 \$MC_AXCONF_MACHAX_USED.
 Permits following MD assignment:
 \$AXCONF_MACHAX_USED[0] = 1 ; 1st MA is 1st axis in channel
 \$AXCONF_MACHAX_USED[1] = 2 ; 2nd MA is 2nd axis in channel
 \$AXCONF_MACHAX_USED[2] = 0 ; Channel axis gap
 \$AXCONF_MACHAX_USED[3] = 3 ; 3rd MA is 3rd axis in channel
 \$AXCONF_MACHAX_USED[4] = 0
C A U T I O N:
 (BIT0 set with MD20070 \$MC_AXCONF_MACHAX_USED):
 If a geo axis is placed in a channel axis gap with MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[1]= 3, the control responds as with MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[1]= 0. This eliminates the geo axis!
 Transformation machine data must not be assigned a channel axis number specified as a gap.
 BIT1 - BIT31: not used.
 Related to:
 MD20080 \$MC_AXCONF_CHANAX_NAME_TAB,
 MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB,
 MD20060 \$MC_AXCONF_GEOAX_NAME_TAB
 MD20070 \$MC_AXCONF_MACHAX_USED
 MD24... \$MC_TRAFO_AXES_IN...
 MD24... \$MC_TRAFO_GEOAX_ASSIGN_TAB...

11717	D_NO_FCT_CYCLE_NAME			EXP, N12, N07	K1	
-	Subroutine name for D function replacement			STRING	PowerOn	
-						
-	-		-	-	2/2	M

Description:

Cycle name for replacement routine of the D function.

If a D function is programmed in a part program block, then, depending on machine data MD10717 \$MN_T_NO_FCT_CYCLE_NAME, MD10719 \$MN_T_NO_FCT_CYCLE_MODE and MD10718 \$MN_M_NO_FCT_CYCLE_PAR, the MD subprogram defined in MD11717 \$MN_D_NO_FCT_CYCLE_NAME is called.

The programmed D number can be polled in the cycle via system variable \$C_D / \$C_D_PROG.

MD11717 \$MN_D_NO_FCT_CYCLE_NAME is only active in Siemens mode (G290).

No more than one M/T/D function replacement can be active per part program line.

A modal subprogram call must not be programmed in the block with the D function replacement. Furthermore, neither subprogram return nor part program end are allowed.

In the event of a conflict alarm 14016 is output.

11750	NCK_LEAD_FUNCTION_MASK			N09	-	
-	Functions for master value coupling			DWORD	NEW CONF	
-						
-	-	0x00	0	0x10	1/1	M

Description:

Special functions of the master value coupling are set with this MD.

The MD is bit-coded, the following bits are assigned:

Bits 0-3:

reserved

Bit 4 == 0:

the following axis of a master value coupling decelerates independently on NC or mode group stop or channel-specific feed disable

Bit 4 == 1:

the following axis of a master value coupling does not decelerate independently on NC or mode group stop or channel-specific feed disable

Bits 5-31:

reserved

11752	NCK_TRAIL_FUNCTION_MASK			N09	-	
-	Functions for coupled motion			DWORD	NEW CONF	
-						
-	-	0x200	0	0x210	1/1	M

Description:

Special functions for coupled motions are set with this MD.

The MD is bit-coded; the following bits are assigned:

Bits 0-3:

reserved

Bit 4 = 0:

the following axis of a coupled axis grouping activated by a synchronized action decelerates independently on NC or mode group stop or channel-specific feed disable

2.2 General machine data

Bit 4 = 1:
 the following axis of a coupled axis grouping activated by a synchronized action does not decelerate independently on NC or mode group stop or channel-specific feed disable

Bit 5-31:
 reserved

11754	COUPLE_CYCLE_MASK	EXP, N09	-
-	Replacement of coupling language commands by machining cycles	DWORD	PowerOn
-			
-	-	0x3F	0
		0x7F	1/1
			M

Description: This machine data defines which predefined procedures for axis-spindle coupling are replaced by machining cycles.

This MD is bit-coded; the following bits are assigned:

Bit 0 == 0:
 The predefined procedures EGDEL, EGOFC, EGOFS, EGON, EGONSYN, and EGONSYNE are executed

Bit 0 == 1:
 The predefined procedures EGDEL, EGOFC, EGOFS, EGON, EGONSYN, and EGONSYNE are replaced by calling machining cycles

Bit 1 == 0:
 The predefined procedures LEADON and LEADOF are executed

Bit 1 == 1:
 The predefined procedures LEADON and LEADOF are replaced by calling machining cycles

Bit 2 == 0:
 The predefined procedures TRAILON and TRAILOF are executed

Bit 2 == 1:
 The predefined procedures TRAILON and TRAILOF are replaced by calling machining cycles

Bit 3 == 0:
 The predefined procedures COUPDEF, COUPDEL, COUPOF, COUPOFS, COUPON, COUPONC, and COUPRES are executed

Bit 3 == 1:
 The predefined procedures COUPDEF, COUPDEL, COUPOF, COUPOFS, COUPON, COUPONC, and COUPRES are replaced by calling machining cycles

Bit 4 == 0:
 The predefined procedures LEADON and LEADOF are executed in synchronized actions

Bit 4 == 1:
 The predefined procedures LEADON and LEADOF are replaced in synchronized actions by calling machining cycles as technology cycles

Bit 5 == 0:
 The predefined procedures TRAILON and TRAILOF are executed in synchronized actions

Bit 5 == 1:
 The predefined procedures TRAILON and TRAILOF are replaced in synchronized actions by calling machining cycles as technology cycles

Bit 6 == 0:

NCU link: Synchronism signals for classic couplings

Bit 6 == 1:

NCU link: Synchronism signals for generic coupling

11756	NCK_EG_FUNCTION_MASK			N09	-	
-	Functions for Electronic Gear			DWORD	NEW CONF	
-						
-	-	0x0	0	0x2F	1/1	M

Description:

This MD is used to set special functions of Electronic Gear (EG).

The MD is bit-coded, the following bits are occupied:

Bit 0 - 4:

reserved

Bit 5 = 0:

Positions indicated in EGONSYN and EGONSYNE are evaluated according to setting G700 or G710 inch or metric that is valid in the currently machined part program block.

Bit 5 = 1

Positions indicated in EGONSYN and EGONSYNE are evaluated in the basic system involved.

Bit 6 - 31:

reserved

12000	OVR_AX_IS_GRAY_CODE			EXP, N10	V1,Z1	
-	Axis feedrate override switch Gray-coded			BOOLEAN	PowerOn	
-						
-	-	TRUE	-	-	1/1	M

Description:

This machine data is used to adapt the axis feed override switch to the interface coding of the PLC interface.

1: The 5 low-order bits of the PLC interface signal DB380x DBX0 (Feed override A-H) are interpreted as a Gray code. The value which is read corresponds to a switch setting. It is used as an index for selecting the correct override factor from the table of MD12010 \$MN_OVR_FACTOR_AX_SPEED [n].

0: The feed override byte of the PLC interface is interpreted as a binary representation of the override value in percent (limit 200 percent).

Related to:

NC/PLC interface signal DB380x DBX0 (Feed override A-H), (axis-specific)

MD12010 \$MN_OVR_FACTOR_AX_SPEED [n]

(Evaluation of the axis feed override switch)

12010	OVR_FACTOR_AX_SPEED			EXP, N10	V1,Z1	
-	Evaluation of axis feedrate override switch			DOUBLE	PowerOn	
-						
-	31	0.00,0.01,0.02,0.04,0.06,0.08,0.10...	0.00	2.00	1/1	M

Description:

Evaluation of the axis velocity override switch with gray-coded interface.

Not relevant with:

MD12000 \$MN_OVR_AX_IS_GRAY_CODE = 0

Related to:

NC/PLC interface signal DB380x DBX0 (Feed override A-H), (axis-specific)

12020	OVR_FEED_IS_GRAY_CODE	EXP, N10	V1,Z1
-	Path feedrate override switch Gray-coded	BOOLEAN	PowerOn
-			
-	-	TRUE	-
-	-	-	1/1 M

Description:

This machine data is used to adapt the path feed override switch to the interface coding of the PLC interface.

1: The 5 low-order bits of the NC/PLC interface signal DB380x DBX0 (Feed override A-H) are interpreted as a Gray code. The value which is read corresponds to a switch setting. It is used as an index for selecting the correct override factor from the table of MD12030 \$MN_OVR_FACTOR_FEEDRATE [n].

0: The feed override byte of the PLC interface is interpreted as a binary representation of the override value in percent (limit 200 percent).

Related to:

NC/PLC interface signal DB380x DBX0 (Feed override A-H)

MD12030 \$MN_OVR_FACTOR_FEEDRATE [n]

(Evaluation of the path feed override switch)

12030	OVR_FACTOR_FEEDRATE	EXP, N10	V1,B1,Z1
-	Evaluation of path feedrate override switch	DOUBLE	PowerOn
-			
-	31	0.00,0.01,0.02,0.04,0.06,0.08,0.10...	0.00 2.00 1/1 M

Description:

Evaluation of the feedrate override switch with gray-coded interface.

Special function of the 31st value for the velocity control:

The setting of the 31st override value defines the dynamic reserves which take the velocity control to be an excessive increase in the path feed. The setting should correspond to the highest override factor actually used.

The function of the 31st value is thus identical to the effect of MD12100 \$MN_OVR_FACTOR_LIMIT_BIN when using the binary-coded interface.

Not relevant with:

MD12020 \$MN_OVR_FEED_IS_GRAY_CODE = 0

Related to:

NC/PLC interface signal DB380x DBX0 (Feed override A-H)

12040	OVR_RAPID_IS_GRAY_CODE	EXP, N10	V1,Z1
-	Rapid traverse override switch Gray-coded	BOOLEAN	PowerOn
-			
-	-	TRUE	-
-	-	-	1/1 M

Description:

This machine data is used to adapt the rapid traverse override switch to the interface coding of the PLC interface.

1: The 5 low-order bits of the PLC interface signal DB3200 DBX5 (Rapid traverse override A-H) are interpreted as a Gray code. The value which is read corresponds to a switch setting.

It is used as an index for selecting the correct override factor from the table of MD12050 \$MN_OVR_FACTOR_RAPID_TRA[n].

0: The rapid traverse override byte of the PLC interface is interpreted as a binary representation of the override value in percent (limit 200 percent).

Related to:

NC/PLC interface signal DB3200 DBX5 (Rapid traverse override A-H)

MD12050 \$MN_OVR_FACTOR_RAPID_TRA[n]

(Evaluation of the rapid traverse override switch)

12050	OVR_FACTOR_RAPID_TRA		EXP, N10	V1,Z1		
-	Evaluation of rapid traverse override switch		DOUBLE	PowerOn		
-						
-	31	0.00,0.01,0.02,0.04,0.06,0.08,0.10...	0.00	1.00	1/1	M

Description: Evaluation of the rapid traverse override switch with gray-coded interface.
Not relevant with:

MD12040 \$MN_OVR_RAPID_IS_GRAY_CODE = 0

Related to:

NC/PLC interface signal DB3200 DBX5 (Rapid traverse override A-H)

12060	OVR_SPIND_IS_GRAY_CODE		EXP, N10	V1,Z1		
-	Spindle override switch Gray-coded		BOOLEAN	PowerOn		
-						
-	-	TRUE	-	-	1/1	M

Description: This machine data is used to adapt the spindle speed override switch to the interface coding of the PLC interface.

1: The 5 low-order bits of the "spindle speed override" PLC interface signal are interpreted as a Gray code. The value which is read corresponds to a switch setting. It is used as an index for selecting the correct override factor from the table of MD12070 \$MN_OVR_FACTOR_SPIND_SPEED [n].

0: The spindle speed override byte of the PLC interface is interpreted as a binary representation of the override value in percent (limit 200 percent).

Related to:

NC/PLC interface signal DB380x DBX2003 (Spindle speed override)

MD12070 \$MN_OVR_FACTOR_SPIND_SPEED[n]

(Evaluation of the spindle speed override switch)

12070	OVR_FACTOR_SPIND_SPEED		EXP, N10	V1,Z1		
-	Evaluation of spindle override switch		DOUBLE	PowerOn		
-						
-	31	0.5,0.55,0.60,0.65,0.70,0.75,0.80...	0.00	2.00	1/1	M

Description: Evaluation of the spindle-specific override switch with Gray-coded interface.
Special function of the 31st value for the velocity control:

The setting of the 31st override value defines the dynamic reserves which take the velocity control to be an excessive increase in the spindle feed. The setting should correspond to the highest override factor actually used. The function of the 31st value is thus identical to the effect of MD12100 \$MN_OVR_FACTOR_LIMIT_BIN when using the binary-coded interface.

Not relevant for:

MD12060 \$MN_OVR_SPIND_IS_GRAY_CODE = 0

Related to:

NC/PLC interface signal DB380x DBX2003 (Spindle speed override)

12080	OVR_REFERENCE_IS_PROG_FEED	N10, N09	V1
-	Override reference speed	BOOLEAN	PowerOn
-			
-	-	TRUE	-
-	-	-	-
			1/1
			M

Description: The entry in this MD specifies whether the spindle override given by the IS refers to the speed limited by MD/SD or to the programmed speed.

- 1: Spindle override acts with reference to the programmed speed
(programmed speed _ spindle override 100%)
- 0: Spindle override acts on the speed limited by MD or SD
(speed limited by MD/SD _ spindle override 100%)

Related machine data:

A speed limitation is effected by the following MDs or SDs:

MD35100	\$MA_SPIND_VELO_LIMIT	Maximum spindle speed
MD35130	\$MA_GEAR_STEP_MAX_VELO_LIMIT	Maximum speed of gear stage
MD35160	\$MA_SPIND_EXTERN_VELO_LIMIT	Spindle speed limitation by PLC
SD43220	\$SA_SPIND_MAX_VELO_G26	Maximum spindle speed
SD43230	\$SA_SPIND_MAX_VELO_LIMS	Spindle speed limitation with G96

12082	OVR_REFERENCE_IS_MIN_FEED	N10, N09	V1
-	Specification of the reference of the path override	BOOLEAN	PowerOn
-			
-	-	FALSE	-
-	-	-	-
			1/1
			M

Description: The reference speed for the path feed override specified via the machine control panel can be set differently from the standard.

0: Standard:

The override is relative to the programmed feed.

1: Special case:

The override is relative to the programmed feed or to the path feed limit, depending on which resulting value is lower. In this way, even for a great feed reduction (due to the permissible axis dynamics), the effect of the override value (in the range 0 to 100%) is always visible.

12090	OVR_FUNCTION_MASK	N01, N10, N09	-
-	Selection of override specifications	DWORD	Reset
-			
-	-	0	0
-	-	0x01	1/1
			M

Description: The functionality of the override switches can be affected by the bits.

Bit 0: = 0,

Standard: Spindle override active with G331/G332

= 1,

Path override is active instead of spindle override with G331/G332

(Tapping without compensating chuck)

12100	OVR_FACTOR_LIMIT_BIN	EXP, N10	V1,B1,Z1
-	Limitation for binary-coded override switch	DOUBLE	PowerOn
-			
-	-	1.2	0.0
-		2.0	1/1
			M

Description: This machine data can be used as an additional limit for the override factor when using the binary-coded interface for path, axis and spindle feeds.

In this case, the maximum values

- 200% for channel-specific feed override
- 100% for channel-specific rapid traverse override
- 200% for axis-specific feed override
- 200% for spindle override

are replaced with the limit value entered in MD: OVR_FACTOR_LIMIT_BIN when this value is lower.

Example: OVR_FACTOR_LIMIT_BIN = 1.20

--> maximum override factor for

- channel-specific feed override =120%
- channel-specific rapid traverse override =100%
- axis-specific feed override =120%
- spindle override =120%

This value also defines the dynamic reserves maintained by the speed control for increasing the path and spindle feedrates.

References:

/FB/, B1, "Continuous Path Mode, Exact Stop and Look Ahead"

12202	PERMANENT_FEED	N01, N09	Z1,V1
mm/min	Fixed feedrates for linear axes	DOUBLE	Reset
-			
-	4	0.,0.,0.,0.	-
			2/2
			M

Description: In AUTOMATIC mode:
After activating a fixed feedrate via an interface signal, traversing is done with a fixed feedrate instead of the programmed feedrate.

Note:

The fixed feedrate is also evaluated in continuous-path mode in order to optimize the overhead for the Look Ahead calculation. Unnecessarily high values should therefore be avoided. Enter zero if a fixed feedrate is not wanted

In JOG mode:

After activating a fixed feedrate via an interface signal, and traversing the linear axis with a traversing key, traversing proceeds in the selected direction with the fixed feedrate.

n = 0, 1, 2, 3 mean fixed feedrates 1, 2, 3, 4. The values must be entered in ascending order.

Special cases, errors,

The maximum velocity defined by MD32000 \$MA_MAX_AX_VELO is active. An override setting of 100 % is assumed. MD12200 \$MN_RUN_OVERRIDE_0 is active if the override is 0.

Related to:

MD12200 \$MN_RUN_OVERRIDE_0

12204	PERMANENT_ROT_AX_FEED			N01, N09	V1	
rev/min	Fixed feedrates for rotary axes			DOUBLE	Reset	
-						
-	4	0.,0.,0.,0.	-	-	2/2	M

Description:

Fixed feedrate values:

In AUTOMATIC mode:

After activating a fixed feedrate via an interface signal, traversing is done with a fixed feedrate instead of the programmed feedrate.

Note: PERMANENT_ROT_AX_FEED is used instead of PERMANENT_FEED for the path motion if all synchronously traversed axes in the current block are rotary axes. PERMANENT_FEED applies if linear and rotary axes are to be synchronously traversed together.

The fixed feedrate is also evaluated in continuous-path mode in order to optimize the overhead for the Look Ahead calculation. Unnecessarily high values should therefore be avoided. Enter zero if a fixed feedrate is not wanted

In JOG mode:

After activating a fixed feedrate via an interface signal, and traversing the rotary axis with a traversing key, traversing proceeds in the selected direction with the fixed feedrate.

n = 0, 1, 2, 3 mean fixed feedrates 1, 2, 3, 4.

Special cases, errors,

The maximum velocity defined by MD32000 \$MA_MAX_AX_VELO is active. An override setting of 100 % is assumed. MD12200 \$MN_RUN_OVERRIDE_0 is active if the override is 0.

Related to:

MD12200 \$MN_RUN_OVERRIDE_0

12205	PERMANENT_SPINDLE_FEED			N01, N09	FBMA	
rev/min	Fixed feedrates for spindles			DOUBLE	Reset	
-						
-	4	0.,0.,0.,0.	-	-	2/2	M

Description:

Fixed feedrate values:

JOG: A spindle is traversed with a fixed feedrate by activating the traversing keys and activating the appropriate signals in the PLC interface.

The override is not active.

Depending upon MD12200 \$MN_RUN_OVERRIDE_0, traversing also takes place with override 0.

The value defined by MD32000 \$MA_MAX_AX_VELO is taken as the upper limit. If the fixed feedrate has a larger value, the aforementioned limiting value applies.

12300	CENTRAL_LUBRICATION		N01, N09	-		
-	Central lubrication active		BOOLEAN	PowerOn		
-						
-	-	FALSE	-	-	2/2	M

Description: When a settable axial path has been exceeded, the axial VDI signals request a lubrication pulse from the PLC (compare MD33050 \$MA_LUBRICATION_DIST). These axial pulses act (by default) independently of each other.

If the machine construction requires a central lubrication, i.e. the lubrication pulse of any axis is acting on all axes, the corresponding path monitoring of all axes must be restarted after lubrication pulse output. This start synchronization of the monitoring is executed via MD12300 \$MN_CENTRAL_LUBRICATION=TRUE.

12986	PLC_DEACT_IMAGE_LADDR_IN		N10	-		
-	Deactivation of I/O connection to the PLC image		DWORD	PowerOn		
-						
-	8	0,9,18,27,36,96,112,-1	-1	255	1/1	M

Description: The PLC input/output image of the stations with these logical addresses is not connected to the real I/Os

12987	PLC_DEACT_IMAGE_LADDR_OUT		N10	-		
-	Deactivation of I/O connection to the PLC image		DWORD	PowerOn		
-						
-	8	-1,-1,-1,-1,-1,-1,-1,-1	-1	255	1/1	M

Description: The PLC input/output image of the stations with these logical addresses is not connected to the real I/Os

13060	DRIVE_TELEGRAM_TYPE		N04, N10	G2		
-	Standard message frame type for PROFIdrive		DWORD	PowerOn		
-						
-	31	116,116,116,116,116,116,116,116,116...	-	-	1/1	M

Description: For PROFIdrive only:
Standard telegram type for PROFIdrive axes:
0 = No standard type, user-defined
(telegram type 103 is then used internally in the NCK, whereby other process data can be added.)
1... 6 = PROFIdrive type
101...107 = SIEMENS type
116 = SIEMENS type as 106 plus trace data
118 = SIEMENS type as 116, but use of encoders 2+3
136 = SIEMENS type as 116 plus torque feedforward control
139 = SIEMENS type telegram specifically for Weiss spindle functionality

201...203 = internal type

Notes: Alarm 26015 is issued with reference to this machine data if the telegram configuration exhibits inconsistencies, i.e. if the telegram type selected on the NCK does not match the telegram type set on the drive (see parameter P922) and the process data configuration does not match (see parameters P923, P915, P916). The check for telegram configuration errors can be disabled using MD DRIVE_FUNCTION_MASK bit 15.

The SIEMENS telegram types lxx must be operated in the SINUMERIK context in 611U interface mode.

13110	PROFIBUS_TRACE_ADDRESS	EXP	-			
-	PROFIBUS/PROFINET trace of I/O slots	DWORD	NEW CONF			
-						
-	14	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M

Description: For PROFIBUS/PROFINET only:
Logical I/O address that is to be recorded.

13111	PROFIBUS_TRACE_TYPE	EXP	-			
-	PROFIBUS/PROFINET trace settings	DWORD	NEW CONF			
-						
-	-	0	0	3	1/1	M

Description: For PROFIBUS/PROFINET only:
0: Recording to the part program memory /_N_MPF_DIR/_N_SIEMDPTRC_MPF
1: Recording to mass storage /user/sinumerik/data/temp/siemptrc.trc
2: Recording to the part program memory with runtime measurement
3: Recording of cyclic PN-NCULINK communication

13112	PROFIBUS_TRACE_FILE_SIZE	EXP	-			
-	Maximum trace file size in kbytes	DWORD	NEW CONF			
-						
-	-	40	-	-	1/1	M

Description: For PROFIBUS/PROFINET only:
0: Trace without file size limitation
>0: Trace with file size limitation

13113	PROFIBUS_TRACE_START	EXP	-			
-	Activation of PROFIBUS/PROFINET trace	DWORD	Immediately			
-						
-	-	0	0	1	1/1	M

Description: For PROFIBUS/PROFINET only:
0: Trace off
1: Trace on
MD13112 \$MN_PROFIBUS_TRACE_FILE_SIZE > 0: Trace is automatically disabled when the file size is reached.

13114	PROFIBUS_TRACE_START_EVENT			EXP	-	
-	Trigger conditions for PROFIBUS/PROFINET trace			DWORD	NEW CONF	
-						
-	14	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0x00000000	0x111ffff	1/1	M

Description: For PROFIBUS/PROFINET only:
The trigger frequency is configured bit-by-bit
Bits 0-15: 0x0001-0xffff: bit mask
Bits 16-23: 0x01-0x14: process data number (a maximum of 20 words are permissible)
Bits 24-27:0x01: status change 0->1
 0x00: status change 1->0
Bits 28-31:0x10: send slot
 0x00: receive slot
When MD13113=1 and MD13114=0x0 Recording starts immediately
When MD13113=1 and MD13114=0x1 Recording starts on control power on
When MD13113=1 and MD13114=0x2 Recording starts on loss of the sign of life

13120	CONTROL_UNIT_LOGIC_ADDRESS			N04, N10	-	
-	Logical address of SINAMICS CU			DWORD	PowerOn	
-						
-	15	6500,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	8191	2/2	M

Description: For PROFIBUS/PROFINET, SINAMICS:
Logical I/O address of a SINAMICS-CU (Control Unit) on the PROFIBUS/PROFINET.
The cyclic DP communication with SINAMICS-CU is activated by taking over the associated slot address from the STEP7 project. The onboard I/Os cannot be accessed until after configuration.

13140	PROFIBUS_ALARM_ACCESS			N04, N10	-	
-	Alarm response of PROFIBUS/PROFINET drives on power up			DWORD	Immediately	
-						
-	-	1	0	2	1/7	M

Description: For PROFIBUS/PROFINET only:
Specifies the time of activation for evaluation/transmission of PROFIBUS/PROFINET node alarms or warnings (fine diagnostics messages) on the NCK.
Affects drive alarms or warnings 380500, 380501 (or alarms 200000ff etc. created from these in the HMI) as well as drive safety alarms 27900.
Meaning of the MD values:
0 = alarms/warnings are evaluated immediately
1 = alarms/warnings are not evaluated
2 = alarms are evaluated only after power up, i.e. as soon as HMI has set value 2 active again (NCK automatically resets the MD value to 1 at every power up; HMI must explicitly articulate its readiness for message processing by setting value 2)

2.2 General machine data

Note: the MD restricts the range or effectiveness of MD13150 \$MN_SINAMICS_ALARM_MASK

Default: the display default behavior of the mentioned drive alarms changes with the introduction of this MD. Now the alarms are not transported and displayed by default.

The previous default behavior can be restored with MD13140 \$MN_PROFIBUS_ALARM_ACCESS=0.

13150	SINAMICS_ALARM_MASK	N04, N05	-			
-	Activate fault and warning buffer output for Sinamics	DWORD	Immediately			
-						
-	-	0x2929	-	-	2/2	M

Description: For PROFIBUS/PROFINET only, especially SINAMICS:
 Relevant to SINAMICS diagnostics:
 Note: the effect of this MD may be hidden independently of the value of \$MN_PROFIBUS_ALARM_ACCESS.
 Mask for displaying the SINAMICS DOS fault and warning buffers
 Bit set: Alarms in this DO group are output
 Bit not set: Alarms in this DO group are not output
 Bit Hex. Meaning
 value
 =====
 =====
 0: 0x1 Output faults of the Control Units
 1: 0x2 Reserved
 2: 0x4 Output faults of the Drive Controls
 3: 0x8 Output faults of the Line Modules
 4: 0x10 Output faults of the Terminal Boards
 5: 0x20 Output faults of the Terminal Modules
 8: 0x100 Output warnings of the Control Units
 9: 0x200 Output warnings of the Communication Objects
 10: 0x400 Output warnings of the Drive Controls
 11: 0x800 Output warnings of the Line Modules
 12: 0x1000 Output warnings of the Terminal Boards
 13: 0x2000 Output warnings of the Terminal Modules

13200	MEAS_PROBE_LOW_ACTIVE	N10, N09	M5			
-	Polarity reversal of sensor	BOOLEAN	PowerOn			
-						
-	2	FALSE,FALSE	-	-	3/3	M

Description: This MD defines the electrical polarity of each connected sensor.
 Value 0:
 (Default setting)
 Non-deflected state 0 V
 Deflected state 24 V

Value 1:

Non-deflected state 24 V
 Deflected state 0 V

The programmed edges of the sensor are independent of the electrical polarity, and are to be regarded as purely mechanical. The programming of a positive edge always means the transition from the non-deflected into the deflected state. The programming of a negative edge always means the transition from the deflected into the non-deflected state.

13210	MEAS_TYPE			N10, N09	M5	
-	Meas. type with decentralized drives			BYTE	PowerOn	
-						
-	-	1	0	1	1/0	M

Description:

For PROFIdrive only:

This MD sets the measuring function of decentralized drives.

The MD currently only functions for PROFIdrive drives.

MEAS_TYPE = 0 defines:

A probe is used that is connected centrally to the NC.

However, as the encoders only provide actual position values in cycles, the actual measuring position is found by interpolation.

MEAS_TYPE = 1 defines:

The probe must be wired decentralized to ALL drives.

The measuring functionality of the drive is then used, saving the actual encoder values in the hardware at the time of the measuring edge.

This method is more accurate than that with MEAS_TYPE = 0, but it requires a more complex wiring and drives that support this measuring functionality (e.g. 611U).

13220	MEAS_PROBE_DELAY_TIME			N10, N09	FBA/IAD	
s	Delay time between probe deflection and recognition			DOUBLE	PowerOn	
-						
-	2	0.0,0.0	0	0.1	3/3	M

Description:

For probes with e.g. radio transmission, the probe deflection can be detected in the NC only with delay.

With this MD, the transmission link delay between the probe deflection and its detection is set in the control.

The measured value is corrected internally by the control by the distance that corresponds to the traversing motion during this time before measuring (modeling).

It is practicable to set values only up to a maximum of 15 position controller cycles.

Anyhow, the modeling could not work with the expected accuracy with values greater than that. In this case, the input value is therefore limited internally by the software to 15 position controller cycles (without any further feedback).

Machine data

2.2 General machine data

13230	MEAS_PROBE_SOURCE	N10, N09		-		
-	Probe simulation	BYTE		PowerOn		
-						
-	-	0	0	9	7/2	M

Description: Simulation of the probe only works when all axes are simulated.
Value = 0: the probe is triggered on the programmed end position.
Value = 1-8: the probe is triggered via digital output with the number=value.
Value = 9: reserved

13231	MEAS_PROBE_OFFSET	N10, N09		-		
mm/inch, degrees	Probe offset	DOUBLE		Immediately		
-						
-	-	0.1	-	-	7/7	U

Description: The switching position of the probe is offset by the value.
The offset is only active with the simulated probes and MD 13230=0.

14510	USER_DATA_INT	N03		P3		
-	User data (INT)	DWORD		PowerOn		
-						
-	256	0,0,0,0,0,0,0,0,0,0, 0,0,0,0,0,0,0,0,0,0, 0,0...	-32768	32767	2/2	I

Description: User data is stored in the NCK-PLC interface, and can be read by the PLC user from the DB20 during the runup.

14512	USER_DATA_HEX	N03		P3		
-	User data (HEX)	DWORD		PowerOn		
-						
-	256	0,0,0,0,0,0,0,0,0,0, 0,0,0,0,0,0,0,0,0,0, 0,0...	0	0x0FF	2/2	I

Description: User data is stored in the NCK-PLC interface and can be read by the PLC user from the DB20 during the PLC runup.

14514	USER_DATA_FLOAT	N03		P3		
-	User data (FLOAT)	DOUBLE		PowerOn		
-						
-	32	0,0,0,0,0,0,0,0,0,0, 0,0,0,0,0,0...	-3.40e38	3.40e38	2/2	I

Description: User data is stored in the NCK-PLC interface, and can be read by the PLC user from the DB20 during the runup.

14516	USER_DATA_PLC_ALARM	N03		A2,P3		
-	User data (HEX)	BYTE		PowerOn		
-						
-	248	0,0,0,0,0,0,0,0,0,0, 0,0,0,0,0,0,0,0,0,0, 0,0...	-	-	2/2	S

Description: User data is stored in the NCK-PLC interface and can be evaluated by the PLC basic system (currently for software PLC 2xx).

15700	LANG_SUB_NAME	N01	K1
-	Name for substitution subroutine	STRING	PowerOn
-			
-	-	-	2/2 M

Description: Name of the user program called on the basis of a substitution configured by MD30465 \$MA_AXIS_LANG_SUB_MASK.
The user program is called with the path configured by MD15702 \$MN_LANG_SUB_PATH.

15702	LANG_SUB_PATH	N01	K1
-	Call path for substitution subroutine	BYTE	PowerOn
-			
-	-	0	0 2 2/2 M

Description: Path with which the user program set by MD15700 \$MN_LANG_SUB_NAME is called on the basis of a substitution configured by MD30465 \$MA_AXIS_LANG_SUB_MASK:
0: /_N_CMA_DIR (default)
1: /_N_CUS_DIR
2: /_N_CST_DIR

15710	TCA_CYCLE_NAME	N09	K1,FBW
-	Program name for replacement of the TCA command	STRING	PowerOn
-			
-	-	-	7/2 M

Description: Program name for the replacement program when calling the TCA command.
If the TCA command is programmed in a part program block, then the subprogram defined in \$MN_TCA_CYCLE_NAME is called at the end of the block. The programmed tool can be requested in the replacement program via the system variables \$C_TS_PROG / \$C_TS, the Duplo number via \$C_DUPLO_PROG / \$C_DUPLO and the toolholder/spindle number via \$C_THNO_PROG / \$C_THNO. The system variable \$C_TCA returns the value TRUE in the replacement program.
If \$MN_TCA_CYCLE_NAME contains an empty string, the replacement is deactivated (default).

17400	OEM_GLOBAL_INFO	A01, A11	-
-	OEM version information	STRING	PowerOn
-			
-	5	-	2/2 I

Description: A version information freely available to the user (is indicated in the version screen)
Note: MD17400 \$MN_OEM_GLOBAL_INFO[0] is used with functions such as logbook, licensing, etc. to store the machine identity.

17500	MAXNUM_REPLACEMENT_TOOLS			N09	FBW	
-	Maximal number of replacement tools.			DWORD	PowerOn	
-						
-	-	1	0	32	1/1	M

Description:

Only relevant if the tool management function is active.

Only relevant if the tool management (TMMA) function or the tool monitoring function (TMMO) is active.

0: The number of replacement tools is not monitored.

1: Exactly one replacement tool may be assigned to an identifier.

The data does not influence the memory requirement. It is solely for monitoring purposes.

Related to:

MD18080 \$MN_MM_TOOL_MANAGEMENT_MASK,

MD20310 \$MC_TOOL_MANAGEMENT_MASK

17600	DEPTH_OF_LOGFILE_OPT			EXP, N01	-	
-	Depth of log memory optimization in REORG			DWORD	Reset	
-						
-	-	5	0	300	1/1	M

Description:

The depth of memory optimization in the REORG log file

(=search depth to determine if a parameter to be written is already included in the REORG log file).

The value of the machine data can be increased if alarm 15110 occurs during program execution and if this alarm is to be avoided.

(Alternatively, the size of the REORG log file can be increased with MD28000 \$MC_MM_REORG_LOG_FILE_MEM, provided that the operator has the access rights required. This procedure should generally be preferred.)

Value

0 = No optimization,

That is each write operation creates an input into the REORG log file.

Writing a variable value is therefore very time-efficient, but requires more memory.

0 < n ≤ Maximum value

When a new variable value is written, the n previously entered write operations (but maximally up to the previous indicatable block) are checked to determine if the parameter now to be written has already been written in the past. If this is the case, a new entry is not made in the REORG log file.

If this is not the case, an entry is made. A variable value can therefore be written in a very memory-efficient way, but requires more time.

Example:

MD17600 \$MN_DEPTH_OF_LOGFILE_OPT is assumed to be 5 and the following would be a typical program sequence:

```
x10      ; Executable NC block
r1=1     ; The first write command since x10
         ; -> Save old value in log file. 1st entry
r2=1     ; Determine that r2 is not yet included
         ; -> Save old value in log file. 2nd entry
```



```

r3=1    ; Determine that r3 is not yet included
        ; -> Save old value in log file. 3rd entry
r4=1    ; Determine that r4 is not yet included
        ; -> Save old value in log file. 4th entry
r5=1    ; Determine that r5 is not yet included
        ; -> Save old value in log file. 5th entry
r6=1    ; Determine that r6 is not yet included
        ; -> Save old value in log file. 6th entry
r2=1    ; Determine that r2 is already included
        ; (5th oldest entry) -> no renewed saving
r3=1    ; Determine that r3 is already included
        ; (4th oldest entry) -> no renewed saving
r1=2    ; As MD17600 $MN_DEPTH_OF_LOGFILE_OPT = 5 it is not detected that
        ; r1 is already included
        ; (6th oldest entry) -> save old value in log file.
        ; 7th entry
x20     ; Executable NC block
r1=3    ; The first write command since x20
        ; -> Save old value in log file. 1st entry
r1=4    ; Determine that r1 is already included
        ; (Only one entry) -> no renewed saving

```

The setting of the MD is particularly useful if a small number of various parameters are written frequently (e.g. in a loop) and if alarm 15110 occurs for this reason.

17610	DEPTH_OF_LOGFILE_OPT_PF			EXP, N01	-	
-	Depth of the PowerFail log memory optimization			DWORD	Reset	
-						
-	3	10,0,0	0	300	1/1	M

Description:

Depth of the memory optimization in the PowerFail log file (=search depth, to find out

whether a parameter to be written is already included in the PowerFail log file).

It is possible to increase the value of the machine data if alarm 15120 occurs during program processing and if you wish to avoid it. (Alternatively, you can increase the size of the PowerFail log file itself by means of MD18232 \$MN_MM_ACTFILESYS_LOG_FILE_MEM, if you have the necessary access right

and if the required memory is available.

Value

0 = same effect as value 1.

Writing of a variable value is therefore very time-efficient at the cost of the required memory.

0 < n <= Maximum value

= Writing of a new variable value leads, prior to saving of the new variable value in the PowerFail log file, to the last n write operations which have been being checked to see whether the new parameter to be written has already been written once.

2.2 General machine data

If yes, the new value is not entered again in the PowerFail log file, but the old value is overwritten with the new one.
 If no, the new value is entered.

At the cost of the required time, writing of a variable value can therefore be designed very memory-efficiently.

Changing of the data can shorten/increase the time requirement of the present application.

Changing of the data can fill the available log buffers faster/more slowly.

Frequent occurring of alarm 15120 -> Increase values for index=0,1,2.

The value indicating the index to be changed can be deducted from the parameter of alarm 15120:

if it is the value for MD18232 \$MN_MM_ACTFILESYS_LOG_FILE_MEM[0], then increase the value for index 0;

or increase MD18232 \$MN_MM_ACTFILESYS_LOG_FILE_MEM[0] itself.

Index Meaning

- 0 Search depth in preprocessing buffer
- 1 Search depth in buffer for data changes within the range of tool change
- 2 Search depth in buffer for data changes of main processing (especially synchronized actions)

18030	HW_SERIAL_NUMBER			N05	-	
-	Hardware series number			STRING	PowerOn	
-						
-	1		-	-	2/RO	M

Description: During power on of the control, a unique hardware serial number is stored in this MD:

- For Powerline series modules this is the serial number of the NCU module
- For Solutionline series modules this is the serial number of the CF card, or the unique number of the MCI module in the case of PC-based systems

This data cannot be written.

18040	VERSION_INFO			N05	IAD	
-	Version			STRING	PowerOn	
-						
828d-me41	4	828D-ME41	-	-	7/RO	M
828d-me61	4	828D-ME61	-	-	7/RO	M
828d-me81	4	828D-ME81	-	-	7/RO	M
828d-te61	4	828D-TE61	-	-	7/RO	M
828d-te81	4	828D-TE81	-	-	7/RO	M
828d-te41	4	828D-TE41	-	-	7/RO	M

Description: Version identifiers of the system software

18050	INFO_FREE_MEM_DYNAMIC	N01, N02, N05	S7
-	Display data of free dynamic memory	DWORD	PowerOn
-			
-	-	1572864	-
-	-	-	1/1 M

Description:

The data is used for

a) the manufacturer's presetting of the memory size [bytes] available to the user for each channel after cold restart.

b) Displaying the available dynamic memory [bytes]

The data cannot be written.

The contents of the data state how much unbuffered memory is available per channel for increasing the unbuffered user data storage area via MD.

One should check whether the available memory is sufficient before increasing, for example, the number of LUDs, number of functional parameters, or the size of the IPO buffer.

If necessary, proceed step by step:

- increase by 1, note (old) value
- NCK startup (= 'warm start' or NCK reset), read off new value
- memory requirement = new value - old value

On the first NCK startup or cold restart of the control (=deletion of user data), MD18210 \$MN_MM_USER_MEM_DYNAMIC is set by the NCK software so that at least the preset value results for MD18050 \$MN_INFO_FREE_MEM_DYNAMIC.

That is, the value is automatically increased if the initial value of MD18210 \$MN_MM_USER_MEM_DYNAMIC is too low.

The following also applies to multichannel systems:

- The preset value applies to each possible channel. That is, if there are ten possible channels, MD18210 \$MN_MM_USER_MEM_DYNAMIC is set by the NCK SW so that at least the 'preset value* ten' results for MD18050 \$MN_INFO_FREE_MEM_DYNAMIC.
- On activation of a channel, MD18210 \$MN_MM_USER_MEM_DYNAMIC is increased if necessary so that the memory free at the time of activation continues to be free (provided that the memory structure permits this) after the channel has become active.
- The activation of the maximum possible number of axes is ensured by increasing the data MD18210 \$MN_MM_USER_MEM_DYNAMIC if necessary so that memory free at the time of activation continues to be free (provided that the memory structure permits this) after the axis has become active.

'If necessary' in the previous sentences means that the adjustment is automatic if the channel/axis could not be activated with the current values of MD18210 \$MN_MM_USER_MEM_DYNAMIC/\$MN_INFO_FREE_MEM_DYNAMIC.

18060	INFO_FREE_MEM_STATIC			N01, N02, N05	S7	
-	Display data of free static memory			DWORD	PowerOn	
-						
-	-	1048576	-	-	1/1	M

Description:

The following applies to powerline control models:

Output of the buffered memory available in the passive file system [bytes].
The data cannot be written.

The preset value states the minimum number of bytes available to the user when the NCK starts up with a cold restart.

The contents of the data state how much battery-backed memory is available for the passive file system at the time of startup.

After a non-buffered startup, the maximum memory available in the file system can be read.

If MDs that affect the requirement for buffered memory (e.g. MM_NUM_GUD_VALUES_MEM, MD38000 \$MA_MM_ENC_COMP_MAX_POINTS) are changed then this changes the amount of memory available for the passive file system, as the amount of memory allocated to the passive file system consists of MD18230 \$MN_MM_USER_MEM_BUFFERED minus all other buffered user data.

(See also the document on MD18350 \$MN_MM_USER_FILE_MEM_MINIMUM)

At the first NCK startup or cold restart of the control (=deletion of user data) MD18230 \$MN_MM_USER_MEM_BUFFERED is set by the NCK software so that at least the default value results for MD18060 \$MN_INFO_FREE_MEM_STATIC.

That is MD18230 \$MN_MM_USER_MEM_BUFFERED is automatically increased if its initial value is too low.

The following applies to solution line control models:

The data reserves the available memory for the data that are not the passive file system.

(MD18350 \$MN_MM_USER_FILE_MEM_MINIMUM[0] dimensions the passive file system.)

Machine data for setting the active file system (tools, GUDs, ...) can be increased until this memory has all been allocated.

18080	MM_TOOL_MANAGEMENT_MASK			N02, N09	K1,W1	
-	Step-by-step memory reservation for tool management (SRAM)			DWORD	PowerOn	
-						
828d-me41	-	0x3F	0	0x3FF	1/0	S
828d-me61	-	0x3F	0	0x3FF	1/0	S
828d-me81	-	0x3F	0	0x3FF	1/0	S
828d-te61	-	0xBF	0	0x3FF	1/0	S
828d-te81	-	0xBF	0	0x3FF	1/0	S
828d-te41	-	0xBF	0	0x3FF	1/0	S

Description:

Activating the TM memory with "0" means:

The set TM data does not take up any memory space, TM is not available.

Bit 0=1: Memory for TM-specific data is provided, the MDs which reserve memory space have to be set accordingly (MD18086 \$MN_MM_NUM_MAGAZINE_LOCATION, MD18084 \$MN_MM_NUM_MAGAZINE)

Bit 1=1: Memory for monitoring data (WZMO) is provided

Bit 2=1: Memory for user data (CC data) is provided

Bit 3=1: Memory to consider adjacent location is provided

Bit 4=1: Memory and function enable for PI service `_N_TSEARC` = "Complex search for tools in magazines" is provided.

Bit 5=1: Wear monitoring active

Bit 6=1: Wear grouping available

Bit 7=1: Reserve memory for adapters for magazine locations

Bit 8=1: Memory for application and/or setup offsets

Bit 9=1: Tools associated with a revolver no longer leave their revolver location on tool change (display).

Bit 10=1: The multitool function is available
(other MDs can be used to modify the configuration).

Bit 10=0: The multitool function is not available
(the functional scope configured with other MDs is ineffective).

This broken down approach to memory reservation means that memory usage can be optimized in line with the functions used.

Example:

Default memory reservation for TM:

MD18080 `$MN_MM_TOOL_MANAGEMENT_MASK` = 3 (bit 0 + 1=1) means that TM and tool monitoring data are provided

MD18080 `$MN_MM_TOOL_MANAGEMENT_MASK` = 1 means tool management without tool monitoring function data

18084	MM_NUM_MAGAZINE			N02, N09	FBW	
-	Number of magazines the NCK can manage (SRAM)			DWORD	PowerOn	
-						
828d-me41	-	3	0	3	1/0	S
828d-me61	-	3	0	3	1/0	S
828d-me81	-	4	0	4	1/0	S
828d-te61	-	3	0	3	1/0	S
828d-te81	-	4	0	4	1/0	S
828d-te41	-	3	0	3	1/0	S

Description: Tool management (TOOLMAN and TMMG) - only when MD TOOLMAN and option TOOLMAN are set:

Number of magazines which the NCK can manage (active and background magazines).

This MD reserves the buffered memory for the magazines.

Important: One loading and one buffer magazine are set up in in the tool management for each TOA unit. These magazines have to be taken into account here.

Value = 0 -The tool management cannot be activated because no data can be created.

Related to:

MD18080 `$MN_MM_TOOL_MANAGEMENT_MASK`

MD20310 `$MC_TOOL_MANAGEMENT_MASK`

18086	MM_NUM_MAGAZINE_LOCATION			N02, N09	FBW	
-	Number of magazine locations the NCK can manage (SRAM)			DWORD	PowerOn	
-						
828d-me41	-	84	0	600	1/0	S
828d-me61	-	132	0	600	1/0	S
828d-me81	-	260	0	600	1/0	S
828d-te61	-	132	0	600	1/0	S
828d-te81	-	260	0	600	1/0	S
828d-te41	-	84	0	600	1/0	S

Description:

TMMG - only when MD TOOLMAN and TOOLMAN option are set:

Number of magazine locations which the NCK can manage.

This machine data reserves the buffered memory for the magazine locations. Important: The number of all buffers and loading points also has to be included in the calculation here.

Value = 0: Tool management cannot be activated because no data can be created.

Related to:

MD18080 \$MN_MM_TOOL_MANAGEMENT_MASK

MD20310 \$MC_TOOL_MANAGEMENT_MASK

18097	MM_TYPE_CC_TOA_PARAM			N02, N09	-	
-	Type of OEM data per cutting edge (SRAM)			DWORD	PowerOn	
-						
-	10	4,4,4,4,4,4,4,4,4,4	1	6	2/2	M

Description:

Work may only be done with the default setting.

Individual types can be assigned to the parameters in this way. The array index n can accept values from 0 to the value of MD18096 \$MN_MM_NUM_CC_TOA_PARAM.

The possible values of the MD = 1, 2, 3, 4 and 6 represent the NC language types

- 1 BOOL,
- 2 CHAR,
- 3 INT,
- 4 REAL and
- 6 AXIS.

The type STRING is explicitly not possible here. The value 5 is treated like value 2).

The type FRAME cannot be defined here.

Example:

MD18096 \$MN_MM_NUM_CC_TOA_PARAM=1

MD18097 \$MN_MM_TYPE_CC_TOA_PARAM=2

"A" can then be programmed for parameter \$TC_DPC1.

Buffered working memory is used. A value change can - but need not - lead to reconfiguration of the buffered memory.

Related to:

MD18096 \$MN_MM_NUM_CC_TOA_PARAM

MD18100 \$MN_MM_NUM_CUTTING_EDGES_IN_TOA

18310	MM_NUM_DIR_IN_FILESYSTEM			N02	S7	
-	Number of directories in passive file system (SRAM)			DWORD	PowerOn	
-						
-	-	120	30	256	1/0	M

Description: This machine data limits the number of directories in the passive file system.

It can be used to reserve memory in the SRAM for the management of the directories. The directories and subdirectories of the passive file system set up by the system are included in this machine data. The memory required for the management of the directories can be calculated as follows:

Memory required = a (440+28 (b+c)) bytes

a = Input value of MD18310 \$MN_MM_NUM_DIR_IN_FILESYSTEM
(no. of directories in passive file system)

b = Input value of MD19300 \$MN_MM_DIR_HASH_TABLE_SIZE
(HASH table size for subdirectories)

c = Input value of MD18290 \$MN_MM_FILE_HASH_TABLE_SIZE
(hash table size for the files of a directory)

Buffered user memory is used.

Special cases:

The battery-backed data are lost if this machine data is altered.

Related to:

MD18270 \$MN_MM_NUM_SUBDIR_PER_DIR
(Number of subdirectories)

18342	MM_CEC_MAX_POINTS			N01, N02	K3	
-	max. number of interpolation points on sag compensation (SRAM)			DWORD	PowerOn	
-						
-	62	200,200,200,200,200, 200,200,200	0	200	1/0	M

Description: The MD defines the memory space available for the compensation tables.

When MD18342 \$MN_MM_CEC_MAX_POINTS = 0, no memory is set up for the table. The sag compensation function cannot then be used.

Caution!

If MD18342 \$MN_MM_CEC_MAX_POINTS[t] is changed, when the system is powered up, the buffered NC user memory is automatically reset. This deletes all user data in the buffered user memory (e.g. drive and HMI machine data, tool off-sets, part programs etc.).

Related to:

SD41300 \$SN_CEC_TABLE_ENABLE[t]
Evaluation of the sag compensation table (t) enabled.

References:

/FB/, S7, "Memory Configuration"

18370	MM_PROTOC_NUM_FILES			N02	D1,OEM	
-	Max.no. of log files in passive file system			DWORD	PowerOn	
-						
-	10	2,0,0,0,0,2,2,2,0,3	0	10	1/1	M

Description: Maximum number of log files in the passive file system.

18371	MM_PROTOC_NUM_ETPD_STD_LIST		N02	D1,OEM		
-	Number of standard data lists ETPD.		DWORD	PowerOn		
-						
-	10	25,0,0,0,0,25,25,25,0, 3	0	25	1/1	M

Description: Number of standard data lists in the OPI module ETPD (user-specific)

18372	MM_PROTOC_NUM_ETPD_OEM_LIST		N02	D1,OEM		
-	Number of OEM data lists ETPD.		DWORD	PowerOn		
-						
-	10	0,0,0,0,0,0,0,0,0	0	20	1/1	M

Description: Number of OEM data lists in the OPI module ETPD (user-specific).

18373	MM_PROTOC_NUM_SERVO_DATA		N02	D1		
-	Number of servo data for log		DWORD	PowerOn		
-						
-	10	0,0,0,0,0,10,10,10,0,0	0	20	1/1	M

Description: Number of servo data which must be recordable at the same time (user-specific).

18374	MM_PROTOC_FILE_BUFFER_SIZE		N02	-		
-	Size of log file buffer		DWORD	PowerOn		
-						
-	10	8000,8000,8000,8000, 8000,8000,8000...	5000	-	1/1	M

Description: Size of the data buffer between the IPO and preprocessing time levels of a log file [Bytes].

18375	MM_PROTOC_SESS_ENAB_USER		N02	-		
-	Users enabled for sessions		BYTE	PowerOn		
-						
-	10	0,0,0,0,0,1,1,1,0,0	0	1	1/1	M

Description: Users that are available for session management.

18391	TRACE_PATHNAME		EXP	-	
-	Path for trace generation		STRING	PowerOn	
NBUP					
-	-	-	-	1/1	M

Description: Path on which traces are saved.
The trace files are used for problem analysis by NCK development.

18392	TRACE_SAVE_OLD_FILE		EXP	-	
-	Old trace files are retained		BOOLEAN	PowerOn	
NBUP					
-	-	FALSE	-	1/1	M

Description: The old traces are no longer overwritten when new traces are created; instead, a version extension is added to the trace file name.
At the current time this function is executed only if files are saved on the host file system (see TRACE_PATHNAME).
The trace files are used for problem analysis by NCK development.

18450	MM_NUM_CP_MODULES			N02, N09	-	
-	Max. number of CP modules			DWORD	PowerOn	
-						
-	-	5	0	48	1/1	M

Description: Number of CP coupling modules available within the NCK
The MD defines the max. permissible number of CP couplings and reserves the required dynamic memory (DRAM).

18452	MM_NUM_CP_MODUL_LEAD			N02, N09	-	
-	Maximum number of CP master values			DWORD	PowerOn	
-						
-	-	4	0	99	1/1	M

Description: Number of NCK-wide available CP master values.
This MD defines the max. permissible number of CP master values and reserves the required dynamic memory (DRAM).

18710	MM_NUM_AN_TIMER			N02	-	
-	Number of global time variable for synchronized actions			DWORD	PowerOn	
-						
-	-	0	0	10000	7/2	M

Description: Number of global time variables for motion-synchronous actions (DRAM)

18730	MM_MAXNUM_ALARM_ACTIONS			N02	-	
-	Length of the alarm action list			DWORD	PowerOn	
-						
-	-	500	100	2000	1/1	M

Description: Maximum number of alarm actions that are retained. This is the length of the alarm action list.

18794	MM_TRACE_VDI_SIGNAL			EXP, N02, N06	-	
-	Trace specification of VDI signals			DWORD	PowerOn	
NBUP						
-	-	0	0	0x7FFFFFFF	1/1	M

Description: The NCK sends and receives PLC VDI signals. The Trace function stores the signals which have changed in each interpolation cycle in an FIFO memory (first in-first out) having a size of MM_MAX_TRACE_POINTS.
The FIFO is written to a file (for the 1st channel: ncsctr01.mpf) when a "trigger event" occurs (e.g. Cancel Alarm key, see MD22704 \$MC_TRACE_STOPTRACE_EVENT and MD22700 \$MC_TRACE_STARTTRACE_EVENT).
The machine data should be interpreted as bit mask. The corresponding VDI signals are recorded depending on which bit is set.
Bits 1.. 6 describe which axial VDI input signals are recorded in the trace (see .. TRACE_DATA_FUNCTION).

18960	POS_DYN_MODE			N01	K1	
-	Type of positioning axis dynamic response			BYTE	Reset	
-						
-	-	0	0	1	7/2	M

Description:

The machine data determines the accelerations and jerks which are applied in the case of positioning axis motion.

Value 0:

The acceleration is taken from the first field entry in \$MA_MAX_AX_ACCEL (value for DYNNORM).

With G75 and active jerk limitation (SOFT), the jerk is taken from the first field entry in \$MA_MAX_AX_JERK (value for DYNNORM); without jerk limitation (BRISK) it is infinite.

The following applies for all other positioning axis movements:

If \$MA_JOG_AND_POS_JERK_ENABLE is true, the jerk is taken from \$MA_JOG_AND_POS_MAX_JERK; otherwise it is infinite (BRISK behavior).

Value 1:

The acceleration is taken from the second field entry in \$MA_MAX_AX_ACCEL (value for DYNPOS).

The jerk is taken from the second field entry in \$MA_MAX_AX_JERK (value for DYNPOS).

For BRISK behavior, enter very high values here.

2.3 Channel-specific machine data

Number	Identifier			Display filters	Reference	
Unit	Name			Data type	Active	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

20050	AXCONF_GEOAX_ASSIGN_TAB			C01, C10	TE7,TE8,M1,R2,K1,K2	
-	Assignment of geometry axis to channel axis			BYTE	PowerOn	
-						
828d-me41	3	1, 2, 3, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0	0	20	2/2	M
828d-me61	3	1, 2, 3, 0, 0, 0, 0, 0, 0, 0, 0, 0	0	20	2/2	M
828d-me81	3	1, 2, 3, 0, 0, 0, 0, 0, 0, 0, 0, 0	0	20	2/2	M
828d-te61	3	1, 0, 2	0	20	2/2	M
828d-te81	3	1, 0, 2	0	20	2/2	M
828d-te41	3	1, 0, 2	0	20	2/2	M

Description: This MD is used to specify which channel axis the geometry axis is assigned to. Each geometry axis must be assigned to a specific channel. If a geometry axis is not assigned to a channel axis, then this geometry axis is not available, and cannot be programmed (with the name defined under MD20060 \$MC_AXCONF_GEOAX_NAME_TAB).

For example: Turning machine without transformation:

MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[0] = 1 ; 1st geometry axis = 1st channel axis

MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[1] = 0 ; 2nd geometry axis not defined

MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[2] = 2 ; 3rd geometry axis = 2nd channel axis

The assignment made here is valid if no transformation is active. With active transformation n, the transformation-specific assignment table MD24...

\$MC_TRAFO_GEOAX_ASSIGN_TAB... becomes active.

20060	AXCONF_GEOAX_NAME_TAB			C01, C11, C10	F2,V2,M1,K2	
-	Geometry axis name in channel			STRING	PowerOn	
-						
-	3	X, Y, Z,X, Y, Z...	-	-	1/1	M

Description:

This MD is used to enter the names of the geometry axes separately for each channel. Geometry axes can be programmed in the part program using the names specified here.

Special cases:

- The geometry axis name entered must not conflict with the designations and assignments of the machine and channel axis names.
- The machine axis names entered must not be the same as the names entered for Euler angles (MD10620 \$MN_EULER_ANGLE_NAME_TAB), names specified for directional vectors (MD10640 \$MN_DIR_VECTOR_NAME_TAB), names given to intermediate point coordinates in the case of CIP (MD10660 \$MN_INTERMEDIATE_POINT_NAME_TAB) or the names of interpolation parameters (MD10650 \$MN_IPO_PARAM_NAME_TAB).
- The geometry axis name entered must not include any of the following reserved address letters:

- D Tool offset (D function)	- E Reserved
- F Feedrate (F function)	- G Preparatory function
- H Auxiliary function (H function)	- L Subroutine call
- M Miscellaneous function (M function)	- N Subblock
- P Subroutine number of passes	- R Arithmetic parameters
- S Spindle speed (S function)	- T Tool (T function)
- The name must not include any keywords (e.g. DEF, SPOS etc.) or pre-defined identifiers (e.g. ASPLINE, SOFT).
- The use of an axis identifier consisting of a valid address letter (A, B, C, I, J, K, Q, U, V, W, X, Y, Z) followed by an optional numerical extension (1-99) gives slightly better block cycle times than a general identifier.
- Identical names may be given to geometry axes assigned to different channels.

Related to:

MD10000 \$MN_AXCONF_MACHAX_NAME_TAB
 (machine axis name [axis no.])
 MD20080 \$MC_AXCONF_CHANAX_NAME_TAB
 (channel axis name in the channel [channel axis no.]

20070	AXCONF_MACHAX_USED			C01, C10	TE3,B3,K5,M1,K1,K2,P3pl,P3sl,S1	
-	Machine axis number valid in channel			BYTE	PowerOn	
-						
828d-me41	20	1, 2, 3, 4, 0	0	31	2/2	M
828d-me61	20	1, 2, 3, 4, 0, 0	0	31	2/2	M
828d-me81	20	1, 2, 3, 4, 0, 0	0	31	2/2	M
828d-te61	20	1, 2, 3, 0, 0, 0	0	31	2/2	M
828d-te81	20	1, 2, 3, 0, 0, 0, 0	0	31	2/2	M
828d-te41	20	1, 2, 3, 0, 0	0	31	2/2	M

Description:

This MD is used to specify the machine axis which the channel axis/special axis is assigned to. Each channel axis has to be assigned to a specific channel. A machine axis that has not been assigned to a channel is inactive, i.e. the axis control is not computed, the axis is not shown on the screen, and it cannot be programmed in any channel.

From software version 5, a machine axis need not be assigned to a channel axis for reasons of uniform configuration. The MD for the machine axis is set to 0 in this case. At the same time, MD11640 \$MN_ENABLE_CHAN_AX_GAP must be set to 1 (channel axis gaps are permitted).

From software version 5, the machine data MD20070 \$MC_AXCONF_MACHAX_USED does not directly refer to the machine axes created with MD10000 \$MN_AXCONF_MACHAX_NAME_TAB, but to the logical machine axis map which is defined with MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB.

MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB refers:

- directly to a local machine axis on the NCU,
- to a machine axis of another NCU in the NCU grouping or
- indirectly to an axis container with local or remote machine axes.

If the default values AX1, AX2, ..., AX31 are entered with MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB, then the NCK behaves in the same way as up to software version 4, this means that machine data MD20070

\$MC_AXCONF_MACHAX_USED refers to the corresponding local machine axis.

Special cases:

- Each geometry axis must be assigned to a channel axis and a machine axis so that it can be programmed.
- If a machine axis is assigned to several channels by means of MD20070 \$MC_AXCONF_MACHAX_USED, then the number of the channel from which the axis is to be programmed must be entered in MD30550 \$MA_AXCONF_ASSIGN_MASTER_CHAN.
- Up to software version 4, the list of entries must not contain any gaps (as from software version 5 - see above). In contrast, the assignment of the machine axes used may contain gaps.

For example:

Permissible:

```
AXCONF_MACHAX_USED [0] = 3; 3rd MA is the 1st axis in the channel
AXCONF_MACHAX_USED [1] = 1; 1st MA is the 2nd axis in the channel
AXCONF_MACHAX_USED [2] = 5; 5th MA is the 3rd axis in the channel
AXCONF_MACHAX_USED [3] = 0
```

Error for software version 4, permissible for version 5:

```
AXCONF_MACHAX_USED [0] = 1; 1st MA is the 1st axis in the channel
AXCONF_MACHAX_USED [1] = 2; 2nd MA is the 2nd axis in the channel
AXCONF_MACHAX_USED [2] = 0; gap in the list ...
```

2.3 Channel-specific machine data

AXCONF_MACHAX_USED [3] = 3; ... of the channel axes
 Axis identifiers must be defined in the corresponding list places of
 AXCONF_CHANAX_NAME_TAB for the axes activated in the channel.

Related to:

- MD30550 \$MA_AXCONF_ASSIGN_MASTER_CHAN
(Initial setting of the channel for axis change)
- MD20080 \$MC_AXCONF_CHANAX_NAME_TAB
(Channel axis name in the channel [channel axis number])
- MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB
- MD11640 \$MN_ENABLE_CHAN_AX_GAP

Reference:

Description of Functions B3.

20080	AXCONF_CHANAX_NAME_TAB			C01, C11, C10	F2,V2,M1,K2,V1
-	Channel axis name in channel			STRING	PowerOn
-					
828d-me41	20	X1, Y1, Z1, SP1, A1	-	-	1/1 M
828d-me61	20	X1, Y1, Z1, SP1, A1, C1	-	-	1/1 M
828d-me81	20	X1, Y1, Z1, SP1, A1, C1	-	-	1/1 M
828d-te61	20	X1, Z1, C1, SP1, Q1, Y1	-	-	1/1 M
828d-te81	20	X1, Z1, C1, SP1, Q1, Y1...	-	-	1/1 M
828d-te41	20	X1, Z1, C1, SP1, Q1	-	-	1/1 M

Description:

This MD is used to set the name of the channel axis/special axis. The first three channel axes are normally occupied by the three assigned geometry axes (see also MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB). The remaining channel axes are also designated as special axes. The channel axis/special axis is always displayed on the screen in the WCS (workpiece coordinate system) with the name set in this MD.

Special cases:

- The specified channel axis name/special axis name must not conflict with the designation and assignment of the machine and geometry axis names.
- The specified channel axis name must not be the same as the names entered for Euler angles (Eulerwinkel (MD10620 \$MN_EULER_ANGLE_NAME_TAB), names specified for directional vectors (MD10640 \$MN_DIR_VECTOR_NAME_TAB), names given to intermediate point coordinates in the case of CIP (MD10660 \$MN_INTERMEDIATE_POINT_NAME_TAB) or the names of interpolation parameters (MD10650 \$MN_IPO_PARAM_NAME_TAB).
- The channel axis name entered must not include any of the following reserved address letters:
 - D Tool offset (D function)
 - E Reserved
 - F Feedrate (F function)
 - G Preparatory function
 - H Auxiliary function (H function)
 - L Subroutine call
 - M Miscellaneous function (M function)
 - N Subblock
 - P Subroutine number of passes
 - R Arithmetic parameters
 - S Spindle speed (S function)
 - T Tool (T function)

- The name must not include any keywords (e.g. DEF, SPOS etc.) or pre-defined identifiers (e.g. ASPLINE, SOFT).
 - The use of an axis identifier consisting of a valid address letter (A, B, C, I, J, K, Q, U, V, W, X, Y, Z) followed by an optional numerical extension (1-99) gives slightly better block cycle times than a general identifier.
 - No special names need be entered in this MD for channel axes to which geometry axes are assigned (normally the first three channel axes).
- Axis identifiers that are not allowed are rejected with an alarm during runup.

20082	AXCONF_CHANAX_DEFAULT_NAME	C01, C11, C10	-			
-	Default axis name for axis variables in the channel	STRING	PowerOn			
-						
-	-	-	-	1/1	M	

Description: Variables or parameters of type Axis which have not been initialized are initialized with a default axis identifier. The identifier can be configured via the machine data MD20082 \$MC_AXCONF_CHANAX_DEFAULT_NAME. If this machine data is set with an empty string, the 1st geometry axis is used, as previously. MD20082 \$MC_AXCONF_CHANAX_DEFAULT_NAME can be set by default with all available, valid axis identifiers. The value of this machine data should generally always correspond to a value of \$MD20060 \$MC_AXCONF_GEOAX_NAME_TAB, MD20080 \$MC_AXCONF_CHANAX_NAME_TAB or MD10000 \$MN_AXCONF_MACHAX_NAME_TAB.

If an invalid axis name is entered as a value or if this name has been changed, for example, in MD20080 \$MC_AXCONF_CHANAX_NAME_TAB but not in MD20082 \$MC_AXCONF_CHANAX_DEFAULT_NAME, then this is indicated with alarm 4041 channel %1 block %2 axis identifier %3 is invalid".

Only valid axis identifiers, empty string and "NO_AXIS" may be entered in MD20082 \$MC_AXCONF_CHANAX_DEFAULT_NAME. "NO_AXIS" is used to indicate a non-initialized axis variable, empty string means previous behavior, i.e. each variable is initialized with the 1st geometry axis.

20090	SPIND_DEF_MASTER_SPIND	C01, C03	H2,K1,K2,P3 pl,P3 sl,S1,W1			
-	Initial setting of master spindle in channel	BYTE	PowerOn			
-						
-	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	20	2/2	M	

Description: Definition of the default setting for the master spindle (in the channel). The number of the spindle is entered.

A number of functions are linked to the master spindle, which are not possible with any other spindle.

Note:

The language command SETMS(n) can declare the spindle number as the master spindle.

The spindle defined in this MD is declared once again as the master spindle with SETMS.

The spindle defined in this MD is also declared as the master spindle at program end and program abort.

20094	SPIND_RIGID_TAPPING_M_NR		C01, C03, C10	H2,K1,S1	
-	M function for switching into controlled axis mode		DWORD	PowerOn	
-					
-	-	70,70,70,70,70,70,70, 70,70,70,70,70,70...	-	-	2/2 M

Description:

This machine data defines the M auxiliary function number with which the spindle is switched into axis mode.

The M number defined in the machine data replaces M70 in Siemens language mode.

Note:

On the VDI interface, M70 is always output with the corresponding address extension to indicate the switch to axis mode.

Restrictions: Refer to machine data MD10715 \$MN_M_NO_FCT_CYCLE

Related to:

MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR

For nibbling:

\$MD26008 \$MC_NIBBLE_PUNCH_CODE

20095	EXTERN_RIGID_TAPPING_M_NR		C01, C11, C03, C10	H2,K1	
-	M function for switching to controlled axis mode(external mode)		DWORD	PowerOn	
-					
-	-	29,29,29,29,29,29,29, 29,29,29,29,29,29...	-	-	2/2 M

Description:

This machine data defines the M function number with which the switchover to controlled spindle/axis mode is to be carried out.

The M number defined in the machine data replaces M29 in external language mode.

Pre-defined M numbers, such as M00,M1,M2,M3, etc., are not allowed as M numbers.

Restrictions: See machine data MD10715 \$MN_M_NO_FCT_CYCLE

Related to:

MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

```
MD10814 $MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 $MN_EXTERN_M_NO_SET_INT
MD10806 $MN_EXTERN_M_NO_DISABLE_INT,
MD10800 $MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 $MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 $MC_EXTERN_RIGID_TAPPING_M_NR
```

For nibbling:

```
MD26008 $MC_NIBBLE_PUNCH_CODE
```

20096	T_M_ADDRESS_EXT_IS_SPINO		C01, C04, C09	H2,W1		
-	Meaning of address extension at T, M tool change		BOOLEAN	PowerOn		
-						
-	-	FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	-	2/2	M

Description: This MD is only significant if the functions 'Tool management'/'flat D numbers' are inactive.

FALSE

The contents of the address extensions of the NC addresses T and M 'tool change command number' are not evaluated by the NCK. The PLC decides on the significance of the programmed extension.

TRUE

The address extensions of the NC addresses T and M 'tool change command number' - 'tool change command number'=TOOL_CHANGE_M_CODE with 6 as the default value - are interpreted as spindle numbers.

NCK treats the extension in the same way as the active functions 'tool management' and 'flat D number management'.

That is, the programmed D number always refers to the T number of the programmed main spindle number.

See also:

```
MD20090 $MC_SPIND_DEF_MASTER_SPIND,
MD22550 $MC_TOOL_CHANGE_MODE,
MD22560 $MC_TOOL_CHANGE_M_CODE
```

20098	DISPLAY_AXIS		EXP, C01	-		
-	Display axis on HMI		DWORD	Immediately		
-						
-	20	0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF...	-	-	1/1	M

Description: Identifies whether the axis is to be displayed by the HMI as a machine, geometry or auxiliary axis.

This data is only evaluated by the HMI.

Bits 0 to 15: Machine

Bit 0= 1 Display machine axis in the actual value windows
0 Hide machine axis in the actual value windows

2.3 Channel-specific machine data

Bit 1= 1 Display machine axis in the reference point windows
 0 Hide machine axis in the reference point windows
 Bit 2=1 Display machine axis in preset/scratch/parameter work offset
 0 Hide machine axis in preset/scratch/parameter work offset
 Bit 3= 1 Display machine axis in the handwheel selection window
 0 Hide machine axis in the handwheel selection window
 Bit 16 to 31: WCS
 Bit 16= 1 Display geometry axis in the actual value windows
 0 Hide geometry axis in the actual value windows
 (Bit 17) Not assigned
 Bit 18= 1 Display geometry axis in parameter work offset
 0 Hide geometry axis in parameter work offset
 Bit 19= 1 Display geometry axis in the handwheel selection window
 0 Hide geometry axis in the handwheel selection window
 Bit 20= 1 Display position axes in the JOG/manual windows
 0 Hide position axes in the JOG/manual windows

20100	DIAMETER_AX_DEF			C01, C10	H1,M5,P1,V1,W1	
-	Geometry axis with transverse axis function			STRING	PowerOn	
-						
828d-me41	-		-	-	1/1	M
828d-me61	-		-	-	1/1	M
828d-me81	-		-	-	1/1	M
828d-te61	-	X	-	-	1/1	M
828d-te81	-	X	-	-	1/1	M
828d-te41	-	X	-	-	1/1	M

Description:

This MD is used to define a geometry axis as a transverse axis. Only one transverse axis can be defined here for each channel.

Further transverse axes for axis-specific diameter programming can be activated via MD30460 \$MA_BASE_FUNCTION_MASK, bit 2.

The axis identifier of an active geometry axis that has been defined in the channel-specific MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[n] or MD24120 \$MC_TRAFO_AX_GEOAX_ASSIGN_TAB_1[n] (from SW 4) and MD20060 \$MC_AXCONF_GEOAX_NAME_TAB[n] must be specified.

If space characters are entered or if an axis identifier is specified for an axis which is not defined as a geometry axis, this leads to the following alarms:

- during runup, to alarm 4032 "Channel %1 wrong identifier for transverse axis in %2", if the "Diameter programming" function (DIAMON) or constant cutting velocity G96/G961/G962 is the switch-on setting.
- when the "Diameter programming (DIAMON)" function is activated, to alarm 16510 "Channel %1 block %2 No transverse axis available for diameter programming", if no axis has been permitted via DIAMCHANA[AX] for channel-specific diameter programming.
- when G96/G961/G962 has been programmed, to alarm 10870 "Channel %1 block %2 No transverse axis defined as reference axis for G96/G961/G962", if no geometry axis has been defined as the reference axis for G96/G961/G962 by the instruction SCC[ax].

Related to:

MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[n]
 (assignment of geometry axis to channel axis)
 MD20060 \$MC_AXCONF_GEOAX_NAME_TAB[n]
 (geometry axis name in the channel)
 MD24120 \$MC_TRAFO_AX_GEOAX_ASSIGN_TAB_1[n]
 (assignment of GEO axis to channel axis for transformation 1)
 MD30460 \$MA_BASE_FUNCTION_MASK
 (Bit2 == 1: Axis-specific diameter programming)

20106	PROG_EVENT_IGN_SINGLEBLOCK		N01	K1,Z1		
-	Prog-Events ignore single block		DWORD	PowerOn		
-						
-	-	0x1F	0	0x3F	1/1	M

Description: Event-driven program calls (Prog-Events) can be set regarding their single-block response.

Bit 0 = 1 :
 Prog-Event after start-of-part-program causes block change without restart

Bit 1 = 1 :
 Prog-Event after end-of-part-program causes block change without restart

Bit 2 = 1 :
 Prog-Event after OP reset causes block change without restart

Bit 3 = 1 :
 Prog-Event after ramp-up causes block change without restart

Bit 4 = 1 :
 Prog-Event after 1st start after search causes block change without restart

Bit 5 = 1 :
 Safety Prog-Event during ramp-up causes block change without restart

20107	PROG_EVENT_IGN_INHIBIT		N01	K1,Z1		
-	Prog-Events ignore read-in disable		DWORD	PowerOn		
-						
-	-	0x0C	0	0x3F	1/1	M

Description: Event-driven programm calls (Prog-Events) can be set regarding their read-in disable response.

Bit 0 = 1 :
 Prog-Event after start-of-part-program causes block change despite read-in disable

Bit 1 = 1 :
 Prog-Event after end-of-part-program causes block change despite read-in disable

Bit 2 = 1 :
 Prog-Event after OP reset causes block change despite read-in disable

Bit 3 = 1 :
 Prog-Event after ramp-up causes block change despite read-in disable

2.3 Channel-specific machine data

Bit 4 = 1 :

Prog-Event after 1st start after search run causes block change despite read-in disable

Bit 5 = 1 :

Safety-Prog-Event during ramp-up causes block change despite read-in disable

20108	PROG_EVENT_MASK		N01, -	TE3,K1		
-	Setting of event-driven programm calls		DWORD	PowerOn		
-						
-	-	0x0,0x0,0x0,0x0,0x0,0	0	0x3F	2/2	M

Description:

Parameterization of the events causing the user program set with MD11620 \$MN_PROG_EVENT_NAME (default: _N_PROG_EVENT_SPF) or the safety program _N_SAFE_SPF to be called implicitly:

Bit 0 = 1 : Start-of-part-program

Bit 1 = 1 : End-of-part-program

Bit 2 = 1 : Operator panel reset

Bit 3 = 1 : Ramp-up

Bit 4 = 1 : Reserved

Bit 5 = 1 : Safety program booting

The user program is called via the following search path:

1. /_N_CUS_DIR/_N_PROG_EVENT_SPF
2. /_N_CMA_DIR/_N_PROG_EVENT_SPF
3. /_N_CST_DIR/_N_PROG_EVENT_SPF

The safety program has to be available in the following location:

1. /_N_CST_DIR/_N_SAFE_SPF

Furthermore, MD11450 \$MN_SEARCH_RUN_MODE bit 1 also causes the user program set with MD11620 \$MN_PROG_EVENT_NAME to be started up automatically after the action blocks, regardless of the settings in the machine data.

20109	PROG_EVENT_MASK_PROPERTIES		N01	K1		
-	Properties of Prog-Events		DWORD	PowerOn		
-						
-	-	0x01	0	0x1	1/1	M

Description:

Parameterization of additional properties of the event-controlled program calls (in short, Prog-Event), that is, the MD20108 \$MC_PROG_EVENT_MASK is further parameterized.

Bit 0 = 1 :

An ASUB started from channel status RESET does not result in a Prog-Event.

20110	RESET_MODE_MASK		C11, C03	F2,K6,M3,TE4,W5,B3,K5,M1, G2,K1,K2,P1,S1,W1,2.4,2.7		
-	Definition of basic control settings after reset/PP end		DWORD	Reset		
-						
-	-	0x14041,0x14041,0x1 4041,0x14041...	0	0x7FFFF	1/1	M

Description:

Definition of the initial setting of the control after ramp-up and at reset/end-of-part-program with regard to the G codes (in particular the active plane and the settable work offset), tool length offset and transformation by setting the following bits:

Bit 0: Reset mode
 Bit 1: Suppress aux. funct. output on tool selection
 Bit 2: Select reset response after power-on (e.g. tool offset)
 Bit 3: Select reset response after end of test mode with regard to active tool offsets
 Bit 4: Reserved
 Bit 5: Reserved
 Bit 6: Reset response "Active tool length offset"
 Bit 7: Reset response "Active kinematic transformation"
 Bit 8: Reset response "Coupled-motion axes"
 Bit 9: Reset response "Tangential correction"
 Bit 10: Reset response "Synchronous spindle"
 Bit 11: Reset response "Revolutional feedrate"
 Bit 12: Reset response "Geo axis replacement"
 Bit 13: Reset response "Master value coupling"
 Bit 14: Reset response "Basic frame"
 Bit 15: Reset response "Electronic gearbox"
 Bit 16: Reset response "Master spindle"
 Bit 17: Reset response "Master toolholder"
 Bit 18: Reset response "Reference axis for G96/G961/G962"
 Bit 19: Reserved "Adjustable software limit switch ineffective"
 Bits 4 to 11, 16, and 17 are only evaluated when bit 0 = 1.

Meaning of each bit:

Bit 0 (LSB) = 0: Corresponds with response of software version 1

Initial setting after ramp-up:

- G codes acc. to \$MC_GCODE_RESET_VALUES
- Tool length offset not active
- Transformation not active
- No coupled-motion axis groupings active
- No tangential correction active
- No axial revolutional feedrate active
- Path revolutional feedrate with master spindle (default)

Initial setting after reset or end-of-part-program:

The current settings are retained.

When next part program is started, the following initial setting is in effect:

- G codes acc. to \$MC_GCODE_RESET_VALUES
- Tool length offset not active
- Transformation not active
- No coupled-motion axis groupings active
- No tangential correction active
- No master value coupling active
- No axial revolutional feedrate active
- Path revolutional feedrate with master spindle (default)

Bit 0 (LSB) = 1:

Initial setting after ramp-up:

- G codes acc. to \$MC_GCODE_RESET_VALUES
- Tool length offset active acc. to \$MC_TOOL_RESET_VALUE, \$MC_CUTTING_EDGE_RESET_VALUE and \$MC_SUMCORR_RESET_VALUE

- Transformation active acc. to \$MC_TRAFO_RESET_VALUE
- Geometry axis replacement acc. to \$MC_GEOAX_CHANGE_RESET
- No coupled-motion axis groupings active
- No tangential correction active

Initial setting after reset or end-of-part-program:

Depending on \$MC_GCODE_RESET_MODE the current settings are retained for the G groups or the initial settings stored in \$MC_GCODE_RESET_VALUES are set.

Initial setting after reset or end-of-part-program:

Depending on \$MC_RESET_MODE_MASK bits 6 to 7,

the current settings are retained or the initial settings stored in the MDs are set for:

- Tool length offset
- Transformation

Depending on bits 8 and 9, the current settings of coupled-motion axes or tangentially corrected axes are either deactivated or retained.

- Synchronous spindle coupling configured:

The coupling is deselected depending on the setting in \$MC_COUPLE_RESET_MODE_1.

- Synchronous spindle coupling not configured:

Depending on bit 10, the coupling is either deactivated or retained.

Depending on bit 14, the basic frame is either retained or deselected.

Bit 1 = 0:

Aux. funct. output (D, T, M) to PLC on tool selection according to MDs \$MC_TOOL_RESET_VALUE, \$MC_CUTTING_EDGE_RESET_VALUE, \$MC_TOOL_PRESEL_RESET_VALUE, and \$MC_TOOL_CHANGE_MODE. If magazine management is active, T, M are generally not output as auxiliary functions. The function uses its own communication to output T, M to the PLC, for example.

Bit 1 = 1:

Suppress aux. funct. output to PLC on tool selection.

If tool management or magazine management is active, T, M are generally not output as auxiliary functions.

Bit 2 = 0:

If tool or magazine management is not active:

- No tool offset active after power-on. Active and programmed T depend on the subsequent settings of the machine data (bits 0, 6).

If tool or magazine management is active:

- Not relevant

Bit 2 = 1:

If tool or magazine management is not active:

- If bits 0 and 6 both = 1 (0x41), the tool offset of the last tool active in the NCK is active after the first reset after power-on.

(The value of the programmed tool depends on the value of machine data \$MC_TOOL_PRESEL_RESET_VALUE.)

Notice: The NCK does not know the conditions at the machine.

If tool or magazine management is active:

- Not relevant

Bit 3 = 0:
 With and without active tool management:
 End of test mode: "Retain current setting for active tool length offset" (bits 0 and 6 set) refers to the program which was active before activation of test mode.

Bit 3 = 1:
 Relevant only if tool management is not active:
 End of test mode: "Retain current setting for active tool length offset" (bits 0 and 6 set) refers to the program which was active at the end of test mode. (If tool management is active, the tool on the spindle is generally the active tool. Exception only for \$MC_CUTTING_EDGE_DEFAULT = -2.)

Bit 4 = 0:Reserved
 Bit 4 = 1:Reserved
 Bit 5 = 0:Reserved
 Bit 5 = 1:Reserved
 Bit 6 = 0:
 Initial setting for active tool length offset after reset/end-of-part-program acc. to \$MC_TOOL_RESET_VALUE, \$MC_CUTTING_EDGE_RESET_VALUE, \$MC_USEKT_RESET_VALUE, and \$MC_SUMCORR_RESET_VALUE.
 If \$MC_TOOL_CHANGE_MODE = 1, the tool specified in \$MC_TOOL_PRESEL_RESET_VALUE is also preselected.
 If tool or magazine management is active, \$MC_TOOL_RESET_NAME is used instead of \$MC_TOOL_RESET_VALUE.

Bit 6 = 1:
 Current setting for active tool length offset is retained after reset/end-of-part-program.
 If tool or magazine management is active, the tool that is currently on the master spindle (generally = master toolholder) is selected.
 If the tool on the master spindle is disabled, the 'disabled' status is ignored.
 Please note that after a program ends or is aborted either the most recent value for master spindle or master toolholder programmed in the program or the value specified with \$MC_SPIND_DEF_MASTER_SPIND or \$MC_TOOL_MANAGEMENT_TOOLHOLDER defines the master spindle or master toolholder.
 (The selection is made using bit 16 or bit 17.)
 For \$MC_CUTTING_EDGE_DEFAULT = -2 the following applies specifically:
 If a tool has been switched to the spindle but a new offset D has not yet been programmed, the previous tool is still active in the NCK.
 If machining is aborted in this status (e.g. with the Reset key), the offset is defined with the smallest D number associated with the master spindle tool.

Bit 7 = 0:
 Initial setting for active transformation after reset/end-of-part-program according to \$MC_TRAFO_RESET_VALUE.

Bit 7 = 1:
 The current setting for active transformation is retained after reset/end-of-part-program.

Bit 8 = 0:
 Coupled-motion axis groupings are ungrouped at reset/end-of-part-program.

- Bit 8 = 1:
Coupled-motion axis groupings remain active after reset/end-of-part-program.
- Bit 9 = 0:
Tangential correction is switched off at reset/end-of-part-program.
- Bit 9 = 1:
Tangential correction remains active after reset/end-of-part-program.
- Bit 10 = 0:
Non-configured synchronous spindle coupling is switched off at reset/end-of-part-program.
- Bit 10 = 1:
Non-configured synchronous spindle coupling remains active after reset/end-of-part-program.
- Bit 11 = 0:
At reset/end-of-part-program the setting data `$$SA_ASSIGN_FEED_PER_REV_SOURCE` is reset to 0 for all non-active axes/spindles, i.e. traversing at revolutional feedrate is canceled and the setting for path and synchronous axes is reset to the master spindle (default).
- Bit 11 = 1:
The current setting for revolutional feedrate is retained after reset/end-of-part-program. At the start of the part program, the setting data `$$SA_ASSIGN_FEED_PER_REV_SOURCE` is reset to 0 for all non-active axes/spindles, i.e. traversing at revolutional feedrate is canceled and the setting for path and synchronous axes is reset to the master spindle (default).
- Bit 12 = 0:
If machine data `$MC_GEOAX_CHANGE_RESET` is set, a changed geometry axis assignment is canceled at reset/end-of-part-program. The initial setting for the geometry axis assignment defined in the machine data becomes active.
- Bit 12 = 1:
A changed geometry axis assignment remains active after reset/end-of-part-program.
- Bit 13 = 0:
Master value couplings are canceled at reset/end-of-part-program.
- Bit 13 = 1:
Master value couplings remain active after reset/end-of-part-program.
- Bit 14 = 0:
The basic frame is deselected.
- Bit 14 = 1:
The current setting of the basic frame is retained.
- Bit 15 = 0:
Active electronic gearboxes remain active at reset/end-of-part-program.
- Bit 15 = 1:
Active electronic gearboxes are canceled at reset/end-of-part-program.
- Bit 16 = 0:
Initial setting for the master spindle according to `$MC_SPIND_DEF_MASTER_SPIND`.
- Bit 16 = 1:
The current setting of the master spindle (SETMS) is retained.
If `$MC_TOOL_MANAGEMENT_TOOLHOLDER = 0`, this bit has also an effect on the response of bit 6.

Bit 17 = 0:

Initial setting for the master toolholder according to
\$MC_TOOL_MANAGEMENT_TOOLHOLDER

Bit 17 = 1:

The current setting of the master toolholder (SETMTH) is retained
(Bit 17 is only relevant if tool or magazine management is active and if
\$MC_TOOL_MANAGEMENT_TOOLHOLDER > 0. Otherwise, the setting for master spin-
dle bit 16 applies if tool or magazine management is active. This bit has
also an effect on the response of bit 6.)

Bit 18 = 0:

Reference axis for G96/G961/G962 according to MD 20100:
\$MC_DIAMETER_AX_DEF.

When using SCC with its own spindle reset, setting bit 18 = 1 is recom-
mended (see also MD 20112: \$MC_START_MODE_MASK, bit 18).

Bit 18 = 1:

Reference axis for G96/G961/G962 is retained.

Bit 19: Reserved!

Bit 19 = 0:

The two adjustable software limit switches are deleted after reset and are
no longer effective.

Bit 19 = 1:

The two adjustable software limit switches remain active after reset.

Corresponds with:

MD20120 \$MC_TOOL_RESET_VALUE
MD20130 \$MC_CUTTING_EDGE_RESET_VALUE
MD20150 \$MC_GCODE_RESET_VALUES
MD20152 \$MC_GCODE_RESET_MODE
MD20140 \$MC_TRAFO_RESET_VALUE
MD20112 \$MC_START_MODE_MASK
MD20121 \$MC_TOOL_PRESEL_RESET_VALUE
MD20118 \$MC_GEOAX_CHANGE_RESET

20112	START_MODE_MASK	C03	K6,M3,K5,M1,K1,K2,P1,S1,W 1
-	Definition of basic setting of control after part program start	DWORD	Reset
-			
-	-	0x400,0x400,0x400,0 x400,0x400,0x400...	0
		0x7FFFF	1/1
			M

Description:

Definition of the initial setting of the control at the start of the part
program with respect to G codes (in particular, active plane and active set-
table work offset), tool length offset, transformation, and axis couplings by
setting the following bits:

Bit 0: Not assigned: MD20112 \$MC_START_MODE_MASK is evaluated every time a
part program starts up

Bit 1: Suppress aux. funct. output on tool selection

Bit 2: Not assigned, but reserved (see corresponding bit in RESET_MODE_MASK)

Bit 3: Not assigned, but reserved (see corresponding bit in RESET_MODE_MASK)

Bit 4: Start response for G code "Current plane"

Bit 5: Start response for G code "Settable work offset"

Bit 6: Start response for "Active tool length offset"

Bit 7: Start response for "Active kinematic transformation"
 Bit 8: Start response for "Coupled-motion axes"
 Bit 9: Start response for "Tangential correction"
 Bit 10: Start response for "Synchronous spindle"
 Bit 11: Not assigned, but reserved (see corresponding bit in RESET_MODE_MASK)
 Bit 12: Start response for "Geo axis replacement"
 Bit 13: Start response for "Master value coupling"
 Bit 14: Not assigned, but reserved (see corresponding bit in RESET_MODE_MASK)
 Bit 15: Not assigned, but reserved (see corresponding bit in RESET_MODE_MASK)
 Bit 16: Start response for "Master spindle"
 Bit 17: Start response for "Master toolholder"
 Bit 18: Start response for "Reference axis for G96/G961/G962"
 Bit 19: Reserved "Adjustable software limit switch ineffective"
 Meaning of individual bits:
 Bit 1 = 0:
 Auxiliary function output (D, T, M, DL) to PLC on tool selection according to the following MDs: \$MC_TOOL_RESET_VALUE, \$MC_CUTTING_EDGE_RESET_VALUE, \$MC_TOOL_PRESEL_RESET_VALUE, and \$MC_TOOL_CHANGE_MODE.
 Note:
 If tool or magazine management is active, only auxiliary functions D and DL are output.
 Bit 1 = 1:
 Suppress auxiliary function output to PLC on tool selection.
 Bit 1 is not relevant if tool or magazine management is active.
 Bit 2 : Reserved (reset response after power-on)
 Bit 3 : Reserved (end of test mode)
 Bit 4 = 0:
 The current setting for G code "current plane" is retained.
 Bit 4 = 1:
 Initial setting for G code "current plane" according to \$MC_GCODE_RESET_VALUES
 Bit 5 = 0:
 The current setting for G code "settable work offset" is retained.
 Bit 5 = 1:
 Initial setting for G code "settable work offset" according to \$MC_GCODE_RESET_VALUES
 Bit 6 = 0:
 The current setting for active tool length offset is retained.
 If tool or magazine management is active, the tool currently on the active toolholder (spindle) is always selected.
 If the tool that is currently on the spindle is disabled, it is automatically replaced by a suitable spare tool.
 If such a spare tool does not exist, an alarm is output.
 Bit 6 = 1:
 Initial setting for active tool length offset according to \$MC_TOOL_RESET_VALUE, \$MC_CUTTING_EDGE_RESET_VALUE, \$MC_USEKT_RESET_VALUE, and \$MC_SUMCORR_RESET_VALUE.
 If \$MC_TOOL_CHANGE_MODE == 1, the tool selected via \$MC_TOOL_PRESEL_RESET_VALUE is preselected in addition.
 If tool or magazine management is active, MD \$MC_TOOL_RESET_NAME is used

instead of `$MC_TOOL_RESET_VALUE`.

Bit 7 = 0:
The current setting for active transformation is retained.

Bit 7 = 1:
Initial setting for active transformation after reset/end-of-part-program according to `$MC_TRAFO_RESET_VALUE`

Bit 8 = 0:
Coupled-motion axis groupings remain active.

Bit 8 = 1:
Coupled-motion axis groupings are ungrouped.

Bit 9 = 0:
Tangential correction remains active.

Bit 9 = 1:
Tangential correction is switched off.

Bit 10 = 0:
Non-configured synchronous spindle coupling remains active.

Bit 10 = 1:
Non-configured synchronous spindle coupling is switched off.

Bit 11 : Reserved (revolutional feedrate)

Bit 12 = 0:
A changed geometry axis assignment remains active when the part program starts up.

Bit 12 = 1:
If machine data `$MC_GEOAX_CHANGE_RESET` is set, a changed geometry axis assignment is deleted when the part program starts up.

Bit 13 = 0:
Master value couplings remain active.

Bit 13 = 1:
Master value couplings are canceled.

Bit 14 : Reserved (basic frame)

Bit 15 = 0:
Active electronic gearboxes remain active.

Bit 15 = 1:
Active electronic gearboxes are canceled.

Bit 16 = 0:
The current setting of the master spindle (SETMS) is retained.

Bit 16 = 1:
Initial setting for the master spindle according to `$MC_SPIND_DEF_MASTER_SPIND`

Bit 17 = 0:
The current setting of the master toolholder (SETMTH) is retained (relevant only if tool or magazine management is active)

Bit 17 = 1:
Only if `$MC_TOOL_MANAGEMENT_TOOLHOLDER > 0`: Initial setting for the master toolholder according to `$MC_TOOL_MANAGEMENT_TOOLHOLDER`.
Otherwise, the setting for the master spindle applies.

2.3 Channel-specific machine data

Bit 18 = 0:

Reference axis for G96/G961/G962 according to MD20100 \$MC_DIAMETER_AX_DEF.
 When using SCC with its own spindle reset, setting bit 18 = 1 is recommended (see also MD 20110: \$MC_RESET_MODE_MASK, bit 18).

Bit 18 = 1:

Reference axis for G96/G961/G962 is retained.

Corresponds with:

- MD20120 \$MC_TOOL_RESET_VALUE
- MD20130 \$MC_CUTTING_EDGE_RESET_VALUE
- MD20150 \$MC_GCODE_RESET_VALUES
- MD20152 \$MC_GCODE_RESET_MODE
- MD20140 \$MC_TRAFO_RESET_VALUE
- MD20110 \$MC_RESET_MODE_MASK
- MD20121 \$MC_TOOL_PRESEL_RESET_VALUE
- MD20118 \$MC_GEOAX_CHANGE_RESET

20114	MODESWITCH_MASK		C03	K1		
-	Interruption MDA by mode change		DWORD	Reset		
-						
-	-	0x0,0x0,0x0,0x0,0x0,0	0	0xFFFF	1/1	M

Description:

After program interruption in MDI mode (e.g. in order to carry out a measurement on the workpiece and to correct the tool wear values or after tool breakage) the tool can be manually withdrawn from the contour by changing into JOG mode.

In this case, the control stores the coordinates of the position of the interruption and indicates the path differences traversed by the axes in JOG mode as "Repos offset". When MDI mode is selected again, the axis is repositioned on the contour. This response can be canceled by means of this machine data.

Bit 0 (LSB) = 0:

When MDI (JOG, JOGREF, JOGREPOS, MDIREF and MDIREPOS) are deselected in stopped status, the system ASUB Repos is selected.

Bit 0 (LSB) = 1:

When MDI (JOG, JOGREF, JOGREPOS, MDIREF and MDIREPOS) are deselected in stopped status, the system ASUB Repos is not selected.

Bit 1 (LSB) = 0:

If the NCK stops at a part program block in the program execution in which repositioning is not possible, alarm 16916 is generated if an attempt is made to switch to manual mode.

Bit 1 (LSB) = 1:

If the NCK stops at a part program block in the program execution in which repositioning is not possible, no alarm is generated if an attempt is made to switch to manual mode.

2.3 Channel-specific machine data

20120	TOOL_RESET_VALUE			C03	K1,W1	
-	Tool with length compens. during runup (reset/part program end).			DWORD	Reset	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	32000	1/1	M

Description: Definition of the tool for which tool length compensation is selected during runup or on reset or part program end as a function of MD20110 \$MC_RESET_MODE_MASK, and on part program start as a function of MD20112 \$MC_START_MODE_MASK
 Related to:
 MD20110 \$MC_RESET_MODE_MASK
 MD20112 \$MC_START_MODE_MASK

20122	TOOL_RESET_NAME			C03	-	
-	Active tool at RESET/START with tool management			STRING	Reset	
-						
-	-		-	-	2/2	M

Description: This MD is used only with active tool management.
 Definition of the tool for which tool length compensation is selected during runup or on reset or part program end as a function of MD20110 \$MC_RESET_MODE_MASK, and on part program start as a function of MD20112 \$MC_START_MODE_MASK.
 Related to:
 MD20110 \$MC_RESET_MODE_MASK,
 MD20112 \$MC_START_MODE_MASK
 MD20124 \$MC_TOOL_MANAGEMENT_TOOLHOLDER
 MD20130 \$MC_CUTTING_EDGE_RESET_VALUE

20123	USEKT_RESET_VALUE			C03	-	
-	Preselected value of \$P_USEKT on RESET			DWORD	Reset	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	0xF	2/2	M

Description: The system variable \$P_USEKT is set with the value of this MD:
 • after run-up:
 As a function of MD20112 \$MC_START_MODE_MASK
 • after RESET or part program end:
 As a function of MD20110 \$MC_RESET_MODE_MASK
 Related to:
 MD20110 \$MC_RESET_MODE_MASK
 MD20112 \$MC_START_MODE_MASK

20124	TOOL_MANAGEMENT_TOOLHOLDER			C03	H2,K1	
-	Tool holder number			DWORD	PowerOn	
-						
-	-	1	0	20	2/2	M

Description:

This MD is only relevant with tool management active.

The TM must know on which tool holder a tool has to be loaded.

The data is only evaluated if the value is greater than zero.

Then, the numbers \$TC_MPP5 are no longer regarded as spindle numbers but as tool holder numbers.

The automatic address extension of T and M=6 is then the value of this machine data, and no longer the value of MD20090 \$MC_SPIND_DEF_MASTER_SPIND. The MD defines the master tool holder number to which a tool preparation or a tool change refers.

Reference is also made to this value for the determination of the tool on the tool holder for the setting 'retain old offset' of MD20110 \$MC_RESET_MODE_MASK.

If a machine has several tool holders but no defined master spindle, then the MD serves as a default value for determining the tool holder on which the tool is to be loaded during a tool change (reset, start, T='identifier', M6).

When defining the magazine locations of internal magazines (see documentation for TM), locations of the type 'SPINDLE' - \$TC_MPP1=2 = spindle location can be given a 'location kind index' (\$TC_MPP5). This assigns the location to a specific tool holder.

The tool holder with the number n can be declared the master tool holder with the language command SETMTH(n). That is, the offsets of a tool, which is loaded in a provisional buffer storage location of the type 'SPINDLE', correct the tool path with the value \$TC_MPP5=n.

Tool changes on 'SPINDLE' locations with \$TC_MPP5 unequal to the number of the master tool holder do not influence the path.

The tool holder defined in the MD is again declared as the master tool holder with SETMTH.

Related to:

MD20110 \$MC_RESET_MODE_MASK,

MD20112 \$MC_START_MODE_MASK

MD20122 \$MC_TOOL_RESET_NAME

MD20130 \$MC_CUTTING_EDGE_RESET_VALUE

References:

Description of Functions: Coordinate Systems (K2)

20125	CUTMOD_ERR	C08	-
-	Error handling for function CUTMOD	DWORD	Immediately
-			
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-

Description:

When function CUTMOD becomes active (through explicit call or tool selection), various error conditions may occur. For any of these error conditions it can be set with this machine data whether the error shall trigger an alarm and, if so, whether such an alarm shall only be displayed (warning) or whether the interpretation of the part program shall be aborted.

Two machine data bits are assigned to each error condition (see also the description of alarm 14162).

Bit Hex. Meaning
Value

```

-----
0  0x1Display error "Invalid cutting direction"
1  0x2Program stop after error "Invalid cutting direction"
2  0x4Display error "Undefined cutting angles"
3  0x8Program stop after error "Undefined cutting angles"
4  0x10Display error "Invalid clearance angle"
5  0x20Program stop after error "Invalid clearance angle"
6  0x40Display error "Invalid holder angle"
7  0x80Program stop after error "Invalid holder angle"
8  0x100Display error "Invalid insert angle"
9  0x200Program stop after error "Invalid insert angle"
10 0x400Error "Invalid combination of cutting edge position and holder
angle"
11 0x800Program stop after error "Invalid combination of cutting edge position
and holder angle"
12 0x1000Display error "Invalid rotation"
13 0x2000Program stop after error "Invalid rotation"

```


20126	TOOL_CARRIER_RESET_VALUE			C03	W1	
-	Active tool holder on RESET			DWORD	Reset	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S

Description: Definition of the tool holder for which tool length compensation is selected during runup or on reset or part program end as a function of MD20110 \$MC_RESET_MODE_MASK and as a function of MD20112 \$MC_START_MODE_MASK on part program start.

This data is valid without tool management.

Related to:

MD20110 \$MC_RESET_MODE_MASK

MD20112 \$MC_START_MODE_MASK

20127	CUTMOD_INIT			C08	K1,W1	
-	Initialize CUTMOD after power ON			DWORD	PowerOn	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	2/2	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	2/2	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	2/2	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	0/0	S
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	0/0	S
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-2	999999999	0/0	S

Description: The value programmable with NC command CUTMOD is initialized automatically on power ON with the value stored in this machine data. If the value of the machine data equals -2, CUTMOD will be set to the value included in MD20126 \$MC_TOOL_CARRIER_VALUE.

20140	TRAFO_RESET_VALUE			C03	F2,TE4,M1	
-	Transformation data block selected during runup (reset/pp end)			BYTE	Reset	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0	0	20	2/2	M

Description: Definition of the transformation data block which is selected during runup and on reset or part program end as a function of MD20110 \$MC_RESET_MODE_MASK, and as a function of MD20112 \$MC_START_MODE_MASK on part program start.

Related to:

MD20110 \$MC_RESET_MODE_MASK

MD20112 \$MC_START_MODE_MASK

20142	TRAFO_RESET_NAME			C03	K1	
-	Transformation during power up (reset/part program end)			STRING	Reset	
-						
-	-		-	-	2/2	M

Description: Specifies the name of a transformation (\$NT_NAME[n]) defined with the aid of kinematic chains, which is selected during power on or on reset/part program end as a function of MD 20110: \$MC_RESET_MODE_MASK and, on part program start, as a function of MD 20112: \$MC_START_MODE_MASK.

If this machine data is not empty, machine data MD20140 \$MC_TRAFO_RESET_VALUE is ignored. This means that MD20142 \$MC_TRAFO_RESET_NAME has priority over MD20140 \$MC_TRAFO_RESET_VALUE.

Not relevant:

MD20110 \$MC_RESET_MODE_MASK, bit 0 = 0

20144	TRAFO_MODE_MASK			C07	M1	
-	Function selection of kinematic transformation			BYTE	Reset	
-						
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x03	2/2	M

Description: The specific functionality of the kinematic transformation is selected by setting the following bits:

Bit 0 = 0:

Default behavior.

Bit 0 = 1:

The transformation as defined in MD20140 \$MC_TRAFO_RESET_VALUE is persistent. That is, it is also selected with TRAFOOF and not shown in the display. This requires that the transformation defined in MD20140 \$MC_TRAFO_RESET_VALUE is selected automatically after RESET and START via MD20110 \$MC_RESET_MODE_MASK and MD20112 \$MC_START_MODE_MASK. This means that:

MD20110 \$MC_RESET_MODE_MASK bit 0 = 1 and bit 7 = 0,

MD20112 \$MC_START_MODE_MASK bit 7 = 1

MD20118 \$MC_GEOAX_CHANGE_RESET = TRUE

Bit 1 = 0:

Default behavior.

Bit 1 = 1:

The last active transformation is selected again after control power on.

MD20110 \$MC_RESET_MODE_MASK Bit 0 = 1 and Bit 7 = 1 also have to be set.

20150	GCODE_RESET_VALUES			C11, C03	F2,TE4,K3,M1,M5,K1,K2,P1, V1
-	Initial setting of G groups			BYTE	Reset
-					
828d-me41	70	2, 0, 0, 3, 0, 1, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M
828d-me61	70	2, 0, 0, 3, 0, 1, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M
828d-me81	70	2, 0, 0, 3, 0, 1, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M
828d-te61	70	2, 0, 0, 1, 0, 2, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M
828d-te81	70	2, 0, 0, 1, 0, 2, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M
828d-te41	70	2, 0, 0, 1, 0, 2, 1, 1, 0, 2, 0, 1, 4, 1...	-	-	2/2 M

Description:

Definition of the G codes which become active on runup and reset or at part program end depending on MD20110 \$MC_RESET_MODE_MASK (up to software version 4) and MD20152 \$MC_GCODE_RESET_MODE (from software version 5) and at part program start depending on MD20112 \$MC_START_MODE_MASK.

The index of the G codes in the respective groups must be programmed as the default value.

For a list of the G groups and their G functions, please refer to References: Programming Manual, Fundamentals

TitleGroupDefault setting on 840D

```

GCODE_RESET_VALUES[0] 12 (G1)
GCODE_RESET_VALUES[1] 20 (inactive)
GCODE_RESET_VALUES[2] 30 (inactive)
GCODE_RESET_VALUES[3] 42 (STARTFIFO)
GCODE_RESET_VALUES[4] 50 (inactive)
GCODE_RESET_VALUES[5] 61 (G17)
GCODE_RESET_VALUES[6] 71 (G40)
GCODE_RESET_VALUES[7] 81 (G500)
GCODE_RESET_VALUES[8] 90 (inactive)
GCODE_RESET_VALUES[9] 101 (G60)
GCODE_RESET_VALUES[10] 110 (inactive)
GCODE_RESET_VALUES[11] 121 (G601)
GCODE_RESET_VALUES[12] 132 (G71)
GCODE_RESET_VALUES[13] 141 (G90)
GCODE_RESET_VALUES[14] 151 (G94)
GCODE_RESET_VALUES[15] 161 (CFC)
GCODE_RESET_VALUES[16] 171 (NORM)
GCODE_RESET_VALUES[17] 181 (G450)
GCODE_RESET_VALUES[18] 191 (BNAT)
GCODE_RESET_VALUES[19] 201 (ENAT)

```

2.3 Channel-specific machine data

GCODE_RESET_VALUES[20]	211	(BRISK)
GCODE_RESET_VALUES[21]	221	(CUT2D)
GCODE_RESET_VALUES[22]	231	(CDOF)
GCODE_RESET_VALUES[23]	241	(FFWOF)
GCODE_RESET_VALUES[24]	251	(ORIWKS)
GCODE_RESET_VALUES[25]	262	(RMI)
GCODE_RESET_VALUES[26]	271	(ORIC)
GCODE_RESET_VALUES[27]	281	(WALIMON)
GCODE_RESET_VALUES[28]	291	(DIAMOF)
GCODE_RESET_VALUES[29]	301	(COMPOF)
GCODE_RESET_VALUES[30]	311	(inactive)
GCODE_RESET_VALUES[31]	321	(inactive)
GCODE_RESET_VALUES[32]	331	(FTOCOF)
GCODE_RESET_VALUES[33]	341	(OSOF)
GCODE_RESET_VALUES[34]	351	(SPOF)
GCODE_RESET_VALUES[35]	361	(PDELAYON)
GCODE_RESET_VALUES[36]	371	(FNORM)
)GCODE_RESET_VALUES[37]	381	(SPIF1)
GCODE_RESET_VALUES[38]	391	(CPRECOF)
GCODE_RESET_VALUES[39]	401	(CUTCONOF)
GCODE_RESET_VALUES[40]	411	(LFOF)
GCODE_RESET_VALUES[41]	421	(TCOABS)
GCODE_RESET_VALUES[42]	431	(G140)
GCODE_RESET_VALUES[43]	441	(G340)
GCODE_RESET_VALUES[44]	451	(SPATH)
GCODE_RESET_VALUES[45]	461	(LFTXT)
GCODE_RESET_VALUES[46]	471	(G290 SINUMERIK mode)
GCODE_RESET_VALUES[47]	483	(G462)
GCODE_RESET_VALUES[48]	491	(CP)
GCODE_RESET_VALUES[49]	501	(ORIEULER)
GCODE_RESET_VALUES[50]	511	(ORIVECT)
GCODE_RESET_VALUES[51]	521	(PAROTOF)
GCODE_RESET_VALUES[52]	531	(TOROTOF)
GCODE_RESET_VALUES[53]	541	(ORIROTA)
GCODE_RESET_VALUES[54]	551	(RTLION)
GCODE_RESET_VALUES[55]	561	(TOWSTD)
GCODE_RESET_VALUES[56]	571	(FENDNORM)
GCODE_RESET_VALUES[57]	581	(RELIEVEON)
GCODE_RESET_VALUES[58]	591	(DYNNORM)
GCODE_RESET_VALUES[59]	601	(WALCS0)
GCODE_RESET_VALUES[60]	611	(ORISOF)
:	::	
GCODE_RESET_VALUES[69]	701	(not defined)

20152	GCODE_RESET_MODE			C03	M1,K1,K2,P1	
-	Reset response of G groups			BYTE	Reset	
-						
828d-me41	70	0, 0, 0, 0, 0, 1, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M
828d-me61	70	0, 0, 0, 0, 0, 1, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M
828d-me81	70	0, 0, 0, 0, 0, 1, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M
828d-te61	70	0, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M
828d-te81	70	0, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M
828d-te41	70	0, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0...	0	1	2/2	M

Description:

This MD is only evaluated if bit 0 is set in MD20110 \$MC_RESET_MODE_MASK. For each entry in MD20150 \$MC_GCODE_RESET_VALUES (that is for each G group), this MD is used to determine whether, on reset/part program end, the setting in MD20150 \$MC_GCODE_RESET_VALUES is used again (MD = 0) or the current setting is retained (MD = 1).

Example:

Here, the basic setting for the 6th G group (current plane) is read from MD20150 \$MC_GCODE_RESET_VALUES at each reset / part program end:
`$MC_GCODE_RESET_VALUES[5]=1 ; reset value of the 6th G group is M17`
`$MC_GCODE_RESET_MODE[5]=0 ; basic setting for 6th G group corresponds, after ;reset / part program end ;to MD20150 $MC_GCODE_RESET_VALUES[5]`
 However, if the current setting for the 6th G group (current plane) is to be retained after reset / part program end, then the following setting results:
`$MC_GCODE_RESET_VALUES[5]=1 ; reset value of the 6th G group is M17`
`$MC_GCODE_RESET_MODE[5]=1 ; current setting for 6th G group ;is retained even after reset / part program end.`

Related to:

MD20110 \$MC_RESET_MODE_MASK
 MD20112 \$MC_START_MODE_MASK

20154	EXTERN_GCODE_RESET_VALUES			C11, C03	-	
-	Initial setting of G groups in ISO mode			BYTE	Reset	
-						
-	31	1, 1, 1, 2, 1, 1, 1, 3, 4, 1, 1, 2, 2, 1, 3, 2, 1, 0, 1, 1, 1...	-	-	2/2	M

Description: When an external NC programming language is used, the G codes which become active on runup and reset or at part program end are defined as a function of MD20110 \$MC_RESET_MODE_MASK and at part program start as a function of MD20112 \$MC_START_MODE_MASK.

The following external programming languages are possible:

ISO2 dialect Milling

ISO3 dialect Turning

The G group division that is to be used is stated in the current SINUMERIK documentation.

The following groups within MD20154 \$MC_EXTERN_GCODE_RESET_VALUES can be written:

ISO2 dialect M:

G group 2: G17/G18/G19

G group 3: G90/G91

G group 5: G94/G95

G group 6: G20/G21

G group 13: G96/G97

G group 14: G54-G59

ISO3 dialect T:

G group 2: G96/G97

G group 3: G90/G91

G group 5: G94/G95

G group 6: G20/G21

G group 16: G17/G18/G19

20156	EXTERN_GCODE_RESET_MODE			C03	-	
-	Reset response of external G groups			BYTE	Reset	
-						
-	31	0, 0...	0	1	2/2	M

Description: This MD is evaluated only if bit0 is set in MD20110 \$MC_RESET_MODE_MASK (see there).

For each entry in MD20154 \$MC_EXTERN_GCODE_RESET_VALUES (that is for each G group), this MD is used to determine whether, on reset/part program end, the setting in MD20154 \$MC_EXTERN_GCODE_RESET_VALUES is used again (MD = 0) or the current setting is retained (MD = 1).

Example for ISO dialect M:

Here, the basic setting for the 14th G group (settable zero offset) is read from MD20154 \$MC_EXTERN_GCODE_RESET_VALUES at each reset / part program end: MD20154 \$MC_EXTERN_GCODE_RESET_VALUES[13]=1 ; the reset value for the 14th G group

;is G54

```

MD20156 $MC_EXTERN_GCODE_RESET_MODE[13]=0 ; the basic setting for the 14th G
group

                                ;after reset / part program end
is defined by

                                ;MD20154
$MC_EXTERN_GCODE_RESET_VALUES[13]

                                ;
However, if the current setting for the 14th G group is to be retained beyond
reset / part program end, this results in the following setting:
MD20154 $MC_EXTERN_GCODE_RESET_VALUES[13]=1 ;reset value for the 14th G group
                                ;is G54
MD20156 $MC_EXTERN_GCODE_RESET_MODE[13]=1 ;current setting for the 14th
                                ;G group is retained even after
                                ;reset / part program end

```

20160	CUBIC_SPLINE_BLOCKS		EXP, C09	-		
-	Number of blocks for C spline		BYTE	PowerOn		
-						
-	-	8,8,8,8,8,8,8,8,8,8,8,8,8,8,8,8,8,8	4	9	1/1	M

Description: Number of motion blocks across which a spline section is calculated with the cubic spline (CSPLINE) function.

The larger the value, the closer the generated contour is to the ideal mathematical cubic spline, which in the boundary condition CUBIC_SPLINE_BLOCKS = reaches infinity.

However, the higher the value, the longer the block search calculation time.

References:

/PA/, Programming Guide: Fundamentals

20170	COMPRESS_BLOCK_PATH_LIMIT		C09	B1		
mm	Maximum traversing distance of an NC block with compression		DOUBLE	NEW CONF		
-						
-	-	20.0,20.0,20.0,20.0,20.0,20.0,20.0,20.0,20.0,20.0...	-	-	2/2	M

Description: The machine data defines the maximum traversing length of a block that can be compressed. Longer blocks interrupt the compression and are traversed in the normal way.

Related to:

MD33100 \$MA_COMPRESS_POS_TOL (maximum deviation with compression)

References:

/PA/, Programming Guide: Fundamentals

2.3 Channel-specific machine data

20172	COMPRESS_VELO_TOL			C09	B1,V1	
mm/min	Max. permissible deviation of path feedrate with compression			DOUBLE	PowerOn	
-						
828d-me41	-	1000.0	-	-	1/1	M
828d-me61	-	1000.0	-	-	1/1	M
828d-me81	-	1000.0	-	-	1/1	M
828d-te61	-	60000.0,60000.0,60000.0,60000.0...	-	-	0/0	S
828d-te81	-	60000.0,60000.0,60000.0,60000.0...	-	-	0/0	S
828d-te41	-	60000.0,60000.0,60000.0,60000.0...	-	-	0/0	S

Description: The value indicates the maximum permissible deviation for the compression for the path feedrate. The larger the value, the more short blocks can be compressed into one long block. The maximum number of compressible blocks is limited by the size of the spline buffer.

In this way, the the compressors COMPON and COMPCURV may limit the compression of the path axes.

Compressor COMPCAD acts differently: It ignores changes to the F word as long as they lie below the threshold defined by COMPRESS_VELO_TOL. If the feed programmed in a block changes more than COMPRESS_VELO_TOL, COMPCAD interrupts the compression at this block transition so that the feed change takes place at exactly the desired position.

Related to:

- MD33100 \$MA_COMPRESS_POS_TOL[AXn]
- MD20170 \$MC_COMPRESS_BLOCK_PATH_LIMIT

References:

/PGA/, Programming Guide, Advanced

20180	TOCARR_ROT_ANGLE_INCR			C08	W1	
-	Rotary axis increment of orientable tool holder			DOUBLE	NEW CONF	
-						
828d-me41	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	3/3	U
828d-me61	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	3/3	U
828d-me81	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	3/3	U
828d-te61	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	0/0	S
828d-te81	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	0/0	S
828d-te41	2	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	0/0	S

Description: For orientable tool carriers, this machine data defines the size of the minimum increment (in degrees) by which the first or second orientation axis can be changed (e.g. for Hirth tooth systems).

A programmed or calculated angle is rounded to the nearest value resulting from

$$\phi = s + n * d$$

with integer n.

In which:

s = MD20180 \$MC_TOCARR_ROT_ANGLE_INCR[i]

d = MD20182 \$MC_TOCARR_ROT_ANGLE_OFFSET[i]

and i is 0 for the 1st and 1 for the 2nd axis.

There is no rounding if this machine data is equal to zero.

20182	TOCARR_ROT_ANGLE_OFFSET			C08	-	
-	Rotary axis offset of orientable tool holder			DOUBLE	NEW CONF	
-						
828d-me41	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	3/3	U
828d-me61	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	3/3	U
828d-me81	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	3/3	U
828d-te61	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	0/0	S
828d-te81	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	0/0	S
828d-te41	2	0.0, 0.0,0.0, 0.0,0.0, 0.0,0.0, 0.0...	-	-	0/0	S

Description: This machine data defines the offset of the rotary axis for an orientable tool holder if its position cannot be continuously changed.
It is only evaluated if MD20180 \$MC_TOCARR_ROT_ANGLE_INCR is not equal to zero.
For the precise meaning of this machine data, see the description of MD20180 \$MC_TOCARR_ROT_ANGLE_INCR.

20184	TOCARR_BASE_FRAME_NUMBER			C08	K2,W1	
-	Base frame number for holding machine table offset			DWORD	NEW CONF	
-						
828d-me41	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	3/3	U
828d-me61	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	3/3	U
828d-me81	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	3/3	U
828d-te61	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	0/0	S
828d-te81	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	0/0	S
828d-te41	-	-1,-1,-1,-1,-1,-1,-1,-1, 1,-1,-1,-1,-1...	-1	15	0/0	S

Description: This machine data indicates into which channel-specific base frame the table offset of an orientable tool holder with a rotary table is written.
This machine data must refer to a valid base frame.
If its content is less than 0 or greater than or equal to the maximum number of base frames set in MD28081 \$MC_MM_NUM_BASE_FRAMES, selection of a corresponding tool holder causes an alarm.

20188	TOCARR_FINE_LIM_LIN			C07	W1	
mm	Limit of linear fine offset TCARR			DOUBLE	Immediately	
-						
828d-me41	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-me61	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-me81	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-te61	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S
828d-te81	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S
828d-te41	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S

Description: Indicates for each channel the input limit for the linear fine offset values of an orientable tool holder.

20190	TOCARR_FINE_LIM_ROT			C07	W1	
degrees	Limit of rotary fine offset TCARR			DOUBLE	Immediately	
-						
828d-me41	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-me61	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-me81	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	3/3	U
828d-te61	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S
828d-te81	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S
828d-te41	-	1,0,1,0,1,0,1,0,1,0,1,0, 1,0,1,0,1,0...	-	-	0/0	S

Description: Indicates for each channel the input limit for the rotary fine offset values of an orientable tool holder.

20191	IGN_PROG_STATE_ASUP			EXP	K1	
-	Do not display interrupt program execution on OPI			DWORD	NEW CONF	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0, 0,0,0,0	-	-	2/2	M

Description: If the ASUB is started, OPI variables progStatus and chanStatus do not change, i.e. the HMI does not see this normally short program execution.

Bit 0 is assigned to interrupt channel 1.

Bit 1 is assigned to interrupt channel 2, etc.

Korrespondiert mit:

MD20192 \$MC_PROG_EVENT_IGN_PROG_STATE

20192	PROG_EVENT_IGN_PROG_STATE	EXP	-
-	Do not display the Prog-Event on OPI	DWORD	PowerOn
-			
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0
-	-		0x3F
-	-		2/2
-	-		M

Description: Event-driven program calls (Prog-Events) can be set regarding their response on the OPI.

The progStatus and chanStatus variables remain unaffected despite Prog-Event processing being active and retain the old value. This provides a means of concealing Prog-Event processing from the HMI.

Bit 0 = 1 :
Reserved bit, ineffective

Bit 1 = 1 :
Prog-Event after end-of-part-program does not change progStatus and chanStatus

Bit 2 = 1 :
Prog-Event after OP reset does not change progStatus and chanStatus

Bit 3 = 1 :
Prog-Event after ramp-up does not change progStatus and chanStatus

Bit 4 = 1 :
Reserved

Bit 5 = 1 :
Safety-Prog-Event during ramp-up does not change progStatus and chanStatus

20193	PROG_EVENT_IGN_STOP	EXP	-
-	Prog-Events ignore the stop key	DWORD	PowerOn
-			
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0
-	-		0xF
-	-		2/2
-	-		M

Description: Event-controlled program calls (Prog-Events) can be influenced with regard to their behavior after pressing of the stop key.

The Stop, StopAll and StopAtEnd key of the PLC is ignored, if required.

Bit 0 = 1 :
Prog-Event after part program start delays the stop until the part program starts, i.e. the stop only becomes active in the part program, not before its start. If the part program starts with a traversing block, it is possible that it starts briefly, i.e. a short motion occurs, although Stop has already been pressed in the Start-Prog-Event.

Bit 1 = 1 :
Prog-Event after part program end ignores the stop

Bit 2 = 1 :
Prog-Event after operator panel reset ignores the stop

Bit 3 = 1 :
Prog-Event after power up ignores the stop

20196	TOCARR_ROTAX_MODE			C07	W1	
-	ToolCarrier: rotary axis setting with axis positions not defined			DWORD	Immediately	
-						
828d-me41	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	3/3	U
828d-me61	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	3/3	U
828d-me81	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	3/3	U
828d-te61	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	0/0	S
828d-te81	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	0/0	S
828d-te41	-	2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2	0	3	0/0	S

Description:

The MD is bit-coded. Bit 0 applies to orientable tool holders with one axis, bit 1 for those with 2 axes.

When the axis positions of an orientable tool holder are determined from a specified frame, it might happen that the required orientation is achieved at any position of a rotary axis.

This MD specifies how the rotary axis position is defined in these cases:

If the relevant bit is 0, the position of the rotary axis will be 0; a possibly necessary rotation is performed through the specified frame.

If the relevant bit is 1, the rotation is performed by means of the rotary axis of the orientable tool holder. The resulting frame will no longer include a rotation.

Example:

A tool in its basic position points into the Z direction, and an axis of the orientable tool holder rotates the workpiece around Z (C_Axis). If the tool shall be oriented in parallel with the Z axis of a rotating frame, and if the frame only rotates around the Z axis, the tool orientation will not be changed, if the C axis is rotated. The condition saying that the tool is to point in the direction of the Z axis defined by the frame is therefore fulfilled for any position of the Z axis.

20200	CHFRND_MAXNUM_DUMMY_BLOCKS			EXP, C02, C06, C09	V1	
-	Empty blocks with chamfer/radii			BYTE	PowerOn	
-						
-	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	15	2/2	M

Description:

Indicates the maximum number of blocks without traversing information in the compensation plane (dummy blocks) that can be programmed between two blocks with traversing information when chamfer/rounding are active.

20201	CHFRND_MODE_MASK			C09	V1	
-	Chamfer/rounding behavior			DWORD	Reset	
-						
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0xFFFF	2/2	M

Description: Determination of the chamfer/rounding behavior

Bit 0: (LSB) Assignment of the chamfer/rounding to the preceding or following block.

This influences:

- The technology of the chamfer/rounding (feed, type of feed, M commands ...)
- The execution of the blocks without movement in the active plane (e.g. M commands, movement in the applicate) before or after a modal rounding (RNDM)

Bit 1: free

Meaning of the individual bits:

Bit 0 = 0

Chamfer/rounding is derived from the following block (default value). The technology of the chamfer/rounding is determined by the following block. Blocks without movement (M commands) or movement only in the applicate between two movement blocks in the plane are executed before the modal rounding.

Bit 0 = 1:

Chamfer/rounding is derived from the preceding block. The technology of the chamfer/rounding is determined by the preceding block. Blocks without movement (M commands) or movement only in the applicate between two movement blocks in the plane are executed after the modal rounding.

20202	WAB_MAXNUM_DUMMY_BLOCKS			C02, C06	W1	
-	maximum number of blocks w/o traversing movement with SAR			BYTE	Reset	
-						
-	-	10	0	10	7/2	M

Description: Maximum number of blocks which can appear between the SAR (soft approach and retraction) block and the traversing block which determines the direction of the approach or retraction tangent.

2.3 Channel-specific machine data

20204	WAB_CLEARANCE_TOLERANCE	C06	W1
mm	Change of direction with SAR	DOUBLE	PowerOn
-			
-	-	0.01,0.01,0.01,0.01,0.01,0.01,0.01,0.01...	2/2 M

Description: In the case of smooth approach and retraction, the point defined with DISCL, from which, in the case of infeed from the initial plane, traversing is carried out at lower speed (G341) or the point in which the actual approach movement begins (G 340), must lie between the initial plane and the approach plane.

If this point lies outside this interval and the deviation is less than or equal to this machine data, it is assumed that the point lies in the approach or retraction plane.

If the deviation is greater, then alarm 10741 is output.

Example:

An approach is made from position Z = 20. The SAR plane is at Z = 0. The point defined by DISCL must therefore lie between these two values. If it lies between 20.000 and 20.010 or between 0 and -0.010, it is assumed that the value 20.0 or 0.0 was programmed (under the condition that the MD has the value 0.010). The alarm is output if the position is greater than 20.010 or less than -0.010.

20210	CUTCOM_CORNER_LIMIT	C08, C06	W1
degrees	Maximum angle f. compensation blocks in tool radius compensation	DOUBLE	Reset
-			
-	-	100.,100.,100.,100.,10 0.0 0.,100.,100....	150. 2/2 M

Description: Where outer corners are very pointed, G451 can result in long idle paths. The system therefore switches automatically from G451 (intersection) to G450 (transition circle, with DISC where appropriate) when the outer corners are very pointed. The contour angle which can be traversed following this automatic switchover (intersection ---> transition circle) can be defined in CUTCOM_CORNER_LIMIT.

20220	CUTCOM_MAX_DISC	C08, C06	W1
-	Maximum value for DISC	DOUBLE	Reset
-			
-	-	50.0,50.0,50.0,50.0,50 0.0 .0,50.0,50.0...	75.0 2/2 M

Description: The G450 transition circle cannot produce sharp outer contour corners, because the path of the tool center point through the transition circle is controlled so that the cutting edge stops at the outer corner (programmed position).

Where sharp outer corners are to be machined with G450, the DISC instruction can be used in the program to program an overshoot. This transforms the transition circle into a conic section and the cutting edge lifts off from the outer corner.

The value range of the DISC instruction extends from 0 to theoretically 100 in steps of 1.

DISC = 0 ...Overshoot disabled, transition circle active

DISC = 100 ...Overshoot large enough to theoretically produce a response similar to intersection (G451).

Programmed values of DISC which are higher than those stored in CUTCOM_MAX_DISC are limited to this maximum value without output of a message. A severely non-linear alteration in the path speed can thus be avoided. Special cases:

It is not generally meaningful to enter values higher than 50 in DISC.

It is therefore not possible to enter values > 75.

20230	CUTCOM_CURVE_INSERT_LIMIT		C08, C06	W1	
-	Maximum angle for calculation of intersection with TRC		DOUBLE	Reset	
-					
-	-	10.,10.,10.,10.,10.,10., 10.,10.,10....	0.0	150.	2/2 M

Description: Where outer corners are very flat, G450 (transition circle) and G451 (intersection) approximate each other more and more. In such a case, it is no longer useful to insert a transition circle. Especially with 5-axis machining, it is not allowed to insert a transition circle at these outer corners, as this might lead to losses in velocity during continuous-path mode (G64). That is why the system switches automatically from G450 (transition circle, possibly with DISC) to G451 (intersection) in the case of very flat outer corners. The contour angle (in degrees), as of which the automatic switchover (transition circle ---> intersection) is to be carried out, can be specified in CUTCOM_CURVE_INSERT_LIMIT.

20240	CUTCOM_MAXNUM_CHECK_BLOCKS		C08, C02	W1	
-	Blocks for look-ahead contour calculation with TRC		DWORD	PowerOn	
-					
-	-	4,4,4,4,4,4,4,4,4,4, 4,4,4,4	2	10000	7/2 M

Description: Indicates the maximum number of blocks with traversing information at the offset plane that are considered simultaneously for collision detection with active radius compensation.

20250	CUTCOM_MAXNUM_DUMMY_BLOCKS		C08, C02	W1	
-	maximum number of blocks without traversing motion in TRC		DWORD	PowerOn	
-					
-	-	5	0	1000	7/2 M

Description: During active TRC only program blocks with movements of geometry axes perpendicular to the current tool orientation are normally programmed. Nevertheless, individual intermediate blocks that do not contain such path information may also be programmed during active TRC. For example:

- Movements in the direction of tool orientation
- Movements in axes that are not geometry axes
- Auxiliary functions
- In general: Blocks that are taken over into the main run and executed there

2.3 Channel-specific machine data

The maximum number of intermediate blocks is defined with this MD. If the value is exceeded, alarm 10762 "Too many empty blocks between 2 traversing blocks during active tool radius compensation" is output.

Note:

Comment blocks, arithmetic blocks and empty blocks are not intermediate blocks in the sense of this MD and can therefore be programmed in any number (without an alarm being triggered).

20256	CUTCOM_INTERS_POLY_ENABLE		C09	W1	
-	Intersection procedure for polynomials is possible		BOOLEAN	PowerOn	
-					
-	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	2/2 M

Description:

If this machine data is TRUE and tool radius compensation active, the transitions at outer corners where polynomes (splines) are involved can be treated with the intersection mode. If the machine data is FALSE, conic sections (circles) are always inserted in this case.
 If the machine data is FALSE, the response is identical to that of software releases older than 4.0.

20270	CUTTING_EDGE_DEFAULT		C11, C03	H2,W1	
-	Initial position of tool cutting edge without programming		DWORD	PowerOn	
-					
-	-	1,1,1,1,1,1,1,1,1,1, 1,1,1,1	-2	32000	1/1 M

Description:

Default cutting edge after tool change
 If no cutting edge has been programmed after a tool change, the default cutting edge number set in MD20270 \$MC_CUTTING_EDGE_DEFAULT is used.
 Value
 := 0
 Initially, no cutting edge is active after a tool change.
 The cutting edge is not selected until D programming.
 := 1
 MD_SLMAXCUTTINGEDGENUMBER
 No. of cutting edge (MD_SLMAXCUTTINGEDGENUMBER=9 is valid up to P4)
 := -1
 Cutting edge number of old tool also applies to new tool.
 := -2
 Cutting edge (correction) of old tool remains active until D is programmed. This means that the old tool remains the active tool until D is programmed. In other words, the tool on the spindle remains the programmed tool until D is programmed.
 Example:
 MD20270 \$MC_CUTTING_EDGE_DEFAULT = 1;
 After a tool change, the first cutting edge is active if no other cutting edge has been programmed.

20272	SUMCORR_DEFAULT		C03	H2,W1		
-	Initial position resulting offset without program		DWORD	PowerOn		
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-1	6	2/2	M

Description: The number of the total offset of the cutting edge which becomes active when a new cutting edge compensation is activated without a programmed DL value being available.

MD18110 \$MN_MM_MAX_SUMCORR_PER_CUTTEDGE

defines the maximum useful value which can be entered.

Value Meaning

> 0 Number of the total offset

= 0 No total offset active with D programming

= 1 The total offset number for the previously programmed D is used.

Related to:

MD20270 \$MC_CUTTING_EDGE_DEFAULT.

20280	LIMIT_CHECK_MODE		EXP	-		
-	Type of limit position check		DWORD	Reset		
-						
-	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	1	1/1	M

Description: This MD can be used to set the mode of operation for the software limit position check.

The following options are available:

0: The limit positions are checked in real time on active transformation

1: The limit positions are checked in a preparative manner on active transformation

20310	TOOL_MANAGEMENT_MASK		C09	P3 pl,P3 sl		
-	Activation of tool management functions		DWORD	PowerOn		
-						
828d-me41	-	0x180400F,0x180400F,0x180400F...	0	0xFFFFFFFF	1/1	M
828d-me61	-	0x180400F,0x180400F,0x180400F...	0	0xFFFFFFFF	1/1	M
828d-me81	-	0x180400F,0x180400F,0x180400F...	0	0xFFFFFFFF	1/1	M
828d-te61	-	0x181400F,0x181400F,0x181400F...	0	0xFFFFFFFF	1/1	M
828d-te81	-	0x181400F,0x181400F,0x181400F...	0	0xFFFFFFFF	1/1	M
828d-te41	-	0x181400F,0x181400F,0x181400F...	0	0xFFFFFFFF	1/1	M

Description: MD = 0: Tool management inactive

Bit 0 to bit4

Bit 0=1: Tool management active

Tool management functions are enabled for the current channel.

Bit 1=1: Tool monitoring function active

The functions for monitoring the tools (tool life and quantity) are enabled.

Bit 2=1: OEM functions active

The memory for user data can be used (see also MD18090 \$MN_MM_NUM_CC_MAGAZINE_PARAM to MD18098 \$MN_MM_NUM_CC_MON_PARAM)

Bit 3=1: Consider adjacent location active

Bit 0 to bit 3 must be set as in MD18080 \$MN_MM_TOOL_MANAGEMENT_MASK.

Bit 4=1: The PLC has the option of requesting a T preparation again with changed parameters.

The acknowledgment states "2", "7" und "103" are enabled with this bit. The tool selection is then recalculated in the NCK.

Bit 5 to bit 8

Bit 5 and bit 7 refer to the main spindle

Bit 6 und bit 8 refer to secondary spindles

Bit 5 = 1: The command is regarded as output when the internal transport acknowledgment + the transport acknowledgment are present, that is, when the command has been accepted by the basic PLC program.

(Bit 19=1 also allows the block change to be prevented (main run) until the required acknowledgments have been received.)

Bit 7 = 1: The output of the command is not regarded as being completed until the end acknowledgment has been received from the PLC. That is, the command has been acknowledged by the PLC user program with status "1".

(Bit 19=1 also allows the block change to be prevented (main run) until the required acknowledgments have been received.)

Bit 5 and bit 7 (alternatively bit 6 and bit 8) are mutually exclusive.

Only the following combinations are permissible:

Bit 5: ...0...1...0

Bit 7: ...0...0...1

With the default setting, that is bits 5 to 8 = 0, synchronisation takes place in the block in which a cutting edge is selected for the first time. Setting these bits delays the block processing.

Bit 9 to bit 11

Bit 9: Reserved for test purposes

It can also be used by machine manufacturers during the test phase, provided that the PLC program does not yet control the tool change.

Bit 10=1: M06 is delayed until the preparation has been accepted by the PLC user program.

The change command is not output until the preparation acknowledgment has been received. That can be, for example, status "1" or "105".

Bit 10=0: The change command is output without delay, directly after the preparation command.

Bit 11=1: The tool preparation command (PLC command numbers=2, 4, 5) is also executed if the same tool preparation command has already been executed. (Commands 4, 5 contain the tool preparation)

Example: (Tool changed with M6 (PLC command no.= 3):

T="Tool1"; tool preparation

M6; tool change

T="Tool2" ; 1st tool preparation after M6 (for same tool holder)

; is always output to PLC.

T="Tool2"; 2nd tool preparation is only output as a command to the PLC if bit 11 = 1.

; This tool preparation counts as the first if the state of the tool has changed since the previous tool preparation such that it would no longer be

serviceable.

That might be, for example, an asynchronous unloading of the tool. This tool preparation then attempts to select a replacement tool.

Bit 11=0: The preparation command can only be output once for any one tool.

Bit 12 to bit 14

Bit 12=1: The preparation command (PLC command numbers = 2, 4, 5) is also executed when the tool is already in the spindle/tool holder.

T="Tool1" ; tool preparation

M6; tool change

T="Tool1"; tool is already in the tool holder

; 1st tool preparation after M6 (for the same tool holder)

; is only output to the PLC if bit 12 = 1.

; An unserviceable tool (e.g. disabled because of tool monitoring.) on the tool holder does not count as being on the tool holder. This tool preparation then attempts to select a replacement tool.

T="Tool2" ; 2nd tool preparation - the rules of bit 11 apply to the output.

Bit 12=0: The preparation command is not executed if the tool is already in the spindle.

Bit 13=1: On reset, the commands are retrieved from the diagnostics buffer and stored in the passive file system (TCTRAxx.MPF under part program) This file is required by the Hotline.

The tool sequences are only recorded in the the diagnostics buffers of systems that have adequate memory (NCU572, NCU573)).

Bit 14=1: Reset mode

Tool and offset selection correspond to the settings in MD20110

\$MC_RESET_MODE_MASK and MD20112 \$MC_START_MODE_MASK.

Bit 14=0: No reset mode

Bit 15 to bit 19

Bit 15=1: No return transport of the tool if there are multiple preparation commands (Tx->Tx).

Bit 15=0: Return transport of the tool from any defined buffers.

Bit 16=1: T = location number is active

Bit 16=0: T="Tool name"

Bit 17=1: Tool life decrementation can be started and stopped via the PLC in channel DB 2.1...DBx 1.3.

Bit 18=1: Activation of monitoring of "Last tool in the tool group"

Bit 18 Lengthens the search for a suitable tool, above all, when there are a large number of disabled replacement tools.

Bit 18=0: No monitoring of "Last tool in the tool group"

Bit 19=1: The synchronizations determined by bits 5...8 refer to the main run block. This means that the block change is delayed until the required acknowledgments have been received.

Bit 19, in conjunction with set bits 5, 6, 7, 8, delays block processing.

Bit 19=0: The synchronizations determined by bits 5...8 refer to the tool command output. This means that the block change is not delayed.

Bit 20 to bit 24

Bit 20=0: If the PLC signal "Program test active" is present, then the commands generated are not output to the PLC. The NCK acknowledges the commands itself. The magazine and tool data are not changed.

2.3 Channel-specific machine data

Bit 20=1: If the PLC signal "Program test active" is present, then the commands generated are output to the PLC. Depending upon the type of acknowledgment, tool/magazine data can be changed in the NCK. If the acknowledgment parameters for the "target magazine" are given the values of the "source magazine", then there is no tool transport, and thus also no data change in the NCK.

Bit 21=0: Default setting: Ignore the tool state "W" during tool selection.

Bit 21=1: Tools in the state "W" cannot be selected by another tool change/ tool preparation command.

Bit 22=1: Function "Tool subgroups"

\$TC_TP11[x] is the grouping or selection parameter

Bit 23=0: Default setting

The tool management selects the tool optimally and safely in the main run. This means that the interpreter may have to wait until the end of the tool selection for the offset selection.

Bit 23=1: For simple applications

The interpreter selects the tool itself. This means synchronization with the main run is not required for the offset selection. (However, an uncorrectable alarm may be issued if a tool becomes unserviceable after selection but before loading.)

Bit 24=0: Default setting

If the PLC commands 8 and 9 (asynchronous transfer) want to move a tool to a location reserved for another tool, then this is rejected with an alarm.

Bit 24=1: If the PLC commands 8 and 9 want to move a tool to a location reserved for another tool with "Reserved for tool from buffer" (bit value="H4"), then this is possible. This location reservation is removed before execution of the motion ("Reserved for new tool to be loaded" (bit value="H8") remains effective).

Related to:

MD18080 \$MN_MM_TOOL_MANAGEMENT_MASK

MD20320 \$MC_TOOL_TIME_MONITOR_MASK

MD20122 \$MC_TOOL_RESET_NAME

MD20110 \$MC_RESET_MODE_MASK

MD20124 \$MC_TOOL_MANAGEMENT_TOOLHOLDER

MD22560 \$MC_TOOL_CHANGE_M_CODE

20320	TOOL_TIME_MONITOR_MASK	C06, C09	-
-	Time monitoring for tool in tool holder	DWORD	PowerOn
-			
-	-	0x1	-
			1/1 M

Description: Activation of the tool time monitoring for the tool holders and spindles 1..x.

As soon as the path axes have been traversed (not with G00, always with G63), the tool time monitoring data of the active D compensation are updated for the tool in the selected tool holder, which is also the master tool holder.

Bit 0...x-1: Monitoring of the tool in tool holder 1...x

20360	TOOL_PARAMETER_DEF_MASK		C09	M5,P1,W1		
-	Definition of tool parameters		DWORD	PowerOn		
-						
828d-me41	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x7FFFF	1/1	M
828d-me61	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x7FFFF	1/1	M
828d-me81	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x7FFFF	1/1	M
828d-te61	-	0x283	0	0x7FFFF	1/1	M
828d-te81	-	0x283	0	0x7FFFF	1/1	M
828d-te41	-	0x283	0	0x7FFFF	1/1	M

Description:

Definition of the effects of tool parameters.

Bit no. Meaning when bit is set

-

Bit 0: (LSB):

For turning and grinding tools, the wear parameter of the transverse axis is included in the calculator as a diameter value.

Bit 1:

For turning and grinding tools, the tool length component of the transverse axis is included in the calculator as a diameter value.

Bit 2:

If a wear component or a length component is included in the calculator as a diameter value, the tool may only be used in the plane that was active when the tool was selected. If this bit is set, a plane change leads to an alarm.

Bit 3:

Work offsets in frames in the transverse axis are included in the calculator as a diameter value.

Bit 4:

PRESET value is included in the calculator as a diameter value

Bit 5:

Include the external work offset in the transverse axis in the calculator as a diameter value

Bit 6:

Read actual values of the transverse axis as diameter values (AA_IW, AA_IEN, AA_IBN, AA_IB. Notice! Not AA_IM.)

Bit 7:

Display all actual values of the transverse axis as diameter values, irrespective of the G code of group 29 (DIAMON / DIAMOF)

Bit 8:

Always display the distance-to-go as a radius in the work (WCS)

Bit 9:

During DRF handwheel travel of a transverse axis, only half the distance of the specified increment is traveled (on condition that MD11346 \$MN_HANDWH_TRUE_DISTANCE = 1).

Bit10:

Activate the tool component of an active, orientable tool carrier even if no tool is active.

Bit11:

The tool parameter \$TC_DP6 is not interpreted as a tool radius but as a tool diameter.

Bit12:

The tool parameter \$TC_DP15 is not interpreted as wear of the tool radius but as wear of the tool diameter.

Bit13:

During JOG of circles, the circle center coordinate is always a radius value, see D42690 \$SC_JOG_CIRCLE_CENTRE.

Bit14:

Absolute values of the transverse axis with cycle masks in the radius

Bit15:

Incremental values of the transverse axis with cycle masks as diameter

Bit16:

For GWPS (GWPSON/TMON), the tool parameters tool length, wear and base dimension are interpreted as diameter values

Bit17:

With cutting edge position compensation (CUTMOD) for turning and grinding tools, the cutting plane for calculating the compensation values is rotated into the machining plane. If this bit is not set, the cutting edge is projected into the machining plane instead.

Bit18:

With cutting edge position compensation (CUTMOD) for turning and grinding tools, always use the active plane (G17 - G19). If this bit is not set, the plane specified by setting data \$SC_TOOL_LENGTH_CONST has priority over the plane specified by the G code group 6 (plane selection, G17 - G19).

20370	SHAPED_TOOL_TYPE_NO		C01, C08	-		
-	Tool type number for contour tools		DWORD	Immediately		
-						
-	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	2/2	M

Description:

Indicates for each channel max. two number ranges for tool types that are treated as forming tools. Therefore individual ranges are possible both for grinding and for turning tools.

The first range is specified by the first and the second number, the second range by the third and fourth number.

If the first number is not smaller than the second one (the same applies for the third and fourth number), no range will be defined, but two individual numbers will be specified instead.

The numbers 400 through 599 are permissible (tool type numbers for turning and grinding tools), and also value 0 (no tool type number defined).

Examples:

- 400 405 590 596 : Tool types 400-405 and 590-596 are contour tools
- 410 400 590 596 : tool types 400, 410 and 590-596 are contour tools
- 450 0 420 430 : Tool types 450 and 420-430 are contour tools

20372	SHAPED_TOOL_CHECKSUM			C01, C08	-	
-	Checksum test for contour tools			BOOLEAN	Immediately	
-		FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	-	2/2	U

Description: Indicates for each channel whether for completion of the contour tool definition an edge must be available that includes the negative sums of tool length components and tool radius of the previous edges.

20380	TOOL_CORR_MODE_G43G44			C01, C08, C11	-	
-	Treatment of tool length compensation with G43 / G44			BYTE	Reset	
-		0,0	0	2	2/2	M

Description: This machine data determines in ISO dialect M (G43 / G44) the way in which length compensations programmed with H are processed.

0: Mode A

Tool length H always acts on the third geometry axis (usually Z)

1: Mode B

Tool length H acts, depending on the active plane, on one of the three geometry axes. This means with

G17 on the 3rd geometry axis (usually Z)

G18 on the 2nd geometry axis (usually Y)

G19 on the 1st geometry axis (usually X)

In this mode, compensations in all three geometry axes can be configured through multiple programming, i.e. through the activation of one component, the length compensation possibly active in another axis is not deleted.

2: Mode C

The tool length acts, independent of the active plane, on the axis that has simultaneously been programmed with H. Otherwise, the response is the same as with mode B.

20382	TOOL_CORR_MOVE_MODE			C01, C08	-	
-	Traversing of tool length compensation			BOOLEAN	Reset	
-		FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	-	2/2	M

Description: This machine data determines how the tool length compensations are traversed.

0: A tool length compensation is only traversed if the associated axis has been programmed (behavior as in previous software versions)

1: Tool lengths are always traversed independently of whether the associated axes are programmed or not.

2.3 Channel-specific machine data

20384	TOOL_CORR_MULTIPLE_AXES		C01, C08, C11	-		
-	Tool length compensation in several axes simultaneously		BOOLEAN	Reset		
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M

Description: This machine data determines for tool length compensation in ISO dialect M (ISO2) (G43 / G44), whether the compensation shall be allowed in mode C (selection of the axis on which the compensation is acting by specifying the corresponding axis letter) to act on several axes simultaneously.
If this machine data is 1, this type of programming is allowed; otherwise it is rejected with an alarm.

20390	TOOL_TEMP_COMP_ON		C01, C08	K3,W1		
-	Activation of temperature compensation for tool length		BOOLEAN	Reset		
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M

Description: This machine data activates the temperature compensation in tool direction (see also SD42960 \$SC_TOOL_TEMP_COMP)

20392	TOOL_TEMP_COMP_LIMIT		C01, C08	W1		
mm	Max. temperature compensation for tool length		DOUBLE	Reset		
-	3	1.0, 1.0, 1.0, 1.0, 1.0, 1.0...	-	-	2/2	U

Description: With temperature compensation, this machine data indicates the maximum permissible value for the tool length for each geometry axis.
If a temperature compensation value larger than this limit value is entered, it will be limited without an alarm.

20400	LOOKAH_USE_VELO_NEXT_BLOCK		EXP, C05	B1		
-	LookAhead following block velocity		BOOLEAN	PowerOn		
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	2/2	M

Description: For SW-internal function optimization.

20430	LOOKAH_NUM_OVR_POINTS		EXP, C02, C05	B1		
-	Number of override characteristics for LookAhead		DWORD	PowerOn		
-	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	2/2	M

Description: For SW-internal function optimization.

20440	LOOKAH_OVR_POINTS			EXP, C05	B1	
-	Override switch points for Look Ahead			DOUBLE	PowerOn	
-						
-	2	1.0, 0.2, 1.0, 0.2, 1.0, 0.2, 1.0, 0.2...	0.2	2.0	2/2	M

Description: For SW-internal function optimization.

20443	LOOKAH_FFORM			EXP, C05	-	
-	Activate extended LookAhead			BYTE	NEW CONF	
-						
828d-me41	5	0, 0, 0, 0, 0, 0, 0, 0, 0...	0	2	2/2	M
828d-me61	5	0, 0, 1, 1, 1	0	2	2/2	M
828d-me81	5	0, 0, 1, 1, 1	0	2	2/2	M
828d-te61	5	0, 0, 0, 0, 0, 0, 0, 0, 0...	0	2	0/0	S
828d-te81	5	0, 0, 0, 0, 0, 0, 0, 0, 0...	0	2	0/0	S
828d-te41	5	0, 0, 0, 0, 0, 0, 0, 0, 0...	0	2	0/0	S

Description: The MD specifies for which technology groups the extended LookAhead is active.
Value 0: Default LookAhead
Value 1: Extended LookAhead
Value 2: Extended LookAhead
E.g. MD20443 \$MC_LOOKAH_FFORM[4]=1; i.e. activation for DYNFINISH.
Entry for all dynamic G code groups.
When changing between default LookAhead and extended LookAhead or vice versa, the continuous-path mode is interrupted by an interpolatory stop.

20450	LOOKAH_RELIEVE_BLOCK_CYCLE			EXP, C05	B1	
-	Relief factor for block cycle time			DOUBLE	PowerOn	
-						
-	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	2/2	M

Description: Block cycle problems occur for the following reason:
The traversing length of the NC blocks to be processed is so short that the Look Ahead function must reduce the machine velocity to provide enough time for block preparation. In this situation, constant deceleration and acceleration of the path motion can occur.
This machine data defines the extent to which such velocity fluctuations are to be smoothed.
Special cases:
Values up to approx. 1.0 are appropriate.
The value 0.0 means that the function is deactivated.

20470	CPREC_WITH_FFW			EXP, C06, C05	K6	
-	Programmable contour accuracy			BYTE	PowerOn	
-						
828d-me41	-	1	0	3	0/0	S
828d-me61	-	1	0	3	0/0	S
828d-me81	-	1	0	3	0/0	S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	3	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	3	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	3	1/1	M

Description: This machine data defines the behavior of the programmable function CPRECON.

0: The CPRECON function is inactive when feedforward control is activated simultaneously.

1: CPRECON is also active with feedforward control.

2: As 1, but the function is parameterized with \$MA_EQUIV_CPREC_TIME.

3: As 2, but any contour accuracy programmed with CTOL has priority over \$SC_CONTPREC.

The values 0 and 1 are no longer recommended. They only provide compatibility with older software versions.

Related to:

\$SC_CONTPREC, \$SC_MINFEED, \$MA_EQUIV_CPREC_TIME

20480	SMOOTHING_MODE			EXP	B1	
-	Behavior of smoothing with G64x			DWORD	NEW CONF	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	15744	2/2	U

Description:

Configuration of smoothing with G641 and G642 or G643.

The MD is decimal-coded. The units digits define the behavior with G643, and the tens digits the behavior with G642. The hundreds digit can define whether, with G641 or G642, the axes might be accelerated within the smoothing range or traversed at constant velocity. The thousands and ten-thousands digits are used to configure smoothing with G644.

x0: G643 uses axis-specific tolerances; these are set with the axis-specific MD33100 \$MA_COMPRESS_POS_TOL.

x1: G643 uses the contour tolerance SD42465 \$SC_SMOOTH_CONTUR_TOL for smoothing the geometry axes. The axis-specific tolerances in MD33100 \$MA_COMPRESS_POS_TOL are used for smoothing all other axes.

x2: The angular tolerance SD42466 \$SC_SMOOTH_ORI_TOL is used for smoothing the orientation movement. The axis-specific tolerances in MD33100 \$MA_COMPRESS_POS_TOL are used for all other axes.

x3: Combination of the two options 01 and 02. This means that G643 uses the tolerances SD42465 \$SC_SMOOTH_CONTUR_TOL and SD42466 \$SC_SMOOTH_ORI_TOL. All other axes are smoothed with an axis-specific tolerance.

x4: G643 uses the smoothing length programmed with ADIS= or ADISPOS=. The specification of possible axis-specific tolerances or contour and orientation tolerances is ignored.

0x: G642 uses axis-specific tolerances; these are set with the axis-specific MD33100 \$MA_COMPRESS_POS_TOL.

1x: G642 uses the contour tolerance for smoothing the geometry axes. The axis-specific tolerances in MD33100 \$MA_COMPRESS_POS_TOL are used for smoothing all other axes.

2x: The orientation movement with G642 is smoothed using the angular tolerance SD42466 \$SC_SMOOTH_ORI_TOL. The axis-specific tolerances in MD33100 \$MA_COMPRESS_POS_TOL are used for smoothing all other axes.

3x: Combination of both options 10 and 20. This means that G642 uses the tolerances SD42465 \$SC_SMOOTH_CONTUR_TOL und SD42466 \$SC_SMOOTH_ORI_TOL. All other axes are smoothed with an axis-specific tolerance.

x4: G642 uses the smoothing length programmed with ADIS= or ADISPOS=. The specification of possible axis-specific tolerances or contour and orientation tolerances is ignored.

Possible values of the hundreds digit (specification of path velocity for smoothing):

0xx: A profile of the limit velocity is calculated within the smoothing range from the specified maximum values for acceleration and jerk of the axes or path involved. This can lead to an increase in

path velocity in the smoothing range and consequently to an acceleration of the axes involved.

1xx: A profile of the limit velocity is not calculated for smoothing blocks with G641. Only a constant limit velocity is specified. In the case of smoothing with G641/G642 this prevents the axes involved accelerating in the smoothing range. However, this setting may lead to smoothing blocks being traversed at a velocity that is too low, especially in the case of long smoothing ranges.

2xx: No velocity profile for G642 and G645 (see the above scenario for description)

4xx: The "effective" path velocity in a smoothing block will remain constant if possible as long as the dynamic response of the axes permits this. Differing from the default setting, with this setting, the smoothing blocks are also interpolated as a path.

Possible values for the thousands digit (configuration of G644):

0xxx:

When smoothing with G644, the maximum deviations of each axis specified in MD COMPRESS_POS_TOL are adhered to. If the dynamic response of the axis allows, the specified tolerance might not be fully utilized.

1xxx:

When smoothing with G644, the smoothing distance is specified.

2xxx:

When smoothing with G644, the maximum frequency at which the smoothing movement of each axis occurs is limited. The maximum frequency is specified in MD32440 \$MA_LOOKAH_FREQUENCY.

3xxx:

When smoothing with G644, neither the tolerance nor the smoothing distance is monitored. Each axis traverses around a corner with the maximum possible dynamic response. With SOFT, both the maximum acceleration and the maximum jerk of each axis are observed. With BRISK, the jerk is not limited; instead each axis traverses with the maximum possible acceleration.

4xxx:

When smoothing with G644, the maximum deviations of each axis specified in MD COMPRESS_POS_TOL are adhered to. In contrast to the value 0xxx, the specified tolerance is fully utilized where possible. The axis then does not reach its maximum possible dynamic response.

5xxx:

When smoothing with G644, the smoothing distance is specified (ADIS or ADISPOS). In contrast to the value 1xxx, the specified smoothing distance is also fully utilized if possible. The axes involved then might not reach their maximum dynamic response.

Possible values for the ten-thousands digit (configuration of G644):

0xxxx:

The velocity profiles of the axes in the smoothing range are defined without jerk limitation when BRISK is active, and with jerk limitation when SOFT is active.

1xxxx:

The velocity profiles of the axes in the smoothing range are always defined with jerk limitation no matter whether BRISK or SOFT is active.

The values of the units, tens, hundreds and thousands digits are added.

Related to:

MD33100 \$MA_COMPRESS_POS_TOL,
SD42465 \$SC_SMOOTH_CONTUR_TOL,
SD42466 \$SC_SMOOTH_ORI_TOL

2.3 Channel-specific machine data

20482	COMPRESSOR_MODE			EXP	F2	
-	Mode of compressor			DWORD	NEW CONF	
-						
828d-me41	-	300	0	333	1/1	M
828d-me61	-	300	0	333	1/1	M
828d-me81	-	300	0	333	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	333	0/0	S
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	333	0/0	S
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	333	0/0	S

Description: This MD is used to set the compressor operating mode.
The units digits, the tens digits, and the hundreds digits have different meanings.
The following options are available:
Units digits:
0: With the compressor, the tolerances specified with MD33100 \$MA_COMPRESS_POS_TOL are met for all axes (geometry and orientation axes).
1: With the compressor, the contour tolerances specified with SD42475 \$SC_COMPRESS_CONTUR_TOL become active for the geometry axes.
For the orientation axes, the axis-specific tolerances MD33100 \$MA_COMPRESS_POS_TOL become active.
2: With the compressor, the axis-specific tolerances MD33100 \$MA_COMPRESS_POS_TOL become active for the geometry axes. The orientation movement is compressed in compliance with the maximum angular deviations specified with SD42476 \$SC_COMPRESS_ORI_TOL and SD42477 \$SC_COMPRESS_ORI_ROT_TOL.
3: With the compressor, the contour tolerance SD42475 \$SC_COMPRESS_CONTUR_TOL becomes active for the geometry axes and the maximum angular deviation SD42476 \$SC_COMPRESS_ORI_TOL or SD42477 \$SC_COMPRESS_ORI_ROT_TOL becomes active for the orientation axes.
Tens digits:
The tens digits of this MD can be used to set a compressor response that is compatible with previous software releases (< SW 6.3).
0x: All blocks with orientations and value assignments are compressed.
This is the default setting.
Notice: This response is incompatible with previous software releases!
1x: Blocks with value assignments are not compressed (e.g. X=100 ..., etc.)
2x: Blocks with a programmed tool orientation are not compressed (e.g. A3= B3= C3=).
3x: All blocks with value assignments and/or programmed tool orientation are not compressed. With this setting, the response is fully compatible with previous software releases (< 6.3).
Hundreds digits:
The hundreds digit can be used to set which blocks in addition to G01 blocks are to be compressed or not:
0xx: Circular blocks and G00 blocks are not compressed. Is compatible with previous releases.
1xx: Circular blocks are linearized and compressed by COMPCAD.
2xx: G00 blocks are compressed; a different tolerance may be applied here

(see MD 20560 \$MC_G0_TOLERANCE_FACTOR).

3xx: Combination of the two previous options: Both circular blocks and G00 blocks are compressed.

20485	COMPRESS_SMOOTH_FACTOR			EXP, C05	B1	
-	Smoothing by compressor			DOUBLE	NEW CONF	
-						
-	5	0., 0., 0., 0., 0., 0., 0., 0., 0., 0....	0.	1.	7/2	M

Description: Smoothing of the programmed block end points with compressor type COMPCAD. Value 0: no smoothing. Value 1: maximum smoothing. Entry for all dynamic G code groups.

20487	COMPRESS_SMOOTH_FACTOR_2			EXP, C05	B1	
-	Smoothing by compressor			DOUBLE	NEW CONF	
-						
-	5	0., 0., 0., 0., 0., 0., 0., 0., 0., 0....	0.	1.	7/2	M

Description: Extent to which the programmed block end points are smoothed in the case of compressor type COMPCAD for non-geometry axes. Value 0: No smoothing. Value 1: Maximum smoothing. Entry for each dynamic G code group.

20488	SPLINE_MODE			EXP	B1	
-	Setting for spline interpolation			BYTE	NEW CONF	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	7	3/3	M

Description: This MD is used to determine the settings for spline interpolation. The allocation of the spline segments to the NC blocks can thus be influenced. With spline interpolation, the spline blocks are combined, if possible, in such a way, that there are no blocks that are too short and could lead to a reduction in the possible path velocity.
Bit 0: With BSPLINE, blocks that are too short are avoided.
Bit 1: With BSPLINE/ORICURVE, blocks that are too short are avoided.
Bit 2: With CSPLINE, blocks that are too short are avoided.

2.3 Channel-specific machine data

20490	IGNORE_OVL_FACTOR_FOR_ADIS			EXP	B1	
-	G641/G642 independent of overload factor			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE	-	-	1/1	M
828d-me61	-	TRUE	-	-	1/1	M
828d-me81	-	TRUE	-	-	1/1	M
828d-te61	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	1/1	M
828d-te81	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	1/1	M
828d-te41	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	1/1	M

Description: A block transition is normally only smoothed with G641 and G642 when the path velocity at block transition is reduced by the overload factor set in MD32310 \$MA_MAX_ACCEL_OVL_FACTOR. When SOFT is active, the maximum jerk occurring at block transitions is also limited by MD32432 \$MA_PATH_TRANS_JERK_LIM. This means that the effect of smoothing with G641 and G642 depends on the values set for the overload factor and possibly for the maximum jerk.

By setting MD20490 \$MC_IGNORE_OVL_FACTOR_FOR_ADIS = TRUE a block transition can be smoothed with G641 and G642, irrespectively of the values set for the overload factor.

20500	CONST_VELO_MIN_TIME			EXP, C05	B2	
s	Minimum time with constant velocity			DOUBLE	PowerOn	
-						
-	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	0.0	0.1	2/2	M

Description: Defines the minimum time for constant velocity during transition from acceleration to deceleration in short blocks in which the set velocity cannot be reached. Entering a time of at least several IPO cycles prevents a direct transition from the acceleration to the deceleration phase and thus reduces the acceleration jump to half. This acceleration limitation is only active with the acceleration profile BRISK.

MD irrelevant for:
 Look Ahead does not take account of this function.

20550	EXACT_POS_MODE	EXP	B1			
-	Exact stop conditions on G00/G01.	BYTE	NEW CONF			
-						
-	-	3,3,3,3,3,3,3,3,3	0	33	1/1	M

Description: Configuration of the exact stop conditions for G00 and other G codes of the 1st G code group.

The MD is decimal-coded. The units digits define the behavior at G00 (infeed motion) and the tens digits the behavior of all the other G codes of the 1st group ("machining G codes").

x0: At G00, the relevant programmed exact stop conditions become active.

x1: At G00, G601 (fine positioning window) becomes active independent of the programmed exact stop condition.

x2: At G00, G602 (coarse positioning window) becomes active independent of the programmed exact stop condition.

x3: At G00, G603 (setpoint value reached) becomes active independent of the programmed exact stop condition.

0x: At the machining G codes, the relevant programmed exact stop conditions become active.

1x: At the machining G codes, G601 (fine positioning window) becomes active independent of the programmed exact stop condition.

2x: At the machining G codes, G602 (coarse positioning window) becomes active independent of the programmed exact stop condition.

3x: At the machining G codes, G603 (setpoint value reached) becomes active independent of the programmed exact stop condition.

The values of the units digits and tens digits are added.

For example, the value of EXACT_POS_MODE = 2 means that the exact stop condition G602 is always activated automatically at G00, independently of which exact stop condition was programmed. At all other G codes of group 1, the programmed exact stop condition becomes active.

20552	EXACT_POS_MODE_G0_TO_G1	EXP	B1			
-	Exact stop condition at G00-G01 transition	BYTE	NEW CONF			
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	5	2/2	M

Description: Configuration of a stop at transition from G00 to a different G code of the 1st G code group, and also vice versa, at transition from non-G00 to G00 in continuous-path mode.

In exact-stop mode, the positioning window programmed or set in MD20550 \$MC_EXACT_POS_MODE is used.

The following applies:

0: No additional stop, no control of exact stop

1: Behavior active as with G601 (positioning window, fine).

2: Behavior active as with G602 (positioning window, coarse).

3: Behavior active as with G603 (setpoint reached).

2.3 Channel-specific machine data

- 4: As 0,
in addition, the override of the subsequent non-G00 block is taken into account in the G00 block via LookAhead in the case of a change from G00 to non-G00.
- 5: As 0,
in addition, the override of the subsequent block is taken into account via LookAhead in the case of a change from G00 to non-G00 and non-G00 to G00.

20560	G0_TOLERANCE_FACTOR			EXP	B1	
-	Tolerance factor for G00			DOUBLE	NEW CONF	
-						
828d-me41	-	3.0	1.e-9	-	1/1	M
828d-me61	-	3.0	1.e-9	-	1/1	M
828d-me81	-	3.0	1.e-9	-	1/1	M
828d-te61	-	1.0,1.0,1.0,1.0,1.0,1.0, 1.0,1.0,1.0...	1.e-9	-	1/1	M
828d-te81	-	1.0,1.0,1.0,1.0,1.0,1.0, 1.0,1.0,1.0...	1.e-9	-	1/1	M
828d-te41	-	1.0,1.0,1.0,1.0,1.0,1.0, 1.0,1.0,1.0...	1.e-9	-	1/1	M

Description: Tolerance factor for G00.
 This factor is used to make different settings for the tolerances for processing when G00 is active (rapid traverse, infeed motion).
 This tolerance factor is relevant for the following control functions:
 1. Compressor (COMPCAD, COMPCURV, and COMPON)
 2. Smoothing with G64x
 3. Smoothing of orientation with OST
 4. Smoothing of orientation response with ORISON
 This factor can be both greater than 1 and less than 1. However, higher tolerance settings are usual for infeed motion.
 If the factor is equal to 1, the tolerances applied for G00 motion are the same as those for non-G00 motion.

20600	MAX_PATH_JERK			C05	B1,B2	
m/s³	Path-related maximum jerk			DOUBLE	NEW CONF	
-						
-	5	10000., 10000., 10000., 10000....	1.e-9	-	1/1	M

Description: The jerk limitation restricts the path acceleration change in SOFT mode. The path acceleration divided by the jerk limitation value produces a time in which the acceleration change takes place.
 The jerk limitation is activated on the path by the NC command SOFT, and deactivated by BRISK.
 MD irrelevant for:
 Error states that lead to a rapid stop. In addition, the limitation is also inactive for positioning axes.
 There is an entry for each dynamic G code group.

20602	CURV_EFFECT_ON_PATH_ACCEL	EXP, C05	B1,B2
-	Effect of path curvature on path dynamic	DOUBLE	NEW CONF
-			
-	5	0., 0., 0.65, 0.6, 0.5	0. 0.95 2/2 M

Description: This MD is used to determine whether the reaction of path curvature on path acceleration and path velocity is taken into account.

0:

Not taken into account

> 0:

If required, the path velocity and path acceleration are reduced in order to keep a sufficient reserve on the machine axes for centripetal acceleration.

0.75: Recommended setting.

MD20602 \$MC_CURV_EFFECT_ON_PATH_ACCEL defines the proportion of the axis accelerations (see MD32300 \$MA_MAX_AX_ACCEL[...]) that can be used for centripetal acceleration. The remainder is used for changing the path velocity. Centripetal acceleration is not required for linear blocks; the full axis acceleration is therefore available for the path acceleration. On slightly curved contours or with a sufficiently low maximum path feedrate \$MC_CURV_EFFECT_ON_PATH_ACCEL has only a partial or no effect. Accordingly, the path acceleration is higher than that specified by $(1. - MD20602 \$MC_CURV_EFFECT_ON_PATH_ACCEL) * MD32300 \$MA_MAX_AX_ACCEL[...]$.

There is an entry for each dynamic G code group.

20603	CURV_EFFECT_ON_PATH_JERK	EXP, C05	B1
-	Effect of path curvature on path jerk	DOUBLE	NEW CONF
-			
-	5	0., 0., 0., 0., 0., 0., 0., 0., 0., 0....	0. 1000. 2/2 M

Description: Allows the reaction of the path curvature on the path jerk to be taken into account on especially jerk-sensitive machines.

Entry for each dynamic G code group.

20605	PREPDYN_SMOOTHING_FACTOR	EXP, C05	B1
-	Factor for curve smoothing	DOUBLE	NEW CONF
-			
828d-me41	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 1/1 M
828d-me61	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 1/1 M
828d-me81	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 1/1 M
828d-te61	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 0/0 S
828d-te81	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 0/0 S
828d-te41	5	1., 1., 1., 1., 1., 1., 1., 1., 1., 1....	- - 0/0 S

Description: Factor to determine the degree of smoothing and torsion.

A larger value of this MD causes a stronger smoothing and thus a more homogeneous curvature/torsion and resulting path velocity.

2.3 Channel-specific machine data

With this factor being zero no smoothing is performed.
There is an entry for all dynamic G code groups.

20606	PREPDYN_SMOOTHING_ON			EXP, C05	B1	
-	Activation of curve smoothing			BOOLEAN	NEW CONF	
-						
828d-me41	5	0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	2/2	M
828d-me61	5	0, 0, 1, 1, 1	-	-	2/2	M
828d-me81	5	0, 0, 1, 1, 1	-	-	2/2	M
828d-te61	5	0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	0/0	S
828d-te81	5	0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	0/0	S
828d-te41	5	0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	0/0	S

Description: Switch on of curve and torsion smoothing.
Smoothing of the curve or torsion causes a homogenous path velocity.
Smoothing is only performed, when the relevant factor is MD 20605
\$MC_PREPDYN_SMOOTHING_FACTOR > 0.
There is an entry for all dynamic G code groups.

20610	ADD_MOVE_ACCEL_RESERVE			C05	F2,B2,K1	
-	Acceleration margin for overlaid movements			DOUBLE	PowerOn	
-						
-	-	.2,.2,.2,.2,.2,.2,.2,.2, 0.	0.	0.9	2/2	M

Description: This machine data contains the factor which defines the acceleration margin which is not used by a path movement in order to provide sufficient acceleration reserves for an overlaid movement for the velocity control.
A factor of 0.2 means that the path axes utilize 80% of the path acceleration in normal operation. Only when a request for overlaid movement is made, can 100% of the path acceleration be utilized.
MD irrelevant for:
Error states that lead to a rapid stop. In addition, the limitation is also ineffective for positioning axes.
Special cases:
At the moment the machine data is only taken into account if the function "Fast retraction" is first activated.
Related to:
MD32300 \$MA_MAX_AX_ACCEL (axis acceleration)

20620	HANDWH_GEOAX_MAX_INCR_SIZE			C08, C06	H1	
mm	Limitation handwheel increment for geometry axes			DOUBLE	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0, 0,0,0,0,0...	-	-	2/2	M

Description: > 0: Limitation of the size of the selected increment for geometry axes
\$MN_JOG_INCR_SIZE0[<increment/VDI signal>] or
SD41010 \$SN_JOG_VAR_INCR_SIZE for geometry axes
0: No limitation on geometry axes

20622	HANDWH_GEOAX_MAX_INCR_VSIZE	C08, C06, C05	-
mm/min	Path velocity override	DOUBLE	PowerOn
-			
-	-	500.,500.,500.,500.,500. 0.,500.,500....	-
			2/2 M

Description: The following applies to the velocity override of the path:
 > 0: Limitation of the size of the selected increment
 (\$MN_JOG_INCR_SIZE_ [<increment/VDI signal>] or
 SD41010 \$SN_JOG_VAR_INCR_SIZE) / 1000*IPO sampling time
 = 0: No limitation

20624	HANDWH_CHAN_STOP_COND	EXP, C09	H1,P1
-	Definition of response of handwheel travel, channel-specific	DWORD	PowerOn
-			
-	-	0x13FF,0x13FF,0x13 FF,0x13FF,0x13FF...	0
			0xFFFF 2/2 M

Description: Definition of the behavior for handwheel travel to channel-specific VDI interface signals (bit 0 to bit 7) or the context-sensitive interpolator stop (bit 7):
 Bit = 0:
 Interruption or collection of the displacements entered via the handwheel.
 Bit = 1:
 Traversing aborted and no collecting

Bit assignment:

Bit 0: Mode group stop

Bit 1: Mode group stop, axes plus spindle

Bit 2: NC stop

Bit 3: NC stop, axes plus spindles

Bit 4: Feed disable (exceptions with MD30460 \$MA_BASE_FUNCTION_MASK bit 6)

For bit 4 feed disable, it must be taken into account that a PLC-controlled axis, for which MD30460 \$MA_BASE_FUNCTION_MASK bit 6 = 1, is not stopped by the feed disable, and that no interruption and no abort are triggered here.

Bit 5: Feedrate override

Bit 6: Rapid traverse override

Bit 7: Feed stop, geometry axis or context-sensitive interpolator stop

Bit 8 = 0:

The maximum feedrate for handwheel travel of geometry axes is that specified in machine data JOG_AX_VELO for the corresponding machine axis/axes.

Bit 8 == 1:

The maximum feedrate for handwheel travel of geometry axes is that specified in machine data MAX_AX_VELO for the corresponding machine axis/axes.

Bit 9 = 0:

The override is active during handwheel travel of geometry axes

Bit 9 = 1:

During handwheel travel of geometry axes, the override is assumed to be 100% irrespective of the position of the override switch.

Exception: override 0, which is always active.

Bit 10 = 0:

MD11310 \$MN_HANDWH_REVERSE is not active for DRF, i.e. handwheel travel with DRF is carried out as if MD11310 \$MN_HANDWH_REVERSE = 0.

Bit 10 = 1:

MD11310 \$MN_HANDWH_REVERSE is active for DRF.

Bit 11 = 0:

When the contour handwheel is deselected, program processing is continued automatically.

Bit 11 = 1:

When the contour handwheel is deselected, an NCSTOP is triggered automatically. Program processing is not continued until NCSTART is entered.

Bit 12 = 0

NC start has no effect on handwheel travel.

Bit 12 = 1:

The previously collected paths are rejected at NC start.

Bit 13 = 0:

For DRF, bits 0 - 3 and bit 12: bit = 0 / bit = 1 are active (see above).

Bit 13 = 1:

For DRF, bits 0 - 3 and bit 12 are NOT active: the DRF motion is not interrupted by a stop, and a DRF motion can take place even in "Automatic interrupted" state (achieved by NC Stop).

Note:

If an alarm leads to an axis stop and if such an alarm is pending, no DRF motion can take place.

2.3 Channel-specific machine data

Bit 14 = 0:

The maximum feedrate for handwheel travel of geometry axes is that specified in SD41120 \$SN_JOG_REV_SET_VELO or in MD32050 \$MA_JOG_REV_VELO (for rotational feedrate) or in MD32040 \$MA_JOG_REV_VELO RAPID (for rapid traverse) for the corresponding machine axis, the spindle or rotary axis feedrate is included in the calculation.

Bit 14 = 1:

The maximum rotational feedrate for handwheel travel of geometry axes is the feedrate specified in MD32000 \$MA_MAX_AX_VELO for the corresponding machine axis (see also bit 6).

Bit 15 = 0:

If an axis with active diameter programming is traversed in the channel, only half the distance of the specified increment is traveled during handwheel travel (\$MN_HANDWH_TRUE_DISTANCE = 1 or 3).

Bit 15 = 1:

If an axis with active diameter programming is traversed in the channel, the specified increment is fully traveled during handwheel travel (\$MN_HANDWH_TRUE_DISTANCE = 1 or 3).

20700	REFP_NC_START_LOCK		C01, C03	D1,R1,Z1	
-	NC start disable without reference point		BYTE	Reset	
-					
-		1,1,1,1,1,1,1,1,1,1, 1,1,1,1	0	2	2/2 M

Description:

0: The NC/PLC interface signal DB3200 DBX7.1 (NC start) for starting part programs or part program blocks (MDI and overstore) is active even if one or all axes of the channel have not yet been referenced.

To ensure that the axes nevertheless reach the correct position after NC startup, the work (workpiece coordinate system = WCS) must be set to the correct value by means of other methods (scratch method, automatic work offset determination etc.).

1: Axes for which the axial MD34110 \$MA_REFP_CYCLE_NR specifies that a reference point is mandatory (value > -1), must be referenced for NC startup to be enabled.

2: Advanced form of setting 1 in that the axis state "Position restored" (instead of "referenced") is sufficient for NC startup in MDI or overstore.

20730	GO_LINEAR_MODE		C09	P2	
-	GO interpolation mode		BOOLEAN	PowerOn	
-					
-		TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	2/2 M

Description:

This machine data defines the interpolation behavior of G0:

0: Non-linear interpolation (RTLIOF): Each path axis interpolates as an individual axis (positioning axis), independently of the other axes, at the rapid traverse velocity of the axis (MD32000 \$MA_MAX_AX_VELO).

1: Linear interpolation (RTLION): The path axes are interpolated jointly.

Related to:

MD20732 \$MC_EXTERN_GO_LINEAR_MODE

20732	EXTERN_G0_LINEAR_MODE		N12	P2	
-	G00 interpolation mode		BOOLEAN	PowerOn	
-					
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	2/2 M

Description: This machine data defines the interpolation behavior of G00:
 0: Axes are traversed as positioning axes
 1: Axes interpolate with each other
 Related to:
 MD10886 \$MN_EXTERN_INCREMENT_SYSTEM

20734	EXTERN_FUNCTION_MASK		N12	-	
-	Function mask for external language		DWORD	Reset	
-					
-	-	0x2840,0x2840,0x2840,0x2840,0x2840,0x2840...	0	0xFFFF	1/1 M

Description: This machine data is used to influence functions in ISO mode.

Bit0: 0:
 ISO mode T: "A" and "C" are interpreted as axes. If contour definition has been programmed, "A" or "C" must be preceded by a comma.
 1:
 "A" and "C" in the part program are always interpreted as a contour definition. An axis "A" or "C" is not allowed.

Bit1: 0:
 ISO mode T: G10 P < 100 tool geometry
 P > 100 tool wear
 1:
 G10 P < 10000 tool geometry
 P > 10000 tool wear

Bit2: 0:
 G04 dwell time: always [s] or [ms]
 1:
 If G95 is active, in spindle revolutions

Bit3: 0:
 Errors in ISO scanner lead to an alarm
 1:
 Errors in ISO scanner are not output, the block is transferred to the Siemens translator.

Bit4: 0:
 G00 is traversed with the current exact stop - continuous-path mode G code
 1:
 G00 is always traversed with G09

Bit5: 0:
 Modulo rotary axis is positioned at the shortest possible distance
 1:
 Direction of rotation of modulo rotary axis depends on sign

- Bit6: 0:
Only 4-digit program number allowed.
1:
8-digit program number allowed. If the program number has less than 4 digits, it is expanded to 4 digits with 0.
- Bit7: 0:
Axis programming for geometry axis exchange/parallel axes is compatible with ISO mode.
1:
Axis programming for geometry axis exchange/parallel axes in ISO mode is compatible with Siemens mode.
- Bit8: 0:
With cycles, the F value transferred is always interpreted as a feedrate.
1:
With threading cycles, the F value transferred is interpreted as a pitch.
- Bit9: 0:
Multiplication with 0.01mm / 0.0001inch is carried out in ISO mode T for G84, G88 and in standard mode F for G95.
1:
Multiplication with 0.001mm / 0.00001inch is carried out in ISO mode T for G84, G88 and in standard mode F for G95.
- Bit10: 0:
With M96 Pxx, the program programmed with Pxx is always called in the case of an interrupt
1:
With M96 Pxx, CYCLE396.spf is always called in the case of an interrupt
- Bit11: 0:
With G54 Pxx, only G54.1 is displayed
1:
With G54 Pxx, the programmed program is displayed after the point, e.g. G54.48
- Bit12: 0:
When the subroutine defined with M96 Pxx is called, \$P_ISO_STACK is not modified
1:
When the subroutine defined with M96 Pxx is called, \$P_ISO_STACK is incremented
- Bit13: 0:
G10 is executed without internal STOPRE
1:
G10 is executed with internal STOPRE
- Bit14: 0:
ISO_mode T: No alarm if a cutting edge has been programmed in the T command.
1:
ISO mode T: Alarm 14185 if a cutting edge has not been programmed in the T command.

20750	ALLOW_G0_IN_G96		C09, C05	P2,V1		
-	G0 logic with G96, G961		BOOLEAN	PowerOn		
-						
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	2/2	M

Description: This machine data defines the speed regulation characteristic of the spindle in G0 blocks with constant cutting rate (G96, G961) selected .

1: In a G0 block, the spindle speed is kept constant at the last value of the previous block that was unequal G0.

Prior to a subsequent block that does not contain G0, the spindle speed is increased to a value that belongs to the transverse axis position of the subsequent block.

0: In a G0 block, the spindle speed changes against the transverse axis position.

20800	SPF_END_TO_VDI		C04, C03	H2,K1		
-	End of subroutine to PLC		BYTE	PowerOn		
-						
-	-	3,3,3,3,3,3,3,3,3,3	-	-	1/1	M

Description: Bit 0 = 1:
The M functions for subroutine end (M17 and/or M2/M30) are transferred to the PLC interface.

Bit 0 = 0:
The M functions for subroutine end (M17 and/or M2/M30) are not transferred to the PLC interface.

Note:
To prevent stopping in continuous-path mode, M17 must not be programmed alone in a block.

Example of a subroutine: G64 F2000 G91 Y10 X10
X10 Z10 M17

Bit 1 = 0:
M01:
conditional program stop is always output to PLC, irrespective of whether the M01 signal is active or not.
Fast auxiliary function output M=QU(1) is inactive because M01 is assigned to the 1st M function group and thus is always output at block end.

Bit 1 = 1:
M01:
conditional program stop is only output to PLC, if M01 is also active.
This thus enables optimal run-time processing of the part program.
With fast auxiliary function output M=QU(1), M1 is output during the movement; thus it is possible to traverse blocks in continuous-path mode with programmed M01 as long as M01 is not active.
The request of the M01 signal with M=QU(1) no longer occurs at block end but during the movement.

20850	SPOS_TO_VDI	C04, C03	S1
-	Output of M19 to PLC on SPOS/SPOSA	BYTE	PowerOn
-			
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-
-	-	0,0,0,0	-
-	-		
-	-		1/1
-	-		M

Description:

Bit 0 = 0:

When bit 19 is also set to '0' in MD35035 `$MA_SPIND_FUNCTION_MASK`, auxiliary function M19 is not generated with SPOS and SPOSA. This also eliminates the acknowledgement time for the auxiliary function, which can cause faults with very short blocks.

Bit 0 = 1:

When SPOS and SPOSA are programmed in the part program, auxiliary function M19 is generated and output to the PLC. The address extension corresponds to the spindle number.

Related to:

`SPIND_FUNCTION_MASK`

21000	CIRCLE_ERROR_CONST	C06	-
mm	Circle end point monitoring constant	DOUBLE	PowerOn
-			
-	-	0.01,0.01,0.01,0.01,0.01,0.01,0.01,0.01,0.01...	-
-	-		2/2
-	-		M

Description:

This machine data is used to specify the permissible absolute circle error [mm].

When a circle is programmed, both conditions (that the distances from the programmed center point to the start and end points (circle radius) must be the same and that the center point of the circle must be located on the perpendicular bisector of the straight line connecting the start and end points (perpendicular bisector of the circular plane)) apply.

The fact that the circular parameters can be freely programmed means that these conditions are not usually met exactly in the case of circular-path programming with I, J, and K (the circle is "overdefined").

The maximum permissible difference between the two radii that is accepted without an alarm, as well as the distance between the programmed center point of the circle and the perpendicular bisector described above, is defined by the larger value in the following data:

- MD21000 `$MC_CIRCLE_ERROR_CONST`
- Start radius multiplied by MD21010 `$MC_CIRCLE_ERROR_FACTOR`

This means that for small circles the tolerance is a fixed value (MD21000 `$MC_CIRCLE_ERROR_CONST`), and for large circles it is proportional to the start radius.

Related to:

MD21010 `$MC_CIRCLE_ERROR_FACTOR`

(circle end point monitoring factor)

In the context of the predefined tolerances, conflicting circle data is compensated essentially by moving the center point of the circle. Please note that the deviation between the programmed center point and the actual center point can reach the order of magnitude set with machine data

`$MC_CIRCLE_ERROR_CONST` and/or `$MC_CIRCLE_ERROR_FACTOR`. In the case of circles which are almost full circles in particular, this can also lead to contour deviations of the same order of magnitude.

2.3 Channel-specific machine data

21010	CIRCLE_ERROR_FACTOR	C06	-
-	Circle end point monitoring factor	DOUBLE	PowerOn
-			
-	-	0.001,0.001,0.001,0.001,0.001,0.001...	-
			2/2 M

Description: Factor for permissible radius difference.
 Defines the factor for large circles by which the starting radius and end radius may deviate from each other (see also MD21000 \$MC_CIRCLE_ERROR_CONST (circle end point monitoring constant)).
 When a circle is programmed, both conditions (that the distances from the programmed center point to the start and end points (circle radius) must be the same and that the center point of the circle must be located on the perpendicular bisector of the straight line connecting the start and end points (perpendicular bisector of the circular plane)) apply.
 The fact that the circular parameters can be freely programmed means that these conditions are not usually met exactly in the case of circular-path programming with I, J, and K (the circle is "overdefined").
 The maximum permissible difference between the two radii that is accepted without an alarm, as well as the distance between the programmed center point of the circle and the perpendicular bisector described above, is defined by the larger value in the following data:

- MD21000 \$MC_CIRCLE_ERROR_CONST
- Start radius multiplied by MD21010 \$MC_CIRCLE_ERROR_FACTOR

This means that for small circles the tolerance is a fixed value (MD21000 \$MC_CIRCLE_ERROR_CONST), and for large circles it is proportional to the start radius.
 Related to:
 MD21000 \$MC_CIRCLE_ERROR_CO'NST
 (circle end point monitoring factor)
 In the context of the predefined tolerances, conflicting circle data is compensated essentially by moving the center point of the circle. Please note that the deviation between the programmed center point and the actual center point can reach the order of magnitude set with machine data \$MC_CIRCLE_ERROR_CONST and/or \$MC_CIRCLE_ERROR_FACTOR. In the case of circles which are almost full circles in particular, this can also lead to contour deviations of the same order of magnitude.

21020	WORKAREA_WITH_TOOL_RADIUS	C03, C06	A3
-	Consideration of tool radius for working area limitation	BOOLEAN	Reset
-			
-	-	FALSE,FALSE,FALSE,FALSE,FALSE...	-
			2/2 M

Description: This machine data indicates whether the tool radius is taken into account in the working area limitation.
 0: It is checked whether the tool center lies within the working area limits.
 1: The tool radius is taken into account when the working area limitation is checked. This means that the working area is reduced by the tool radius.

21090	MAX_LEAD_ANGLE		C08, C09	M1
degrees	Maximum value of permitted lead angle for orientation progr.		DOUBLE	NEW CONF
-				
-	-	80.,80.,80.,80.,80.,80., 80.,80.,80....	0.	80.
				2/2
				U

Description: Maximum permissible value of the lead angle in degrees.

21092	MAX_TILT_ANGLE		C08, C09	M1
degrees	Maximum value of permitted side angle for orientation progr.		DOUBLE	NEW CONF
-				
-	-	180.,180.,180.,180.,18 0.,180.,180....	-180.	180.
				2/2
				U

Description: Maximum permissible value of the tilt angle in degrees.

21100	ORIENTATION_IS_EULER		C01, C09	F2,TE4,M1
-	Angle definition for orientation programming		BOOLEAN	NEW CONF
-				
828d-me41	-	FALSE	-	-
				1/1
				M
828d-me61	-	FALSE	-	-
				1/1
				M
828d-me81	-	FALSE	-	-
				1/1
				M
828d-te61	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-
				1/1
				M
828d-te81	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-
				1/1
				M
828d-te41	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-
				1/1
				M

Description: This data is only active for MD21102 \$MC_ORI_DEF_WITH_G_CODE = 0
MD = 0 (FALSE):

The values programmed with A2, B2, C2 during orientation programming are interpreted as an RPY angle (in degrees).

The orientation vector is produced by rotating a vector in direction Z first by C2 around the Z axis, then by B2 around the new Y axis and finally by A2 around the new X axis. In contrast to Euler angle programming, all three values influence the orientation vector in this case.

MD = 1 (TRUE):

The values programmed with A2, B2, C2 during orientation programming are interpreted as Euler angles (in degrees).

The orientation vector is produced by rotating a vector in direction Z first by A2 around the Z axis, then by B2 around the new X axis and finally by C2 around the new Z axis. This means that the value of C2 is meaningless.

2.3 Channel-specific machine data

21110	X_AXIS_IN_OLD_X_Z_PLANE			EXP, C01, C09	M1,K2	
-	Coordinate system for automatic frame definition			BOOLEAN	PowerOn	
-						
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	2/2	M

Description: 1 = With automatic definition of a frame (TOFRAME), the Z direction of which equals the current tool orientation, the new coordinate system is additionally rotated around the new Z axis so that the new X axis is in the old Z-X plane.

0 = With automatic definition of a frame (TOFRAME), the Z direction of which equals the current tool orientation, the new coordinate system is maintained as it results from the kinematics of the machine, i.e. it is assumed that the coordinate system is fixed to the tool and rotates with the tool (orientation).

From SW 5.3:

This machine data is only effective when the three lowest value decimal positions (units, tens, hundreds) of SD42980 \$SC_TOFRAME_MODE) equal zero. Otherwise the frame definition is specified by SD42980 \$SC_TOFRAME_MODE.

MD irrelevant for:

No orientation programming

Related to:

MD21100 \$MC_ORIENTATION_IS_EULER

Further references:

/PG/, Programming Guide, Fundamentals

21160	JOG_VELO_RAPID_GEO			C07	F2	
mm/min	JOG rapid traverse for geometry axes			DOUBLE	Reset	
-						
-	3	10000., 10000.0, 10000., 10000., 10000.0, 10000....	-	-	2/2	M

Description: Velocity in JOG mode with rapid traverse override for geometry axes in the channel (mm/min)

21165	JOG_VELO_GEO			C07	F2	
mm/min	Jog feedrate for geometry axes			DOUBLE	Reset	
-						
-	3	1000., 1000., 1000., 1000., 1000., 1000....	-	-	2/2	M

Description: JOG velocity for geometry axes in the channel (mm/min)

21186	TOCARR_ROT_OFFSET_FROM_FR		C01, C07	F2
-	Offset of TOCARR rotary axes from WO		BOOLEAN	Immediately
-				
828d-me41	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	2/2 M
828d-me61	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	2/2 M
828d-me81	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	2/2 M
828d-te61	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	0/0 S
828d-te81	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	0/0 S
828d-te41	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	0/0 S

Description: Rotary axes offset for the orientable tool holder is automatically accepted from the work offset activated on activation of the orientable tool holder for the rotary axes.

21198	ORI_TRAFO_ONLINE_CHECK_LIM		C07	F2
mm	Activation limit of the realtime dynamic monitoring		DOUBLE	NEW CONF
-				
-	-	1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0...	-	2/2 M

Description: If, in the case of an orientation transformation, the effective BCS position or the effective tool length deviates from the values applied in preprocessing by more than the value defined in this machine data (e.g. due to superimposed movement or the activation of online tool length offset), real-time limiting of the dynamic response is activated.

21199	ORI_TRAFO_ONLINE_CHECK_LIMR		C07	F2
degrees	Activation limit for real-time monitoring of dynamic response, rotary axes		DOUBLE	NEW CONF
-				
-	-	1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0...	-	2/2 M

Description: If, in the case of an orientation transformation, the effective BCS position of one of the rotary axes involved in the transformation deviates from the values applied in preprocessing by more than the value defined in this machine data (e.g. due to superimposed movement), real-time limiting of the dynamic response is activated.

2.3 Channel-specific machine data

21200	LIFTFAST_DIST	C09	K1,V1,2.6.6.1
mm	Traversing distance on rapid lift from contour	DOUBLE	PowerOn
-	-	-	-
-	-	0.1,0.1,0.1,0.1,0.1,0.1,0.1, 0.1,0.1,0.1...	-
-	-	-	2/2 M

Description: The machine data determines the absolute value of the traverse movement for rapid lift. The direction of the traverse movement is defined in the part program by the command ALF.

References:
/PA/, Programming Guide: Fundamentals

21202	LIFTFAST_WITH_MIRROR	C09	K1
-	Rapid retract with mirroring	BOOLEAN	PowerOn
-	-	-	-
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-
-	-	-	2/2 M

Description:

1: When determining the retraction direction, if mirroring of the contour is active then the retraction direction is also mirrored. Mirroring of the retraction direction only refers to the directional components vertical to the tool direction.

0: Mirroring of the contour is NOT taken into account when determining the retraction direction.

21204	LIFTFAST_STOP_COND	C09	M3
-	Stop behavior with fast retraction	DWORD	NEW CONF
-	-	-	-
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0, 0,0,0,0	-
-	-	-	2/2 M

Description: Specifies the stop behavior of the liftfast motion under different stop conditions

Bit0: Axial NC/PLC interface signal DB380x DBX4.3 (Axial feed stop / Spindle stop) or context-sensitive interpolator stop
 =0 Stop of the retraction motion in case of an axial feed stop or context-sensitive interpolator stop
 =1 No stop of the retraction motion in case of an axial feed stop or context-sensitive interpolator stop

Bit1: Feed disable in channel NC/PLC interface signal DB3200 DBX6.0 (Feed stop)
 =0 Stop of the retraction motion in case of the feed stop in the channel
 =1 No stop of the retraction motion in case of the feed stop in the channel

21300	COUPLE_AXIS_1			C09	S3	
-	Synchron. spindle pair def, mach. axis no: follow. spindle [0], lead.sp [1]			BYTE	PowerOn	
-						
828d-me41	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	0/0	S
828d-me61	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	0/0	S
828d-me81	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	0/0	S
828d-te61	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	2/2	M
828d-te81	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	2/2	M
828d-te41	2	0, 0,0, 0,0, 0,0, 0,0,	0	31	0/0	S

Description:

One pair of synchronous spindles per NC channel can be defined in a fixed configuration with this machine data.

The machine axis numbers (channel-specific MD20070 \$MC_AXCONF_MACHAX_USED) applicable in the NC channel must be entered for the following spindle [n=0] and the leading spindle [n=1].

The coupling is not regarded as configured if values of "0" are entered, thus leaving 2 couplings to be configured freely via the NC part program.

MD irrelevant for:

User-defined coupling

Related to:

Channel-specific MD21310 \$MC_COUPLING_MODE_1

(type of coupling in synchronous spindle mode)

Channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1

(coupling parameters cannot be changed)

Channel-specific MD21330 \$MC_COUPLE_RESET_MODE_1

(coupling abort response)

Channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1

(block change response in synchronous spindle mode)

SD42300 \$SC_COUPLE_RATIO_1

(speed ratio parameters for synchronous spindle mode)

21310	COUPLING_MODE_1			C03, C09	S3	
-	Type of coupling in synchronous spindle operation			BYTE	PowerOn	
-						
828d-me41	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	0/0	S
828d-me61	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	0/0	S
828d-me81	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	0/0	S
828d-te61	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	2/2	M
828d-te81	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	2/2	M
828d-te41	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	2	0/0	S

Description:

This machine data determines the type of coupling for the fixed coupling configuration defined with machine data COUPLE_AXIS_1[n].

1: Setpoint coupling activated.

With a setpoint coupling, the reference variable for the following spindle is calculated from the position setpoint of the leading spindle, thus allowing the setpoints for the FS and LS to be input simultaneously. This has a particularly positive effect on the spindle synchronism during acceleration and deceleration processes.

A setpoint coupling thus achieves better command behavior than an actual-value coupling.

When a setpoint coupling is used, the following conditions must be fulfilled before synchronous mode is activated:

- The LS must be assigned to the same NC channel as the FS
- The FS and LS must be in position control mode (SPCON)
- The FS and LS must have the same dynamic control response

0: Actual-value coupling activated.

With an actual-value coupling, the command variable for the following spindle is calculated from the position actual value of the leading spindle. With this type of coupling, the following drive must be significantly more dynamic than the leading drive, but never vice versa.

The actual-value coupling can be used, for example, in the following cases:

- The LS must be assigned to a different NC channel than the FS.
- For leading spindles which are not suitable for position control.
- In cases where the dynamic control response of the leading spindle is considerably slower than that of the following spindle. As soon as the actual-value coupling is active, the NC/PLC interface signal <Istwertkopplung/> (Actual-value coupling) for the FS is set to "1-signal".

2: Speed coupling activated.

Internally, the speed coupling is a setpoint coupling. Lower dynamic requirements are placed on the FS and LS. A defined relation between the positions of the FS and LS cannot be established.

A speed coupling is used in the following cases:

- LS and/or FS are not in position control.
- There are no measuring systems present.

The coupling type can be altered in the NC part program when the coupling is deactivated by means of language instruction COUPDEF provided this option has

2.3 Channel-specific machine data

not been inhibited by the channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1. However, the parameterized value of channel-specific MD21310 \$MC_COUPLING_MODE_1 remains unchanged.

MD irrelevant to:

User-defined coupling

Related to:

Channel-specific MD21300 \$MC_COUPLE_AXIS_1

(definition of pair of synchronous spindles)

Channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1

(write-protection for configured coupling parameters)

NC/PLC interface signal <Istwertkopplung/> (Actual-value coupling)

21320	COUPLE_BLOCK_CHANGE_CTRL_1			C09	S3	
-	Block change behavior in synchronous spindle operation			BYTE	PowerOn	
-						
828d-me41	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	0/0	S
828d-me61	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	0/0	S
828d-me81	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	0/0	S
828d-te61	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	2/2	M
828d-te81	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	2/2	M
828d-te41	-	3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3,3	0	3	0/0	S

Description:

This machine data determines the condition under which a block change has to be executed when synchronous mode is activated for the fixed coupling configuration defined in the channel-specific machine data COUPLE_AXIS_ [n].

The following options are available:

- 0: Block change is enabled immediately
- 1: Block change in response to "Fine synchronization"
- 2: Block change in response to "Coarse synchronization"
- 3: Block change in response to IPOSTOP (i.e. after setpoint-based synchronization)

The block change response can be altered in the NC part program with language instruction COUPDEF provided this option is not inhibited by the channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1. However, the parameterized value of the channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1 remains unchanged.

The selected block change response remains valid even when the velocity ratio is changed or a defined angular offset is programmed while the coupling is active.

MD irrelevant for:

User-defined coupling

Related to:

Channel-specific MD21300 \$MC_COUPLE_AXIS_1
(definition of pair of synchronous spindles)
Channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1
(coupling parameters cannot be changed)
Channel-specific MD37200 \$MA_COUPLE_POS_TOL_COARSE or MD37220
\$MA_COUPLE_VELO_TOL_COARSE
(threshold value for coarse synchronization)
Channel-specific MD37210 \$MA_COUPLE_POS_TOL_FINE or MD37230
\$MA_COUPLE_VELO_TOL_FINE
(threshold value for fine synchronization)

21330	COUPLE_RESET_MODE_1			C03, C09	S3,K1	
-	Coupling abort behavior			DWORD	PowerOn	
-						
828d-me41	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	0/0	S
828d-me61	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	0/0	S
828d-me81	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	0/0	S
828d-te61	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	2/2	M
828d-te81	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	2/2	M
828d-te41	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	0	0x3FF	0/0	S

Description: This machine data defines the behavior of the synchronous mode for the pair of synchronous spindles configured with machine data COUPLE_AXIS_1[n].

Bit 0=0:

Synchronous mode remains active with a new program start and, as long as the control remains switched on, can be canceled only with COUPOF.

Bit 0=1:

Synchronous mode is canceled with program start (from the reset condition).

Bit 1=0:

Synchronous mode remains active even with program end and reset and, as long as the control remains switched on, can be canceled only with COUPOF.

Bit 1=1:

Synchronous mode is canceled with program end or RESET.

Bit 5=1:

The configured data are activated with program start.

Bit 6=1:

The configured data are activated with program end or RESET.

Bit 9=1:

Synchronous mode is switched on with program start.

2.3 Channel-specific machine data

Note:

Synchronous mode is not deselected with NC Start after NC Stop.

MD irrelevant to:

User-defined coupling

Related to:

Channel-specific MD21300 \$MC_COUPLE_AXIS_1 (definition of pair of synchronous spindles)

NC/PLC interface signal DB390x DBX2002.4 (Active spindle mode - synchronous mode)

21340	COUPLE_IS_WRITE_PROT_1			C09	S3	
-	Coupling parameters cannot be altered			BOOLEAN	PowerOn	
-						
828d-me41	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	0/0	S
828d-me61	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	0/0	S
828d-me81	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	0/0	S
828d-te61	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M
828d-te81	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M
828d-te41	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	0/0	S

Description:

This machine data defines whether or not the coupling parameters (speed ratio, block change response, coupling type) for the pair of synchronous spindles configured with channel-specific machine data COUPLE_AXIS_1[n] may be altered by the NC part program.

1: Coupling parameters may not be altered by the NC program (write-protection active)

An alarm message is generated if an attempt is made to change the parameters.

0: NC part program may alter coupling parameters using language instruction COUPDEF.

MD irrelevant for:

User-defined coupling

Related to:

Channel-specific MD21300 \$MC_COUPLE_AXIS_1 (definition of pair of synchronous spindles)

Channel-specific MD21310 \$MC_COUPLING_MODE_1 (type of coupling in synchronous spindle mode)

22035	AUXFU_ASSIGN_SPEC		C04	H2		
-	Output specification		DWORD	PowerOn		
-						
-	255	0, 0...	-	-	2/2	M

Description: Specification of the output behavior of the user-defined auxiliary functions.

- Bit 0 = 1Acknowledgment "normal" after an OB1 cycle
- Bit 1 = 1Acknowledgment "quick" with OB40
- Bit 2 = 1No predefined auxiliary function
- Bit 3 = 1No output to the PLC
- Bit 4 = 1Spindle reaction after acknowledgment by the PLC
- Bit 5 = 1Output before the motion
- Bit 6 = 1Output during the motion
- Bit 7 = 1Output at block end
- Bit 8 = 1No output after block search types 1, 2, 4
- Bit 9 = 1Collection during block search type 5 (SERUPRO)
- Bit 10 = 1 No output during block search type 5 (SERUPRO)
- Bit 11 = 1Cross-channel auxiliary function (SERUPRO)
- Bit 12 = 1Output via synchronized action
- Bit 13 = 1 Implicit auxiliary function
- Bit 14 = 1 Active M01
- Bit 15 = 1 No output during running-in test
- Bit 16 = 1 Nibbling off
- Bit 17 = 1 Nibbling on
- Bit 18 = 1 Nibbling

22037	AUXFU_ASSIGN_SIM_TIME		C04	H2,S1		
-	Acknowledgment time		DWORD	PowerOn		
-						
-	255	0, 0...	0	0x7FFFFFFF	2/2	M

Description: Acknowledgment time for auxiliary functions in ms.
See MD22010 \$MC_AUXFU_ASSIGN_TYPE[n] (auxiliary function type)

22040	AUXFU_PREDEF_GROUP		C04	H2		
-	Predefined auxiliary function groups		DWORD	PowerOn		
-						
-	301	1, 1, 1, 1, 1, 1, 2, 2, 2, 2, 2, 4, 4, 4, 4, 4, 3, 1, 1, 1...	0	168	2/2	M

Description: Group assignment of predefined auxiliary functions.
The predefined groups cannot be changed for indices 0, 1, 2, 3, 4, 22, 23, 24.

2.3 Channel-specific machine data

22050	AUXFU_PREDEF_TYPE		C04	H2
-	Predefined auxiliary function type		STRING	PowerOn
-				
-	301	"M", "M", "M", "M", "M", "M", "M", "M", "M", "M", "M", "M", "M"...	-	2/2 M

Description: The address codes of the predefined auxiliary functions are fix.
This setting cannot be changed!

22060	AUXFU_PREDEF_EXTENSION		C04	H2
-	Predefined auxiliary function extension		DWORD	PowerOn
-				
-	301	0, 0, 0, 0, 0, 0, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 0, 0, 0...	-1	99 2/2 M

Description: Address extension for predefined auxiliary functions:
This setting can be changed only for indices 5 to 17 and 21!

22070	AUXFU_PREDEF_VALUE		C04	H2
-	Predefined auxiliary function value		DWORD	PowerOn
-				
-	301	0, 1, 2, 17, 30, 6, 3, 4, 5, 19, 70, 40, 41, 42, 43, 44, 45, -1...	-	2/2 M

Description: Value of predefined auxiliary functions.
This setting cannot be changed!

22080	AUXFU_PREDEF_SPEC		C04	H2, K1
-	Output specification		DWORD	PowerOn
-				
-	301	0x81, 0x81, 0x81, 0x81, 0x81, 0x21, 0x21, 0x21, 0x21, 0x21...	-	2/2 M

Description: Specification of the output behavior of the predefined auxiliary functions.
 Bit 0 = 1Acknowledgment "normal" after an OB1 cycle
 Bit 1 = 1Acknowledgment "quick" with OB40
 Bit 2 = 1No predefined auxiliary function
 Bit 3 = 1No output to the PLC
 Bit 4 = 1Spindle reaction after acknowledgment by the PLC
 Bit 5 = 1Output before the motion
 Bit 6 = 1Output during the motion
 Bit 7 = 1Output at block end
 Bit 8 = 1No output after block search types 1, 2, 4
 Bit 9 = 1 Collection during block search type 5 (SERUPRO)
 Bit 10 = 1No output during block search type 5 (SERUPRO)

22210	AUXFU_S_SYNC_TYPE	C04	H2,2,4			
-	Output time of S functions (see MD22200 for values)	BYTE	PowerOn			
-						
-	-	1	0	4	1/1	M

Description: Synchronization of the S auxiliary functions with regard to a simultaneously programmed axis motion.

0 = Output before motion

1 = Output during motion

2 = Output at block end

3 = No output to the PLC (therefore no block change delay)

4 = Output in accordance with the predefined output specification

Notice:

An auxiliary function output specification configured by MD22080
`$MC_AUXFU_PREDEF_SPEC[preIndex]`, MD22035 `$MC_AUXFU_ASSIGN_SPEC[auxIndex]` or

A group output specification configured by MD11110 `$MN_AUXFU_GROUP_SPEC[groupIndex]`, which has a higher priority.

22220	AUXFU_T_SYNC_TYPE	C11, C04	H2,2,4			
-	Output time for T functions (see MD22200 for values)	BYTE	PowerOn			
-						
-	-	1	0	4	1/1	M

Description: Synchronization of the T auxiliary functions with regard to a simultaneously programmed axis motion.

0 = Output before motion

1 = Output during motion

2 = Output at block end

3 = No output to the PLC (therefore no block change delay)

4 = Output in accordance with the predefined output specification

Notice:

An auxiliary function output specification configured by MD22080
`$MC_AUXFU_PREDEF_SPEC[preIndex]`, MD22035 `$MC_AUXFU_ASSIGN_SPEC[auxIndex]` or

A group output specification configured by MD11110 `$MN_AUXFU_GROUP_SPEC[groupIndex]`, which has a higher priority.

22230	AUXFU_H_SYNC_TYPE	C04	H2,2,4			
-	Output time for H functions (see MD22200 for values)	BYTE	PowerOn			
-						
-	-	1	0	3	1/1	M

Description: Synchronization of the H auxiliary functions with regard to a simultaneously programmed axis motion.

0 = Output before motion

1 = Output during motion

2 = Output at block end

3 = No output to the PLC (therefore no block change delay)

Notice:

An auxiliary function output specification configured by MD22080
`$MC_AUXFU_PREDEF_SPEC[preIndex]`, MD22035 `$MC_AUXFU_ASSIGN_SPEC[auxIndex]` or

A group output specification configured by MD11110 `$MN_AUXFU_GROUP_SPEC[groupIndex]`, which has a higher priority.

22250	AUXFU_D_SYNC_TYPE	C04	H2
-	Output time for D functions (see MD22200 for values)	BYTE	PowerOn
-			
-	-	1	0
-	-	4	1/1
-	-		M

Description: Synchronization of the D auxiliary functions with regard to a simultaneously programmed axis motion.

0 = Output before motion

1 = Output during motion

2 = Output at block end

3 = No output to the PLC (therefore no block change delay)

4 = Output in accordance with the predefined output specification

Notice:

An auxiliary function output specification configured by MD22080
`$MC_AUXFU_PREDEF_SPEC[preIndex]`, MD22035 `$MC_AUXFU_ASSIGN_SPEC[auxIndex]` or

A group output specification configured by MD11110 `$MN_AUXFU_GROUP_SPEC[groupIndex]`, which has a higher priority.

22252	AUXFU_DL_SYNC_TYPE	C04	H2
-	Output time of DL functions	BYTE	PowerOn
-			
-	-	1	0
-	-	4	1/1
-	-		M

Description: Synchronization of the auxiliary function with regard to a simultaneously programmed motion.

0 = Output before motion

1 = Output during motion

2 = Output at block end

3 = No output to the PLC (therefore no block change delay)

4 = Output in accordance with the predefined output specification

Notice:

An auxiliary function output specification configured by MD22080
`$MC_AUXFU_PREDEF_SPEC[preIndex]`, MD22035 `$MC_AUXFU_ASSIGN_SPEC[auxIndex]` or

A group output specification configured by MD11110 `$MN_AUXFU_GROUP_SPEC[groupIndex]`, which has a higher priority.

22254	AUXFU_ASSOC_M0_VALUE	C01, C03, C10	H2,K1
-	Additional M function to stop a program	DWORD	PowerOn
-			
-	-	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	2/2 M

Description: This machine data defines an additional, predefined M function, which behaves in the same way as M0. The value of the machine data corresponds to the number of the auxiliary M function.

Predefined M numbers, such as M0, M1, M2, M3, etc., are not allowed.

Restriction:

See MD10715 \$MN_M_NO_FCT_CYCLE

Related to:

MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

MD10814 \$MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 \$MN_EXTERN_M_NO_SET_INT
MD10806 \$MN_EXTERN_M_NO_DISABLE_INT,
MD10800 \$MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 \$MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 \$MC_EXTERN_RIGID_TAPPING_M_NR

For nibbling:

MD26008 \$MC_NIBBLE_PUNCH_CODE

22256	AUXFU_ASSOC_M1_VALUE	C01, C03, C10	H2
-	Additional M function for conditional stop	DWORD	PowerOn
-			
-	-	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1...	2/2 M

Description: This machine data defines an additional, predefined M function, which behaves in the same way as M1. The value of the machine data corresponds to the number of the auxiliary M function.

Predefined M numbers, such as M0, M1, M2, M3, etc., are not allowed.

Restriction:

See MD10715 \$MN_M_NO_FCT_CYCLE

Related to:

MD10714 \$MN_M_NO_FCT_EOP,
MD10715 \$MN_M_NO_FCT_CYCLE,
MD20094 \$MC_SPIND_RIGID_TAPPING_M_NR,
MD22254 \$MC_AUXFU_ASSOC_M0_VALUE

For external language mode:

```
MD10814 $MN_EXTERN_M_NO_MAC_CYCLE,
MD10804 $MN_EXTERN_M_NO_SET_INT
MD10806 $MN_EXTERN_M_NO_DISABLE_INT,
MD10800 $MN_EXTERN_CHAN_SYNC_M_NO_MIN,
MD10802 $MN_EXTERN_CHAN_SYNC_M_NO_MAX
MD20095 $MC_EXTERN_RIGID_TAPPING_M_NR
```

For nibbling:

```
MD26008 $MC_NIBBLE_PUNCH_CODE
```

22400	S_VALUES_ACTIVE_AFTER_RESET	C04, C03, C05	-			
-	S function active beyond RESET	BOOLEAN	PowerOn			
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M

Description:

- 1: The last S values set in the main run are still active after a RESET.
This also applies to the dynamic correction values ACC, VELOLIM in spindle mode.
- 0: The various S values are equal to 0 after a RESET, and must therefore be reprogrammed.
The dynamic correction values ACC and VELOLIM are reset to 100% for spindle mode if the axis-specific MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET and MD32320 \$MA_DYN_LIMIT_RESET_MASK do not specify anything else.

Note:

The values for ACC and VELOLIM are also retained for spindle mode if MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET is not equal to zero or the axis-specific MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET is not equal to zero.

22410	F_VALUES_ACTIVE_AFTER_RESET	C04, C03, C05	M3,V1			
-	F function active beyond RESET	BOOLEAN	PowerOn			
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M

Description:

- 1: The last programmed F, FA, OVR and OVRA values are still active after RESET.
This also applies to the dynamic correction values (ACC, VELOLIM, JERKLIM, ACCLIMA, VELOLIMA, JERKLIMA).
- 0: The various values are set to their default values after reset.
This does not apply to the dynamic correction values if the axis-specific MD32320 \$MA_DYN_LIMIT_RESET_MASK specifies anything else.

Note:

The dynamic correction values are also retained if the axis-specific MD32320 \$MA_DYN_LIMIT_RESET_MASK is not equal to zero.

Related to:

```
MD22240 $MC_AUXFU_F_SYNC_TYPE Output time of the F functions
```

22420	FGROUP_DEFAULT_AXES			C11	-	
-	Default setting for FGROUP command			BYTE	PowerOn	
-						
-	8	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	-	-	3/3	U

Description: Default setting for FGROUP command. You can specify up to 8 channel axes whose resulting velocity is equivalent to the programmed path feed.
If all eight values are zero (default), the geo axis entered in MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB are active as the default setting for the FGROUP command as previously.

22510	GCODE_GROUPS_TO_PLC			C04	K1,P3 pl,P3 sl	
-	G codes output at NCK-PLC interface on block change/RESET			BYTE	PowerOn	
-						
-	8	1, 0, 0, 0, 0, 0, 0, 0, 0	-	-	1/1	M

Description: Specification of the G code group, the G codes of which are output to the NCK/PLC interface in case of block change/ reset.

The interface is updated after each block change and reset.

Notice:

It is not guaranteed that a PLC user program has at all times a block-synchronous relation between the active NC block and the G codes present.

Example: Path mode with very short blocks

22512	EXTERN_GCODE_GROUPS_TO_PLC			C11, C04	-	
-	Send G codes of an external NC language to PLC			BYTE	PowerOn	
-						
-	8	18, 0, 0, 0, 0, 0, 0, 0, 0	-	-	1/1	M

Description: Specification of the G code group of external languages, the G codes of which are output at the NCK interface on block change/reset.

The interface is updated at each block change and after RESET.

Notice:

It is not guaranteed that a PLC user program has at all times a block-synchronous relation between the active NC block and the G codes present.

(Example: Path mode with very short blocks).

22515	GCODE_GROUPS_TO_PLC_MODE			C04	-	
-	Behavior of G group transfer to PLC			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	1	1/1	M

Description: For setting the behavior, i.e. how the G groups are to be interpreted in the PLC with regard to data.

With the current behavior (bit 0 = 0), the G group is the array index of a 64-byte field (DBB 208 - DBB 271).

Maximally the 64th G group can be reached in this way.

With the new behavior (bit 0 = 1), the data storage in the PLC consists of max. 8 bytes (DBB 208 - DBB 215).

With this procedure, the array index of this byte array is identical with the index of the MD22510 \$MC_GCODE_GROUPS_TO_PLC[Index] and MD22512 \$MC_EXTERN_GCODE_GROUPS_TO_PLC[Index].

2.3 Channel-specific machine data

Each index (0 - 7) may only be set for one of the two machine data; the value 0 must be entered for the other MD.

Bit 0 (LSB) = 0:

Behavior as before, the 64-byte field is used for displaying the G codes

Bit 0 (LSB) = 1:

The user specifies for which G groups the first 8 bytes are to be used

22530	TOCARR_CHANGE_M_CODE			C04	H2,W1	
-	M code at change of tool holder			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-99999999	99999999	2/2	M

Description: The absolute value of this machine data indicates the number of the M code, which is output at the VDI interface when a tool holder is activated.

- If the MD is positive, the unchanged M code is always output.
- If the MD is negative, the number of the tool holder is added to the absolute value of the machine data and the number is output.

Special cases:

N M code is output, if the number of the M code to be output or the absolute value of this MD is set to one of the values 0 to 6, 17 or 30. It is not monitored whether an M code created in this way will conflict with other functions.

References:

/FB/, H2, Auxiliary Function Output to PLC

22532	GEOAX_CHANGE_M_CODE			C04	H2,K2	
-	M code at change of geo axes			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	99999999	1/1	M

Description: Number of the M code, which is output at the VDI interface in the case of a switchover of the geometry axes.

No M code is output if this MD is set to one of the values 0 to 6, 17 or 30. It is not monitored whether an M code created in this way will conflict with other functions.

22534	TRAFO_CHANGE_M_CODE			C04	M1,H2	
-	M code at change of transformation			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	99999999	2/2	M

Description: Number of the M code that is output at the VDI interface in the case of a transformation changeover of the geometry axes.

No M code is output if this MD is set to one of the values 0 to 6, 17 or 30. It is not monitored whether an M code created in this way will conflict with other functions.

2.3 Channel-specific machine data

22550	TOOL_CHANGE_MODE			C01, C11, C04, C09	W3,K1,W1	
-	New tool compensation for M function			BYTE	PowerOn	
-						
828d-me41	-	1	0	1	1/1	M
828d-me61	-	1	0	1	1/1	M
828d-me81	-	1	0	1	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0		1	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0		1	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0		1	1/1	M

Description: The T function is used to select a tool in the program. The setting in this machine data determines whether the new tool is loaded immediately on execution of the T function:

```
MD22550 $MC_TOOL_CHANGE_MODE = 0
```

The new tool is loaded directly with the programming of T or D. This setting is mainly used on lathes. If a D is not programmed in the block by T, then the tool offset defined in MD20270 \$MC_CUTTING_EDGE_DEFAULT is active.

In this case, the function "Manual tools" is not enabled.

```
MD22550 $MC_TOOL_CHANGE_MODE = 1
```

The new tool is prepared for loading on execution of the T function. This setting is used mainly on milling machines with a tool magazine in order to bring the new tool into the tool change position without interrupting the machining process. The M function entered in MD22560 \$MC_TOOL_CHANGE_M_CODE is used to remove the old tool from the spindle and load the new tool onto the spindle. According to DIN 66025, this tool change has to be programmed with M function M06.

Related to:

```
MD22560 $MC_TOOL_CHANGE_M_CODE
```

22560	TOOL_CHANGE_M_CODE			C01, C04, C09	H2,K1,W1	
-	M function for tool change			DWORD	PowerOn	
-						
828d-me41	-	206	6	99999999	2/2	M
828d-me61	-	206	6	99999999	2/2	M
828d-me81	-	206	6	99999999	2/2	M
828d-te61	-	6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6		99999999	2/2	M
828d-te81	-	6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6		99999999	2/2	M
828d-te41	-	6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6,6		99999999	2/2	M

Description: If the T function is only used to prepare a new tool for a tool change (this setting is used mainly on milling machines with a tool magazine, in order to bring the new tool into the tool change position without interrupting the machining process), another M function must be used to trigger the tool change.

The M function entered in TOOL_CHANGE_M_CODE triggers the tool change (remove old tool from the spindle and load new tool into the spindle). This tool change is required to be programmed with M function M06, in accordance with DIN 66025.

Related to:

MD22550 \$MC_TOOL_CHANGE_MODE

22562	TOOL_CHANGE_ERROR_MODE			C09	W1	
-	Response to tool change errors			DWORD	PowerOn	
-						
-	-	0x8	0	0xFF	2/2	M

Description:

Behavior if faults/problems occur during programmed tool change.

Bit 0=0: Standard behavior: Stop on the faulty NC block

Bit 0=1: If a fault is detected in the block with the tool change preparation, the alarm relevant to the preparation command T is delayed until the corresponding tool change command (M06) has been interpreted in the program sequence. Until then, the alarm triggered by the preparation command is not output. The operator can take corrective actions in this block. When the program continues, the faulty NC block is re-interpreted, and the preparation command is automatically executed again internally.

The value = 1 is relevant only if the setting MD22550 \$MC_TOOL_CHANGE_MODE = 1 is used.

Bit 1 Only relevant with active tool management:

Bit 1=0: Standard behavior: Only tools with data assigned to a magazine are detected during tool change preparation.

Bit 1=1: Manual tools can be loaded.

A tool will also be loaded if its data are known in the NCK but have not been assigned to a magazine. In this case, the tool data is automatically assigned to the programmed tool holder.

The user is prompted to insert tools into or remove tools from the tool holder).

Bit 2 modifies the offset programming

Bit 2=0: active D no. > 0 and active T no.=0 gives offset 0

Active D no. > 0 and active D no.=0 gives total offset 0

Bit 2=1: active D no. > 0 and active T no.=0 lead to an alarm message

Active D no. > 0 and active D no.=0 lead to an alarm message

Bits 3 and 4 are only relevant with active tool management.

Function:

Control of the behavior of the init. block generation on program start if a disabled tool is on the spindle and this tool is to be activated.

See MD20112 \$MC_START_MODE_MASK, MD20110 \$MC_RESET_MODE_MASK

On RESET, this does not affect the behavior "Keep disabled tool on the spindle active".

Bit 3=0: Standard: If the tool on the spindle is disabled, generate a tool change command requesting a replacement tool. An alarm will be generated if there is no such replacement tool.

Bit 3=1: The disabled status of the spindle tool is ignored. The tool becomes active. The subsequent part program should be formulated so that no parts are machined with the disabled tool.

Bit 4=0: Standard: The system tries to activate the spindle tool or its replacement tool.

Bit 4=1: If the tool on the spindle is disabled, T0 is programmed in the start init block.

The combination of bits 3 and 4 produces the following statements:

0 / 0: Behavior as before, automatic change on NC start if a disabled tool is in the spindle

1 / 0: No automatic change

0 / 1: A T0 is automatically generated if a disabled tool is in the spindle at NC start

1 / 1: No statement

Bit 5: Reserved

Bit 6=0: Standard: If T0 or D0, only T0 or D0 is exactly programmed. This means that MD20270 \$MC_CUTTING_EDGE_DEFAULT and MD20272 \$MC_SUMCORR_DEFAULT determine the value of D and DL for the programming of T0.

Example: MD20270 \$MC_CUTTING_EDGE_DEFAULT=1, MD20272 \$MC_SUMCORR_DEFAULT=2, MD22550 \$MC_TOOL_CHANGE_MODE=0 (tool change with T programming)

N10 T0 ; T no. 0 has active numbers D1 and DL=2, which results in offset zero. If bit 2 is also set:

Programming of

a) T0; for tool deselection

b) D0; for offset deselection

generates an alarm, if

a) at least one of MD20270 \$MC_CUTTING_EDGE_DEFAULT and MD20272 \$MC_SUMCORR_DEFAULT is unequal to zero (The correct programming is T0 D0 DL=0).

b) MD20272 \$MC_SUMCORR_DEFAULT is unequal to zero (The correct programming is D0 DL=0).

Bit 6=1: Controls the NCK behavior when x, y, z are all programmed greater than zero, if at least one of MD20270 \$MC_CUTTING_EDGE_DEFAULT and MD20272 \$MC_SUMCORR_DEFAULT is unequal to zero.

a) Tx Dy --> T0:

With T0, D0 or D0 DL=0 is automatically programmed in the NCK; i.e. values in MD20270 \$MC_CUTTING_EDGE_DEFAULT and \$MC_SUMCORR_DEFAULT unequal to zero are treated as values equal to zero.

b) Tx Dy --> T0 Dy, or T0 DL=z, or T0 Dy DL=z, or T0 D0 DL=z, explicitly programmed values of D, DL are not influenced.

c) Dy DL=z --> D0

With D0, DL=0 is automatically programmed in the NCK; i.e. values in MD20272 \$MC_SUMCORR_DEFAULT unequal to zero are treated as values equal to zero.

d) Dy DL=z --> D0 DL=z

Explicitly programmed values of DL are not influenced.

If bit 2 is also set:

Only T0 / D0 have to be programmed for tool/offset deselection, and this does not generate an alarm.

The statements relating to MD20272 \$MC_SUMCORR_DEFAULT or DL are valid only if the total offset function is active (see MD18080 \$MN_MM_TOOL_MANAGEMENT_MASK, bit 8).

Bit 7=0: When Tx is programmed, a check is made to see whether a tool with T number x is known in the T0 unit of the channel. If not, the program is stopped in this block with alarm 17190

Bit 7=1: Only if tool basic functionality is active (MD20310
 $\$MC_TOOL_MANAGEMENT_MASK$, bit 0,1=0) and (MD18102
 $\$MN_MM_TYPE_OF_CUTTING_EDGE=0$):

When Tx is programmed, an unknown Tx is initially be ignored, and the alarm relating to the preparation command (Tx) is also ignored until the D selection is interpreted in the program sequence. Only then is alarm 17191, which has been triggered by the preparation command, output. This means that the operator can take corrective actions with the D selection in this block. When the program is continued, the incorrect NC block is re-interpreted, and the preparation command is automatically executed again internally.

(This is of interest for Cutting-Edge-Default=0 or ==-2 and D0 programming, otherwise the D of Cutting-Edge-Default is deselected on tool change.)

This variant is justified for programming "Tool number=Location" (revolver as tool holder) without tool management. The revolver can now positioned on a location for which a tool has not (yet) been defined.

This bit has no meaning if bit 0=1 is set.

22600	SERUPRO_SPEED_MODE		EXP	K1		
-	Speed for block search run type 5		DWORD	Immediately		
-						
-	-	1,1	0	3	1/1	M

Description:

This machine data specifies the search run mode: SERUPRO in more detail. SERUPRO search run is activated with PI service $_N_FINDBL$ mode parameter = 5. SERUPRO means Search Run by Program test, i.e. traversing under program test from beginning of program to search target.

Note:

Program test does not move any axes/spindles.

$\$MC_SERUPRO_SPEED_MODE= 0$

Program test with the search run/dry run speed

Under program test, the axes/spindles are traversed at the following velocity/speed:

Axes: $\$MC_SERUPRO_SPEED_FACTOR \times$ dry run feed

Spindles: $\$MC_SERUPRO_SPEED_FACTOR \times$ programmed speed

Dynamic axis / spindle limitations are not taken into account.

$\$MC_SERUPRO_SPEED_MODE= 1$

Program test at programmed speed

Under program test, the axes/spindles are traversed at the following velocity/speed:

Axes: at the same velocity as dry run feed.

Spindles: at the programmed speed.

Dynamic axis / spindle limitations are taken into account.

$\$MC_SERUPRO_SPEED_MODE= 2$

Program test at dry run speed

Under program test, the axes/spindles are traversed at the programmed velocity/speed.

Dynamic axis /spindle limitations are taken into account.

$\$MC_SERUPRO_SPEED_MODE= 3$

Program test at search run speed

2.3 Channel-specific machine data

Under program test, the axes/spindles are traversed at the following velocity/speed:

Axes: \$MC_SERUPRO_SPEED_FACTOR*programmed feed
 Spindles: \$MC_SERUPRO_SPEED_FACTOR*programmed speed.
 Dynamic axis / spindle limitations are not taken into account.

Note:

With active revolutional feedrate (e.g. G95), the programmed F value is not multiplied by the factor \$MC_SERUPRO_SPEED_FACTOR but only by the programmed spindle speed. Here again, this increases the effective path speed by the \$MC_SERUPRO_SPEED_FACTOR.

Related to:

SD42100 \$SSC_DRY_RUN_FEED, MD22601 \$MC_SERUPRO_SPEED_FACTOR

22601	SERUPRO_SPEED_FACTOR	EXP	K1			
-	Speed factor for search run type 5	DOUBLE	Immediately			
-						
-	-	10.0,10.0,10.0,10.0,10.0,10.0,10.0,10.0,10.0,10.0...	1.0	-	1/1	M

Description: SERUPRO means Search Run by Program test, i.e. traversing under program test from beginning of program to search target.

Note:

Program test does not move any axes / spindles.

The machine data is relevant only if the first two bits of MD22600

\$MC_SERUPRO_SPEED_MODE are 0. The machine data has the following meaning:

Axes: MD specifies the factor by which the test run feedrate is multiplied.

Spindles: MD specifies the factor by which the programmed speed is multiplied.

Dynamic limitations of axes / spindles are always ignored.

Related to:

SD42100 \$SSC_DRY_RUN_FEED, MD22600 \$MC_SERUPRO_SPEED_MODE

22620	START_MODE_MASK_PRT	EXP, C03	M3,K1			
-	Initial setting on special starts	DWORD	Reset			
-						
-	-	0x400,0x400,0x400,0x400,0x400,0x400,0x400,0x400...	0	0xFFFF	1/1	M

Description: This machine data is activated via MD22621 \$MC_ENABLE_START_MODE_MASK_PRT. If MD22621 \$MC_ENABLE_START_MODE_MASK_PRT is in its initial setting, MD22620 \$MC_START_MODE_MASK_PRT is inactive.

If MD22620 \$MC_START_MODE_MASK_PRT is activated for "search via program test" (abbr. SERUPRO), then MD22620 \$MC_START_MODE_MASK_PRT replaces MD20112 \$MC_START_MODE_MASK when "search via program test" is started.

This enables a behavior deviating from PLC start to be set at the start of the search. The meaning of the bit-by-bit assignment of MD22620 \$MC_START_MODE_MASK_PRT is the same as that in MD20112 \$MC_START_MODE_MASK.

22621	ENABLE_START_MODE_MASK_PRT		EXP, C03	M3,K1		
-	Enables MD22620 \$MC_START_MODE_MASK_PRT		DWORD	Reset		
-						
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x1	1/1	M

Description: MD22620 \$MC_START_MODE_MASK_PRT is activated via MD22621 \$MC_ENABLE_START_MODE_MASK_PRT.
If MD22621 \$MC_ENABLE_START_MODE_MASK_PRT is in its initial setting, MD22620 \$MC_START_MODE_MASK_PRT is inactive.
Bit0 = 1:
If a "search via program test" (English abbr. SERUPRO) is started from RESET (PI service _N_FINDBL mode parameter == 5), MD22620 \$MC_START_MODE_MASK_PRT replaces MD20112 \$MC_START_MODE_MASK.
This method can be used to set a start behavior differing from PLC start when the search is started.

22700	TRACE_STARTTRACE_EVENT		EXP, C06	-		
-	Diagnostic data rec. starts with event TRACE_STARTTRACE_EVENT.		STRING	PowerOn		
NBUP						
-	-		-		2/2	M

Description: The machine data is used for diagnostics.
The recording of the diagnostic data does not start until the event (TRACE_STARTTRACE_EVENT) has occurred at the trace point (TRACE_STARTTRACE_TRACEPOINT) and in the correct step (TRACE_STARTTRACE_STEP).

22702	TRACE_STARTTRACE_STEP		EXP, C06	-		
-	Conditions for start of trace recording		STRING	PowerOn		
NBUP						
-	2	,,, , , , , , , , , , , , , , , ,	-	-	2/2	M

Description: The machine data is only intended for diagnostic use.
See TRACE_STARTTRACE_EVENT
In the case of TRACE_STARTTRACE_EVENT BLOCK_CHANGE the string TRACE_STARTTRACE_STEP is interpreted as a file name and block number.
In the case of BSEVENTTYPE_SETALARM the string is interpreted as an alarm number.

22704	TRACE_STOPTRACE_EVENT		EXP, C06	-		
-	Conditions for stop of trace recording		STRING	PowerOn		
NBUP						
-	-	CLEARCANCELALARM_M,CLEARCANCELALARM_M...	-	-	2/2	M

Description: The machine data is only used for diagnostics.
The recording of the diagnostic data ends when the event (TRACE_STOPTRACE_EVENT) has occurred at the trace point (TRACE_STOPTRACE_TRACEPOINT) and in the correct step (TRACE_STOPTRACE_STEP).

Machine data

2.3 Channel-specific machine data

(After reaching the stop condition, the previously recorded diagnostic data is stored in a file "NCSCTRYy.MPF" or for NCU-LINK in "NCxxTRYy.MPF" in the MPF directory.

22706	TRACE_STOPTRACE_STEP		EXP, C06	-		
-	CommandSequenzStep with which the recording ends		STRING	PowerOn		
NBUP						
-	2	, , , , , , , , ...	-	-	2/2	M

Description: The machine data is only intended for diagnostic use.

22708	TRACE_SCOPE_MASK		EXP, C06	-		
-	Selects the contents of the trace file		STRING	PowerOn		
NBUP						
-	-		-	-	2/2	M

Description: The machine data is only intended for diagnostic purposes.
 Specific trace contents are selected with the MD datum.
 The entry SETALARM records the alarm environment and the block change in the main run is also logged by means of BLOCK_CHANGE.

22710	TRACE_VARIABLE_NAME		-	-		
-	Definition of trace data		STRING	PowerOn		
NBUP						
-	10	"BL_NR", "TR_POINT", "EV_TYPE", "EV_SRC", "CS_ASTEP"...	-	-	2/2	M

Description: The machine data is only intended for diagnostic purposes.
 The MD datum defines which data are recorded in the trace file.

22712	TRACE_VARIABLE_INDEX		EXP, C06	-		
-	Index for trace recording data		DWORD	PowerOn		
NBUP						
-	10	0x0, 0x0, 0x0, 0x0, 0x0, 0x0, 0x0, 0x0, 0x0, 0x0...	0	0xFFFF	2/2	M

Description: The machine data is only intended for diagnostic use.
 The MD data, together with TRACE_VARIABLE_NAME, determines which data are recorded in the trace file.
 It enables access to an array element.
 E.g. use as an axis index when accessing axis data.

22714	MM_TRACE_DATA_FUNCTION	EXP, C02, C06	-
-	Activating diagnostics	DWORD	PowerOn
NBUP			
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0
			0xFFFF
			2/2
			M

Description: The machine data is only intended for diagnostic purposes.
 Activating diagnostics
 An internal ring buffer records important events.
 After a trigger event, with the 'Cancel alarm' key set as default, the ring buffer is briefly frozen, read, and converted into an ASCII file in the part program directory. The file name for the 1st channel is ncsctr01.mpf and for the 7th channel it is ncsctr07.mpf.
 The data in the ring buffer is referred to as dynamic data in the following. In addition to the trigger event, other up-to-date data is read from the NCK and transferred to the ASCII file. These recordings do NOT have a history and are referred to as static data in the following.
 Bit no. Significance when bit is set

-
- 0 (LSB) Recording of dynamic data (see TRACE_VARIABLE_NAME)
 - 1 Recording of block control static data
 - 2 Recording of alarm data static data
 - 3 Recording of process data static data
 - 4 Recording of command sequence static data
 - 5 Recording of tool management static data
 - 6 Recording of the NCK version file. Static data
 - 7 Recording of the statuses of the current block
 Various statuses of the axes and the SPARPI. Static data
 - 8 Recording of various statuses of the channel. Static data
 - 9 Error statuses in the NCK memory management are scanned during trace generation.
 An error renames the trace file. Static data
 Possible names and their meaning:
 NCFIER.MPF Error in the file system
 NCSLER.MPF Error during string creation
 NCFIER.MPF Error on New/Delete
 - 10 All block changes in the interpreter are recorded. Dynamic data.
 - 11 Axial VDI signals are recorded. Dynamic data.
 Only in conjunction with MD18794 \$MN_MM_TRACE_VDI_SIGNAL
 - 12 OEM traces are activated. Dynamic data.
 - 13 Synchronized actions are recorded. Dynamic data.
 NOTICE: Filled in applications with intensive use of these trace points, other events are ignored!
 That is why this bit should remain at 0 in these cases.
 - 14 Not assigned.
 - 15 Recording of station commands. Dynamic data.
 Note: Most important output of the NCK module NCSC!
 - 16 Recording of gantry commands
 - 17 Recording of changes in the drive's status

2.3 Channel-specific machine data

- 18 Recording of the processing of the Event-Queue and generation of command sequences
- 19 Recording of event destructor call

22900	STROKE_CHECK_INSIDE		EXP, C01, C11	-		
-	Direction (inside/outside) in which prot. zone 3 is effective		BOOLEAN	PowerOn		
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	7/2	M

Description: This MD defines whether protection zone 3 is a protection zone inside or outside.

Meaning:

- 0: Protection zone 3 is a protection zone inside, i.e. the protection zone must not entered inwardly.
- 1: Protection zone 3 is a protection zone outside

22910	WEIGHTING_FACTOR_FOR_SCALE		EXP, C01, C11	-		
-	Input resolution for scaling factor		BOOLEAN	PowerOn		
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M

Description: Definition of the unit for the scaling factor P and for the axial scaling factors I, J, K.

Meaning:

- 0 Scale factor in 0.001
- 1 Scale factor in 0.00001

Related to:

- SD43120 \$SA_DEFAULT_SCALE_FACTOR_AXIS,
- SD42140 \$SC_DEFAULT_SCALE_FACTOR_P

22914	AXES_SCALE_ENABLE		EXP, C01, C11	-		
-	Activation for axial scaling factor (G51)		BOOLEAN	PowerOn		
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	2/2	M

Description: This MD enables axial scaling.

Meaning:

- 0: Axial scaling not possible
- 1: Axial scaling possible -> MD DEFAULT_SCALE_FACTOR_AXIS is active

Related to:

- SD43120 \$SA_DEFAULT_SCALE_FACTOR_AXIS

22920	EXTERN_FIXED_FEEDRATE_F1_ON		EXP, C01, C11	-		
-	Activation of fixed feedrates F1 - F9		BOOLEAN	PowerOn		
-						
-	-	FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	-	2/2	M

Description: This MD is used to activate the fixed feedrates set in SD42160 \$SC_EXTERN_FIXED_FEEDRATE_F1_F9[].
Meaning:
0: no fixed feedrates with F1 - F9
1: the feedrates set in SD42160 \$SC_EXTERN_FIXED_FEEDRATE_F1_F9[] become active when F1 - F9 are programmed.

22930	EXTERN_PARALLEL_GEOAX		EXP, C01, C11	-		
-	Assignment of a parallel channel axis to the geometry axis		BYTE	PowerOn		
-						
-	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	2/2	M

Description: Assignment table of the axes positioned parallel to the geometry axes. This table can be used to assign channel axes positioned parallel to the geometry axes. The parallel axes can then be activated as geometry axes in ISO mode using the G functions of plane selection (G17 - G19) and the axis name of the parallel axis. The axis is then replaced by the axis defined via MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB[].
Prerequisite:
The channel axes used must be active. (list position assigned in AXCONF_MACHAX_USED). Entering zero deactivates the corresponding parallel geometry axis:

24002	CHBFRAME_RESET_MASK		C03	K2		
-	Active channel-specific base frames after reset		DWORD	Reset		
-						
-	-	0xFFFF,0xFFFF,0xFF FF,0xFFFF,0xFFFF...	0	0xFFFF	1/1	M

Description: Bit mask for the reset setting of the channel-specific base frames which are included in the channel.
The following apply:
If MD20110 \$MC_RESET_MODE_MASK bit0 = 1 and BIT14 = 1
the entire base frame is determined on reset by chaining the base frame field elements, whose bit is 1 in the bit mask.
If MD20110 \$MC_RESET_MODE_MASK bit0 = 1 and BIT14 = 0
the entire base frame is deselected on reset.

24004	CHBFRAME_POWERON_MASK			C03	K2	
-	Reset channel-specific base frames after power on			DWORD	PowerOn	
-						
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0xFFFF	1/1	M

Description: This machine data defines whether channel-specific base frames are reset in the data management on Power On.

That is

- Offsets and rotations are set to 0,
- Scalings are set to 1.
- Mirror image machining is disabled.

The selection can be made separately for individual base frames.

Bit 0 means base frame 0, bit 1 base frame 1 etc.

Value=0: Base frame is retained on Power On

Value=1: Base frame is reset in the data management on Power On.

Related to:

MD10615 \$MN_NCBFRAME_POWERON_MASK

24006	CHSFRAME_RESET_MASK			C03	K2	
-	Active system frames after reset			DWORD	Reset	
-						
828d-me41	-	0x811	0	0x00000FFF	1/1	M
828d-me61	-	0x811	0	0x00000FFF	1/1	M
828d-me81	-	0x811	0	0x00000FFF	1/1	M
828d-te61	-	0x801	0	0x00000FFF	1/1	M
828d-te81	-	0x801	0	0x00000FFF	1/1	M
828d-te41	-	0x801	0	0x00000FFF	1/1	M

Description: Bit mask used for the reset setting of the channel-specific system frames included in the channel.

Bit 0: System frame for actual value setting and scratching is active after reset.

Bit 1: System frame for external work offset is active after reset.

Bit 2: Reserved, for TCARR and PAROT see MD20150 \$MC_GCODE_RESET_VALUES[].

Bit 3: Reserved, for TOROT and TOFRAME see MD20150 \$MC_GCODE_RESET_VALUES[].

Bit 4: System frame for workpiece reference points is active after reset.

Bit 5: System frame for cycles is active after reset.

Bit 6: Reserved; reset behavior dependent on MD20110 \$MC_RESET_MODE_MASK.

Bit 7: System frame \$P_ISO1FR (ISO G51.1 Mirror) is active after reset.

Bit 8: System frame \$P_ISO2FR (ISO G68 2DROT) is active after reset.

Bit 9: System frame \$P_ISO3FR (ISO G68 3DROT) is active after reset.

Bit 10: System frame \$P_ISO4FR (ISO G51 Scale) is active after reset.

Bit 11: System frame \$P_RELFR is active after reset.

Related to:

MD28082 \$MC_MM_SYSTEM_FRAME_MASK

24007	CHSFRAME_RESET_CLEAR_MASK	C03	K2			
-	Deletion of system frames after reset	DWORD	Reset			
-						
-	-	0x20	0	0x00000FFF	1/1	M

Description:

Bit mask used to delete channel-specific system frames from the data management on reset.

Bit 0: System frame for actual value setting and scratching is deleted on reset.

Bit 1: System frame for external work offset is deleted on reset.

Bit 2: Reserved, for TCARR and PAROT, see MD20150 \$MC_GCODE_RESET_VALUES[].

Bit 3: Reserved, for TOROT and TOFRAME, see MD20150 \$MC_GCODE_RESET_VALUES[].

Bit 4: System frame for workpiece reference points is deleted on reset.

Bit 5: System frame for cycles is deleted on reset.

Bit 6: Reserved; reset behavior depends on MD20110 \$MC_RESET_MODE_MASK.

Bit 7: System frame \$P_ISO1FR (ISO G51.1 Mirror) is deleted on reset.

Bit 8: System frame \$P_ISO2FR (ISO G68 2DROT) is deleted on reset.

Bit 9: System frame \$P_ISO3FR (ISO G68 3DROT) is deleted on reset.

Bit 10: System frame \$P_ISO4FR (ISO G51 Scale) is deleted on reset.

Bit 11: System frame \$P_RELFPR is deleted on reset.

24008	CHSFRAME_POWERON_MASK	C03	K2			
-	Reset channel system frames after power on	DWORD	PowerOn			
-						
-	-	0x0,0x0,0x0,0x0,0x0,0 x0,0x0,0x0,0x0...	0	0x00000FFF	1/1	M

Description:

This machine data defines whether channel-specific system frames are reset in the data management on Power On. That is offsets and rotations are set to 0, scalings to 1. Mirroring is disabled.

The selection can be made separately for individual system frames.

Bit 0: System frame for set actual value and scratching is deleted after Power On.

Bit 1: System frame for external work offset is deleted after Power On.

Bit 2: System frame for TCARR and PAROT is deleted after Power On.

Bit 3: System frame for TOROT and TOFRAME is deleted after Power On.

Bit 4: System frame for work piece reference points deleted after Power On.

Bit 5: System frame for cycles retained after Power On.

Bit 6: System frame for transformations deleted after Power On.

Bit 7: System frame \$P_ISO1FR (ISO G51.1 Mirror) is deleted after power ON.

Bit 8: System frame \$P_ISO2FR (ISO G68 2DROT) is deleted after power ON.

Bit 9: System frame \$P_ISO3FR (ISO G68 3DROT) is deleted after power ON.

Bit 10: System frame \$P_ISO4FR (ISO G51 Scale) is deleted after power ON.

Bit 11: System frame \$P_RELFPR is deleted after power ON.

Related to:

MD28082 \$MC_MM_SYSTEM_FRAME_MASK

2.3 Channel-specific machine data

The following applies:

Bit 0:

Data handling frames are only activated by programming the bit masks \$P_CHBFRMASK, \$P_NCBFRMASK and \$P_CHSFRMASK. G500..G599 only activate the relevant settable frame. The reset behavior is independent of this.

Bit 1:

Data handling frames are not written implicitly by system functions such as TOROT, PAROT, ext. work offset, transformations.

24080	USER_FRAME_POWERON_MASK		N01	-		
-	Parameterize properties for settable frame		DWORD	PowerOn		
-						
-	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x1	7/2	M

Description: Setting the following bits activates certain properties of the settable frame:

Bit 0 = 0: default behavior.

Bit 0 = 1: if MD20152 \$MC_GCODE_RESET_MODE[7] = 1, the last active settable frame is selected again according to G code group 8 after power up of the control.

24100	TRAFO_TYPE_1		C07	F2,TE4,M1,K1,W1		
-	Definition of transformation 1 in channel		DWORD	NEW CONF		
-						
828d-me41	-	0,0	-	-	1/1	M
828d-me61	-	0,0	-	-	1/1	M
828d-me81	-	0,0	-	-	1/1	M
828d-te61	-	256	-	-	1/1	M
828d-te81	-	256	-	-	1/1	M
828d-te41	-	256	-	-	1/1	M

Description: This MD specifies the first available transformation in each channel. The 4 low-value bits identify the specific transformation of a specific transformation group. The transformation group is identified by a number starting with the 5th bit.

Meaning:

0 No transformation

16 and higher

5-axis transformation with turnable tool

32 and higher

5-axis transformation with turnable workpiece

48 and higher

5-axis transformation with turnable tool and turnable workpiece

72

Generic 5-axis transformation. Type and kinematic data are determined by an associated, orientable tool carrier, see MD24582 \$MC_TRAFO5_TCARR_NO_1 and MD24682 \$MC_TRAFO5_TCARR_NO_2

The 4 low-value bits have the following meaning for a 5-axis transformation:

- 0 Axis sequence AB
- 1 Axis sequence AC
- 2 Axis sequence BA
- 3 Axis sequence BC
- 4 Axis sequence CA
- 5 Axis sequence CB
- 8 Generic orientation transformation (3- 5 axes)

256 and higher

TRANSMIT transformation

512 and higher

TRACYL transformation

1024 and higher

TRAANG transformation

2048

TRACLG: centerless transformation

From 4096 to 4098

OEM transformation

8192 and higher

TRACON: cascaded transformations

Example:

A 5-axis transformation with turnable tool and axis sequence CA (i.e. C axis turns A axis) has number 20 (= 16 + 4)

Notice:

Not all combinations of group numbers and axis sequence numbers are allowed. An error message is output if a number for a non-existent transformation is entered.

Related to:

MD24200 \$MC_TRAFO_TYPE_2, MD24300 \$MC_TRAFO_TYPE_3, ... MD24460 \$MC_TRAFO_TYPE_8

References:

/FB/, F2, "5-Axis Transformation"

24110	TRAFO_AXES_IN_1			C07	F2,TE4,M1,K1,W1	
-	Axis assignment for the 1st transformation in the channel			BYTE	NEW CONF	
-						
828d-me41	20	0, 0, 0, 0, 0, 0	0	20	1/1	M
828d-me61	20	0, 0, 0, 0, 0, 0	0	20	1/1	M
828d-me81	20	0, 0, 0, 0, 0, 0	0	20	1/1	M
828d-te61	20	1, 3, 2, 0, 0, 0	0	20	1/1	M
828d-te81	20	1, 3, 2, 0, 0, 0, 0, 0	0	20	1/1	M
828d-te41	20	1, 3, 2, 0, 0	0	20	1/1	M

Description:

Axis assignment at input point of 1st transformation

The index input at the nth position states which axis is mapped internally from the transformation to axis n.

Not relevant:

No transformation

Related to:

MD24200 \$MC_TRAFO_TYPE_2, MD24300 \$MC_TRAFO_TYPE_3, ...

MD24460 \$MC_TRAFO_TYPE_8

References:

/FB/, F2, "5-Axis Transformation"

24120	TRAFO_GEOAX_ASSIGN_TAB_1			C07	F2,TE4,TE4,M1,K1,W1	
-	Assignment of the geometry axes to channel axes for transformation 1			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-me61	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-me81	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te61	3	1, 3, 2	0	20	1/1	M
828d-te81	3	1, 3, 2	0	20	1/1	M
828d-te41	3	1, 3, 2	0	20	1/1	M

Description:

This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 1.

Not relevant:

No transformation

Related to:

MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB, if no transformation is active.

References:

/FB/, K2, "Coordinate Systems, Axis Types, Axis Configurations, Workpiece-Related Actual Value System, External Work Offset"

2.3 Channel-specific machine data

24130	TRAFO_INCLUDES_TOOL_1		C07	-		
-	Tool handling with 1st active transformation		BOOLEAN	NEW CONF		
-						
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TR UE...	-	-	1/1	U

Description: This machine data states for each channel whether the tool is handled during the 1st transformation or externally.
 This machine data is evaluated only with specific transformations.
 It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation. In standard transformations, only the "inclined-axis transformation" fulfills this condition.
 If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
 The method of operation of protection zones and working area limitations varies correspondingly.

24200	TRAFO_TYPE_2		C07	F2,M1		
-	Definition of the 2nd transformation in the channel		DWORD	NEW CONF		
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	U

Description: This MD states the second available transformation in each channel. Same as TRAFO_TYPE_1, but for the second available transformation in the channel.
 References:
 /FB/, F2, "5-Axis Transformation"

24210	TRAFO_AXES_IN_2		C07	F2,M1		
-	Axis assignment for transformation 2		BYTE	NEW CONF		
-						
-	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	U

Description: TRAFO_AXES_IN_2 (n)
 Axis assignment at input of 2nd to 8th transformation.
 Same meaning as for TRAFO_AXES_IN_1.

24220	TRAFO_GEOAX_ASSIGN_TAB_2		C07	F2,M1		
-	Assignment of geometry axes to channel axes for transformation 2		BYTE	NEW CONF		
-						
-	3	0, 0...	0	20	1/1	U

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 2.
 Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24230	TRAFO_INCLUDES_TOOL_2		C07	-		
-	Tool handling with active 2nd transformation		BOOLEAN	NEW CONF		
-						
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	U

Description: This machine data states for each channel whether the tool is handled during the 2nd transformation or externally.
This machine data is evaluated only with specific transformations.
It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation. In standard transformations, only "inclined-axis transformation" fulfills this condition.
If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
The method of operation of protection zones and working area limitations varies correspondingly.

24300	TRAFO_TYPE_3		C07	M1		
-	Definition of the 3rd transformation in the channel		DWORD	NEW CONF		
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M

Description: This MD states the third available transformation in each channel.
Same as TRAFO_TYPE_1, but for the third available transformation in the channel.
References:
/FB/, F2, "5-Axis Transformation"

2.3 Channel-specific machine data

24310	TRAFO_AXES_IN_3			C07	M1	
-	Axis assignment for transformation 3			BYTE	NEW CONF	
-						
828d-me41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-te61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M

Description: Axis assignment at the input point of the 3rd transformation in the channel. Meaning is the same as TRAFO_AXES_IN_1, but for the third available transformation in the channel.

24320	TRAFO_GEOAX_ASSIGN_TAB_3			C07	M1	
-	Assignment of geometry axes to channel axes for transformation 3			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 3. Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24330	TRAFO_INCLUDES_TOOL_3		C07	-		
-	Tool handling with active 3rd transformation		BOOLEAN	NEW CONF		
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M

Description:

This machine data states for each channel whether the tool is handled during the 3rd transformation or externally.

This machine data is evaluated only with specific transformations.

It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation. In standard transformations, only "inclined-axis transformation" fulfills this condition.

If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).

The method of operation of protection zones and working area limitations varies correspondingly.

24420	TRAFO_GEOAX_ASSIGN_TAB_4			C07	M1	
-	Assignment of geometry axes to channel axes for transformation 4			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 4.
Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24426	TRAFO_INCLUDES_TOOL_4			C07	-	
-	Tool handling with active 4th transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M

Description: This machine data states for each channel whether the tool is handled during the 4th transformation or externally.
This machine data is evaluated only with specific transformations.
It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation. In standard transformations, only "inclined-axis transformation" fulfills this condition.
If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
The method of operation of protection zones and working area limitations varies correspondingly.

Machine data

2.3 Channel-specific machine data

24430	TRAFO_TYPE_5	C07		M1	
-	Type of transformation 5 in the channel	DWORD		NEW CONF	
-					
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0 S
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0 S
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0 S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1 M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1 M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1 M

Description: Type of transformation available as the fifth in the channel. See MD24100 \$MC_TRAFO_TYPE_1 for explanation.

24432	TRAFO_AXES_IN_5	C07		F2	
-	Axis assignment for transformation 5	BYTE		NEW CONF	
-					
828d-me41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0 S
828d-me61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0 S
828d-me81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0 S
828d-te61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1 M
828d-te81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1 M
828d-te41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0 S

Description: Axis assignment at the input point of the 5th transformation. See TRAFO_AXES_IN_1 for explanation.

24434	TRAFO_GEOAX_ASSIGN_TAB_5			C07	M1	
-	Assignment of geometry axes to channel axes for transformation 5			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 5.
Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24436	TRAFO_INCLUDES_TOOL_5			C07	-	
-	Tool handling with active 5th transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S

Description: This machine data states for each channel whether the tool is handled during the 5th transformation or externally.
This machine data is evaluated only with specific transformations.
It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation.
In standard transformations, only "inclined-axis transformation" fulfills this condition.
If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
The method of operation of protection zones and working area limitations varies correspondingly.

24440	TRAFO_TYPE_6	C07	-			
-	Type of transformation 6 in the channel	DWORD	NEW CONF			
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S

Description: Type of transformation available as the sixth in the channel. See MD24100 \$MC_TRAFO_TYPE_1 for explanation.

24442	TRAFO_AXES_IN_6	C07	-			
-	Axis assignment for transformation 6	BYTE	NEW CONF			
-						
828d-me41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-te61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S

Description: Axis assignment at the input point of the 6th transformation. See TRAFO_AXES_IN_1 for explanation.

24444	TRAFO_GEOAX_ASSIGN_TAB_6			C07	-	
-	Assignment of geometry axes to channel axes for transformation 6			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	7/7	M

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 6.
Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24446	TRAFO_INCLUDES_TOOL_6			C07	-	
-	Tool handling with active 6th transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S

Description: This machine data states for each channel whether the tool is handled during the 6th transformation or externally.
This machine data is evaluated only with specific transformations.
It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation.
In standard transformations, only "inclined-axis transformation" fulfills this condition.
If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
The method of operation of protection zones and working area limitations varies correspondingly.

24450	TRAFO_TYPE_7			C07	-	
-	Type of transformation 7 in the channel			DWORD	NEW CONF	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S

Description: Type of transformation available as the seventh in the channel. See MD24100 \$MC_TRAFO_TYPE_1 for explanation.

24452	TRAFO_AXES_IN_7			C07	-	
-	Axis assignment for transformation 7			BYTE	NEW CONF	
-						
828d-me41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-te61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S

Description: Axis assignment at the input point of the 7th transformation. See TRAFO_AXES_IN_1 for explanation.

24454	TRAFO_GEOAX_ASSIGN_TAB_7			C07	-	
-	Assignment of geometry axes to channel axes for transformation 7			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 7.
Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24456	TRAFO_INCLUDES_TOOL_7			C07	-	
-	Tool handling with active 7th transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S

Description: This machine data states for each channel whether the tool is handled during the 7th transformation or externally.
This machine data is evaluated only with specific transformations.
It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation.
In standard transformations, only "inclined-axis transformation" fulfills this condition.
If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).
The method of operation of protection zones and working area limitations varies correspondingly.

24460	TRAFO_TYPE_8			C07	F2,TE4,M1	
-	Type of transformation 8 in the channel			DWORD	NEW CONF	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	0/0	S

Description: Type of transformation available as the eighth in the channel. See MD24100 \$MC_TRAFO_TYPE_1 for explanation.

24462	TRAFO_AXES_IN_8			C07	F2	
-	Axis assignment for transformation 8			BYTE	NEW CONF	
-						
828d-me41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-me81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S
828d-te61	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te81	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	20	1, 2, 3, 4, 5, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	0/0	S

Description: Axis assignment at the input point of the 8th transformation. See TRAFO_AXES_IN_1 for explanation.

24464	TRAFO_GEOAX_ASSIGN_TAB_8			C07	-	
-	Assignment of geometry axes to channel axes for transformation 8			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	7/7	M

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 8.

Otherwise the meaning corresponds to TRAFO_GEOAX_ASSIGN_TAB_1.

24466	TRAFO_INCLUDES_TOOL_8			C07	-	
-	Tool handling with 8th active transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	0/0	S

Description: This machine data states for each channel whether the tool is handled during the 8th transformation or externally.

This machine data is evaluated only with specific transformations.

It is evaluated on the condition that the orientation of the tool with reference to the Basic Coordinate System cannot be changed by the transformation. In standard transformations, only "inclined-axis transformation" fulfills this condition.

If this machine data is set, the Basic Coordinate System (BCS) refers to the tool reference point even with active transformations. Otherwise, it refers to the tool tip (Tool Center Point - TCP).

The method of operation of protection zones and working area limitations varies correspondingly.

24474	TRAFO_GEOAX_ASSIGN_TAB_9			C07	-	
-	Assignment of geometry axes to channel axes for transformation 9			BYTE	NEW CONF	
-						
828d-me41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-me81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S
828d-te61	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te81	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	1/1	M
828d-te41	3	0, 0, 0,0, 0, 0,0, 0, 0,0, 0, 0...	0	20	0/0	S

Description: This MD states the channel axes on which the axes of the cartesian coordinate system are mapped for active transformation 9.

24476	TRAFO_INCLUDES_TOOL_9			C07	-	
-	Treatment of tool with active 9th transformation			BOOLEAN	NEW CONF	
-						
828d-me41	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	0/0	S
828d-me61	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	0/0	S
828d-me81	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	0/0	S
828d-te61	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	1/1	M
828d-te81	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	1/1	M
828d-te41	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-	-	0/0	S

Description: Same as TRAFO_INCLUDES_TOOL_1, but for the 9th transformation.

2.3 Channel-specific machine data

24700	TRAANG_ANGLE_1			C07	M1	
degrees	Angle between Cartesian axis and real (inclined) axis			DOUBLE	NEW CONF	
-						
828d-me41	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	-1/7	M
828d-me61	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	-1/7	M
828d-me81	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	-1/7	M
828d-te61	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	0/0	S
828d-te81	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	1/1	M
828d-te41	-	0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0,0.0...	-	-	-1/7	M

Description: Indicates for the first agreed TRAANG transformation of the channel the angle of the inclined axis in degrees between the 1st machine axis and the 1st basic axis while TRAANG is active. The angle is measured positively clockwise.

Related to:

MD24750 \$MC_TRAANG_ANGLE_2

24710	TRAANG_BASE_TOOL_1			C07	M1	
mm	Vector of base tool for 1st TRAANG transformation			DOUBLE	NEW CONF	
-						
828d-me41	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	-1/7	M
828d-me61	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	-1/7	M
828d-me81	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	-1/7	M
828d-te61	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	0/0	S
828d-te81	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	1/1	M
828d-te41	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	-1/7	M

Description: Indicates a basic offset of the tools zero for the 1st TRAANG transformation. The offset is referenced to the geometry axes valid when TRAANG is active. The basic offset is included with and without selection of the tool length compensation. Programmed length corrections have an additive effect with respect to the basic tool.

The index *i* takes the values 0, 1, 2 for the 1st to 3rd geometry axes.

Related to:

MD24760 \$MC_TRAANG_BASE_TOOL_2

24720	TRAANG_PARALLEL_VELO_RES_1		C07	M1		
-	Velocity margin for 1st TRAANG transformation		DOUBLE	NEW CONF		
-						
828d-me41	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	-1/7	M
828d-me61	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	-1/7	M
828d-me81	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	-1/7	M
828d-te61	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	0/0	S
828d-te81	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	1/1	M
828d-te41	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	0.0	1.0	-1/7	M

Description:

Indicates the axis velocity reserve for jog, positioning and oscillating movements for each channel for the first TRAANG transformation which is held ready on the parallel axis (see MD2.... \$MC_TRAFO_AXES_IN_...[1]) for the compensating movement.

Velocity reserve to be provided for jog, positioning and oscillating movements on the parallel axis to handle the compensating movement as a consequence of the inclined axis.

0.0 means that the control or the transformation itself determines the reserve according to the angle of the inclined axis and the velocity capacity of the inclined and parallel axes. - The criterion for this is that the same velocity limit has to be maintained in the direction of the parallel axis and the (virtual) axis at right-angles to it.

>0.0 means that a fixed reserve has been set (MD24720 \$MC_TRAANG_PARALLEL_VELO_RES_1 * MD32000 \$MA_MAX_AX_VELO of the parallel axis). The velocity capacity in the virtual axis is determined by this. The lower MD24720 \$MC_TRAANG_PARALLEL_VELO_RES_1 has been set, the lower it is

Related to:

MD24771 \$MC_TRAANG_PARALLEL_ACCEL_RES_2

24760	TRAANG_BASE_TOOL_2			C07	M1	
mm	Vector of base tool for 2nd TRAANG transformation			DOUBLE	NEW CONF	
-						
828d-me41	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	-1/7	M
828d-me61	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	-1/7	M
828d-me81	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	-1/7	M
828d-te61	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	0/0	S
828d-te81	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	1/1	M
828d-te41	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	-1/7	M

Description: Indicates a basic offset of the tools zero for the 2nd TRAANG transformation. The offset is referenced to the geometry axes valid when TRAANG is active. The basic offset is included with and without selection of the tool length compensation. Programmed length corrections have an additive effect with respect to the basic tool.

The index i takes the values 0, 1, 2 for the 1st to 3rd geometry axes.

Related to:

MD24710 \$MC_TRAANG_BASE_TOOL_1

24770	TRAANG_PARALLEL_VELO_RES_2			C07	M1	
-	Velocity margin for 2nd TRAANG transformation			DOUBLE	NEW CONF	
-						
828d-me41	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	-1/7	M
828d-me61	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	-1/7	M
828d-me81	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	-1/7	M
828d-te61	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	0/0	S
828d-te81	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	1/1	M
828d-te41	-	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	0.0	1.0	-1/7	M

Description: Indicates the axis velocity reserve for jog, positioning and oscillating movements for each channel for the second TRAANG transformation which is held ready on the parallel axis (see MD2.... \$MC_TRAFO_AXES_IN_...[1]) for the compensating movement.

Related to:

MD24771 \$MC_TRAANG_PARALLEL_ACCEL_RES_2

2.3 Channel-specific machine data

24855	TRACYL_ROT_AX_FRAME_2		C07	M1,K2	
-	Rotary axis offset TRACYL 2		BYTE	NEW CONF	
-					
-	-	2	0	2	1/1 U

Description: 0: axial rotary axis offset is not considered.
 1: axial rotary axis offset is considered.
 2: axial rotary axis offset is considered until SZS.
 SZS frames include transformed axial rotary axis offsets.

24858	TRACYL_DEFAULT_MODE_2		C07	M1	
-	TRACYL mode selection		BYTE	NEW CONF	
-					
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	1	1/1 U

Description: Default setting of TRACYL type 514 for the 2nd TRACYL:
 0: without groove side offset (i.e. TRACYL type 514 - equals 512)
 1: with groove side offset (i.e. TRACYL type 514 - equals 513)
 MD2.... \$MC_TRAFO_TYPE... = 514 can be used to decide, via the selection parameters, whether calculation is made with or without groove side offset. The parameter defines the variable to be selected if no selection is made in the call parameters.
 If MD24858 \$MC_TRACYL_DEFAULT_MODE_2 = 1, it is sufficient to program TRACYL(30,2) in the part program instead of TRACYL(30,2,1).

24860	TRACYL_ROT_SIGN_IS_PLUS_2		C07	-	
-	Sign of rotary axis for 2nd TRACYL transformation		BOOLEAN	NEW CONF	
-					
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE	-	-	1/1 U

Description: Indicates the sign with which the rotary axis is taken into account in the TRACYL transformation for the 2nd agreed TRACYL transformation for each channel.
 Related to:
 MD24810 \$MC_TRACYL_ROT_SIGN_IS_PLUS_1

24870	TRACYL_BASE_TOOL_2		C07	M1	
mm	Vector of base tool for 2nd TRACYL transformation		DOUBLE	NEW CONF	
-					
-	3	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0...	-	-	1/1 U

Description: Indicates a basic offset of the tools zero for the 2nd TRACYL transformation. The offset is referenced to the geometry axes valid when TRACYL is active. The basic offset is included with and without selection of the tool length compensation. Programmed length corrections have an additive effect with respect to the basic tool.
 The index i takes the values 0, 1, 2 for the 1st to 3rd geometry axes.
 Related to:
 MD24820 \$MC_TRACYL_BASE_TOOL_1

24900	TRANSMIT_ROT_AX_OFFSET_1	C07	M1
degrees	Offset of rotary axis for the 1st TRANSMIT transformation	DOUBLE	NEW CONF
-			
-	-	0.0,0.0,0.0,0.0,0.0,0.0, 0.0,0.0,0.0...	-
-	-	-	-
-	-	1/1	U

Description: Indicates the offset of the rotary axis for the first agreed TRANSMIT transformation in degrees in relation to the neutral position while TRANSMIT is active.

Related to:

MD24950 \$MC_TRANSMIT_ROT_AX_OFFSET_2

24905	TRANSMIT_ROT_AX_FRAME_1	C07	M1,K2
-	Rotary axis offset TRANSMIT 1	BYTE	NEW CONF
-			
-	-	2	0
-	-	2	1/1
-	-		U

Description: 0: axial rotary axis offset is not considered.

1: axial rotary axis offset is considered.

2: axial rotary axis offset is considered until SZS.

SZS frames include transformed rotations around the rotary axis.

24910	TRANSMIT_ROT_SIGN_IS_PLUS_1	C07	M1
-	Sign of rotary axis for 1st TRANSMIT transformation	BOOLEAN	NEW CONF
-			
-	-	TRUE,TRUE,TRUE,T RUE,TRUE,TRUE,TR UE...	-
-	-	-	-
-	-	1/1	U

Description: Indicates the sign with which the rotary axis is taken into account in the TRANSMIT transformation for the first agreed TRANSMIT transformation for each channel.

Related to:

MD24960 \$MC_TRANSMIT_ROT_SIGN_IS_PLUS_2

24911	TRANSMIT_POLE_SIDE_FIX_1			C07	M1	
-	Restriction of working range in front of / behind the pole, 1. TRANSMIT			BYTE	NEW CONF	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	2	1/1	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	2	1/1	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	2	1/1	M
828d-te61	-	1	0	2	1/1	M
828d-te81	-	1	0	2	1/1	M
828d-te41	-	1	0	2	1/1	M

Description: Restriction of the working area in front of/behind pole or no restriction, i.e. traversal through the pole.

The assigned values have the following meanings:

- 1: Working area of linear axis for positions ≥ 0 ,
(if tool length compensation parallel to linear axis equals 0)
- 2: Working area of linear axis for positions ≤ 0 ,
(if tool length compensation parallel to linear axis equals 0)
- 0: No restriction of working area. Traversal through pole.

24920	TRANSMIT_BASE_TOOL_1			C07	M1	
mm	Vector of base tool for 1st TRANSMIT transformation			DOUBLE	NEW CONF	
-						
-	3	0,0...	-	-	1/1	U

Description: Indicates a basic offset of the tools zero for the 1st TRANSMIT transformation. The offset is referenced to the geometry axes valid when TRANSMIT is active. The basic offset is included with and without selection of the tool length compensation. Programmed length corrections have an additive effect with respect to the basic tool.

The index i takes the values 0, 1, 2 for the 1st to 3rd geometry axes.

Related to:

MD24970 \$MC_TRANSMIT_BASE_TOOL_2

24950	TRANSMIT_ROT_AX_OFFSET_2			C07	M1	
degrees	Offset of rotary axis for the 2nd TRANSMIT transformation			DOUBLE	NEW CONF	
-						
-	-	0,0...	-	-	1/1	U

Description: Indicates the offset of the rotary axis for the second agreed TRANSMIT transformation in degrees in relation to the neutral position while TRANSMIT is active.

Related to:

MD24900 \$MC_TRANSMIT_ROT_AX_OFFSET_1

24955	TRANSMIT_ROT_AX_FRAME_2			C07	M1	
-	Rotary axis offset TRANSMIT 2			BYTE	NEW CONF	
-						
-	-	2	0	2	1/1	U

Description:

- 0: axial rotary axis offset is not considered.
- 1: axial rotary axis offset is considered.
- 2: axial rotary axis offset is considered until SZS.

SZS frames include transformed rotations around the rotary axis.

24960	TRANSMIT_ROT_SIGN_IS_PLUS_2			C07	M1	
-	Sign of rotary axis for 2nd TRANSMIT transformation			BOOLEAN	NEW CONF	
-						
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	-	-	1/1	U

Description: Indicates the sign with which the rotary axis is taken into account in the TRANSMIT transformation for the second agreed TRANSMIT transformation for each channel.

Related to:
MD24910 \$MC_TRANSMIT_ROT_SIGN_IS_PLUS_1

24961	TRANSMIT_POLE_SIDE_FIX_2			C07	M1	
-	Restriction of working range before/behind the pole, 2. TRANSMIT			BYTE	NEW CONF	
-						
828d-me41	-	0,0	0	2	1/1	M
828d-me61	-	0,0	0	2	1/1	M
828d-me81	-	0,0	0	2	1/1	M
828d-te61	-	1	0	2	1/1	M
828d-te81	-	1	0	2	1/1	M
828d-te41	-	1	0	2	1/1	M

Description: Restriction of working area in front of/behind pole or no restriction, i.e. traversal through pole.

The assigned values have the following meanings:

- 1: Working area of linear axis for positions ≥ 0 ,
(if tool length compensation parallel to linear axis equals 0)
- 2: Working area of linear axis for positions ≤ 0 ,
(if tool length compensation parallel to linear axis equals 0)
- 0: No restriction of working area. Traversal through pole.

2.3 Channel-specific machine data

Transformations cannot be concatenated with one another at will.

The following limitations apply in SW version 5:

The first transformation in the chain must be an orientation transformation (3- , 4- , 5-axis transformation, nutator) transmit or peripheral curve transformation.

The second transformation must be an inclined axis transformation.

No more than two transformations may be concatenated.

24997	TRACON_CHAIN_3			C07	M1	
-	Transformation grouping			DWORD	NEW CONF	
-						
828d-me41	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-me61	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-me81	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-te61	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-te81	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M

Description: Transformation chain of the third concatenated transformation.
See TRACON_CHAIN_1 for documentation.

24998	TRACON_CHAIN_4			C07	M1	
-	Transformation grouping			DWORD	NEW CONF	
-						
828d-me41	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-me61	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-me81	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-te61	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M
828d-te81	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	1/1	M
828d-te41	4	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0...	0	20	-1/7	M

Description: Transformation chain of the fourth concatenated transformation.
See TRACON_CHAIN_1 for documentation.

2.3 Channel-specific machine data

27100	ABSBLOCK_FUNCTION_MASK			N01	K1,P1	
-	Parameterize basic blocks with absolute values			DWORD	PowerOn	
-						
828d-me41	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x1	1/1	M
828d-me61	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x1	1/1	M
828d-me81	-	0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0...	0	0x1	1/1	M
828d-te61	-	0x1	0	0x1	1/1	M
828d-te81	-	0x1	0	0x1	1/1	M
828d-te41	-	0x1	0	0x1	1/1	M

Description: Parameterization of the "basic blocks with absolute values" function
 Bit 0 = 1 :
 The position values of the transverse axis are always displayed as diameter values.
 Transverse axes can be applied using MD20100 \$MC_DIAMETER_AX_DEF or MD30460 \$MA_BASE_FUNCTION_MASK, bit 2.

27400	OEM_CHAN_INFO			A01, A11	-	
-	OEM version information			STRING	PowerOn	
-						
-	3	, , , , , , , , , ,	-	-	2/2	M

Description: A version information freely available to the user
 (is indicated in the version screen)

27850	PROG_NET_TIMER_MODE			C09	-	
-	Impact of the program runtime net counter			DWORD	Reset	
-						
-	-	0x01	0x00	0x03	7/2	M

Description: The program run time is measured using system variables and can be read out. It provides a means of outputting the current progress of the processing of a part program. This MD can be used to make the following settings on a channel-specific basis:
 Bit 0 = 0
 \$SAC_ACT_PROG_NET_TIME is not deleted on a jump to the start of the program with GOTOS
 Bit 0 = 1
 \$SAC_ACT_PROG_NET_TIME is deleted on a jump to the start of the program with GOTOS, the value is saved in \$SAC_OLD_PROG_NET_TIMES, and the program counter \$SAC_OLD_PROG_NET_TIME_COUNT is incremented.
 Bit 1 = 0
 \$SAC_ACT_PROG_NET_TIME ceases to be increased if override = 0 is set; in other words, the program run time is measured without the time for which the override was set to 0.
 Bit 1 = 1
 \$SAC_ACT_PROG_NET_TIME is increased if override = 0; in other words, the program run time is measured with the time for which the override was set to 0.

2.3 Channel-specific machine data

Bits 2 to 31
Reserved

27860	PROCESSTIMER_MODE	C09	K1
-	Activation and impact of program runtime measurement	DWORD	Reset
-			
-	-	0x173	0
		0x7FF	1/1
			M

Description: Timers are provided as system variables under the function program runtime. While the NCK-specific timers are always activated (for time measurements since the last control power on), the channel-specific timers have to be started via this machine data.

Meaning:

Bit 0 = 0

No measurement of total operating time for any part program

Bit 0 = 1

Measurement of total operating time is active for all part programs (\$AC_OPERATING_TIME)

Bit 1 = 0

No measurement of current program runtime

Bit 1 = 1

Measurement of current program runtime is active (\$AC_CYCLE_TIME)

Bit 2 = 0

No measurement of tool operating time

Bit 2 = 1

Measurement of tool operating time is active (\$AC_CUTTING_TIME)

Bit 3

Reserved

Bits 4,5 only when bit 0, 1, 2 = 1:

Bit 4 = 0 No measurement with active dry run feed

Bit 4 = 1 Measurement also with active dry run feed

Bit 5 = 0 No measurement with program test

Bit 5 = 1 Measurement also with program test

Bit 6 only when Bit 1 = 1:

Bit 6 = 0

Delete \$AC_CYCLE_TIME also with start by ASUB and PROG_EVENTS

Bit 6 = 1

\$AC_CYCLE_TIME is not deleted on start by ASUB and PROG_EVENTS.

Bit 7 only when bit 2 = 1:

Bit 7 = 0 \$AC_CUTTING_TIME counts only with active tool

Bit 7 = 1 \$AC_CUTTING_TIME counts irrespective of tool

Bits 8 only when bit 1 = 1

Bit 8 = 0

\$AC_CYCLE_TIME is not deleted on jumping to program start with GOTOS

Bit 8 = 1

\$AC_CYCLE_TIME is deleted on jumping to program start with GOTOS.

Bit 9 only when bits 0, 1 = 1:

Bit 9 = 0

\$AC_OPERATING_TIME, \$AC_CYCLE_TIME: No measurement with override = 0.

Bit 9 = 1

\$AC_OPERATING_TIME, \$AC_CYCLE_TIME: Measurement also with override = 0.

Bits 10 to 31

Reserved

27880	PART_COUNTER	C09	K1
-	Activation of workpiece counter	DWORD	Reset
-			
-	-	0x901	0
		0x0FFFF	1/1
			M

Description:

The part counters can be configured with this machine data.

Note: with bit 0 = 1 and \$AC_REQUIRED_PARTS smaller than 0 all workpiece counts

activated in this MD are frozen at the status reached.

Meaning of the individual bits:

Bits 0 - 3:Activating \$AC_REQUIRED_PARTS

 Bit 0 = 1:Counter \$AC_REQUIRED_PARTS is activated

Further significance of bits 1-3 only when bit 0 =1 and \$AC_REQUIRED_PARTS > 0:

Bit 1 = 0:Alarm/VDI output if \$AC_ACTUAL_PARTS corresponds to \$AC_REQUIRED_PARTS

Bit 1 = 1:Alarm/VDI output if \$AC_SPECIAL_PARTS corresponds to \$AC_REQUIRED_PARTS

Bit 2Reserved!

Bit 3Reserved!

Bits 4 - 7:Activating \$AC_TOTAL_PARTS

 Bit 4 = 1:Counter \$AC_TOTAL_PARTS is active

Further meaning of bits 5-7 only when bit 4 =1 and \$AC_REQUIRED_PARTS > 0:

Bit 5 = 0:Counter \$AC_TOTAL_PARTS is incremented by 1 with a VDI output of M02/M30

Bit 5 = 1:Counter \$AC_TOTAL_PARTS is incremented by 1 with output of the M command from MD PART_COUNTER_MCODE[0]

Bit 6 = 0:\$AC_TOTAL_PARTS also active with program test/block search

Bit 7 = 1:counter \$AC_TOTAL_PARTS is incremented by 1 when jumping back with GOTOS

Bits 8 - 11:Activating \$AC_ACTUAL_PARTS

 Bit 8 = 1:Counter \$AC_ACTUAL_PARTS is active

Further significance of bits 9-11 only when bit 8 =1 and \$AC_REQUIRED_PARTS > 0:

Bit 9 = 0:Counter \$AC_ACTUAL_PARTS is incremented by 1 with a VDI output of M02/M30

2.3 Channel-specific machine data

Bit 9 = 1:Counter \$AC_ACTUAL_PARTS is incremented by 1 with output of the M command from MD PART_COUNTER_MCODE[1]
 Bit 10 = 0:\$AC_ACTUAL_PARTS also active with program test/block search
 Bit 10 = 1:No machining \$AC_ACTUAL_PARTS with program test/block search
 Bit 11 = 1:counter \$AC_ACTUAL_PARTS is incremented by 1 when jumping bak with GOTOS
 Bit 12 - 15:Activating \$AC_SPECIAL_PARTS

 Bit 12 = 1:Counter \$AC_SPECIAL_PARTS is active
 Further significance of bits 13-15 only when bit 12 =1 and \$AC_REQUIRED_PARTS > 0:
 Bit 13 = 0:Counter \$AC_SPECIAL_PARTS is incremented by 1 with a VDI output of M02/M30
 Bit 13 = 1:Counter \$AC_SPECIAL_PARTS is incremented by 1 with output of the M command from MD PART_COUNTER_MCODE[2]
 Bit 14 = 0:\$AC_SPECIAL_PARTS also active with program test/block search
 Bit 14 = 1:No machining \$AC_SPECIAL_PARTS with program test/block search
 Bit 15 = 1:counter \$AC_SPECIAL_PARTS is incremented by 1 when jumping back with GOTOS
 Related to:
 MD27882 \$MC_PART_COUNTER_MCODE

27882	PART_COUNTER_MCODE			C09	K1	
-	Workpiece counting with user-defined M command			BYTE	PowerOn	
-						
-	3	2, 2, 2, 2, 2, 2, 2, 2, 2, 2, 2...	0	99	3/2	M

Description: If part counting is activated via MD27880 \$MC_PART_COUNTER, the count pulse can be triggered by a special M command.
 Only then are the values defined here taken into account:
 Meaning:
 The part counters are incremented by 1 in the NST signal output of the M command described, where:
 MD27882 \$MC_PART_COUNTER_MCODE[0] for \$AC_TOTAL_PARTS
 MD27882 \$MC_PART_COUNTER_MCODE[1] for \$AC_ACTUAL_PARTS
 MD27882 \$MC_PART_COUNTER_MCODE[2] for \$AC_SPECIAL_PARTS

27920	TIME_LIMIT_NETTO_INT_TASK			EXP, C01	-	
s	Runtime limit of interpreter subtask			DOUBLE	PowerOn	
-						
-	-	0.005,0.005,0.005,0.005,0.005,0.005,0.005...	0.001	0.100	7/0	S

Description: With MD27920 \$MC_TIME_LIMIT_NETTO_INT_TASK, the maximum runtime of the interpreter subtask is set. The interpreter subtask is started from the preprocessing task. If the interpreter task does not end on its own within the time set with MD27920 \$MC_TIME_LIMIT_NETTO_INT_TASK, it will be stopped and continued after a preprocessing cycle.

28010	MM_NUM_REORG_LUD_MODULES	EXP, C02	V2,K1			
-	Number of blocks for local user variables in REORG (DRAM)	DWORD	PowerOn			
-						
-	-	30	0	SLMAXNUMBE ROF_USERMO DULES	1/1	M

Description: Defines the number of additional LUD data blocks available for the function REORG (see Description of Functions, Channels, Mode Groups, Program Operation (K1)).

This value can be 0 if the function REORG is not used. The CNC always opens 12 LUD data blocks, of which 8 are used for NC programs and 4 for the ASUBs.

An LUD data block is needed for each NC program and ASUB in which a local user variable is defined. This value may have to be increased for the function REORG if a large IPO buffer is present and a large number of short NC programs in which LUD variables are defined are active (prepared NC blocks of the programs are located in the IPO buffer).

An LUD data block is needed for each of these programs. The size of the reserved memory is affected by the number of LUDs per NC program and their individual memory requirements. The LUD data blocks are stored in the dynamic memory.

The memory requirement for managing the blocks for local user variables with REORG can be determined as follows:

The size of the LUD blocks depends on the number of active LUDs and their data type. The memory for the LUD blocks is limited by the MD28000 \$MC_MM_REORG_LOG_FILE_MEM (memory size for REORG).

28020	MM_NUM_LUD_NAMES_TOTAL	C02	V2,K1			
-	Number of local user variables (DRAM)	DWORD	PowerOn			
-						
-	-	2000,2000,2000,2000, 2000,2000,2000...	0	32000	1/1	M

Description: Defines the number of variables for the local user data (LUD) which are permitted to exist in the active sections of the program. Approximately 150 bytes of memory per variable are reserved for the names of the variables and the variable values. The memory required for the variable value is equal to the size of the data type. If the total of the local user variables from the active main program and the related subprograms is larger than the defined limit, the variables which are over the limit are not accepted during execution of the program. Dynamic memory is used for the variable names and variable values.

Overview of the memory used by the data types:

Data type	Memory used
REAL	8 bytes
INT	4 bytes
BOOL	1 byte
CHAR	1 byte
STRING	1 byte per character, 200 characters per string are possible
AXIS	4 bytes
FRAME	400 bytes

2.3 Channel-specific machine data

28040	MM_LUD_VALUES_MEM			C02	V2,K1	
-	Memory space for local user variables (DRAM)			DWORD	PowerOn	
-						
-	-	250,250,250,250,250, 250,250,250,250...	0	32000	1/1	M

Description: This MD defines the amount of memory space available for LUD variables. The maximum number of available LUDs is given by one of the limit values of MD28020 \$MC_MM_NUM_LUD_NAMES_TOTAL or MD28040 \$MC_MM_LUD_VALUES_MEM. The memory defined here is subdivided into $(MD28040 \$MC_MM_LUD_VALUES_MEM * 1024) / MD18242 \$MN_MM_MAX_SIZE_OF_LUD_VALUE$ blocks, and allocated to part programs which request memory. Each part program that contains at least one definition of an LUD variable or call parameters uses at least one such block.

It should be remembered that several part programs requiring memory can be open simultaneously in the NCK. The number depends on the type of programming, the program length, and the size of the internal NCK block memory upwards of $(MD28060 \$MC_MM_IPO_BUFFER_SIZE, MD28070 \$MC_MM_NUM_BLOCKS_IN_PREP)$.

Related to:

MD28020 \$MC_MM_NUM_LUD_NAMES_TOTAL
(number of local user variables (DRAM))

28060	MM_IPO_BUFFER_SIZE			C02	B1,K1	
-	Number of NC blocks in IPO buffer (DRAM)			DWORD	PowerOn	
-						
828d-me41	-	150	2	250	1/1	M
828d-me61	-	150	2	250	1/1	M
828d-me81	-	150	2	250	1/1	M
828d-te61	-	10	2	250	1/1	M
828d-te81	-	10	2	250	1/1	M
828d-te41	-	10	2	250	1/1	M

Description: Defines the number of blocks for the interpolation buffer. This buffer contains prepared NC blocks available for the interpolation. A number of kbytes of the dynamic user memory are reserved for each NC block. The data also limits the number of blocks for look ahead consideration of speed limitation for the LookAhead function.

MD28060 \$MC_MM_IPO_BUFFER_SIZE is set by the system.

Related to:

MD28070 \$MC_MM_NUM_BLOCKS_IN_PREP
(number of blocks for block preparation)

28070	MM_NUM_BLOCKS_IN_PREP	EXP, C02	B1,K1
-	Number of blocks for block preparation (DRAM)	DWORD	PowerOn
-			
-	-	80	65
-	-	500	1/1
-	-		M

Description: Defines the number of NC blocks available for NC block preparation. This figure is determined mainly by the system software and is used largely for optimization. Approximately 10 Kbytes of dynamic memory is reserved per NC block. Related to:

MD28060 \$MC_MM_IPO_BUFFER_SIZE
(number of NC blocks with IPO buffer)

28082	MM_SYSTEM_FRAME_MASK	C02	M5,K2,W1
-	System frames (SRAM)	DWORD	PowerOn
-			
828d-me41	-	0xFFD	0
828d-me61	-	0xFFD	0
828d-me81	-	0xFFD	0
828d-te61	-	0xFE1	0
828d-te81	-	0xFE1	0
828d-te41	-	0xFE1	0

Description: Bit mask for configuring channel-specific system frames included in the channel.

Bit 0: System frame for setting actual value and scratching
 Bit 1: System frame for external work offset
 Bit 2: System frame for TCARR and PAROT
 Bit 3: System frame for TOROT and TOFRAME
 Bit 4: System frame for workpiece reference points
 Bit 5: System frame for cycles
 Bit 6: System frame for transformations
 Bit 7: System frame \$P_ISO1FR for ISO G51.1 Mirror
 Bit 8: System frame \$P_ISO2FR for ISO G68 2DROT
 Bit 9: System frame \$P_ISO3FR for ISO G68 3DROT
 Bit 10: System frame \$P_ISO4FR for ISO G51 Scale
 Bit 11: System frame \$P_RELFR for relative coordinate systems

2.3 Channel-specific machine data

28083	MM_SYSTEM_DATAFRAME_MASK			C02	-	
-	System frames (SRAM)			DWORD	PowerOn	
-						
828d-me41	-	0xF9D	0	0x00000FFF	1/0	S
828d-me61	-	0xF9D	0	0x00000FFF	1/0	S
828d-me81	-	0xF9D	0	0x00000FFF	1/0	S
828d-te61	-	0xF81	0	0x00000FFF	1/0	S
828d-te81	-	0xF81	0	0x00000FFF	1/0	S
828d-te41	-	0xF81	0	0x00000FFF	1/0	S

Description: Bit mask for configuring channel-specific system frames in the data storage (SRAM).

Bit 0: System frame for setting actual value and scratching
 Bit 1: System frame for external work offset
 Bit 2: System frame for TCARR and PAROT
 Bit 3: System frame for TOROT and TOFRAME
 Bit 4: System frame for workpiece reference points
 Bit 5: System frame for cycles
 Bit 6: System frame for transformations
 Bit 7: System frame \$P_ISO1FR for ISO G51.1 Mirror
 Bit 8: System frame \$P_ISO2FR for ISO G68 2DROT
 Bit 9: System frame \$P_ISO3FR for ISO G68 3DROT
 Bit 10: System frame \$P_ISO4FR for ISO G51 Scale
 Bit 11: System frame \$P_RELFR for relative coordinate systems

28180	MM_MAX_TRACE_DATAPOINTS			EXP, C02, C06	-	
-	Length of the trace data buffer			DWORD	PowerOn	
NBUP						
-	-	100,100,100,100,100, 100,100,100,100...	0	20000	1/1	M

Description: MM_MAX_TRACE_DATAPOINTS defines the size of an internal data buffer which contains the trace recordings.

28240	MM_NUM_SYNC_DIAG_ELEMENTS			N05, C02	-	
-	Number of diagnostic elements for expressions in synchronized actions			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	32000	2/2	M

Description: The values of the variables and machine data during diagnostics of the motion-synchronous actions are saved to memory elements for storage in the control. A motion-synchronous action uses up to the number of elements for as many variables as are set with \$MC_MAXNUM_SYNC_DIAG_VAR.

The following are assigned:

- 1 element for each variable
- 1 element for each index

They are stored as arrays.

The indices 0 - 5 have special meanings:

n= 0:

A new value is stored in the FIFO when writing with index 0.

The oldest element is read and removed from the FIFO when writing with index 0.

n=1: Access to the first element read in

n=2: Access to the last element 1 read in

n=3: Sum of all FIFO elements

n=4: Number of elements available in the FIFO

n=5: Current write index relative to FIFO start

n=6: 1st element read in

28262	START_AC_FIFO	C01	2,3,2,4,6,1		
-	FIFO variables store from R parameter	DWORD	PowerOn		
-					
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	32535	7/2 M

Description:

Number of the R parameter as from which FIFO variables are stored. All R parameters with lower numbers can be used freely in the part program. R parameters above the FIFO range cannot be written from the part program.

The number of R parameters must set via MD28050 \$MC_MM_NUM_R_PARAM so that all FIFI variables can be accommodated from the start of the R parameters:

$$\text{MD28050 } \$\text{MC_MM_NUM_R_PARAM} = \text{MD28262 } \$\text{MC_START_AC_FIFO} + \text{MD28260 } \$\text{MC_NUM_AC_FIFO} * (\text{MD28264 } \$\text{MC_LEN_AC_FIFO} + 6)$$

The FIFO variables bear the names \$AC_FIFO1 to \$AC_FIFO n . They are stored as arrays.

The indices 0 - 5 have special meanings:

n= 0:

A new value is stored in the FIFO when writing with index 0.

The oldest element is read and removed from the FIFO when reading with index 0.

n=1: Access to the first element read in

n=2: Access to the last element read in

n=3: Sum of all FIFO elements

n=4: Number of elements available in the FIFO

n=5: Current write index relative to FIFO start

Related to:

MD28260 \$MC_NUM_AC_FIFO

28264	LEN_AC_FIFO	C01	2,3,2,4,6,1,M5		
-	Length of FIFO variables \$AC_FIFO1-\$AC_FIFO10	DWORD	PowerOn		
-					
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	32535	2/2 M

Description:

Length of the FIFO variables \$AC_FIFO1 to \$AC_FIFO10.

All FIFO variables are the same length.

28266	MODE_AC_FIFO			C01	2.3,2.4,6.1	
-	Mode of FIFO processing			BYTE	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0	0	-	7/2	M

Description: Mode of FIFO processing:
 Bit 0 = 1:
 The sum of all FIFO contents is updated at each write access.
 Bit 0 = 0:
 No summation
 Related to:
 MD28260 \$MC_NUM_AC_FIFO

28274	MM_NUM_AC_SYSTEM_PARAM			EXP, C02	-	
-	Number of \$AC_SYSTEM_PARAM for motion-synchronous actions			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0	0	20000	2/2	M

Description: Number of \$AC_SYSTEM_PARAM parameters for motion-synchronous actions.
 Depending on MD28255 \$MC_MM_BUFFERED_AC_PARAM, DRAM or SRAM is required.
 Reserved for SIEMENS applications.

28276	MM_NUM_AC_SYSTEM_MARKER			EXP, C02	-	
-	Number of \$AC_SYSTEM_MARKER for motion-synchronous actions			DWORD	PowerOn	
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0	0	20000	2/2	M

Description: Number of \$AC_SYSTEM_MARKER markers for motion-synchronous actions.
 Depending on MD28257 \$MC_MM_BUFFERED_AC_MARKER, DRAM or SRAM is required.
 Reserved for SIEMENS applications.

28290	MM_SHAPED_TOOLS_ENABLE			C01, C08, C02	-	
-	Enable tool radius compensation for contour tools			BOOLEAN	PowerOn	
-						
-	-	FALSE,FALSE,FALSE,FALSE,FALSE...	-	-	1/1	S

Description: The function "Tool radius compensation for contour tools" is enabled with this tool.
 Modification of this machine data will cause a reconfiguration of the memory.

28300	MM_PROTOC_USER_ACTIVE		C02	-		
-	Activation of logging for a user		BOOLEAN	PowerOn		
-						
-	10	TRUE, FALSE, FALSE, FALSE, FALSE, TRUE, TRUE, TRUE, FALSE...	-	-	1/1	M

Description: Activation of recording for a user.
The users 0 and 1, and 5 - 9 are reserved for system functions.
The users 2, 3 and 4 can be used by OEM.

28302	MM_PROTOC_NUM_ETP_STD_TYP		C02	-		
-	Number of standard event types ETP		DWORD	PowerOn		
-						
-	10	28, 0, 0, 0, 0, 20, 20, 20, 0, 3...	0	59	1/1	M

Description: Number of standard event types required in the ETP OPI block.

28520	MM_MAX_AXISPOLY_PER_BLOCK		C02	B1		
-	maximal number of axial polynomials per block		DWORD	PowerOn		
-						
-	-	3,3,3,3,3,3,3,3,3,3, 3,3,3,3	1	5	1/1	M

Description: Maximum number of axis polynomials which can be contained in a block.
In the standard case, each block only contains one polynomial per axis, i.e. this data can immediately be set to one.
Currently, more polynomials are only needed for the new ADIS function with G643.
In this case, this data must have a minimum value of three.

28530	MM_PATH_VELO_SEGMENTS		C02	A2,B1		
-	Number of memory elements for path velocity limitation		DWORD	PowerOn		
-						
828d-me41	-	5	0	100	1/1	M
828d-me61	-	5	0	100	1/1	M
828d-me81	-	5	0	100	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	100	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	100	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0, 0,0,0,0	0	100	1/1	M

Description: Number of memory elements available for limiting the path velocity and changing it in the block.
0 : Each block is limited by a maximum path velocity.

2.3 Channel-specific machine data

> 0 : If required, a profile of the permissible path velocity ; and its modification options is generated and monitored ; in the block. ; This results in a smoother axis velocity progression and ; a shorter travel time. ; MD28530 \$MC_MM_PATH_VELO_SEGMENTS defines the average ; number of segments available in the block. ; The necessary setting essentially depends ; on the requirements.

The following values are recommended:

- 3: for G643 and G644, if only geometry axes are traversed
- 5: for G643 and G644, if geometry and rotary axes are traversed
- 5: for COMPCAD
- 5: for dyn. transformation

A value that is too low this may lead to additional velocity limitations if a sufficient number of blocks cannot be made available for interpolation. MD28530 \$MC_MM_PATH_VELO_SEGMENTS additionally increases the memory requirement of dyn. Look Ahead. Values higher than 5 are only practical in exceptional cases.

3 ... 5 :
Recommended setting.

28533	MM_LOOKAH_FFORM_UNITS			C02	-	
-	Memory for extended LookAhead			DWORD	PowerOn	
-						
828d-me41	-	18	0	100000	1/1	M
828d-me61	-	18	0	100000	1/1	M
828d-me81	-	18	0	100000	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100000	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100000	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100000	1/1	M

Description: The machine data is used to configure the work memory for extended LookAhead. The MD scales the value defined internally through MD28060 \$MC_MM_IPO_BUFFER_SIZE, MD28520 \$MC_MM_MAX_AXISPOLY_PER_BLOCK, MD28530 \$MC_MM_PATH_VELO_SEGMENTS, MD28535 \$MC_MM_FEED_PROFILE_SEGMENTS, MD28540 \$MC_MM_ARCLENGTH_SEGMENTS). Its practical size depends on the part program, the block lengths, the axis dynamics, and an active kinematic transformation. The MD should only be set for those channels in which free-form surfaces are also machined.
0 : default LookAhead is active.
> 0 : extended LookAhead is active if switched on by MD20443 \$MC_LOOKAH_FFORM.
The guide value for free-form surface applications is: 18..20

28535	MM_FEED_PROFILE_SEGMENTS	C02	-			
-	Number of memory element for feed profiles	DWORD	PowerOn			
-						
-	-	1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1	1	10	1/1	M

Description: Number of memory elements available for feed profile per block. The default value 1 is adequate for a programmable feed profile (FLIN, FCUB, FPO()).

If compile cycle applications require more segments per block, this machine data must be increased accordingly.

If, for example, a feed profile is to be activated in which there is deceleration at both the beginning and the end of the block, 3 segments will be required for the feed profile in the block, i.e. this MD must have value 3.

28540	MM_ARCLENGTH_SEGMENTS	C02	B1			
-	Number of memory elements for arc length function representation	DWORD	PowerOn			
-						
828d-me41	-	10	0	100	1/1	M
828d-me61	-	10	0	100	1/1	M
828d-me81	-	10	0	100	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100	1/1	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100	1/1	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	100	1/1	M

Description: Number of memory elements available for the arc length function for parameterizing polynomials.

If this machine data is equal to zero, a fixed interval division is used to represent the arc length function. In this case, the calculated function is only tangent-continuous. This can lead to discontinuities in the axis accelerations.

If the function G643 or G644 is used for smoothing and/or COMPCAD, this MD should be assigned a value of at least 10. In this case, the calculated function also has a constant curvature which results in a smoother progression of the path velocity, as well as the axis velocities and accelerations.

Values substantially larger than 10 are only practical in exceptional cases. Not only the value of MD28540 \$MC_MM_ARCLENGTH_SEGMENTS but also that of MD20262 \$MC_SPLINE_FEED_PRECISION are crucial for the accuracy.

28560	MM_SEARCH_RUN_RESTORE_MODE	C02	K2			
-	Data restore after simulation	DWORD	PowerOn			
-						
-	-	0x1	0	0x00000001	1/1	M

Description: Bit mask to restore data after abort of a simulated program execution. The following applies:
Bit 0: All frames in the data storage are restored.

2.3 Channel-specific machine data

28600	MM_NUM_WORKAREA_CS_GROUPS	C02	-
-	Number of coordinate system-specific operating range limits	DWORD	PowerOn
-			
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	10
		0,0,0,0	2/2 M

Description: Number of data blocks in the channel that are created for coordinate system-specific operating range limits.
 It indicates the maximum value of the 1st index of system variable \$P_WORKAREA_CS...[WALimNo, Ax]. It furthermore defines the number of the programmable G functions "WALCS1, WALCS2, ... WALCS10" as well as the maximum value in system variable \$AC_WORKAREA_CS_GROUP".
 = 0: Function "Monitoring of coordinate system-specific operating range limits" cannot be activated.

2.4 Axis-specific machine data

Number	Identifier			Display filters	Reference	
Unit	Name			Data type	Active	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

30100	CTRLOUT_SEGMENT_NR			EXP, A01	G2,S9	
-	Setpoint assignment: bus segment number			BYTE	PowerOn	
-						
-	1	5	0	5	2/2	M

Description: In this MD, enter the number of the bus segment through which the output is addressed.

- 0: Local bus (for 802D MCPA, 808d, 828d analog spindle)
- 1: SIMODRIVE611D drive bus for SINUMERIK 840D/810D (1st DCM)
- 2: reserved (previously local P bus)
- 3: reserved (previously 611D bus, 2nd DCM)
- 4: reserved (virtual buses)
- 5: PROFIBUS/PROFINET (e.g. SINUMERIK 840Di)
- 6: reserved (same effect as 5)

30110	CTRLOUT_MODULE_NR			A01, A11, -	G2,S9	
-	Setpoint assignment: module number			BYTE	PowerOn	
-						
828d-me41	1	2,3,4,1,5	1	31	2/2	M
828d-me61	1	2,3,4,1,5,6	1	31	2/2	M
828d-me81	1	2,3,4,1,5,6	1	31	2/2	M
828d-te61	1	2,3,1,5,4,6	1	31	2/2	M
828d-te81	1	2,3,1,5,4,6,8,7	1	31	2/2	M
828d-te41	1	2,3,1,5,4	1	31	2/2	M

Description: Enter in this MD the number of the module within a bus segment through which the output is addressed.

For axes on the PROFIBUS/PROFINET, the number of the drive assigned with MD13050 \$MN_DRIVE_LOGIC_ADDRESS must be entered here (MD30110 \$MA_CTRLOUT_MODULE_NR=n consequently points to MD13050 \$MN_DRIVE_LOGIC_ADDRESS[n]).

30120	CTRLOUT_NR			EXP, A01, -	G2	
-	Setpoint assignment: Setpoint output on drive submodule/ module			BYTE	PowerOn	
-						
-	1	1,1,1,1,1,1,1,1,1,1,1,1, 1,1,1,1,1,1,1,1,1,1,1,1, 1,1...	1	3	2/2	M

Description: Number of the output on a module which is used to address the setpoint output.

The value is always 1 for modular drives.

30130	CTRL_OUT_TYPE			A01, A11	G2, M3, S9	
-	Output type of setpoint			BYTE	PowerOn	
-						
-	1	0	0	3	2/2	M

Description: The type of speed setpoint output is entered in this MD:
0: Simulation (no hardware required)
1: Setpoint output active (differentiated by hardware configuration)
2: stepper motor
3: reserved (previously stepper motor)
4: reserved (previously virtual axis, simulation, no hardware available)
For SW 4 and higher, MD30132 \$MA_IS_VIRTUAL_AX must now be used instead of the value 4.

30132	IS_VIRTUAL_AX			A01	M3, TE1, TE3	
-	Axis is a virtual axis			BOOLEAN	PowerOn	
CTEQ						
-	1	FALSE	-	-	1/1	M

Description: Virtual axis. An axis that is also interpolated in follow-up mode. (Electronic transfer technology; virtual and real master values.)
This MD is the successor to MD30130 \$MA_CTRL_OUT_TYPE=4. MD30130 \$MA_CTRL_OUT_TYPE=0 and MD30132 \$MA_IS_VIRTUAL_AX=1 must now be used instead of MD30130 \$MA_CTRL_OUT_TYPE=4.
Related to:
MD30130 \$MA_CTRL_OUT_TYPE

30134	IS_UNIPOLAR_OUTPUT			A01	G2	
-	Setpoint output is unipolar			BYTE	PowerOn	
-						
-	1	0	0	2	2/2	M

Description: Only for PROFIdrive, special application of analog additional drives:
Unipolar output driver (for unipolar analog drive actuator):
Only positive set speeds are supplied to the drive, the sign of the set speed is separately output in its own digital control signal.
Input value "0":
Bipolar output with pos./neg. set speed (this is the normal case)
Input value "1":
0. Digital bit = servo enable
1. Digital bit = neg. direction of travel
Input value "2": (linking of enable and direction of travel signals):
0. Digital bit = servo enable pos. direction of travel
1. Digital bit = servo enable neg. direction of travel

30200	NUM_ENCS			A01, A02, -	G2,R1,Z1	
-	Number of encoders			BYTE	PowerOn	
-						
-	-	1	0	2	2/2	M

Description: The number of encoders of the axis or spindle is to be entered in the MD for actual position value sensing (the differentiation between direct and indirect measuring systems, i.e. the locations at which these encoders are installed, is then specified, for example, in MD31040 \$MA_ENC_IS_DIRECT). For simulation axes/spindles, MD30200 \$MA_NUM_ENCS > 0 must be specified for referencing.

30220	ENC_MODULE_NR			A01, A02, A11	G2	
-	Actual value assignment: Drive number/measuring circuit number			BYTE	PowerOn	
-						
828d-me41	2	2, 2,3, 3,4, 4,1, 1,5, 5	1	31	2/2	M
828d-me61	2	2, 2,3, 3,4, 4,1, 1,5, 5,6, 6	1	31	2/2	M
828d-me81	2	2, 2,3, 3,4, 4,1, 1,5, 5,6, 6	1	31	2/2	M
828d-te61	2	2, 2,3, 3,1, 1,5, 5,4, 4,6, 6	1	31	2/2	M
828d-te81	2	2, 2,3, 3,1, 1,5, 5,4, 4,6, 6,8, 8,7, 7	1	31	2/2	M
828d-te41	2	2, 2,3, 3,1, 1,5, 5,4, 4	1	31	2/2	M

Description: The number of the module within a bus segment (MD30210 \$MA_ENC_SEGMENT_NR[n]) through which the encoder is addressed must be entered in the MD.

For axes on PROFIBUS/PROFINET, the number of the drive assigned via MD13050 \$MN_DRIVE_LOGIC_ADDRESS must be entered here (MD30220 \$MA_ENC_MODULE_NR=n consequently points to MD13050 \$MN_DRIVE_LOGIC_ADDRESS[n]).

The index[n] of the machine data has the following coding:

[Encoder no.]: 0 or 1

Related to:

MD30110 \$MA_CTRL_OUT_MODULE_NR[n]

(setpoint assignment: drive number/module number)

30230	ENC_INPUT_NR			A01, A02, A11, -	G2,S9	
-	Actual value assignm.: Input on drive module/meas. circuit board			BYTE	PowerOn	
-						
-	2	1, 2,1, 2,1, 2,1, 2,1, 2,1, 2,1, 2,1, 2,1, 2...	1	2	2/2	M

Description: For PROFIdrive:

Number of the encoder within the PROFIdrive message frame through which the encoder is addressed.

For example telegram 103: 1 (=G1_ZSW etc.) or 2 (=G2_ZSW etc.).

The index[n] of the machine data has the following coding:

[Encodernr.]: 0 or 1

If an input is selected, to which no encoder is connected, alarm 300008 "Measuring circuit not available on drive" is output.

30240	ENC_TYPE	A01, A02, A11,	A3,,G2,R1
-	Encoder type of actual value sensing (actual position value).	BYTE	PowerOn
-			
-	2	0, 0	0 5 2/2 M

Description: Encoder type:
0: Simulation
1: Raw signal generator (high resolution)
2: Reserved
3: Reserved
4: General absolute encoder (e.g. with EnDat interface)
35 Reserved
Related to:
PROFIdrive parameter p979 (compare there)

30242	ENC_IS_INDEPENDENT	A02, A11, -	G2,R1
-	Encoder is independent	BYTE	NEW CONF
-			
-	2	0, 0	0 3 1/1 M

Description: If actual value corrections performed by the NC on the encoder selected for position control are not to influence the actual value of any other encoder defined in the same axis, then the position control encoder must be declared to be "independent".
Actual value corrections include the following:

- Modulo treatment,
- Reference point approach,
- Measuring system calibration,
- PRESET

Example:
MD30200 \$MA_NUM_ENCS[AX1] = 2
MD30242 \$MA_ENC_IS_INDEPENDENT[0, AX1] = 0
MD30242 \$MA_ENC_IS_INDEPENDENT[1, AX1] = 1
When the VDI interface has selected the first encoder for position control, the above mentioned actual value corrections will be executed on this encoder only.
When the VDI interface has selected the second encoder for position control, the above mentioned actual value corrections will be executed on both encoders.
The machine data is therefore only valid for encoders that have not been selected by the VDI interface for position control (passive encoders).
As from SW5, the scope of functions has been extended:
MD30242 \$MA_ENC_IS_INDEPENDENT = 2
The passive encoder is dependent. The active encoder changes the actual encoder value. In combination with MD35102 \$MA_REFP_SYNC_ENCS = 1, the passive encoder is adjusted to the active encoder during reference point approach, but is NOT referenced.

In reference mode MD34200 \$MA_ENC_REFP_MODE = 3 (distance-coded reference marks), the passive encoder is automatically referenced with the next traversing movement after zero mark distance overtravel. This is done independently of the current mode setting.

MD30242 \$MA_ENC_IS_INDEPENDENT = 3

In contrast to MD30242 \$MA_ENC_IS_INDEPENDENT = 1, modulo actual value corrections are executed in the passive encoder of modulo rotary axes.

30244	ENC_MEAS_TYPE	A01, A02, A11			-	
-	Encoder measurement type	BYTE			PowerOn	
-						
-	2	1, 1	0	1	1/0	S

Description:

For PROFIdrive only:

In combination with the MD13210 \$MN_MEAS_TYPE = 1 (decentralized measurement), this MD can be used to set the type of axial measuring function for drives.

Encoder measurement type:

0: encoder measurement type central (global) measurement

1: encoder measurement type decentral (local) measurement

MEAS_TYPE	ENC_MEAS_TYPE	measuring sensor input used
0	0	central
0	1	central
1	0	central
1	1	decentralized

30250	ACT_POS_ABS	EXP, A02, A08			R1	
-	Internal encoder position	DOUBLE			PowerOn	
ODLD, -, -						
-	2	0.0, 0.0	-	-	1/1	I

Description:

The actual position (hardware counter status only without machine reference) is stored (in internal format display) in this MD.

At power ON (or encoder activation), it acts with:

- Absolute encoders:

To restore the current position (in combination with the position, possibly with several meanings, buffered in the encoder).

- Incremental encoders:

To buffer the actual value beyond power OFF when the functionality is activated MD34210 \$MA_ENC_REFP_STATE = 1 or 2 (i.e. as a reference point replacement).

To buffer the actual value beyond power OFF when the functionality is activated MD34210 \$MA_ENC_REFP_STATE = 3 (i.e. as a restored position value).

Note:

This MD is changed internally by the control during traversing movements. Loading a previously saved MD data block can therefore destroy the encoder calibration (machine position reference) of absolute encoders.

For software conversions, we recommend removing the MD data block from the old software release prior to conversion and reloading it into the new software release without moving any axis in the meantime. Protection level 1 should be set for SW 3.6; protection level 2 suffices for SW 4 and higher. The encoder calibration must be explicitly verified (controlled, calibrated) after the software conversion.

30260	ABS_INC_RATIO			EXP, A01, A02	-	
-	Absolute encoder: Ratio of absolute to incremental resolution			DWORD	PowerOn	
-						
-	2	4, 4	-	-	1/1	M

Description: Absolute track resolution in relation to the incremental signal resolution. This MD only applies for absolute encoders:

- PROFIBUS drives:
 - Absolute information XIST2 related to incremental information XIST1.
 - In the case of plausible drive parameters (e.g. for SIMODRIVE611U: P1042/P1043 or P1044/P1045 or corresponding entries in PROFIdrive parameter p979) the value of this MD is automatically calculated and updated from drive parameters (if parameter read-out has not been deactivated with \$MN_DRIVE_FUNCTION_MASK, bit2)
 - Implausible drive parameters (e.g. multiplication of absolute track higher than that of the incremental signal) are rejected and replaced by the value entered in the current MD.
 - Implausible input values in the current MD (e.g. value=0) are reset to the default value. In addition, alarm 26025 or 26002 is output to inform the user accordingly.

30270	ENC_ABS_BUFFERING			EXP, A01, A02	R1	
-	Absolute encoder: Traversing range extension			BYTE	PowerOn	
-						
-	2	0, 0	0	1	2/2	M

Description: This MD defines the way in which the absolute encoder position is buffered, and whether a traversing range extension is active on software side (exceeding the limits of the absolute value encoder range that can be displayed on the hardware).

"0" = standard = traversing range extension (compare ACT_POS_ABS) is active.
 "1" = traversing range extension on software side is inactive.

When using an absolute linear scale, there will not be a traversing range overflow for mechanical reasons. This MD is therefore only valid for rotary absolute value encoders.

For rotary absolute value encoders, the traversing range that can be clearly displayed on the encoder side, is stored in MD34220 \$MA_ENC_ABS_TURNS_MODULO. You can do without a traversing range extension without any problems (a hardware counter overflow that might be within the traversing range is concealed in the software via shortest-path decision):

- a. in linear axes or limited rotary axes, if the actual traversing range on the load side is smaller than the traversing range on the load side that corresponds to MD34220 \$MA_ENC_ABS_TURNS_MODULO.
- b. in endlessly turning rotary axes (ROT_IS_MODULO = TRUE), if the absolute encoder is connected on the load side (no gear to be considered) or if "without remainder" can be calculated:

Number of rotations on the load side = ENC_ABS_TURNS_MODULO * gear ratio
 (Example: ENC_ABS_TURNS_MODULO = 4096 encoder rotations, gear 25:32, i.e. number of rotations on load side = 4096*(25/32)=3200).

Notice:

If you do not meet the conditions under a. or b., you run the risk of getting a wrong absolute encoder position at next Power ON or encoder activation after parking without prewarning if the traversing range extension is not working. Therefore, the traversing range extension remains active in the standard version.

Related to:

MD30240 \$MA_ENC_TYPE
 MD30300 \$MA_IS_ROT_AX
 MD30310 \$MA_ROT_IS_MODULO
 MD30250 \$MA_ACT_POS_ABS
 MD34220 \$MA_ENC_ABS_TURNS_MODULO
 MD34090 \$MA_REFP_MOVE_DIST_CORR

30300	IS_ROT_AX	A01, A06, A11, -	G1,K3,R2,T1,G2,K2,R1,S1,V1
-	Rotary axis / spindle	BOOLEAN	PowerOn
SCAL, CTEQ			
828d-me41	-	FALSE,FALSE,FALS E,TRUE,TRUE	- - 2/2 M
828d-me61	-	FALSE,FALSE,FALS E,TRUE,TRUE	- - 2/2 M
828d-me81	-	FALSE,FALSE,FALS E,TRUE,TRUE	- - 2/2 M
828d-te61	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE	- - 2/2 M
828d-te81	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE...	- - 2/2 M
828d-te41	-	FALSE,FALSE,TRUE, TRUE,TRUE	- - 2/2 M

Description:

- 1: Axis: The axis is defined as a "rotary axis".
- The special functions of the rotary axis are active or can be activated by means of additional machine data according to the type of machine required (see below).
 - The unit of measurement is degrees.
 - The units of the axis-specific machine and setting data are interpreted as follows with the standard control setting:
 - Positions in "degrees"
 - Speedsin "rev/minute"
 - Accelerationin "rev/second²"
 - Jerk limitationin "rev/second³"

Spindle:

The machine data should always be set to "1" for a spindle, otherwise alarm 4210 "Rotary axis declaration missing" is output.

0: The axis is defined as a "linear axis".

Special cases:

- For an axis: Alarm 4200 if the axis is already defined as a geometry axis.
- For a spindle: Alarm 4210

2.4 Axis-specific machine data

Related to:

The following machine data are active only after activation of MD30300
 \$MA_IS_ROT_AX = "1":

- MD30310 \$MA_ROT_IS_MODULO "Modulo conversion for rotary axis"
- MD30320 \$MA_DISPLAY_IS_MODULO "Position display is modulo"
- MD10210 \$MN_INT_INCR_PER_DEG "Calculation precision for angular positions"

30310	ROT_IS_MODULO	A01, A06, A11,	TE3,K3,R2,T1,A3,R1,R2,S1
-	Modulo conversion for rotary axis / spindle	BOOLEAN	PowerOn
CTEQ			
828d-me41	-	FALSE,FALSE,FALS E,TRUE,TRUE	- - 2/2 M
828d-me61	-	FALSE,FALSE,FALS E,TRUE,TRUE,TRUE	- - 2/2 M
828d-me81	-	FALSE,FALSE,FALS E,TRUE,TRUE,TRUE	- - 2/2 M
828d-te61	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE	- - 2/2 M
828d-te81	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE...	- - 2/2 M
828d-te41	-	FALSE,FALSE,TRUE, TRUE,TRUE	- - 2/2 M

Description:

1: A modulo conversion is performed on the setpoints for the rotary axis. The software limit switches and the working area limitations are inactive; the traversing range is therefore unlimited in both directions. MD30300 \$MA_IS_ROT_AX must be set to "1"

0: No modulo conversion

MD irrelevant for:

MD30300 \$MA_IS_ROT_AX = "0" (linear axes)

Related to:

- MD30320 \$MA_DISPLAY_IS_MODULO "Position display is modulo 360°"
- MD30300 \$MA_IS_ROT_AX = 1 "Rotary axis"
- MD36100 \$MA_POS_LIMIT_MINUS "Software limit switch minus"
- MD36110 \$MA_POS_LIMIT_PLUS "Software limit switch plus"
- SD43430 \$SA_WORKAREA_LIMIT_MINUS "Working area limitation minus"
- SD43420 \$SA_WORKAREA_LIMIT_PLUS "Working area limitation plus"

30320	DISPLAY_IS_MODULO			A01, A06, A11	R2,T1,K2	
-	Modulo 360 degrees displayed for rotary axis or spindle.			BOOLEAN	PowerOn	
CTEQ						
828d-me41	-	FALSE,FALSE,FALS E,TRUE,TRUE	-	-	2/2	M
828d-me61	-	FALSE,FALSE,FALS E,TRUE,TRUE,TRUE	-	-	2/2	M
828d-me81	-	FALSE,FALSE,FALS E,TRUE,TRUE,TRUE	-	-	2/2	M
828d-te61	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE	-	-	2/2	M
828d-te81	-	FALSE,FALSE,TRUE, TRUE,TRUE,FALSE...	-	-	2/2	M
828d-te41	-	FALSE,FALSE,TRUE, TRUE,TRUE	-	-	2/2	M

Description:

1: "Modulo 360 degrees" position display is active:

The position display of the rotary axis or spindle (for basic or machine coordinate system) is defined as "Modulo 360 degrees". In the case of a positive direction of rotation, the control resets the position display internally to 0.000 degrees following each cycle of 359.999 degrees. The display range is always positive and lies between 0 and 359.999 degrees.

0: Absolute position display is active:

In contrast to the modulo 360 degrees position display, absolute positions are indicated by the absolute position display, e.g. +360 degrees after 1 rotation, and +720 degrees after 2 rotations, etc in the positive direction. In this case, the display range is limited by the control in accordance with the linear axes.

MD irrelevant for:

Linear axes MD30300 \$MA_IS_ROT_AX = "0"

Related to:

MD30300 \$MA_IS_ROT_AX = 1 "Axis is rotary axis"

30330	MODULO_RANGE			EXP, A01, -	R2,T1,R1	
degrees	Size of modulo range.			DOUBLE	Reset	
CTEQ						
-	-	360.0	1.0	360000000.0	1/1	M

Description:

Defines the size of the modulo range. Default positions are accepted and displayed within this range. Useful modulo ranges are $n * 360$ degrees with integer n . Other settings are equally possible in principle. Attention should be paid to having a useful relationship between the positions in the NC and the mechanics (ambiguity). Velocity definitions are not affected by settings in this MD.

2.4 Axis-specific machine data

30340	MODULO_RANGE_START		EXP, A01	R1,R2
degrees	Modulo range start position		DOUBLE	Reset
CTEQ				
-	-	0.0	-	1/1 M

Description: Defines the start position for the modulo range.

Example:

Start = 0 degree -> modulo range 0 <->360 degrees

Start = 180 degrees -> modulo range 180 <->540 degrees

Start = -180 degrees -> modulo range -180 <->180 degrees

30350	SIMU_AX_VDI_OUTPUT		A01, A06	A2,G2,Z1
-	Axis signals output for simulation axes		BOOLEAN	PowerOn
CTEQ				
-	-	FALSE	-	2/2 M

Description: The machine data defines whether axis-specific interface signals are output to the PLC while an axis is being simulated.

1: The axis-specific NC/PLC interface signals for a simulated axis are output to the PLC.

This means that the user PLC program can be tested without the drives having to be available.

0: The axis-specific NC/PLC interface signals for a simulated axis are not output to the PLC.

All axis-specific NC/PLC interface signals are set to "0".

Not relevant for:

MD30130 \$MA_CTRL_OUT_TYPE (setpoint output type) = 1

30450	IS_CONCURRENT_POS_AX		EXP, A01	G1
-	Default for reset: neutral/channel axis		BOOLEAN	Reset
CTEQ				
-	-	FALSE	-	1/1 M

Description: For SW4.3:

If FALSE: On RESET, a neutral axis is reassigned to the NC program.

If TRUE: On RESET, a neutral axis remains in the neutral axis state and an axis assigned to the NC program becomes a neutral axis

30455	MISC_FUNCTION_MASK		A06, A10	R2,S3,R1
-	Axis functions		DWORD	Reset
CTEQ				
-	-	0x00	0	0x7FF 1/1 M

Description: Bit 0 =0:

Modulo rotary axis/spindle: Programmed positions must be within the modulo range. Otherwise, an alarm is output.

Bit 0 =1:

If positions outside the modulo range are programmed, no alarm is output. The position is modulo-converted internally.

Example: B-5 is equivalent to B355, POS[A]=730 is identical to POS[A]=10, and SPOS=-360 behaves like SPOS=0 (modulo range 360 degrees)

Bit 1 =0:

Determination of reference point position of rotary, distance-coded encoders analog (1:1) in relation to the mechanical absolute position.

Bit 1 =1:

Determination of reference point position of rotary, distance-coded encoders within the configured modulo range.

For rotary axes with MD30310 \$MA_ROT_IS_MODULO=0 using rotary, distance-coded encoders MD34200 \$MA_ENC_REFP_MODE=3, the reference point position is determined as a function of MD30330 \$MA_MODULO_RANGE and MD30340 \$MA_MODULO_RANGE_START. This is automatically adapted to the motion limits of the modulo range. This bit is irrelevant for rotary axes with MD30310 \$MA_ROT_IS_MODULO=1, since the reference point position is always determined within the modulo range.

Bit 2 =0:

Modulo rotary axis positioned at G90 with AC by default

Bit 2 =1:

Modulo rotary axis positioned at G90 with DC by default (shortest path)

Bit 3 =0:

With spindle/axis disable, \$VA_IM, \$VA_IM1, \$VA_IM2 supply the setpoint value

Bit 3 =1:

With spindle/axis disable, \$VA_IM, \$VA_IM1, \$VA_IM2 supply the actual value

Bit 4 =0:

Synchronous spindle coupling, following spindle: Cancellation of feedrate enable will decelerate the coupled group.

Bit 4 =1:

Following spindle: Feedrate enable only refers to the interpolation share of the overlaid motion (SPOS, etc.) and has no impact on the coupling.

Bit 5 = 0:

Synchronous spindle coupling, following spindle: Position control, feed-forward control, and parameter block are set corresponding to the leading spindle.

Bit 5 =1:

Synchronous spindle coupling: The parameters of the following spindle are set as in the uncoupled case.

Bit 6 =0:

Programming of FA, OVRA, ACC, and VELOLIM is applied separately for spindle and axis modes. The assignment is made by the programmed axis or spindle identifier.

Bit 6 =1:

Programming of FA, OVRA, ACC, and VELOLIM is applied in concert for spindle and axis modes, irrespective of the programmed identifier.

Bit 7 = 0:

Synchronous spindle, correct synchronism error: Correction value \$AA_COUP_CORR[Sn] is continuously calculated as long as the NC/PLC interface signal <Synchronlauf_nachfuehren/> (Correct synchronism) is set and setpoint-related synchronism is present.

Bit 7 = 1:

Synchronous spindle, correct synchronism error: Correction value \$AA_COUP_CORR[Sn] is calculated only at the moment the NC/PLC interface signal <Synchronlauf_nachfuehren/> (Correct synchronism) is set from 0 to

2.4 Axis-specific machine data

- 1.
- Bit 8 = 0:
Absolute encoders can only be readjusted in the enabled state MD34210=1.
- Bit 8 = 1:
Absolute encoders can also be readjusted in the adjusted state MD34210=2.
- Bit 9 = 0:
Coupled axes (e.g. gantry) jointly delete their pulse enable if an error occurs.
- Bit 9 = 1:
Coupled axes (e.g. gantry) only delete their pulse enable for their own errors.
- Bit 10 = 0:
The maximum dynamic of a TRAIL or TANGON axis limits the maximum dynamic path response.
- Bit 10 = 1:
The maximum dynamic of a TRAIL or TANGON axis has no effects on the dynamic path response. This can lead to a longer overtravel of the dependent axis.

30460	BASE_FUNCTION_MASK			A01	K5,P2,P1	
-	Axis functions			DWORD	PowerOn	
CTEQ						
-	-	0x00	0	0x1FF	1/1	M

Description: Axis-specific functions can be set by means of this MD. The MD is bit-coded; the following bits are assigned:

- Bit 0 = 0:
"Axis control" is not permissible.
- Bit 0 = 1:
"Axis control" is permissible (the axis moves in the speed mode, if the NC/PLC interface signal <AchseSteuern/> (Axis control) is set).
- Bit 1:
Reserved for "Axis control".
- Bit 2 = 0:
Axis-specific diameter programming not permitted.
- Bit 2 = 1:
Axis-specific diameter programming permitted.
- Bit 3:
Reserved for "Axis control"
- Bit 4 = 0:
For control purposes, the axis can be used by NC and PLC.
- Bit 4 = 1:
The axis is exclusively controlled by the PLC.
- Bit 5 = 0:
The axis can be used by the NC and PLC.

Bit 5 = 1:

The axis is a permanently assigned PLC axis. However, the axis can be jogged and referenced.

Axis exchange between channels is not possible. The axis cannot be assigned to the NC program.

Bit 6 = 0:

The channel-specific interface signal DB3200 DBX6.0 (feedforward disable) has an effect on the axis, even though it is a PLC-controlled axis.

Bit 6 = 1:

The channel-specific interface signal DB3200 DBX6.0 (feedforward disable) will have no effect on the axis, if it is a PLC-controlled axis.

Bit 7 = 0:

The channel-specific interface signal DB3300 DBX4.3 (all axes stationary) is set dependently of the axis, even though it is PLC-controlled.

Bit 7 = 1:

The channel-specific interface signal DB3300 DBX4.3 (all axes stationary) will be set independently of the axis, if this axis is PLC-controlled.

Bit 8 = 0:

The axis is an 'interpolating (full) axis' (path/GEO/additional path axis/GEOAX()/spindle for thread cutting/tapping)

Bit 8 = 1:

The axis is a positioning axis / auxiliary spindle

30465	AXIS_LANG_SUB_MASK			N01	K1	
-	Substitution of NC language commands			DWORD	PowerOn	
-						
-	-	0x0	0x0	0x3	2/2	M

Description: MD30465 \$MA_AXIS_LANG_SUB_MASK defines for the leading spindle(s) of a coupling (synchronous spindle coupling, ELG, tangential tracking, coupled motion, master value coupling, master/slave) which language constructs/functions are to be substituted by the user program set by MD15700 \$MN_LANG_SUB_NAME / MD15702 \$MN_LANG_SUB_PATH (default: /_N_CMA_DIR/_N_LANG_SUB_SPF).

The substitution is executed only if a coupling is active for the relevant spindle and, in the case of a gear stage change, only if a gear stage change is actually pending.

Bit 0 = 1:

Automatic (M40) and direct (M41-M45) gear stage change

Bit 1 = 1:

Spindle positioning with SPOS/SPOSA/M19

30500	INDEX_AX_ASSIGN_POS_TAB			A01, A10	T1, H1	
-	Axis is an indexing axis			BYTE	Reset	
-						
-	-	0	0	3	2/2	M

Description: The axis is declared as an indexing axis by assignment of indexing position table 1 or 2.

0: The axis is not declared as an indexing axis

1: The axis is an indexing axis. The associated indexing positions are stored in table 1 (MD10910 \$MN_INDEX_AX_POS_TAB_1).

2.4 Axis-specific machine data

2: The axis is an indexing axis. The associated indexing positions are stored in table 2 (MD10930 \$MN_INDEX_AX_POS_TAB_2).

3: Equidistant indexing with SW 4.3 and higher (840D) and SW 2.3 and higher (810D)

>3: Alarm 17090 "Value violates upper limit"

Special cases:

Several axes can be assigned to an indexing position table on the condition that all these indexing axes are of the same type (linear axis, rotary axis, modulo 360° function). If they are not, alarm 4000 is output during power-up.

Alarm 17500 "Axis is not an indexing axis"

Alarm 17090 "Value violates upper limit"

Related to:

MD10910 \$MN_INDEX_AX_POS_TAB_1 (indexing position table 1)

MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1

(no. of indexing positions used in table 1)

MD10930 \$MN_INDEX_AX_POS_TAB_2 (indexing position table 2)

MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2

(no. of indexing positions used in table 2)

For equidistant indexings with value 3:

MD30501 \$MA_INDEX_AX_NUMERATOR Numerator

MD30502 \$MA_INDEX_AX_DENOMINATOR Denominator

MD30503 \$MA_INDEX_AX_OFFSET First indexing position

MD30505 \$MA_HIRTH_IS_ACTIVE Hirth tooth system

30501	INDEX_AX_NUMERATOR	A01, A10	T1
mm, degrees	Indexing axis equidistant positions numerator	DOUBLE	Reset
-			
-	-	0.0	-
			2/2 M

Description: Defines the value of the numerator for calculating the distances between two indexing positions when the positions are equidistant. Modulo axes ignore this value and use MD30330 \$MA_MODULO_RANGE instead.

MD irrelevant for non-equidistant indexes in accordance with tables.

Related to:

MD30502 \$MA_INDEX_AX_DENOMINATOR,

MD30503 \$MA_INDEX_AX_OFFSET;

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB

30502	INDEX_AX_DENOMINATOR	A01, A10	T1
-	Indexing axis equidistant positions denominator	DWORD	Reset
-			
-	-	1	1
			2/2 M

Description: Defines the value of the denominator for calculating the distances between two indexing positions when the positions are equidistant. For modulo axes it therefore specifies the number of indexing positions.

MD irrelevant for non-equidistant indexes in accordance with tables.

Related to:

MD30501 \$MA_INDEX_AX_NUMERATOR,

MD30503 \$MA_INDEX_AX_OFFSET,

MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB

30503	INDEX_AX_OFFSET	A01, A10	T1,R2
mm, degrees	Indexing axis with equidistant positions first index position	DOUBLE	Reset
-			
-	-	0.0	-
-	-	-	-
-	-	2/2	M

Description: Defines the position of the first indexing position from zero for an indexing axis with equidistant positions.
 MD irrelevant for non-equidistant indexes in accordance with tables.
 Related to:
 MD30501 \$MA_INDEX_AX_NUMERATOR, MD30502 \$MA_INDEX_AX_DENOMINATOR, MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB

30505	HIRTH_IS_ACTIVE	A01, A10	T1
-	Axis is an indexing axis with Hirth tooth system	BOOLEAN	Reset
CTEQ			
-	-	FALSE	-
-	-	-	-
-	-	1/1	M

Description: Hirth tooth system is active when value 1 is set.
 MD irrelevant if axis is not an indexing axis.
 Related to:
 MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB, MD30501 \$MA_INDEX_AX_NUMERATOR, MD30502 \$MA_INDEX_AX_DENOMINATOR, MD30503 \$MA_INDEX_AX_OFFSET

30600	FIX_POINT_POS	A03, A10	K1,W3
mm, degrees	Fixed-value positions of axis with G75	DOUBLE	PowerOn
-			
-	4	0.0, 0.0, 0.0, 0.0	-
-	-	-	-
-	-	2/2	I

Description: The fixed-point positions (4 max.) for each axis which can be approached when G75 is programmed or via JOG are entered in these machine data.
 References:
 /PA/, "Programming Guide: Fundamentals"

30610	NUM_FIX_POINT_POS	A03, A10	K1
-	Number of fixed-value positions of an axis	DWORD	PowerOn
-			
-	-	0	0
-	-	4	2/2
-	-	-	M

Description: Number of fixed point positions set, i.e. the number of valid entries in MD30600 \$MA_FIX_POINT_POS.
 For G75, two (2) fixed point positions are assumed in MD30600 \$MA_FIX_POINT_POS for reasons of compatibility, even if '0' has been entered in this machine data.

30800	WORKAREA_CHECK_TYPE	-	A3
-	Type of check of working area limitations.	BOOLEAN	NEW CONF
CTEQ			
-	-	FALSE	-
-	-	-	-
-	-	1/1	M

Description: With this machine data you can specify whether only the working area limitations of traversing axes are to be checked (0)
 or
 whether the stationary axes in a traversing block are also to be checked (1).
 The value 0 corresponds to the behavior up to SW5.

31000	ENC_IS_LINEAR	A02, A11, -		G2	
-	Linear scale	BOOLEAN		PowerOn	
-					
-	2	FALSE, FALSE	-	-	2/2 M

Description: MD = 1: Encoder for position actual-value acquisition is linear (linear scale).
MD = 0: Encoder for position actual-value acquisition is rotary.
The index [n] of the machine data has the following coding:
[encoder no.]: 0 or 1

31010	ENC_GRID_POINT_DIST	A02, A11, -		G2	
mm	Division period for linear scales	DOUBLE		PowerOn	
-					
-	2	0.01, 0.01	-	-	2/2 M

Description: For linear measuring system only:
The distance between the reference marks on the linear scale must be entered in this MD.
Index [n] of the machine data has the following coding:
[encoder no.]: 0 or 1

31020	ENC_RESOL	A02, A11, -		G2,R1	
-	Encoder lines per revolution	DWORD		PowerOn	
-					
-	2	2048, 2048, 2048, 2048, 2048, 2048...	-	-	2/2 M

Description: For rotary measuring system only:
The number of encoder lines per encoder revolution must be entered in this MD.
Index [n] of the machine data has the following coding:
[encoder no.]: 0 or 1

31025	ENC_PULSE_MULT	EXP, A01, A02		-	
-	Encoder multiplication (high-resolution)	DWORD		PowerOn	
-					
-	2	2048, 2048, 2048, 2048, 2048...	-	-	2/2 M

Description: For PROFIdrive only:
This MD describes the measuring system multiplication on PROFIBUS/PROFINET.
Default value 2048 means: changing by just one encoder line can be seen in bit11 of the actual PROFIdrive value XIST1, that is, the actual encoder value is multiplied by 2 to the power of 11= 2048.

31030	LEADSCREW_PITCH	A02, A11, -		G2,A3	
mm	Pitch of leadscrew	DOUBLE		PowerOn	
-					
-	-	10.0	-	-	2/2 M

Description: The ball screw lead must be entered in the MD (see data sheet: mm/rev or inch/rev).
Special meaning for hydraulic linear drives:
If a hydraulic linear drive (HLA) is configured as rotary axis, it must be specified in this MD, which drive feedrate in mm corresponds to a programmed revolution (360 degrees).

31040	ENC_IS_DIRECT	A02, A11, -		G2,S1	
-	Direct measuring system (no compilation to load position)	BOOLEAN		PowerOn	
-					
-	2	FALSE, FALSE	-	-	2/2 M

Description: MD = 1:
Encoder for actual position value sensing is attached directly to the machine (without an intermediate gear unit).
MD = 0:
Encoder for actual position value sensing is attached to the motor (MD31060 \$MA_DRIVE_AX_RATIO_NUMERA and MD31050 \$MA_DRIVE_AX_RATIO_DENOM are included in the encoder valuation).
The index[n] of the machine data has the following coding:
[encoder no.]: 0 or 1
Special cases:
An incorrect entry may result in an incorrect encoder resolution, as, for example, the gear ratios would be calculated incorrectly.

31044	ENC_IS_DIRECT2	A02, -		G2,S1	
-	Encoder mounted on the additional gearbox	BOOLEAN		NEW CONF	
-					
-	2	FALSE, FALSE	-	-	2/2 M

Description: When using a load intermediate gearbox (for example for rotating tools, compare MD31066 \$MA_DRIVE_AX_RATIO2_NUMERA and MD31064 \$MA_DRIVE_AX_RATIO2_DENOM), the encoder installation location can be defined as "on the output" of this load intermediate gearbox:
Encoder installation "on the output of the load intermediate gearbox" is configured by MD31040 \$MA_ENC_IS_DIRECT=1 and MD31044 \$MA_ENC_IS_DIRECT2=1 at the same time.
Encoder installation "on the input of the load intermediate gearbox" is configured by MD31040 \$MA_ENC_IS_DIRECT=1 together with MD31044 \$MA_ENC_IS_DIRECT2=0.
A parameterization alarm will be output if MD31044 \$MA_ENC_IS_DIRECT2=1 is set without MD31040 \$MA_ENC_IS_DIRECT=1 (this combination has not been defined).

2.4 Axis-specific machine data

31050	DRIVE_AX_RATIO_DENOM			A02, A11, -	A2,A3,G2,S1,V1	
-	Denominator load gearbox			DWORD	PowerOn	
-						
-	6	1, 1, 1, 1, 1, 1	1	2147000000	2/2	M

Description: The load gearbox denominator is entered in this MD.
The index [n] of the machine data has the following coding:
[control parameter set no.]: 0-5

31060	DRIVE_AX_RATIO_NUMERA			A02, A11, -	A2,A3,G2,S1,V1	
-	Numerator load gearbox			DWORD	PowerOn	
-						
-	6	1, 1, 1, 1, 1, 1	-2147000000	2147000000	2/2	M

Description: The load gearbox numerator is entered in this MD.
The index [n] of the machine data has the following coding:
[control parameter set no.]: 0-5

31064	DRIVE_AX_RATIO2_DENOM			A02, -	G2,S1	
-	Denominator additional gearbox			DWORD	NEW CONF	
-						
-	-	1	1	2147000000	2/2	M

Description: Intermediate gearbox denominator
This MD together with MD31066 \$MA_DRIVE_AX_RATIO2_NUMERA defines an intermediate gearbox that acts as a multiplier to the motor/load gearbox (described by MD31060 \$MA_DRIVE_AX_RATIO_NUMERA and MD31050 \$MA_DRIVE_AX_RATIO_DENOM). The load intermediate gearbox is inactive with the default values 1:1. Please consider MD31044 \$MA_ENC_IS_DIRECT2 for encoder installation.
When the Safety Integrated functionality (see MD36901 \$MA_SAFE_FUNCTION_ENABLE) is active, the intermediate gearbox can be used, if

- the effectively active gear ratio from the motor to the tool is considered in the safety-relevant machine data and if
- the safety-relevant supplementary conditions for gear ratios are considered.

For more detailed information see the Safety Integrated Description of Functions.

31066	DRIVE_AX_RATIO2_NUMERA			A02, -	G2,S1	
-	Numerator additional gearbox			DWORD	NEW CONF	
-						
-	-	1	-2147000000	2147000000	2/2	M

Description: Intermediate gearbox numerator
Related to:
MD31064 \$MA_DRIVE_AX_RATIO2_DENOM

31070	DRIVE_ENC_RATIO_DENOM	A02, A11, -		A3,G2,S1		
-	Denominator measuring gearbox	DWORD		PowerOn		
-						
-	2	1, 1	1	2147000000	2/2	M

Description: The measuring gearbox denominator is entered in this MD.
The index [n] of the machine data has the following coding:
[encoder no.]: 0 or 1

31080	DRIVE_ENC_RATIO_NUMERA	A02, A11, -		A3,G2,S1		
-	Numerator measuring gearbox	DWORD		PowerOn		
-						
-	2	1, 1	1	2147000000	2/2	M

Description: The measuring gearbox numerator is entered in this MD.
The index [n] of the machine data has the following coding:
[encoder no.]: 0 or 1

31090	JOG_INCR_WEIGHT	A01, A12		H1,G2		
mm, degrees	Evaluation of an increment with INC/handwheel	DOUBLE		Reset		
CTEQ						
-	2	0.001, 0.00254	-	-	2/2	M

Description: The value entered in this MD defines the path of an increment which applies when an axis is traversed with the JOG keys in incremental mode or with the handwheel.

The path traveled by the axis on each increment each time the traversing key is pressed or for each handwheel detent position is defined by the following parameters:

- MD31090 \$MA_JOG_INCR_WEIGHT
(Weighting of an increment of a machine axis for INC/handwheel)
- Selected increment size (INC1, ..., INCvar)

The possible increment stages are defined globally for all axes in MD11330 \$MN_JOG_INCR_SIZE_TAB [n] and in SD41010 \$SN_JOG_VAR_INCR_SIZE.

Entering a negative value reverses the direction of evaluation of the traverse keys and the handwheel rotation.

Related to:

MD11330 \$MN_JOG_INCR_SIZE_TAB
SD41010 \$SN_JOG_VAR_INCR_SIZE

31122	BERO_DELAY_TIME_PLUS	A02, A06		S1,R1		
s	BERO delay time Plus	DOUBLE		NEW CONF		
-						
-	2	0.000110, 0.000110	-	-	2/2	M

Description: This machine data in combination with the setting in MD34200 \$MA_ENC_REFP_MODE (referencing mode) = 7 causes a signal runtime compensation in the positive direction of movement at a position determined by a BERO (zero mark).

The typical total delay time of the BERO message path for overtravel in the positive direction of movement is entered.

2.4 Axis-specific machine data

This time includes:

- the BERO edge delay time
- the time for digitizing the signal
- the time for processing the measured value, etc.

The periods of time depend on the hardware used. The default value is typical for SIEMENS products. Adjustment by the customer is only required in exceptional cases.

Input of the minimum value "0.0" deactivates the compensation (only active in combination with MD34200 \$MA_ENC_REFP_MODE = 7).

The machine data is available for all encoders.

Related to:

MD34200 \$MA_ENC_REFP_MODE (referencing mode)

MD34040 \$MA_REFP_VELO_SEARCH_MARKER[n]

(reference point creep velocity [Enc. no.]

31123	BERO_DELAY_TIME_MINUS			A02, A06	S1,R1	
s	BERO delay time minus			DOUBLE	NEW CONF	
-						
-	2	0.000078, 0.000078	-	-	2/2	M

Description:

This machine data in combination with the setting in MD34200 \$MA_ENC_REFP_MODE (referencing mode) = 7 causes a signal runtime compensation in the negative direction of movement at a position determined by a BERO (zero mark).

The typical total delay time of the BERO message path for overtravel in the negative direction of movement is entered.

The time includes:

- the BERO edge delay time
- the time for digitizing the signal
- the time for processing the measured value, etc.

The periods of time depend on the hardware used. The default value is typical for SIEMENS products. Adjustment by the customer is only required in exceptional cases.

Input of the minimum value "0.0" deactivates the compensation (only active in combination with MD34200 \$MA_ENC_REFP_MODE = 7).

The machine data is available for all encoders.

Related to:

MD34200 \$MA_ENC_REFP_MODE (referencing mode)

MD34040 \$MA_REFP_VELO_SEARCH_MARKER[n]

(creep velocity [Enc. no.]

31200	SCALING_FACTOR_G70_G71	EXP, A01	G2
-	Factor for converting values while G70/G71 is active	DOUBLE	PowerOn
CTEQ			
-	-	25.4	1.e-9
		-	1/1
			M

Description: The inch/metric conversion factor by which the programmed geometry of an axis (position, polynomial coefficients, radius for circular programming,...) is multiplied when the programmed value for G code group G70/G71 differs from the initial setting value (set in MD20150 \$MC_GCODE_RESET_VALUES[n]) is entered in this MD.

The factor can be set for each axis individually, so that pure positioning axes are not dependent on G70/G71. The factors within the three geometry axes should not be different.

The data influenced by G70/G71 are described in the Programming Guide.

Related to:

MD20150 \$MC_GCODE_RESET_VALUES[n] (G group initial setting).

31600	TRACE_VDI_AX	EXP, N06	-
-	Trace-specification for axial VDI signals	BOOLEAN	PowerOn
NBUP			
-	-	FALSE	-
		-	1/1
			M

Description: This machine data determines whether the axial VDI signals for this axis are recorded in the NCSC trace (according to MD18794 \$MN_MM_TRACE_VDI_SIGNAL).

32000	MAX_AX_VELO	A11, A04	M3,TE1,TE3,W6,Z3,H1,K3,M1,P2,A3,B2,G2,H2,S1,V1,W1
mm/min, rev/min	maximum axis velocity	DOUBLE	NEW CONF
CTEQ			
828d-me41	-	10000.,10000.,10000.,36000.,36000.	1.e-9
	-	-	-
		2/2	M
828d-me61	-	10000.,10000.,10000.,36000.,36000....	1.e-9
	-	-	-
		2/2	M
828d-me81	-	10000.,10000.,10000.,36000.,36000....	1.e-9
	-	-	-
		2/2	M
828d-te61	-	10000.,10000.,36000.,36000.,36000....	1.e-9
	-	-	-
		2/2	M
828d-te81	-	10000.,10000.,36000.,36000.,36000....	1.e-9
	-	-	-
		2/2	M
828d-te41	-	10000.,10000.,36000.,36000.,36000.	1.e-9
	-	-	-
		2/2	M

Description: Maximum velocity at which the axis can permanently travel. The value limits both the positive and the negative axis velocity. The axis traverses at this velocity, if rapid traverse has been programmed.

Depending on the MD30300 \$MA_IS_ROT_AX, the maximum rotary or linear axis velocity has to be entered.

In the machine data, the dynamic behavior of the machine and drive and the limit frequency of the actual value acquisition must be taken into account.

2.4 Axis-specific machine data

32010	JOG_VELO_RAPID	A11, A04, -	H1
mm/min, rev/min	Rapid traverse in jog mode	DOUBLE	Reset
CTEQ			
828d-me41	-	10000.,10000.,10000.,36000.,36000.	- - 2/2 M
828d-me61	-	10000.,10000.,10000.,36000.,36000....	- - 2/2 M
828d-me81	-	10000.,10000.,10000.,36000.,36000....	- - 2/2 M
828d-te61	-	10000.,10000.,36000.,36000.,36000....	- - 2/2 M
828d-te81	-	10000.,10000.,36000.,36000.,36000....	- - 2/2 M
828d-te41	-	10000.,10000.,36000.,36000.,36000.	- - 2/2 M

Description: The axis velocity entered applies when the rapid traverse override key is pressed in JOG mode and when the axial feedrate override is set to 100%. The value entered must not exceed the maximum permissible axis velocity (MD32000 \$MA_MAX_AX_VELO).

This machine data is not used for the programmed rapid traverse G0.

MD irrelevant to:
 Operating modes AUTOMATIC and MDI

Related to:
 MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)
 MD32040 \$MA_JOG_REV_VELO_RAPID (revolutional feedrate for JOG with rapid traverse override)
 NC/PLC interface signal DB3200 DBX1000.5,1004.5,1008.5 (Rapid traverse override)
 NC/PLC interface signal DB3200 DBX4 (Feedrate override A-H)

32020	JOG_VELO	A11, A04, -	H1
mm/min, rev/min	Jog axis velocity	DOUBLE	Reset
CTEQ			
828d-me41	-	2000.,2000.,2000.,36000.,36000.	- - 2/2 M
828d-me61	-	2000.,2000.,2000.,36000.,36000....	- - 2/2 M
828d-me81	-	2000.,2000.,2000.,36000.,36000....	- - 2/2 M
828d-te61	-	2000.,2000.,36000.,36000.,36000....	- - 2/2 M
828d-te81	-	2000.,2000.,36000.,36000.,36000....	- - 2/2 M
828d-te41	-	2000.,2000.,36000.,36000.,36000.	- - 2/2 M

Description:

The velocity entered applies to traversing in JOG mode when the axial feedrate override switch position is 100%.

This velocity is only used when general SD41110 \$SN_JOG_SET_VELO = 0 for linear axes, and linear feedrate is selected (SD41100 \$SN_JOG_REV_IS_ACTIVE = 0) or SD41130 \$SN_JOG_ROT_AX_SET_VELO = 0 for rotary axes.

If this is the case, the axis velocity is active for

- continuous jogging
- incremental jogging (INC1, ... INCvar)
- handwheel jogging

The value entered must not exceed the maximum permissible axis velocity (MD32000 \$MA_MAX_AX_VELO).

If DRF is active, the axis velocity for JOG must be reduced with MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR.

Spindles in JOG mode:

This machine data can also be used to define the JOG mode speed for specific spindles (if SD41200 \$SN_JOG_SPIND_SET_VELO = 0). However, the speed can be modified with the spindle override switch.

Related to:

MD32000 \$MA_MAX_AX_VELO

(maximum axis velocity)

MD32050 \$MA_JOG_REV_VELO

(revolutional feedrate for JOG)

MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR

(ratio of JOG velocity to handwheel velocity (DRF))

SD41110 \$SN_JOG_SET_VELO

(JOG velocity for G94)

SD41130 \$SN_JOG_ROT_AX_SET_VELO

(JOG velocity for rotary axes)

NC/PLC interface signal DB3200 DBX4 (Feedrate override A-H)

32040	JOG_REV_VELO_RAPID			A11, A04	H1,P2,R2,T1,V1,Z1	
mm/rev	Revolutional feedrate in JOG with rapid traverse override			DOUBLE	Reset	
CTEQ						
828d-me41	-	2.5,2.5,2.5,1.0,1.0	-	-	2/2	M
828d-me61	-	2.5,2.5,2.5,1.0,1.0,1.0	-	-	2/2	M
828d-me81	-	2.5,2.5,2.5,1.0,1.0,1.0	-	-	2/2	M
828d-te61	-	2.5,2.5,1.0,1.0,1.0,2.5	-	-	2/2	M
828d-te81	-	2.5,2.5,1.0,1.0,1.0,2.5, 2.5,1.0	-	-	2/2	M
828d-te41	-	2.5,2.5,1.0,1.0,1.0	-	-	2/2	M

Description: The value entered defines the revolutional feedrate of the axis in JOG mode with rapid traverse override in relation to the revolutions of the master spindle. This feedrate is active when SD41100 \$SN_JOG_REV_IS_ACTIVE = 1. (Revolutional feedrate active with JOG)

MD irrelevant for:

SD41100 \$SN_JOG_REV_IS_ACTIVE = "0"

Related to:

SD41100 \$SN_JOG_REV_IS_ACTIVE (revolutional feedrate with JOG active)

MD32050 \$MA_JOG_REV_VELO (revolutional feedrate with JOG)

32050	JOG_REV_VELO			A11, A04	H1,P2,R2,T1,V1,Z1	
mm/rev	Revolutional feedrate in JOG			DOUBLE	Reset	
CTEQ						
828d-me41	-	0.5,0.5,0.5,1.0,1.0	-	-	2/2	M
828d-me61	-	0.5,0.5,0.5,1.0,1.0,1.0	-	-	2/2	M
828d-me81	-	0.5,0.5,0.5,1.0,1.0,1.0	-	-	2/2	M
828d-te61	-	0.5,0.5,1.0,1.0,1.0,0.5	-	-	2/2	M
828d-te81	-	0.5,0.5,1.0,1.0,1.0,0.5, 0.5,1.0	-	-	2/2	M
828d-te41	-	0.5,0.5,1.0,1.0,1.0	-	-	2/2	M

Description: The value entered defines the revolutional feedrate of the axis in JOG mode in relation to the revolutions of the master spindle. This feedrate is active when SD41100 \$SN_JOG_REV_IS_ACTIVE= 1 (revolutional feedrate active with JOG).

MD irrelevant for:

Linear feedrate; i.e. SD41100 \$SN_JOG_REV_IS_ACTIVE = 0

Related to:

SD41100 \$SN_JOG_REV_IS_ACTIVE
(revolutional feedrate for JOG active)

MD32040 \$MA_JOG_REV_VELO_RAPID

(JOG revolutional feedrate with rapid traverse override)

32060	POS_AX_VELO	A12, A04	H1,P2,K1,V1,2.4,6.2
mm/min, rev/min	Initial setting for positioning axis velocity	DOUBLE	Reset
CTEQ			
828d-me41	-	10000.,10000.,10000., 36000.,36000.	- - 2/2 M
828d-me61	-	10000.,10000.,10000., 36000.,36000....	- - 2/2 M
828d-me81	-	10000.,10000.,10000., 36000.,36000....	- - 2/2 M
828d-te61	-	10000.,10000.,36000., 36000.,36000....	- - 2/2 M
828d-te81	-	10000.,10000.,36000., 36000.,36000....	- - 2/2 M
828d-te41	-	10000.,10000.,36000., 36000.,36000.	- - 2/2 M

Description: If a positioning axis is programmed in the part program without specifying the axis-specific feedrate, the feedrate entered in MD32060 \$MA_POS_AX_VELO is automatically used for this axis. The feedrate in MD32060 \$MA_POS_AX_VELO applies until an axis-specific feedrate is programmed in the part program for this positioning axis.

MD irrelevant for:

MD32060 \$MA_POS_AX_VELO is irrelevant for all axis types other than positioning axis.

Special cases:

If a ZERO velocity is entered in MD32060 \$MA_POS_AX_VELO, the positioning axis does not traverse if it is programmed without feed. If a velocity is entered in MD32060 \$MA_POS_AX_VELO that is higher than the maximum velocity of the axis (MD32000 \$MA_MAX_AX_VELO), the velocity is automatically restricted to the maximum rate.

32070	CORR_VELO	A04	2.4,6.2
%	Axis velocity for override	DOUBLE	Reset
CTEQ			
-	-	50.0	- - 2/2 M

Description: Limitation of axis velocity for handwheel override, external zero offset, continuous dressing, distance control \$AA_OFF via synchronized actions related to the JOG velocity

MD32020 \$MA_JOG_VELO,
MD32010 \$MA_JOG_VELO_RAPID,
MD32050 \$MA_JOG_REV_VELO,
MD32040 \$MA_JOG_REV_VELO_RAPID.

The maximum permissible velocity is the maximum velocity in MD32000 \$MA_MAX_AX_VELO. Velocity is limited to this value.

The conversion into linear or rotary axis velocity is made according to MD30300 \$MA_IS_ROT_AX.

32074	FRAME_OR_CORRPOS_NOTALLOWED	A01	K5,K2,2.4,6.2
-	Frame or tool length compensation are not permissible	DWORD	PowerOn
CTEQ			
-	-	0	0
		0xFFF	2/2 M

Description:

This machine data is used to define the effectiveness of the frames and tool length compensations for indexing axes, PLC axes and command axes started from synchronized actions.

Bit assignment:

Bit 0 = 0:

Programmable zero offset (TRANS) allowed for indexing axis

Bit 0 = 1:

Programmable zero offset (TRANS) forbidden for indexing axis

Bit 1 = 0:

Scale modification (SCALE) allowed for indexing axis

Bit 1 = 1:

Scale modification (SCALE) forbidden for indexing axis

Bit 2 = 0:

Direction change (MIRROR) allowed for indexing axis

Bit 2 = 1:

Direction change (MIRROR) forbidden for indexing axis

Bit 3 = 0:

DRF offset allowed for axis

Bit 3 = 1:

DRF offset forbidden for axis

Bit 4 = 0:

External zero offset allowed for axis

Bit 4 = 1:

External zero offset forbidden for axis

Bit 5 = 0:

Online tool compensation allowed for axis

Bit 5 = 1:

Online tool compensation forbidden for axis

Bit 6 = 0:

Synchronized action offset allowed for axis

Bit 6 = 1:

Synchronized action offset forbidden for axis

Bit 7 = 0:

Compile cycles offset allowed for axis

Bit 7 = 1:

Compile cycles offset forbidden for axis

Bit 8 = 0:

Axial frames and tool length compensation are NOT considered for PLC axes (bit evaluation so for compatibility reasons)

Bit 8 = 1:

Axial frames are considered for PLC axes, and the tool length compensation is considered for PLC axes which are geometry axes.

Bit 9 = 0:

Axial frames are considered for command axes, and the tool length compensation is considered for command axes which are geometry axes.

Bit 9 = 1:

Axial frames and tool length compensation are NOT considered for command axes

Bit 10 = 0:

In JOG mode, too, traversing of a geometry axis as a PLC or command axis is NOT allowed with active rotation.

Bit 10 = 1:

In JOG mode, traversing of a geometry axis as a PLC axis or command axis (static synchronized action) is allowed with active rotation (ROT frame). Traversing must be terminated prior to returning to AUTOMATIC mode (neutral axis state), as otherwise alarm16908 would be output when the mode is changed.

Bit 11 = 0:

In the 'Program interrupted' status, repositioning to the interrupt position (AUTO - JOG) takes place when changing from JOG to AUTO.

Bit 11 = 1:

Prerequisite: Bit 10 == 1 (PLC or command axis motion with active rotation in JOG mode).

In the 'Program interrupted' status, the end point of the PLC or command axis motion is taken over when changing from JOG to AUTOMATIC and the geometry axes are positioned according to the rotation

32075	MAPPED_FRAME	A01	-
-	Mapping an axial frame	STRING	PowerOn
-			
-	-	NO_AXIS	-
			7/2
			M

Description: This machine data can be used to map an axial frame onto an axial frame of another axis. This means that the description of a frame in the data management can simultaneously describe the frame of another axis with the same values. Selected data management frames can be enabled for the mapping in \$MN_MAPPED_FRAME_MASK.

32080	HANDWH_MAX_INCR_SIZE	A05, A10	H1
mm, degrees	Limitation of selected increment	DOUBLE	Reset
CTEQ			
-	-	0.0	-
			1/1
			M

Description: > 0: Limitation of size of selected increment \$MN_JOG_INCR_SIZE <Increment/VDI signal> or SD41010 \$SN_JOG_VAR_INCR_SIZE for the associated machine axis
0: No limitation

32082	HANDWH_MAX_INCR_VELO_SIZE			A05, A10, A04	-	
mm/min, rev/min	Limitation for velocity override			DOUBLE	Reset	
CTEQ						
828d-me41	-	500.,500.,500.,1800.,1800.	-	-	2/2	M
828d-me61	-	500.,500.,500.,1800.,1800.,1800.	-	-	2/2	M
828d-me81	-	500.,500.,500.,1800.,1800.,1800.	-	-	2/2	M
828d-te61	-	500.,500.,1800.,1800.,1800.,500.	-	-	2/2	M
828d-te81	-	500.,500.,1800.,1800.,1800.,500....	-	-	2/2	M
828d-te41	-	500.,500.,1800.,1800.,1800.	-	-	2/2	M

Description: For the velocity override of positioning axes:
 >0: Limitation of size of selected increment \$MN_JOG_INCR_SIZE<Increment/VDI signal> 0 or SD41010 \$SN_JOG_VAR_INCR_SIZE for the associated machine axis
 0: No limitation

32084	HANDWH_STOP_COND			EXP, A10	H1	
-	Handwheel travel behavior			DWORD	Reset	
CTEQ						
-	-	0xFF	0	0x7FF	2/2	M

Description: Definition of the response of the handwheel travel to axis-specific VDI interface signals or a context-sensitive interpolator stop:
 Bit = 0:
 Interruption or collection of the distances preset via the handwheel.
 Bit = 1:
 Cancellation of the traversing motion or no collection.
 Bit assignment:
 Bit 0: feedrate override
 Bit 1: spindle speed override
 Bit 2: feedrate stop/spindle stop or context-sensitive interpolator stop
 Bit 3: clamping procedure running (= 0 no effect)
 Bit 4: servo enable
 Bit 5: pulse enable
 For machine axis:
 Bit 6 = 0
 For handwheel travel, the maximum velocity at which the relevant machine axis can be traversed is the feedrate set in MD32020 \$MA_JOG_VELO.
 Bit 6 = 1
 For handwheel travel, the maximum velocity at which the relevant machine axis can be traversed is the feedrate set in MD32000 \$MA_MAX_AX_VELO.
 Bit 7 = 0
 The override is active in handwheel travel.

Bit 7 = 1

The override is always assumed to be 100% for handwheel travel, regardless of how the override switch is set.

Exception: override 0% is always active.

Bit 8 = 0

The override is active with DRF

Bit 8 = 1

The override is always assumed to be 100% for DRF, regardless of how the override switch is set.

Exception: override 0% is always active.

Bit 9 = 0

For handwheel travel, the maximum possible velocity with revolutional feedrate is

- with the feedrate in SD41120 \$SN_JOG_REV_SET_VELO or

- the feedrate in MD32050 \$MA_JOG_REV_VELO or

- in the case of rapid traverse with MD32040 \$MA_JOG_REV_VELO_RAPID

of the relevant machine axis calculated with the spindle or rotary axis feedrate.

Bit 9 = 1

For handwheel travel, the maximum possible velocity is with the revolutional feedrate in MD32000 \$MA_MAX_AX_VELO of the relevant machine axis. (see also bit 6)

Bit 10 = 0

For overlaid motions, \$AA_OVR is not active.

Bit 10 = 1

For overlaid motions (DRF, \$AA_OFF, external work offset, online tool offset), the override \$AA_OVR settable via synchronized actions is active.

Bit 11 = 0

With the VDI interface signal "driveReady" (= 0) missing, paths defined by the handwheel are not collected, but a traversing request is displayed. Start of a continuous JOG motion in continuous mode (\$SN_JOG_CONT_MODE_LEVELTRIGGRD 41050 = 0) or an incremental JOG motion in continuous mode (\$MN_JOG_INC_MODE_LEVELTRIGGRD 11300 = 0) is displayed as a traversing request. With "driveReady" = 1, however, the tool is not traversed, but the procedure is aborted and must be started again.

Bit 11 = 1

With the VDI interface "driveReady" missing, the paths defined by the handwheel are collected. Start of a continuous JOG motion in continuous mode (\$SN_JOG_CONT_MODE_LEVELTRIGGRD 41050 = 0) or an incremental JOG motion in continuous mode (\$MN_JOG_INC_MODE_LEVELTRIGGRD 11300 = 0) is displayed and saved as a traversing request. With "driveReady" = 1 the traversing motion is started. |

32090	HANDWH_VELO_OVERLAY_FACTOR			A10, A04	H1	
-	Ratio of JOG velocity to handwheel velocity (DRF)			DOUBLE	Reset	
CTEQ						
-	-	0.5	-	-	2/2	M

Description:

The velocity active with the handwheel in DRF can be reduced from the JOG velocity with this machine data.

The following applies to linear axes for the velocity active with DRF:

$$v_{DRF} = SD41110 \$SN_JOG_SET_VELO * MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR$$

$$\text{or when } SD41110 \$SN_JOG_SET_VELO = 0:$$

$$v_{DRF} = MD32020 \$MA_JOG_VELO * MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR$$

The velocity setting in SD41130 $\$SN_JOG_ROT_AX_SET_VELO$ applies for DRF on rotary axes instead of the value in SD41110 $\$SN_JOG_SET_VELO$.

MD irrelevant for:

JOG handwheel

Related to:

MD32020 $\$MA_JOG_VELO$ (JOG axis velocity)

SD41110 $\$SN_JOG_SET_VELO$ (JOG velocity for G94)

SD41130 $\$SN_JOG_ROT_AX_SET_VELO$ (JOG velocity for rotary axes)

32100	AX_MOTION_DIR			A07, A03, A11, -	G1,TE3,G2	
-	Traversing direction (not control direction)			DWORD	PowerOn	
-						
-	-	1	-1	1	2/2	M

Description:

The direction of movement of the machine can be reversed with this MD.

The control direction is, however, not destroyed; i.e. closed-loop control remains stable.

-1: Direction reversal

0, 1: No direction reversal

Note:

In the case of SINAMICS drives, we recommend that the direction of motion is reversed in the drive (see P1821).

32110	ENC_FEEDBACK_POL			A07, A02, A11	G2	
-	Sign actual value (control direction)			DWORD	PowerOn	
-						
-	2	1, 1	-1	1	2/2	M

Description:

The evaluation direction of the shaft encoder signals is entered in the MD.

-1: Actual value reversal

0, 1: No actual value reversal

The index[n] of the machine data is encoded as follows:

[Encoder no.]: 0 or 1

Special cases:

The axis can run off if an incorrect control direction is entered.

Depending on the setting of the corresponding limit values, one of the following alarms is displayed:

Alarm 25040 "Standstill monitoring"

Alarm 25050 "Contour monitoring"

Alarm 25060 "Speed setpoint limitation"

If an uncontrolled setpoint step change occurs on connection of a drive, the control direction might be incorrect.

Note:

In the case of SINAMICS drives, we recommend that the direction of motion is reversed in the drive (see P410).

This is obligatory if you are using DSC (see also MD32640

\$MA_STIFFNESS_CONTROL_ENABLE).

32200	POSCTRL_GAIN			A07, A11	G1,TE1,TE9,K3,S3,A2,A3,D1, G2,S1,V1	
1000/min	Servo gain factor			DOUBLE	NEW CONF	
CTEQ						
-	6	33.33333334, 33.33333334, 33.33333334...	0	2000.	7/2	M

Description:

Position controller gain, or servo gain factor.

The input/output unit for the user is [(m/min)/mm].

I.e. MD32200 \$MA_POSCTRL_GAIN[n] = 1 corresponds to a 1 mm following error at V = 1m/min.

The following machine data have default settings for adapting the standard selected input/output unit to the internal unit [rev/s].

- MD10230 \$MN_SCALING_FACTORS_USER_DEF[9] = 16.666667S
- MD10220 \$MN_SCALING_USER_DEF_MASK = 0x200; (bit no 9 as hex value).

If the value "0" is entered the position controller is opened.

When entering the servo gain factor it is important to take into account that the gain factor of the whole position control loop is still dependent on other parameters of the controlled system. A distinction should be made between a "desired servo gain factor" (MD32200 \$MA_POSCTRL_GAIN) and an "actual servo gain factor" (produced by the machine). Only when all the parameters of the control loop are matched will these servo gain factors be the same.

Other factors are:

- Speed setpoint adjustment (MD32260 \$MA_RATED_VELO, MD32250 \$MA_RATED_OUTVAL)
or automatic speed setpoint interface adjustment (with MD32250 \$MA_RATED_OUTVAL = 0 etc.)
- Correct actual value recording of the position encoder (no. of encoder marks, high resolution, encoder mounting location, gear etc.)
- Correct actual speed recording on the drive (standardization, possibly tacho compensation, tacho generator)

Note:

Axes which interpolate together and are to perform a machining operation, must either have the same gain setting (i.e. have the identical following error = 45° slope at the same velocity) or they must be matched via MD32910 \$MA_DYN_MATCH_TIME.

The actual servo gain factor can be checked by means of the following error (in the service display).

In the case of analog axes, a drift compensation must be performed prior to the control.

The index [n] of the machine data has the following coding:

[control parameter set no.]: 0-5

32250	RATED_OUTVAL			A01, A11	A3,D1,G2	
%	Rated output voltage			DOUBLE	NEW CONF	
CTEQ						
-	1	0.0	0.0	200	1/1	M

Description:

a.)

Scaling of the manipulated variable with analog drives:

The value of the speed setpoint in percent is to be entered in this MD, in relation to the maximum speed setpoint at which the motor speed specified in MD32260 \$MA_RATED_VELO[n] is reached.

Related to:

MD32250 \$MA_RATED_OUTVAL[n] only makes sense in combination with MD32260 \$MA_RATED_VELO[n].

Example:

1. At a voltage of 5V, the drive reaches a speed of
1875 rpm ==> RATED_OUTVAL = 50%, RATED_VELO = 11250 [degrees/s]
2. At a voltage of 8V, the drive reaches a speed of
3000 rpm ==> RATED_OUTVAL = 80%, RATED_VELO = 18000 [degrees/s]
3. At a voltage of 1.5V, the drive reaches a speed of
562.5 rpm ==> RATED_OUTVAL = 15%, RATED_VELO = 3375 [degrees/s]

All three examples are possible for one and the same drive/converter. The ratio of the two values is decisive; it is the same in all three examples. MD32250 \$MA_RATED_OUTVAL and MD32260 \$MA_RATED_VELO describe physical characteristics of converter and drive; they can therefore only be determined by means of a measurement or commissioning instructions (converter, drive).

b.)

Scaling of the manipulated variable with digital PROFIdrive drives:

Default value "0" declares MD32250 \$MA_RATED_OUTVAL and MD32260 \$MA_RATED_VELO as invalid. Scaling of the manipulated variable is automatically determined and adjusted from the drive parameters instead.

Otherwise (MD32250 \$MA_RATED_OUTVAL unequal to zero), the scaling of the manipulated variable is not determined from the drive (for example non-Siemens PROFIdrive drives), but set with RATED_VELO and RATED_OUTVAL, even in the case of these, irrespective of the scaling active on the drive side. In this case, the following applies:

Scaling of the manipulated variable on the drive = $RATED_VELO / RATED_OUTVAL$

Further scalings from drive parameters, such as torque scaling, are not active if \$MA_RATED_OUTVAL is not equal to zero, the values based on it remain zero.

In the case of simultaneous operation of analog and PROFIdrive drives, the settings for the analog axes must be adjusted as described in a.).

32260	RATED_VELO			A01, A11	A3,D1,G2	
rev/min	Rated motor speed			DOUBLE	NEW CONF	
CTEQ						
-	1	3000.0	-	-	1/1	M

Description:

Only applies when:

MD32250 \$MA_RATED_OUTVAL is set greater than 0.

The drive speed (scaled on the drive) that is reached with the percentual speed setpoint specified in MD32250 \$MA_RATED_OUTVAL[n] must be entered in the MD.

Related to:

MD32260 \$MA_RATED_VELO[n] only makes sense in combination with MD32250 \$MA_RATED_OUTVAL[n].

32300	MAX_AX_ACCEL			A11, A04, -	M3,TE6,Z3,H1,K3,M1,A3,B1, B2,K1,V1,2.4	
m/s ² , rev/s ²	maximum axis acceleration			DOUBLE	NEW CONF	
CTEQ						
-	5	2.0, 2.0, 2.0, 1.0, 1.0,2.0, 2.0...	1.0e-3	-	2/2	M

Description:

Maximum acceleration, i.e. change in setpoint velocity, which is to act upon the axis. The value limits both positive and negative axis acceleration.

The maximum angular or linear axis acceleration must be entered dependent upon machine data MD30300 \$MA_IS_ROT_AX.

In the case of linear interpolation of the axes in a grouping, the grouping is limited in such a way that no axis is overloaded. With regard to contour accuracy, the control dynamic behavior has to be taken into account.

Not relevant for error states that lead to quick stop.

Each field element corresponds to a G code in the 59th G code group.

Related to:

MD32210 \$MA_MAX_ACCEL_OVL_FACTOR
MD32434 \$MA_G00_ACCEL_FACTOR
MD32433 \$MA_SOFT_ACCEL_FACTOR
MD20610 \$MC_ADD_MOVE_ACCEL_RESERVE
MD20602 \$MC_CURV_EFFECT_ON_PATH_ACCEL

32310	MAX_ACCEL_OVL_FACTOR			A04	B1	
-	Overload factor for axial velocity steps			DOUBLE	NEW CONF	
CTEQ						
-	5	1.2, 1.2, 1.2, 1.2, 1.2	-	-	1/1	U

Description:

The overload factor limits the velocity jump of the machine axis on block transition. The value entered is related to the value of MD32300 \$MA_MAX_AX_ACCEL (axis acceleration) and states by how much the maximum acceleration can be exceeded for one IPO cycle.

Related to:

MD32300 \$MA_MAX_AX_ACCEL (axis acceleration)

MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO (interpolator clock)

Each field element corresponds to a G code in the 59th G group.

32320	DYN_LIMIT_RESET_MASK			A05, A06, A10, A04	-	
-	Reset behavior of dynamic response limitation.			DWORD	Reset	
CTEQ						
-	-	0	0	0x03	2/2	M

Description:

MD32320 \$MA_DYN_LIMIT_RESET_MASK is used to set the reset response of functions limiting dynamic response for specific axes and groups.

The MD is bit-coded, bit 0 (LSB) and bit 1 are currently allocated.

Bit 0 = 0:

Programmed ACC, VELOLIM and JERKLIM are reset to 100% with channel reset/M30 if the channel-specific MD22410 \$MC_F_VALUES_ACTIVE_AFTER_RESET is also zero.

For spindle mode, programmed ACC and VELOLIM are reset to 100% with channel reset/M30 if MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET is zero and the channel-specific MD22400 \$MC_S_VALUES_ACTIVE_AFTER_RESET is also zero.

Bit 0 = 1:

Programmed ACC, VELOLIM and JERKLIM are retained beyond channel reset/M30.

Bit 1 = 0:

Programmed ACCLIMA, VELOLIMA and JERKLIMA are reset to 100% with channel reset/M30, if MD22410 \$MC_F_VALUES_ACTIVE_AFTER_RESET is also zero.

Bit 1 = 1:

Programmed ACCLIMA, VELOLIMA and JERKLIMA are retained beyond channel reset//M30.

Notes:

In MD22410 \$MC_F_VALUES_ACTIVE_AFTER_RESET, the reset responses of the dynamic instructions ACC, VELOLIM, JERKLIM, ACCLIMA, VELOLIMA and JERKLIMA are set channel specifically. If the MD is set, then the values are also retained.

For spindle mode, the values for ACC and VELOLIM are also retained if MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET is not equal to zero or the channel-specific MD22400 \$MC_S_VALUES_ACTIVE_AFTER_RESET is not equal to zero.

32400	AX_JERK_ENABLE			A07, A04, -	B2	
-	Axial jerk limitation			BOOLEAN	NEW CONF	
CTEQ						
-	-	FALSE	-	-	2/2	M

Description:

Enables the function of an axial jerk limitation.

The limitation is set via a time constant; it is always active.

The limitation works independently of the limitations "path-related maximum jerk", "knee-shaped acceleration characteristic" and the axial jerk limitation of the axes that are operated in JOG mode or positioning axis mode.

Related to:

MD32410 \$MA_AX_JERK_TIME (time constant for axial jerk limitation)

32402	AX_JERK_MODE	A07, A04	B2,G2,B3
-	Filter type for axial jerk limitation	BYTE	PowerOn
CTEQ			
-	-	2	1
		3	2/2
			M

Description:

Filter type for axial jerk limitation:

1: 2nd order filter (as in SW 1 through 4)

2: Moving averaging (SW 5 and higher)

3: Bandstop filter (SW 6 and higher)

Type 2 requires more computing time, but causes smaller contour errors for the same smoothing effect, or smoother movements at the same accuracy.

Type 2 is recommended; type 1 is set as a default value for reasons of compatibility.

The maximum jerk is set in the time constant MD32410 \$MA_AX_JERK_TIME.

Recommended values for type 1:

Min. 0.03 s; max. 0.06s.

Recommended values for type 2:

Min. 1 position-control cycle; max. 16 position-control cycles

At a position-control cycle of 2ms, this corresponds to 0.002 to 0.032 seconds.

Type 3 requires the setting of MD32410 \$MA_AX_JERK_TIME, MD32412 \$MA_AX_JERK_FREQ and MD32414 \$MA_AX_JERK_DAMP.

To parameterize a simple bandstop filter, we recommend setting MD32410 \$MA_AX_JERK_TIME=0, which automatically sets "denominator frequency = numerator frequency = blocking frequency = MD32412 \$MA_AX_JERK_FREQ".

However, MD32410 \$MA_AX_JERK_TIME>0 is used to set a specific denominator frequency, which makes it possible to implement a bandstop filter with amplitude increase for frequencies beyond the blocking frequency.

MD32402 \$MA_AX_JERK_MODE is only active if MD32400 \$MA_AX_JERK_ENABLE has been set to 1.

Special cases, errors:

The machine data must be same for all axes of an axis container.

Related to:

MD32400 \$MA_AX_JERK_ENABLE

MD32410 \$MA_AX_JERK_TIME

and for type 3: MD32412 \$MA_AX_JERK_FREQ and MD32414 \$MA_AX_JERK_DAMP

2.4 Axis-specific machine data

32410	AX_JERK_TIME	A07, A04	G1,TE1,S3,B2,G2
s	Time constant for axial jerk filter	DOUBLE	NEW CONF
-			
-	-	0.001	- - 2/2 M

Description: Time constant of the axial jerk filter which causes a smoother axis setpoint characteristic. The jerk filter will only be active, if the time constant is higher than a position control cycle.
 Not active in case of errors that cause a change in follow-up mode (for example EMERGENCY STOP99):
 Special cases:
 Machine axes that are supposed to be interpolating with one another, must have the same effective jerk filtering (for example the same time constant for tapping without compensating chuck).
 Related to:
 MD32400 \$MA_AX_JERK_ENABLE (axial jerk limitation)

32415	EQUIV_CPREC_TIME	A07, A04	\$MA_AX_JERK_TIME, \$MC_CPREC_WITH_FFW
s	Time constant for the programmable contour accuracy	DOUBLE	NEW CONF
-			
-	-	0	- - 2/2 M

Description: The data states the jerk filter time constant at which the contour error with active feedforward control is negligibly small.

32420	JOG_AND_POS_JERK_ENABLE	A04	G1,H1,P2,S3,B2
-	Default setting of axis jerk limitation	BOOLEAN	Reset
CTEQ			
-	-	FALSE	- - 2/2 M

Description: Enables the function of the axis-specific jerk limitation for the operating modes JOG, REF and positioning axis mode.
 1: Axial jerk limitation for JOG mode and positioning axis mode
 0: No jerk limitation for JOG mode and positioning axis mode
 The maximum jerk occurring is defined in MD32430 \$MA_JOG_AND_POS_MAX_JERK.
 Related to:
 MD32430 \$MA_JOG_AND_POS_MAX_JERK (axial jerk)

32430	JOG_AND_POS_MAX_JERK			A04	G1,P2,S3,B2	
m/s ³ , rev/s ³	Axial jerk			DOUBLE	NEW CONF	
CTEQ						
828d-me41	-	100,100,100,100,100	1.e-9	-	2/2	M
828d-me61	-	100,100,100,100,100, 100	1.e-9	-	2/2	M
828d-me81	-	100,100,100,100,100, 100	1.e-9	-	2/2	M
828d-te61	-	100,100,100,100,100, 100	1.e-9	-	2/2	M
828d-te81	-	100,100,100,100,100, 100,100,100	1.e-9	-	2/2	M
828d-te41	-	100,100,100,100,100	1.e-9	-	2/2	M

Description: The jerk limit value limits the rate of change of axis acceleration in JOG and REF modes as well as in positioning axis mode with \$MN_POS_DYN_MODE=0. The setting and time calculation are made as for MD20600 \$MC_MAX_PATH_JERK (path-related maximum jerk).

Not relevant for:

- Path interpolation
- Error states that lead to quick stop.

Related to:

MD32420 \$MA_JOG_AND_POS_JERK_ENABLE (initial setting of axial jerk limitation)

MD18960 \$MN_POS_DYN_MODE

32431	MAX_AX_JERK			A04	B1,B2	
m/s ³ , rev/s ³	maximum axial jerk for path movement			DOUBLE	NEW CONF	
-						
-	5	1.e6, 1.e6, 1.e6, 20., 20.,1.e6...	1.e-9	-	2/2	I

Description: Maximum axial jerk for path motion
Each field element corresponds to a G code in the 59th G code group.

32432	PATH_TRANS_JERK_LIM			A04	B1,B2	
m/s ³ , rev/s ³	maximum axial jerk at block transition in continuous-path mode			DOUBLE	NEW CONF	
CTEQ						
-	5	1.e6, 1.e6, 1.e6, 20., 20.,1.e6...	-	-	2/2	I

Description: The control limits the jerk (acceleration jump) at a block transition between contour sections of different curvature to the value set with active jerk limitation.

Not relevant for:

Exact stop

There is an entry for each G code from the 59th G code group (dynamic G code group).

Related to:

Path control, SOFT type of acceleration

2.4 Axis-specific machine data

32433	SOFT_ACCEL_FACTOR			A04, -	TE9,B1,B2	
-	Scaling of acceleration limitation with SOFT			DOUBLE	NEW CONF	
-						
-	5	1., 1., 1., 1., 1.	1e-9	-	3/3	I

Description: Scaling of acceleration limitation with SOFT.
 Relevant axial acceleration limitation for SOFT =:
 (MD32433 \$MA_SOFT_ACCEL_FACTOR[...] * MD32300 \$MA_MAX_AX_ACCEL[...])
 Each field element corresponds to a G code in the 59th G code group.

32434	G00_ACCEL_FACTOR			A04, -	TE9,B1,B2	
-	Scaling of acceleration limitation with G00.			DOUBLE	NEW CONF	
-						
-	-	1.	1e-9	-	3/3	I

Description: Scaling of the acceleration limitation with G00.
 Relevant axial acceleration limitation for G00 =:
 (MD32433 \$MA_G00_ACCEL_FACTOR[...] * MD32300 \$MA_MAX_AX_ACCEL[...])

32435	G00_JERK_FACTOR			A04	B1,B2	
-	Scaling of jerk limitation with G00.			DOUBLE	NEW CONF	
-						
-	-	1.	1e-9	-	3/3	I

Description: Scaling of the jerk limitation with G00.
 Relevant axial jerk limitation for G00 =:
 (MD32435 \$MA_G00_JERK_FACTOR[...] * MD32431 \$MA_MAX_AX_JERK[...])

32437	AX_JERK_VEL0			A04	B1	
mm/min, rev/min	Velocity threshold for linear jerk adjustment			DOUBLE	NEW CONF	
-						
828d-me41	5	3000, 3000, 3000, 3000, 3000,3000...	-	-	2/2	M
828d-me61	5	3000, 3000, 3000, 3000, 3000,3000...	-	-	2/2	M
828d-me81	5	3000, 3000, 3000, 3000, 3000,3000...	-	-	2/2	M
828d-te61	5	3000, 3000, 3000, 3000, 3000...	-	-	2/2	M
828d-te81	5	3000, 3000, 3000, 3000, 3000...	-	-	2/2	M
828d-te41	5	3000, 3000, 3000, 3000, 3000...	-	-	2/2	M

Description: Velocity at and above which the permissible jerk of an axis increases in a linear fashion.
 Jerk adjustment only becomes active if MD \$MA_MAX_AX_JERK_FACTOR is > 1.0.
 There is an entry for each dynamic G code group.
 See also MD \$MA_AX_JERK_VEL1 and \$MA_MAX_AX_JERK_FACTOR.

32438	AX_JERK_VEL1			A04	B1	
mm/min, rev/min	Velocity threshold for linear jerk adjustment			DOUBLE	NEW CONF	
-						
828d-me41	5	6000, 6000, 6000, 6000, 6000,6000...	-	-	2/2	M
828d-me61	5	6000, 6000, 6000, 6000, 6000,6000...	-	-	2/2	M
828d-me81	5	6000, 6000, 6000, 6000, 6000,6000...	-	-	2/2	M
828d-te61	5	6000, 6000, 6000, 6000, 6000...	-	-	2/2	M
828d-te81	5	6000, 6000, 6000, 6000, 6000...	-	-	2/2	M
828d-te41	5	6000, 6000, 6000, 6000, 6000...	-	-	2/2	M

Description: Velocity at and above which the permissible jerk of an axis switches from increasing in a linear fashion to the saturation defined in MD \$MA_MAX_AX_JERK_FACTOR.
The value of this velocity must be greater than the value set with MD \$MA_AX_JERK_VEL0.
Jerk adjustment becomes active only if MD \$MA_MAX_AX_JERK_FACTOR is > 1.0.
There is an entry for each dynamic G code group.
See also MD \$MA_AX_JERK_VEL0 and \$MA_MAX_AX_JERK_FACTOR

32439	MAX_AX_JERK_FACTOR			A04	B1	
-	Factor for jerk adjustment at high velocities			DOUBLE	NEW CONF	
-						
-	5	1.0, 1.0, 1.0, 1.0, 1.0	1.0	-	2/2	I

Description: Factor for setting adaptive jerk adjustment for an axis.
Jerk adjustment becomes active only if the value of this MD is greater than 1.
There is an entry for each dynamic G code group.
See also MD \$MA_AX_JERK_VEL0 and \$MA_AX_JERK_VEL1.

32440	LOOKAH_FREQUENCY			EXP, A04	B1	
-	Smoothing frequency for Look Ahead			DOUBLE	NEW CONF	
-						
-	-	10.	-	-	2/2	M

Description: Acceleration procedures in continuous-path mode with Look Ahead which execute with a higher frequency than that parameterized in this MD are smoothed as a function of the parameterization in MD20460 \$MC_LOOKAH_SMOOTH_FACTOR.
It is always the minimum of all the axes participating in the path which is determined.
If vibrations are aroused in the mechanics of this axis and if their frequency is known, then this MD should be set to a lower value than this frequency.

2.4 Axis-specific machine data

32450	BACKLASH			A09	K3,G2	
mm, degrees	Backlash			DOUBLE	NEW CONF	
-						
-	2	0.0, 0.0	-	-	2/2	I

Description: Backlash on reversal between positive and negative travel directions.
 Input of the compensation value is

- positive, if the encoder is leading the machine part (normal situation)
- negative, if the encoder is behind the machine part.

Backlash compensation is not active when 0 is entered.
 Backlash compensation is always active after reference point approach in all operating modes.
 Special cases:
 A specific backlash on reversal must be entered for each measuring system.
 Related to:
 MD30200 \$MA_NUM_ENCS (number of measuring systems)
 MD36500 \$MA_ENC_CHANGE_TOL
 (Maximum tolerance at actual position value change)

32452	BACKLASH_FACTOR			A09	K3,G2,S1,V1	
-	Evaluation factor for backlash			DOUBLE	NEW CONF	
-						
-	6	1.0, 1.0, 1.0, 1.0, 1.0, 1.0	0.01	100.0	2/2	I

Description: Evaluation factor for backlash.
 The machine data enables the backlash defined in MD32450 \$MA_BACKLASH to be changed as a function of the parameter set, in order to take a gear stage dependent backlash into account, for example.
 Related to:
 MD32450 \$MA_BACKLASH[n]

32490	FRICT_COMP_MODE			A09	K3	
-	Type of friction compensation			BYTE	PowerOn	
-						
-	1	1	0	2	2/2	M

Description: 0: No friction compensation
 1: Friction compensation with constant injection value or adaptive characteristic
 2: Friction compensation with learned characteristic via neural network

32500	FRICT_COMP_ENABLE		A09	K3,G2		
-	Friction compensation active		BOOLEAN	NEW CONF		
-						
-	-	FALSE	-	-	2/2	M

Description:

1: Friction compensation is enabled for this axis.
Depending on the setting of MD32490 \$MA_FRICT_COMP_MODE, either "friction compensation with constant modulation factor" or "QEC with neural networks" becomes active.
In the case of neural QEC, the machine data should not be set to "1" until a valid characteristic has been "learnt".
During the learning stage, the compensation values are added on independently of the contents of this machine data.

0: Friction compensation is not enabled for this axis.
Thus, no friction compensation values are entered.

Related to:

MD32490 \$MA_FRICT_COMP_MODE
Friction compensation type

MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE
Friction compensation adaptation active

MD32520 \$MA_FRICT_COMP_CONST_MAX
Maximum friction compensation value

MD32540 \$MA_FRICT_COMP_TIME
Friction compensation time constant

MD38010 \$MA_MM_QEC_MAX_POINTS
Number of interpolation points for QEC with neural networks

32510	FRICT_COMP_ADAPT_ENABLE		EXP, A09	K3		
-	Adaptation friction compensation active		BOOLEAN	NEW CONF		
-						
-	1	FALSE	-	-	2/2	M

Description:

1: Friction compensation with amplitude adaptation is enabled for the axis. Quadrant errors on circular contours can be compensated with friction compensation.
The amplitude of the friction compensation value required to be added on is frequently not constant over the entire acceleration range. That is, a lower compensation value needs to be entered for optimum friction compensation for higher accelerations than for lower accelerations.
The parameters of the adaptation curve have to be determined, and entered in the machine data.

0: Friction compensation with amplitude adaptation is not enabled for the axis.

MD irrelevant for:

MD32500 \$MA_FRICT_COMP_ENABLE = 0
MD32490 \$MA_FRICT_COMP_MODE = 2

Related to:

MD32500 \$MA_FRICT_COMP_ENABLE
Friction compensation active

MD32520 \$MA_FRICT_COMP_CONST_MAX
Maximum friction compensation value

2.4 Axis-specific machine data

MD32530 \$MA_FRICT_COMP_CONST_MIN
 Minimum friction compensation value
 MD32550 \$MA_FRICT_COMP_ACCEL1
 Adaptation acceleration value 1
 MD32560 \$MA_FRICT_COMP_ACCEL2
 Adaptation acceleration value 2
 MD32570 \$MA_FRICT_COMP_ACCEL3
 Adaptation acceleration value 3
 MD32540 \$MA_FRICT_COMP_TIME
 Friction compensation time constant

32520	FRICT_COMP_CONST_MAX	EXP, A09	K3
mm/min, rev/min	Maximum friction compensation value	DOUBLE	NEW CONF
-			
-	1	0.0	-
			2/2 M

Description: If adaptation is inactive (MD32510=0), the maximum friction compensation is applied throughout the entire acceleration range.
 If adaptation is active (MD32510=1), the maximum friction compensation is applied in accordance with the adaptation curve.
 In the 1st acceleration range ($a < MD32550$), the switching amplitude = $MD32520 * (a/MD32550)$.
 In the 2nd acceleration range ($MD32550 \leq a \leq MD32560$), the switching amplitude = $MD32520$.
 In the 3rd acceleration range ($MD32560 < a < MD32570$), the switching amplitude = $MD32520 + (MD32530 - MD32520) / (MD32570 - MD32560) * (a - MD32560)$.
 In the 4th acceleration range ($MD32570 \leq a$), the switching amplitude = $MD32530$.
 Not relevant for:
 MD32500 \$MA_FRICT_COMP_ENABLE = 0
 MD32490 \$MA_FRICT_COMP_MODE = 2 (neural QEC)
 Related to:
 MD32500 \$MA_FRICT_COMP_ENABLE
 Friction compensation active
 MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE
 Friction compensation adaptation active
 MD32530 \$MA_FRICT_COMP_CONST_MIN
 Minimum friction compensation value
 MD32550 \$MA_FRICT_COMP_ACCEL1
 Adaptation acceleration value 1
 MD32560 \$MA_FRICT_COMP_ACCEL2
 Adaptation acceleration value 2
 MD32570 \$MA_FRICT_COMP_ACCEL3
 Adaptation acceleration value 3
 MD32540 \$MA_FRICT_COMP_TIME
 Friction compensation time constant

32530	FRICT_COMP_CONST_MIN	EXP, A09	K3
mm/min, rev/min	Minimum friction compensation value	DOUBLE	NEW CONF
-			
-	1	0.0	-

Description: The minimum friction compensation value is active only if "Friction compensation with adaptation" (MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE=1) is active. The amplitude of the friction compensation value is entered in the 4th acceleration range (MD32570 \$MA_FRICT_COMP_ACCEL3 <= a).

MD irrelevant for:

MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE = 0

MD32490 \$MA_FRICT_COMP_MODE = 2 (neural QEC)

Special cases:

In special cases, the value for FRICT_COMP_CONST_MIN may be even higher than for MD32520 \$MA_FRICT_COMP_CONST_MAX.

Related to:

MD32500 \$MA_FRICT_COMP_ENABLE

Friction compensation active

MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE

Friction compensation adaptation active

MD32520 \$MA_FRICT_COMP_CONST_MAX

Maximum friction compensation value

MD32550 \$MA_FRICT_COMP_ACCEL1

Adaptation acceleration value 1

MD32560 \$MA_FRICT_COMP_ACCEL2

Adaptation acceleration value 2

MD32570 \$MA_FRICT_COMP_ACCEL3

Adaptation acceleration value 3

MD32540 \$MA_FRICT_COMP_TIME

Friction compensation time constant

32540	FRICT_COMP_TIME	EXP, A09	K3
s	Friction compensation time constant	DOUBLE	NEW CONF
-			
-	1	0.015	-

Description: The friction compensation value is entered via a DT1 filter. The add-on amplitude decays in accordance with the time constant.

MD irrelevant for:

MD32500 \$MA_FRICT_COMP_ENABLE = 0

Related to:

MD32500 \$MA_FRICT_COMP_ENABLE

Friction compensation active

MD32520 \$MA_FRICT_COMP_CONST_MAX

Maximum friction compensation value

2.4 Axis-specific machine data

32550	FRICT_COMP_ACCEL1			EXP, A09	K3	
m/s ² , rev/s ²	Adaptation acceleration value 1			DOUBLE	NEW CONF	
-						
-	1	0.0	-	-	2/2	M

Description: The adaptation acceleration value is only required if "Friction compensation with adaptation" (MD32510=1) is active.

The adaptation acceleration values 1 to 3 are interpolation points for defining the adaptation curve. The adaptation curve is subdivided into 4 ranges, in each of which a different friction compensation value applies.

For the 1st range (a < MD32550), the add-on amplitude = a * MD32520/ MD32550
MD irrelevant for:

```
MD32510 $MA_FRICT_COMP_ADAPT_ENABLE = 0
MD32490 $MA_FRICT_COMP_MODE = 2
```

Related to:

```
MD32500 $MA_FRICT_COMP_ENABLE
Friction compensation active
MD32510 $MA_FRICT_COMP_ADAPT_ENABLE
Friction compensation adaptation active
MD32520 $MA_FRICT_COMP_CONST_MAX
Maximum friction compensation value
MD32530 $MA_FRICT_COMP_CONST_MIN
Minimum friction compensation value
MD32560 $MA_FRICT_COMP_ACCEL2
Adaptation acceleration value 2
MD32570 $MA_FRICT_COMP_ACCEL3
Adaptation acceleration value 3
MD32540 $MA_FRICT_COMP_TIME
Friction compensation time constant
```

32560	FRICT_COMP_ACCEL2			EXP, A09	K3	
m/s ² , rev/s ²	Adaptation acceleration value 2			DOUBLE	NEW CONF	
-						
-	1	0.0	-	-	7/2	M

Description: The adaptation acceleration value is only required if "Friction compensation with adaptation" (MD32510=1) is active.

Adaptation acceleration values 1 to 3 are interpolation points for defining the adaptation curve. The adaptation curve is subdivided into 4 ranges, in each of which a different friction compensation value applies.

In the 1st acceleration range (a < MD32550), the switching amplitude = MD32520 * (a/MD32550).

In the 2nd acceleration range (MD32550 <= a <= MD32560), the switching amplitude = MD32520.

In the 3rd acceleration range (MD32560 < a < MD32570), the switching amplitude = MD32520 + (MD32530-MD32520)/(MD32570-MD32560) * (a - MD32560).

In the 4th acceleration range (MD32570 <= a), the switching amplitude = MD32530.

Not relevant for:

```
MD32510 $MA_FRICT_COMP_ADAPT_ENABLE = 0
MD32490 $MA_FRICT_COMP_MODE = 2
```

Related to:

MD32500 \$MA_FRICT_COMP_ENABLE
Friction compensation active
MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE
Friction compensation adaptation active
MD32520 \$MA_FRICT_COMP_CONST_MAX
Maximum friction compensation value
MD32530 \$MA_FRICT_COMP_CONST_MIN
Minimum friction compensation value
MD32550 \$MA_FRICT_COMP_ACCEL1
Adaptation acceleration value 1
MD32570 \$MA_FRICT_COMP_ACCEL3
Adaptation acceleration value 3
MD32540 \$MA_FRICT_COMP_TIME
Friction compensation time constant

32570	FRICT_COMP_ACCEL3	EXP, A09	K3
m/s ² , rev/s ²	Adaptation acceleration value 3	DOUBLE	NEW CONF
-			
-	1	0.0	-
			2/2
			M

Description:

The adaptation acceleration value is only required if "Friction compensation with adaptation" (MD32510=1) is active.

Adaptation acceleration values 1 to 3 are interpolation points for defining the adaptation curve. The adaptation curve is subdivided into 4 ranges, in each of which a different friction compensation value applies.

In the 1st acceleration range ($a < MD32550$), the switching amplitude = $MD32520 * (a/MD32550)$.

In the 2nd acceleration range ($MD32550 \leq a \leq MD32560$), the switching amplitude = $MD32520$.

In the 3rd acceleration range ($MD32560 < a < MD32570$), the switching amplitude = $MD32520 + (MD32530 - MD32520) / (MD32570 - MD32560) * (a - MD32560)$.

In the 4th acceleration range ($MD32570 \leq a$), the switching amplitude = $MD32530$.

Not relevant for:

MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE = 0
MD32490 \$MA_FRICT_COMP_MODE = 2

Related to:

MD32500 \$MA_FRICT_COMP_ENABLE
Friction compensation active
MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE
Friction compensation adaptation active
MD32520 \$MA_FRICT_COMP_CONST_MAX
Maximum friction compensation value
MD32530 \$MA_FRICT_COMP_CONST_MIN
Minimum friction compensation value

2.4 Axis-specific machine data

MD32550 \$MA_FRICT_COMP_ACCEL1
 Adaptation acceleration value 1
 MD32560 \$MA_FRICT_COMP_ACCEL2
 Adaptation acceleration value 2
 MD32540 \$MA_FRICT_COMP_TIME
 Friction compensation time constant

32580	FRICT_COMP_INC_FACTOR				A09	K3	
%	Weighting of friction compensation value with short travel motions.				DOUBLE	NEW CONF	
-							
-	1	0.0	0	100.0	2/2	M	

Description: The optimum friction compensation value determined by the circularity test can cause overcompensation of this axis if compensation is activated and axial positioning movements are short.
 In such cases, a better setting can be achieved by reducing the amplitude of the friction compensation value and acts on all positioning blocks that are made within an interpolation cycle of the control.
 The factor that has to be entered can be determined empirically and can be different from axis to axis because of the different friction conditions. The input range is between 0 and 100% of the value determined by the circularity test.
 The default setting is 0; so that no compensation is performed for short traversing movements.
 Related to:
 MD32500 \$MA_FRICT_COMP_ENABLE Friction compensation active

32610	VELO_FFW_WEIGHT				A07, A09	G1,TE1,K3,S3,A3,G2,S1,V1	
-	Feedforward control factor f. velocity/speed feedforward control				DOUBLE	NEW CONF	
-							
-	6	1.0, 1.0, 1.0, 1.0, 1.0, 1.0	-	-	2/2	M	

Description: Weighting factor for feedforward control. Is normally = 1.0 on digital drives, since these keep the setpoint speed exactly .
 On analog drives, this factor can be used to compensate the gain error of the drive actuator, so that the actual speed becomes exactly equal to the setpoint speed (this reduces the following error with feedforward control).
 On both drive types, the effect of the feedforward control can be continuously reduced with a factor of < 1.0, if the machine moves too abruptly and other measures (e.g. jerk limitation) are not to be used. This also reduces possibly existing overshoots; however, the error increases on curved contours, e.g. on a circle. With 0.0, you have a pure position controller without feedforward control.
 Contour monitoring takes into account factors < 1.0.
 In individual cases, it can, however, become necessary to increase MD CONTOUR_TOL.

32620	FFW_MODE		A07, A09	G1,K3,S3,G2,S1		
-	Feedforward control mode		BYTE	Reset		
-						
-	-	3	0	4	1/1	M

Description: FFW_MODE defines the feedforward control mode to be applied on an axis-specific basis:

0 = No feedforward control

1 = Speed feedforward control with PT1 balancing

2 = Torque feedforward control (only for SINAMICS) with PT1 balancing

3 = Speed feedforward control with Tt balancing

4 = Torque feedforward control (only for SINAMICS) with Tt balancing

The high-level language instructions FFWON and FFEOF are used to activate and deactivate feedforward control for specific channels on all axes.

To prevent feedforward control from being affected by these instructions on individual axes, you can define that it is always activated or always deactivated in machine data FFW_ACTIVATION_MODE (see also FFW_ACTIVATION_MODE).

Torque feedforward control must be activated via the global option data \$ON_FFW_MODE_MASK.

If a feedforward control mode is selected (speed or torque feedforward control), MD32630 \$MA_FFW_ACTIVATION_MODE can be used to program in addition whether feedforward control can be activated or deactivated by the part program.

Note for SINAMICS drives with torque feedforward control selected:

Alarm 26016 refers to the current machine data if

the telegram used (see \$MN_DRIVE_TELEGRAM_TYPE) does not support the torque feedforward control function. Remedy: Use telegram 136.

Torque feedforward control is an option that must be activated.

Related to:

MD32630 \$MA_FFW_ACTIVATION_MODE

MD32610 \$MA_VELO_FFW_WEIGHT

MD32650 \$MA_AX_INERTIA

32630	FFW_ACTIVATION_MODE		A07, A09	K3,G2		
-	Activate feedforward control from program		BYTE	Reset		
CTEQ						
-	-	1	0	2	2/2	M

Description: MD32630 \$FFW_ACTIVATION_MODE can be used to define whether the feedforward control for this axis/spindle can be switched on and off by the part program.
0 = The feedforward control cannot be switched on or off by the high-level language elements FFWON and FFEOF respectively.

For the axis/spindle, the state specified by MD32620 \$MA_FFW_MODE is therefore always effective.

1 = The feedforward control can be switched on and off by the part program with FFWON and FFEOF respectively.

The instruction FFWON/FFEOF becomes active immediately

2 = The feedforward control can be switched on and off by the part program with FFWON and FFEOF respectively.

The instruction FFWON/FFEOF does not become active until the next axis standstill

2.4 Axis-specific machine data

The default setting is specified by the channel-specific MD20150 \$MC_GCODE_RESET_VALUES. This setting is valid even before the first NC block is executed.

Notes:

The last valid state continues to be active even after Reset (and therefore also with JOG).

As the feedforward control of all axes of the channel is switched on and off by FFWON and FFWOF respectively, MD32630 \$MA_FFW_ACTIVATION_MODE should be set identically for axes interpolating with one another.

Switching feedforward control on or off while the axis/spindle is traversing may cause compensation operations in the control loop. Interpolating axes are therefore stopped by the part program if such switching operations occur (internal stop Stop G09 is triggered).

Related to:

MD32620 \$MA_FFW_MODE

MD20150 \$MC_GCODE_RESET_VALUES

32640	STIFFNESS_CONTROL_ENABLE			A01, A07	TE3,G2	
-	Dynamic stiffness control			BOOLEAN	NEW CONF	
CTEQ						
-	1	TRUE	-	-	1/1	M

Description:

Activate dynamic stiffness control, if bit is set.

Higher servo gain factors are possible if stiffness control is active (MD32200 \$MA_POSCTRL_GAIN).

Notes:

The availability of this function is determined by the drive used (the drive has to support the DSC function).

Note on PROFIdrive drives:

Alarm 26017 refers to this machine data if:

a. The PROFIdrive telegram used (see \$MN_DRIVE_TELEGRAM_TYPE) does not support the DSC function or does not contain an encoder 1 (such as Tel. 118), to which the DSC scaling for PZD XERR refers. Remedy: Use a sufficiently powerful telegram which also includes encoder 1 (e.g. Tel. 106, 116).

b. Specifically for SINAMICS drives, if inversion of the encoder signal is parameterized in \$MA_ENC_FEEDBACK_POL=-1 with active DSC. Remedy: Remove inversion of the encoder signal from \$MA_ENC_FEEDBACK_POL, and enter it in SINAMICS parameter p410 instead.

32650	AX_INERTIA			EXP, A07, A09	G1,K3,S3,G2	
kgm ²	Inertia for torque feedforward control			DOUBLE	NEW CONF	
-						
-	-	0.0	-	-	2/2	M

Description:

Only with SINAMICS:

Inertia of axis. Used for torque feedforward control.

With torque feedforward control, an additional current setpoint proportional to the torque is directly injected at the input of the current controller. This value is formed using the acceleration and the moment of inertia. The equivalent time constant of the current control loop must be defined for this purpose and entered in MD32800 \$MA_EQUIV_CURRCTRL_TIME.

The total moment of inertia of the axis (drive + load) must also be entered in MD32650 \$MA_AX_INERTIA (total moment of inertia referred to motor shaft according to data supplied by machine manufacturer).

When MD32650 \$MA_AX_INERTIA and MD32800 \$MA_EQUIV_CURRCTRL_TIME are set correctly, the following error is almost zero even during acceleration (check this by looking at the "following error" in the service display).

The torque feedforward control is deactivated if MD32650 \$MA_AX_INERTIA is set to 0. However, because the calculations are performed anyway, torque feedforward control must always be deactivated with MD32620 \$MA_FFW_MODE = 0 or 1 or 3 (recommended). Because of the direct current setpoint injection, torque feedforward control is only possible on digital drives.

MD irrelevant for:

MD32620 \$MA_FFW_MODE = 0 or 1 or 3

Related to:

MD32620 \$MA_FFW_MODE

MD32630 \$MA_FFW_ACTIVATION_MODE

MD32800 \$MA_EQUIV_CURRCTRL_TIME

32652	AX_MASS		EXP, A07, A09	-		
kg	Axis mass for torque feedforward control		DOUBLE		NEW CONF	
-						
-	-	0.0	-	-	2/2	M

Description:

SINAMICS only:

Mass of axis for torque feedforward control.

The MD is used on linear drives (MD13040 \$MN_DRIVE_TYPE=3 or MD13080 \$MN_DRIVE_TYPE_DP=3) instead of MD32650 \$MA_AX_INERTIA.

32700	ENC_COMP_ENABLE		A09	K3		
-	Encoder/spindle error compensation.		BOOLEAN		NEW CONF	
-						
-	2	FALSE, FALSE	-	-	2/2	M

Description:

1: LEC (leadscrew error compensation) is activated for the measuring system.

This enables leadscrew and measuring system errors to be compensated.

The function is not enabled internally until the relevant measuring system has been referenced (NC/PLC interface signal DB390x DBX0.4 / .5 (Referenced/synchronized 1 or 2) = 1).

write protect function (compensation values) active.

0: LEC is not active for the axis/measuring system.

Related to:

MD38000 \$MA_MM_ENC_COMP_MAX_POINTS number of interpolation points with LEC

NC/PLC interface signal DB390x DBX0.4 (Referenced/synchronized 1)

NC/PLC interface signal DB390x DBX0.5 (Referenced/synchronized 2)

2.4 Axis-specific machine data

32710	CEC_ENABLE		A09	K3		
-	Enable of sag compensation		BOOLEAN	NEW CONF		
-						
-	-	FALSE	-	-	1/1	M

Description:

1: Sag compensation is enabled for this axis.

Inter-axis machine geometry errors (e.g. sag and angularity errors) can be compensated with sag compensation.

The function is not activated until the following conditions have been fulfilled:

- The "Interpolatory compensation" option is set
- The associated compensation tables have been loaded into the NC user memory and enabled (SD41300 \$SN_CEC_TABLE_ENABLE[t] = 1)
- The relevant position measuring system is referenced (NC/PLC interface signal DB390x DBX0.4 / .5 = 1 (Referenced/synchronized 1 or 2)):

0: Sag compensation is not enabled for the compensation axis.

Related to:

MD18342 \$MN_MM_CEC_MAX_POINTS[t]

Number of interpolation points for sag compensation

SD41300 \$SN_CEC_TABLE_ENABLE[t]

Enable evaluation of sag compensation table t

NC/PLC interface signal DB390x DBX0.4 / .5

(referenced/synchronized 1 or 2)

32711	CEC_SCALING_SYSTEM_METRIC		A09	K3,G2		
-	Measuring system of sag compensation		BOOLEAN	NEW CONF		
-						
828d-me41	-	TRUE	-	-	1/1	M
828d-me61	-	TRUE	-	-	1/1	M
828d-me81	-	TRUE	-	-	1/1	M
828d-te61	-	TRUE	-	-	7/2	M
828d-te81	-	TRUE	-	-	7/2	M
828d-te41	-	TRUE	-	-	7/2	M

Description:

Compensation data exist in:

0: inch system

1: metric system

32720	CEC_MAX_SUM		A09	K3		
mm, degrees	Maximum compensation value for sag compensation		DOUBLE	NEW CONF		
-						
-	-	1.0	0	1.0	1/1	M

Description:

In sag compensation, the absolute value of the total compensation value (sum of compensation values of all active compensation relations) is monitored axially with machine data value CEC_MAX_SUM.

If the determined total compensation value is larger than the maximum value, alarm 20124 is triggered. Program processing is not interrupted. The compensation value output as the additional setpoint is limited to the maximum value.

MD irrelevant to:

- MSEC
- Backlash compensation
- Temperature compensation

Related to:

MD32710 \$MA_CEC_ENABLE
 Enable sag compensation
 SD41300 \$SN_CEC_TABLE_ENABLE[t]
 Enable evaluation of sag compensation table t
 NC/PLC interface signal DB390x DBX0.4 / .5
 (referenced/synchronized 1 or 2)

32730	CEC_MAX_VELO	EXP, A09, A04	K3			
%	Change in velocity at CEC	DOUBLE	NEW CONF			
-						
-	-	10.0	0	100.0	1/1	M

Description: In sag compensation, modification of the total compensation value (sum of the compensation values of all active compensation relations) is limited axially. The maximum change value is defined in this machine data as a percentage of MD32000 \$MA_MAX_AX_VELO (maximum axis velocity).

If the change in the total compensation value is greater than the maximum value, alarm 20125 is output. Program processing is however continued. The path not covered because of the limitation is made up as soon as the compensation value is no longer subject to limitation.

MD irrelevant to:

- MSEC
- Backlash compensation
- Temperature compensation

Related to:

MD32710 \$MA_CEC_ENABLE
 Enable sag compensation
 MD32000 \$MA_MAX_AX_VELO
 Maximum axis velocity
 SD41300 \$SN_CEC_TABLE_ENABLE[t]
 Enable evaluation of sag compensation table t
 NC/PLC interface signal DB390x DBX0.4 / .5
 (referenced/synchronized 1 or 2)

32750	TEMP_COMP_TYPE	A09	K3,W1			
-	Temperature compensation type	BYTE	PowerOn			
CTEQ						
-	-	0	0	7	2/2	M

Description: The type of temperature compensation applicable to the machine axis is activated in MD32750 \$MA_TEMP_COMP_TYPE.

A distinction is made between the following types:

- 0: No temperature compensation active
- 1: Position-independent temperature compensation active
 (compensation value with SD43900 \$SA_TEMP_COMP_ABS_VALUE)

2.4 Axis-specific machine data

- 2: Position-dependent temperature compensation active
(compensation value with SD43910 \$SA_TEMP_COMP_SLOPE and SD43920 TEMP_COMP_REF_POSITION)
 - 3: Position-dependent and position-independent temperature compensation active
(compensation values with SD according to types 1 and 2)
- Temperature compensation is an option that must be enabled.

Related to:

- SD43900 \$SA_TEMP_COMP_ABS_VALUE
Position-dependent temperature compensation value
- SD43920 \$SA_TEMP_COMP_REF_POSITION
Reference point for position-dependent temperature compensation
- SD43910 \$SA_TEMP_COMP_SLOPE
Gradient for position-dependent temperature compensation
- MD32760 \$MA_COMP_ADD_VELO_FACTOR
Excessive velocity due to compensation

32760	COMP_ADD_VELO_FACTOR	EXP, A09, A04	K3
-	Excessive velocity due to compensation	DOUBLE	NEW CONF
CTEQ			
-	-	0.01	0. 0.10 2/2 M

Description:

The maximum distance that can be traversed because of temperature compensation in one IPO cycle can be limited by the axial MD32760 \$MA_COMP_ADD_VELO_FACTOR.

If the resulting temperature compensation value is above this maximum, it is traversed over several IPO cycles. There is no alarm.

The maximum compensation value per IPO cycle is specified as a factor referring to the maximum axis velocity (MD32000 \$MA_MAX_AX_VELO).

The maximum gradient of the temperature compensation tanbmax is also limited with this machine data.

Example of calculation of the maximum gradient tanb(max):

1. Calculation of the interpolator cycle time (see Description of Functions Velocities, Setpoint/Actual Value Systems, Cycle Times (G2))
 - Interpolator cycle time = Basic system clock rate * factor for interpolation cycle
 - Interpolator cycle time = MD10050 \$MN_SYSCLOCK_CYCLE_TIME ^ MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO
 - Example:
 - MD10050 \$MN_SYSCLOCK_CYCLE_TIME = 0.004 [s]
 - MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO = 3
 - > Interpolator cycle time = 0.004 * 3 = 0.012 [s]
2. Calculation of the maximum velocity increase resulting from a change made to the temperature compensation parameter DvTmax
 - DvTmax = MD32000 \$MA_MAX_AX_VELO * MD32760 \$MA_COMP_ADD_VELO_FACTOR
 - Example: MD32000 \$MA_MAX_AX_VELO = 10 000 [mm/min]
 - MD32760 \$MA_COMP_ADD_VELO_FACTOR = 0.01
 - > DvTmax = 10 000 * 0.01 = 100 [mm/min]

3. Calculation of the traverse distances per interpolator cycle

$$S1 \text{ (at } v_{\max}) = 10\,000 \times \frac{0.012}{60} = 2.0 \text{ [mm]}$$

$$ST \text{ (at } DvT_{\max}) = 100 \times \frac{0.012}{60} = 0.02 \text{ [mm]}$$

4. Calculation of $\tan b_{\max}$

$$\tan b_{\max} = \frac{ST}{S1} = \frac{0.02}{2} = 0.01 \text{ (corresponds to value for COMP_ADD_VELO_FACTOR)}$$

-> $b_{\max} = \arctan 0.01 = 0.57 \text{ degrees}$

With larger values of SD43910 \$SA_TEMP_COMP_SLOPE, the maximum gradient (here 0.57 degrees) for the position-dependent temperature compensation value is used internally. There is no alarm.

Note:

Any additional excessive velocity resulting from temperature compensation must be taken into account when defining the limit value for velocity monitoring (MD36200 \$MA_AX_VELO_LIMIT).

MD irrelevant for:

MD32750 \$MA_TEMP_COMP_TYPE = 0, sag compensation, LEC, backlash compensation

Related to:

MD32750 \$MA_TEMP_COMP_TYPE
Temperature compensation type
SD43900 \$SA_TEMP_COMP_ABS_VALUE
Position-independent temperature compensation value
SD43910 \$SA_TEMP_COMP_SLOPE
Gradient for position-dependent temperature compensation
MD32000 \$MA_MAX_AX_VELO
Maximum axis velocity
MD36200 \$MA_AX_VELO_LIMIT
Threshold value for velocity monitoring
MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO
Ratio of basic system clock rate to IPO cycle
MD10050 \$MN_SYSCLOCK_CYCLE_TIME
Basic system clock rate

32800	EQUIV_CURRCTRL_TIME		EXP, A07, A09	G1,K3,S3,A2,A3,G2,S1,V1	
s	Equiv. time const. current control loop for feedforward control		DOUBLE	NEW CONF	
-					
-	6	0.0005, 0.0005, 0.0005, 0.0005, 0.0005, 0.0005	-	-	2/2 M

Description:

The time constant is used for parameterizing the torque feedforward control and for calculating the dynamic following error model (contour monitoring). In order to set the torque feedforward control correctly, the equivalent time constant of the current control loop must be determined exactly by measuring the step response of the current control loop.

2.4 Axis-specific machine data

Closed-loop control free of following errors can be set by inputting negative values when MD32620 \$MA_FFW_MODE=4 (but positioning overshoots may then occur).

Delay values taken into account automatically by the software internally are thus compensated again until the actually active minimum symmetrizing time "0" is reached.

Any other negative input values have no further effect.

Negative values input when MD32620 \$MA_FFW_MODE=2 are automatically converted internally to the input value "0", which means that they are not active in this case.

Related to:

- MD32620 \$MA_FFW_MODE
Type of feedforward control
- MD32650 \$MA_AX_INERTIA
Moment of inertia for torque feedforward control
or MD32652 \$MA_AX_MASS
Axis mass for torque feedforward control
- MD36400 \$MA_CONTOUR_TOL
Tolerance band contour monitoring

32810	EQUIV_SPEEDCTRL_TIME			A07, A09	G1,K3,S3,A2,A3,G2,S1,V1	
s	Equiv. time constant speed control loop for feedforward control			DOUBLE	NEW CONF	
-						
828d-me41	6	0.008, 0.008, 0.008, 0.008, 0.008, 0.008	-	-	2/2	M
828d-me61	6	0.003, 0.003, 0.003, 0.003, 0.003...	-	-	2/2	M
828d-me81	6	0.0015, 0.0015, 0.0015, 0.0015...	-	-	2/2	M
828d-te61	6	0.003, 0.003, 0.003, 0.003, 0.003...	-	-	2/2	M
828d-te81	6	0.0015, 0.0015, 0.0015, 0.0015...	-	-	2/2	M
828d-te41	6	0.008, 0.008, 0.008, 0.008, 0.008, 0.008	-	-	2/2	M

Description:

This time constant must be equal to the equivalent time constant of the closed current control loop.

It is used for parameterizing the speed feedforward control and for calculating the dynamic following error model (contour monitoring).

In addition, this MD determines the time behavior of the closed-loop speed control circuit for simulated drives (MD30130 \$MA_CTRL_OUT_TYPE 0).

In order to set the speed feedforward control correctly, the equivalent time constant of the current control loop must be determined exactly by measuring the step response of the current control loop.

Closed-loop control free of following errors can be set by inputting negative values when MD32620 \$MA_FFW_MODE=3 (but positioning overshoots may then occur).

Delay values taken into account automatically by the software internally are thus compensated again until the actually active minimum symmetrizing time "0" is reached.

Any other negative input values have no further effect.

Negative values input when MD32620 \$MA_FFW_MODE=1 are automatically converted internally to the input value "0", which means that they are not active in this case.

Related to:

MD32620 \$MA_FFW_MODE (type of feedforward control)

MD32610 \$MA_VELO_FFW_WEIGHT (moment of inertia for speed feedforward control)

MD36400 \$MA_CONTOUR_TOL (tolerance band contour monitoring)

32900	DYN_MATCH_ENABLE	A07	G21,S3,G2
-	Dynamic response adaptation	BOOLEAN	NEW CONF
CTEQ			
-	-	FALSE	-
-	-	-	-
-	-	2/2	M

Description: With dynamic response adaptation, axes with different servo gain factors can be set to the same following error with MD32910 \$MA_DYN_MATCH_TIME.

1: Dynamic response adaptation active.

0: Dynamic response adaptation inactive.

Related to:

MD32910 \$MA_DYN_MATCH_TIME[n]

(time constant of dynamic response adaptation)

32910	DYN_MATCH_TIME	A07	G1,K3,S3,A2,A3,G2,S1,V1
s	Time constant of dynamic response adaptation	DOUBLE	NEW CONF
-			
-	6	0.0, 0.0, 0.0, 0.0, 0.0, 0.0	-
-	-	0.0	-
-	-	-	-
-	-	2/2	M

Description: The time constant of the dynamic response adaptation of an axis has to be entered in this MD.

Axes interpolating with each other but having different dynamic responses can be adapted to the "slowest" control loop by means of this value.

The difference of the equivalent time constant of the "slowest" control loop to the individual axis has to be entered here as the time constant of the dynamic response adaptation.

The MD is only active if MD32900 \$MA_DYN_MATCH_ENABLE = 1.

Related to:

MD32900 \$MA_DYN_MATCH_ENABLE (dynamic response adaptation)

33050	LUBRICATION_DIST	A03, A10	A2,Z1
mm, degrees	Traversing path for lubrication from PLC	DOUBLE	NEW CONF
-			
-	-	1.0e8	-
-	-	-	-
-	-	3/3	I

Description: After the traversing path defined in the MD has been covered, the state of the axial interface signal "Lubrication pulse" is inverted, this can activate an automatic lubrication device.

The traversing path is summated after Power on.

The "Lubrication pulse" can be used with axes and spindles.

Application example(s):

The machine bed lubrication can be carried out as a function of the relevant traversed path.

2.4 Axis-specific machine data

Note:

When 0 is entered, the NC/PLC interface signal DB390x DBX1002.0 (Lubrication pulse) is set in every cycle.

Related to:

NC/PLC interface signal DB390x DBX1002.0 (Lubrication pulse)

33100	COMPRESS_POS_TOL			A10	F2,B1,K1	
mm, degrees	Maximum deviation during compression			DOUBLE	NEW CONF	
CTEQ						
828d-me41	-	0.1	1.e-9	-	3/3	U
828d-me61	-	0.1	1.e-9	-	3/3	U
828d-me81	-	0.1	1.e-9	-	3/3	U
828d-te61	-	0.1	1.e-9	-	0/0	S
828d-te81	-	0.1	1.e-9	-	0/0	S
828d-te41	-	0.1	1.e-9	-	0/0	S

Description: The value specifies the maximum permissible path deviation for each axis with compression.

The higher the value, the more short blocks can be compressed into a long block.

Not relevant for:

Active programmable contour/orientation tolerance (CTOL, OTOL, ATOL)

33120	PATH_TRANS_POS_TOL			A10	K1,PGA	
mm, degrees	Maximum deviation for smoothing with G645			DOUBLE	NEW CONF	
CTEQ						
828d-me41	-	0.005	1.e-9	-	3/3	U
828d-me61	-	0.005	1.e-9	-	3/3	U
828d-me81	-	0.005	1.e-9	-	3/3	U
828d-te61	-	0.005	1.e-9	-	0/0	S
828d-te81	-	0.005	1.e-9	-	0/0	S
828d-te41	-	0.005	1.e-9	-	0/0	S

Description: The value specifies the maximum permitted path deviation for smoothing with G645.

This is only relevant to tangential block transitions that are not acceleration-continuous.

For smoothing of corner with G645 tolerance MD33100 \$MA_COMPRESS_POS_TOL becomes active like with G642.

34000	REFP_CAM_IS_ACTIVE			A03, A11	G1,R1	
-	Axis with reference point cam			BOOLEAN	Reset	
-						
-	-	TRUE	-	-	2/2	M

Description: 1: There is at least one reference point cam for this axis

0: This axis does not have a reference point cam (e.g. rotary axis)

The referencing cycle starts immediately with phase 2 (see documentation) Machine axes that have only one zero mark over the whole travel range or rotary axes that have only one zero mark per revolution do not require an additional reference cam that selects the zero mark (select MD34000 \$MA_REFP_CAM_IS_ACTIVE = 0).

The machine axis marked this way accelerates to the velocity specified in MD34040 \$MA_REFP_VELO_SEARCH_MARKER (reference point creep velocity) when the plus/minus traversing key is pressed, and synchronizes with the next zero mark.

34010	REFP_CAM_DIR_IS_MINUS	A03, A11	G1, R1
-	Approach reference point in minus direction	BOOLEAN	Reset
-			
-	-	FALSE	-
			2/2
			M

Description:

0: MD34010 \$MA_REFP_CAM_DIR_IS_MINUS Reference point approach in plus direction

1: MD34010 \$MA_REFP_CAM_DIR_IS_MINUS Reference point approach in minus direction

For incremental measuring systems:

If the machine axis is positioned in front of the reference cam, it accelerates, depending on the plus/minus traversing key pressed, to the velocity specified in MD34020 \$MA_REFP_VELO_SEARCH_CAM (reference point approach velocity) in the direction specified in MD34010 \$MA_REFP_CAM_DIR_IS_MINUS. If the wrong traversing key is pressed, reference point approach is not started.

If the machine axis is positioned on the reference cam, it accelerates to the velocity specified in MD34020 \$MA_REFP_VELO_SEARCH_CAM and travels in the direction opposite to that specified in MD34010 \$MA_REFP_CAM_DIR_IS_MINUS.

For linear measuring systems with distance-coded reference marks:

If the machine axis has a reference cam (linear measuring systems with distance-coded reference marks do not necessarily require a reference cam) and the machine axis is positioned on the reference cam, it accelerates, irrespectively of the plus/minus traversing key pressed, to the velocity specified in MD34040 \$MA_REFP_VELO_SEARCH_MARKER (reference point creep velocity) in the direction opposite to that specified in MD34010 \$MA_REFP_CAM_DIR_IS_MINUS.

34020	REFP_VELO_SEARCH_CAM			A03, A11, A04	G1,R1	
mm/min, rev/min	Reference point approach velocity			DOUBLE	Reset	
-						
828d-me41	-	5000.,5000.,5000.,720.,720.	-	-	2/2	M
828d-me61	-	5000.,5000.,5000.,720.,720.,720.	-	-	2/2	M
828d-me81	-	5000.,5000.,5000.,720.,720.,720.	-	-	2/2	M
828d-te61	-	5000.,5000.,720.,720.,720.,5000.	-	-	2/2	M
828d-te81	-	5000.,5000.,720.,720.,720.,5000....	-	-	2/2	M
828d-te41	-	5000.,5000.,720.,720.,720.	-	-	2/2	M

Description: The reference point approach velocity is the velocity at which the machine axis travels in the direction of the reference cam after the traversing key has been pressed (phase 1). This value should be set at a magnitude large enough for the axis to be stopped to 0 before it reaches a hardware limit switch.

MD irrelevant for:

Linear measuring systems with distance-coded reference marks

34030	REFP_MAX_CAM_DIST			A03, A11	G1,R1	
mm, degrees	Maximum distance to reference cam			DOUBLE	Reset	
-						
-	-	10000.0	-	-	7/2	M

Description: If the machine axis travels a maximum distance defined in MD34030 \$MA_REFP_MAX_CAM_DIST from the starting position in the direction of the reference cam, without reaching the reference cam (NC/PLC interface signal DB380x DBX1000.7 (Reference point approach delay) is reset), the axis stops and alarm 20000 "Reference cam not reached" is output.

Irrelevant to:

Linear measuring systems with distance-coded reference marks

34040	REFP_VELO_SEARCH_MARKER			A03, A11, A04	G1,R1,S1	
mm/min, rev/min	Creep velocity			DOUBLE	Reset	
-						
-	2	300.00, 300.00,300.00, 300.00...	-	-	2/2	M

Description: 1) For incremental measuring systems:

This is the velocity at which the axis travels during the time between initial detection of the reference cam and synchronization with the first zero mark (phase 2).

Traversing direction: Opposite to the direction specified for the cam search (MD34010 \$MA_REFP_CAM_DIR_IS_MINUS)

If MD34050 \$MA_REFP_SEARCH_MARKER_REVERSE (direction reversal on reference cam) is enabled, then if the axis is synchronized with a rising reference cam signal edge on the cam, the axis traverses at the velocity defined in MD34020 \$MA_REFP_VELO_SEARCH_CAM.

2) Indirect measuring system with BERO on the load-side (preferred for spindles):

At this velocity, a search is made for the zero mark associated with the BERO (zero mark selection per VDI signal). The zero mark is accepted if the actual velocity lies within the tolerance range defined in MD35150

\$MA_SPIND_DES_VELO_TOL as a deviation from the velocity specified in MD34040 \$MA_REFP_VELO_SEARCH_MARKER[n].

3) For linear measuring systems with distance-coded reference marks:

The axis crosses the two reference marks at this velocity. The maximum velocity must be low enough to ensure that the time required to travel the smallest possible reference mark distance [(x(minimum))] on the linear measuring system is longer than one position controller cycle.

The formula

$$[x(\text{minimum})] [\text{mm}] = \frac{\text{Basic dist.}}{2} * \text{Grad.cycle} - \frac{\text{Meas.length}}{\text{Basic dist.}}$$

with Basic distance [multiple of graduation cycle]

Graduation cycle [mm]

Measuring length [mm] yields:

x(minimum) [mm]

$$\text{max. velocity [m/s]} = \frac{\text{Position controller cycle [ms]}}{\text{Position controller cycle [ms]}}$$

This limiting value consideration also applies to the other measuring systems.

Traversing direction:

- as defined in MD34010 \$MA_REFP_CAM_DIR_IS_MINUS;
- if the axis is already positioned on the cam, the axis is traversed in the opposite direction

34050	REFP_SEARCH_MARKER_REVERSE	A03, A11	G1, R1
-	Direction reversal to reference cam	BOOLEAN	Reset
-			
-	2	FALSE, FALSE	- - - - - 2/2 M

Description:

This MD can be used to set the direction of search for the zero mark:

MD34050 \$MA_REFP_SEARCH_MARKER_REVERSE = 0

Synchronization with falling reference cam signal edge

The machine axis accelerates to the velocity specified in MD34040

\$MA_REFP_VELO_SEARCH_MARKER (reference point creep velocity) in the opposite direction to that specified in MD34010 \$MA_REFP_CAM_DIR_IS_MINUS (reference point approach in minus direction).

If the axis leaves the reference cam (NC/PLC interface signal DB380x

DBX1000.7 (Reference point approach delay) is reset) the control is synchronized with the first zero mark.

MD34050 \$MA_REFP_SEARCH_MARKER_REVERSE = 1

Synchronization with rising reference cam signal edge

2.4 Axis-specific machine data

The machine axis accelerates to the velocity defined in MD34020 \$MA_REFP_VELO_SEARCH_CAM (reference point creep velocity) in the opposite direction to that specified in the MD34010 \$MA_REFP_CAM_DIR_IS_MINUS. If the axis leaves the reference cam (NC/PLC interface signal DB380x DBX1000.7 (Reference point approach delay) is reset), the machine axis decelerates to a halt and accelerates in the opposite direction towards the reference cam at the velocity specified in MD34040: \$MA_REFP_VELO_SEARCH_MARKER. When the reference cam is reached (NC/PLC interface signal DB380x DBX1000.7 (Reference point approach delay) is enabled) the control is synchronized with the first zero mark.

MD irrelevant to:

Linear measuring systems with distance-coded reference marks

34060	REFP_MAX_MARKER_DIST			A03, A11	G1,R1,S1	
mm, degrees	maximum distance to reference mark			DOUBLE	Reset	
-						
828d-me41	2	20.0, 20.0,20.0, 20.0,20.0, 20.0...	-	-	2/2	M
828d-me61	2	20.0, 20.0,20.0, 20.0,20.0, 20.0...	-	-	2/2	M
828d-me81	2	20.0, 20.0,20.0, 20.0,20.0, 20.0...	-	-	2/2	M
828d-te61	2	20.0, 20.0,20.0, 20.0,720.0, 720.0...	-	-	2/2	M
828d-te81	2	20.0, 20.0,20.0, 20.0,720.0, 720.0...	-	-	2/2	M
828d-te41	2	20.0, 20.0,20.0, 20.0,720.0, 720.0...	-	-	2/2	M

Description:

For incremental measuring systems:

If, after leaving the reference cam (NC/PLC interface signal DB380x DBX1000.7 (Reference point approach delay) is reset), the machine axis travels a distance defined in MD34060: \$MA_REFP_MAX_MARKER_DIST without detecting the zero mark, the axis stops and alarm 20002 "Zero mark missing" is output.

For linear measuring systems with distance-coded reference marks:

If the machine axis travels a distance defined in MD34060 \$MA_REFP_MAX_MARKER_DIST from the starting position without crossing two zero marks, the axis stops and alarm 20004 "Reference mark missing" is output.

34070	REFP_VELO_POS			A03, A11, A04	G1,R1	
mm/min, rev/min	Reference point positioning velocity			DOUBLE	Reset	
-						
828d-me41	-	10000.,10000.,10000.,720.,720.	-	-	2/2	M
828d-me61	-	10000.,10000.,10000.,720.,720....	-	-	2/2	M
828d-me81	-	10000.,10000.,10000.,720.,720....	-	-	2/2	M
828d-te61	-	10000.,10000.,720.,720.,720.,10000.	-	-	2/2	M
828d-te81	-	10000.,10000.,720.,720.,720.,10000....	-	-	2/2	M
828d-te41	-	10000.,10000.,720.,720.,720.	-	-	2/2	M

Description:

For incremental measuring systems:

The axis travels at this velocity between the time of synchronization with the first zero mark and arrival at the reference point.

For linear measuring systems with distance-coded reference marks:

The axis travels at this velocity between the time of synchronization (crossing two zero marks) and arrival at the target point.

34080	REFP_MOVE_DIST			A03, A11	G1,R1,S1,S3,G2	
mm, degrees	Reference point distance			DOUBLE	NEW CONF	
-						
-	2	-2.0, -2.0	-1e15	1e15	2/2	I

Description:

1. Standard measuring system (incremental with equidistant zero marks)
Reference point positioning movement: 3rd phase of the reference point approach:

The axis traverses from the position at which the zero mark is detected with the velocity REFP_AX_VELO_POS along the path REFP_MOVE_DIST + REFP_MOVE_DIST_CORR (relative to the marker).

REFP_SET_POS is set as the current axis position at the target point.

2. Irrelevant for distance-coded measuring system.

Override switch and selection jog/continuous mode (MD JOG_INC_MODE_IS_CONT) are active.

34090	REFP_MOVE_DIST_CORR			A03, A02, A08, A11	G1,R1,S1,S3,G2	
mm, degrees	Reference point offset/absolute offset			DOUBLE	NEW CONF	
-, -						
-	2	0.0, 0.0	-1e12	1e12	2/2	I

Description:

• Incremental encoder with zero mark(s):

After detection of the zero mark, the axis is positioned away from the zero mark by the distance specified in MD34080 \$MA_REFP_MOVE_DIST + MD34090 \$MA_REFP_MOVE_DIST_CORR. After traversing this distance, the axis has reached the reference point. MD34100 \$MA_REFP_SET_POS is transferred into the actual value.

During traversing by MD34080 \$MA_REFP_MOVE_DIST + MD34090 \$MA_REFP_MOVE_DIST_CORR, the override switch and MD11300 \$MN_JOG_INC_MODE_LEVELTRIGGRD (jog/continuous mode) are active.

2.4 Axis-specific machine data

- Distance-coded measuring system:

MD34090 \$MA_REFP_MOVE_DIST_CORR acts as an absolute offset. It describes the offset between the machine zero and the first reference mark of the measuring system.

- Absolute encoder:

MD34090 \$MA_REFP_MOVE_DIST_CORR acts as an absolute offset.

It describes the offset between the machine zero and the zero point of the absolute measuring system.

Note:

In conjunction with absolute encoders, this MD is modified by the control during calibration processes and modulo offset.

With rotary absolute encoders (on linear and rotary axes), the modification frequency also depends on the setting of MD34220 \$MA_ENC_ABS_TURNS_MODULO.

Manual input or modification of this MD via the part program should therefore be followed by a Power ON Reset to activate the new value and prevent it from being lost.

The following applies to an NCU-LINK:

If a link axis uses an absolute encoder, every modification of MD34090 \$MA_REFP_MOVE_DIST_CORR on the home NCU (servo physically available) is updated only locally and not beyond the limits of the NCU. The modification is therefore not visible to the link axis. Writing MD34090

\$MA_REFP_MOVE_DIST_CORR through the link axis is rejected with alarm 17070.

34092	REFP_CAM_SHIFT			A03, A11	G1,R1	
mm, degrees	electronic cam offset for incremental measuring systems			DOUBLE	Reset	
-						
-	2	0.0, 0.0	-	-	2/2	I

Description:

Electronic cam offset for incremental measuring systems with equidistant zero marks.

When the reference cam signal occurs, the zero mark search does not start immediately but is delayed until after the distance from REFP_CAM_SHIFT.

This ensures the reproducibility of the zero mark search through a defined selection of a zero mark, even with temperature-dependent expansion of the reference cam.

Because the reference cam offset is calculated by the control in the interpolation cycle, the actual cam offset is at least REFP_CAM_SHIFT and at most REFP_CAM_SHIFT+(MD34040 \$MA_REFP_VELO_SEARCH_MARKER*interpolation cycle)

The reference cam offset is effective in the search direction of the zero mark.

The reference cam offset is only active if existing cam MD34000 \$MA_REFP_CAM_IS_ACTIVE=1.

34093	REFP_CAM_MARKER_DIST	A03, A11	R1
mm, degrees	Reference cam/reference mark distance	DOUBLE	PowerOn
-			
-	2	0.0, 0.0	- - 2/2

Description: The value displayed corresponds to the distance between exiting the reference cam and the occurrence of the reference mark. If the values are too small, there is a risk of not being able to determine the reference point due to temperature reasons or varying operating times of the cam signal. The distance travelled may serve as a clue for setting the electronic reference cam offset.

This machine data is a display data and can therefore not be changed.

34100	REFP_SET_POS	A03, A11	G1,S3,G2,R1,S1
mm, degrees	Reference point for incremental system	DOUBLE	Reset
-			
-	4	0., 0., 0., 0.	-45000000 45000000 2/2

Description:

- Incremental encoder with zero mark(s):
The position value which is set as the current axis position after detection of the zero mark and traversal of the distance REFP_MOVE_DIST + REFP_MOVE_DIST_CORR (relative to zero mark). REFP_SET_POS of the reference point number, which is set at the instant that the edge of the reference cam signal rises (NC/PLC interface signal <Referenzpunktwert1-4/> (Reference point value 1 to 4)), is set as the axis position.

- Distance-coded measuring system:

Target position which is approached when MD34330 \$MA_REFP_STOP_AT_ABS_MARKER is set to 0 (FALSE) and two zero marks have been crossed.

- Absolute encoder:

MD34100 \$MA_REFP_SET_POS corresponds to the correct actual value at the calibration position.

The reaction on the machine depends on the status of MD34210

\$MA_ENC_REFP_STATE: When MD34210 \$MA_ENC_REFP_STATE = 1, the value of MD34100 \$MA_REFP_SET_POS is transferred as the absolute value.

When MD34210 \$MA_ENC_REFP_STATE = 2 and MD34330 \$MA_REFP_STOP_AT_ABS_MARKER = 0 (FALSE), the axis approaches the target position stored in MD34100 \$MA_REFP_SET_POS.

The value of MD34100 \$MA_REFP_SET_POS that has been set via NC/PLC interface signal <Referenzpunktwert1-4/> (Reference point value 1 to 4) is used.

Related to:

NC/PLC interface signal <Referenzpunktwert1-4/> (Reference point value 1 to 4)

34102	REFP_SYNC_ENCS	A03, A02	R1,Z1
-	Calibration of measuring systems	BYTE	Reset
-			
-	-	0 0 1	2/2 M

Description: Calibrating the measuring system to the reference measuring system can be activated for all measuring systems of this axis with this machine data. The calibration procedure is made during reference point approach or when calibrated absolute encoders selected for the closed-loop control are switched on.

2.4 Axis-specific machine data

Values:

0: No measuring system calibration, measuring systems must be referenced individually

1: Calibration of all measuring systems of the axis to the position of the reference measuring system

In combination with MD30242 \$MA_ENC_IS_INDEPENDENT = 2, the passive encoder is calibrated to the active encoder but NOT referenced.

34104	REFP_PERMITTED_IN_FOLLOWUP	A03, A02	R1
-	Enable referencing in follow-up mode	BOOLEAN	Reset
-			
-	-	FALSE	-
			1/1 M

Description: An axis can also be referenced in the follow-up mode under JOG+REF mode by means of an external motion.

34110	REFP_CYCLE_NR	A03	G1,TE3,D1,R1,Z1
-	Sequence of axes in channel-specific referencing	DWORD	PowerOn
-			
-	-	1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18, ..	-1 31 2/2 M

Description: MD34110 \$MA_REFP_CYCLE_NR = 0 -----> axis-specific referencing
 Axis-specific referencing is started separately for each machine axis with the NC/PLC interface signal DB380x DBX4.7 / 4.6 (Plus/minus travel keys). Up to 8 axes (840D) can be referenced simultaneously.
 The following alternatives are provided for referencing the machine axes in a specific sequence:

- The operator has to observe the correct sequence on startup.
- The PLC checks the sequence on startup or defines the sequence itself.
- The channel-specific referencing function is used.

MD34110 \$MA_REFP_CYCLE_NR = 1 -----> channel-specific referencing
 Channel-specific referencing is started with the NC/PLC interface signal DB3200 DBX1.0 (Activate referencing). The control acknowledges a successful start with the NC/PLC interface signal DB3300 DBX1.0 (Referencing active). Each machine axis assigned to the channel can be referenced with channel-specific referencing (this is achieved internally on the control by simulating the plus/minus traversing keys). The axis-specific MD34110 \$MA_REFP_CYCLE_NR can be used to define the sequence in which the machine axes are referenced:

-1 means:

The machine axis is not started by channel-specific referencing, and NC start is possible without referencing this axis.

0 means:

The machine axis is not started by channel-specific referencing, and NC start is not possible without referencing this axis.

1 means:

The machine axis is started by channel-specific referencing.

2 means:

The machine axis is started by channel-specific referencing if all machine axes identified by a 1 in MD34110 \$MA_REFP_CYCLE_NR are referenced.

3 means:

The machine axis is started by channel-specific referencing if all machine axes identified by a 2 in MD34110 \$MA_REFP_CYCLE_NR are referenced.

4 to 8 :

As above for further machine axes.

Setting the channel-specific MD20700 \$MC_REF_NC_START_LOCK (NC start disable without reference point) to zero has the effect of entering -1 for all the axes of a channel.

MD irrelevant to:

Axis-specific referencing

Related to:

NC/PLC interface signal DB3200 DBX1.0 (Activate referencing)

NC/PLC interface signal DB3300 DBX1.0 (Referencing active)

34200	ENC_REFP_MODE			A03, A02	G1,R1,S1	
-	Referencing mode			BYTE	PowerOn	
-						
-	2	1, 1	0	8	2/2	M

Description: The mounted position measuring systems can be classified for referencing as follows with MD34200 \$MA_ENC_REFP_MODE:

- MD34200 \$MA_ENC_REFP_MODE = 0
If an absolute encoder is available: MD34100 \$MA_REFP_SET_POS is taken over
Other encoders: Reference point approach not possible (SW2.2 and higher)
- MD34200 \$MA_ENC_REFP_MODE = 1
Referencing of incremental, rotary or linear measuring systems:
Zero pulse on the encoder track
Referencing of absolute, rotary measuring systems:
Replacement zero pulse based on the absolute information
- MD34200 \$MA_ENC_REFP_MODE = 3
Referencing on linear measuring systems with distance-coded reference marks:
Linear measuring system with distance-coded reference marks (as specified by Heidenhain)
- MD34200 \$MA_ENC_REFP_MODE = 4 :
Reserved (BERO with 2-edge evaluation)
- MD34200 \$MA_ENC_REFP_MODE = 8
Referencing for linear measuring systems with distance-coded reference marks:
Linear measuring system with distance-coded reference marks over 4 zero marks (increased safety).

34210	ENC_REFP_STATE			A07, A03, A02	R1	
-	Adjustment status of absolute encoder			BYTE	Immediately	
-						
-	2	0, 0	0	3	2/2	I

Description:

- Absolute encoder:
 - This machine data contains the absolute encoder status
 - 0: Encoder is not calibrated
 - 1: Encoder calibration enabled (but not yet calibrated)
 - 2: Encoder is calibrated
 - Default setting for recommissioning: Encoder is not calibrated.
 - 3: No significance, has the same effect as "0"
- Incremental encoder:
 - This machine data contains the "Referenced status", which can be saved beyond Power On:
 - 0: Default setting: No automatic referencing
 - 1: Automatic referencing enabled, but encoder not yet referenced
 - 2: Encoder is referenced and at exact stop, automatic referencing becomes active at the next encoder activation
 - 3: The last axis position buffered before switch off is restored, no automatic referencing
 - Default setting for recommissioning: No automatic referencing

34220	ENC_ABS_TURNS_MODULO			A03, A02	R1	
-	Modulo range for rotary absolute encoder			DWORD	PowerOn	
-						
-	2	4096, 4096	1	100000	2/2	M

Description:

Number of encoder revolutions a rotary absolute encoder is able to resolve (see also the maximum multiturn information of the absolute encoder, see encoder data sheet or PROFIdrive parameter p979).

The absolute position of a rotary axis is reduced to this resolvable range when an absolute encoder is switched on:

In other words, a MODULO transformation takes place if the actual position sensed is larger than the position permitted by MD ENC_ABS_TURNS_MODULO.

$0 \text{ degrees} \leq \text{position} \leq n \cdot 360 \text{ degrees}$ (with $n = \text{ENC_ABS_TURNS_MODULO}$)

Note:

With SW 2.2, the position is reduced to this range when the control/encoder is switched on. With SW 3.6 and higher, half of this value represents the maximum permissible travel distance with the control switched off/the encoder inactive.

Special cases:

For PROFIdrive, any integer value is permissible.

This MD is relevant only for rotary encoders (on linear and rotary axes).

Related to:

PROFIdrive parameter p979

34230	ENC_SERIAL_NUMBER		A02	R1	
-	Encoder serial number		DWORD	PowerOn	
-					
-	2	0, 0	-	-	2/2 I

Description: The encoder serial number (EnDat encoders) can be read out here. It is updated at PowerOn or when parking is deselected. "0" is supplied for encoders which do not have a serial number available. Manipulating this MD normally causes automatic absolute encoder maladjustment (\$MA_ENC_REFP_MODE returns to "0").

34232	EVERY_ENC_SERIAL_NUMBER		A02	R1	
-	Range of encoder serial number		BOOLEAN	PowerOn	
-					
-	2	TRUE, TRUE	-	-	1/1 M

Description: 0 = only valid encoder serial number are entered in the MD, i.e. when the drive supplies a "0" (which corresponds to invalid or unknown) the last valid encoder serial number is retained in the MD (e.g. for add-on axes that are not permanently connected to the machine).
1 = (default, upward compatible): the value supplied by the drive for the encoder serial number is taken over into the MD with every control runup. A validity check is not carried out.
Note for PROFIdrive drives:
As not every drive can supply the relevant parameters at all or in good time, the functionality is coded permanently corresponding to "0" for the PROFIdrive drive. A "1" setting is therefore ineffective on the PROFIBUS.

34300	ENC_REFP_MARKER_DIST		A03, A02	R1	
mm, degrees	Basic distance of reference marks of distance-coded encoders.		DOUBLE	PowerOn	
-					
-	2	10.0, 10.0	-	-	2/2 M

Description: In addition to the incremental encoder track, a further encoder track is available with distance-coded measuring systems for determining the absolute encoder position. This encoder track has reference marks at defined, different distances. The basic distance between the fixed reference marks (which are the reference marks that are always the same distance from one another) can be taken from the data sheet, and directly transferred into machine data MD34300 \$MA_ENC_REFP_MARKER_DIST.
With the basic distance between the fixed reference marks (MD34300 \$MA_ENC_REFP_MARKER_DIST), the distance between two reference marks (MD34310 \$MA_ENC_MARKER_INC), and the number of encoder marks (MD31020 \$MA_ENC_RESOL) on angular measuring systems or the graduation cycle (MD31010 \$MA_ENC_GRID_POINT_DIST) on linear measuring systems, the absolute encoder position can be determined once two successive reference marks have been crossed.
MD34300 \$MA_ENC_REFP_MARKER_DIST is also used for a plausibility check of reference mark distances.

2.4 Axis-specific machine data

Examples of application:

For example: Heidenhain LS186 C

MD 31010 = 0.02mm (graduation cycle)

MD 34300 = 20.00mm (basic distance between the reference marks)

MD 34310 = 0.02mm (distance between two reference marks corresponds to one graduation cycle).

34310	ENC_MARKER_INC			A03, A02	R1	
mm, degrees	Interval between two reference marks for distance-coded scales			DOUBLE	Reset	
-						
-	2	0.02, 0.02	-	-	2/2	M

Description: The distances between two reference marks are defined variably, so that the position of the crossed reference marks can be determined accurately in linear measuring systems with distance-coded reference marks.

The difference between two reference mark distances is entered in MD34310 \$MA_ENC_MARKER_INC.

MD irrelevant for:

Incremental measuring systems

Special cases:

On linear measuring systems with distance-coded reference marks supplied by Heidenhain, the interval between two reference marks is always equal to one graduation cycle.

34320	ENC_INVERS			A03, A02	G2,R1	
-	Length measuring system inverse to axis movement.			BOOLEAN	Reset	
-						
-	2	FALSE, FALSE	-	-	2/2	M

Description: • In the case of a distance-coded measuring system:

When setting a reference point, the actual position (determined by the distance-coded reference marks) on the linear measuring system is assigned to an exact machine axis position (referred to the machine zero point). The absolute offset between the machine zero point and the position of the 1st reference mark on the linear measuring system must therefore be entered in MD34090 \$MA_REFP_MOVE_DIST_CORR (reference point/absolute offset). In addition, MD34320 \$MA_ENC_INVERS must be used to set whether the linear measuring system is connected in the same or the opposite direction to the machine system.

MD irrelevant to:

Incremental encoders without distance-coded reference marks.

34330	REFP_STOP_AT_ABS_MARKER			A03	G1,R1	
-	Distance-coded linear measuring system without target point			BOOLEAN	Reset	
-						
-	2	TRUE, TRUE	-	-	2/2	M

Description: • Distance-coded measuring system:

REFP_STOP_AT_ABS_MARKER = 0:

At the end of the reference cycle, the position entered in MD34100 \$MA_REFP_SET_POS is approached (normal case for phase 2).

REFP_STOP_AT_ABS_MARKER = 1:

The axis is braked after detection of the second reference mark (shortening of phase 2)

- Absolute encoder:
MD34330 \$MA_REFP_STOP_AT_ABS_MARKER defines the response of an axis with a valid calibration identifier (MD34210 \$MA_ENC_REFP_STATE = 2) with G74 or when a traversing key is actuated in JOG-REF:
REFP_STOP_AT_ABS_MARKER = 0:
Axis traverses to the position entered in MD34100 \$MA_REFP_SET_POS
REFP_STOP_AT_ABS_MARKER = 1:
Axis does not traverse.
MD irrelevant for:
Incremental encoders with zero mark (standard encoders)
Related to:
MD34100 \$MA_REFP_SET_POS
(reference point distance/target point for distance-coded system)

34800	WAIT_ENC_VALID	A01	-
-	Parameter setting for part program command WAITENC	DWORD	PowerOn
-			
-	-	0	0
-		1	7/2
			M

Description: Parameter setting for part program command WAITENC:
0: Axis is not taken into account when waiting for synchronized / referenced or restored position with part program command WAITENC.
1: A delay is applied in part program command WAITENC until a synchronized / referenced or restored position is available for this axis.

34990	ENC_ACTVAL_SMOOTH_TIME	A02	V1
s	Smoothing time constant for actual values.	DOUBLE	Reset
-			
-	2	0.0, 0.0	0.0
-		0.5	3/3
			I

Description: Using low-resolution encoders, a more continuous motion of coupled path or axis motions can be achieved with smoothed actual values. The bigger the time constant, the better the smoothing of actual values and the larger the over-travel.
Smoothed actual values are used for:

- Thread-cutting (G33, G34, G35)
- Revolutions feedrate (G95, G96, G97, FPRAON)
- Display of actual position and velocity, or speed respectively.

35000	SPIND_ASSIGN_TO_MACHAX	A01, A06, A11	M1,S3,K2,S1
-	Assignment of spindle to machine axis	BYTE	PowerOn
-			
828d-me41	-	0,0,0,1,0	0
828d-me61	-	0,0,0,1,0,0	0
828d-me81	-	0,0,0,1,0,0	0
828d-te61	-	0,0,1,2,0,0	0
828d-te81	-	0,0,1,3,0,0,0,2	0
828d-te41	-	0,0,1,2,0	0
		20	1/1
		20	1/1
		20	1/1
		20	1/1
		20	1/1
		20	1/1
			M

Description: Spindle definition. The spindle is defined when the spindle number has been entered in this MD.

2.4 Axis-specific machine data

Example:

If the corresponding axis is to be spindle 1, value "1" must be entered in this MD.

The spindle functions are possible only for modulo rotary axes. For this purpose MD30300 \$MA_IS_ROT_AX and MD30310 \$MA_ROT_IS_MODULO must be set.

The axis functionality is maintained; transition to axis operation can be performed with M70.

The gear stage-specific spindle data are set in parameter blocks 1 to 5; parameter block 0 is used for axis operation (MD35590 \$MA_PARAMSET_CHANGE_ENABLE).

The lowest spindle number is 1, the highest number depends on the number of axes in the channel.

If other spindle numbers are to be assigned, the function "spindle converter" must be used.

With multi-channel systems, the same numbers can be assigned in all channels, except for those spindles active in several channels (replacement axes/spindles MD 30550: \$MA_AXCONF_ASSIGN_MASTER_CHAN).

35010	GEAR_STEP_CHANGE_ENABLE		A06, A11	P3 pl,P3 sl,S1		
-	Parameterize gear stage change		DWORD	Reset		
CTEQ						
-	-	0x00	0	0x2B	2/2	M

Description:

Meaning of bit places:

Bit 0 = 0 and bit 1 = 0:

There is an invariable gear ratio between motor and load. The MD of the first gear stage is active. Gear stage change is not possible with M40 to M45.

Bit 0 = 1:

Gear stage change at undefined change position. The gear can have up to 5 gear stages, which can be selected with M40, M41 to M45. To support the gear stage change, the motor can carry out oscillating motions, which must be enabled by the PLC program.

Bit 1 = 1:

Same meaning as bit 0 = 1, although the gear stage change is carried out in a configured spindle position (SW 5.3 and higher). The change position is configured in MD35012 \$MA_GEAR_STEP_CHANGE_POSITION. The position is approached in the current gear stage before the gear stage change. If this bit is set, bit 0 is not taken into account!

Bit 2: Reserved

Bit 3 = 1:

The gear stage change dialog between NCK and PLC is simulated. The set-point gear stage is output to the PLC. A checkback signal from the PLC is not awaited. The acknowledgment is generated internally in the NCK.

Bit 4: Reserved

Bit 5 = 1:

The second gear stage data set is used for tapping with G331/G332. The bit must be set for the master spindle used for tapping. Bit 0 or bit 1 must be set.

Related to:

MD35090 \$MA_NUM_GEAR_STEPS (number of gear stages 1st data set, see bit 5)
 MD35092 \$MA_NUM_GEAR_STEPS2 (number of gear stages 2nd data set, see bit 5)
 MD35110 \$MA_GEAR_STEP_MAX_VELO (max. speed for autom. gear stage change)
 MD35112 \$MA_GEAR_STEP_MAX_VELO2 (max. speed for autom. gear stage change 2nd data set, see bit 5)
 MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for autom. gear stage change)
 MD35122 \$MA_GEAR_STEP_MIN_VELO2 (min. speed for autom. gear stage change 2nd data set, see bit 5)

35012	GEAR_STEP_CHANGE_POSITION			A06, A11	S1	
mm, degrees	Gear stage change position			DOUBLE	NEW CONF	
CTEQ						
-	6	0.0, 0.0, 0.0, 0.0, 0.0, 0.0	-	-	2/2	M

Description: Gear stage change position.
 The value range must be within the configured modulo range.

Related to:

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE, bit 1
 MD30330 \$MA_MODULO_RANGE

35014	GEAR_STEP_USED_IN_AXISMODE			A01, A06, A11	-	
-	Gear stage for axis mode with M70			DWORD	NEW CONF	
CTEQ						
-	-	0	0	5	2/2	M

Description: With this MD, a gear stage can be defined which can be loaded into the axis mode during the transition with M70. The parameter set zero used in axis mode is to be optimized on this gear stage.

Significance of the values:

0: There is no implicit gear stage change with M70.

The current gear stage is retained.

1 ... 5:

There is a change into gear stage (1...5) during the execution of M70.

During the transition into axis mode without M70, there is monitoring for this gear stage and alarm 22022 is issued if necessary. The condition for a gear stage change is the general release of the function in MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE.

Secondary conditions:

When changing from axis mode into spindle mode, the configured gear stage continues to remain active. There is no automatic return to the last active gear stage in spindle mode.

35020	SPIND_DEFAULT_MODE			A06, A10	S1	
-	Initial spindle setting			BYTE	Reset	
CTEQ						
-	-	0	0	3	2/2	M

Description: SPIND_DEFAULT_MODE activates the set operating mode of the spindle at the time specified in MD35030 \$MA_SPIND_DEFAULT_ACT_MASK. The appropriate spindle operating modes can be set with the following values:

- 0 Speed mode, position control deselected
- 1 Speed mode, position control activated
- 2 Positioning mode, no check for synchronized/referenced position on NC start
- 3 Axis mode, MD34110 \$MA_REFP_CYCLE_NR can be used to configure / deactivate forced referencing on NC start

Corresponds with:

- MD35030 \$MA_SPIND_DEFAULT_ACT_MASK (activate spindle initial setting)
- MD20700 \$MC_REFP_NC_START_LOCK (NC start disable without reference point)

35030	SPIND_DEFAULT_ACT_MASK			A06, A10	S1	
-	Time at which initial spindle setting is effective			BYTE	Reset	
CTEQ						
-	-	0x2	0	0x03	1/1	M

Description: SPIND_DEFAULT_ACT_MASK specifies the time at which the operating mode defined in MD35020 \$MA_SPIND_DEFAULT_MODE becomes effective. The initial spindle setting can be assigned the following values at the following points in time:

- 0 POWER ON
- 1 POWER ON and NC program start
- 2 POWER ON and RESET (M2/M30)

Special cases:

If MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET = 1, the following supplementary conditions are applicable:

- SPIND_DEFAULT_ACT_MASK should be set to 0
- If this is not possible, the spindle must be at a standstill prior to activation.

Related to:

- MD35020 \$MA_SPIND_DEFAULT_MODE (initial spindle setting)
- MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET (spindle active after reset)

35035	SPIND_FUNCTION_MASK			A06, A10	K1,S1	
-	Spindle functions			DWORD	Reset	
CTEQ						
828d-me41	-	0x130	-	-	1/1	M
828d-me61	-	0x130	-	-	1/1	M
828d-me81	-	0x130	-	-	1/1	M
828d-te61	-	0x110	-	-	1/1	M
828d-te81	-	0x110	-	-	1/1	M
828d-te41	-	0x110	-	-	1/1	M

Description:

This MD allows spindle-specific functions to be set.

The MD is bit-coded, the following bits are assigned:

Bit 0 = 1: Gear stage changes are suppressed with activated DryRun function for

block programming (M40, M41 to M45), programming via FC18, and synchronized actions.

Bit 1 = 1: Gear stage changes are suppressed with activated program test function

for block programming (M40, M41 to M45), programming via FC18, and synchronized actions.

Bit 2 = 1: Gear stage change for programmed gear stage will finally be carried

out after deselection of DryRun or program test functions with REPOS.

Bit 3: reserved

Bit 4 = 1:

The programmed speed is transferred to SD 43200 \$SA_SPIND_S (incl. speed default settings via FC18 and synchronized actions).

S programmings that are not speed programmings are not written to the SD. These include, for example, S value with constant cutting velocity (G96, G961), S value with revolution-related dwell time (G4).

Bit 5 = 1:

The content of SD 43200 \$SA_SPIND_S is applied as the speed setpoint for JOG. If the content is zero, then other JOG speed default settings become active (see SD 41200 JOG_SPIND_SET_VELO).

Bit 6: reserved

Bit 7: reserved

Bit 8 = 1:

The programmed cutting velocity is transferred to SD 43202 \$SA_SPIND_CONSTCUT_S (incl. default settings via FC18). S programmings, that are not cutting velocity programmings, are not written to the SD. These include, for example, S value outside of constant cutting velocity (G96, G961, G962), S value with revolution-related dwell time (G4), S value in synchronized actions.

Bit 9: reserved

Bit 10 = 0:

SD 43206 \$SA_SPIND_SPEED_TYPE is not changed by part program or channel settings,

= 1:

For the master spindle, the value of the 15th G group (type of feedrate) is transferred to SD 43206 \$SA_SPIND_SPEED_TYPE. For all other spindles,

2.4 Axis-specific machine data

the corresponding SD remains unchanged.

Bit 11: reserved

Bit 12 = 1:

Spindle override is active with zero mark search for M19, SPOS, and SPOSA = 0:

Previous response (default)

The following bits 16-20 can be used to set spindle-specific M functions which are output to the VDI interface

if the corresponding M functionality has been generated implicitly for the program sequence.

Bit 16: reserved

Bit 17: reserved

Bit 18: reserved

Bit 19:"Output implicit M19 to PLC"

= 0: If MD20850 \$MC_SPOS_TO_VDI = 0 too, no auxiliary function M19 is generated for SPOS and SPOSA. As a result, the acknowledgment time for the auxiliary function is also eliminated. This can cause problems in the case of short blocks.

= 1: The implicit auxiliary function M19 is generated with the programming of SPOS and SPOSA and output to the PLC. The address is expanded in accordance with the spindle number.

Bit 20:"Output implicit M70 to PLC"

= 0: No generation of implicit auxiliary function M70. Note: A programmed auxiliary function M70 is always output to the PLC.

= 1: Auxiliary function M70 is generated implicitly and output to the PLC on transition to axis mode. The address is expanded in accordance with the spindle number.

Bit 21: reserved

Bit 22 = 0: As of NCK version 78.00.00: The NC/PLC interface signal DB380x DBX2001.6 (invert M3/M4) is applied to the function for interpolatory tapping G331/G332.

Bit 22 = 1: Response is compatible with SW releases prior to NCK version 78.00.00: The NC/PLC interface signal DB380x DBX2001.6 (invert M3/M4) is not applied to the function for interpolatory tapping G331/G332.

MD is Corresponds with:

- MD20850 \$MC_SPOS_TO_VDI
- MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET
- MD35020 \$MA_SPIND_DEFAULT_MODE
- SD43200 \$SA_SPIND_S

35040	SPIND_ACTIVE_AFTER_RESET	A06, A10	S1,Z1,2,7
-	Own spindle RESET	BYTE	PowerOn
CTEQ			
-	-	2	0
		2	1/0
			M

Description: MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET defines the response of the spindle after channel reset NC/PLC interface signal DB3000 DBX0.7 (Reset) and program end (M2, M30).

This MD is only active in the spindle mode open-loop control mode. In positioning mode or oscillation mode, the spindle is always stopped.

MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET = 0:

- Spindle stops (with M2/M30 and channel and mode group reset).
- Program is aborted.
- For spindle mode, the programmed ACC and VELOLIM are reset to 100% if MD22400 \$MC_S_VALUES_ACTIVE_AFTER_RESET and the axis-specific MD32320 \$MA_DYN_LIMIT_RESET_MASK do not specify anything else.

MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET= 1:

- Spindle does not stop.
- Program is aborted.
- For spindle mode, the programmed ACC and VELOLIM are retained.

MD35040 \$MA_SPIND_ACTIVE_AFTER_RESET= 2:

- Spindle does not stop at the M function configured via MD10714 \$MN_M_NO_FCT_EOP (e.g. M32).
- However, the spindle stops at channel or mode group reset.
- For spindle mode, the programmed ACC and VELOLIM are retained.

The NC/PLC interface signal DB380x DBX2.2 (Delete distance-to-go/Spindle reset) is always effective, independent of MD35040

\$MA_SPIND_ACTIVE_AFTER_RESET.

Not relevant to:

- Spindle modes other than open-loop control mode.

Related to:

NC/PLC interface signal DB3000 DBX0.7 (Reset)

NC/PLC interface signal DB380x DBX2.2 (Delete distance-to-go/Spindle reset)

35090	NUM_GEAR_STEPS		A06, A10	S1	
-	Number of gear stages		DWORD	Reset	
-					
-	-	MAXNUM_GEAR_STEPS	1	5	2/2 M

Description:

Number of set gear stages.

The first gear stage is always available.

Corresponding MDs:

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stages available/functions)

MD35012 \$MA_GEAR_STEP_CHANGE_POSITION (gear stage change position)

MD35014 \$MA_GEAR_STEP_USED_IN_AXISMODE (gear stage for axis mode with M70)

MD35110 \$MA_GEAR_STEP_MAX_VELO (max. speed for gear stage change)

MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for gear stage change)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (max. speed of gear stage)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (min. speed of gear stage)

MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL (acceleration in speed control mode)

MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL (acceleration in position control mode)

MD35310 \$MA_SPIND_POSIT_DELAY_TIME (positioning delay time)

MD35550 \$MA_DRILL_VELO_LIMIT (maximum speeds for tapping)

MD35092 \$MA_NUM_GEAR_STEPS2 (number of gear stages 2nd gear stage data set)

2.4 Axis-specific machine data

35092	NUM_GEAR_STEPS2			A06, A10	S1	
-	Number of gear stages of 2nd gear stage data set			DWORD	Reset	
-						
-	-	MAXNUM_GEAR_STEPS	1	5	2/2	M

Description: Number of set gear stages of the second gear stage data set for the function 'Tapping with G331/G332'.

Activation (only makes sense for master spindle on tapping): MD 35010 \$MA_GEAR_STEP_CHANGE_ENABLE, bit 5.

The number of gear stages must not be the same in the first and second gear stage data sets.

Corresponding MD:

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stages available/functions)

MD35112 \$MA_GEAR_STEP_MAX_VELO2 (2nd gear stage data set: max. speed for gear stage change)

MD35122 \$MA_GEAR_STEP_MIN_VELO2 (2nd gear stage data set: min. speed for gear stage change)

MD35212 \$MA_GEAR_STEP_POSCTRL_ACCEL2 (2nd gear stage data set: acceleration in position control mode)

35100	SPIND_VELO_LIMIT			A06, A11, A04	TE3,G2,S1,V1,Z1	
rev/min	Maximum spindle speed			DOUBLE	Reset	
CTEQ						
-	-	10000.0	1.0e-3	-	7/2	M

Description: MD35100 \$MA_SPIND_VELO_LIMIT defines the maximum spindle speed that the spindle (the spindle chuck with the workpiece or the tool) must not exceed. The NCK limits an excessive spindle setpoint speed to this value. If the maximum spindle actual speed is exceeded, even allowing for the spindle speed tolerance (MD35150 \$MA_SPIND_DES_VELO_TOL), there is a fault with the drive and the NC/PLC interface signal DB390x DBX2001.0 (speed limit exceeded) is set. Alarm 22100 "Maximum speed reached" is also output and all axes and spindles on the channel are decelerated (provided the encoder is still functioning correctly). The spindle has to be brought to a standstill before modifying the MD.

Corresponds with:

MD35150 \$MA_SPIND_DES_VELO_TOL (spindle speed tolerance)

NC/PLC interface signal DB390x DBX2001.0 (speed limit exceeded)

Alarm 22100 "Maximum speed reached"

35110	GEAR_STEP_MAX_VELO			A06, A11, A04	A3,S1	
rev/min	Maximum speed for gear stage change			DOUBLE	NEW CONF	
CTEQ						
-	6	500., 500., 1000., 2000., 4000., 8000.	-	-	2/2	M

Description: MD35110 \$MA_GEAR_STEP_MAX_VELO defines the maximum speed (upper switching threshold) of the gear stage for automatic gear stage change M40 S... The speed ranges for the gear stages must be defined without gaps between them or can overlap.

Incorrect

MD35110 \$MA_GEAR_STEP_MAX_VELO [gear stage1] =1000

MD35120 \$MA_GEAR_STEP_MIN_VELO [gear stage2] =1200

Correct

MD35110 \$MA_GEAR_STEP_MAX_VELO [gear stage1] =1000

MD35120 \$MA_GEAR_STEP_MIN_VELO [gear stage2] = 950

Note:

- Programming a spindle speed which exceeds the highest numbered gear stage MD35110 \$MA_GEAR_STEP_MAX_VELO [MD35090] triggers a switch to the highest gear stage (MD35090).

Related to:

MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for automatic gear stage selection M40)

MD35090 \$MA_NUM_GEAR_STEPS (number of gear stages)

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change is possible)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of gear stage with speed control)

MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of gear stage with position control)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (min. speed of gear stage)

35112	GEAR_STEP_MAX_VELO2			A06, A11, A04	S1	
rev/min	2nd data set: Maximum speed for gear stage change			DOUBLE	NEW CONF	
CTEQ						
-	6	500., 500., 1000., 2000., 4000., 8000.	0	-	2/2	M

Description:

-

The 2nd gear stage data block for tapping with G331/G332 is activated with MD 35010:\$MA_GEAR_STEP_CHANGE_ENABLE bit 5 for the master spindle.

Related to:

MD35122 \$MA_GEAR_STEP_MIN_VELO2 (minimum speed for 2nd data block gear stage selection)

MD35092 \$MA_NUM_GEAR_STEPS2 (number of gear stages 2nd gear stage data block)

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change, 2nd data block is possible)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of gear stage with speed control)

MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of gear stage with position control)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (min. speed of gear stage)

35120	GEAR_STEP_MIN_VELO			A06, A11, A04	S1	
rev/min	Minimum speed for gear stage change			DOUBLE	NEW CONF	
CTEQ						
-	6	50., 50., 400., 800., 1500., 3000.	-	-	2/2	M

Description:

-

See MD35120 \$MA_GEAR_STEP_MAX_VELO for more information.

Note:

- Programming a spindle speed which undershoots the lowest speed of the first gear stage MD35120 \$MA_GEAR_STEP_MIN_VELO[1] triggers a switch to the first gear stage.

Not relevant for:

- Programming of speed 0 (S0) if MD35120 \$MA_GEAR_STEP_MIN_VELO[1] > 0

Related to:

MD35110 \$MA_GEAR_STEP_MAX_VELO (maximum speed for automatic gear stage selection M40)

MD35090 \$MA_NUM_GEAR_STEPS (number of gear stages)

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change is possible)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of the gear stage with speed control)

MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of the gear stage with position control)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (min. speed of the gear stage)

35122	GEAR_STEP_MIN_VELO2			A06, A11, A04	S1	
rev/min	2nd data set: Minimum speed for gear stage change			DOUBLE	NEW CONF	
CTEQ						
-	6	50., 50., 400., 800., 1500., 3000.	0	-	2/2	M

Description:

The minimum speed (lower switching threshold) of the gear stage for automatic gear stage change M40 G331 S.. is set in GEAR_STEP_MIN_VELO2 for interpolatory tapping G331, G332. The speed ranges of the gear stages must be defined so that there are no gaps between them or they can overlap.

The 2nd gear stage data block for tapping with G331/G332 is activated with MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE bit 5 for the master spindle.

Related to:

MD35112 \$MA_GEAR_STEP_MAX_VELO2 (maximum speed for 2nd data block gear stage change)

MD35092 \$MA_NUM_GEAR_STEPS2 (number of gear stages 2nd gear stage data block)

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change, 2nd data block is possible)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of gear stage with speed control)

MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of gear stage with position control)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (min. speed of gear stage)

35130	GEAR_STEP_MAX_VELO_LIMIT			A06, A11, A04	A2,S1,V1	
rev/min	Maximum speed of gear stage			DOUBLE	NEW CONF	
CTEQ						
-	6	500., 500., 1000., 2000., 4000., 8000.	1.0e-3	-	2/2	M

Description: The maximum speed of the current gear stage for speed control mode (position control not active) is configured in MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT. The speed setpoints generated taking the override into account are limited to this speed.

Note:

- The configured speed cannot exceed the value from MD35100 \$MA_SPIND_VELO_LIMIT.
- If position control is active for the spindle, the speed is limited to the maximum speed of MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT.
- The NC/PLC interface signal "Setpoint speed limited" is set to indicate that the speed is being limited.
- The maximum speed entered here has no effect on the automatic gear stage selection M40 S..
- The upper switching threshold for the automatic gear stage selection M40 is configured in MD35110 \$MA_GEAR_STEP_MAX_VELO.

Related to:

MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of the gear stage with position control)

MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (minimum speed of the gear stage)

MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage selection is possible)

MD35110 \$MA_GEAR_STEP_MAX_VELO (max. speed for automatic gear stage selection M40)

MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for automatic gear stage selection M40)

35135	GEAR_STEP_PC_MAX_VELO_LIMIT			A06, A11, A04	S1	
rev/min	Maximum speed of the gear stage with position control			DOUBLE	NEW CONF	
CTEQ						
-	6	0., 0., 0., 0., 0., 0.	0	-	2/2	M

Description: The maximum speed of the current gear stage is configured in MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT with position control active. The speed setpoints generated taking the override into account are limited to this speed. If a value of 0 is set (default), 90% of the value from MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT will become the maximum speed with position control active.

Note:

- The configured speed cannot exceed the value from MD35100 \$MA_SPIND_VELO_LIMIT.
- The NC/PLC interface signal "Setpoint speed limited" is set to indicate that the speed is being limited.
- The maximum speed entered here has no effect on the automatic gear stage selection M40 S..
- The upper switching threshold for the automatic gear stage selection M40 is configured in MD35110 \$MA_GEAR_STEP_MAX_VELO.

2.4 Axis-specific machine data

Related to:

- MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of the gear stage with speed control)
- MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (minimum speed of the gear stage)
- MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage selection is possible)
- MD35110 \$MA_GEAR_STEP_MAX_VELO (max. speed for automatic gear stage selection M40)
- MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for automatic gear stage selection M40)

35140	GEAR_STEP_MIN_VELO_LIMIT	A06, A11, A04	S1,V1
rev/min	Minimum speed of gear stage	DOUBLE	NEW CONF
CTEQ			
-	6	5., 5., 10., 20., 40., 80.	-
			2/2
			M

Description: The minimum speed of the current gear stage is configured in MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT. The minimum speed is applied only if the spindle is in speed control mode. The speed setpoints generated taking the override into account do not undershoot the minimum speed.

Note:

- If an S value lower than the minimum speed is programmed, the setpoint speed is increased to the minimum speed.
- The NC/PLC interface signal "Setpoint speed increased" is set to indicate that the speed has been increased.
- The minimum speed entered here has no effect on the automatic gear stage selection M40 S..
- The lower switching threshold for the automatic gear stage selection M40 is configured in MD35120 \$MA_GEAR_STEP_MIN_VELO.

Not relevant for:

- Spindle oscillation mode (gear stage change)
- Positioning and axis spindle modes
- Signals which cause the spindle to stop

Related to:

- MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed of gear stage with speed control)
- MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (maximum speed of gear stage with position control)
- MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change is possible)
- MD35110 \$MA_GEAR_STEP_MAX_VELO (max. speed for automatic gear stage selection M40)
- MD35120 \$MA_GEAR_STEP_MIN_VELO (min. speed for automatic gear stage selection M40)

35150	SPIND_DES_VELO_TOL	A03, A05, A06, A10, A04			R1,S1,Z1	
-	Spindle speed tolerance	DOUBLE			Reset	
-						
-	-	0.1	0.0	1.0	2/2	M

Description:

In spindle control mode, the set speed (programmed speed x spindle offset, allowing for limits) is compared with the actual speed.

- If the actual speed deviates from the set speed by more than MD35150 \$MA_SPIND_DES_VELO_TOL, the NC/PLC interface signal is DB390x DBX2001.5 (Spindle in setpoint range) is set to zero.
- If the actual speed deviates from the set speed by more than MD35150 \$MA_SPIND_DES_VELO_TOL, the path feed is disabled (positioning axes continue traversing).
- If the actual speed exceeds the maximum spindle speed (MD35100 \$MA_SPIND_VELO_LIMIT) by more than MD35150 \$MA_SPIND_DES_VELO_TOL, the NC/PLC interface signal is DB390x DBX2001.0 (Speed limit exceeded) is enabled and alarm 22050 "Maximum speed reached" is output. All axes and spindles on the channel are decelerated.

MD irrelevant to:

- Spindle oscillation mode
- Spindle positioning mode

Example:

MD 35150 \$MA_SPIND_DES_VELO_TOL = 0.1

The actual spindle speed must not deviate from the set speed by more than +/- 10%.

Related to:

MD35500 \$MA_SPIND_ON_SPEED_AT_IPO_START

(feed enable for spindle in setpoint range)

MD35100 \$MA_SPIND_VELO_LIMIT

(maximum spindle speed)

NC/PLC interface signal DB390x DBX2001.5 (Spindle in setpoint range)

NC/PLC interface signal DB390x DBX2001.0 (Speed limit exceeded)

Alarm 22050 "Maximum speed reached"

35160	SPIND_EXTERN_VELO_LIMIT	A06, A04			A3,S1,V1,Z1	
rev/min	Spindle speed limitation from PLC	DOUBLE			NEW CONF	
CTEQ						
-	-	1000.0	1.0e-3	-	2/2	M

Description:

A limiting value for the maximum spindle speed is entered in MD35160 \$MA_SPIND_EXTERN_VELO_LIMIT, which is taken into account exactly when the NC/PLC interface signal DB380x DBX3.6 (Velocity/speed limitation) is set.

The control limits a spindle speed which is too high to this value.

2.4 Axis-specific machine data

35200	GEAR_STEP_SPEEDCTRL_ACCEL			A06, A11, A04, -	S1	
rev/s ²	Acceleration in speed control mode			DOUBLE	NEW CONF	
CTEQ						
-	6	100, 100	1.0e-3	-	1/1	M

Description: If the spindle is in speed control mode, the acceleration is entered in MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL.
The spindle is in speed control mode with the function SPCOF.
Special cases:
The acceleration in speed control mode (MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL) can be set so that the electric current limit is reached.
Related to:
MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL (acceleration in position control mode)
MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT (speed limit for reduced acceleration)

35210	GEAR_STEP_POSCTRL_ACCEL			A06, A11, A04, -	S1	
rev/s ²	Acceleration in position control mode			DOUBLE	NEW CONF	
CTEQ						
-	6	30.0, 30.0, 25.0, 20.0, 15.0, 10.0	1.0e-3	-	2/2	M

Description: The acceleration in position control mode must be set so that the electric current limit is not reached.
Related to:
MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL
MD35212 \$MA_GEAR_STEP_POSCTRL_ACCEL2

35212	GEAR_STEP_POSCTRL_ACCEL2			A06, A11, A04, -	S1	
rev/s ²	2nd data set: Acceleration in position control mode			DOUBLE	NEW CONF	
CTEQ						
-	6	30.0, 30.0, 25.0, 20.0, 15.0, 10.0	1.0e-3	-	2/2	M

Description: Second gear stage data set for maximum acceleration capability of the gear stages in position control mode.
The acceleration in position control mode must be set so that the electric current limit is not reached.
The 2nd data set for tapping with G331/G332 is activated by MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE, bit 5 for the master spindle.
Related to:
MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL
MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL
MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT

35220	ACCEL_REDUCTION_SPEED_POINT	A06, A04			S1,S3,B2	
-	Speed for reduced acceleration	DOUBLE			Reset	
-						
-	-	1.0	0.0	1.0	2/2	M

Description: This machine data defines the threshold speed/velocity for spindles/positioning/path axes from which the acceleration reduction is to start. The reference is the defined maximum speed/velocity. The starting point is a percentage of the maximum values.

Example: MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT = 0.7, the maximum speed is 3000 rpm. Acceleration reduction starts at $v_{on} = 2100$ rpm, i.e. the maximum acceleration capacity is utilized in the speed range 0...2099.99 rpm. Reduced acceleration is used from 2100 rpm to the maximum speed.

Related to:

MD32000 \$MA_MAX_AX_VELO
(maximum axis velocity)
MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT
(maximum gear stage speed)
MD35230 \$MA_ACCEL_REDUCTION_FACTOR
(reduced acceleration)

35230	ACCEL_REDUCTION_FACTOR	A06, A04			S1,S3,B2	
-	Reduced acceleration	DOUBLE			Reset	
CTEQ						
-	-	0.0	0.0	0.95	2/2	M

Description: The machine data contains the factor by which the acceleration of the spindle/positioning/path axes is reduced with reference to the maximum speed/velocity. The acceleration is reduced by this factor between the threshold speed/velocity defined in MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT and the maximum speed/velocity.

Example:

$a = 10 \text{ rev/s}^2$, $v_{on} = 2100$ rpm, MD35230 \$MA_ACCEL_REDUCTION_FACTOR = 0.3. Acceleration and deceleration take place within the speed range 0...2099.99 rpm with an acceleration of 10 rev/s^2 . From a speed of 2100 rpm up to the maximum speed, the acceleration is reduced from 10 rev/s^2 to 7 rev/s^2 .

MD irrelevant to:

Errors that lead to rapid stop.

Related to:

MD32300 \$MA_MAX_AX_ACCEL (axis acceleration)
MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL
(acceleration in speed control mode)
MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL
(acceleration in position control mode)
MD35242 \$MA_ACCEL_REDUCTION_SPEED_POINT
(speed for reduced acceleration)

35240	ACCEL_TYPE_DRIVE	A04	B1,B2
-	Acceleration curve DRIVE for axes ON/OFF	BOOLEAN	Reset
CTEQ			
-	-	FALSE	-
			1/1
			M

Description: Basic setting of the acceleration response of the axis (positioning, oscillation, JOG, path motions):
 FALSE: No acceleration reduction
 TRUE: Acceleration reduction active
 MD is active only when MD32420 \$MA_JOG_AND_POS_JERK_ENABLE = FALSE.
 The settings in MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT and MD35230 \$MA_ACCEL_REDUCTION_FACTOR are always active for spindles (in spindle mode).
 Remark:
 This MD also influences the path motion with SOFT, BRISK, TRAFO

35242	ACCEL_REDUCTION_TYPE	A04	B1,B2
-	Type of acceleration reduction	BYTE	Reset
CTEQ			
-	-	1	0
			2
			2/2
			M

Description: Shape of acceleration reduction characteristic with DRIVE velocity control
 0: Constant
 1: Hyperbolic
 2: Linear

35300	SPIND_POSCTRL_VELO	A06, A04	P3 pl,P3 sl,R1,S1
rev/min	Position control activation speed	DOUBLE	NEW CONF
CTEQ			
-	6	500.0, 500.0, 500.0, 500.0, 500.0, 500.0	-
			-
			2/2
			M

Description: When positioning a spindle that is not in position control mode from a high speed, the position control is not activated until the spindle has reached or falls below the velocity defined in MD35300 \$MA_SPIND_POSCTRL_VELO.
 The speed can be changed with FA[Sn] from the part program. Please refer to the documentation:
 /FB1/ Function Manual, Basic Functions; Spindles (S1), section "Spindle mode 'positioning operation" for a description of the spindle behavior under various supplementary conditions (positioning from rotation, positioning from standstill).
 Note:
 The active speed from MD35300 \$MA_SPIND_POSCTRL_VELO cannot exceed the max. speed set in MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT. If MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT = 0, the value is limited to 90% of MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT.
 Related to:
 MD35350 \$MA_SPIND_POSITIONING_DIR (direction of rotation during positioning from standstill, if no synchronization is available)
 MD35100 \$MA_SPIND_VELO_LIMIT (chuck speed)

35310	SPIND_POSIT_DELAY_TIME			A06, A04	S1	
s	Positioning delay time			DOUBLE	NEW CONF	
CTEQ						
-	6	0.0, 0.05, 0.1, 0.2, 0.4, 0.8	-	-	2/2	M

Description:

Positioning delay time.

After reaching the positioning end (exact stop fine), there is a waiting time equal to the time set in this MD. The position matching the currently set gear stage is selected.

The delay time is activated for:

- Gear stage change at defined spindle position. After reaching the position configured in MD35012 \$MA_GEAR_STEP_CHANGE_POSITION, there is a waiting period equal to the time specified here. After expiry of this time, the position control is switched off for an active direct measuring system, and the NC/PLC interface signals DB390x DBX2000.3 (Change gear) and DB390x DBX2000.0 - .2 (Setpoint gear stage A-C) are output.
- Block search upon the output of an accumulated positioning block (SPOS, SPOSA, M19).

35350	SPIND_POSITIONING_DIR			A06	S1	
-	Direction of rotation when positioning			BYTE	Reset	
CTEQ						
-	-	3	3	4	2/2	M

Description:

When SPOS or SPOSA is programmed, the spindle is switched to position control mode and accelerates with the acceleration defined in MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL (acceleration in position control mode) if the spindle is not synchronized. The direction of rotation is defined by MD35350 \$MA_SPIND_POSITIONING_DIR (direction of rotation for positioning from stand-still).

MD35350 \$MA_SPIND_POSITIONING_DIR = 3 ---> Clockwise direction of rotation

MD35350 \$MA_SPIND_POSITIONING_DIR = 4 ---> Counterclockwise direction of rotation

Related to:

MD35300 \$MA_SPIND_POSCTRL_VELO (position control activation speed)

35400	SPIND_OSCILL_DES_VELO			A06, A04	P3 pl,P3 sl,S1	
rev/min	Oscillation speed			DOUBLE	NEW CONF	
CTEQ						
-	-	500.0	-	-	2/2	M

Description:

During oscillation, the NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed) is used to select a motor speed for the spindle motor. This motor speed is defined in MD35400 \$MA_SPIND_OSCILL_DES_VELO. The motor speed defined in this MD is independent of the current gear stage. In the AUTOMATIC and MDI displays, the oscillation speed is displayed in the "Spindle setpoint" window until the gear is changed.

MD irrelevant to:

All spindle modes except oscillation mode

Special cases:

The acceleration during oscillation (MD35410 \$MA_SPIND_OSCILL_ACCEL) is valid for the oscillation speed defined in this MD.

2.4 Axis-specific machine data

Related to:

MD35410 \$MA_SPIND_OSCILL_ACCEL (acceleration during oscillation)

NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)

NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC)

35410	SPIND_OSCILL_ACCEL	A06, A04, -	S1,Z1
rev/s ²	Acceleration during oscillation	DOUBLE	NEW CONF
CTEQ			
-	-	16.0	1.0e-3
		-	2/2
			M

Description:

The acceleration specified here is only effective for the output of the oscillation speed (MD35400 \$MA_SPIND_OSCILL_DES_VELO) to the spindle motor. The oscillation speed is selected using the NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed).

MD irrelevant to:

All spindle modes except oscillation mode

Related to:

MD35400 \$MA_SPIND_OSCILL_DES_VELO (oscillation speed)

NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)

NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC)

35430	SPIND_OSCILL_START_DIR	A06	S1
-	Start direction during oscillation	BYTE	Reset
CTEQ			
-	-	0	0
		4	2/2
			M

Description:

With the NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed), the spindle motor accelerates to the speed specified in MD35400: \$MA_SPIND_OSCILL_DES_VELO.

The start direction is defined by MD35430 \$MA_SPIND_OSCILL_START_DIR if the NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC) is not enabled.

MD35430 \$MA_SPIND_OSCILL_START_DIR = 0 ---> Start direction same as the last direction of rotation

MD35430 \$MA_SPIND_OSCILL_START_DIR = 1 ---> Start direction counter to the last direction of rotation

MD35430 \$MA_SPIND_OSCILL_START_DIR = 2 ---> Start direction counter to the last direction of rotation

MD35430 \$MA_SPIND_OSCILL_START_DIR = 3 ---> Start direction is M3

MD35430 \$MA_SPIND_OSCILL_START_DIR = 4 ---> Start direction is M4

MD irrelevant to:

All spindle modes except oscillation mode

Related to:

MD35400 \$MA_SPIND_OSCILL_DES_VELO (oscillation speed)

NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)

NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC)

35440	SPIND_OSCILL_TIME_CW	A06	S1,Z1
s	Oscillation time for M3 direction	DOUBLE	NEW CONF
CTEQ			
-	-	1.0	-
			2/2
			M

Description: The oscillation time defined here is active in the M3 direction.
MD irrelevant to:

- All spindle modes except oscillation mode
- Oscillation via PLC (NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC) enabled)

Related to:

MD35450 \$MA_SPIND_OSCILL_TIME_CCW (oscillation time for M4 direction)
MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO (interpolator cycle)
NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)
NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC)

35450	SPIND_OSCILL_TIME_CCW	A06	S1,Z1
s	Oscillation time for M4 direction	DOUBLE	NEW CONF
CTEQ			
-	-	0.5	-
			2/2
			M

Description: The oscillation time defined here is active in the M4 direction.
MD irrelevant to:

- All spindle modes except oscillation mode
- Oscillation via PLC (NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC) enabled)

Related to:

MD35440 \$MA_SPIND_OSCILL_TIME_CW (oscillation time for M3 direction)
MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO (interpolator cycle)
NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)
NC/PLC interface signal DB380x DBX2002.4 (Oscillation via PLC)

35500	SPIND_ON_SPEED_AT_IPO_START	A03, A06, A10	S1,Z1
-	Feedrate enable for spindle in the set range	BYTE	Reset
CTEQ			
-	-	2	0
		2	1/1
			M

Description: For SW 4.2 and higher:

Byte = 0:
The path interpolation is not affected

Byte = 1:
The path interpolation is not enabled (positioning axes continue traversing) until the spindle has reached the specified speed. The tolerance range can be set in MD 35150: \$MA_SPIND_DES_VELO_TOL. If a measuring system is active, then the actual speed is monitored, otherwise the set speed. Path axes traversing in continuous-path mode (G64) are not stopped.

Byte = 2:
In addition to 1, traversing path axes are also stopped before machining begins, e.g. continuous-path mode (G64) and the change from rapid traverse (G0) to a machining block (G1, G2,..). The path is stopped at the last G0 block, and does not start traversing until the spindle is within the set speed range.

2.4 Axis-specific machine data

Restriction:

If the spindle is newly programmed by the PLC (FC18) or a synchronized action "shortly" before the end of the last G0 block, then the path decelerates taking the dynamic limitations into account. Because the spindle programming is asynchronous, a traverse can be made into the machining block if necessary. If the spindle has reached the setpoint speed range, then machining starts from this position.

Byte = 3:

No longer available for SW 5.3 and higher.

Related to:

MD35150 \$MA_SPIND_DES_VELO_TOL (spindle speed tolerance)

NC/PLC interface signal DB390x DBX2001.5 (Spindle in setpoint range)

35510	SPIND_STOPPED_AT_IPO_START			A03, A06, A10	S1	
-	Feedrate enable for spindle stopped			BOOLEAN	Reset	
CTEQ						
-	-	TRUE	-	-	1/1	M

Description: When a spindle is stopped (M5), the path feed is disabled (positioning axes continue traversing) if MD35510 \$MA_SPIND_STOPPED_AT_IPO_START is enabled and the spindle is in control mode.

When the spindle has come to a standstill (NC/PLC interface signal DB390x DBX1.4 (Axis/spindle stationary) enabled), the path feed is enabled.

Related to:

MD35500 \$MA_SPIND_ON_SPEED_AT_IPO_START (feed enable for spindle in setpoint range)

35550	DRILL_VELO_LIMIT			A06, A11, A04	-	
rev/min	Maximum speeds for tapping			DOUBLE	NEW CONF	
CTEQ						
-	6	2000., 2000., 2000., 2000., 2000....	1	-	1/1	M

Description: Limit speed values for tapping without compensating chuck with G331/G332. The maximum speed of the linear motor characteristic range (constant acceleration capacity) must be specified depending on the gear stage.

35590	PARAMSET_CHANGE_ENABLE			EXP, A05	TE3,A2,S1,Z1	
-	Parameter set can be changed			BYTE	PowerOn	
CTEQ						
-	-	0	0	2	1/1	M

Description: 0: Parameter set changes cannot be controlled.

For axes and spindles in axis mode: The first parameter set is always active. In the case of spindles the parameter set is set as appropriate for the gear stage (1st gear stage uses 2nd parameter set). Exceptions: See below.

1: The parameter set applied in the servo is defined via the VDI interface or SCPARA. Parameter sets 1 to 6 can be selected. Sets are selected using the NC/PLC interface signal <Regler-Parametersatz1A-C/> (selection of parameter set servo A, B, C) in the binary-coded value range 0 to 5. Binary values 6 and 7 select parameter set no. 6. Exceptions: See below.

For 0 and 1:

With G33, G34, G35, G331, G332, the parameter set number for the axes involved is activated in accordance with the master spindle gear stage, increased by one (corresponds with parameter set numbers 2 to 6).

For spindles, parameter sets 2 to 6 are always active, depending on the set gear stage plus one.

2: The parameter set is only ever defined via the VDI interface or SCPARA. Parameter sets 1 to 6 can be selected. Sets are selected using the NC/PLC interface signal <Regler-Parametersatz1A-C/> (selection of parameter set servo A, B, C) in the binary-coded value range 0 to 5. Binary values 6 and 7 select parameter set no. 6.

Secondary conditions:

Changeover response is determined by whether the KV factor differs between the active parameter set and the new parameter set.

Changing a parameter set where the load gearbox factors differ between the active parameter set and the new parameter set will reset the referenced signal, provided that the axis has an indirect measuring system.

The parameter set contains the following axial machine data:

```
MD36200 $MA_AX_VELO_LIMIT
MD32200 $MA_POSCTRL_GAIN
MD32800 $MA_EQUIV_CURRCTRL_TIME
MD32810 $MA_EQUIV_SPEEDCTRL_TIME
MD32910 $MA_DYN_MATCH_TIME
MD31050 $MA_DRIVE_AX_RATIO_DENOM
MD31060 $MA_DRIVE_AX_RATIO_NUMERA
```

Corresponds with:

NC/PLC interface signals <Regler-Parametersatz1A-C/> (selection of parameter set servo A, B, C) and <Regler-Parametersatz2A-C/> (selected parameter set servo A, B, C)

References:

/FB/, H2, "Output of Auxiliary Functions to PLC"

36000	STOP_LIMIT_COARSE			A05	TE1,A3,B1,G2,S1,Z1	
mm, degrees	Exact stop coarse			DOUBLE	NEW CONF	
-						
828d-me41	-	0.04,0.04,0.04,0.4,0.04	-	-	2/2	M
828d-me61	-	0.04,0.04,0.04,0.4,0.04	-	-	2/2	M
828d-me81	-	0.04,0.04,0.04,0.4,0.04	-	-	2/2	M
828d-te61	-	0.04,0.04,0.4,0.4,0.04,0.04	-	-	2/2	M
828d-te81	-	0.04,0.04,0.4,0.4,0.04,0.04,0.04...	-	-	2/2	M
828d-te41	-	0.04,0.04,0.4,0.4,0.04	-	-	2/2	M

Description:

Threshold for exact stop coarse

An NC block is considered as terminated if the actual position of the path axes is away from the setpoint position by the value entered for the exact stop limit. If the actual position of a path axis is not within this limit, the NC block is considered as not terminated, and further part program execution is not possible. The magnitude of the value entered influences the transition to the next block. The larger the value, the earlier the block change is initiated.

If the specified exact stop limit is not reached, then

- the block is considered as not terminated,
- further traversing of the axis is not possible,
- alarm 25080 Positioning monitoring is output after expiry of the time specified in MD36020 \$MA_POSITIONING_TIME (monitoring time for exact stop fine),
- the direction of movement +/- is indicated for the axis in the positioning display. The exact stop window is also evaluated for spindles in position control mode (SPCON instruction).

Special cases:

MD36000 \$MA_STOP_LIMIT_COARSE must not be set smaller than MD36010 \$MA_STOP_LIMIT_FINE (exact stop fine). To achieve the identical block change behavior as with the "exact stop fine" criterion, the exact stop coarse window may be identical to the exact stop fine window. MD36000 \$MA_STOP_LIMIT_COARSE must not be set equal to or greater than MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance).

Related to:

MD36020 \$MA_POSITIONING_TIME (delay time, exact stop fine)

36010	STOP_LIMIT_FINE	A05	TE1,A3,B1,D1,G2,S1,Z1
mm, degrees	Exact stop fine	DOUBLE	NEW CONF
-			
828d-me41	-	0.01,0.01,0.01,0.1,0.01	- - 2/2 M
828d-me61	-	0.01,0.01,0.01,0.1,0.01,0.01	- - 2/2 M
828d-me81	-	0.01,0.01,0.01,0.1,0.01,0.01	- - 2/2 M
828d-te61	-	0.01,0.01,0.1,0.1,0.01,0.01	- - 2/2 M
828d-te81	-	0.01,0.01,0.1,0.1,0.01,0.01,0.01...	- - 2/2 M
828d-te41	-	0.01,0.01,0.1,0.1,0.01	- - 2/2 M

Description:

Threshold for exact stop fine

See also MD36000 \$MA_STOP_LIMIT_COARSE (exact stop coarse)

Special cases:

MD36010 \$MA_STOP_LIMIT_FINE must not be set greater than MD36000 \$MA_STOP_LIMIT_COARSE (exact stop coarse).

MD36010 \$MA_STOP_LIMIT_FINE must not be set greater than or equal to MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance).

Related to:

MD 36020: \$MA_POSITIONING_TIME (delay time, exact stop fine)

36012	STOP_LIMIT_FACTOR	A05	G1,A3,B1,G2,S1,Z1
-	Factor for exact stop coarse/fine and standstill	DOUBLE	NEW CONF
-			
-	6	1.0, 1.0, 1.0, 1.0, 1.0, 0.001	1000.0 2/2 M

Description:

With this factor,

MD36000 \$MA_STOP_LIMIT_COARSE,

MD36010 \$MA_STOP_LIMIT_FINE,

MD36030 \$MA_STANDSTILL_POS_TOL

can be re-assessed as a function of the parameter set. The relationship between these three values always remains the same.

Application examples:

Adapting the positioning behavior if the mass relationships change significantly with a gear change, or if it is desired to save on machine positioning time at the cost of accuracy in various operating conditions.

Related to:

MD36000 \$MA_STOP_LIMIT_COARSE,

MD36010 \$MA_STOP_LIMIT_FINE,

MD36030 \$MA_STANDSTILL_POS_TOL

2.4 Axis-specific machine data

36020	POSITIONING_TIME	A05	TE1,A3,B1,G2
s	Delay time exact stop fine	DOUBLE	NEW CONF
-			
-	-	1.0	-
-	-	-	2/2
-	-	-	M

Description: The following error must have reached the limit value for exact stop fine by the expiry of the time entered in this MD for traveling into the position (position setpoint has reached the destination).

The current following error is therefore continuously monitored for the time limit MD36010 \$MA_STOP_LIMIT_FINE. If this time is exceeded, alarm 25080 "Positioning monitoring" is output, and the axis stopped. The time entered in this MD should be long enough to ensure that the monitoring function is not triggered under normal operating conditions, taking into account any settling times.

Related to:

MD 36010: \$MA_STOP_LIMIT_FINE (exact stop fine)

36030	STANDSTILL_POS_TOL	A05	G1,A3,D1,G2
mm, degrees	Standstill tolerance	DOUBLE	NEW CONF
-			
828d-me41	-	0.2,0.2,0.2,1.0,0.2	-
828d-me61	-	0.2,0.2,0.2,1.0,0.2,0.2	-
828d-me81	-	0.2,0.2,0.2,1.0,0.2,0.2	-
828d-te61	-	0.2,0.2,1.0,1.0,0.2,0.2	-
828d-te81	-	0.2,0.2,1.0,1.0,0.2,0.2,0.2,1.0	-
828d-te41	-	0.2,0.2,1.0,1.0,0.2	-
-	-	-	7/2
-	-	-	M

Description: This MD serves as a tolerance band for the following monitoring functions:

- After termination of a traversing block (position partial setpoint=0 at the end of the movement), whether the following error has reached the limit value for MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance) is monitored after the programmable MD36040 \$MA_STANDSTILL_DELAY_TIME (delay time, standstill monitoring).
- After termination of a positioning action (exact stop fine reached), positioning monitoring is replaced by standstill monitoring. The axis is monitored for moving from its position by more than defined in MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance).

If the setpoint position is over- or undershot by the standstill tolerance, alarm 25040 "Standstill monitoring" is output and the axis stopped.

Special cases:

The standstill tolerance must be greater than the "exact stop limit coarse".

Related to:

MD36040 \$MA_STANDSTILL_DELAY_TIME (delay time, standstill monitoring)

36040	STANDSTILL_DELAY_TIME	A05	TE1,A3,F1,G2
s	Delay time for standstill monitoring	DOUBLE	NEW CONF
-			
-	-	0.4	-
-	-	-	2/2
-	-	-	M

Description: See MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance)

36042	FOC_STANDSTILL_DELAY_TIME	A05	F1
s	Delay time for standstill monitoring w/ active torque or force limitation.	DOUBLE	NEW CONF
-			
-	-	0.4	-
-	-	-	-
-	-	-	2/2
-	-	-	M

Description: Only for SIMODRIVE611D or PROFIdrive telegrams including a torque/force limiting value:
Waiting time between the end of a movement and activation of standstill monitoring with active torque/force limitation.
If the configurable end of block criterion occurs within this time, then standstill monitoring is activated.

36050	CLAMP_POS_TOL	A05	A3,D1,Z1
mm, degrees	Clamping tolerance	DOUBLE	NEW CONF
-			
-	-	0.5	-
-	-	-	-
-	-	-	2/2
-	-	-	M

Description: With NC/PLC interface signal DB380x DBX2.3 (Blocking action active), blocking monitoring is activated. If the monitored axis is forced away from the set-point position (exact stop limit) by more than the blocking tolerance, alarm 26000 "Blocking monitoring" is output and the axis stopped.
Threshold value for clamping tolerance (half width of window).
Special cases:
The clamping tolerance must be greater than the "exact stop limit coarse".
Related to:
NC/PLC interface signal DB380x DBX2.3 (Blocking action active)

36052	STOP_ON_CLAMPING	A10	A3
-	Special functions with clamped axis	BYTE	NEW CONF
CTEQ			
-	-	0	0
-	-	0x07	2/1
-	-	-	M

Description: This MD defines how a blocked axis is taken into account.
Bit 0 =0:
If a blocked axis is to be traversed again in continuous-path mode, it must be ensured via the part program that the path axes are stopped and that there is time for releasing the blockage.
Bit 0 =1:
If a blocked axis is to be traversed again in continuous-path mode, the LookAhead function stops the path motion if required until the position controller is allowed to traverse the blocked axis again, i.e. until the controller enable is set again.
Bit 1 is relevant only if bit 0 is set:
Bit 1 =0:
If a blocked axis is to be traversed again in continuous-path mode, the LookAhead function does not release the blockage.
Bit 1 =1:
If a blocked axis is to be traversed again in continuous-path mode, a traversing command for the blocked axis is given in the preceding G0 blocks so that the PLC releases the axis blockage again.

2.4 Axis-specific machine data

Bit 2 =0:

If an axis is to be blocked in continuous-path mode, it must be ensured in the part program that the path axes are stopped to make sure that there is time for setting the blockage.

Bit 2 =1:

If an axis is to be blocked in continuous-path mode, the LookAhead function stops the path motion prior to the next non-G0 block, if the axis has not yet been blocked by that time, i.e. the PLC has not yet set the feedrate override to zero.

36060	STANDSTILL_VELO_TOL			A05, A04	TE1,A2,A3,D1,Z1	
mm/min, rev/min	Threshold velocity/speed 'Axis/spindle in stop'			DOUBLE	NEW CONF	
-						
828d-me41	-	5.00,5.00,5.00,1800.0 0,360.00	-	-	7/2	M
828d-me61	-	5.00,5.00,5.00,1800.0 0,360.00,360.00	-	-	7/2	M
828d-me81	-	5.00,5.00,5.00,1800.0 0,360.00,360.00	-	-	7/2	M
828d-te61	-	5.00,5.00,1800.00,180 0.00,360.00...	-	-	7/2	M
828d-te81	-	5.00,5.00,1800.00,180 0.00,360.00...	-	-	7/2	M
828d-te41	-	5.00,5.00,1800.00,180 0.00,360.00	-	-	7/2	M

Description: This MD defines the standstill range for the axis velocity / spindle speed. If the current actual velocity of the axis or the actual speed of the spindle is less than the value entered in this MD, the NC/PLC interface signal DB390x DBX1.4 (Axis/spindle stationary) is set.

To bring the axis/spindle to a standstill under control, the pulse enable should not be removed until the axis/spindle is at a standstill. Otherwise the axis will coast down.

Related to:

NC/PLC interface signal DB390x DBX1.4 (Axis/spindle stationary)

36100	POS_LIMIT_MINUS			A03, A05, A11,	TE1,R2,T1,A3,Z1	
mm, degrees	1st software limit switch minus			DOUBLE	NEW CONF	
CTEQ						
-	-	-1.0e8	-	-	2/2	M

Description: Same meaning as 1st software limit switch plus, however the traversing range limitation is in the negative direction.

The MD becomes active after reference point approach if the NC/PLC interface signal DB380x DBX1000.2 (2nd software limit switch minus) is not set.

MD irrelevant:

if axis is not referenced.

Related to:

NC/PLC interface signal DB380x DBX1000.2 (2nd software limit switch minus)

36110	POS_LIMIT_PLUS	A03, A05, A11,	TE1,R2,T1,G2,A3,Z1
mm, degrees	1st software limit switch plus	DOUBLE	NEW CONF
CTEQ			
-	-	1.0e8	-
			2/2
			M

Description: A software limit switch can be activated in addition to the hardware limit switch. The absolute position in the machine axis system of the positive range limit of each axis is entered.

The MD is active after reference point approach if NC/PLC interface signal DB380x DBX1000.3 (2nd software limit switch plus) has not been set.

MD irrelevant:

if axis is not referenced.

Related to:

NC/PLC interface signal DB380x DBX1000.3 (2nd software limit switch plus)

36120	POS_LIMIT_MINUS2	A03, A05, -	TE1,A3,Z1
mm, degrees	2nd software limit switch minus	DOUBLE	NEW CONF
CTEQ			
-	-	-1.0e8	-
			2/2
			M

Description: Same meaning as 2nd software limit switch plus, but the traversing range limitation is in the negative direction.

The PLC can select whether software limit switch 1 or 2 is to be active by means of the interface signal.

For example:

DB380x DBX1000.2 = 0 (1st software limit switch minus) active for 1st axis

DB380x DBX1000.2 = 1 (2nd software limit switch minus) active for 1st axis

MD irrelevant:

if axis is not referenced.

Related to:

NC/PLC interface signal DB380x DBX1000.2 (2nd software limit switch minus)

36130	POS_LIMIT_PLUS2	A03, A05, -	TE1,A3,Z1
mm, degrees	2nd software limit switch plus	DOUBLE	NEW CONF
CTEQ			
-	-	1.0e8	-
			2/2
			M

Description: This machine data can define a 2nd software limit switch position in the positive direction in the machine axis system. The PLC can select which of the two software limit switches 1 or 2 is to be active by means of an interface signal.

For example:

DB380x DBX1000.3 = 0 (1st software limit switch plus) active for 1st axis

DB380x DBX1000.3 = 1 (2nd software limit switch plus) active for 1st axis

MD irrelevant:

if axis is not referenced.

Related to:

NC/PLC interface signal DB380x DBX1000.3 (2nd software limit switch plus)

2.4 Axis-specific machine data

36200	AX_VELO_LIMIT			A05, A11, A04	TE3,A3,G2,S1,V1	
mm/min, rev/ min	Threshold value for velocity monitoring			DOUBLE	NEW CONF	
CTEQ						
-	6	11500., 11500., 11500., 11500....	-	-	2/2	M

Description: The threshold value for actual velocity monitoring is entered in this machine data.

If the axis has at least one active encoder and if this encoder is below its limit frequency, alarm 25030 "Actual velocity alarm limit" is triggered when the threshold value is exceeded, and the axis is stopped.

Settings:

- For axes, a value should be selected that is 10 to 15 % higher than that in MD32000 \$MA_MAX_AX_VELO (maximum axis velocity). With active temperature compensation MD32750 \$MA_TEMP_COMP_TYPE, the maximum axis velocity is increased by an additional factor which is determined by MD32760 \$MA_COMP_ADD_VELO_FACTOR (velocity overshoot through compensation). The following should therefore apply to the velocity monitoring threshold value:

$$MD36200 \$MA_AX_VELO_LIMIT[n] > MD32000 \$MA_MAX_AX_VELO * (1.1 \dots 1.15 + MD32760 \$MA_COMP_ADD_VELO_FACTOR)$$

- For spindles, a value should be selected for each gear stage that is 10 to 15 % higher than the corresponding values in MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT[n] (maximum speed of gear stage).

The index of the machine data has the following coding: [control parameter set no.]: 0-5

36210	CTRLOUT_LIMIT			EXP, A05	A3,D1,G2	
%	Maximum speed setpoint			DOUBLE	NEW CONF	
CTEQ						
-	1	110.0	0	200	7/2	M

Description: This MD defines the maximum speed setpoint in percent. 100% is the maximum speed setpoint, this corresponds to 10 V for an analog interface or the maximum speed for PROFIdrive drives (manufacturer-specific adjustable parameter in the drive, e.g. p1082 for SINAMICS).

The maximum speed setpoint depends on whether there are any setpoint limitations in the speed and current controller.

An alarm is output and the axis is stopped when the limit is exceeded.

The limit is to be selected so that the maximum velocity (rapid traverse) can be reached, and an appropriate additional control margin is available.

36220	CTRLOUT_LIMIT_TIME			EXP, A05	A3	
s	Delay time for speed setpoint monitoring			DOUBLE	NEW CONF	
-						
-	1	0.0	-	-	2/2	M

Description: This MD defines how long the speed setpoint may be within the limit CTRLOUT_LIMIT[n] (max. speed setpoint) until the monitoring function is triggered.

Monitoring (and with it also this machine data) is always active. Reaching the limit renders the position control loop non-linear, which results in contour errors provided that the speed setpoint limited axis is participating in contour generation. That is why this MD has default value 0, i.e. the monitoring function responds as soon as the speed setpoint reaches the limit.

36300	ENC_FREQ_LIMIT	EXP, A02, A05, A06	A3, D1, R1, Z1
-	Encoder limit frequency	DOUBLE	PowerOn
-			
-	2	3.0e5, 3.0e5	- - 2/2 M

Description: This MD is used to enter the encoder frequency, which, in general, is a manufacturer specification (type plate, documentation). For PROFIdrive:
No automatic, software-internal limitation for encoders on the PROFIdrive drive; here, the limit values of the measuring circuit module depend on the drive hardware used, i.e. known only by the drive. Therefore, it is the user who is responsible for taking into account the limit frequency of the measuring circuit module.

36302	ENC_FREQ_LIMIT_LOW	EXP, A02, A05, A06	A3, R1, S1, Z1
%	Encoder limit frequency for new encoder synchronization.	DOUBLE	NEW CONF
-			
-	2	99.9, 99.9	0 100 2/2 M

Description: Encoder frequency monitoring uses a hysteresis.
MD36300 \$MA_ENC_FREQ_LIMIT defines the encoder limit frequency. The encoder is switched off when this frequency is exceeded. The encoder is switched on again when the frequency falls below that defined in MD36302 \$MA_ENC_FREQ_LIMIT_LOW.
MD36300 \$MA_ENC_FREQ_LIMIT is entered directly in Hertz, whereas MD36302 \$MA_ENC_FREQ_LIMIT_LOW is a fraction, expressed as a percentage, of MD36300 \$MA_ENC_FREQ_LIMIT.
MD36302 \$MA_ENC_FREQ_LIMIT_LOW is therefore already correctly preset for most of the encoders used.
Exception: In the case of absolute encoders with an En-Dat interface, the limit frequency of the absolute track is significantly lower than the limit frequency of the incremental track. A low value in MD36302 \$MA_ENC_FREQ_LIMIT_LOW ensures that the encoder is not switched on again until it falls below the limit frequency of the absolute track, and therefore is not referenced until permitted by the absolute track. For spindles, this referencing is carried out automatically.
Example EnDat encoder EQN 1325:
Limit frequency of the electronics of the incremental track: 430 kHz
==> MD36300 \$MA_ENC_FREQ_LIMIT = 430 kHz
The limit frequency of the absolute track is approx. 2000 encoder rpm at 2048 increments/encoder revolution, i.e. the limit frequency is 2000/60 * 2048 Hz = 68 kHz
==> MD36302 \$MA_ENC_FREQ_LIMIT_LOW = 68/430 = 15%

2.4 Axis-specific machine data

36310	ENC_ZERO_MONITORING			EXP, A02, A05	A3,R1	
-	Zero mark monitoring			DWORD	NEW CONF	
-						
-	2	0,0	-	-	2/2	M

Description:

This MD is used to activate zero mark monitoring.

For PROFIdrive drives (the corresponding diagnostics system variables are not currently supplied for incremental measuring systems):

For PROFIdrive, the permissible deviation must be set in the drive, *not* in the NC. Zero mark monitoring reported by the drive is mapped to the NCK according to the following rule:

0: no zero mark monitoring

100: no zero mark monitoring together with suppression of all encoder monitoring operations, i.e. not only alarm 25020 but also alarms 25000, 25010 etc. are suppressed).

>0 but less than 100: direct triggering of power ON alarm 25000 (or 25001).

>100: attenuated error message: reset alarm 25010 (25011) is output instead of power ON alarm 25000 (25001).

For absolute measuring systems (\$MA_ENC_TYPE=4):

Permissible deviation in 1/2 coarse increments between the absolute and the incremental encoder track (one 1/2 coarse increment is sufficient).

If a SIMODRIVE611U drive type is used, monitoring only takes place at a standstill.

36400	CONTOUR_TOL			A05, A11	A3,D1,G2	
mm, degrees	Tolerance band for contour monitoring			DOUBLE	NEW CONF	
-						
828d-me41	-	1.0,1.0,1.0,20.0,1.0	-	-	7/2	M
828d-me61	-	1.0,1.0,1.0,20.0,1.0,1.0	-	-	7/2	M
828d-me81	-	1.0,1.0,1.0,20.0,1.0,1.0	-	-	7/2	M
828d-te61	-	1.0,1.0,20.0,20.0,1.0,1.0	-	-	7/2	M
828d-te81	-	1.0,1.0,20.0,20.0,1.0,1.0,1.0,20.0	-	-	7/2	M
828d-te41	-	1.0,1.0,20.0,20.0,1.0	-	-	7/2	M

Description:

Tolerance band for axial contour monitoring (dynamic following error monitoring).

The permissible deviation between the real and the modelled following error is entered in this MD.

The input of the tolerance band is intended to avoid spurious tripping of the dynamic following error monitoring caused by minor speed fluctuations, which occur during normal closed-loop control operations (e.g. during first cut). Following error modelling and thus the input of this MD depend on the position control gain MD32200 \$MA_POSCTRL_GAIN and, in the case of precontrol or simulation, on the accuracy of the controlled system model MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant for precontrol of speed control loop), as well as on the accelerations and velocities used.

36500	ENC_CHANGE_TOL	A02, A05	G1,K6,K3,A3,D1,G2,Z1
mm, degrees	Tolerance at actual position value change.	DOUBLE	NEW CONF
-			
-	-	0.1	-
-	-	-	2/2
-	-	-	M

Description: The permissible deviation between the actual values of the two measuring systems is entered in this MD.

This difference must not be exceeded when switching over the measuring system used for closed-loop control, in order to avoid compensating processes that are too strong. Otherwise, the error message 25100 "Axis %1 Switchover of measuring system not possible" is generated and the switchover does not take place.

MD irrelevant for:

MD30200 \$MA_NUM_ENCS = 0 or 1.

36510	ENC_DIFF_TOL	A02, A05	A3,G2
mm, degrees	Tolerance of measuring system synchronization	DOUBLE	NEW CONF
-			
-	-	0.0	-
-	-	-	2/2
-	-	-	M

Description: Permissible deviation between the actual values of the two measuring systems. This difference must not be exceeded during the cyclic comparison of the two measuring systems used, as otherwise error message 25105 (measuring systems deviate) would be generated.

The corresponding monitoring function is not active

- with MD input value=0,
- if less than 2 measuring systems are active/available in the axis
- or if the axis has not been referenced (at least act. closed-loop control meas. system).

With modulo axes, it is always the absolute value of the shortest/direct position difference that is monitored.

36520	DES_VELO_LIMIT	A02, A05	-
%	Threshold for setpoint velocity monitoring	DOUBLE	NEW CONF
-			
-	-	125.0	-
-	-	-	2/2
-	-	-	M

Description: Maximum permissible setpoint velocity as a percentage of the maximum axis velocity/spindle speed.

With MD36520 \$MA_DES_VELO_LIMIT, the position setpoint is monitored for abrupt changes. If the permissible limit value is exceeded, alarm 1016 error code 550010 is output.

With axes, this machine data refers to MD32000 \$MA_MAX_AX_VELO.

With spindles, this MD refers to the lower of the speeds set in MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT of the current gear stage and MD35100 \$MA_SPIND_VELO_LIMIT.

36600	BRAKE_MODE_CHOICE			EXP, A05	A3,Z1	
-	Deceleration response on hardware limit switch			BYTE	PowerOn	
CTEQ						
-	-	0	0	1	2/2	M

Description: If a rising edge of the axis-specific hardware limit switch is detected while the axis is traversing, the axis is braked immediately.

The type of braking is determined by this machine data:

Value = 0:

Controlled braking along the acceleration ramp defined by MD32300 \$MA_MAX_AX_ACCEL (axis acceleration).

Value = 1:

Rapid braking (selection of setpoint = 0) with reduction of following error.

Related to:

NC/PLC interface signal DB380x DBX1000.1 und .0 (Hardware limit switch plus or minus)

36610	AX_EMERGENCY_STOP_TIME			A05, -	TE3,K3,A2,A3,N2,Z1	
s	Maximum time for braking ramp in case of error.			DOUBLE	NEW CONF	
-						
-	-	0.05	0.0	1.0e15	2/2	M

Description: This MD defines the braking ramp time that an axis or spindle requires to brake from maximum velocity/speed to a standstill in the event of errors (e.g. emergency stop). At the same lead/brake acceleration, standstill is reached correspondingly earlier from lower velocities/speeds.

Mechanically robust axes are normally stopped abruptly with speed setpoint 0; values in the lower ms range are appropriate in these cases (default setting).

However, high moving masses or limited mechanical conditions (e.g. gear load capacity) often have to be taken into account for spindles. This means that the MD has to be changed to set a longer braking ramp.

Notice:

- With interpolating axes or axis/spindle couplings, it cannot be ensured that the contour or coupling will be maintained during the braking phase.
- If the time set for the braking ramp for error states is too long, the controller enable will be removed although the axis/spindle is still moving. Depending on the drive type used and the activation of the pulse enable, either an immediate stop with speed setpoint 0 will be initiated or the axis/spindle will coast down without power. The time selected in MD36610 \$MA_AX_EMERGENCY_STOP_TIME should therefore be shorter than the time in MD36620 \$MA_SERVO_DISABLE_DELAY_TIME (cutout delay, controller enable) so that the configured braking ramp can be fully active throughout the entire braking operation.
- The braking ramp may be ineffective or not maintained if the active drive follows its own braking ramp logic (e.g. SINAMICS).

Related to:

MD36620 \$MA_SERVO_DISABLE_DELAY_TIME (cutout delay controller enable)

MD36210 \$MA_CTRLOUT_LIMIT (maximum speed setpoint)

36620	SERVO_DISABLE_DELAY_TIME	A05, -	TE3,K3,A2,A3,N2,Z1
s	Cutout delay servo enable	DOUBLE	NEW CONF
-			
-	-	0.1	0.0
		1.0e15	2/2
			M

Description: Maximum time delay for removal of "controller enable" after faults. The speed enable (controller enable) of the drive is removed internally within the controller after the set delay time, at the latest.

The delay time entered becomes active as a result of the following events:

- Errors that lead to immediate stopping of the axes
- Removal of the interface signal DB380x DBX2.1 (Controller enable) from the PLC

As soon as the actual speed reaches the standstill range (MD36060 \$MA_STANDSTILL_VELO_TOL), the "controller enable" for the drive is removed. The time set should be long enough to enable the axis / spindle to brake down to a standstill from maximum traversing velocity or maximum speed. If the axis / spindle is stationary, the "controller enable" for the drive is removed immediately (i.e. the time defined in MD36620 \$MA_SERVO_DISABLE_DELAY_TIME is terminated prematurely).

Application example(s):

Speed control of the drive should be retained long enough to enable the axis / spindle to brake down to standstill from maximum traversing velocity or maximum speed.

Notice:

If the cutout delay controller enable is set too short, controller enable will be removed although the axis/spindle is still moving. This axis/spindle then coasts down without power (which may be appropriate for grinding wheels, for example); otherwise the time set in MD36620 \$MA_SERVO_DISABLE_DELAY_TIME should be longer than the duration of the braking ramp for error states (MD36610 \$MA_AX_EMERGENCY_STOP_TIME).

Related to:

NC/PLC interface signal DB380x DBX2.1 (Controller enable)

MD36610 \$MA_AX_EMERGENCY_STOP_TIME

For SINAMICS drives: Drive parameter P1082 (maximum speed / velocity)

36700	DRIFT_ENABLE	EXP, A07, A09	G2
-	Automatic drift compensation	BOOLEAN	NEW CONF
-			
-	-	FALSE	-
			1/1
			M

Description: Only for special analog and hydraulic drives (not active with PROFIdrive drives):

Automatic drift compensation is activated with MD36700 \$MA_DRIFT_ENABLE.

1: Automatic drift compensation active (only for position-controlled axes/spindles).

With automatic drift compensation, while the axis is at a standstill, the control continually calculates the additional drift value still required to ensure that the following error reaches the value 0 (compensation criterion). The total drift value is, therefore, formed from the drift basic value (MD36720 \$MA_DRIFT_VALUE) and the drift additional value.

0: Automatic drift compensation not active.

The drift value is formed only from the drift basic value (MD36720 \$MA_DRIFT_VALUE).

2.4 Axis-specific machine data

Not relevant for:

Non-position-controlled spindles

Related to:

MD36710 \$MA_DRIFT_LIMIT drift limit value for automatic drift compensation

MD36720 \$MA_DRIFT_VALUE drift basic value

36720	DRIFT_VALUE	EXP, A07, A09		-		
%	Basic drift value	DOUBLE		NEW CONF		
-						
-	1	0.0	-1e15	1e15	1/1	M

Description:

Only for special analog and hydraulic drives (not active with PROFIdrive drives):

The value entered in MD36720 \$MA_DRIFT_VALUE is always added as an offset to the manipulated variable. Whereas automatic drift compensation is active only for position-controlled axes, this machine data is always active.

Special case: the following applies to PROFIdrive drives:

This MD can also be used for "simple" drives that have drift problems due to drive-internal implementation as analog drives. To avoid erroneous settings, this static drift compensation only becomes active with PROFIdrive if \$MA_RATED_OUTVAL != 0 (i.e. the MD has no effect in the case of automatic interface adjustment between the NC and the drive).

Note:

Drift compensation must not be active if the DSC function (MD32640 \$MA_STIFFNESS_CONTROL_ENABLE=1) is being used, otherwise unexpected speed oscillations will occur when DSC is enabled/disabled.

Standardization: The input value is related to the corresponding interface standardization in

MD32250 \$MA_RATED_OUTVAL,
 MD32260 \$MA_RATED_VELO, and
 MD36210 \$MA_CTRL_OUT_LIMIT.

36730	DRIVE_SIGNAL_TRACKING	A10		B3		
-	Acquisition of additional drive actual values	BYTE		PowerOn		
-						
-	-	0	0	1	1/1	M

Description:

MD36730 \$MA_DRIVE_SIGNAL_TRACKING = 1 activates the acquisition of the following drive actual values (if they are made available by the drive):

- \$AA_LOAD Drive load
- \$AA_POWER Drive active power
- \$AA_TORQUE Drive torque setpoint
- \$AA_CURR Smoothed current setpoint (q-axis current) of drive

MD36730 \$MA_DRIVE_SIGNAL_TRACKING = 2 activates the acquisition of the following drive actual values:

With PROFIdrive, it must be ensured that the stated values are also transmitted in the drive actual message frame (provide sufficient message frame length on the bus, assign the values to the message frame content in the drive, e.g. use message frame 116).

- \$VA_DP_ACT_TEL shows actual value message frame words

Note: Values 3 and 4 are reserved

Note: The value range of MD36730 \$MA_DRIVE_SIGNAL_TRACKING can be restricted because of reduced functions of control systems

36750	AA_OFF_MODE	A10	2,4,5,3,6,2
-	Effect of value assignment for axial override of synchr. action.	BYTE	PowerOn
CTEQ			
-	-	0	0
-	-	7	2/2
-	-		M

Description: Mode setting for axial offset \$AA_OFF

Bit 0: Effect of value assignment within a synchronized action

0: Absolute value

1: Incremental value (integrator)

Bit 1: Response of \$AA_OFF on RESET

0: \$AA_OFF is deselected on RESET

1: \$AA_OFF is retained beyond RESET

Bit 2: \$AA_OFF in JOG mode

0: No superimposed motion due to \$AA_OFF

1: A superimposed motion due to \$AA_OFF is interpolated

37000	FIXED_STOP_MODE	A10, -	-
-	Travel to fixed stop mode	BYTE	PowerOn
CTEQ			
-	-	0x0	0x0
-	-	0x1	2/2
-	-		M

Description: Activation of subfunctions of "Travel to fixed stop".

Bit 0: Reserved

37002	FIXED_STOP_CONTROL	A10	F1
-	Sequence control for travel to fixed stop	BYTE	PowerOn
-			
-	-	0x0	0x0
-	-	0x3	2/2
-	-		M

Description: Sequence control for travel to fixed stop.

Bit 0: behavior on pulse disable at fixed stop

= 0: travel to fixed stop is canceled

= 1: travel to fixed stop is interrupted, i.e. the drive is without power. As soon as the pulse disable is canceled again, the drive continues with the limited torque.

Control of the torque injection see bit 1.

Bit 1: behavior after pulse disable at the fixed stop

= 0: the torque is applied in steps.

= 1: the torque is applied in ramps (see MD37012 \$MA_FIXED_STOP_TORQUE_RAMP_TIME)

37010	FIXED_STOP_TORQUE_DEF	A10	-
%	Default fixed stop clamping torque	DOUBLE	PowerOn
CTEQ			
-	-	5.0	0.0
-	-	100.0	2/2
-	-		M

Description: The clamping torque is set in this machine data as a % of the maximum motor torque (in the case of FDD this corresponds to the % of the max. current set-point).

The clamping torque becomes active as soon as the fixed stop is reached or the NC/PLC interface signal DB380x DBX1.1 (Acknowledge fixed stop reached) has been set.

2.4 Axis-specific machine data

The entered value is a default and is active only as long as

- no clamping torque has been programmed with command FXST[x]
- the clamping torque set in SD 43510: FIXED_STOP_TORQUE was not changed after fixed stop had been reached.

In the case of "Travel to fixed stop" with an analog drive (611-A) and fixed clamping torque, the torque limit set in the drive should be the same as the limit entered in MD37070 \$MA_FIXED_STOP_ANA_TORQUE.

Related to:

MD37070 \$MA_FIXED_STOP_ANA_TORQUE
 (torque limit on approach to fixed stop for analog drives)
 SD 43510: FIXED_STOP_TORQUE
 (clamping torque for travel to fixed stop)

37012	FIXED_STOP_TORQUE_RAMP_TIME	A10	-
s	Time period until reaching the changed torque limit	DOUBLE	NEW CONF
-			
-	0.0	-	2/2 M

Description: Period in seconds until the changed torque limit is reached.
 The value 0.0 deactivates the ramp function.

37014	FIXED_STOP_TORQUE_FACTOR	A10	TE3
-	Adaption factor torque limit	DOUBLE	NEW CONF
-			
-	1.0	-	2/2 M

Description: Interface factor torque limit.
 With this factor, the torque limit of linked slave axes (MD 37250) can be weighted additionally.
 Even with different motors, the torque limits can be kept equal in all linked axes.

37020	FIXED_STOP_WINDOW_DEF	A05, A10	-
mm, degrees	Default fixed-stop monitoring window	DOUBLE	PowerOn
CTEQ			
-	1.0	0.0	1.0e15 2/2 M

Description: This machine data is used to enter the default for the standstill monitoring window at fixed stop.
 Fixed stop monitoring becomes active as soon as the fixed stop is reached, i.e. NC/PLC interface signal DB390x DBX2.5 (Fixed stop reached) is set.
 If the position at which the fixed stop is detected is left by more than the tolerance specified in MD37020 \$MA_FIXED_STOP_WINDOW_DEF alarm 20093 "Fixed stop monitoring has responded" is output and the "FXS" function is deselected.
 The value entered is a default setting and is active only as long as

- no fixed stop monitoring window is programmed with command FXSW[x],
- the fixed stop monitoring window is not changed via SD 43520: FIXED_STOP_WINDOW (after reaching of fixed stop).

Related to:
 SD43520 \$SA_FIXED_STOP_WINDOW (fixed stop monitoring window)

37030	FIXED_STOP_THRESHOLD			A10, -		
mm, degrees	Threshold for fixed stop detection			DOUBLE	NEW CONF	
-						
-	-	2.0	0.0	1.0e15	2/2	M

Description: Threshold value for fixed stop detection.

The contour deviation is checked for this threshold as a criterion for reaching the fixed stop. Waiting until the set torque limit is reached is a further condition for digital drives.

This machine data is only active if MD37040 \$MA_FIXED_STOP_BY_SENSOR = 0.

The NC/PLC interface signal DB390x DBX2.5 (Fixed stop reached) is set if the axial contour deviation exceeds the threshold value set in MD37030 \$MA_FIXED_STOP_THRESHOLD.

MD irrelevant to:

MD37040 \$MA_FIXED_STOP_BY_SENSOR = 1

Related to:

NC/PLC interface signal DB390x DBX2.5 (Fixed stop reached)

37040	FIXED_STOP_BY_SENSOR			A10		
-	Fixed stop detection by sensor			BYTE	Immediately	
CTEQ						
-	-	0	0	3	2/2	M

Description: This machine data defines how the criterion "Fixed stop reached" is determined.

A change of this machine data becomes active with the next selection of travel to fixed stop.

MD=0

The criterion "Fixed stop reached" is determined internally on the basis of the axial FIXED_STOP_THRESHOLD.

MD=1

The criterion "Fixed stop reached" is determined via an external sensor and signalled to the NC via the NC/PLC interface signal DB380x DBX1.2 (Sensor fixed stop).

MD=2

The criterion "Fixed stop reached" is accepted if either the contour monitoring (MD = 0) or the signal of the external sensor (MD = 1) has responded.

MD=3

Triggering through movement analysis (only as an alternative to triggering via sensor)

Related to:

MD37030 \$MA_FIXED_STOP_THRESHOLD
(threshold for fixed stop detection)

NC/PLC interface signal DB380x DBX1.2 (Sensor fixed stop)

37050	FIXED_STOP_ALARM_MASK	A05, A10			-	
-	Enable of the fixed stop alarms	BYTE			NEW CONF	
-						
-	-	1	0	15	2/2	M

Description: This machine data defines whether the alarms
 20091 "Fixed stop not reached",
 20094 "Fixed stop aborted" and
 25042 "FOC: Standstill monitoring" are output.
 MD= 0
 Suppression of alarm 20091 "Fixed stop not reached"
 MD= 2
 Suppression of alarms
 20091 "Fixed stop not reached" and
 20094 "Fixed stop aborted" (SW 4 and higher)
 MD=3
 Suppression of alarm 20094 "Fixed stop aborted" (SW 4 and higher)
 Add value 8
 Suppression of alarm 25042 "FOC: Standstill monitoring" (SW 7 and higher)
 Errors occurring during travel to fixed stop can be read out from the status
 variable \$AA_FXS irrespective of the setting of the alarm screen.
 Standard: 1 = Alarms 20091, 20094 and 25042 are triggered

37052	FIXED_STOP_ALARM_REACTION	A05, A10			-	
-	Reaction with fixed stop alarms	BYTE			PowerOn	
-						
-	-	0	-	-	1/1	M

Description: Behavior of VDI signal "Mode group ready" in case of fixed stop alarms:
 Bit value = 0: "Mode group ready" will be deleted (drives de-energized)
 Bit value = 1: "Mode group ready" remains active
 Bit0: Alarm 20090 Travel to fixed stop not possible
 Bit1: Alarm 20091 Fixed stop not reached
 Bit2: Alarm 20092 Travel to fixed stop still active
 Bit3: Alarm 20093 Standstill monitoring at fixed stop has triggered
 Bit4: Alarm 20094 Travel to fixed stop aborted
 All other bits without meaning.
 Standard: 0 = All alarms de-energize the drives

37060	FIXED_STOP_ACKN_MASK	A10			-	
-	Waiting for PLC acknowledgements during travel to fixed stop	BYTE			PowerOn	
CTEQ						
-	-	0x0	0x0	0x3	2/2	M

Description: This machine data defines whether or not the NC waits for acknowledgment mes-
 sages from the PLC when the "Travel to fixed stop" function is active.
 Bit 0 = 0
 Once the NC has transmitted the interface signal DB390x DBX2.4 (Activate
 travel to fixed stop) to the PLC, it starts the programmed traversing.

Bit 0 = 1

After the NC has transmitted the interface signal DB390x DBX2.4 (Activate travel to fixed stop) to the PLC, it waits for the PLC to acknowledge with the interface signal DB380x DBX3.1 (Enable travel to fixed stop) and then starts the programmed traversing.

Bit 0 = 1 should be set for analog drives so that the motion is not started before the PLC has limited the torque in the drive.

Bit 1 = 0

Once the NC has transmitted the interface signal DB390x DBX2.5 (Fixed stop reached) to the PLC, the program advances to the next block.

Bit 1 = 1

After the NC has transmitted the interface signal DB390x DBX2.5 (Fixed stop reached) to the PLC, it waits for the PLC to acknowledge with the interface signal DB380x DBX1.1 (Acknowledge fixed stop reached), outputs the programmed torque and then advances to the next block.

Bit 1 should be set for analog drives so that the PLC can switch the drive to torque-controlled operation if a programmable clamping torque has to be specified.

With digital drives (PROFIdrive), the "Travel to fixed stop" function can be executed without any acknowledgments, thus allowing program run times to be reduced.

Related to:

NC/PLC interface signal DB390x DBX2.4 (Activate travel to fixed stop)

NC/PLC interface signal DB380x DBX3.1 (Enable travel to fixed stop)

NC/PLC interface signal DB390x DBX2.5 (Fixed stop reached)

NC/PLC interface signal DB380x DBX1.1 (Acknowledge fixed stop reached)

37080	FOC_ACTIVATION_MODE			A10	-	
-	Initial setting of modal torque/force limitation			BYTE	PowerOn	
-						
-	-	0x0	0x0	0x3	2/2	M

Description: The initial setting of the modal torque/force limitation is set with this MD after reset and PowerOn:

Bit 0: Response after PowerON

= 0 : FOCOF

= 1 : FOCON (modal)

Bit 1: Response after reset

= 0 : FOCOF

= 1 : FOCON (modal)

Default setting: FOCOF after reset and PowerOn

37100	GANTRY_AXIS_TYPE			A01, A10	G1,TE1,Z3	
-	Gantry axis definition			BYTE	PowerOn	
CTEQ						
-	-	0	0	11	2/2	M

Description: General: decimal representation, with a b

a

0: Leading axis

1: Synchronized axis

2.4 Axis-specific machine data

b

- 0: No gantry axis
- 1: Axis in gantry grouping 1
- 2: Axis in gantry grouping 2
- 3: Axis in gantry grouping 3
- ...

A max. of 8 gantry groupings is possible.

Examples:

- 11: Axis is a synchronized axis in a gantry grouping 1
- 2: Axis is a leading axis in gantry a grouping 2
- 12: Axis is a synchronized axis in a gantry grouping 2
- 3: Axis is a leading axis in a gantry grouping 3
- 13: Axis is a synchronized axis in a gantry grouping 3

Special cases:

Alarm 10650 "Incorrect gantry machine data" and 10651 "Gantry unit not defined" in the case of an incorrect gantry axis definition.

Related to:

- MD37110 \$MA_GANTRY_POS_TOL_WARNING (gantry warning limit)
- MD37120 \$MA_GANTRY_POS_TOL_ERROR (gantry trip limit)
- MD37130 \$MA_GANTRY_POS_TOL_REF (gantry trip limit during referencing)

37110	GANTRY_POS_TOL_WARNING			A05, A10	G1,Z3	
mm, degrees	Gantry warning limit			DOUBLE	Reset	
-						
-	-	0.0	-1e15	1e15	2/2	M

Description:

Value > 0

With gantry axes, the difference between the position actual values of the leading and synchronized axes is constantly monitored.

MD37110 \$MA_GANTRY_POS_TOL_WARNING is used to define a limit value for the position actual value difference; when the limit is exceeded, warning 10652 "Warning limit exceeded" is output. However, the gantry axes are not stopped internally in the control. The warning threshold must therefore be selected so that the machine can withstand the position actual value deviation between the gantry axes without sustaining mechanical damage.

Furthermore, the NC/PLC interface signal <Gantry-Warngrenze_ueberschritten/> (Gantry warning limit exceeded) to the PLC is set to "1". The PLC user program can thus initiate the necessary measures (e.g. program interruption at block end) when the warning limit is exceeded.

As soon as the current position actual value difference has dropped below the warning limit again, the message is canceled and the interface signal "Gantry warning limit exceeded" is reset.

Effect of the gantry warning limit on the gantry synchronization process: The position actual value difference between the leading and synchronized axes is determined during gantry synchronization. If the deviation is less than the gantry warning limit, the synchronizing motion of the gantry axes is automatically started internally in the control.

Otherwise the synchronizing motion has to be initiated via the PLC interface (interface signal <Gantry-Synchronisationslauf_starten/> (Start gantry synchronization process))

Value = 0

The setting MD37110 \$MA_GANTRY_POS_TOL_WARNING = 0 deactivates the monitoring for violation of the warning limit.

The gantry synchronization is not initiated internally in the control.

Special cases:

Alarm 10652 "Warning limit exceeded" in response to violation of the gantry warning limit.

Related to:

MD37100 \$MA_GANTRY_AXIS_TYPE Gantry axis definition

MD37120 \$MA_GANTRY_POS_TOL_ERROR Gantry trip limit

MD37130 \$MA_GANTRY_POS_TOL_REF

Gantry trip limit during referencing

NC/PLC interface signal <Gantry-Warngrenze_ueberschritten/> (Gantry warning limit exceeded)

NC/PLC interface signal <Gantry-Synchronisationslauf_starten/> (Start gantry synchronization process)

37120	GANTRY_POS_TOL_ERROR			A05, A10	G1,Z3	
mm, degrees	Gantry trip limit			DOUBLE	PowerOn	
-						
-	-	0.0	-1e15	1e15	2/2	M

Description:

With gantry axes, the difference between the position actual values of the leading and synchronized axes is continuously monitored. MD37120 \$MA_GANTRY_POS_TOL_ERROR defines the maximum permissible deviation in position actual value between the synchronized axis and the leading axis in the gantry axis grouping. Violation of this limit value is monitored only if the gantry axis grouping is already synchronized (NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> (Gantry grouping is synchronized) = 1); otherwise the value set in MD37130 \$MA_GANTRY_POS_TOL_REF is used.

When this limit value is exceeded, alarm 10653 "Error limit exceeded" is output. The gantry axes are immediately stopped internally in the control to prevent any damage to the machine.

In addition, the NC/PLC interface signal <Gantry-Abschaltgrenze_ueberschritten/> (Gantry trip limit exceeded) to the PLC is set to "1".

Special cases:

Alarm 10653 "Error limit exceeded" in response to violation of the gantry trip limit.

Related to:

MD37100 \$MA_GANTRY_AXIS_TYPE Gantry axis definition

MD37110 \$MA_GANTRY_POS_TOL_WARNING Gantry warning limit

MD37130 \$MA_GANTRY_POS_TOL_REF

Gantry trip limit during referencing

NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> (Gantry grouping is synchronized)

NC/PLC interface signal <Gantry-Abschaltgrenze_ueberschritten/> (Gantry trip limit exceeded)

2.4 Axis-specific machine data

37130	GANTRY_POS_TOL_REF			A05, A10	G1,Z3	
mm, degrees	Gantry trip limit during referencing			DOUBLE	PowerOn	
-						
-	-	0.0	-1e15	1e15	2/2	M

Description:

With gantry axes, the difference between the position actual values of the leading and synchronized axes is continuously monitored. MD37130 \$MA_GANTRY_POS_TOL_REF defines the maximum permissible difference between the position actual values of the synchronized axis and the leading axis that is monitored if the gantry axis grouping has not yet been synchronized (NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> (Gantry grouping is synchronized) = 0).

Alarm 10653 "Error limit exceeded" is output if the limit value is exceeded. The gantry axes are immediately stopped internally in the control to prevent any damage to the machine.

In addition, the NC/PLC interface signal <Gantry-Abschaltgrenze_ueberschritten/> (Gantry trip limit exceeded) to the PLC is set to "1".

Special cases:

Alarm 10653 "Error limit exceeded" in response to violation of the gantry trip limit.

Related to:

MD37100 \$MA_GANTRY_AXIS_TYPE Gantry axis definition

MD37110 \$MA_GANTRY_POS_TOL_WARNING Gantry warning limit

MD37120 \$MA_GANTRY_POS_TOL_ERROR Gantry trip limit

NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> (Gantry grouping is synchronized)

NC/PLC interface signal <Gantry-Abschaltgrenze_ueberschritten/> (Gantry trip limit exceeded)

37135	GANTRY_ACT_POS_TOL_ERROR			A05, A10	-	
mm, degrees	Current gantry trip limit			DOUBLE	Reset	
-						
-	-	0.0	-	-	2/2	M

Description:

Actual value difference between master axis and slave axis in the case of alarm 10653.

Leads to alarm 10657 after Power ON.

37140	GANTRY_BREAK_UP			EXP, A01, A10	G1,Z3	
-	Invalidate gantry axis grouping			BOOLEAN	Reset	
CTEQ						
-	-	FALSE	-	-	2/2	M

Description:

GANTRY_BREAK_UP = "0"

The forced coupling of the gantry axis grouping remains valid! Monitoring of violation of the gantry warning or trip limit is active!

GANTRY_BREAK_UP = "1"

This breaks up the forced coupling of the gantry grouping, thus allowing all gantry axes in this grouping to be traversed individually in JOG, AUTOMATIC, and MDI modes. Monitoring for violation of the gantry warning or trip limit is deactivated! The NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> "gantry grouping is synchronized" is set to "0".

Notice:

In cases where the gantry axes continue to be mechanically coupled, the machine may sustain damage in this operating state when the leading or synchronized axis is traversed!

The gantry axes cannot be referenced individually.

Corresponds with:

MD 37100: \$MA_GANTRY_AXIS_TYPE Gantry axis definition

MD 37110: \$MA_GANTRY_POS_TOL_WARNING Gantry warning limit

MD 37130: \$MA_GANTRY_POS_TOL_REF

Gantry trip limit during referencing

NC/PLC interface signal <Gantry-Verbund_ist_synchronisiert/> (gantry grouping is synchronized)

NC/PLC interface signal <Gantry-Abschaltgrenze_ueberschritten/> (gantry trip limit exceeded)

37150	GANTRY_FUNCTION_MASK			A10	-	
-	Gantry functions			DWORD	Reset	
-						
-	-	0x00	0	0x7	2/2	M

Description:

Special gantry functions are set with this MD.

The MD is bit-coded, the following bits are assigned:

Bit 0 == 0:

Extended monitoring of the actual value difference is inactive.

An offset between master and slave axes occurring in tracking or BREAK_UP is not taken into account in the monitoring of the actual value difference.

Alarm 10657 is not output if alarm 10563 occurs before Power OFF.

Bit 0 = 1:

Extended monitoring of the actual value difference is active.

An offset between master and slave axes occurring in tracking or BREAK_UP is taken into account in the monitoring of the actual value difference.

Prerequisite: The gantry grouping must be rereferenced or resynchronized after control startup.

Alarm 10657 is output if alarm 10563 occurs before Power OFF.

Bit 1 = 0:

Zero mark search direction of the slave axis analogous to MD 34010

Bit 1 = 1:

Zero mark search direction of the slave axis same as for master axis

Bit 2 = 0 :

Alarm 10655 "Synchronization in progress" is output

Bit 2 = 1

Alarm 10655 "Synchronization in progress" is not output

2.4 Axis-specific machine data

37200	COUPLE_POS_TOL_COARSE			A05, A10	M3,S3,2,4,6,2	
mm, degrees	Threshold value for 'Synchronism coarse'			DOUBLE	NEW CONF	
-						
828d-me41	-	1.0	0.0	1.0e15	0/0	S
828d-me61	-	1.0	0.0	1.0e15	0/0	S
828d-me81	-	1.0	0.0	1.0e15	0/0	S
828d-te61	-	1.0	0.0	1.0e15	2/2	M
828d-te81	-	1.0	0.0	1.0e15	2/2	M
828d-te41	-	1.0	0.0	1.0e15	2/2	M

Description:

In synchronous mode, the positional difference between the leading and following axis(axis)/spindle(s) is monitored (only DV and AV mode or cmdpos and actpos in the case of CP programming).

The NC/PLC interface signal <Synchronlauf_grob/> (synchronism coarse) is set if the current positional difference is within the tolerance band specified by the threshold value.

Furthermore, this threshold value can be used to define the criterion for block change on activation of synchronous mode or on modification of the speed ratio parameters when the coupling is active in cases where "synchronism coarse" is selected as the block change response condition (see channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1 or language instruction COUPDEF, WAITC, CPBC).

Entering a value of "0" always sets the NC/PLC interface signal <Synchronlauf_grob/> "synchronism coarse" to "1" in DV/AV mode or with cmd/actpos.

Corresponds with:

Channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1
(block change response in synchronous mode)

NC/PLC interface signal <Synchronlauf_grob/> (synchronism coarse)

37202	COUPLE_POS_TOL_COARSE_2			A05, A10	-	
mm, degrees	Second threshold value for 'synchronism monitoring coarse'			DOUBLE	NEW CONF	
-						
828d-me41	-	2.0	0.0	1.0e15	0/0	S
828d-me61	-	2.0	0.0	1.0e15	0/0	S
828d-me81	-	2.0	0.0	1.0e15	0/0	S
828d-te61	-	2.0	0.0	1.0e15	2/2	M
828d-te81	-	2.0	0.0	1.0e15	2/2	M
828d-te41	-	2.0	0.0	1.0e15	2/2	M

Description:

Generic coupling - second synchronism monitoring of the synchronism difference on the actual value side in the case of positional couplings - coarse threshold value.

Entering a value of "0" deactivates monitoring.

Entering a value other than "0" starts synchronism monitoring (2) once 'synchronism coarse' has been reached:

The VDI interface signal DB31., DBX103.5 "synchronism 2 coarse" indicates whether the synchronism difference on the actual value side violates the threshold value.

If the threshold value is violated, this is indicated by show alarm 22026, which can be canceled.

Corresponds with:

MD37200 \$MA_COUPLE_POS_TOL_COARSE

VDI interface signal DB31..., DBX98.1 'synchronism coarse'

37210	COUPLE_POS_TOL_FINE			A05, A10	M3,S3,2,4	
mm, degrees	Threshold value for 'Synchronism fine'			DOUBLE	NEW CONF	
-						
828d-me41	-	0.5	0.0	1.0e15	0/0	S
828d-me61	-	0.5	0.0	1.0e15	0/0	S
828d-me81	-	0.5	0.0	1.0e15	0/0	S
828d-te61	-	0.5	0.0	1.0e15	2/2	M
828d-te81	-	0.5	0.0	1.0e15	2/2	M
828d-te41	-	0.5	0.0	1.0e15	2/2	M

Description: In synchronous mode, the positional difference between the leading and following axis(axis)/spindle(s) is monitored (only DV and AV mode or cmdpos and actpos in the case of CP programming).

The NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine) is set if the current positional difference is within the tolerance band specified by the threshold value.

Furthermore, this threshold value can be used to define the criterion for block change on selection of synchronous mode or on modification of the speed ratio parameters when the coupling is active in cases where "synchronism fine" is selected as the block change response condition (see channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1 or language instruction COUP-DEF, WAITC, CPBC).

Entering a value of "0" always sets the NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine) to "1" in DV/AV mode or with cmd/actpos.

Corresponds with:

Channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1

(block change response in synchronous mode)

NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine)

37212	COUPLE_POS_TOL_FINE_2			A05, A10	-	
mm, degrees	Second threshold value for 'synchronism monitoring fine'			DOUBLE	NEW CONF	
-						
828d-me41	-	1.0	0.0	1.0e15	0/0	S
828d-me61	-	1.0	0.0	1.0e15	0/0	S
828d-me81	-	1.0	0.0	1.0e15	0/0	S
828d-te61	-	1.0	0.0	1.0e15	2/2	M
828d-te81	-	1.0	0.0	1.0e15	2/2	M
828d-te41	-	1.0	0.0	1.0e15	2/2	M

Description: Generic coupling - second synchronism monitoring of the synchronism difference on the actual value side in the case of positional couplings - fine threshold value.

Entering a value of "0" deactivates monitoring.

2.4 Axis-specific machine data

Entering a value other than "0" starts synchronism monitoring (2) once 'synchronism fine' has been reached:

The VDI interface signal DB31.., DBX103.4 "synchronism 2 fine" indicates whether the synchronism difference on the actual value side violates the threshold value.

If the threshold value is violated, this is indicated by show alarm 22025, which can be canceled.

Corresponds with:

MD37210 \$MA_COUPLE_POS_TOL_FINE

VDI interface signal DB31.., DBX98.0 'synchronism coarse'

37220	COUPLE_VELO_TOL_COARSE			A05, A10	S3	
mm/min, rev/min	Velocity tolerance 'coarse'			DOUBLE	NEW CONF	
-						
828d-me41	-	60.0	-	-	0/0	S
828d-me61	-	60.0	-	-	0/0	S
828d-me81	-	60.0	-	-	0/0	S
828d-te61	-	60.0	-	-	2/2	M
828d-te81	-	60.0	-	-	2/2	M
828d-te41	-	60.0	-	-	0/0	S

Description:

In synchronous mode, the velocity difference between the leading and following axis(axis)/spindle(s) is monitored (only VV mode or cmdvel in the case of CP programming).

The NC/PLC interface signal <Synchronlauf_grob/> (synchronism coarse) is set if the current velocity difference is within the tolerance band specified by the threshold value.

Furthermore, this threshold value can be used to define the criterion for block change on activation of synchronous mode or on modification of the speed ratio parameters when the coupling is active in cases where "synchronism coarse" is selected as the block change response condition (see channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1 or language instruction COUPDEF, WAITC, CPBC).

Entering a value of "0" always sets the NC/PLC interface signal <Synchronlauf_grob/> (synchronism coarse) to "1" in VV mode or with cmdvel.

Corresponds with:

Channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1

(block change response in synchronous mode)

NC/PLC interface signal <Synchronlauf_grob/> (synchronism coarse)

37230	COUPLE_VELO_TOL_FINE		A05, A10	S3
mm/min, rev/min	Velocity tolerance 'fine'		DOUBLE	NEW CONF
-				
828d-me41	-	30.0	-	0/0 S
828d-me61	-	30.0	-	0/0 S
828d-me81	-	30.0	-	0/0 S
828d-te61	-	30.0	-	2/2 M
828d-te81	-	30.0	-	2/2 M
828d-te41	-	30.0	-	0/0 S

Description: In synchronous mode, the velocity difference between the leading and following axis(axis)/spindle(s) is monitored (only VV mode or cmdvel in the case of CP programming).

The NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine) is set if the current velocity difference is within the tolerance band specified by the threshold value.

Furthermore, this threshold value can be used to define the criterion for block change on activation of synchronous mode or on modification of the speed ratio parameters when the coupling is active in cases where "synchronism fine" is selected as the block change response condition (see channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1 or language instruction COUPDEF, WAITC, CPBC).

Entering a value of "0" always sets the NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine) to "1" in VV mode or with cmdvel.

Corresponds with:

Channel-specific MD21320 \$MC_COUPLE_BLOCK_CHANGE_CTRL_1
(block change response in synchronous mode)
NC/PLC interface signal <Synchronlauf_fein/> (synchronism fine)

37240	COUP_SYNC_DELAY_TIME		A05, A10	-
s	Delay time actual value synchronism		DOUBLE	NEW CONF
-				
828d-me41	2	60, 30	-	0/0 S
828d-me61	2	60, 30	-	0/0 S
828d-me81	2	60, 30	-	0/0 S
828d-te61	2	60, 30	-	2/2 M
828d-te81	2	60, 30	-	2/2 M
828d-te41	2	60, 30	-	2/2 M

Description: Synchronous spindle coupling: delay time - monitors the time taken to reach actual value synchronism after reaching setpoint synchronism.

\$MA_COUP_SYNC_DELAY_TIME[0]: time to reach 'Synchronism fine'

\$MA_COUP_SYNC_DELAY_TIME[1]: time to reach 'Synchronism coarse'

If the value "0" is entered, the relevant monitoring is inactive

Related to:

MD 37200 \$MA_COUPLE_POS_TOL_COARSE
MD 37210 \$MA_COUPLE_POS_TOL_FINE
MD 37220 \$MA_COUPLE_VELO_TOL_COARSE
MD 37230 \$MA_COUPLE_VELO_TOL_FINE

37250	MS_ASSIGN_MASTER_SPEED_CMD			A10	TE3	
-	Master axis for speed setpoint coupling			DWORD	PowerOn	
-						
828d-me41	-	0	0	5	2/2	M
828d-me61	-	0	0	6	2/2	M
828d-me81	-	0	0	6	2/2	M
828d-te61	-	0	0	6	2/2	M
828d-te81	-	0	0	8	2/2	M
828d-te41	-	0	0	5	2/2	M

Description: A master/slave speed setpoint linkage is configured by indicating the machine axis number of the master axis belonging to this slave.

Related to:

MD37252 \$MA_MS_ASSIGN_MASTER_TORQUE_CTR

37252	MS_ASSIGN_MASTER_TORQUE_CTR			A10	TE3	
-	Master axis number for torque control			DWORD	PowerOn	
-						
828d-me41	-	0	0	5	2/2	M
828d-me61	-	0	0	6	2/2	M
828d-me81	-	0	0	6	2/2	M
828d-te61	-	0	0	6	2/2	M
828d-te81	-	0	0	8	2/2	M
828d-te41	-	0	0	5	2/2	M

Description: Torque distribution between master and slave axes is configured by stating the machine axis number of the master axis belonging to the slave. Homogenous torque distribution is achieved by using the torque compensatory controller.

In order to do this, the controller has to know the torque actual values of the drives involved (with PROFIdrive, the message frame used must include and transfer these values, e.g. use message frame 116)

With default setting = 0, the same master axis is used for torque control as for speed setpoint coupling MD37250 \$MA_MS_ASSIGN_MASTER_SPEED_CMD.

Related to:

MD37250 \$MA_MS_ASSIGN_MASTER_SPEED_CMD

MD37254 \$MA_MS_TORQUE_CTRL_MODE

MD37256 \$MA_MS_TORQUE_CTRL_P_GAIN

MD37258 \$MA_MS_TORQUE_CTRL_I_TIME

MD37268 \$MA_MS_TORQUE_WEIGHT_SLAVE

37253	MS_FUNCTION_MASK			A10	TE3	
-	Master/slave settings			DWORD	NEW CONF	
-						
-	-	0x0	-	-	2/2	M

Description: Parameterizing a master/slave coupling

Bit 0 = 0:

The scaling of MD37256 \$MA_MS_TORQUE_CTRL_P_GAIN, MD37260

\$MA_MS_MAX_CTRL_VELO is smaller than described in the documentation by the factor 1s/IPO cycle.

Bit 0 = 1:

The scaling of MD37256 \$MA_MS_TORQUE_CTRL_P_GAIN, MD37260 \$MA_MS_MAX_CTRL_VELO corresponds to the documentation.

Bit 1 = 0:

With MASLDEF, the master axis for torque compensation control is the programmed axis

Bit 1 = 1:

With MASLDEF, the master axis for torque compensation control is the axis configured in MD37252.

37254	MS_TORQUE_CTRL_MODE	A10	TE3			
-	Torque compensatory controller interconnection	DWORD	Immediately			
-						
-	-	0	0	3	2/2	M

Description: The output of the torque compensatory controller is connected to

- 0: Master and slave axis
- 1: Slave axis
- 2: Master axis
- 3: No axis

when the torque control is active.

Related to:

MD37252 \$MA_MS_ASSIGN_MASTER_TORQUE_CTR
 MD37250 \$MA_MS_ASSIGN_MASTER_SPEED_CMD
 MD37254 \$MA_MS_TORQUE_CTRL_MODE

37255	MS_TORQUE_CTRL_ACTIVATION	A10	TE3			
-	Torque compensatory controller activation	BYTE	NEW CONF			
-						
-	-	0	0	1	2/2	M

Description: The torque compensatory controller can be switched ON and OFF by means of MD37254 \$MA_MS_TORQUE_CTRL_MODE or via the NC/PLC interface signal DB380x DBX5000.4 (torque compensatory controller on).

In order to do this, the controller has to know the torque actual values of the drives involved (with PROFIdrive, the message frame used must include and transfer these values, e.g. use message frame 116).

In the case of the PLC, MD37254 \$MA_MS_TORQUE_CTRL_MODE is only used for configuring the interconnection of the torque compensatory controller.

0: Switch ON/OFF via MD37254

1: Switch ON/OFF via the NC/PLC interface signal DB380x DBX5000.4 (torque compensatory controller on)

37256	MS_TORQUE_CTRL_P_GAIN	A10	TE3			
%	Torque compensatory controller gain factor	DOUBLE	NEW CONF			
-						
-	-	0.0	0.0	100.0	2/2	M

Description: Gain factor of the torque compensatory controller

The gain factor is entered in percent as the ratio of the maximum axis velocity of the slave axis on the load side to the rated torque.

The maximum axis velocity is derived from MD32000 \$MA_MAX_AX_VELO, the rated torque from the product of drive machine data MD1725.

2.4 Axis-specific machine data

Related to:

- MD37254 \$MA_MS_TORQUE_CTRL_MODE
- MD37258 \$MA_MS_TORQUE_CTRL_I_TIME
- MD32000 \$MA_MAX_AX_VELO

37258	MS_TORQUE_CTRL_I_TIME	A10	TE3
s	Torque compensatory controller integral action time	DOUBLE	NEW CONF
-			
-	-	0.0	0.0
-	-	100.0	2/2 M

Description: Integral time of the torque compensatory controller
 The integral time does not become active until the P gain factor is greater than 0.

Related to:

- MD37254 \$MA_MS_TORQUE_CTRL_MODE
- MD37256 \$MA_MS_TORQUE_CTRL_P_GAIN
- MD32000 \$MA_MAX_AX_VELO

37260	MS_MAX_CTRL_VELO	A10	TE3
%	Torque compensatory controller limit	DOUBLE	NEW CONF
-			
-	-	100.0	0.0
-	-	100.0	2/2 M

Description: Torque compensatory controller limitation
 The speed setpoint value calculated by the torque compensatory controller is limited.

The limit that can be entered as a percentage refers to MD32000 \$MA_MAX_AX_VELO of the slave axis.

Related to:

- MD37254 \$MA_MS_TORQUE_CTRL_MODE
- MD37256 \$MA_MS_TORQUE_CTRL_P_GAIN
- MD37258 \$MA_MS_TORQUE_CTRL_I_TIME
- MD32000 \$MA_MAX_AX_VELO

37262	MS_COUPLING_ALWAYS_ACTIVE	A10	TE3
-	Permanent master/slave link	BYTE	NEW CONF
-			
-	-	0	0
-	-	1	2/2 M

Description: Activation behavior of a master/slave coupling
 0: Temporary coupling
 The coupling is activated/deactivated via PLC interface signals and language commands.

1: Permanent coupling
 This machine data activates the permanent coupling.
 PLC interface signals and language commands do not have any effect.

Related to:

- MD37252 \$MA_MS_ASSIGN_MASTER_TORQUE_CTR
- MD37250 \$MA_MS_ASSIGN_MASTER_SPEED_CMD

37263	MS_SPIND_COUPLING_MODE			A10	TE3	
-	Link response of a spindle			BYTE	NEW CONF	
-						
-	-	0	0	1	2/2	M

Description: Link behavior of a speed-controlled spindle:
0: Link is closed/released in standstill only.
1: Link is closed/released already during motion.
The configuration is valid both for activation/deactivation via DB3x.DBX24.5 and for MASLON, MASLOF, MASLOFs, MASLDEL

37264	MS_TENSION_TORQUE			A10	TE3	
%	Master-slave tension torque			DOUBLE	Immediately	
-						
-	-	0.0	-100.0	100.0	2/2	M

Description: A constant tension torque between the master and the slave axis can be entered as a percentage of the rated drive torque of the slave axis. Use of a tension torque requires an active torque compensatory controller (compare MD37255 \$MA_MS_TORQUE_CTRL_ACTIVATION).
Related to:
MD37252 \$MA_MS_ASSIGN_MASTER_TORQUE_CTR
MD37266 \$MA_MS_TENSION_TORQ_FILTER_TIME
MD37255 \$MA_MS_TORQUE_CTRL_ACTIVATION

37266	MS_TENSION_TORQ_FILTER_TIME			A10	TE3	
s	Filter time constant tension torque			DOUBLE	NEW CONF	
-						
-	-	0.0	0.0	100.0	2/2	M

Description: The tension torque between the master and slave axes can be activated via a PT1 filter. Any change of MD37264 \$MA_MS_TENSION_TORQUE is then travelled out with the time constant of the filter.
As default, the filter is inactive; any torque change becomes active unfiltered.
Related to:
MD37264 \$MA_MS_TENSION_TORQUE

37268	MS_TORQUE_WEIGHT_SLAVE			A10	TE3	
%	Torque weighting of slave axis			DOUBLE	NEW CONF	
-						
-	-	50.0	1.0	100.0	2/2	M

Description: The torque share that the slave axis contributes to the total torque can be configured via the weighting. This enables different torque shares to be implemented between the master and slave axes.
In the case of motors with the same rated torque, a 50% to 50% torque sharing is suggested.
The torque share of the master axis results implicitly from 100% - MD37268.
Related to:
MD37252 \$MA_MS_ASSIGN_MASTER_TORQUE_CTR
MD37266 \$MA_MS_TENSION_TORQ_FILTER_TIME

2.4 Axis-specific machine data

37270	MS_VELO_TOL_COARSE	A10	TE3,Z3
%	Master/slave speed tolerance coarse	DOUBLE	NEW CONF
-			
-	-	5.0	- - - 2/2 M

Description: Tolerance window, coarse, for the differential speed between the master and the slave.

If the speed difference is within the tolerance window, the NC/PLC interface signal <Master-Slave_Ausgleichr_aktiv/> (Master-Slave compensatory controller active) is set.

The tolerance value is entered as a percentage of MD32000 \$MA_MAX_AX_VELO.

37272	MS_VELO_TOL_FINE	A10	TE3,Z3
%	Master/slave speed tolerance fine	DOUBLE	NEW CONF
-			
-	-	1.0	- - - 2/2 M

Description: Tolerance window, fine, for the differential speed between the master and the slave.

If the speed difference is within the tolerance window, the NC/PLC interface signal <Master-Slave_grob/> (Master/Slave coarse) is set.

The tolerance value is entered as a percentage of MD32000 \$MA_MAX_AX_VELO.

37274	MS_MOTION_DIR_REVERSE	A10	-
-	Inverting traversing direction slave axis	BYTE	NEW CONF
-			
-	-	0	0 1 2/2 M

Description: Inverting the traversing direction of a slave axis in the linked status.

0: Equidirectional to the master axis

1: Inverse to the master axis

37500	ESR_REACTION	EXP, A01, A10,	M3,P2
-	Axial mode of "Extended Stop and Retract"	BYTE	NEW CONF
CTEQ			
-	-	0	0 22 2/2 M

Description: Selection of the response to be triggered via system variable "\$AN_ESR_TRIGGER".

0 = No response Reaktion (or only external response through synchronized action programming of rapid digital outputs).

21 = NC-controlled retraction axis

22 = NC-controlled stopping axis

37510	AX_ESR_DELAY_TIME1	EXP, A01, A10,	P2
s	Delay time ESR single axis	DOUBLE	NEW CONF
CTEQ			
-	-	0.0	- - - 2/2 M

Description: If, for example, an alarm occurs, the deceleration time can be delayed by means of this MD, e.g. to allow in case of gear hobbing the retraction from the tooth gap first.

37511	AX_ESR_DELAY_TIME2	EXP, A01, A10,	P2
s	ESR time for interpolatory deceleration of single axis	DOUBLE	NEW CONF
CTEQ			
-	-	0.0	-
-	-	-	2/2
-	-	-	M

Description: The time for interpolatory braking specified here in MD37511 \$MA_AX_ESR_DELAY_TIME2 still remains after expiry of the time MD37510 \$MA_AX_ESR_DELAY_TIME1.
Rapid braking with subsequent tracking is initiated after expiry of the time MD37511 \$MA_AX_ESR_DELAY_TIME2.

37610	PROFIBUS_CTRL_CONFIG	EXP, A01	-
-	PROFIdrive control bit configuration	BYTE	PowerOn
-			
-	-	0	0
-	-	2	2/2
-	-	-	M

Description: For PROFIdrive only:
Machine data for setting special PROFIdrive control word functionality:
0 =
default = no change of standard behavior
1 =
STW2, bits 0-1 are set depending on mode of operation/rapid traverse suppressing the setting of defaults for the VDI control bits "Parameter set bit0/1" from the PLC.
Bits 0-1 get the following combinations depending on the mode of operation, and controlled by NCK:
00 = Default (after Power-On)
01 = JOG (except for JOG-INC) or ((AUTOMATIC or MDI) and G0)
10 = ((AUTOMATIC or MDI) and not G0), other
11 = JOG-INC
2 =
Combination of MD=0 (preset by VDI) and MD=1 (internally preset):
MD=2 acts as MD=1, as long as there are no VDI control bits from the PLC, i.e. if the VDI control bits "Parameter set bit0/1" are both reset (0).
MD=2 acts as MD=0, if the VDI control bits "Parameter set bit0/1" are set both or individually (!=0). In this case, the VDI control bits are transferred directly to the drive (priority of VDI signals higher than that of internally created signals).

37620	PROFIBUS_TORQUE_RED_RESOL	EXP, A01	-
%	Resolution PROFIdrive torque reduction	DOUBLE	NEW CONF
-			
-	-	1.0	0.005
-	-	10.0	2/2
-	-	-	M

Description: For PROFIdrive only:
Resolution of torque reduction on the PROFIdrive (LSB significance)
The MD is only relevant for controls with PROFIdrive drives. For these controls, it defines the resolution of the cyclic interface data "Torque reduction value" (only exists for MD13060 \$MN_DRIVE_TELEGRAM_TYPE = 101 ff. or 201 ff.), which is required for the "Travel to fixed stop" functionality.

2.4 Axis-specific machine data

The 1% default value corresponds to the original significance. The torque limit is transferred on the PROFIdrive with increments of 1%; the value 100 in the corresponding PROFIdrive message frame data cell corresponds to full torque reduction (i.e. without force).

By changing this MD to 0.005%, for example, the value can be entered in increments of 0.005%, i.e. the increments for the torque limit value become finer by a factor of 200.

For limitation to the rated torque, the value 0 is transmitted in this case; complete torque reduction (i.e. without force) characterizes the transmittable value 10000.

To avoid misadaptation, the setting value of the MD must be selected to match the interpretation configured on the drive side or the firmly defined interpretation of the torque reduction value. If the setting of the control on the drive (manufacturer-specific drive parameter) is known (i.e. with SIEMENS drives), the software automatically sets the MD; in other words, in this case the MD is merely used for display purposes.

37800	OEM_AXIS_INFO	A01, A11	-
-	OEM version information	STRING	PowerOn
-			
-	2	,	-
			2/2 M

Description: A version information freely available to the user (is indicated in the version screen)

38000	MM_ENC_COMP_MAX_POINTS	A01, A09, A02	K3
-	Number of intermediate points for interpol. compensation (SRAM)	DWORD	PowerOn
-			
-	2	200, 200	0 5000 1/0 M

Description: The number of interpolation points required per measuring system must be defined for the leadscrew error compensation.

The required number can be calculated as follows using the defined parameters:

$$MD38000 \$MA_MM_ENC_COMP_MAX_POINTS = \frac{\$AA_ENC_COMP_MAX - \$AA_ENC_COMP_MIN}{\$AA_ENC_COMP_STEP} + 1$$

- $\$AA_ENC_COMP_MIN$ Initial position (system variable)
- $\$AA_ENC_COMP_MAX$ End position (system variable)
- $\$AA_ENC_COMP_STEP$ Distance between interpolation points (system variable)

When selecting the number of interpolation points and/or the distances between them, it is important to take into account the size of the resulting compensation table and the space required in the buffered NC user memory (SRAM). 8 bytes are required for each compensation value (interpolation point).

The index [n] has the following coding: [encoder no.]: 0 or 1

Special cases:

Notice:

After any change in MD38000 \$MA_MM_ENC_COMP_MAX_POINTS, the buffered NC user memory is automatically re-allocated on system power-on.

All data in the buffered NC user memory are then lost (e.g. part programs, tool offsets etc.). Alarm 6020 "Machine data changed - memory reallocated" is output.

If reallocation of the NC user memory fails because the total memory capacity available is insufficient, alarm 6000 "Memory allocation made with standard machine data" is output.

In this case, the NC user memory division is allocated using the default values of the standard machine data.

References:

/FB/, S7, "Memory Configuration"

/DA/, "Diagnostics Guide"

Related to:

MD32700 \$MA_ENC_COMP_ENABLE[n]LEC active

References:

/FB/, S7, "Memory Configuration"

NC setting data

Number	Identifier			Display filters	Reference	
Unit	Name			Data type	Active	
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

41010	JOG_VAR_INCR_SIZE			-	H1	
-	Size of the variable increment for JOG			DOUBLE	Immediately	
-						
-	-	0.	-	-	7/7	U

Description: This setting data defines the number of increments when variable increment (INCvar) is selected. This increment size is traversed by the axis in JOG mode each time the traverse key is pressed or the handwheel is turned one detent position and variable increment is selected (PLC interface signal "Active machine function: INC variable" for machine or geometry axes is set to 1). The defined increment size also applies to DRF.

Note:

Please note that the increment size is active for incremental jogging and handwheel jogging. So, if a large increment value is entered and the handwheel is turned, the axis might cover a large distance (depends on setting in MD31090 \$MA_JOG_INCR_WEIGHT).

SD irrelevant to

JOG continuous

Related to

NC/PLC interface signal DB3300 DBX1001.5,1005.5,1009.5 (Geometry axis 1-3 active machine function: INC variable) or NC/PLC interface signal DB390x DBX5.5 (Active machine function: INC variable)

MD31090 \$MA_JOG_INCR_WEIGHT (weighting of an increment for INC/handwheel)

41050	JOG_CONT_MODE_LEVELTRIGGRD			-	H1	
-	Jog mode / continuous operation with continuous JOG			BOOLEAN	Immediately	
-						
-	-	TRUE	-	-	2/2	U

Description: 1: Jog mode for JOG continuous
In jog mode (default setting) the axis traverses as long as the traverse key is held down and an axis limitation has not been reached. When the key is released the axis is decelerated to zero speed and the movement is considered complete.

0: Continuous operation for JOG continuous

In continuous operation the traverse movement is started with the first rising edge of the traverse key and continues to move even after the key is released. The axis can be stopped again by pressing the traverse key again (second rising edge).

SD irrelevant for

Incremental jogging (JOG INC)

Reference point approach (JOG REF)

41100	JOG_REV_IS_ACTIVE	-	-
-	JOG mode: revolutionary feedrate / linear feedrate	BYTE	Immediately
-			
-	-	0x0E	-
			1/1
			U

Description:

Bit 0 = 0:

The behavior depends on the following:

- in the case of an axis/spindle:
on the axial SD43300 \$SA_ASSIGN_FEED_PER_REV_SOURCE
- in the case of a geometry axis with an active frame with rotation:
on the channel-specific SD42600 \$SC_JOG_FEED_PER_REV_SOURCE
- in the case of an orientation axis:
on the channel-specific SD42600 \$SC_JOG_FEED_PER_REV_SOURCE

Bit 0 = 1:

A JOG motion with revolutionary feedrate shall be traversed depending on the master spindle.

The following must be considered:

- If a spindle is the master spindle itself, it will be traversed without revolutionary feedrate.
- If the master spindle is in stop position and if SD43300 \$SA_ASSIGN_FEED_PER_REV_SOURCE (with an axis/spindle) or SD42600 \$SC_JOG_FEED_PER_REV_SOURCE (with a geometry axis with an active frame with rotation, or with an orientation axis) = -3, traversing will be carried out without revolutionary feedrate.

Bit 1 = 0:

The axis/spindle, geometry axis or orientation axis will be traversed with revolutionary feedrate even during rapid traverse (see bit 0 for selection).

Bit 1 = 1:

The axis/spindle, geometry axis or orientation axis is always traversed without revolutionary feedback during rapid traverse.

Bit 2 = 0:

The axis/spindle, geometry axis or orientation axis is traversed with revolutionary feedrate during JOG handwheel travel, too (see bit 0 for selection).

Bit 2 = 1:

The axis/spindle, geometry axis or orientation axis is always traversed without revolutionary feedrate during JOG handwheel travel.

Bit 3 = 0:

The axis/spindle is traversed with revolutionary feedrate during DRF handwheel travel, too (see bit 0 for selection).

Bit 3 = 1:

The axis/spindle is always traversed without revolutionary feedrate during DRF handwheel travel.

41110	JOG_SET_VELO	-	H1
mm/min	Axis velocity in JOG	DOUBLE	Immediately
-			
-	-	0.0	-
			7/7 U

Description:

Value not equal to 0:

The velocity value entered applies to linear axes traversed in JOG mode if linear feedrate (G94) is active for the relevant axis (SD41100 \$SN_JOG_REV_IS_ACTIVE = 0).

The axis velocity is active for

- continuous jogging
- incremental jogging (INC1, ... INCvar)
- handwheel traversing.

The value entered is valid for all linear axes and must not exceed the maximum permissible axis velocity (MD32000 \$MA_MAX_AX_VELO).

In the case of DRF, the velocity defined by SD41110 \$SN_JOG_SET_VELO is reduced by

MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR.

Value = 0:

If 0 has been entered in the setting data, the active linear feedrate in JOG mode is

MD32020 \$MA_JOG_VELO "Jog axis velocity". Each axis can be given its own JOG velocity with this MD (axial MD).

SD irrelevant for

- Linear axes if SD41100 \$SN_JOG_REV_IS_ACTIVE = 1
- Rotary axes (SD41130 \$SN_JOG_ROT_AX_SET_VELO is active here)

Application example(s)

The operator can thus define a JOG velocity for a specific application.

Related to

SD41100 \$SN_JOG_REV_IS_ACTIVE (revolutional feedrate with JOG active)

Axial MD32020 \$MA_JOG_VELO (JOG axis velocity)

Axial MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)

Axial MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR (ratio of JOG velocity to handwheel velocity (DRF))

SD41130 \$SN_JOG_ROT_AX_SET_VELO (JOG speed with rotary axes)

41120	JOG_REV_SET_VELO	-	H1
mm/rev	Revolutional feedrate of axes in JOG mode	DOUBLE	Immediately
-			
828d-me41	-	0.0	- - - 1/1 M
828d-me61	-	0.0	- - - 1/1 M
828d-me81	-	0.0	- - - 1/1 M
828d-te61	-	0.0	- - - 7/7 M
828d-te81	-	0.0	- - - 7/7 M
828d-te41	-	0.0	- - - 7/7 M

Description:

Value not equal to 0:

The velocity value entered applies to axes traversed in JOG mode if revolutional feedrate (G95) is active for the relevant axis (SD41100 \$SN_JOG_REV_IS_ACTIVE = 1). The axis velocity is active for

- continuous jogging
- incremental jogging (INCl, ... INCvar)
- handwheel traversing. The value entered is valid for all axes and must not exceed the maximum permissible axis velocity (MD32000 \$MA_MAX_AX_VELO).

Value = 0:

If 0 has been entered in the setting data, the active revolutional feedrate in JOG mode is MD32050 \$MA_JOG_REV_VELO "revolutional feedrate with JOG". Each axis can be given its own revolutional feedrate with this MD (axial MD). SD irrelevant for

- For axes if SD41100 \$SN_JOG_REV_IS_ACTIVE = 0

Application example(s)

The operator can define a JOG velocity for a particular application.

Related to

- Axial SD41100 \$SN_JOG_REV_IS_ACTIVE (revolutional feedrate for JOG active)
- Axial MD32050 \$MA_JOG_REV_VELO (revolutional feedrate with JOG)
- Axial MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)

41130	JOG_ROT_AX_SET_VELO	-	H1
rev/min	Axis velocity for rotary axes in JOG mode	DOUBLE	Immediately
-			
-	-	0.0	- - - 7/7 U

Description:

Value not equal to 0:

The velocity entered applies to rotary axes in JOG mode (to continuous jogging, incremental jogging, jogging with handwheel). The value entered is common to all rotary axes, and must not exceed the maximum permissible axis velocity (MD32000 \$MA_MAX_AX_VELO).

With DRF, the velocity set with SD41130 \$SN_JOG_ROT_AX_SET_VELO must be reduced by MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR.

Value equal to 0:

If the value 0 is entered in the setting data, the velocity applied to rotary axes in JOG mode is the axial MD32020 \$MA_JOG_VELO (jog axis velocity). In this way, it is possible to define a separate JOG velocity for each axis.

Application example(s)

The operator can define a JOG velocity for a particular application.

Related to

MD32020 \$MA_JOG_VELO (JOG axis velocity)

MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)

MD32090 \$MA_HANDWH_VELO_OVERLAY_FACTOR (ratio JOG velocity to handwheel velocity (DRF))

41200	JOG_SPIND_SET_VELO	-	H1
rev/min	Speed for spindle JOG mode	DOUBLE	Immediately
-			
-	0.0	-	7/7 U

Description:

Value not equal to 0:

The speed entered applies to spindles in JOG mode if they are traversed manually by the "Plus and minus traversing keys" or the handwheel. The speed is active for

- continuous jogging
- incremental jogging (INC1, ... INCvar)
- handwheel traversing. The value entered is valid for all spindles, and must not exceed the maximum permissible speed (MD32000 \$MA_MAX_AX_VELO).

Value = 0:

If 0 has been entered in the setting data, MD32020 \$MA_JOG_VELO (JOG axis velocity) acts as the JOG velocity. Each axis can thus be given its own JOG velocity with this MD (axial MD).

The maximum speeds of the active gear stage (MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT) are taken into account when traversing the spindle with JOG.

SD irrelevant for

Application example(s). The operator can thus define a JOG speed for the spindles for a specific application.

Related to

Axial MD32020 \$MA_JOG_VELO (JOG axis velocity)

MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speeds of the gear stages)

41300	CEC_TABLE_ENABLE	-	K3
-	Compensation table enable	BOOLEAN	Immediately
-			
-	62	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	1/1 U

Description:

1: The evaluation of the compensation table [t] is enabled.

The compensation table is now included in the calculation of the compensation value for the compensation axis.

The compensation axis \$AN_CEC_OUTPUT_AXIS can be taken from the table configuration.

The effective total compensation value in the compensation axis can be adapted to the current machining by the targeted activation of tables (from NC part programm or PLC user program).

The function does not become active until the following conditions have been fulfilled:

- The option "Interpolatory compensation" is set
- The associated compensation tables in the NC user memory have been loaded and enabled (SD41300 \$SN_CEC_TABLE_ENABLE[t] = 1)
- The current position measuring system is referenced (NC/PLC interface signal DB390x DBX0.4 / .5 (Referenced/synchronized 1 or 2) = 1).

0: The evaluation of the sag compensation table [t] is not enabled.

Related to

MD18342 \$MN_MM_CEC_MAX_POINTS[t] Number of interpolation points with sag compensation
 SD41300 \$SN_CEC_TABLE_ENABLE[t] Evaluation of the sag compensation table t is enabled
 NC/PLC interface signal DB390x DBX0.4 (Referenced/synchronized 1)
 NC/PLC interface signal DB390x DBX0.5 (Referenced/synchronized 2)

41310	CEC_TABLE_WEIGHT		-	K3	
-	Weighting factor compensation table		DOUBLE	Immediately	
-					
-	62	1.0,1.0,1.0,1.0,1.0,1.0, 1.0,1.0,1.0...	-	-	1/1 U

Description: The compensation value stored in the table [t] is multiplied by the weighting factor.

When selecting the weighting factor it should be ensured that the total compensation value in the compensation axis does not exceed the maximal value of (MD18342 \$MN_CEC_MAX_SUM). With [t] = index of the compensation table (see MD18342 \$MN_MM_CEC_MAX_POINTS)

If, for example, the weight of the tools used on the machine or the workpieces to be machined are too different and this affects the error curve by changing the amplitude, this can be corrected by changing the weighting factor. In the case of sag compensation, the weighting factor in the table can be changed for specific tools or workpieces from the PLC user program or the NC program by overwriting the setting data. However, different compensation tables are to be used if the course of the error curve is substantially changed by the different weights.

Related to

SD41300 \$SN_CEC_TABLE_ENABLE[t] Evaluation of the sag compensation table t is enabled
 MD18342 \$MN_CEC_MAX_SUM Maximum compensation value for sag compensation

42000	THREAD_START_ANGLE		-	K1	
degrees	Starting angle for thread		DOUBLE	Immediately	
-					
-	-	0.,0.,0.,0.,0.,0.,0.,0., 0.,0.,0.,0....	-	-	7/7 U

Description: In the case of multiple thread cutting, the offset of the individual threads can be programmed with the aid of this setting data.
 This SD can be changed by the part program with the command SF.

Note:

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB can be set so that the value written by the part program is transferred to the active file system on reset (that is the value is retained after reset.)

42010	THREAD_RAMP_DISP			-	V1	
mm	Acceleration behavior of axis when thread cutting			DOUBLE	Immediately	
-						
-	2	-1., -1., -1., -1., -1., -1., -1., -1., -1....	-1.	999999.	7/7	U

Description:

The SD is active for thread cutting with G33 (G34, G35).

It features two elements that define the behavior of the thread axis during runup (1st element) and during deceleration/smoothing (2nd element).

The values have the same properties for thread run-in and thread run-out:

<0:

The thread axis is started/decelerated with configured acceleration. Jerk is according to the current programming of BRISK/SOFT. Behavior is compatible with MD 20650 __THREAD_START_IS_HARD = FALSE used until now.

0:

Starting/deceleration of the feed axis during thread cutting is stepped. Behavior is compatible with MD 20650 __THREAD_START_IS_HARD = TRUE used until now.

>0:

The maximum thread starting or deceleration path is specified. The specified distance can lead to acceleration overload of the axis. The SD is written from the block when DITR (displacement thread ramp) is programmed.

Note:

MD 10710 \$MN_PROG_SD_RESET_SAVE_TAB can be set so that the value written by the part program is transferred to the active file system on reset (that is the value is retained after reset.)

42100	DRY_RUN_FEED			-	V1	
mm/min	Dry run feedrate			DOUBLE	Immediately	
-						
-	-	5000.,5000.,5000.,5000.,5000.,5000.,5000....	-	-	7/7	U

Description:

The feedrate for the active dry run is entered in this setting data. The setting data can be altered on the operator panel in the "Parameters" operating area.

The entered dry run feedrate is always interpreted as a linear feed (G94). If the dry run feedrate is activated via the PLC interface, the dry run feedrate is used as the path feed after a reset instead of the programmed feed. The programmed velocity is used for traversing if it is greater than the velocity stored here.

Application example(s)

Program testing

Related to

NC/PLC interface signal DB3200 DBX0.6 (Activate dry run feedrate)

NC/PLC interface signal DB1700 DBX0.6 (Dry run feedrate selected)

42101	DRY_RUN_FEED_MODE	-	V1
-	Mode for dry run velocity	BYTE	Immediately
-			
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	12 7/7 U

Description: This SD can be used to set the method of operation of the dry run velocity set by SD42100 \$SC_DRY_RUN_FEED.
 The following values are possible:

0:
 The maximum of SD42100 \$SC_DRY_RUN_FEED and the programmed velocity become active. This is the standard setting and corresponds to the behavior up to SW 5.

1:
 The minimum of SD42100 \$SC_DRY_RUN_FEED and the programmed velocity become active.

2:
 SD42100 \$SC_DRY_RUN_FEED becomes active directly, irrespective of the programmed velocity.

The values 3...9 are reserved for extensions.

10:
 As configuration 0, except for thread cutting (G33, G34, G35) and tapping (G331, G332, G63). These functions are executed as programmed.

11:
 As configuration 1, except for thread cutting (G33, G34, G35) and tapping (G331, G332, G63). These functions are executed as programmed.

12:
 As configuration 2, except for thread cutting (G33, G34, G35) and tapping (G331, G332, G63). These functions are executed as programmed.

42110	DEFAULT_FEED	-	V1,FBFA
mm/min	Path feed default value	DOUBLE	Immediately
-			
-	-	0.,0.,0.,0.,0.,0.,0.,0.,0., - 0.,0.,0.,0....	7/7 U

Description: Default value for path feedrate, This setting data is evaluated when the part program starts taking into account the feedrate type active at this time (see MD20150 \$MC_GCODE_RESET_VALUES and MD20154 \$MC_EXTERN_GCODE_RESET_VALUES).

42120	APPROACH_FEED	-	-
mm/min	Path feedrate in approach blocks	DOUBLE	Immediately
-			
-	-	0.,0.,0.,0.,0.,0.,0.,0.,0., - 0.,0.,0.,0....	7/7 U

Description: Default value for path feedrate in approach blocks (after repos., block search, SERUPRO etc).
 The contents of this setting data are only used when it is non-zero.
 It is evaluated like an F word programmed for G94.

42200	SINGLEBLOCK2_STOPRE		-	BA		
-	Activate SBL2 debug mode		BOOLEAN	Immediately		
-						
-	-	FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	-	7/7	U

Description: Value = TRUE:
 A preprocessing stop is made with every block if SBL2 (single block with stop after every block) is active. This suppresses the premachining of part program blocks. This variant of the SBL2 is not true-to-contour. This means that a different contour characteristic might be generated as a result of the preprocessing stop than without single block or with SBL1.
 Application: Debug mode for testing part programs.

42300	COUPLE_RATIO_1		-	-		
-	Speed ratio for synchr. spindle mode, numerator, denominator		DOUBLE	Immediately		
-						
828d-me41	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	0/0	S
828d-me61	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	0/0	S
828d-me81	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	0/0	S
828d-te61	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	2/2	M
828d-te81	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	2/2	M
828d-te41	2	1.0, 1.0,1.0, 1.0,1.0, 1.0,1.0, 1.0...	-1.0e8	1.0e8	0/0	S

Description: This setting data defines the speed ratio parameters for the fixed coupling configuration defined with the channel-specific MD21300 \$MC_COUPLE_AXIS_1[n].
 -
 $k_{\ddot{U}}$ = Speed ratio parameter of numerator / Speed ratio parameter of denominator
 = \$SC_COUPLE_RATIO[0] / \$SC_COUPLE_RATIO[1]
 The speed ratio parameters can be altered in the NC part program with the language instruction COUPDEF provided that this is not locked by the channel-specific MD21340 \$MC_COUPLE_IS_WRITE_PROT_1.
 However, the parameterized values of SD42300 \$SC_COUPLE_RATIO_1 are not changed.
 The calculation of $k_{\ddot{U}}$ is initiated with POWER ON.
 SD irrelevant for
 User-defined coupling
 Related to
 SD42300 \$SC_COUPLE_RATIO_1 currently has the same action as a machine data (e.g. active after POWER ON). The SD data are therefore displayed and input in the same way as channel-specific machine data.

42440	FRAME_OFFSET_INCR_PROG	-	K1,K2
-	Work offsets in frames	BOOLEAN	Immediately
-			
-	-	FALSE	- - 3/3 U

Description:

0: When incremental programming is used on an axis, only the programmed position delta is traversed after a frame change. Zero offsets in FRAMES are only traversed when an absolute position is specified.

1: When incremental programming is used on an axis, changes to zero offsets are traversed after a frame change (standard response up to software version 3).

Related to

SD42442 \$SC_TOOL_OFFSET_INCR_PROG

42442	TOOL_OFFSET_INCR_PROG	-	W1,K1
-	Tool length compensations	BOOLEAN	Immediately
-			
-	-	FALSE	- - 3/3 U

Description:

0: When incremental programming is used on an axis, only the programmed position delta is traversed after a frame change. Tool length offsets in FRAMES are only traversed when an absolute position is specified.

1: When incremental programming is used on an axis, changes to tool length offsets are traversed after a tool change (standard response up to SW version 3).

Related to

SD42440 \$SC_FRAME_OFFSET_INCR_PROG

42444	TARGET_BLOCK_INCR_PROG	-	BA
-	Set down mode after search run with calculation	BOOLEAN	Immediately
-			
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	- - 2/2 U

Description:

If the first programming of an axis after "Search run with calculation to end of block" is incremental, the incremental value is added as a function of SD42444 \$SC_TARGET_BLOCK_INCR_PROG to the value accumulated up to the search target :

SD = TRUE: Incremental value is added to accumulated position

SD = FALSE: Incremental value is added to current actual value

The setting data is evaluated on NC start for output of the action blocks.

42450	CONTPREC	-	B1,K6
mm	Contour accuracy	DOUBLE	Immediately
-			
-	-	0.1,0.1,0.1,0.1,0.1,0.1,0.1, 0.1,0.1,0.1...	0.000001 999999. 7/7 U

Description: Contour accuracy. This setting data can be used to define the accuracy to be maintained for the path of the geometry axes on curved contours. The lower the value and the lower the servogain factor of the geometry axes, the greater the reduction of path feed on curved contours.
 Related to
 MD20470 \$MC_CPREC_WITH_FFW
 SD42460 \$SC_MINFEED

42460	MINFEED	-	B1,K6
mm/min	Minimum path feedrate for CPRECON	DOUBLE	Immediately
-			
-	-	1.,1.,1.,1.,1.,1.,1.,1.,1., 1.,1.,1.,1....	0.000001 999999. 7/7 U

Description: Minimum path feedrate with the "Contour accuracy" function active. The feedrate is not limited to below this value unless a lower F value has been programmed or the axis dynamics do not permit it.
 Related to
 MD20470 \$MC_CPREC_WITH_FFW
 SD42450 \$SC_CONTPREC

42465	SMOOTH_CONTUR_TOL	-	B1
mm	maximum contour tolerance on smoothing	DOUBLE	Immediately
-			
-	-	0.05,0.05,0.05,0.05,0. 05,0.05,0.05...	0.000001 999999. 7/7 U

Description: This setting data defines the maximum tolerance for smoothing the contour.
 Related to:
 MD20480 \$MC_SMOOTHING_MODE,
 SD42466 \$SC_SMOOTH_ORI_TOL

42466	SMOOTH_ORI_TOL		-	B1		
degrees	Maximum deviation of tool orientation during smoothing.		DOUBLE	Immediately		
-						
828d-me41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-me61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-me81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-te61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S
828d-te81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S
828d-te41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S

Description: This setting data defines the maximum tool orientation tolerance during smoothing.

The data determines the maximum permissible angular displacement of the tool orientation.

This data only applies if an orientation transformation is active.

Related to:

MD20480 \$MC_SMOOTHING_MODE,
SD42465 \$SC_SMOOTH_CONTUR_TOL

42470	CRIT_SPLINE_ANGLE		-	W1,PGA		
degrees	Corner limit angle for compressor		DOUBLE	Immediately		
-						
828d-me41	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	7/7	M
828d-me61	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	7/7	M
828d-me81	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	7/7	M
828d-te61	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	0/0	S
828d-te81	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	0/0	S
828d-te41	-	36.0,36.0,36.0,36.0,36.0,36.0,36.0,36.0...	0.0	89.0	0/0	S

Description: The setting data defines the limit angle from which the compressor COMPCAD interprets a block transition as a corner. Practical values lie between 10 and 40 degrees. Values from 0 to 89 degrees inclusive are permitted.

The angle only serves as an approximate measure for corner detection. The compressor can also classify flatter block transitions as corners and eliminate larger angles as outliers on account of plausibility considerations.

42471	MIN_CURV_RADIUS			EXP, C09	-	
mm	Minimum radius of curvature			DOUBLE	Immediately	
-						
-	-	1.0	-	-	2/2	U

Description: The setting data defines a typical tool radius. It is only evaluated in compressor COMPCAD. The lower the value, the greater the precision, but the slower the program execution.

42475	COMPRESS_CONTUR_TOL			-	F2,PGA	
mm	maximum contour deviation with compressor			DOUBLE	Immediately	
-						
828d-me41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	7/7	M
828d-me61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	7/7	M
828d-me81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	7/7	M
828d-te61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	0/0	S
828d-te81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	0/0	S
828d-te41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	999999.	0/0	S

Description: This setting data defines the maximum contour tolerance in the compressor.

42477	COMPRESS_ORI_ROT_TOL			-	F2,PGA	
degrees	Maximum deviation of tool rotation with compressor			DOUBLE	Immediately	
-						
828d-me41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-me61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-me81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	7/7	M
828d-te61	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S
828d-te81	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S
828d-te41	-	0.05,0.05,0.05,0.05,0.05,0.05,0.05...	0.000001	90.	0/0	S

Description: This setting data defines the maximum tolerance in the compressor for turning the tool orientation. This data defines the maximum permissible angular displacement of the tool rotation.
 This data is only active if an orientation transformation is active.
 Turning the tool orientation is only possible with 6-axis machines.

42480	STOP_CUTCOM_STOPRE	-	W1
-	Alarm response with tool radius compensation and preproc. stop	BOOLEAN	Immediately
-			
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	7/7 U

Description: If this setting data is TRUE, block execution is stopped by preprocessing stop and active tool radius compensation, and does not resume until after a user acknowledgement (START).
If it is FALSE, machining is not interrupted at such a program point.

42490	CUTCOM_G40_STOPRE	-	W1
-	Retraction behavior of tool radius compensation with prep. stop	BOOLEAN	Immediately
-			
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	7/7 U

Description: FALSE:
If there is a preprocessing stop (either programmed or generated internally by the control) before the deselection block (G40) when tool radius compensation is active, then firstly the starting point of the deselection block is approached from the last end point before the preprocessing stop. The deselection block itself is then executed, i.e. the deselection block is usually replaced by two traversing blocks. Tool radius compensation is no longer active in these blocks. The behavior is thus identical with that before the introduction of this setting data.

TRUE:
If there is a preprocessing stop (either programmed or generated internally by the control) before the deselection block (G40) when tool radius compensation is active, the end point of the deselection point is traversed in a straight line from the last end point before the preprocessing stop.

42494	CUTCOM_ACT_DEACT_CTRL	-	W1
-	Approach & retraction behavior with 2-1/2D tool radius compens.	DWORD	Immediately
-			
-	-	2222,2222,2222,2222, 2222,2222,2222...	-
			7/7 U

Description:

This setting data controls the approach and retraction behavior with tool radius compensation if the activation or deactivation block does not contain any traversing information. It is only evaluated with 2-1/2D TRC (CUT2D or CUT2DF).

The decimal coding is as follows:

N N N N

```

| | | | ____ Approach behavior for tools with tool point direction
| | | | (turning tools)
| | | | ____ Approach behavior for tools without tool point direction
| | | | (milling tools)
| | | | ____ Retract behavior for tools with tool point direction
| | | | (turning tools)
| | | | ____ Retract behavior for tools without tool point direction
| | | | (milling tools)
    
```

If the position in question contains a 1, approach or retraction is always performed, even if G41/G42 or G40 stands alone in a block.

For example:

```

N100 x10 y0
N110 G41
N120 x20
    
```

If a tool radius of 10mm is assumed in the above example, position x10y10 is approached in block N110.

If the position in question contains the value 2, the approach or retraction movement is only performed if at least one geometry axis is programmed in the activation/deactivation block. To obtain the same results as the above example with this setting, the program must be altered as follows:

```

N100 x10 y0
N110 G41 x10
N120 x20
    
```

If axis information x10 is missing in block N110, activation of TRC is delayed by one block, i.e. the activation block would now be N120.

If the position in question contains a 3, retraction is not performed in a deactivation block (G40) if only the geometry axis perpendicular to the compensation plane is programmed. In this case, the motion perpendicular to the compensation plane is performed first. This is followed by the retraction motion in the compensation plane. In this case, the block after G40 must contain motion information in the compensation plane. The approach motions for values 2 and 3 are identical.

If the position in question contains a value other than 1, 2 or 3, i.e. in particular the value 0, an approach or retraction movement is not performed in a block that does not contain any traversing information.

About the term "Tools with tool point direction":

These are tools with tool numbers between 400 and 599 (turning and grinding tools), whose tool point direction has a value between 1 and 8. Turning and grinding tools with tool point direction 0 or 9 or other undefined values are treated like milling tools.

Note:

If the value of this setting data is changed within a program, we recommend programming a preprocessing step (stopre) before the description to avoid the new value being used in program sections before that point. The opposite case is not serious, i.e. if the setting data is written, subsequent NC blocks will definitely access the new value.

42496	CUTCOM_CLSD_CONT	-	-			
-	Tool radius compensation behavior with closed contour	BOOLEAN	Immediately			
-						
-		FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...			7/7	U

Description:

FALSE:

If two intersections are created on correction of the inner side of an (almost) closed contour consisting of two successive circle blocks or a circle and a linear block, the intersection that lies on the first part contour nearer to the block end will be selected as per the default behavior.

A contour will be considered as (almost) closed if the distance between the starting point of the first block and the end point of the second block is smaller than 10% of the active compensation radius, but not larger than 1000 path increments (corresponds to 1mm to 3 decimal places).

TRUE:

Under the same condition as described above, the intersection that lies on the first part contour nearer to block start is selected.

42500	SD_MAX_PATH_ACCEL	-	B2			
m/s ²	maximum path acceleration	DOUBLE	Immediately			
-						
-		10000.,10000.,10000.,10000.,10000.,10000....	1.0e-3		7/7	U

Description:

Setting data for additional limitation of (tangential) path acceleration
Related to ...

MD32300 \$MA_MAX_AX_ACCEL
SD42502 \$SC_IS_SD_MAX_PATH_ACCEL

42502	IS_SD_MAX_PATH_ACCEL	-	B2			
-	Evaluate SD42500 SC_SD_MAX_PATH_ACCEL	BOOLEAN	Immediately			
-						
-		FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...			7/7	U

Description:

SD42500 \$SC_SD_MAX_PATH_ACCEL is included in the limit calculations if SD42502 \$SC_IS_SD_MAX_PATH_ACCEL=TRUE

Related to ...

SD42500 \$SC_SD_MAX_PATH_ACCEL

42526	CORNER_SLOWDOWN_CRIT			-	-	
degrees	Corner detection at G62			DOUBLE	Immediately	
-	-			-	-	
-	-	0.,0.,0.,0.,0.,0.,0.,0.,0.,	-	-	7/7	U
-	-	0.,0.,0.,0....	-	-	-	-

Description: Angle from which a corner is taken into account when reducing the feed with G62.

For example SD42526 \$\$S_CORNER_SLOWDOWN_CRIT = 90 means that all corners of 90 degrees or a more acute angle are traversed slower with G62.

42528	CUTCOM_DECEL_LIMIT			-	-	
-	Feed lowering on circles with tool radius compensation			DOUBLE	Immediately	
-	-			-	-	
-	-	0.1	0.	1.	3/3	U

Description: The setting data limits feed lowering of the tool center point on concave circle segments with tool radius compensation active and CFC or CFIN selected.

With CFC, the feed is defined at the contour. On concave circular arcs, feed lowering of the tool center point is created by the ratio of the contour curvature to the tool center point path curvature. The setting data is limiting this effect, reducing backing off and overheating of the tool.

For contours with varying curvatures, a mid-range curvature is used.

0: Provides the previous behavior: If the ratio between contour radius and tool center point path radius is less than or equal to 0.01 the feed is applied to the tool center point path. Less pronounced feed reductions are executed.

>0: Feed lowering is limited to the programmed factor. At 0.01, this means that the feed of the tool center point path is possibly only 1 percent of the programmed feed value.

1: On concave contours, the tool center point feed equals the programmed feed (the behavior then corresponds to CFTCP).

42600	JOG_FEED_PER_REV_SOURCE			-	V1	
-	Control revolutional feedrate in JOG			DWORD	Immediately	
-	-			-	-	
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	1/1	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	1/1	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	1/1	M
828d-te61	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	7/7	M
828d-te81	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	7/7	M
828d-te41	-	0,0,0,0,0,0,0,0,0,0,0,	-3	31	7/7	M
-	-	0,0,0,0	-	-	-	-

Description: The revolutional feedrate in JOG mode for geometry axes on which a frame with rotation acts.

0= No revolutional feedrate is active.

>0= Machine axis index of the rotary axis/spindle from which the revolutional feedrate is derived.

- 1= The revolutional feedrate is derived from the master spindle of the channel in which the axis/spindle is active.
- 2= The revolutional feedrate is derived from the axis with machine axis index == 0.
- 3= The revolutional feedrate is derived from the master spindle of the channel in which the axis/spindle is active. No revolutional feedrate is active if the master spindle is at a standstill.

Related to

SD43300: \$SA_ASSIGN_FEED_PER_REV_SOURCE (revolutional feedrate for position axes/spindles)

42700	EXT_PROG_PATH	-	K1
-	Program path for external subroutine call EXTCALL	STRING	Immediately
-			
-	-	-	7/7 U

Description: The total path results from the string chaining of SD42700 \$SC_EXT_PROG_PATH + the programmed subprogram identifier.

42750	ABSBLOCK_ENABLE	-	K1
-	Enable base block display	BOOLEAN	Immediately
-			
-	-	TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE,TRUE...	7/7 U

Description: Value 0: Disable basic blocks with absolute values (basic block display)
Value 1: Enable basic blocks with absolute values (basic block display)

42800	SPIND_ASSIGN_TAB	-	S1
-	Spindle number converter.	BYTE	Immediately
-			
-	21	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17...	0 21 7/7 U

Description: The spindle converter converts the programmed (= logical) spindle number to the physical (= internal, configured) spindle number.
The index of the setting data (SD) corresponds to the programmed spindle number or the programmed address extension.
The SD contains the physical spindle which actually exists.
Special cases, errors,

Notes:

- The zero index (SPIND_ASSIGN_TAB[0]) is only used to display the master spindle selected in the channel and must not be overwritten.
- Changes to the spindle converter take effect immediately. It is therefore not advisable to change the spindle converter for spindles used in a part program from the HMI or PLC while a part program is running.
- After "delete SRAM", the numbers of the logical and physical spindles are identical.

42900	MIRROR_TOOL_LENGTH	-	W1
-	Sign change of tool length with mirror image machining	BOOLEAN	Immediately
-			
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	7/7 U

Description:

TRUE:

If a frame with mirror image machining is active, the tool components (\$TC_DP3[... , ...] to \$TC_DP5[... , ...]) and the components of the base dimensions (\$TC_DP21[... , ...] to \$TC_DP23[... , ...]) whose associated axes are mirrored, are also mirrored, i.e. their sign is inverted. The wear values are not mirrored. If the wear values are to be mirrored too, SD42910 \$SSC_MIRROR_TOOL_WEAR must be set.

FALSE:

The sign for tool length components is unaffected by whether a frame with mirror image machining is active.

42910	MIRROR_TOOL_WEAR	-	W1
-	Sign change of tool wear with mirror image machining	BOOLEAN	Immediately
-			
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	7/7 U

Description:

TRUE:

If a frame with mirror image machining is activated, the signs of the wear values of the components in question are inverted. The wear values of the components that are not assigned to mirrored axes remain unchanged.

FALSE:

The signs for wear values are unaffected by whether a frame with mirror image machining is active.

42920	WEAR_SIGN_CUTPOS	-	W1
-	Sign of tool wear depending on tool point direction	BOOLEAN	Immediately
-			
-	-	FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE,FALSE...	7/7 U

Description:

TRUE:

In the case of tools with a relevant tool point direction (turning and grinding tools), the sign for wear of the tool length components depends on the tool point direction.

Bit 1 = TRUE: Do not apply transformations to \$TC_SCPx3 - \$TC_SCPx5.
 Bit 2 = TRUE: Do not apply transformations to \$TC_ECPx3 - \$TC_ECPx5.
 The bits not mentioned here are (currently) not assigned.

42940	TOOL_LENGTH_CONST			-	W1	
-	Change of tool length components with change of active plane			DWORD	Immediately	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-te61	-	18	-	-	2/2	M
828d-te81	-	18	-	-	2/2	M
828d-te41	-	18	-	-	2/2	M

Description: If this setting data is not equal to 0, the assignment of tool length components (length, wear, base dimensions) to geometry axes is not changed when the machining plane (G17 - G19) is changed.

The assignment of tool length components to geometry axes can be derived from the value of the setting data acc. to the following tables.

A distinction is made between turning and grinding tools (tool types 400 to 599) and other tools (typically milling tools) in the assignment.

Representation of this information in tables assumes that geometry axes 1 to 3 are called X, Y and Z. For assignment of an offset to an axis, not the axis identifier but the axis sequence is relevant.

Assignment for turning tools and grinding tools (tool types 400 to 599):

Content	Length 1	Length 2	Length 3
17	Y	X	Z
18*	X	Z	Y
19	Z	Y	X
-17	X	Y	Z
-18	Z	X	Y
-19	Y	Z	X

* Any value which is not 0 and is not one of the six values listed, is treated as value 18.

For values that are the same but with a different sign, assignment of length 3 is always the same, lengths 1 and 2 are reversed. Assignment for all tools which are neither turning nor grinding tools (tool types < 400 or > 599):

Content	Length 1	Length 2	Length 3
17*	Z	Y	X
18	Y	X	Z
19	X	Z	Y
-17	Z	X	Y
-18	Y	Z	X
-19	X	Y	Z

* Any value which is not 0 and is not one of the six values listed, is treated as value 17.

For values that are the same but with a different sign, assignment of length 1 is always the same, lengths 2 and 3 are reversed.

42950	TOOL_LENGTH_TYPE			-	W1	
-	Assignment of tool length compensation independent of tool type			DWORD	Immediately	
-						
828d-me41	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me61	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-me81	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	-	-	2/2	M
828d-te61	-	2	-	-	2/2	M
828d-te81	-	2	-	-	2/2	M
828d-te41	-	2	-	-	2/2	M

Description: This setting data defines the assignment of the tool length components to the geometry axes independently of the tool type. It can assume any value between 0 and 2. Any other value is interpreted as 0.

Value

0: Standard assignment. A distinction is made between turning and grinding tools (tool types 400 to 599) and other tools (milling tools).

1: The assignment of the tool length components is independent of the actual tool type, always as for milling tools.

2: The assignment of the tool length components is independent of the actual tool type, always as for turning tools.

The setting data also affects the wear values assigned to the length components.

If SD42940 \$SC_TOOL_LENGTH_CONST is set, the tables defined there access the table for milling and turning tools defined by SD42950 \$SC_TOOL_LENGTH_TYPE irrespective of the actual tool type, if the value of the table is not equal to 0.

42960	TOOL_TEMP_COMP			-	W1	
-	Temperature compensation for tool			DOUBLE	Immediately	
-						
-	3	0.0, 0.0, 0.0,0.0, 0.0, 0.0...	-	-	7/7	U

Description: Temperature compensation value for the tool. The compensation value acts as vector according to the current rotation of the tool direction.

This setting data will only be evaluated, if temperature compensation has been activated for tools with MD20390 \$MC_TOOL_TEMP_COMP_ON.

Apart from that, the temperature compensation type must be set in bit 2 for the "Compensation in tool direction" MD32750 \$MA_TEP_COMP_TYPE.

The "Temperature compensation" is an option that has to be previously enabled.

42970	TOFF_LIMIT		-	F2
mm	Upper limit of correction value via \$AA_TOFF		DOUBLE	Immediately
-				
-	3	10000000.0, 10000000.0, 10000000.0...	-	7/7 U

Description: Upper limit of the offset value which can be defined by means of synchronized actions via the \$AA_TOFF system variable.
This limit value influences the absolutely effective amount of offset through \$AA_TOFF.
Whether the offset value is within the limit range can be checked via the \$AA_TOFF_LIMIT system variable.

42974	TOCARR_FINE_CORRECTION		C08	-
-	Fine offset TCARR ON / OFF		BOOLEAN	Immediately
-				
-	-	FALSE,FALSE,FALS E,FALSE,FALSE,FAL SE...	-	7/7 U

Description: TRUE:
On activating an orientable tool holder, the fine offset values are considered.
FALSE:
On activating an orientable tool holder, the fine offset are not considered.

42980	TOFRAME_MODE		-	K2
-	Frame definition at TOFRAME, TOROT and PAROT		DWORD	Immediately
-				
-	-	2000	-	2/2 U

Description: This setting data defines the direction of the geometry axes on the machining plane (XY in the case of G17) in the case of the frame definition by means of (TOROTY, TOROTX) or for PAROT.
When a frame is calculated, the tool direction (Z in the case of G17) is uniquely defined so that the tool direction and vertical axis (Z in the case of G17) of the frame are parallel and lie perpendicular on the machining plane.
Rotation around the tool axis is free at first. This free rotation can be defined using this setting data so that the newly defined frame deviates as little as possible from a previously active frame.
In all cases in which the setting data is not zero, an active frame remains unchanged if the tool direction (Z in the case of G17) of the old and the new frame are the same.
SD42980 >= 2000:
In the case of TOROT (or TOROTY and TOROTX), the rotations and translations of the frame chain are used to calculate a frame in the tool reference system frame (\$P_TOOLFRAME) berechnet.
Machine data 21110 \$MC_X_AXIS_IN_OLD_X_Z_PLANE is not evaluated.
The explanatory notes below refer to the G17 plane with the XY axes in the machining plane and the tool axis being Z.

SD42980 = 2000:

Rotation around the Z axis is selected so that the angle between the new X axis and the old X-Z plane has the same absolute value as the angle between the new Y axis and the old Y-Z plane. This setting corresponds to the mean value of both settings which would result for values 2001 and 2002 of this setting data.

It is also applied if the value of the units digit is greater than 2.

SD42980 = 2001:

The new X direction is selected so that it lies in the X-Z plane of the old coordinate system. The angular difference between the old and new Y axes is minimal with this setting.

SD42980 = 2002:

The new Y direction is selected so that it lies in the Y-Z plane of the old coordinate system. The angular difference between the old and new X axes is minimal with this setting.

None of the other settings of SD42980 (0,1,2,...1000,1001..) should be used for recommissioning.

For compatibility reasons, the following settings remain valid:

0: The orientation of the coordinate system is determined by the value of machine data 21110 \$MC_X_AXIS_IN_OLD_X_Z_PLANE.

1: The new X direction is selected so that it lies in the X-Z plane of the old coordinate system. The angular difference between the old and new Y axes is minimal with this setting.

2: The new Y direction is selected so that it lies in the Y-Z plane of the old coordinate system. The angular difference between the old and new X axes is minimal with this setting.

3: The average of the two settings resulting from 1 and 2 is selected.

Addition of 100: In the case of a plane change from G17 to G18 or G19, a tool matrix is generated, in which the new axis directions are parallel to the old directions. The axes are swapped cyclically accordingly (standard transformation on plane changes). If the hundreds digit equals zero, a matrix is supplied in the cases of G18 and G19 which is derived from the unit matrix by simply rotating through 90 degrees around the X axis (G18) or through 90 degrees around the Y axis (G19). Thus in each case one axis is antiparallel to an initial axis. This setting is required to remain compatible with old software versions.

Addition of 1000: The tool-frame is linked to any active basic frames and settable frames. The response is thus compatible with earlier software versions (before 5.3). If the thousands digit is not set, the tool frame is calculated so that any active basic frames and settable frames are taken into account.

42996	JOG_GEOAX_MODE_MASK	-	-			
-	JOG of geometry axis mode	DWORD	Immediately			
-						
-	-	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0	0	0x7	2/2	U

Description: This setting data sets the following during JOG of geometry axes:
 Bit 0 = 1 :
 A traversing request for the 1st geometry axis is inverted, i.e. a traversing request to + triggers a traversing motion to - .
 Bit 1 = 1 :
 A traversing request for the 2nd geometry axis is inverted, i.e. a traversing request to + triggers a traversing motion to - .
 Bit 2 = 1:
 A traversing request for the 3rd geometry axis is inverted, i.e. a traversing request to + triggers a traversing motion to - .

43120	DEFAULT_SCALE_FACTOR_AXIS	-	FBFA			
-	Axial default scaling factor with G51 active	DWORD	Immediately			
-						
-	-	1	-	-	7/7	U

Description: If no axial scaling factor I, J, or K is programmed in the G51 block, SD43120 \$SA_DEFAULT_SCALE_FACTOR_AXIS is active. The scaling factor is only active if MD22914 \$MC_AXES_SCALE_ENABLE is set.
 Related to:
 MD22914 \$MC_AXES_SCALE_ENABLE,
 MD22910 \$MC_WEIGHTING_FACTOR_FOR_SCALE

43200	SPIND_S	-	S1			
rev/min	Speed for spindle start by VDI	DOUBLE	Immediately			
-						
-	-	0.0	-	-	7/7	U

Description: Spindle speed at spindle start by NC/PLC interface signals DB380x DBX5006.1 (Spindle start clockwise rotation) and DB380x DBX5006.2 (Spindle start counterclockwise rotation).
 Example: \$SA_SPIND_S[S1] = 600
 Spindle 1 is started at a speed of 600 rpm upon detection of the positive edge of one of the above-mentioned VDI starting signals.
 Speed programming values are entered in the SD by setting bit 4=1 in MD35035 \$MA_SPIND_FUNCTION_MASK.
 The SD becomes active in JOG mode as a default speed by setting bit 5=1 in MD35035 \$MA_SPIND_FUNCTION_MASK (exception: the value is zero).
 Related to:
 MD35035 \$MA_SPIND_FUNCTION_MASK
 MD10709 \$MN_PROG_SD_POWERON_INIT_TAB
 MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43202	SPIND_CONSTCUT_S	-	S1
m/min	Const cut speed for spindle start by VDI	DOUBLE	Immediately
-			
-	0.0	-	7/7 U

Description: Definition of the constant cutting speed for the master spindle.
The setting data is evaluated at spindle start by the NC/PLC interface signals DB380x DBX5006.1 (Spindle start clockwise rotation) and DB380x DBX5006.2 (Spindle start counterclockwise rotation)
Cutting speed programming values are entered in the SD by setting bit 8=1 in MD35035 \$MA_SPIND_FUNCTION_MASK.
Related to:
MD35035 \$MA_SPIND_FUNCTION_MASK
MD10709 \$MN_PROG_SD_POWERON_INIT_TAB
MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43206	SPIND_SPEED_TYPE	A06	-
-	Spindle speed type for spindle start through VDI	DWORD	Immediately
-			
-	94	93	972 7/7 U

Description: Definition of the spindle speed type for the master spindle.
The range of values and the functionality correspond to the 15th G group "feed type".
Permissible values are the G values: 93, 94, 95, 96, 961, 97, and 971.
The stated values make a functional distinction between the following variants:
==> 93, 94, 95, 97 and 971: The spindle is started at the speed in SD 43200 \$SA_SPIND_S.
==> 96 and 961: The speed of the spindle is derived from the cutting speed of SD 43202 \$SA_SPIND_CONSTCUT_S and the radius of the transverse axis.
The default value is 94 (corresponds to G94).
The default value becomes active if the SD is written with impermissible values.

43210	SPIND_MIN_VELO_G25	-	S1
rev/min	Programmed spindle speed limitation G25	DOUBLE	Immediately
-			
-	0.0	-	7/7 U

Description: A minimum spindle speed limit below which the spindle must not fall is entered in SPIND_MIN_VELO_G25. The NCK limits the set spindle speed to this value if it is too low.
The spindle speed may only fall below the minimum as a result of:

- Spindle offset 0%
- M5
- S0
- NC/PLC interface signal DB380x DBX4.3 (Spindle stop)
- NC/PLC interface signal DB380x DBX2.1 (Servo enable)
- NC/PLC interface signal DB3300 DBX3.7 (Channel status: Reset)

- NC/PLC interface signal DB380x DBX2.2 (Delete distance-to-go/Spindle reset)
- NC/PLC interface signal DB380x DBX2002.5 (Oscillation speed)
- Cancel S value

SD irrelevant to

other spindle modes used in open-loop control mode (SPOS, M19, SPOSA)

Related to:

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43220	SPIND_MAX_VELO_G26	-	S1			
rev/min	Programmable upper spindle speed limitation G26	DOUBLE	Immediately			
-						
-	-	1000.0	-	-	7/7	U

Description:

A maximum spindle speed is entered in SD43220 \$SA_SPIND_MAX_VELO_G26, which the spindle must not exceed. The NCK limits an excessive spindle speed set-point to this value.

SD irrelevant for

all spindle modes except open-loop control mode.

Special cases, errors,

The value in SD43210 \$SA_SPIND_MIN_VELO_G26 can be altered by means of:

- G26 S.... in the part program
- Operator commands via HMI

The value in SD43210 \$SA_SPIND_MIN_VELO_G26 is retained after a reset or Power Off.

Related to

SD43210 \$SA_SPIND_MIN_VELO_G25 (programmed spindle speed limit G25)

SD43230 \$SA_SPIND_MAX_VELO_LIMS (programmed spindle speed limit G96/961)

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43230	SPIND_MAX_VELO_LIMS	-	S1,Z1			
rev/min	Spindle speed limitation with G96	DOUBLE	Immediately			
-						
-	-	100.0	-	-	7/7	U

Description:

Limits the spindle speed with G96, G961, G97 to the stated maximum value [degrees/second]. This setting data can be written from the block with LIMS.

Note:

MD 10710 \$MN_PROG_SD_RESET_SAVE_TAB can be set so that the value written by the part program is transferred into the active file system on reset (that is the value is retained after reset).

Related to

SD43210 \$SA_SPIND_MIN_VELO_G25 (programmed spindle speed limit G25)

SD43230 \$SA_SPIND_MAX_VELO_LIMS (programmed spindle speed limit with G96/961)

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43235	SPIND_USER_VELO_LIMIT	A06	S1,Z1
rev/min	Maximum spindle speed	DOUBLE	Immediately
-			
-	-	10000.0	- - 7/7 U

Description: The user can enter a maximum spindle speed.
The NCK limits an excessive spindle setpoint speed to this value. The SD is effective immediately.
Corresponds with:
MD35100 \$MA_SPIND_VELO_LIMIT (maximum spindle speed)
MD35110 \$MA_GEAR_STEP_MAX_VELO (maximum speed for gear stage change)

43240	M19_SPOS	-, A12	S1
degrees	Spindle position for spindle positioning with M19.	DOUBLE	Immediately
-			
-	-	0.0 -10000000.0 10000000.0	7/7 U

Description: Spindle position in [DEGREES] for spindle positioning with M19.
The position approach mode is defined in \$SA_M19_SPOSMODE.
Default positions must lie in the range $0 \leq \text{pos} < \text{MD30330 } \MA_MODULO_RANGE .
Path defaults (SD43250 \$SA_M19_SPOSMODE = 2) can be positive or negative and are only limited by the input format.

43250	M19_SPOSMODE	-, A12	S1
-	Spindle position approach mode for spindle positioning with M19.	DWORD	Immediately
-			
-	-	0 0 5	7/7 U

Description: Spindle position approach mode for spindle positioning with M19.
In which signify:
0: DC (default) approach position on the shortest path.
1: AC approach position normally.
2: IC approach incrementally (as path), sign gives the traversing direction
3: DC approach position on the shortest path.
4: ACP approach position from the positive direction.
5: ACN approach position from the negative direction.

43300	ASSIGN_FEED_PER_REV_SOURCE	-	V1,P2,S1
-	Revolutional feedrate for positioning axes/spindles	DWORD	Immediately
CTEQ			
-	-	0 -3 31	7/7 U

Description: 0= No revolutional feedrate is active.
>0= Machine axis index of the rotary axis/spindle, from which the revolutional feedrate is derived.
-1= The revolutional feedrate is derived from the master spindle of the channel in which the axis/spindle is active
-2= The revolutional feedrate is derived from the axis with machine axis index == 0 or the axis with an index in MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB == 0.

-3= The revolutional feedrate is derived from the master spindle of the channel in which the axis/spindle is active. No revolutional feedrate is active if the master spindle is at a standstill.

Related to

SD42600 \$SC_JOG_FEED_PER_REV_SOURCE (revolutional feedrate for geometry axes on which a frame with rotation acts in JOG mode.)

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43320	JOG_POSITION	-	-			
mm, degrees	JOG position	DOUBLE	Immediately			
-						
-	-	0.0	-	-	7/7	U

Description: Position to be approached in JOG. Depending on MD10735 \$MN_JOG_MODE_MASK bit 4 axial frames and, with an axis configured as geometry axis, the tool length offset are considered.

43340	EXTERN_REF_POSITION_G30_1	-, A12	FBFA			
-	Reference point position for G30.1	DOUBLE	Immediately			
-						
-	-	0.0	-	-	7/7	U

Description: Reference point position for G30.1.
This setting data will be evaluated in CYCLE328.

43350	AA_OFF_LIMIT	-	S5,FBSY			
mm, degrees	Upper limit of offset value \$AA_OFF with clearance control	DOUBLE	PowerOn			
CTEQ						
-	-	100000000.0	0.0	1e15	7/7	U

Description: The upper limit of the offset value, which can be defined by means of synchronized actions via the variable \$AA_OFF.
This limit value acts on the absolutely effective amount of offset by means of \$AA_OFF.
It is used for clearance control in laser machining:
The offset value is limited so that the laser head cannot get caught in the plate recesses.
Whether the offset value lies within the limit range can be queried via system variable \$AA_OFF_LIMIT.

43400	WORKAREA_PLUS_ENABLE	-	A3			
-	Working area limitation active in positive direction	BOOLEAN	Immediately			
CTEQ						
-	-	FALSE	-	-	7/7	U

Description: 1: The working area limitation of the axis concerned is active in the positive direction.
0: The working area limitation of the axis concerned is switched off in the positive direction.
The setting data is parameterized via the operator panel in the operating area "Parameters" by activating/deactivating the working area limitation.
SD irrelevant for
G code: WALIMOF

43410	WORKAREA_MINUS_ENABLE	-	A3
-	Working area limitation active in the negative direction	BOOLEAN	Immediately
CTEQ			
-	-	FALSE	-
-	-	-	-
-	-	7/7	U

Description:

1: The working area limitation of the axis concerned is active in the negative direction.

0: The working area limitation of the axis concerned is switched off in the negative direction.

The setting data is parameterized via the operator panel in the operating area "Parameters" by activating/deactivating the working area limitation.

SD irrelevant for

G code: WALIMOF

43420	WORKAREA_LIMIT_PLUS	-	A3
mm, degrees	Working area limitation plus	DOUBLE	Immediately
-			
-	-	1.0e+8	-
-	-	-	-
-	-	7/7	U

Description:

The working area defined in the basic coordinate system in the positive direction of the axis concerned can be limited with axial working area limitation.

The setting data can be changed on the operator panel in the operating area "Parameters".

The positive working area limitation can be changed in the program with G26.

SD irrelevant for

G code: WALIMOF

Related to

SD43400 \$SA_WORKAREA_PLUS_ENABLE

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43430	WORKAREA_LIMIT_MINUS	-	A3
mm, degrees	Working area limitation minus	DOUBLE	Immediately
-			
-	-	-1.0e+8	-
-	-	-	-
-	-	7/7	U

Description:

The working area defined in the basic coordinate system in the negative direction of the axis concerned can be limited with axial working area limitation.

The setting data can be changed on the operator panel in the operating area "Parameters".

The negative working area limitation can be changed in the program with G25.

SD irrelevant for

G code: WALIMOF

Related to

SD43410 \$SA_WORKAREA_MINUS_ENABLE

MD10709 \$MN_PROG_SD_POWERON_INIT_TAB

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB

43500	FIXED_STOP_SWITCH	-	F1
-	Selection of travel to fixed stop	BYTE	Immediately
-			
-	-	0	0
-	-	1	7/7
-	-		U

Description: The "Travel to fixed stop" function can be selected and deselected with this setting data.
 SD=0 Deselect "Travel to fixed stop"
 SD=1 Select "Travel to fixed stop"
 The setting data can only be overwritten by the part program with the command FXS[x]=1/0 when software version 2.x is installed.
 The status of the setting data is indicated on the operator panel in the "Parameters" area.

43510	FIXED_STOP_TORQUE	-	F1
%	Fixed stop clamping torque	DOUBLE	Immediately
-			
-	-	5.0	0.0
-	-	800.0	7/7
-	-		U

Description: The clamping torque is entered in this setting data as a % of the maximum motor torque (corresponds to % of max. current value with FDD).
 The setting data is active only if the fixed stop has been reached.
 The fixed stop is considered reached when,

- with MD: MD37060 \$MA_FIXED_STOP_ACKN_MASK, bit 1 = 0 (no acknowledgment required), the interface signal DB390x DBX2.5 (Fixed stop reached) is set by the NC
- with MD37060 \$MA_FIXED_STOP_ACKN_MASK, bit 1 = 1 (acknowledgment required), the interface signal DB390x DBX2.5 (Fixed stop reached) is set by the NC and acknowledged by interface signal DB380x DBX1.1 (Acknowledge fixed stop reached)

The status of the setting data is indicated on the operator panel in the "Parameters" area.
 The FXST[x] command effects a block-synchronous change to this setting data. It can also be changed by the user or via the PLC. Otherwise the value is transferred from MD37010 \$MA_FIXED_STOP_TORQUE_DEF to the setting data when "Travel to fixed stop" is active.
 Related to
 MD37010 \$MA_FIXED_STOP_TORQUE_DEF(default setting for clamping torque)

43520	FIXED_STOP_WINDOW	-	F1
mm, degrees	Fixed stop monitoring window	DOUBLE	Immediately
-			
-	-	1.0	-
-	-		7/7
-	-		U

Description: The fixed stop monitoring window is entered in this setting data.
 The setting data is active only if the fixed stop has been reached.
 The fixed stop is considered reached when,

- with MD37060 \$MA_FIXED_STOP_ACKN_MASK, bit 1 = 0 (no acknowledgment required) interface signal DB390x DBX2.5 (Fixed stop reached) is set by the NC

- with MD37060 \$MA_FIXED_STOP_ACKN_MASK, bit 1 = 1 (acknowledgment required) interface signal DB390x DBX2.5 (Fixed stop reached) is set by the NC and acknowledged by interface signal DB380x DBX1.1 (Acknowledge fixed stop reached)

If the position at which the fixed stop was detected leaves the tolerance band by more than the amount specified in SD43520 \$SA_FIXED_STOP_WINDOW, then alarm 20093 "Fixed stop monitoring has responded" is output and the "FXS" function is deselected.

The status of the setting data is indicated on the operator panel in the "Parameters" area.

The FXSW[x] command effects a block-synchronous change to this setting data. It can also be changed by the user or via the PLC.

The value is otherwise transferred from MD37020 \$MA_FIXED_STOP_WINDOW_DEF to the setting data when "Travel to fixed stop" is active.

Related to

MD37020 \$MA_FIXED_STOP_WINDOW_DEF (default setting for fixed stop monitoring window)

43600	IPOBRAKE_BLOCK_EXCHANGE	A06, A10	K1
%	Block change criterion 'braking ramp'	DOUBLE	Immediately
-			
-	-	0.0	0
		100.0	7/7
			U

Description: Specifies the application time at single axis interpolation for the block change criterion braking ramp: At 100%, the block change criterion is full-filled at the time of application of the braking ramp. At 0%, the block change criterion is identical with IPOENDA.

Note:

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB can be set so that the value written by the part program is transferred into the active file system on reset (i.e. the value is retained even after reset).

43610	ADISPOSA_VALUE	A06, A10	P2
mm, degrees	Tolerance window 'braking ramp'	DOUBLE	Immediately
-			
-	-	0.0	-
			7/7
			U

Description: In case of single-axis interpolation, this value defines the size of the tolerance window which the axis must have reached in order to enable a block change in case of the block-change criterion 'braking ramp with tolerance window valid' and when reaching the corresponding % value of the braking ramp (SD43600 \$SA_IPOBRAKE_BLOCK_EXCHANGE).

Note:

By means of the MD 10710 \$MN_PROG_SD_RESET_SAVE_TAB, the user can specify that the value written by the part program is transferred into the active file system in case of a reset (i.e. the value is retained even after the reset).

43900	TEMP_COMP_ABS_VALUE	-	K3
-	Position-independent temperature compensation value	DOUBLE	Immediately
-			
-	-	0.0	-
-	-	-	-
			7/7
			U

Description: The position-independent temperature compensation value is defined by SD43900 \$SA_TEMP_COMP_ABS_VALUE.

-

The machine axis traverses this additional compensation value as soon as the position-independent temperature compensation has been activated (MD32750 \$MA_TEMP_COMP_TYPE = 1 oder 3).

SD irrelevant for

MD32750 \$MA_TEMP_COMP_TYPE = 0 or 2

Related to

MD32750 \$MA_TEMP_COMP_TYPE Temperature compensation type

MD32760 \$MA_COMP_ADD_VELO_FACTOR Velocity overshoot caused by compensation

43910	TEMP_COMP_SLOPE	-	K3
-	Lead angle for position-dependent temperature compensation	DOUBLE	Immediately
-			
-	-	0.0	-
-	-	-	-
			7/7
			U

Description: In the case of position-dependent temperature compensation, the error curve characteristic of the temperature-dependent actual-value deviation can often be approximated by a straight line. This straight line is defined by a reference point P₀ and a slope tan-β.

SD43910 \$SA_TEMP_COMP_SLOPE defines the slope tan-β. This slope can be changed by the PLC user program as a function of the current temperature.

The axis traverses additionally the compensation value calculated for the current actual position as soon as the position-dependent temperature compensation becomes active (MD32750 \$MA_TEMP_COMP_TYPE = = 2 or 3).

MD32760 \$MA_COMP_ADD_VELO_FACTOR limits the maximum angle of slope tan-β_{max} of the error curve. This maximum angle of slope cannot be exceeded.

SD irrelevant for

MD32750 \$MA_TEMP_COMP_TYPE = 0 or 1

Special cases, errors,

When SD43910 \$SA_TEMP_COMP_SLOPE is greater than tan-β_{max}, the slope tan-β_{max} is used to calculate the position-dependent temperature compensation value internally. No alarm is output.

Related to

MD32750 \$MA_TEMP_COMP_TYPE Temperature compensation type

SD43920 \$SA_TEMP_COMP_REF_POSITION Reference position for position-dependent temperature compensation

MD32760 \$MA_COMP_ADD_VELO_FACTOR Velocity overshoot caused by compensation

43920	TEMP_COMP_REF_POSITION	-	K3
-	Ref. position of position-dependent temperature compensation	DOUBLE	Immediately
-			
-	-	0.0	-
-	-	-	-
-	-	7/7	U

Description:

In the case of position-dependent temperature compensation, the error curve characteristic of the temperature-dependent actual-value deviation can often be approximated by a straight line. This straight line is defined by a reference point P_0 and a slope $\tan\beta$.

SD43920 \$SA_TEMP_COMP_REF_POSITION defines the position of the reference point P_0. This reference position can be changed by the PLC user program as a function of the current temperature.

The axis traverses additionally the compensation value calculated for the current actual position as soon as the position-dependent temperature compensation becomes active (MD32750 \$MA_TEMP_COMP_TYPE = 2 or 3).

SD irrelevant for

MD32750 \$MA_TEMP_COMP_TYPE = 0 or 1

Related to

MD32750 \$MA_TEMP_COMP_TYPE Temperature compensation type

SD43910 \$SA_TEMP_COMP_SLOPE Angle of slope for position-dependent temperature compensation

Cycles, machine and setting data

4

Number	Identifier	Display filters		Reference		
Unit	Name	Data type		Active		
Attributes						
System	Dimension	Default value	Minimum value	Maximum value	Protection	Class

Description: Description

51000	DISP_RES_MM	-	-			
-	Display resolution in mm		BYTE		PowerOn	
-						
-	-	3	0	6	7/3	M

Description: Display resolution in mm

51001	DISP_RES_MM_FEED_PER_REV	-	-			
-	Display resolution in mm feedrate/rev		BYTE		Immediately	
-						
-	-	3	0	6	7/3	M

Description: Display resolution in mm feedrate/rev

51002	DISP_RES_MM_FEED_PER_TIME	-	-			
-	Display resolution in mm feedrate/min		BYTE		Immediately	
-						
-	-	3	0	6	7/3	M

Description: Display resolution in mm feedrate/min

51003	DISP_RES_MM_FEED_PER_TOOTH	-	-			
-	Display resolution in mm feedrate/tooth		BYTE		Immediately	
-						
-	-	3	0	6	7/3	M

Description: Display resolution in mm feedrate/tooth

51004	DISP_RES_MM_CONST_CUT_RATE	-	-			
-	Display resolution constant cutting speed m/min		BYTE		Immediately	
-						
-	-	3	0	6	7/3	M

Description: Display resolution constant cutting speed m/min

51010	DISP_RES_INCH	-	-			
-	Display resolution in inch		BYTE		PowerOn	
-						
-	-	4	0	6	7/3	M

Description: Display resolution in inch

51011	DISP_RES_INCH_FEED_P_REV	-	-			
-	Display resolution in inch feedrate/rev	BYTE	Immediately			
-						
-	-	4	0	6	7/3	M

Description: Display resolution in inch feedrate/rev

51012	DISP_RES_INCH_FEED_P_TIME	-	-			
-	Display resolution in inch feedrate/min	BYTE	Immediately			
-						
-	-	4	0	6	7/3	M

Description: Display resolution in inch feedrate/min

51013	DISP_RES_INCH_FEED_P_TOOTH	-	-			
-	Display resolution in inch feedrate/tooth	BYTE	Immediately			
-						
-	-	4	0	6	7/3	M

Description: Display resolution in inch feedrate/tooth

51014	DISP_RES_INCH_CUT_RATE	-	-			
-	Display resolution constant cutting speed ft/min	BYTE	Immediately			
-						
-	-	4	0	6	7/3	M

Description: Display resolution constant cutting speed ft/min

51020	DISP_RES_ANGLE	-	-			
-	Display resolution of angle	BYTE	Immediately			
-						
-	-	3	0	6	7/3	M

Description: Display resolution of angle

51021	DISP_RES_SPINDLE	-	-			
-	Display resolution of spindles	BYTE	Immediately			
-						
-	-	0	0	6	7/3	M

Description: Decimal places in speed entry field

51022	DISP_RES_ROT_AX_FEED	-	-			
-	Display resolution of rotary axis feedrate	BYTE	Immediately			
-						
-	-	0	0	6	7/3	M

Description: Display resolution of rotary axis feedrate

51023	ACT_VALUE_SPIND_MODE	-	-			
-	Only display spindles in actual values window when in axis mode	BYTE	PowerOn			
-						
-	-	1	0	1	3/4	M

Description: This affects the display of the spindles in the axis actual values window. If the value is set to 1, only those spindles in axis mode are displayed, those in spindle mode are shown as gaps. If the value is set to 0, all spindles are displayed.

51025	FRAMES_ACT_IMMEDIATELY	-	-			
-	Activate active offset immediately	BYTE	PowerOn			
-						
-	-	1	0	1	4/3	M

Description: Active data (frames) are activated immediately after change

51026	AXES_SHOW_GEO_FIRST	-	-			
-	Actual value display with leading geometry axes	BYTE	PowerOn			
-						
-	-	1	0	1	4/3	M

Description: When the machine data value is 1, the geometry axes of the channel are displayed first.

51027	ONLY_MKS_DIST_TO_GO	-	-			
-	Distance-to-go display in work window	BYTE	PowerOn			
-						
-	-	0	0	1	4/3	M

Description: Distance-to-go display in work window

51028	BLOCK_SEARCH_MODE_MASK	-	-			
-	Bit mask for available block search modes	BYTE	PowerOn			
-						
-	-	51	-	-	4/3	M

Description: Bit mask for available search modes
 Bit 0:Block search with calculation but no approach
 Bit 1:Block search with calculation and approach
 Bit 3:Skip EXTCALL programs
 Bit 4:Block search without calculation
 Bit 5:Block search with test run

51029	MAX_SKP_LEVEL	-	-			
-	Maximum number of skip levels in the NC program	BYTE	PowerOn			
-						
-	-	1	1	10	4/3	M

Description: The machine data defines how many skip levels are made available for operation.

51030	SPIND_MAX_POWER	-	-			
%	Maximum value of spindle power rating display	DWORD	PowerOn			
-						
-	-	100	0	255	4/3	M

Description: Maximum value of the permissible spindle power rating in percent; the display bar in the machine image is shown in green within the range between 0 and the value stored in SPIND_MAX_POWER.

51031	SPIND_POWER_RANGE	-	-			
%	Display range of spindle power rating display	DWORD	PowerOn			
-						
-	-	100	0	255	4/3	M

Description: Scale end value for spindle power rating in percent; value must be equal to or greater than SPIND_MAX_POWER.
The display bar in the machine image is shown in red in the range between the values of SPIND_MAX_POWER and SPIND_POWER_RANGE.

51032	STAT_DISPLAY_BASE	-	-			
-	Number basis for display of articulated joint STAT	BYTE	PowerOn			
-						
-	-	2	0	16	4/3	M

Description: Number basis for display of articulated joint STAT
00: no display
02: binary value display
10: decimal value display
16: hexadecimal value display

51033	TU_DISPLAY_BASE	-	-			
-	Number basis for display of rotary axis position TU	BYTE	PowerOn			
-						
-	-	2	0	16	4/3	M

Description: Number basis for display of rotary axis position TU
00: no display
02: binary value display
10: decimal value display
16: hexadecimal value display

51034	TEACH_MODE	-	-			
-	Teach mode to be activated	DWORD	PowerOn			
-						
-	-	1	-	-	4/3	M

Description: Teach mode to be activated
 Bit 0: default teach-in
 Taught-in block is transferred to the program using the Accept softkey.
 Bit 1: acceptance of teach block can be blocked by the PLC.
 DB19.DBX13.0 = 0 block is accepted.
 DB19.DBX13.0 = 1 block is not accepted.
 Bit 2: block selection only explicitly
 Bit 16-31 reserved for OEM.

51035	WRITE_FRAMES_FINE_LIMIT	-	-			
-	Input limit for all WO fine	DOUBLE	PowerOn			
-						
-	-	0.999	-	-	4/3	M

Description: Input limit for all work offsets fine

51036	ENABLE_COORDINATE_REL	-	-			
-	Enable REL coordinate system	BYTE	PowerOn			
-						
-	-	0	0	1	7/3	M

Description: Display REL coordinate system
 0 = no relative coordinate system selectable
 1 = REL coordinate system can be selected as an alternative of the WCS/SZS coordinate system

51037	ENABLE_COORDINATE_ACS	-	-			
-	Enable settable coordinate system	BYTE	PowerOn			
-						
-	-	0	0	1	7/3	M

Description: Activate settable coordinate system
 0 = WCS coordinate system is displayed
 1 = SZS coordinatesystem is displayed
 (SZS is WCS reduced by the offset components defined in MD24030)

51038	SET_ACT_VALUE	-	-			
-	Set actual value selection	BYTE	PowerOn			
-						
-	-	1	0	1	7/3	M

Description: Set actual value selection
 0 = Set actual value is not offered.
 1 = if a user frame (settable work offset e.g. G54) is active, it will be used. In G500 Set actual values is not offered (system frame is no longer used).

51039	PROGRAM_CONTROL_MODE_MASK	-	-			
-	Options for machine - program influence	DWORD	PowerOn			
-						
-	-	1	-	-	7/3	M

Description: Options for machine - program influence:
 Bit 0: program test function available

51040	SWITCH_TO_MACHINE_MASK	-	-			
-	Automatic operating area switchover to machine	BYTE	PowerOn			
-						
-	-	0	-	-	7/3	M

Description: Automatic area switchover dependent upon machine
 Bit 0: No automatic switch to Machine operating area when the program is selected in the Program Manager.
 Bit 1: No automatic switch to Machine operating area when the operating mode is changed over via the machine control panel (MCP).
 Bit 2: No automatic switch to Machine operating area when the program is selected in the Programs operating area.
 Bit 3: No automatic start of block search when the program is selected / executed in the Programs operating area.

51041	ENABLE_PROGLIST_USER	-	-			
-	Activation of PLC program list, USER area	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Activates the PLC program list of the USER area. The programs entered there can be selected by the PLC for processing.

51043	ENABLE_PROGLIST_MANUFACT	-	-			
-	Activation of PLC program list, MANUFACTURER area	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Activates the PLC program list of the MANUFACTURER area. The programs entered here can be selected by the PLC for processing.

51044	ACCESS_SHOW_SBL2	-	-			
-	Display protection level SBL2	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Display protection level SBL2

51045	ACCESS_TEACH_IN	-	-			
-	Protection level TEACH IN	BYTE	PowerOn			
-						
-	-	4	0	7	4/3	M

Description: Protection level TEACH IN

51046	ACCESS_CLEAR_RPA	-	-			
-	Protection level delete R variables	BYTE	PowerOn			
-						
-	-	4	0	7	4/3	M

Description: Protection level delete R variables

51047	ACCESS_READ_GUD_LUD	-	-			
-	Read user variable protection level	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Read user variable protection level

51048	ACCESS_WRITE_GUD_LUD	-	-			
-	Write protection level of user variables	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Write protection level of user variables

51049	ACCESS_WRITE_PRG_COND	-	-			
-	Write program control protection level	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Write program control protection level

51050	ACCESS_WRITE_PROGRAM	-	-			
-	Write part program protection level	BYTE	PowerOn			
-						
-	-	4	0	7	4/3	M

Description: Write part program protection level

51051	ACCESS_WRITE_RPA	-	-			
-	Protection level write R variables	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Protection level write R variables

51052	ACCESS_WRITE_SEA	-	-			
-	Protection level write setting data	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Protection level write setting data

51053	ACCESS_WRITE_BASEFRAME	-	-			
-	Write basic work offset protection level	BYTE	PowerOn			
-						
-	-	7	0	7	4/3	M

Description: Write basic work offset (basic frame) protection level

51054	ACCESS_WRITE_CYCFRAME	-	-
-	Write cycle frame protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write cycle frame protection level

51055	ACCESS_WRITE_EXTRFRAME	-	-
-	Write external WO protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write external work offset protection level

51056	ACCESS_WRITE_PARTFRAME	-	-
-	Write table reference protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write table reference protection level

51057	ACCESS_WRITE_SETFRAME	-	-
-	Write basic reference protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write basic reference protection level

51058	ACCESS_WRITE_TOOLFRAME	-	-
-	Write basic tool reference protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write basic tool reference protection level

51059	ACCESS_WRITE_TRAFRAME	-	-
-	Write transformation frame protec. level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write transformation frame protec. level

51060	ACCESS_WRITE_USERFRAME	-	-
-	Write settable work offset protection level	BYTE	PowerOn
-			
-	-	4	0
		7	4/3
			M

Description: Write settable work offset (G54 ... G599) protection level

51061	ACCESS_WRITE_WPFFRAME	-	-
-	Write workpiece reference protection level	BYTE	PowerOn
-			
-	-	7	0
		7	4/3
			M

Description: Write workpiece reference protection level

51062	ACCESS_WRITE_FINE	-	-			
-	Write protection level for fine offset of all work offsets	BYTE	PowerOn			
-						
-	-	6	0	7	4/3	M

Description: Write protection level for fine offset of all work offsets

51063	ACCESS_SET_ACT_VALUE	-	-			
-	Set actual value protection level	BYTE	PowerOn			
-						
-	-	4	0	7	4/3	M

Description: Set actual value protection level

51064	ACCESS_WRITE_PROGLIST	-	-			
-	Write protection level of program list in USER area	BYTE	Immediately			
-						
-	-	4	0	7	4/3	M

Description: Minimum protection level required to change the program list in the USER area (program manager)

51065	NUM_DISPLAYED_CHANNELS	-	-			
-	Number of channels displayed simultaneously	BYTE	PowerOn			
-						
-	-	1	1	4	4/3	M

Description: Setting of the number of channels to be displayed simultaneously in the machine operating area and in the multi-channel editor.

51066	ORDER_DISPLAYED_CHANNELS	-	-			
-	Channel numbers of the channels displayed	STRING	PowerOn			
-						
-	-	1;	-	-	4/3	M

Description: Contains the numbers of the channels to be displayed under machine in the multi-channel view, in the desired order and separated by commas, semicolons or spaces.

51067	ENABLE_HANDWHEEL_WINDOW	-	-			
-	Show handwheel window	BYTE	PowerOn			
-						
-	-	1	0	1	4/2	M

Description: If the machine data is set to 0, the window for handwheel assignment is hidden

51068	SPIND_DRIVELOAD_FROM_PLC1	-	-			
-	Machine axis index of spindle 1 utilization display from PLC	BYTE	PowerOn			
-						
-	-	0	0	31	4/2	M

Description: Machine axis index of a spindle (analog), which refers to the data for the utilization display in the T,F,S window from the PLC (DB19.DBB6).

51069	SPIND_DRIVELoad_FROM_PLC2	-	-			
-	Machine axis index of spindle 2 utilization display from PLC	BYTE	PowerOn			
-						
-	-	0	0	31	4/2	M

Description: Machine axis index of a spindle (analog), which refers to the data for the utilization display in the T,F,S window from the PLC (DB19.DBB7).

51070	ACCESS_CAL_TOOL_PROBE	-	-			
-	Protection level for calibration of the tool probe (ShopTurn)	BYTE	PowerOn			
-						
-	-	4	0	7	4/3	M

Description: Protection level for calibration of the tool probe (ShopTurn)

51071	ACCESS_ACTIVATE_CTRL_E	-	-			
-	Protection level of Ctrl-Energy	BYTE	PowerOn			
-						
-	-	1	0	7	4/3	M

Description: Protection level for activating, disabling and enabling energy profiles.

51072	ACCESS_EDIT_CTRL_E	-	-			
-	Protection level of Ctrl-Energy for changing profiles	BYTE	PowerOn			
-						
-	-	2	0	7	4/3	M

Description: Protection level of Ctrl-Energy: Definition of status profiles

51073	ACCESS_SET_SOFTKEY_ACCESS	-	-			
-	Protection level of "Adapt softkeys"	BYTE	PowerOn			
-						
-	-	3	0	7	4/3	M

Description: Protection level for the softkey "Adapt softkeys", which is used to change the access levels of other softkeys.

51199	ACCESS_WRITE_TM_GRIND	-	-			
-	Protection level of tool management for writing grinding data	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level of tool management for writing grinding data

51200	ACCESS_WRITE_TM_GEO	-	-			
-	Write tool offset geometry data protection level	BYTE	PowerOn			
-						
-	-	5	0	7	7/4	M

Description: Write tool offset geometry data protection level

51201	ACCESS_WRITE_TM_WEAR	-	-			
-	Write tool offset wear data protection level	BYTE	PowerOn			
-						
-	-	6	0	7	7/4	M

Description: Write tool offset wear data protection level

51202	ACCESS_WRITE_TM_WEAR_DELTA	-	-
-	Protection level for tool offset restricted writing of wear data	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Protection level for restricted writing of tool wear values
S. MD 54213: TM_WRITE_DELTA_LIMIT

51203	ACCESS_WRITE_TM_SC	-	-
-	Write tool offset sum offset protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset sum offset protection level

51204	ACCESS_WRITE_TM_EC	-	-
-	Write tool offset use offsets protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset use offsets protection level

51205	ACCESS_WRITE_TM_SUPVIS	-	-
-	Write tool offset monitoring data protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset monitoring data protection level
One authorization applies to all limit values: quantity, service life, wear and the monitoring type.

51206	ACCESS_WRITE_TM_ASSDNO	-	-
-	Write tool offset unique D number protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset unique D number protection level

51207	ACCESS_WRITE_TM_WGROUP	-	-
-	Write tool offset wear groups protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset wear groups (magazine location / magazine) protection level

51208	ACCESS_WRITE_TM_ADAPT	-	-
-	Write tool offset adapter data protection level	BYTE	PowerOn
-			
-	-	7	0
-	-	7	7/4
-	-		M

Description: Write tool offset tool adapter geometry data protection level

51209	ACCESS_WRITE_TM_NAME	-	-			
-	Write tool offset tool name protection level	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Write tool offset tool name and duplo data protection level

51210	ACCESS_WRITE_TM_TYPE	-	-			
-	Write tool offset tool type protection level	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Write tool offset tool type protection level

51211	ACCESS_READ_TM	-	-			
-	Read tool offset data protection level	BYTE	PowerOn			
-						
-	-	7	0	7	7/4	M

Description: Read tool offset data protection level

51212	TM_WRITE_WEAR_ABS_LIMIT	-	-			
mm	Maximum tool wear value	DOUBLE	PowerOn			
-						
-	-	0.999	0	10	7/4	M

Description: With TM_WRITE_WEAR_ABS_LIMIT, the max. possible value of a tool wear is limited absolutely, independently of the current protection level (keyswitch position), i.e. also independently of ACCESS_WRITE_TM_WEAR. Absolute and incremental wear limitation can be combined, i.e. the wear can be changed incrementally up to the absolute limit. S. MD 51213.

51213	TM_WRITE_WEAR_DELTA_LIMIT	-	-			
mm	Maximum difference value restricted tool wear input	DOUBLE	PowerOn			
-						
-	-	0	0	10	7/4	M

Description: When entering tool offsets, the value of the change from the previous value to the new value cannot exceed the value set here.
 With TM_WRITE_WEAR_DELTA_LIMIT, the change to a tool wear can be limited incrementally, if the current protection level is the same as or higher than the one set in ACCESS_WRITE_TM_WEAR_DELTA. With the current protection level being the same or higher than ACCESS_WRITE_TM_WEAR, an incremental limitation is no longer performed. Absolute and incremental wear limitation can be combined, i.e. the wear can be changed up to the absolute limit. S. MD 51212

51214	TM_WRITE_LIMIT_MASK	-	-			
-	Validity of the restricted tool wear input	BYTE	PowerOn			
-						
-	-	7	0	7	7/4	M

Description: Validity of the restricted tool wear input
 Bit 0:use for cutting edge data, wear
 Bit 1:use for SC data, sum offsets
 Bit 2:use for EC data, use offsets
 Bit 0+1+2:use for all data, wear, SC, EC

51215	ACCESS_WRITE_TM_ALL_PARAM	-	-			
-	Protection level TM details - write all parameters	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM details - write all parameters

51216	ACCESS_TM_TOOL_CREATE	-	-			
-	Protection level TM create tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM create tool

51217	ACCESS_TM_TOOL_DELETE	-	-			
-	Protection level TM delete tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM delete tool

51218	ACCESS_TM_TOOL_LOAD	-	-			
-	Protection level TM load tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM load tool

51219	ACCESS_TM_TOOL_UNLOAD	-	-			
-	Protection level TM unload tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM unload tool

51220	ACCESS_TM_TOOL_MOVE	-	-			
-	Protection level TM relocate tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM relocate tool

51221	ACCESS_TM_TOOL_REACTIVATE	-	-			
-	Protection level TM reactivate tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM reactivate tool

51222	ACCESS_TM_TOOL_MEASURE	-	-			
-	Protection level TM measure tool	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM measure tool
Direct jump from tool list to measuring screen

51223	ACCESS_TM_TOOLEEDGE_CREATE	-	-			
-	Protection level TM create tool cutting edge	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM create tool cutting edge

51224	ACCESS_TM_TOOLEEDGE_DELETE	-	-			
-	Protection level TM delete tool cutting edge	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM delete tool cutting edge

51225	ACCESS_TM_MAGAZINE_POS	-	-			
-	Protection level TM position magazine	BYTE	PowerOn			
-						
-	-	4	0	7	7/4	M

Description: Protection level TM position magazine

51226	FUNCTION_MASK_SIM	-	-			
-	Function mask Simulation	DWORD	PowerOn			
-						
-	-	0	-	-	7/3	M

Description: Function mask Simulation
Bit 0: No automatic start on simulation selection

51228	FUNCTION_MASK_TECH	-	-			
-	Function mask Cross-technology	DWORD	PowerOn			
-						
-	-	0	-	-	7/3	M

Description: Function mask, all technologies
Bit 0: G code programming without multi-channel data
If bit 0 = 1, no multi-channel data will be offered for job lists which only contain G code programs.
Bit 1: Enable print function of Editor

51235	ACCESS_RESET_SERV_PLANNER	-	-			
-	Protection level for acknowledgement of maintenance tasks	BYTE	Immediately			
-						
-	-	3	0	7	4/2	M

Description: Protection level for acknowledgement of maintenance tasks

51600	MEA_CAL_WP_NUM	-	-			
-	Number of calibration data fields for workpiece probes	BYTE	Immediately			
-						
-	-	12	0	12	7/2	I

Description: The workpiece probe calibration data refer to the workpiece coordinate system (WCS) !
In the data fields, the workpiece probe calibration data of the technologies Milling and Turning are stored!

51601	MEA_CAL_EDGE_NUM	-	-			
-	Number of geometry data fields of gauging block, workpiece probe	BYTE	Immediately			
-						
-	-	3	0	3	7/2	I

Description: The gauging block is exclusively used to calibrate the workpiece probe of the Turning technology!

51602	MEA_CAL_TP_NUM	-	-			
-	Number of calibration data fields for tool probes	BYTE	Immediately			
-						
-	-	6	0	6	7/2	I

Description: The value of this parameter corresponds to the number of tool probe calibration data records set up for the machine coordinate system (MCS).

51603	MEA_CAL_TPW_NUM	-	-			
-	Number of calibration data fields for tool probes	BYTE	Immediately			
-						
-	-	6	0	6	7/2	I

Description: The value of this parameter corresponds to the number of tool probe calibration data records set up for the workpiece coordinate system (WCS).

51618	MEA_CM_ROT_AX_POS_TOL	-	-			
degrees	Tolerance of the rotary axis positions	DOUBLE	Immediately			
-						
-	-	0.5	-1	1	7/3	I

Description: Entries in parameter \$MN_MEA_CM_ROT_AX_POS_TOL are effective only if \$MN_MEA_TOOLCARR_ENABLE=1
The real angle position of the rotary axes can deviate from the programmed one (exact stop fine window).

This deviation depends on the position control features of the axis. The maximum deviation expected on the concrete axis must be entered in this parameter. When the tolerance is exceeded, alarm 61442 "Toolholder not in parallel with the geometry axes" is displayed.

51740	MEA_FUNCTION_MASK	-	-			
-	Function mask for measuring cycles	DWORD	Immediately			
-						
-	-	11	-	-	7/3	M

Description:

Function mask for measuring cycles
 Bit 0: Activation of the calibration status monitoring of workpiece measurement for measurements in automatic mode
 0: Calibration monitoring not active
 1: Calibration monitoring active
 The status of the following states is monitored between calibration and measurement:
 - Working plane (G17, 18, 19)
 - Probe type (mono probe, multi probe)
 - Longitudinal reference of the probe (center of probe ball, circumference of probe ball)
 - Programmed velocity of probe
 These monitors are always active with "Measurement in JOG" and cannot be deactivated.
 Bit 1: Length relation of the workpiece probe, milling technology
 0: Tool length L1, in relation to the center of the probe ball
 1: Tool length L1, in relation to the circumference of the probe ball
 Bit 2: Support of orientable tool carriers during workpiece measurement
 0: No support of orientable tool carriers.
 1: Support of a probe or tool positioned by an orientable tool carrier (kinematic type "T") with reference to the specific carrier positions 0°, 90°, 180° and 270°.
 Bit 3: Correction of the position of the mono probe during workpiece measurement
 0: No correction
 1: If the workpiece probe is a mono probe, the alignment of its switching direction (spindle position) is corrected by the angle value in _CORA.
 Bit16: Support of orientable tool carriers during tool measurement
 0: No support of orientable tool carriers.
 1: Support of a tool positioned by an orientable tool carrier (kinematic type "T")

51750	J_MEA_M_DIST	-	-			
mm	Measuring path for measuring with ShopMill, in automatic mode	DOUBLE	Immediately			
-						
-	-	5	-10000	10000	7/5	I

Description:

This parameter defines the measuring path in front of and behind the measuring setpoint.

51751	J_MEA_M_DIST_MANUELL	-	-
mm	Measuring path, for "Measure in JOG"	DOUBLE	Immediately
-			
-	-	10	-10000 10000 7/5 I

Description: This parameter defines the measuring path in front of and behind the measuring setpoint.

51752	J_MEA_M_DIST_TOOL_LENGTH	-	-
mm	Measuring path for tool length measuring, for "Measure in JOG"	DOUBLE	Immediately
-			
-	-	2	-10000 10000 7/5 I

Description: This parameter defines the measuring path in front of and behind the measuring setpoint.

51753	J_MEA_M_DIST_TOOL_RADIUS	-	-
mm	Measuring path for tool radius measuring, for "Measure in JOG"	DOUBLE	Immediately
-			
-	-	1	-10000 10000 7/5 I

Description: This parameter defines the measuring path in front of and behind the measuring setpoint.

51757	J_MEA_COLL_MONIT_FEED	-	-
mm/min	Feedrate in the plane w. active collision detection, for "Measure in JOG"	DOUBLE	Immediately
-			
-	-	1000	0 100000 7/5 I

Description: Feedrate in the working plane w. active collision detection

51758	J_MEA_COLL_MONIT_POS_FEED	-	-
mm/min	Infeed rate with active collision detection, for "Measure in JOG"	DOUBLE	Immediately
-			
-	-	1000	0 100000 7/5 I

Description: Feedrate of the infeed axis with active collision detection, for "Measure in JOG".

51770	J_MEA_CAL_RING_DIAM	-	-
mm	Calibration ring diameter, for "Measure in JOG"	DOUBLE	Immediately
-			
-	12	-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1,-1	10000 7/5 I

Description: Calibration ring diameter, for probe sphere calibration in the plane, for "Measure in JOG"

51772	J_MEA_CAL_HEIGHT_FEEDAX			-	-	
mm	Calibration height in the infeed axis, for probe length calibration			DOUBLE	Immediately	
-						
-	12	-99999,-99999,- 99999,-99999,- 99999...	-100000	100000	7/5	I

Description: Calibration height in the infeed axis for probe length calibration, for "Measure in JOG"
 The calibration height must be entered with reference to the the workpiece coordinate system (WCS)!

51780	J_MEA_T_PROBE_DIAM_RAD			-	-	
mm	Diameter of the tool probe for radius measurement, for "Measure in JOG"			DOUBLE	Immediately	
-						
-	6	0,0,0,0,0,0	0	10000	7/5	I

Description: Effective grinding wheel diameter of the tool probe for radius measurement on milling tools, for "Measure in JOG"

51784	J_MEA_T_PROBE_APPR_AX_DIR			-	-	
-	Approach direction in the plane on the tool probe, for "Measure in JOG"			DWORD	Immediately	
-						
-	6	-1,-1,-1,-1,-1,-1	-2	2	7/5	I

Description: Approach direction in the plane on the tool probe, for "Measure in JOG"
 = -2 negative direction 2nd measuring axis
 = -1 negative direction 1st measuring axis
 = 0 or 1 positive direction 1st measuring axis
 = 2 psoitive direction 2nd measuring axis

51786	J_MEA_T_PROBE_MEASURE_DIST			-	-	
mm	Measur. path for tool measurem. w. stationary spindle, for "Measure in JOG"			DOUBLE	Immediately	
-						
-	-	10	-10000	10000	7/5	I

Description: Measuring path for tool probe calibration and tool measuring with stationary spindle, in front of and behind the expected switching position.

52000	DISP_COORDINATE_SYSTEM			-	-	
-	Coordinate system position			BYTE	PowerOn	
-						
-	-	0	0	47	7/3	M

Description: With this MD you adapt the operator panel of the coordinate system to the machine's coordinate system. Depending on the selected position, all help screens, the sequence graphic, the simulation and the input fields with the circular direction specified will change automatically.
 Also note MD 52210 \$MCS_FUNCTION_MASK_DISP, bit 1.

52005	DISP_PLANE_MILL	-	-			
-	Plane selection Milling	BYTE	Immediately			
-						
-	-	0	0	19	7/3	M

Description: Plane selection Milling
0: plane selection on the operator panel
17: always G17
18: always G18
19: always G19

52006	DISP_PLANE_TURN	-	-			
-	Plane selection Turning	BYTE	Immediately			
-						
-	-	18	0	19	7/3	M

Description: Plane selection Turning
0: plane selection on the operator panel
17: always G17
18: always G18
19: always G19

52010	DISP_NUM_AXIS_BIG_FONT	-	-			
-	Number of actual values with large font	BYTE	PowerOn			
-						
-	-	3	0	31	7/3	M

Description: Number of actual values with large font

52011	ADJUST_NUM_AXIS_BIG_FONT	-	-			
-	Adapt number of act val w large font dynamically to no. of geometry axes	BYTE	PowerOn			
-						
-	-	0	0	2	7/3	M

Description: Adapt the number of actual values with large font if the number of geometry axes changes, e.g. due to transformations like TRANSMIT or TRACYL.
0 = Only MD 52010 "DISP_NUM_AXIS_BIG_FONT" is valid. The number is assigned as a fixed value.
1 = Only the geometry axes are displayed in large font. MD 52010 "DISP_NUM_AXIS_BIG_FONT" is ignored.
2 = The number of geometry axes plus the content of MD 52010 "DISP_NUM_AXIS_BIG_FONT" are displayed in large font.

52200	TECHNOLOGY	-	-			
-	Technology	BYTE	PowerOn			
-						
-	-	0	0	2	7/1	M

Description: Technology
0: no specific configuration
1: turning
2: milling
Also note MD 52201 \$MCS_TECHNOLOGY_EXTENSION.

52201	TECHNOLOGY_EXTENSION			-	-	
-	Extended technology			BYTE	PowerOn	
-						
-	-	0	0	2	7/1	M

Description: Extended technology
 0: no specific configuration
 1: turning
 2: milling
 Also note MD 52200 \$MCS_TECHNOLOGY.
 Example:
 Turning machine with milling technology
 MD 52200 \$MCS_TECHNOLOGY = 1
 MD 52201 \$MCS_TECHNOLOGY_EXTENSION = 2

52206	AXIS_USAGE			-	-	
-	Meaning of the axes in the channel			BYTE	PowerOn	
-						
-	20	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0	0	10	7/3	M

Description: Meaning of the axes in the channel
 0 = no special meaning
 1 = tool spindle (driven tool)
 2 = auxiliary spindle (driven tool)
 3 = main spindle (turning)
 4 = separate C axis of the main spindle (turning)
 5 = counterspindle (turning)
 6 = separate C axis of the counterspindle (turning)
 7 = linear axis of the counterspindle (turning)
 8 = tailstock (turning)
 9 = steady rest (turning)
 10 = B axis (turning)

52207	AXIS_USAGE_ATTRIB			-	-	
-	Axis attributes			DWORD	PowerOn	
-						
-	20	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0	-	-	7/3	M

Description: Axis attributes
 Bit 0: Rotates around 1st geometry axis (in the case of rotary axes)
 Bit 1: Rotates around 2nd geometry axis (in the case of rotary axes)
 Bit 2: Rotates around 3rd geometry axis (in the case of rotary axes)
 Bit 3: Displayed positive direction of rotation is counterclockwise (in the case of rotary axes)
 The rotary axes are always viewed in the negative geometry axis direction.
 In the case of turning machines, a spindle is always viewed from the interior.

Bit 4: Displayed direction of rotation for M3 is counterclockwise (in the case of spindles)

The viewing direction can be selected. Either viewed outward from the interior or from the outside toward the spindle.

However the same selection must be made for all spindles.

Bit 5: Direction of rotation M3 corresponds to minus rotary axis (in the case of spindles)

This bit must be set in the same way as PLC bit DBnn.DBX17.6!

(nn = 31 + machine axis index)

Bit 6: Display rotary axis as offset target for measuring

Bit 7: Offer rotary axis in position pattern

52210	FUNCTION_MASK_DISP	-	-			
-	Function mask Display	BYTE	PowerOn			
-						
-	-	3	-	-	7/3	M

Description:

Function mask, display

Bit 0: Measuring system for programs always in basic system

Bit 1: Front view for turning in school coordinate system

Bit 2: Hide "T,S,M" softkey in JOG area

Bit 3: Generate automatic end-of-program in MDI (with the "Delete blocks" softkey)

Bit 4: Show follow-on tool in T, F, S window

52212	FUNCTION_MASK_TECH	-	-			
-	Function mask Cross-technology	DWORD	Immediately			
-						
-	-	0	-	-	7/3	M

Description:

Function mask, all technologies

Bit 0: Enable swivel

Bit 1: No optimized travel along software limit switches

Bit 2: Startup logic for step drill (ShopTurn)

Bit 3: Call block search cycle for ShopMill/ShopTurn

Bit 4: Startup logic via cycle (ShopTurn)

Bit 5: Call block search cycle for SERUPRO

Bit 6: Work offset value ZV cannot be entered (ShopTurn)

Bit 7: Detect expiry of tool lives in the program (ShopMill/ShopTurn)

Bit 8: Reserved

Bit 9: Reserved

Bit 10: Reserved

Bit 11: Switch off layer check for drilling and milling tools (ShopTurn)

52214	FUNCTION_MASK_MILL	-	-			
-	Function mask Milling	DWORD	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Function mask Milling
 Bit 0: Enable cylinder surface transformation (ShopMill)
 Bit 1:reserved
 Bit 2:reserved
 Bit 3: Enable inside/rear machining
 Bit 4: Enable spindle clamping (C axis)

52216	FUNCTION_MASK_DRILL	-	-			
-	Function mask Drilling	DWORD	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Function mask Drilling
 Bit 0:CYCLE84 Unhide input fields Technology
 Bit 1:CYCLE840 Unhide input fields Technology

52218	FUNCTION_MASK_TURN	-	-			
-	Function mask Turning	BYTE	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Function mask Turning
 Bit 0: Enable zoom under manual for tool measurement
 Bit 1: Enable parts gripper for cut-off
 Bit 2: Enable tailstock
 Bit 3: Reserved
 Bit 4: Enable leadscrew of main spindle through surface
 Bit 5: Enable leadscrew of tool spindle through surface
 Bit 6: Enable balance cutting for dual-channel stock removal

52229	ENABLE_QUICK_M_CODES	-	-			
-	Enable fast M functions	BYTE	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Enable fast M functions
 Bit 0:Coolant OFF
 Bit 1:Coolant 1 ON
 Bit 2:Coolant 2 ON
 Bit 3:Coolant 1 and 2 ON

52230	M_CODE_ALL_COOLANTS_OFF	-	-			
-	M code for all coolants OFF	DWORD	Immediately			
-						
-	-	9	-1	32767	7/3	M

Description: M code for all coolants OFF

52231	M_CODE_COOLANT_1_ON	-	-			
-	M code for coolant 1 ON	DWORD	Immediately			
-						
-	-	8	-1	32767	7/3	M

Description: M code for coolant 1 ON

52232	M_CODE_COOLANT_2_ON	-	-			
-	M code for coolant 2 ON	DWORD	Immediately			
-						
-	-	7	-1	32767	7/3	M

Description: M code for coolant 2 ON

52233	M_CODE_COOLANT_1_AND_2_ON	-	-			
-	M code for both coolants ON	DWORD	Immediately			
-						
-	-	-1	-1	32767	7/3	M

Description: M code for coolant 1 + 2 ON

52240	NAME_TOOL_CHANGE_PROG	-	-			
-	Tool change program for G code steps	STRING	Immediately			
-						
-	-		-	-	7/3	M

Description: Tool change program for G code steps

52244	SUB_SPINDLE_PARK_POS_Y	-	-			
mm	Parking position of the Y axis with counterspindle	DOUBLE	Immediately			
-						
-	-	0	-	-	7/3	U

Description: Parking position of the Y axis with counterspindle

52248	REV_2_BORDER_TOOL_LENGTH	-	-			
mm	Limit value tool length X for 2nd turret	DOUBLE	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Limit value of tool length X for the 2nd turret:
Limit value = 0: only one turret available
Tool length X < limit value: tool belongs to 1st turret/multifix
Tool length X >= limit value: tool belongs to 2nd turret/multifix

52250	M_CODE_CHUCK_OPEN	-	-			
-	M code for Open chuck with non-rotating spindle	STRING	Immediately			
-						
-	2	-	-	-	7/3	M

Description: M code for Open chuck with non-rotating spindle.

Example: "M34" or "M1=34"

Elements:

[0]: Main spindle

[1]: Counterspindle

52251	M_CODE_CHUCK_OPEN_ROT	-	-			
-	M code for Open chuck with rotating spindle	STRING	Immediately			
-						
-	2	-	-	-	7/3	M

Description: M code for Open chuck with rotating spindle.
 Example: "M34" or "M1=34"
 Elements:
 [0]: Main spindle
 [1]: Counterspindle

52252	M_CODE_CHUCK_CLOSE	-	-			
-	M code for Close chuck	STRING	Immediately			
-						
-	2	-	-	-	7/3	M

Description: M code for Close chuck
 Example: "M34" or "M1=34"
 Elements:
 [0]: Main spindle
 [1]: Counterspindle

52260	MACHINE_JOG_INTERRUPT_Prio	-	-			
-	Priority for start ASUB under machine JOG	BYTE	Immediately			
-						
-	-	1	1	8	7/3	S

Description: Priority for start ASUB under machine JOG

52270	TM_FUNCTION_MASK	-	-			
-	Function mask Tool management	DWORD	PowerOn			
-						
-	-	0	-	-	7/3	M

Description: Function mask for tool management
 Bit 0:Create tool on magazine location not allowed. Tools can only be created outside the magazine.
 Bit 1:Load/unload disable, if machine is not in reset. Tools can only be loaded/unloaded, if the appropriate channel is in reset state.
 Bit 2:Load/unload disable on Emergency stop. Tools can only be loaded/unloaded, if Emergency stop is not active.
 Bit 3:Load/unload tool to/from spindle is disabled. Tools cannot be loaded to or unloaded from the spindle.
 Bit 4>Loading is executed directly in the spindle. Tools are loaded exclusively directly in the spindle.
 Bit 5:Use grinding configuration file for creating the tool lists. Only grinding tools are offered.
 Bit 6:Reserved
 Bit 7:Create tool using the tool number. Specify the tool's T number when creating the tool.
 Bit 8:Hide Relocate tool. The function 'Relocate tool' is hidden on the user interface.

Bit 9:Hide Position magazine. The function 'Position magazine' is hidden on the user interface.

Bit 10:Reactivate tool using Position magazine. Prior to reactivation, the tool is positioned on the loading position.

Bit 11:Reactivate tool in all monitoring modes. When reactivating a tool, all monitoring modes enabled in the NC are reactivated for this tool, even the monitoring modes, which have not been set for the relevant tool, but are available in the background only.

Bit 12:Hide Reactivate tool. The function 'Reactivate tool' is hidden on the user interface.

52274	TM_TOOL_LOAD_STATION	-	-			
-	Number of load station	BYTE	PowerOn			
-						
-	-	0	0	16	7/3	M

Description: Number of the loading station
0 = All configured stations are taken into account

52281	TOOL_MCODE_FUNC_ON	-	-			
-	M code for tool-specific function ON	DWORD	Immediately			
-						
-	4	-1, -1, -1, -1	-1	32767	7/3	M

Description: M code for tool-specific function ON
Value -1 means that the M function is not output. If both M commands of a function equal -1, the corresponding field will not be displayed in the user interface

52282	TOOL_MCODE_FUNC_OFF	-	-			
-	M code for tool-specific function OFF	DWORD	Immediately			
-						
-	4	-1, -1, -1, -1	-1	32767	7/3	M

Description: M code for tool-specific function OFF
Value -1 means that the M function is not output. If both M commands of a function equal -1, the corresponding field will not be displayed in the user interface

52290	SIM_DISPLAY_CONFIG	-	-			
-	Location of status display of the channel in the simulation (OP019 only)	BYTE	Immediately			
-						
-	-	0x0F	-	-	7/3	M

Description: Location of status display of the channel in the simulation
Only one of the 4 corners can be selected:
Bit 0 = Top left corner
Bit 1 = Top right corner
Bit 2 = Bottom left corner
Bit 3 = Bottom right corner
This MD is active only on the OP019.

52740	MEA_FUNCTION_MASK	-	-			
-	Functional behavior of third geometry axis (Y), turning technology	DWORD	Immediately			
-						
-	-	65536	-	-	7/3	M

Description: Function mask for measuring cycles
 Bit 0: Measurement input workpiece probe
 0: Workpiece probe at CNC measurement input 1, active - default
 1: Workpiece probe at CNC measurement input 2, active
 Bit 1: Workpiece measurement
 Functional behavior of a third geometry axis (Y axis) in turning technology on the basis of the working plane G18.
 0: An existing third geometry axis (Y axis, applicate) is not supported by the measuring cycles.
 1: Setpoint input and parameterization (SETVAL, _TUL, _TLL, SZO) relate to the third geometry axis (Y axis).
 However, the tool length or work offset is offset in the active components in the second geometry axis (X axis, ordinate)
 (that means measure in Y and offset in X). The offset target can be influenced with the parameter _KNUM.
 Bit16: Measurement input tool probe
 0: Tool probe at CNC measurement input 1, active
 1: Tool probe at CNC measurement input 2, active - default

52750	J_MEA_FIXPOINT	-	-			
mm	Z value for measuring fixed point	DOUBLE	Immediately			
-						
-	-	0	-	-	7/3	I

Description: Z value for measuring against fixed point

52751	J_MEA_MAGN_GLAS_POS	-	-			
mm	Zoom-in position for tool measurement	DOUBLE	Immediately			
-						
-	2	0	-	-	7/3	M

Description: Zoom-in position for tool measurement
 [0] = Position in the 1st axis
 [1] = Position in the 2nd axis

52800	ISO_M_ENABLE_POLAR_COORD	-	-			
-	Polar coordinates	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Polar coordinates
 0: OFF
 1: ON

52802	ISO_ENABLE_INTERRUPTS	-	-			
-	Interrupt process	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Interrupt process
0: OFF
1: ON

52804	ISO_ENABLE_DRYRUN	-	-			
-	Machining skipped at DRYRUN	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Maching skipped during tapping G74/G84 at DRYRUN
0: OFF
1: ON

52806	ISO_SCALING_SYSTEM	-	-			
-	Basic system	BYTE	Immediately			
-						
-	-	0	0	2	7/7	M

Description: Basic system:
0: not defined
1: METRIC
2: INCH

52808	ISO_SIMULTAN_AXES_START	-	-			
-	Simultaneous approach to the boring position on all programmed axes	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Simultaneous approach to the boring position on all programmed axes
0: OFF
1: ON

52810	ISO_T_DEEPHOLE_DRILL_MODE	-	-			
-	Deep hole drilling with chipbreaking/stock removal	BYTE	Immediately			
-						
-	-	0	0	1	7/3	M

Description: Select the type of deep hole drilling
0: deep hole drilling with chipbreaking
1: deep hole drilling with stock removal

53230	SIM_START_POSITION	-	-			
mm, degrees	Axis position at start of simulation	DOUBLE	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Axis position at start of simulation
Simulation is only possible if a value not equal to 0 has been set for at least one geometry axis.

53240	SPINDLE_PARAMETER	-	-			
mm, degrees	Spindle chuck data	DOUBLE	Immediately			
-						
-	3	0	-	-	7/3	U

Description: Spindle chuck data:
 [0]: Chuck dimension
 [1]: Stop dimension
 [2]: Jaw dimension

53241	SPINDLE_CHUCK_TYPE	-	-			
-	Spindle jaw type	BYTE	Immediately			
-						
-	-	0	-	-	7/3	U

Description: Spindle jaw type:
 0 = Clamping from outside
 1 = Clamping from inside

53242	TAILSTOCK_PARAMETER	-	-			
mm, degrees	Tailstock data	DOUBLE	Immediately			
-						
-	2	0	-	-	7/3	M

Description: Tailstock data:
 [0]: Tailstock diameter
 [1]: Tailstock length

54215	TM_FUNCTION_MASK_SET	-	-			
-	Function mask Tool management	DWORD	PowerOn			
-						
-	-	0	-	-	7/4	M

Description: Function mask, tool management

- Bit 0: Diameter display for rotary tools. It is not the radius value but the diameter that is displayed for rotary tools.
- Bit 1: Default direction of rotation for all turning tools is M4. Direction of rotation M4 is assigned by default when turning tools are created.
- Bit 2: Create tool without suggesting name.
- Bit 3: Input disable for tool name and tool type in the case of loaded tools. Once tools have been loaded, the tool name and the tool type cannot be changed.
- Bit 4: Input disable for loaded tools unless the channel is not in reset.
- Bit 5: Accrue tool wear entries additively. Tool wear data entries are added to the existing wear value.
- Bit 6: Entry of tool ID in numerical format. The tool ID may only be entered using numbers.
- Bit 7: Hide tool monitoring parameters. The tool monitoring parameters are hidden on the user interface.
- Bit 8: Diameter display for transverse axis geometry. The geometry value for the transverse axis is displayed as the diameter value.
- Bit 9: Diameter display for transverse axis wear. The wear value for the transverse axis is displayed as the diameter value.

54617	MEA_CAL_EDGE_PLUS_DIR_AX1	-	-
mm	Calibration groove edge in positive direction of the 1st measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove edge in positive direction of the 1st measuring axis (abscissa, Z at G18)
 This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54618	MEA_CAL_EDGE_MINUS_DIR_AX1	-	-
mm	Calibration groove edge in negative direction of the 1st measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove edge in negative direction of the 1st measuring axis (abscissa, Z at G18)
 This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54619	MEA_CAL_EDGE_BASE_AX2	-	-
mm	Calibration groove base of the 2nd measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove base of the 2nd measuring axis (ordinate, X at G18)
 This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54620	MEA_CAL_EDGE_UPPER_AX2	-	-
mm	Calibration groove upper edge of the 2nd measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove upper edge of the 2nd measuring axis (ordinate, X at G18)
 This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54621	MEA_CAL_EDGE_PLUS_DIR_AX2	-	-
mm	Calibration groove edge in positive direction of the 2nd measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove edge in positive direction of the 2nd measuring axis (ordinate, X at G18)
 This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54622	MEA_CAL_EDGE_MINUS_DIR_AX2	-	-
mm	Calibration groove edge in negative direction of the 2nd measuring axis	DOUBLE	Immediately
-			
-	3	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Calibration groove edge in negative direction of the 2nd measuring axis (ordinate, X at G18)
This parameter is a geometrical component of the calibration groove and must be supplied by the user!

54625	MEA_TP_TRIG_MINUS_DIR_AX1	-	-
mm	Trigger point of the 1st measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 1st measuring axis in negative direction (abscissa, X at G17, Z at G18)
The trigger point refers to the machine coordinate system (MCS).
Prior to calibration the approximate trigger point must be entered in the machine coordinate system!
The exact value of this parameter is created by the operation "Calibrate workpiece probe"!

54626	MEA_TP_TRIG_PLUS_DIR_AX1	-	-
mm	Trigger point of the 1st measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 1st measuring axis in positive direction (abscissa, X at G17, Z at G18)
The trigger point refers to the machine coordinate system (MCS).
Prior to calibration the approximate trigger point must be entered in the machine coordinate system!
The exact value of this parameter is created by the operation "Calibrate workpiece probe"!

54627	MEA_TP_TRIG_MINUS_DIR_AX2	-	-
mm	Trigger point of the 2nd measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 2nd measuring axis in negative direction (ordinate, Y at G17, X at G18)
The trigger point refers to the machine coordinate system (MCS).
Prior to calibration the approximate trigger point must be entered in the machine coordinate system!
The exact value of this parameter is created by the operation "Calibrate workpiece probe"!

54628	MEA_TP_TRIG_PLUS_DIR_AX2	-	-
mm	Trigger point of the 2nd measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 2nd measuring axis in positive direction (ordinate, Y at G17, X at G18)
 The trigger point refers to the machine coordinate system (MCS).
 Prior to calibration the approximate trigger point must be entered in the machine coordinate system!
 The exact value of this parameter is created by the operation "Calibrate workpiece probe"!

54629	MEA_TP_TRIG_MINUS_DIR_AX3	-	-
mm	Trigger point of the 3rd measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 3rd measuring axis in negative direction (applicate, Z at G17, Y at G18)
 The trigger point refers to the machine coordinate system (MCS).
 Prior to calibration the approximate trigger point must be entered in the machine coordinate system!
 The exact value of this parameter is created by the operation "Calibrate workpiece probe"!

54630	MEA_TP_TRIG_PLUS_DIR_AX3	-	-
mm	Trigger point of the 2nd measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 3rd measuring axis in positive direction (ordinate, Y at G17, X at G18)
 The trigger point refers to the machine coordinate system (MCS).
 Prior to calibration, the approximate trigger point must be entered in the machine coordinate system!
 The exact value of this parameter is created by the operation "Calibrate tool probe"!

54631	MEA_TP_EDGE_DISK_SIZE	-	-
mm	Tool probe edge length/wheel diameter	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	0 1000 7/7 U

Description: Effective edge length or grinding wheel diameter of the tool probe.
 Milling tools are normally measured with wheel-shaped probes while turning tools are measured with square probes.

54632	MEA_TP_AX_DIR_AUTO_CAL			-	-	
-	Automatic tool probe calibration, enable axes/directions			DWORD	Immediately	
-						
-	6	133,133,133,133,133, 133,133,133,133...	-	-	7/7	U

Description: Enabling axes and traversing directions for the "Automatic calibration" of milling tool probes in the machine coordinate system (MCS).
The default setting refers in X and Y to the plus and minus directions respectively, in Z only to the minus direction.
The parameter is divided into six components, the functions of which are assigned to calibration data records 1 to 6.
Meaning of the parameter components
Decimal position:
Units 1st geometry axis (X)
Tens: 2nd geometry axis (Y)
Hundreds: 3rd geometry axis (Z)
Value:
=0: axis not enabled
=1: only minus direction possible
=2: only plus direction possible
=3: both directions possible

54633	MEA_TP_TYPE			-	-	
-	Tool probe type cube / wheel			DOUBLE	Immediately	
-						
-	6	0,0,0,0,0,0,0,0,0,0,0	0	999	7/7	U

Description: Tool probe type
0: cube
101: wheel in XY, working plane G17
201: wheel in ZX, working plane G18
301: wheel in YZ, working plane G19

54634	MEA_TP_CAL_MEASURE_DEPTH			-	-	
mm	Distance between the upper tool probe edge and the lower milling tool edge			DOUBLE	Immediately	
-						
-	6	2,2,2,2,2,2,2,2,2,2,2	-1000	1000	7/7	U

Description: Distance between the upper tool probe edge and the lower milling tool edge.
For tool probe calibration this distance defines the calibration depth and for milling tool measuring the measuring depth!
This parameter does not apply to turning tool measuring!

54635	MEA_TP_STATUS_GEN			-	-	
-	Calibration status in general			DOUBLE	Immediately	
-						
-	6	0,0,0,0,0,0	-	-	7/7	U

Description: Calibration status general, reserved for internal use
The value of this parameter is assigned when the "Calibrate tool probe" procedure is executed.

54636	MEA_TP_FEED	-	-
mm/min	Trigger point of the 3rd measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	0 5000 7/7 U

Description: Measuring feed for tool probe calibration in WMCS
 This measuring feed is used for all subsequent tool measuring programs in conjunction with the probe field.

54640	MEA_TPW_TRIG_MINUS_DIR_AX1	-	-
mm	Trigger point of the 1st measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 1st measuring axis in negative direction (abscissa, X at G17, Z at G18)
 The trigger point refers to the workpiece coordinate system (WCS).
 Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
 The exact value of this parameter is created by the operation "Calibrate tool probe"!

54641	MEA_TPW_TRIG_PLUS_DIR_AX1	-	-
mm	Trigger point of the 1st measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 1st measuring axis in positive direction (abscissa, X at G17, Z at G18)
 The trigger point refers to the workpiece coordinate system (WCS).
 Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
 The exact value of this parameter is created by the operation "Calibrate tool probe"!

54642	MEA_TPW_TRIG_MINUS_DIR_AX2	-	-
mm	Trigger point of the 2nd measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 2nd measuring axis in negative direction (ordinate, Y at G17, X at G18)
 The trigger point refers to the workpiece coordinate system (WCS).
 Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
 The exact value of this parameter is created by the operation "Calibrate tool probe"!

54643	MEA_TPW_TRIG_PLUS_DIR_AX2	-	-
mm	Trigger point of the 2nd measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 2nd measuring axis in positive direction (ordinate, Y at G17, X at G18)
The trigger point refers to the workpiece coordinate system (WCS).
Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
The exact value of this parameter is created by the operation "Calibrate tool probe"!

54644	MEA_TPW_TRIG_MINUS_DIR_AX3	-	-
mm	Trigger point of the 3rd measuring axis in negative direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 3rd measuring axis in negative direction (applicate, Z at G17, Y at G18)
The trigger point refers to the workpiece coordinate system (WCS).
Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
The exact value of this parameter is created by the operation "Calibrate tool probe"!

54645	MEA_TPW_TRIG_PLUS_DIR_AX3	-	-
mm	Trigger point of the 3rd measuring axis in positive direction	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-100000 100000 7/7 U

Description: Trigger point of the 3rd measuring axis in positive direction (applicate, Z at G17, Y at G18)
The trigger point refers to the workpiece coordinate system (WCS).
Prior to calibration the approximate trigger point must be entered in the workpiece coordinate system!
The exact value of this parameter is created by the operation "Calibrate tool probe"!

54646	MEA_TPW_EDGE_DISK_SIZE	-	-
mm	Tool probe edge length/wheel diameter	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	0 1000 7/7 U

Description: Effective edge length or grinding wheel diameter of the tool probe.
Milling tools are normally measured with wheel-shaped probes while turning tools are measured with square probes.

54647	MEA_TPW_AX_DIR_AUTO_CAL	-	-
-	Automatic tool probe calibration, enable axes/directions	DWORD	Immediately
-			
-	6	133,133,133,133,133, 133,133,133,133...	-
			7/7 U

Description: Enabling axes and traversing directions for "Automatic calibration" in the workpiece coordinate system (WCS) of milling tool probes.
 The default setting refers in X and Y to the plus and minus direction respectively, in Z only to the minus direction.
 The parameter is divided into six components, the functions of which are assigned to calibration data records 1 to 6.
 Meaning of the parameter components
 Decimal position:
 Units 1st geometry axis (X)
 Tens: 2nd geometry axis (Y)
 Hundreds: 3rd geometry axis (Z)
 Value:
 =0: axis not enabled
 =1: only minus direction possible
 =2: only plus direction possible
 =3: both directions possible

54648	MEA_TPW_TYPE	-	-
-	Tool probe type cube / wheel	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0,0,0,0,0,0	-
			7/7 U

Description: Tool probe type
 0: cube
 101: wheel in XY, working plane G17
 201: wheel in ZX, working plane G18
 301: wheel in YZ, working plane G19

54649	MEA_TPW_CAL_MEASURE_DEPTH	-	-
mm	Distance between the upper tool probe edge and the lower milling tool edge	DOUBLE	Immediately
-			
-	6	2,2,2,2,2,2,2,2,2,2	0
		999	7/7 U

Description: Distance between the upper tool probe edge and the lower milling tool edge.
 For tool probe calibration this distance defines the calibration depth and for milling tool measuring the measuring depth!
 This parameter does not apply to turning tool measuring!

54650	MEA_TPW_STATUS_GEN	-	-
-	Calibration status in general	DOUBLE	Immediately
-			
-	6	0,0,0,0,0,0	-
			7/7 U

Description: Calibration status general, reserved for internal use
 The value of this parameter is assigned when the "Calibrate tool probe" procedure is executed.

54651	MEA_TPW_FEED	-	-			
mm/min	Trigger point of the 3rd measuring axis in positive direction	DOUBLE	Immediately			
-						
-	6	0,0,0,0,0,0,0,0,0,0,0	0	5000	7/7	U

Description: Measuring feed for tool probe calibration in WCS
This measuring feed is used for all subsequent tool measuring programs in conjunction with the probe field.

54652	MEA_INPUT_TOOL_PROBE_SUB	-	-			
-	Tool probe available/active on the counterspindle	BYTE	Immediately			
-						
-	6	0,0,0,0,0,0	0	11	7/2	I

Description: CNC measurement input for tool probe with reference to the counterspindle
`$(S)SNS_MEA_INPUT_TOOL_PROBE_SUB[[n]`
 =0: Toolsetter no.= n+1, with reference to the main spindle,
 CNC measurement input corresponds to the value of
`$(M)MCS_MEA_FUNCTION_MASK`, bit16
 (Input values 1 to 9 have the same functional effect as input 0!)
 =10: Toolsetter no.= n+1, with reference to the counterspindle,
 units digit =0 corresponds to CNC measurement input 1
 =11: Toolsetter no.= n+1, with reference to the counterspindle,
 units digit =1 corresponds to CNC measurement input 2

54670	MEA_CM_MAX_PERI_SPEED	-	-			
m/min	Max. permissible peripheral speed of the tool to be measured	DOUBLE	Immediately			
-						
-	2	100,100	0	100000	7/7	U

Description: Max. permissible peripheral speed of the tool to be measured when the spindle rotates.
Monitoring parameter for tool measuring with rotating spindle
only effective with SD54749 `$(S)SNS_MEA_FUNCTION_MASK_TOOL`, Bit 10 = 0!

54671	MEA_CM_MAX_REVOLUTIONS	-	-			
rev/min	Maximum tool speed for tool measuring	DOUBLE	Immediately			
-						
-	2	1000,1000	0	100000	7/7	U

Description: Max. permissible tool speed for tool measuring with rotating spindle.
The speed is automatically reduced when this value is exceeded.
Monitoring parameter for tool measuring with rotating spindle
only effective with SD54749 `$(S)SNS_MEA_FUNCTION_MASK_TOOL`, Bit 10 = 0!

54672	MEA_CM_MAX_FEEDRATE	-	-			
mm/min	Maximum feed for contact of the tool with the probe	DOUBLE	Immediately			
-						
-	2	20,20	0	100000	7/7	U

Description: Max. permissible feed for contact of the tool to be measured with the probe when the spindle rotates.
Monitoring parameter for tool measuring with rotating spindle
only effective with SD54749 `$(S)SNS_MEA_FUNCTION_MASK_TOOL`, Bit 10 = 0!

54673	MEA_CM_MIN_FEEDRATE	-	-			
mm/min	Minimum feed for 1st contact of the tool with the probe	DOUBLE	Immediately			
-						
-	2	1,1	0	100000	7/7	U

Description: Min. feed for first contact of the tool to be measured with the probe when the spindle rotates.
 Too small feeds for large tool radii are thus avoided!
 Monitoring parameter for tool measuring with rotating spindle
 only effective with SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 10 = 0!

54674	MEA_CM_SPIND_ROT_DIR	-	-			
-	Direction of spindle rotation for tool measuring	DOUBLE	Immediately			
-						
-	2	4,4	3	4	7/7	U

Description: Direction of spindle rotation for tool measuring with rotating spindle (default: 4 = M4)
 Notice: if the spindle is already rotating when the measuring cycle is called, the direction of rotation is maintained
 independently of \$SNS_MEA_CM_SPIND_ROT_DIR!
 Monitoring parameter for tool measuring with rotating spindle
 only effective with SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 10 = 0!

54675	MEA_CM_FEEDFACTOR_1	-	-			
-	Feedrate factor 1, for tool measuring	DOUBLE	Immediately			
-						
-	2	10,10	-	-	7/7	U

Description: Feedrate factor 1, for tool measuring with rotating spindle
 =0: single probing with the feedrate calculated by the cycle (but at least with the value of \$SNS_MEA_CM_MIN_FEEDRATE)
 >=1: first probing with calculated feedrate (but at least with the value of \$SNS_MEA_CM_MIN_FEEDRATE).
 Monitoring parameter for tool measuring with rotating spindle
 only effective with SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 10 = 0!

54676	MEA_CM_FEEDFACTOR_2	-	-			
-	Feedrate factor 2, for tool measuring	DOUBLE	Immediately			
-						
-	2	0,0	-	-	7/7	U

Description: Feedrate factor 2, for tool measuring with rotating spindle
 =0: second probing with the feedrate calculated by the cycle (only effective with MEA_CM_FEEDFACTOR_1 > 0)
 >=1: second probing with calculated feedrate, feedrate factor 2
 Third probing with calculated feedrate (tool speed is influenced by SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 12)
 Notice: - Feedrate factor 2 should be smaller than feedrate factor 1!
 - If the value of feedrate factor 2 is 0, a third probing will not be performed!
 Monitoring parameter for tool measuring with rotating spindle
 only effective with SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 10 = 0!

54677	MEA_CM_MEASURING_ACCURACY	-	-			
mm	Required measuring accuracy, for tool measuring	DOUBLE	Immediately			
-						
-	2	0.005,0.005	0	100000	7/7	U

Description: Required measuring accuracy for tool measuring
The value of this parameter always refers to the last contact of the tool with the probe!
Monitoring parameter for tool measuring with rotating spindle
only effective with SD54749 \$SNS_MEA_FUNCTION_MASK_TOOL, Bit 10 = 0!

54689	MEA_T_PROBE_MANUFACTURER	-	-			
-	Tool probe type (manufacturer)	BYTE	Immediately			
-						
-	-	0	0	2	7/5	U

Description: Tool probe type (manufacturer)
These indications are required for tool measuring with rotating spindle.
=0: no indication
=1: TT130 (Heidenhain)
=2: TS27R (Renishaw)

54691	MEA_T_PROBE_OFFSET	-	-			
-	Measurement result offset for tool measuring	BYTE	Immediately			
-						
-	-	0	0	2	7/5	U

Description: Measurement result offset for tool measuring with rotating spindle.
=0: no offset
=1: cycle-internal offset (only effective with SD54690
\$SNS_MEA_T_PROBE_MANUFACTURER<>0)
=2: offset through user-defined offset table

54695	MEA_RESULT_OFFSET_TAB_RAD1	-	-			
mm	Offset table (measure tool radius with rotating spindle)	DOUBLE	Immediately			
-						
-	5	0,0,0,0,0	-	-	7/5	U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle
\$SNS_MEA_RESULT_OFFSET_TAB_RAD1[0] ... this element always has value ZERO
\$SNS_MEA_RESULT_OFFSET_TAB_RAD1[1] ... 1st tool radius
\$SNS_MEA_RESULT_OFFSET_TAB_RAD1[2] ... 2nd tool radius
\$SNS_MEA_RESULT_OFFSET_TAB_RAD1[3] ... 3rd tool radius
\$SNS_MEA_RESULT_OFFSET_TAB_RAD1[4] ... 4th tool radius

54696	MEA_RESULT_OFFSET_TAB_RAD2	-	-
mm	Offset table 1st peripheral speed (radius)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_RAD2[0] ... 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD2[1] ... offset value for radius regarding 1st radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD2[2] ... offset value for radius regarding 2nd radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD2[3] ... offset value for radius regarding 3rd radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD2[4] ... offset value for radius regarding 4th radius and 1st peripheral speed

54697	MEA_RESULT_OFFSET_TAB_RAD3	-	-
mm	Offset table 2nd peripheral speed (radius)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_RAD3[0] ... 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD3[1] ... offset value for radius regarding 1st radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD3[2] ... offset value for radius regarding 2nd radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD3[3] ... offset value for radius regarding 3rd radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD3[4] ... offset value for radius regarding 4th radius and 2nd peripheral speed

54698	MEA_RESULT_OFFSET_TAB_RAD4	-	-
mm	Offset table 3rd peripheral speed (radius)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_RAD4[0] ... 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD4[1] ... offset value for radius regarding 1st radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD4[2] ... offset value for radius regarding 2nd radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD4[3] ... offset value for radius regarding 3rd radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD4[4] ... offset value for radius regarding 4th radius and 3rd peripheral speed

54699	MEA_RESULT_OFFSET_TAB_RAD5	-	-
mm	Offset table 4th peripheral speed (radius)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	-
			7/5
			U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_RAD5[0] ... 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD5[1] ... offset value for radius regarding 1st radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD5[2] ... offset value for radius regarding 2nd radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD5[3] ... offset value for radius regarding 3rd radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD5[4] ... offset value for radius regarding 4th radius and 4th peripheral speed

54700	MEA_RESULT_OFFSET_TAB_RAD6	-	-
mm	Offset table 5th peripheral speed (radius)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	-
			7/5
			U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_RAD6[0] ... 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD6[1] ... offset value for radius regarding 1st radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD6[2] ... offset value for radius regarding 2nd radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD6[3] ... offset value for radius regarding 3rd radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_RAD6[4] ... offset value for radius regarding 4th radius and 5th peripheral speed

54705	MEA_RESULT_OFFSET_TAB_LEN1	-	-
mm	Offset table (measure tool length with rotating spindle)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	-
			7/5
			U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN1[0] ... this element always has value ZERO
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN1[1] ... 1st tool radius
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN1[2] ... 2nd tool radius
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN1[3] ... 3rd tool radius
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN1[4] ... 4th tool radius

54706	MEA_RESULT_OFFSET_TAB_LEN2	-	-
mm	Offset table 1st peripheral speed (length)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN2[0] ... 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN2[1] ... offset value for radius regarding 1st radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN2[2] ... offset value for radius regarding 2nd radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN2[3] ... offset value for radius regarding 3rd radius and 1st peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN2[4] ... offset value for radius regarding 4th radius and 1st peripheral speed

54707	MEA_RESULT_OFFSET_TAB_LEN3	-	-
mm	Offset table 2nd peripheral speed (length)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN3[0] ... 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN3[1] ... offset value for radius regarding 1st radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN3[2] ... offset value for radius regarding 2nd radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN3[3] ... offset value for radius regarding 3rd radius and 2nd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN3[4] ... offset value for radius regarding 4th radius and 2nd peripheral speed

54708	MEA_RESULT_OFFSET_TAB_LEN4	-	-
mm	Offset table 3rd peripheral speed (length)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN4[0] ... 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN4[1] ... offset value for radius regarding 1st radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN4[2] ... offset value for radius regarding 2nd radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN4[3] ... offset value for radius regarding 3rd radius and 3rd peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN4[4] ... offset value for radius regarding 4th radius and 3rd peripheral speed

54709	MEA_RESULT_OFFSET_TAB_LEN5	-	-
mm	Offset table 4th peripheral speed (length)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN5[0] ... 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN5[1] ... offset value for radius regarding 1st radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN5[2] ... offset value for radius regarding 2nd radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN5[3] ... offset value for radius regarding 3rd radius and 4th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN5[4] ... offset value for radius regarding 4th radius and 4th peripheral speed

54710	MEA_RESULT_OFFSET_TAB_LEN6	-	-
mm	Offset table 5th peripheral speed (length)	DOUBLE	Immediately
-			
-	5	0,0,0,0,0	- - 7/5 U

Description: Parameter for user-defined measurement result offset for tool measuring with rotating spindle

\$SNS_MEA_RESULT_OFFSET_TAB_LEN6[0] ... 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN6[1] ... offset value for radius regarding 1st radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN6[2] ... offset value for radius regarding 2nd radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN6[3] ... offset value for radius regarding 3rd radius and 5th peripheral speed
 \$SNS_MEA_RESULT_OFFSET_TAB_LEN6[4] ... offset value for radius regarding 4th radius and 5th peripheral speed

54740	MEA_FUNCTION_MASK	-	-
-	Function mask for measuring cycles	DWORD	Immediately
-			
-	-	8	-
-	-	-	-
-	-	-	7/5 U

Description:

Function mask for measuring cycles

Bit 0: Repeat of workpiece measurement after exceeding the measuring difference (parameter `_TDIF`) and/or safe area (parameter `_TSA`)

0: The measurement is not repeated if the measuring difference and/or safe area is exceeded. A corresponding alarm, which can be acknowledged by "RESET", is displayed.

1: The measurement is repeated a maximum of 4 times if the measuring difference and/or safe area is exceeded.

Bit 1: Repeat of workpiece measurement with alarm and cycle stop at M0

If bit 0 of SD54740 `$_SNS_MEA_FUNCTION_MASK` is set to "1", then the following behavior can be selected with this bit:

0: No alarm, no M0 in the repeat measurements

1: The NC command "M0" is generated in each repeat measurement, and the repeat must be started with NC START.

The corresponding alarm, which can be acknowledged by "NC START", is displayed for each of the repeat measurements

Bit 2: Workpiece measurement: M0 with tolerance alarms 62304 oversize, 62305 undersize, 62306 permissible measuring difference exceeded

0: M0 is not generated in the event of the alarms 62304 "oversize", 62305 "undersize" or 62306 "permissible measuring difference exceeded".

These alarms do not interrupt the program execution, there is just a display!

1: The NC command "M0" is generated when these alarms occur.

Bit 3: Accept calibrated workpiece probe radius in the tool data.

This parameter refers functionally only to CYCLE976.

0: Calibrated workpiece probe radius not accepted in the tool data

1: With the calibration variant "with probe ball calculation", the determined "effective probe ball diameter" (54600 `$_SNS_MEA_WP_BALL_DIAM`)

is converted to a radius value, and entered in the tool radius geometry memory of the active workpiece probe.

Bit16: Repeat measurement of the tool after exceeding the measuring difference (parameter `_TDIF`) and/or safe area (parameter `_TSA`)

0: The measurement is not repeated if the measuring difference and/or safe area is exceeded. A corresponding alarm, which can be acknowledged by "RESET", is displayed.

1: The measurement is repeated a maximum of 4 times if the measuring difference and/or safe area is exceeded.

Bit17: Repeat of tool measurement with alarm and cycle stop at M0

If bit 16 of SD54740 `$_SNS_MEA_FUNCTION_MASK` is set to "1", then the following behavior can be selected with this bit:

0: No alarm, no M0 in the repeat measurements

1: The NC command "M0" is generated in each repeat measurement, and the repeat must be started with NC START.

The corresponding alarm, which can be acknowledged by "NC START", is displayed for each of the repeat measurements

Bit 18: Tool measurement: M0 after exceeding the permissible measuring difference

0: M0 is not generated in the event of alarm 62306 "permissible measuring difference exceeded".

This alarm does not interrupt the program execution, there is just a display!

1: The NC command "M0" is generated if this alarm occurs.

Bit19: Tool measuring milling machine: spindle speed reduction during last touching

0: Last touching without spindle speed reduction

1: Last touching with spindle speed reduction

54750	MEA_ALARM_MASK	-	-			
-	Expert mode for cycle alarms	DWORD	Immediately			
-						
-		0	-	-	7/5	U

Description:

Bit 0-7 workpiece measurement

Bit 0 =1 alarms with cycle-internal states and codings are displayed (expert mode)!

Bit 1-7 reserved

Bit 8-16 tool measuring

Bit 0-7 reserved

54760	MEA_FUNCTION_MASK_PIECE	-	-			
-	Setting f. input screen, measuring cycles in Automatic, workpiece measuring	DWORD	Immediately			
-						
-		514	-	-	7/5	U

Description:

Setting for input mask, Measuring cycles in Automatic, Workpiece measurement

Bit3 Enable selection of probe calibration data field

Bit4 Select Calibrate Input Measuring feed (VMS) 1)

Bit6 Enable selection of WO compensation in basic reference (SETFRAME)

Bit7 Enable selection of WO compensation in channel-specific basic frame

Bit8 Enable selection of WO compensation in global basic frame

Bit9 Enable selection of WO compensation in settable basic frame

Bit10 Enable selection of WO compensation coarse and fine

Bit11 Select Tool offset Geometry and wear

Bit12 Select Tool offset Not inverted and inverted

Bit13 Select Tool offset L1, R or L1, L2, L3 R

Bit14 Select Tool offset Work offset (_TZL)

Bit15 Select Tool offset Dimensional difference check (_TDIF)

Bit18 Select Number of measurements (_NMSP)

Bit19 Select Offset with averaging (_TMV) 1)

Bit20 Select Empirical values (_EVNUM)

Bit21 Select Additive setup offset

Bit22 Select Calibrate to unknown or known center point

Bit24Select Calibrate with / without positional deviation
 If WO compensation bit 6..10 is not selected, then offer "Measure only".
 If WO compensation bit 6..10 is selected, then always also offer compensation in active WO in the input screen
 For averaging, display the following parameters: _K_TMV, _EVNUM
 1) Input measuring feed applies to Automatic and JOG

54762	MEA_FUNCTION_MASK_TOOL	-	-
-	Setting for input screen, measuring cycles in Automatic, tool measuring	DWORD	Immediately
-			
-	-	0	-
			7/5 U

Description: Setting for input mask, Measuring cycles in Automatic, Tool measurement
 54762 MEA_FUNCTION_MASK_TOOL
 Bit3 Enable selection of tool probe calibration data field
 Bit4 Select Calibrate Input Measuring feed (VMS) 1)
 Bit5 Select Input Feed and spindle speeds for contacting
 Bit7 Select Measure in MCS and WCS
 Bit8 Select Measure absolute and incremental
 Bit9 Select Tool offset Geometry and wear
 Bit12Select Number of measurements (_NMSP)
 Bit13Select Empirical values (_EVNUM)
 1) Measuring feed input applies to Automatic and JOG

54764	MEA_FUNCTION_MASK_TURN	-	-
-	Setting for input mask, Measuring cycles in Automatic, Workpiece turning	DWORD	Immediately
-			
-	-	0	-
			7/5 U

Description: 54764 MEA_FUNCTION_MASK_TURN
 Setting for input mask, Measuring cycles Turning in Automatic
 Bit0 Measure inside/outside diameter with reversal
 Bit1 Measure inside/outside diameter "travel under turning center"?

54780	J_MEA_FUNCTION_MASK_PIECE	-	-
-	Setting for input screen, Measure in JOG, workpiece measurement	DWORD	Immediately
-			
-	-	512	-
			7/5 U

Description: 54780 J_MEA_FUNCTION_MASK_PIECE

54782	J_MEA_FUNCTION_MASK_TOOL	-	-
-	Setting for input screen, Measure in JOG, workpiece measurement	DWORD	Immediately
-			
-	-	0	-
			7/5 U

Description: Setting for input mask Measure in JOG, Tool measurement
 Bit2 Enable automatic tool measurement
 Bit3 Enable selection of tool probe calibration data field

55200	MAX_INP_FEED_PER_REV	-	-			
mm/rev	Upper limit feedrate/rev	DOUBLE	Immediately			
-						
-	-	1	0	5	7/4	M

Description: Feedrate input upper limit for mm/rev

55201	MAX_INP_FEED_PER_TIME	-	-			
mm/min	Upper limit feedrate/min	DOUBLE	Immediately			
-						
-	-	10000	0	100000	7/4	M

Description: Feedrate input upper limit for mm/min

55202	MAX_INP_FEED_PER_TOOTH	-	-			
mm	Upper limit feedrate/tooth	DOUBLE	Immediately			
-						
-	-	1	0	2	7/4	M

Description: Feedrate input upper limit for mm/tooth

55212	FUNCTION_MASK_TECH_SET	-	-			
-	Function mask Cross-technology	BYTE	Immediately			
-						
-	-	6	-	-	7/4	M

Description: Function mask Cross-technology
 Bit 0: Tool preselection active
 Bit 1: Calculate thread depth from thread pitch
 Bit 2: Refer to Table for thread diameter and depth

55214	FUNCTION_MASK_MILL_SET	-	-			
-	Function mask Milling	DWORD	Immediately			
-						
-	-	5	-	-	7/4	M

Description: Function mask Milling
 Bit 0: Default setting - milling cycles with synchronous operation
 Bit 2: Depth calculation in milling cycles without parameter SC

55216	FUNCTION_MASK_DRILL_SET	-	-			
-	Function mask Drilling	DWORD	Immediately			
-						
-	-	24	-	-	7/4	M

Description: Function mask Drilling
 Bit 0:tapping CYCLE84: reverse the direction of spindle rotation in the cycle
 Bit 1: -boring CYCLE86: consider rotation of the tool plane when positioning the spindle
 Bit 2: -boring CYCLE86: consider swiveled table kinematics when positioning the spindle (tool carrier)
 Bit 3:tapping CYCLE84: monitoring machine data 31050 and 31060 of the spindle
 Bit 4:tapping CYCLE840: monitoring machine data 31050 and 31060 of the spindle
 Bit 5:tapping CYCLE84: calculation of the brake point at G33

55218	FUNCTION_MASK_TURN_SET	-	-			
-	Function mask Turning	DWORD	Immediately			
-						
-	-	1	-	-	7/4	M

Description: Function mask Turning
 Bit 0: new thread table during thread cutting
 Bit 1:reserved (CYCLE93)
 Bit 2:reserved (CYCLE93)

55220	FUNCTION_MASK_MILL_TOL_SET	-	-			
-	Function mask High Speed Settings CYCLE832	DWORD	Immediately			
-						
-	-	0	-	-	7/5	M

Description: Function mask High Speed Settings CYCLE832
 Bit 0: Display input fields technology
 Bit 1: Settings as agreed in the following setting data:
 \$SCS_MILL_TOL_FACTOR_NORM
 \$SCS_MILL_TOL_FACTOR_ROUGH
 \$SCS_MILL_TOL_FACTOR_SEMIFIN
 \$SCS_MILL_TOL_FACTOR_FINISH
 \$SCS_MILL_TOL_VALUE_NORM
 \$SCS_MILL_TOL_VALUE_ROUGH
 \$SCS_MILL_TOL_VALUE_SEMIFIN
 \$SCS_MILL_TOL_VALUE_FINISH

55221	FUNCTION_MASK_SWIVEL_SET	-	-			
-	Function mask Swivel CYCLE800	DWORD	Immediately			
-						
-	-	0	-	-	7/3	M

Description: Function mask Swivel CYCLE800
 Bit 0: Display input field "No swivel"
 Bit 1: =0: Retract Z or retract Z XY
 =1: Retract to fixed position 1 or 2
 Bit 2: Allow selection "Deselection" of the swivel data block
 Bit 3: Show active swivel plane under Swivel in JOG
 The settings of the Swivel function mask affect all swivel data records.
 Bit 4: =0: Optimized positioning in basic position (pole position) of the kinematics
 =1: Compatibility

55230	CIRCLE_RAPID_FEED	-	-			
mm/min	Positional feed on circular paths	DOUBLE	Immediately			
-						
-	-	10000	100	100000	7/4	M

Description: Rapid traverse feedrate in mm/min for positioning on circle path

55231	MAX_INP_RANGE_GAMMA	-	-			
degrees	Maximum input area alignment angle gamma	DOUBLE	Immediately			
-						
-	-	5	0	90	7/4	M

Description: Maximum input area alignment angle gamma

55232	SUB_SPINDLE_REL_POS	-	-			
mm	Retract position Z for counterspindle	DOUBLE	Immediately			
-						
-	-	0	-	-	7/4	M

Description: Z retraction position for the counterspindle

55260	MAJOG_SAFETY_CLEARANCE	-	-			
mm	Safety clearance for machine JOG	DOUBLE	Immediately			
-						
-	-	1	-	-	7/4	M

Description: Safety clearance for machine JOG

55261	MAJOG_RELEASE_PLANE	-	-			
mm	Retraction plane for machine JOG	DOUBLE	Immediately			
-						
-	-	100	-	-	7/4	M

Description: Retraction plane for machine JOG

55410	MILL_SWIVEL_ALARM_MASK	-	-			
-	Hide and unhide cycle alarms for CYCLE800	DWORD	Immediately			
-						
-	-	0	-	-	7/5	M

Description: Hide and unhide cycle alarms CYCLE800
 Bit 0: error analysis 62186 - active work offset G%4 and base (base relation) include rotations
 Bit 1: error analysis 62187 - active base and base relation (G500) include rotations

55441	MILL_TOL_FACTOR_ROUGH	-	-			
-	Rotary axes tolerance factor for roughing CYCLE832 of G group 59	DOUBLE	Immediately			
-						
-	-	10	0	1000	7/5	U

Description: Rotary axes tolerance factor for roughing CYCLE832 of G group 59

55442	MILL_TOL_FACTOR_SEMIFIN	-	-			
-	Rotary axes tolerance factor for prefinishing CYCLE832 of G group 59	DOUBLE	Immediately			
-						
-	-	10	0	1000	7/5	U

Description: Rotary axes tolerance factor for prefinishing CYCLE832 of G group 59

55443	MILL_TOL_FACTOR_FINISH	-	-			
-	Rotary axes tolerance factor for finishing CYCLE832 of G group 59	DOUBLE	Immediately			
-						
-	-	10	0	1000	7/5	U

Description: Rotary axes tolerance factor for finishing CYCLE832 of G group 59

55446	MILL_TOL_VALUE_ROUGH	-	-			
mm	Tolerance value for roughing CYCLE832 (High Speed Settings)	DOUBLE	Immediately			
-						
-	-	0.1	0	10	7/5	U

Description: Tolerance value for roughing CYCLE832

55447	MILL_TOL_VALUE_SEMIFIN	-	-			
mm	Tolerance value for smooth-finishing CYCLE832 (High Speed Settings)	DOUBLE	Immediately			
-						
-	-	0.05	0	10	7/5	U

Description: Tolerance value for prefinishing CYCLE832

55448	MILL_TOL_VALUE_FINISH	-	-			
mm	Tolerance value for finishing CYCLE832 (High Speed Settings)	DOUBLE	Immediately			
-						
-	-	0.01	0	10	7/5	U

Description: Tolerance value for finishing CYCLE832

55460	MILL_CONT_INITIAL_RAD_FIN	-	-			
mm	Contour pocket milling: approach circle radius finishing	DOUBLE	Immediately			
-						
-	-	0	0	100	7/4	M

Description: This data affects the radius of the approach circle during contour pocket finishing.
 0: the radius is selected to maintain a safety clearance to the finishing allowance in the starting point.
 >0: the radius is selected to maintain the value of this setting data to the finishing allowance in the starting point.

55481	DRILL_TAPPING_SET_GG12	-	-			
-	Setting tapping G group 12: block change behavior at exact stop	DOUBLE	Immediately			
-						
-	2	0	0	3	7/4	M

Description: Settings for tapping G group 12 cycle CYCLE84 and CYCLE840:
 G group 12: block change behavior at exact stop (G60)

55482	DRILL_TAPPING_SET_GG21	-	-			
-	Setting tapping G group 21: acceleration profile	DOUBLE	Immediately			
-						
-	2	0	0	3	7/4	M

Description: Settings for tapping G group 21 cycle CYCLE84
G group 21: acceleration profile (SOFT, BRISK, ...)

55483	DRILL_TAPPING_SET_GG24	-	-			
-	Setting tapping G group 24: precontrol	DOUBLE	Immediately			
-						
-	2	0	0	2	7/4	M

Description: Settings for tapping G group 24 cycle CYCLE84 and CYCLE840:
G group 24: precontrol (FFWON, FFWOF)

55484	DRILL_TAPPING_SET_MC	-	-			
-	Setting tapping: spindle operation at MCALL	DOUBLE	Immediately			
-						
-	2	0	0	1	7/4	M

Description: Setting for tapping cycle CYCLE84 spindle operation at MCALL
0= reactivate spindle operation at MCALL
1= maintain position-controlled spindle operation at MCALL

55489	DRILL_MID_MAX_ECCENT	-	-			
mm	Max. center offset f. center boring	DOUBLE	Immediately			
-						
-	-	0.5	0	10	7/4	M

Description: Maximum center offset for center boring

55490	DRILL_SPOT_DIST	-	-			
mm	Preboring depth drill and thread milling	DOUBLE	Immediately			
-						
-	-	1	0	100	7/4	M

Description: Preboring depth for drill and thread milling

55500	TURN_FIN_FEED_PERCENT	-	-			
%	Roughing feedrate for complete machining in %	BYTE	Immediately			
-						
-	-	100	1	100	7/4	M

Description: When selecting Complete machining (roughing and finishing), the percentage of the entered feedrate F as specified in this setting data is used for finishing.

55505	TURN_ROUGH_O_RELEASE_DIST	-	-			
mm	Return distance stock removal for external machining	DOUBLE	Immediately			
-						
-	-	1	-1	100	7/4	M

Description: This setting data defines the distance by which the tool is returned from the contour during stock removal of an outer corner. This does not apply to stock removal of a contour.
 -1: the distance is specified internally.

55506	TURN_ROUGH_I_RELEASE_DIST	-	-			
mm	Return distance stock removal for internal machining	DOUBLE	Immediately			
-						
-	-	0.5	-1	100	7/4	M

Description: This setting data defines the distance by which the tool is returned from the contour during stock removal of an inner corner. This does not apply to stock removal of a contour.
 -1: the distance is specified internally.

55510	TURN_GROOVE_DWELL_TIME	-	-			
s	Tool clearance time for grooving at the base (neg. value=rotations)	DOUBLE	Immediately			
-						
-	-	-1	-100	100	7/4	M

Description: If a tool clearance time occurs in a cycle, e.g. deep hole drilling, grooving, the value of this setting data is used

- negative value in spindle revolutions
- positive value in seconds

55540	TURN_PART_OFF_CTRL_DIST	-	-			
mm	Path for cut-off check	DOUBLE	Immediately			
-						
-	-	0.1	0	10	7/4	M

Description: Path for cut-off check

55541	TURN_PART_OFF_CTRL_FEED	-	-			
mm/min	Feedrate for cut-off check	DOUBLE	Immediately			
-						
-	-	0	-	-	7/4	M

Description: Feedrate for cut-off check

55542	TURN_PART_OFF_CTRL_FORCE	-	-			
%	Force for cut-off check in %	DOUBLE	Immediately			
-						
-	-	10	1	100	7/4	M

Description: Force in percent for cut-off check

55543	TURN_PART_OFF_RETRACTION	-	-			
mm	Retraction path prior to cut-off with counterspindle	DOUBLE	Immediately			
-						
-	-	0	0	1	7/4	M

Description: Retraction path prior to cut-off with counterspindle

55550	TURN_FIXED_STOP_DIST	-	-			
mm	Counterspindle: path for travel to fixed stop	DOUBLE	Immediately			
-						
-	-	10	0.001	1000	7/4	M

Description: In this setting data you specify the distance to the programmed target position, after which the counterspindle travels with a special feedrate during travel to fixed stop (see 55551 \$SCS_TURN_FIXED_STOP_FEED).

55551	TURN_FIXED_STOP_FEED	-	-			
mm/min	Counterspindle: feedrate for travel to fixed stop	DOUBLE	Immediately			
-						
-	-	0	-	-	7/4	M

Description: In this setting data you specify the feedrate with which the counterspindle travels to a fixed stop. In setting data 55550 \$SCS_TURN_FIXED_STOP_DIST you specify the distance after which the tool travels in this feedrate.

55552	TURN_FIXED_STOP_FORCE	-	-			
%	Counterspindle: force for travel to fixed stop in %	DOUBLE	Immediately			
-						
-	-	10	1	100	7/4	M

Description: In this setting data you specify at which percentage of the driving force the counterspindle is to stop during travel to fixed stop.

55553	TURN_FIXED_STOP_RETRACTION	-	-			
mm	Counterspindle: retraction path prior to chucking after fixed stop	DOUBLE	Immediately			
-						
-	-	0	0	1	7/4	M

Description: Retraction path prior to chucking after travel to fixed stop

55580	TURN_CONT_RELEASE_ANGLE	-	-			
degrees	Contour turning: retraction angle	DOUBLE	Immediately			
-						
-	-	45	0	90	7/4	M

Description: This setting data defines the angle by which the tool is retracted from the contour during contour turning roughing.

55581	TURN_CONT_RELEASE_DIST	-	-			
mm	Contour turning: retraction value	DOUBLE	Immediately			
-						
-	-	1	0	10	7/4	M

Description: This setting data defines the value by which the tool is retracted in both axes during contour turning roughing.

55582	TURN_CONT_TRACE_ANGLE	-	-			
degrees	Contour turning: minimum angle for rounding along contour	DOUBLE	Immediately			
-						
-	-	5	0	90	7/4	M

Description: This setting data specifies the angle between the cutting edge and the contour, at which the contour is rounded in order to remove residual material.

55583	TURN_CONT_VARIABLE_DEPTH	-	-			
%	Contour turning: percentage for variable cutting depth	BYTE	Immediately			
-						
-	-	20	0	50	7/4	M

Description: Percentage for variable cutting depth during contour turning

55584	TURN_CONT_BLANK_OFFSET	-	-			
mm	Contour turning: blank allowance	DOUBLE	Immediately			
-						
-	-	1	0	100	7/4	M

Description: This setting data specifies the distance to the blank, after which contour turning is switched from G0 to G1 in order to adjust any possible blank allowances.

55585	TURN_CONT_INTERRUPT_TIME	-	-			
s	Contour turning: feed interrupt time (neg. values = revolutions)	DOUBLE	Immediately			
-						
-	-	-1	-	-	7/4	M

Description: Feed interrupt time during contour turning, contour grooving and plunge turning

- negative value in spindle revolutions
- positive value in seconds

This setting data is effective only if setting data 55586 is \$SCS_TURN_CONT_INTER_RETRACTION = 0.

55586	TURN_CONT_INTER_RETRACTION	-	-			
mm	Contour turning: retraction path after feed interrupt	DOUBLE	Immediately			
-						
-	-	1	0	10	7/4	M

Description: Retraction path feed interrupt during contour turning, contour grooving and plunge turning:

>0: retraction path after feed interrupt (setting data 55585 \$SCS_TURN_CONT_INTERRUPT_TIME is ineffective!)
 =0: no retraction path

55587	TURN_CONT_MIN_REST_MAT_AX1	-	-			
%	Contour turning: minimum difference dimension residual machining axis 1	DOUBLE	Immediately			
-						
-	-	50	0	1000	7/4	M

Description: This MD defines the limit value for stock removal of residual material in the direction of the 1st axis.

Example:

If this MD is set to 50% and if the finishing allowance is 0.5mm, the residual material which is thinner than 0.25mm is not removed in a separate machining step, but during finishing.

55588	TURN_CONT_MIN_REST_MAT_AX2	-	-
%	Contour turning: minimum difference dimension residual machining axis 2	DOUBLE	Immediately
-			
-	-	50	0
		1000	7/4
			M

Description: This MD defines the limit value for stock removal of residual material in the direction of the 2nd axis.

Example:

If this MD is set to 50% and if the finishing allowance is 0.5mm, the residual material which is thinner than 0.25mm is not removed in a separate machining step, but during finishing.

55595	TURN_CONT_TOOL_BEND_RETR	-	-
mm	Contour plunge turning: retraction path due to tool bending	DOUBLE	Immediately
-			
-	-	0.1	0
		1	7/4
			M

Description: Retraction due to tool bending during plunge turning

55596	TURN_CONT_TURN_RETRACTION	-	-
mm	Contour plunge turning: retraction depth prior to turning	DOUBLE	Immediately
-			
-	-	0.1	0
		1	7/4
			M

Description: Retraction depth prior to plunge turning

55613	MEA_RESULT_DISPLAY	-	-
-	Selection of measurement result display	BYTE	Immediately
-			
-	-	0	0
		10	7/7
			U

Description: Measurement results screen display
 =0: No measurement results screen
 =1: The measurement results screen is visible for a fixed time of 8 seconds
 =3: When the measurement results screen is visible, the cycle is stopped by an internal M0;
 on NC start the measuring cycle is resumed and the measurement results screen is deselected.
 =4: The measurement results screen only appears in the case of cycle alarms 61303, 61304, 61305, 61306.

55618	MEA_SIM_ENABLE	-	-			
-	Selection of measuring cycle response in a simulated environment	BYTE	Immediately			
-						
-	-	1	0	1	7/5	U

Description: Selection of measuring cycle response in an environment simulated in HMI Advanced or in ShopMill / ShopTurn
 = 0: measuring cycles are not executed (measuring cycle is skipped internally)
 = 1: measuring cycles are executed; real axes are required!
 During calibration no values are entered in the probe data fields, no measurement result is displayed, the measuring cycle is not logged, the travel is performed without collision detection.

55619	MEA_SIM_MEASURE_DIFF	-	-			
mm	Value for simulated error of measurement	DOUBLE	Immediately			
-						
-	-	0	-100	100	7/5	U

Description: With this parameter simulated measurement errors can be specified on the measuring points.
 Provided that SD55618 \$SCS_MEA_SIM_ENABLE=1 is used and that the measuring cycles are executed in a simulated environment of HMI Advanced or ShopMill / ShopTurn, a measurement difference can be entered in this parameter. The value of the measurement difference must be smaller than the measuring path in parameter _FA!
 Otherwise cycle alarm 61301 "Probe does not switch" is output during active simulation.

55622	MEA_EMPIRIC_VALUE_NUM	-	-			
-	Number of empirical values	DWORD	Immediately			
-						
-	-	20	0	1000	7/5	U

Description: Number of empirical values

55623	MEA_EMPIRIC_VALUE	-	-			
mm	Empirical value memory	DOUBLE	Immediately			
-						
-	20	0	-100000	100000	7/7	U

Description: In its default setting the empirical value memory consists of 20 memory elements.
 Using parameter \$SCS_MEA_EMPIRIC_VALUE_NUM the number of memory elements can be defined! Currently, however, these 20 memory elements cannot be changed!
 In the empirical value memory, empirical values can be stored which are cleared with the currently calculated difference between the setpoint and the actual value.
 Using parameter _EVNUM the empirical value element to be cleared is addressed!

55624	MEA_AVERAGE_VALUE_NUM	-	-			
-	Number of mean values	DWORD	Immediately			
-						
-	-	20	0	1000	7/5	U

Description: Number of mean values

55625	MEA_AVERAGE_VALUE	-	-			
-	Mean value memory	DOUBLE	Immediately			
-						
-	20	0	-100000	100000	7/7	U

Description: In its default setting the mean value memory consists of 20 memory elements. Using parameter \$SCS_MEA_AVERAGE_VALUE_NUM the number of memory elements can be defined! Currently, however, these 20 memory elements cannot be changed!

In the mean value memory, the mean values calculated in connection with functionality "Automatic tool offset with mean value creation" are stored.

Using parameter _EVNUM the mean value element to be used is addressed!

55628	MEA_TP_FEED_MEASURE	-	-			
mm/min	Feed for calibrating a tool probe	DOUBLE	Immediately			
-						
-	-	300	0	5000	7/7	U

Description: MEA_TP_FEED_MEASURE
Feed for calibrating a tool probe with stationary spindle in AUTO and JOG

55630	MEA_FEED_MEASURE	-	-			
mm/min	Traverse velocity for intermediate positioning in the plane	DOUBLE	Immediately			
-						
-	-	300	0	5000	7/7	U

Description: MEA_FEED_MEASURE
Measure measuring feed of workpiece in Automatic and JOG

55632	MEA_FEED_RAPID_IN_PERCENT	-	-			
%	Rapid traverse velocity in per cent, for intermediate positioning	DOUBLE	Immediately			
-						
-	-	50	0	100	7/7	U

Description: Traverse velocities for positioning in the measuring cycle between the measuring positions, with rapid traverse velocity in per cent, with collision detection not active

Note:
If necessary, adapt the value of the rapid traverse velocity in per cent to the probe type used and to the machine characteristics! This means that the maximum deflection of the actual probe type must be considered!!

Explanations:

In the measuring cycles any intermediate positions are calculated prior to the actual set of measurements. These positions can be approached

- with collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=1 or
- without collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=0).

Depending on this setting different velocities are used for the approach:

- with collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=1):
With SD55631 \$SCS_MEA_FEED_PLAN_VALUE the traversing feed is performed in the plane and
with SD55632 \$SCS_MEA_FEED_FEEDAX_VALUE during traversing in the feed axis (applicate).

If the probe switches when these intermediate positions are approached, the movement is stopped and the alarm "Probe collision" is output.

- without collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=0):
The intermediate positions are approached with the maximum axis velocity (rapid traverse) in per cent as specified in SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT.
With SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT=0 and SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT=100 the maximum axis velocity is effective.

55634	MEA_FEED_PLANE_VALUE	-	-			
mm/min	Traverse velocity for intermediate positioning in the plane	DOUBLE	Immediately			
-						
-	-	1000	0	5000	7/7	U

Description: MEA_FEED_MEASURE
Measure measuring feed of workpiece in Automatic and JOG

55636	MEA_FEED_FEEDAX_VALUE	-	-			
mm/min	Positioning velocity in the infeed axis	DOUBLE	Immediately			
-						
-	-	1000	0	10000	7/7	U

Description: Traverse velocities for intermediate positioning in the measuring cycle in the infeed axis, with and without collision detection
Note:
If necessary, adapt the value of the velocity in the infeed axis to the probe type used and to the machine characteristics! This means that the maximum deflection of the actual probe type must be considered!!

Explanations:

In the measuring cycles any intermediate positions are calculated prior to the actual set of measurements. These positions can be approached

- with collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=1 or
- without collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=0).

Depending on this setting different velocities are used for the approach:

- with collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=1):
With SD55632 \$SCS_MEA_FEED_FEEDAX_VALUE the traversing feed is performed in the infeed axis (applicate).

If the probe switches when these intermediate positions are approached, the movement is stopped and the alarm "Probe collision" is output.

- without collision detection (SD55600 \$SCS_MEA_COLLISION_MONITORING=0):
The intermediate positions are approached with the maximum axis velocity (rapid traverse) in per cent as specified in SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT.
With SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT=0 and SD55630 \$SCS_MEA_FEED_RAPID_IN_PERCENT=100 the maximum axis velocity is effective.

55638	MEA_FEED_FAST_MEASURE	-	-			
mm/min	Rapid measuring feed	DOUBLE	Immediately			
-						
-	-	900	0	10000	7/7	U

Description: Rapid measuring feed
Note:
If necessary, adjust the value of the velocity to the probe type used and to the machine characteristics!
This means that the maximum deflection of the actual probe type must be considered!!
The use of "Rapid measuring feed" depends of SD55610 \$SCS_MEA_FEED_TYP!

55640	MEA_FEED_CIRCLE	-	-			
mm/min	Circular feed for measuring circle segment	DOUBLE	Immediately			
-						
-	-	1000	0	5000	7/7	U

Description: MEA_FEED_CIRCLE
Circular feed for measuring circle segment

55642	MEA_EDGE_SAVE_ANG	-	-			
degrees	Additional safe angle for measuring corner	DOUBLE	Immediately			
-						
-	-	0	0	45	7/7	U

Description: Set \$SCS_MEA_EDGE_SAVE_ANG=10 for compatibility programs.

55740	MEA_FUNCTION_MASK	-	-			
-	Function mask for measuring cycles	DWORD	Immediately			
-						
-	-	81921	-	-	7/4	M

Description: Function mask for measuring cycles
Bit 0: Collision monitoring by workpiece probe with intermediate positioning
0: No collision monitoring
1: In the case of positionings which are calculated from the measuring cycles and executed between the measuring points,
the motion is aborted as soon as the probe returns a switching signal. A corresponding alarm message is displayed.
Bit 1: Coupling of the spindle orientation to the coordinate rotation in the active plane, for workpiece measurement with a multi probe in automatic mode
0: The spindle orientation is not coupled to the coordinate rotation in the plane.

1: If multi probes are used, the spindle is oriented as a function of the active coordinate rotation in the plane (rotations around the infeed axis (applicate)).

The axis-parallel orientation of the probe ball contact points (calibrated trigger points) with reference to the geometry axes is thus retained.

The direction of rotation of the spindle is determined by SD55604 \$SCS_MEA_SPIND_MOVE_DIR.

Note:

Coordinate rotation in the active plane means:

- Rotation around the Z axis with G17

- Rotation around the Y axis with G18

- Rotation around the X axis with G19

Attention:

The coupling is cancelled by the measuring cycle if

- The rotations around the 1st or 2nd measuring axis (abscissa or ordinate with G17) between the calibration and the actual measuring situation are not identical !!!
- The workspindle is not position-controlled (SPOS is not possible)
- A mono probe is used (_PRNUM=x1xx)!
- There is no alarm or message when the measuring cycle cancels the coupling!

Bit 2: Direction of rotation of the spindle positioning for workpiece measurement in relation to active coupling of the spindle orientation to the coordinate rotation in the active plane

0: The spindle is positioned according to default.

- Angle of the coordinate rotation in the plane 0°: spindle positioning 0°
- Angle of the coordinate rotation in the plane 90°: spindle positioning 270°

1: The spindle is positioned in the opposite direction (matched angle values).

- Angle of the coordinate rotation in the plane 0°: spindle positioning 0°
- Angle of the coordinate rotation in the plane 90°: spindle positioning 90°

Bit 3: Number of repetitions of workpiece measurement if the probe does not switch

0: A maximum of 5 attempts to measure are made, then the measuring cycle alarm "Probe not switching" is output.

1: The measuring cycle alarm "Probe not switching" is generated after the first unsuccessful attempt to measure.

Bit 4: Measuring feed for workpiece measurement

0: The feed generated in the cycle or the feed programmed in the parameter _VMS is used for the measuring traverse.

1: The probe is initially traversed with "Fast measuring feed" SD55633 \$SCS_MEA_FEED_FAST_MEASURE, when it touches the measuring object

it then retracts 2 mm from the measuring point. Now the actual measuring traverse is made with the feed from _VMS.

The function "Fast measuring feed" is only realized if the value

in parameter `_FA` ≥ 1 !

Bit 5: Retraction velocity from the measuring point during workpiece measurement

0: The retraction from the measuring point takes place with the same velocity as for intermediate positioning (SD55631 `$SCS_MEA_FEED_PLANE_VALUE`).

1: The retraction velocity is the percentage of the rapid traverse velocity specified in SD55630 `$SCS_MEA_FEED_RAPID_IN_PERCENT`, and is only effective with active collision monitoring (SD55600 `$SCS_MEA_COLLISION_MONITORING=1`).

Bit14: Coupling of the spindle orientation to the coordinate rotation around the infeed axis for workpiece measurement with a multi probe in measuring in JOG mode

0: The current spindle orientation at NC START of the measuring task while measuring in JOG is used as the starting position for the following sequence!

1: When multi probes are used, the spindle is oriented as a function of the active coordinate rotation around the infeed axis (applicate).

The axis-parallel orientation of the probe ball contact points (calibrated trigger points) with reference to the geometry axes is thus retained.

The direction of rotation of the spindle is determined by SD55604 `$SCS_MEA_SPIND_MOVE_DIR`.

Note:

Coordinate rotation in the active plane means: - Rotation around the Z axis with G17

- Rotation around the Y axis with G18

- Rotation around the X axis with G19

Attention:

The coupling is cancelled by the measuring cycle if

- The rotations around the 1st or 2nd measuring axis (abscissa or ordinate with G17) between the calibration and the actual measuring situation are not identical !!!

- The workspindle is not position-controlled (SPOS is not possible)

- A mono probe is used!

- There is no alarm or message when the measuring cycle cancels the coupling!

Bit15: Workpiece measurement calibration in a hole with a known or unknown center in measuring in JOG

0: Calibration in a hole with an unknown center

1: Calibration in a hole with a known center

Bit16: Collision monitoring with tool measurement

0: No collision monitoring

1: In the case of positionings which are calculated from the measuring cycles and executed between the measuring points,

the motion is aborted as soon as the probe returns a switching signal. A corresponding alarm message is displayed.

Bit 17: Number of repetitions of tool measurement if the probe does not switch

0: A maximum of 5 attempts to measure are made, then the measuring cycle alarm "Probe not switching" is output.

1: The measuring cycle alarm "Probe not switching" is generated after the first unsuccessful attempt to measure.

Bit 18: Measuring feed for tool measurement

0: The feed generated in the cycle or the feed programmed in the parameter `_VMS` is used for the measuring traverse.

1: The probe is initially traversed with "Fast measuring feed" `SD55633 $SCS_MEA_FEED_FAST_MEASURE`, when it touches the measuring object

it then retracts 2 mm from the measuring point. Now the actual measuring traverse is made with the feed from `_VMS`.

The function "Fast measuring feed" is only realized if the value in parameter `_FA >=1!`

Bit19: Retraction velocity from the measuring point during tool measurement

0: The retraction from the measuring point takes place at the same velocity as for intermediate positioning (`SD55631 $SCS_MEA_FEED_PLANE_VALUE`).

1: The retraction velocity is the percentage of the rapid traverse velocity specified in `SD55630 $SCS_MEA_FEED_RAPID_IN_PERCENT`, and is only effective with active collision monitoring (`SD55600 $SCS_MEA_COLLISION_MONITORING=1`).

55800	ISO_M_DRILLING_AXIS_IS_Z	-	-			
-	Drilling axis depends on the plane / always Z	BYTE	Immediately			
-						
-	-	0	0	1	7/6	U

Description: Selection of the drilling axis
 0: drilling axis is vertical to the active plane
 1: drilling axis is always "Z", independently of the active plane

55802	ISO_M_DRILLING_TYPE	-	-			
-	Tapping type	BYTE	Immediately			
-						
-	-	0	0	3	7/6	U

Description: Tapping type
 0: tapping without compensating chuck
 1: tapping with compensating chuck
 2: deep hole tapping with chip breakage
 3: deep hole tapping with stock removal

55804	ISO_M_RETRACTION_FACTOR	-	-			
%	Factor for retraction speed (0...200%)	DWORD	Immediately			
-						
-	-	100	0	200	7/6	U

Description: Factor for retraction speed (0...200%)

55806	ISO_M_RETRACTION_DIR	-	-			
-	Retraction direction at G76/87	BYTE	Immediately			
-						
-	-	0	0	4	7/6	U

Description: Retraction direction for precision drilling and reverse countersinking G76/G87

0: G17(-X) G18(-Z) G19(-Y)

1: G17(+X) G18(+Z) G19(+Y)

2: G17(-X) G18(-Z) G19(-Y)

3: G17(+Y) G18(+X) G19(+Z)

4: G17(-Y) G18(-X) G19(-Z)

55808	ISO_T_RETRACTION_FACTOR	-	-			
%	Factor for retraction speed	DWORD	Immediately			
-						
-	-	100	0	200	7/6	U

Description: Factor (1-200%) for retraction speed at tapping G84/G88

55810	ISO_T_DWELL_TIME_UNIT	-	-			
-	Dwell time evaluation	BYTE	Immediately			
-						
-	-	0	0	1	7/6	U

Description: Dwell time evaluation for deep hole drilling G83/G87

0: seconds

1: revolutions

Interface signals - overview

5


5.1 Addressing ranges

Table 5-1

Address identifier	Description	Range
DB	Data	DB1000 to DB7999 ¹ DB9000 to DB9036 ² DB9900 to DB9905 ³
T	Times	T0 to T15 (100 ms) T16 to T127 (10 ms)
C	Counters	C0 to C63
I	Image of digital inputs	I0.0 to I255.7 ⁴ I256.0 to I256.3 ⁵
Q	Image of digital outputs	Q0.0 to Q255.7 ⁴⁾ Q256.0 to Q256.3 ⁵⁾
M	Bit memory	M0.0 to M511.7
SM	Special bit memory	SM0.0 to SM0.6 (Refer to table 5-3)
A	ACCU	AC0 to AC3

1. PLC user interface: The available addressing ranges are described in this document.
2. User data blocks: The available addressing ranges are dependent on which data blocks are present in the project.
3. Special data blocks: The available addressing ranges are dependent on which data blocks are present in the project.
4. Input or output image: Refer to the "Commissioning the drive" section of the Commissioning Manual for details of the assignment of these variables to the physical I/Os.
5. Direct digital onboard inputs and outputs: Refer to the "Commissioning the drive" section of the Commissioning Manual for details of the assignment of these variables to the physical I/Os.

Structure of the DB-range address:



5.1 Addressing ranges

Table 5-2

Access	Example	Explanation
Bit	DB3801.DBX1000.7	Bit 7 of the byte with offset 0 in subrange 1 for axis 2 in user range 38
Byte	DB3801.DBB0	Byte with offset 0 in subrange 0 for axis 2 in user range 38
Word	DB4500.DBW2	Word with offset 2 in subrange 0 in range 0 in user range 45
Double Word	DB2500.DBD3004	Double word with offset 4 in subrange 3 in range 0 in user range 25

Note:

The permitted offset for an address is dependent on the access:

- Bit or byte access: any offset permitted.
Byte-size variables are placed one beside another seamlessly in a DB.
- Word access: Offset must be divisible by 2.
Word-size variables (2 bytes) are always saved on straight offsets.
- Double word access: Offset must be divisible by 4.
Double word-size variables (4 bytes) are always saved on offsets which are divisible by 4.

Special bit memory SM bit definition (read only):

Table 5-3

SM bits	Description
SM0.0	Bit memory with defined ONE signal
SM0.1	Initial state: first PLC cycle '1', subsequent cycles '0'
SM0.2	buffered data lost - only valid in first PLC cycle ('0' data OK, '1' data lost)
SM0.3	Power On: first PLC cycle '1', subsequent cycles '0'
SM0.4	60 s clock cycle (alternating '0' for 30 s, then '1' for 30 s)
SM0.5	1 s clock cycle (alternating '0' for 0.5 s, then '1' for 0.5 s)
SM0.6	PLC cycle clock (alternating one cycle '0', then one cycle '1')

Warning

All of the empty fields in the user interface are "reserved for Siemens" and may neither be written to nor evaluated!

Fields designated with "0" always have the value "logical 0".

Variable access rights:

- [r] Designated area "read only" permitted
- [r/w] Designated area "read and write" permitted

Data format information:

- 1: BIT
- 8: BYTE
- 16: INT/WORD
- 32: DINT/DWORD/REAL

Without data format information: all of the specified data formats can be read or written to.

Reference:

References regarding a signal include the unique chapter number referring to the Function Manuals Basic Functions (FB1), Extended Functions (FB2) and Special Functions (FB3): /.../

Example:

DB1700 Byte0 Bit5: M01 selected [FB1-K1]

FB1: Function Manual Basic Functions, K1: Mode group, channel, programming mode, reset behavior

5.2 User data

5.2.1 User data 1

DB1000		Data 1 [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								User data
1								User data
2								User data
...								...
10								User data
11								User data

5.2.2 User data 2

DB1100		Data 2 [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								User data
1								User data
2								User data
...								...
6								User data
7								User data

5.2.3 Reading/writing NC data: Job

DB1200		Reading/writing NC data [r/w]						
[FB1-P4]		PLC → NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0							Write variable	Start
1	Number of variables							
2								
3								

DB1200 ... 1207		Reading/writing NC data [r/w]						
		PLC → NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Variable index							
1001	Area number							
1002	Column index for the NCK variable x (WORD)							
1004	Line index for the NCK variable x (WORD)							
1006								
1008	Writing: Data to NCK variable x (data type of the variables: 1 ... 4 bytes)							

5.2.4 Reading/writing NC data: Result

DB1200		Reading/writing NC data [r]						
[Commissioning Manual Turning, Milling; FB1-P4]		NCK → PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000							Error in job	Job completed
2001								
2002								

DB1200 ... 1207		NC services [r]						
		NCK → PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000							Error has occurred	Valid variable
3001	Access result ¹							
3002								
3004	Reading: Data from NCK variable x (data type of the variables: 1 ... 4 bytes)							

1. 0 No error
 3 Illegal access to object
 5 Invalid address
 10 Object does not exist

5.3 Retentive data area

5.2.5 PI service: Job

DB1200		PI service [r/w] PLC--> NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000								Start
4001	PI index							
4002								
4003								
4004	PI parameter 1							
4006	PI parameter 2							
4008	PI parameter 3							
4010	PI parameter 4							
4012	PI parameter 5							
4014	PI parameter 6							
4016	PI parameter 7							
4018	PI parameter 8							
4020	PI parameter 9							
4022	PI parameter 10							

5.2.6 PI service: Result

DB1200		PI service [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000							Error in job	Job completed
5001								
5002								

5.3 Retentive data area

DB1400		Retentive data [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	User data							
1	User data							
2	User data							
...	...							
32								
...	...							
126	User data							
127	User data							

5.4 User alarm

Note:

Information on PLC alarms including configuring user alarms is provided in:

Literature: "Turning and Milling Commissioning Manual"

5.4.1 User alarm: Activating

DB1600 [FB1-P4]		Activating alarm [r/w] PLC → HMI interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	700007	700006	700005	700004	700003	700002	700001	700000
Activation of alarm no.								
1	700015	700014	700013	700012	700011	700010	700009	700008
Activation of alarm no.								
2	700023	700022	700021	700020	700019	700018	700017	700016
Activation of alarm no.								
3	700031	700030	700029	700028	700027	700026	700025	700024
Activation of alarm no.								
4	700039	700038	700037	700036	700035	700034	700033	700032
Activation of alarm no.								
5	700047	700046	700045	700044	700043	700042	700041	700040
Activation of alarm no.								
...					...			
30	700247	700246	700245	700244	700243	700242	700241	700240
Activation of alarm no.								

5.4.2 Variable for alarm

DB1600 [FB1-P4]		Variable for alarm [r32/w32] PLC → HMI interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Variable for alarm 700000 Commissioning Manual Turning, Milling							
1004	Variable for alarm 700001							
1008	Variable for alarm 700002							
...	...							
1980	Variable for alarm 700245							
1984	Variable for alarm 700246							
1988	Variable for alarm 700247							

5.4.3 Active alarm response

DB1600 [FB1-P4]		Active alarm response [r] PLC → HMI interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Acknowledge POWER ON	Acknowledge with DB1600 DBX3000.0		PLC STOP	EMER- GENCY STOP	Feedrate disable all axes	Read-in disable	NC start disable
2001								
2002								
2003								

5.4.4 Alarm acknowledgement

DB1600		Alarm acknowledgement [r/w] HMI → PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000								Ack
3001								
3002								
3003								

5.5 Signals from/to HMI

5.5.1 Program control signals from HMI (retentive area) (also refer to signals at channel DB3200)

DB1700		Signals, HMI [r]						
HMI → PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0		Dry run feedrate selected [FB1-K1,V1]	M01 selected [FB1-K1]		DRF selected [FB2-H1]			
1	Program test selected [FB1-K1]				Feedrate override selected for rapid traverse [FB1-K1,V1] [FB2-S3]			
2	Skip block 7 selected [FB1-K1]	Skip block 6 selected [FB1-K1]	Skip block 5 selected [FB1-K1]	Skip block 4 selected [FB1-K1]	Skip block 3 selected [FB1-K1]	Skip block 2 selected [FB1-K1]	Skip block 1 selected [FB1-K1]	Skip block 0 selected [FB1-K1]
3							Skip block 9 selected [FB1-K1]	Skip block 8 selected [FB1-K1]
4								
5								
6								
7	Reset [FB1-K1]				NC stop [FB1-K1]		NC start [FB1-K1]	

5.5.2 Program selection via lists

DB1700		Program selection [r/w]						
PLC → HMI interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Start program [FB1-A2]							Disable teach transfer
1001	always 1	Program handling: Number of the control file for user file names [FB1-A2]						
1002	Program handling: Index of the file to be transferred from the user list							
1003								

DB1700		Program selection [r]						
HMI → PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Part program handling status [FB1-A2]								
2000	Selection				Active	Error	Okay	
2001	Error part program handling							
2002								
2003								

5.5 Signals from/to HMI

5.5.3 Messenger control command

DB1700		Messenger [r] Messenger → PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Control byte							
3001								
3002								
3003								

5.5.4 Signals from HMI

DB1800		Signals from HMI [r] HMI → PLC interface (signals are only present for 1 PLC cycle)						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reset					JOG [FB2-M5]	Mode MDI [FB2-M5]	AUTO- MATIC [FB2-M5]
1						Active machine function		
						REF [FB2-M5]		TEACH IN [FB2-M5]
2								
3								

5.5.5 Signals from PLC

DB1800 [Commissioning Manual Turning and Milling]		Signals from PLC [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000		Commis- sioning archive has been read in					Boot with saved data [FB1-A2]	Boot with default values [FB1-A2]
1001								
1002								
1003								
1004	PLC cycle time in µs [DINT]							
1008	Year: Tens digit, BCD				Year: Units digit, BCD			
1009	Month: Tens digit, BCD				Month: Units digit, BCD			
1010	Day: Tens digit, BCD				Day: Units digit, BCD			
1011	Hour: Tens digit, BCD				Hour: Units digit, BCD			
1012	Minute: Tens digit, BCD				Minute: Units digit, BCD			
1013	Second: Tens digit, BCD				Second: Units digit, BCD			
1014	Millisecond: Hundreds digit, BCD				Millisecond: Tens digit, BCD			
1015	Millisecond: Units digit, BCD				Weekday, BCD {1, 2, ... 7} (1 = Sunday)			

5.5.6 Signals to maintenance planners

DB1800 [Commissioning Manual Turning, Milling]		Deactivation [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Deactivation 8	Deactivation 7	Deactivation 6	Deactivation 5	Deactivation 4	Deactivation 3	Deactivation 2	Deactivation 1
2001	Deactivation 16	Deactivation 15	Deactivation 14	Deactivation 13	Deactivation 12	Deactivation 11	Deactivation 10	Deactivation 9
2002	Deactivation 24	Deactivation 23	Deactivation 22	Deactivation 21	Deactivation 20	Deactivation 19	Deactivation 18	Deactivation 17
2003	Deactivation 32	Deactivation 31	Deactivation 30	Deactivation 29	Deactivation 28	Deactivation 27	Deactivation 26	Deactivation 25

DB1800 [Commissioning Manual Turning, Milling]		Acknowledgements [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000	Acknowledgement 8	Acknowledgement 7	Acknowledgement 6	Acknowledgement 5	Acknowledgement 4	Acknowledgement 3	Acknowledgement 2	Acknowledgement 1
4001	Acknowledgement 16	Acknowledgement 15	Acknowledgement 14	Acknowledgement 13	Acknowledgement 12	Acknowledgement 11	Acknowledgement 10	Acknowledgement 9
4002	Acknowledgement 24	Acknowledgement 23	Acknowledgement 22	Acknowledgement 21	Acknowledgement 20	Acknowledgement 19	Acknowledgement 18	Acknowledgement 17
4003	Acknowledgement 32	Acknowledgement 31	Acknowledgement 30	Acknowledgement 29	Acknowledgement 28	Acknowledgement 27	Acknowledgement 26	Acknowledgement 25

DB1800 [Commissioning Manual Turning, Milling]		Acknowledgement locks [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	Acknowledgement disable 8	Acknowledgement disable 7	Acknowledgement disable 6	Acknowledgement disable 5	Acknowledgement disable 4	Acknowledgement disable 3	Acknowledgement disable 2	Acknowledgement disable 1
5001	Acknowledgement disable 16	Acknowledgement disable 15	Acknowledgement disable 14	Acknowledgement disable 13	Acknowledgement disable 12	Acknowledgement disable 11	Acknowledgement disable 10	Acknowledgement disable 9

5.5 Signals from/to HMI

DB1800 [Commissioning Manual Turning, Milling]		Acknowledgement locks [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5002	Acknowledgement disable 24	Acknowledgement disable 23	Acknowledgement disable 22	Acknowledgement disable 21	Acknowledgement disable 20	Acknowledgement disable 19	Acknowledgement disable 18	Acknowledgement disable 17
5003	Acknowledgement disable 32	Acknowledgement disable 31	Acknowledgement disable 30	Acknowledgement disable 29	Acknowledgement disable 28	Acknowledgement disable 27	Acknowledgement disable 26	Acknowledgement disable 25

5.5.7 Signals from maintenance planners

DB1800 [Commissioning Manual Turning, Milling]		Warnings/Alarms [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Alarm 8	Alarm 7	Alarm 6	Alarm 5	Alarm 4	Alarm 3	Alarm 2	Alarm 1
3001	Alarm 16	Alarm 15	Alarm 14	Alarm 13	Alarm 12	Alarm 11	Alarm 10	Alarm 9
3002	Alarm 24	Alarm 23	Alarm 22	Alarm 21	Alarm 20	Alarm 19	Alarm 18	Alarm 17
3003	Alarm 32	Alarm 31	Alarm 30	Alarm 29	Alarm 28	Alarm 27	Alarm 26	Alarm 25

5.5.8 Signals from operator panel (retentive area)

DB1900		Signals from operator panel [r/w] HMI --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Switch over Machine/ Work [FB1-A2,K2]	Simulation active [FB1-K1]				Cancel		
1	active HMI range							
2								
3								
4	Actual image number of the JobShop interface							
6								
7								

5.5.9 General selection/status signals from HMI (retentive area)

DB1900		Signals from HMI [r]							
		HMI --> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
1000									
1001									
1002									
1003	Machine axis [FB2-H1]	Hand-wheel selected [FB2-H1]	Contour handwheel [FB2-H1]	Axis number for handwheel 1			C	B	A
1004	Machine axis [FB2-H1]	Hand-wheel selected [FB2-H1]	Contour handwheel [FB2-H1]	Axis number for handwheel 2			C	B	A
1005									
1006									
1007									

5.5.10 General selection/status signals to HMI (retentive area)

DB1900		Signals to HMI [r/w]						
		PLC --> HMI interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	Actual value in Work 0=Machine [FB1-A2]					OP key block [FB1-A2]		
5001							External viewer can only monitor	No external viewer permitted
5002								
5003	PLC hard keys (value range 1 .. 255, 0 is the initial state)							
5004								
5005								
5006								
5007								
5008								
5009								
5010								
5011								

5.6 Auxiliary function transfer from NC channel

DB1900		Signals to HMI [r/w]						
		PLC --> HMI interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5012								
5013								
5014								
5012								
5013								
5014								
5015								
5016								
5017								
5018								
5019								

5.6 Auxiliary function transfer from NC channel

DB2500		Auxiliary functions from NCK channel [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								
1								
2								
3								
4				M fct. 5 change [FB1-H2]	M fct. 4 change [FB1-H2]	M fct. 3 change [FB1-H2]	M fct. 2 change [FB1-H2]	M fct. 1 change [FB1-H2]
5								
6								S fct. 1 change [FB1-H2]
7								
8								T fct. 1 change [FB1-H2]
9								
10								D fct. 1 change [FB1-H2]
11								
12						H fct. 3 change [FB1-H2]	H fct. 2 change [FB1-H2]	H fct. 1 change [FB1-H2]
13								
14								
15								
16								
17								
18								
19								

5.6.1 Decoded M signals (M0-M99)

DB2500		M functions from NCK channel [r] ¹² NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	M7	M6	M5	M4	M3	M2	M1	M0
1001	M15	M14	M13	M12	M11	M10	M9	M8
1002	M23	M22	M21	M20	M19	M18	M17	M16
...				...				
1012					M99	M98	M97	M96
1013								
1014								
1015								

1. The PLC user must generate static M functions himself from the dynamic M functions.
2. The basic program decodes dynamic M functions (M0 to M99).

Remark:

The signals are output for the duration of a PLC cycle.

5.6.2 Transferred T functions

DB2500		T functions from NCK channel [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	T function 1 (DINT) [FB1-H2,K2,W1]							
2004								
2005								
2006								
2007								

5.6.3 Transferred M functions

DB2500		M functions from NCK channel [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	M function 1 (DINT) [FB1-H2]							
3004	Extended address M function 1 (byte) [FB1-H2]							
3008	M function 2 (DINT) [FB1-H2]							
3012	Extended address M function 2 (byte) [FB1-H2]							
3016	M function 3 (DINT) [FB1-H2]							
3020	Extended address M function 3 (byte) [FB1-H2]							
3024	M function 4 (DINT) [FB1-H2]							
3028	Extended address M function 4 (byte) [FB1-H2]							
3032	M function 5 (DINT) [FB1-H2]							
3036	Extended address M function 5 (byte) [FB1-H2]							

5.6.4 Transferred S functions

DB2500		S functions from NCK channel [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000	S function 1 (REAL) [FB1-H2]							
4004	Extended address S function 1 (byte) [FB1-H2]							
4008	S function 2 (REAL) [FB1-H2]							
4012	Extended address S function 2 (byte) [FB1-H2]							
4016								
4020								

5.6.5 Transferred D functions

DB2500		D functions from NCK channel [r] NCK--> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	D function 1 (DINT) [FB1-H2,K2,W1]							
5004								

5.6.6 Transferred H functions

DB2500		H functions from NCK channel [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
6000	H function 1 (REAL) [FB1-H2]							
6004	Extended address H function 1 (byte) [FB1-H2]							
6008	H function 2 (REAL) [FB1-H2]							
6012	Extended address H function 2 (byte) [FB1-H2]							
6016	H function 3 (REAL) [FB1-H2]							
6020	Extended address H function 3 (byte)[FB1-H2]							

5.7 NCK signals

5.7.1 General signals to NCK

DB2600		General signals to NCK [r/w]						
		PLC --> NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	Protection level [FB1-A2] Keyswitch position 0-3					Acknowledge EMERGE NCY STOP [FB1-N2]	EMERGE NCY STOP [FB1- N2,K1]	Braking along the contour in case of EMERGE NCY STOP [FB1-N2]
0	4	5	6	7				
1						Request axis distances- to-go [FB2-H1]	Request axis actual values [FB2-H1]	INC inputs in mode signal range active ¹ [FB2-H1]
2								
3								

1. Refer to mode signals

5.7.2 General signals from NCK

DB2700		General signals from NCK [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0							EMERGENCY OFF active [FB1-N2]	
1	Inch measuring system [FB1-G2]						Probe actuated Probe 2 [FB2-M5]	Probe 1 [FB2-M5]
2	NC ready [FB1-A2] [FB2-K3]	Drive ready [FB1-A2]	Drives in cyclic operation [FB1-A2]		HMI ready [FB1-A2]			
3		Air temperature alarm [FB1-A2]						NCK alarm is active [FB1-A2]
4								
5								
6								
7								
8								
9								
10								
11								
12	Change counter for motion, handwheel 1 [FB2-H1]							
13	Modification counter for motion, handwheel 2 [FB2-H1]							
14								
15	Change counter, inch/metric measuring system							
16								
17								
18								
19								

5.7.3 Signals at fast inputs and outputs

DB2800 [FB2-A4]		Signals at fast inputs and outputs [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Block digital NCK inputs								
0	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
Value from PLC for NCK inputs								
1	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
Block digital NCK outputs								
4	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
Overwrite mask for digital NCK outputs								
5	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
Value from PLC for digital NCK outputs								
6	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
Setting mask for NCK outputs								
7	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1

DB2800 [FB2-A4]		Signals at fast inputs and outputs [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Block external digital NCK inputs								
1000	Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9
Value from PLC for the external digital NCK inputs								
1001	Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9
Block external digital NCK outputs								
1008	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
Overwrite mask for external digital NCK outputs								
1009	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
Value from PLC for the external digital NCK outputs								
1010	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
Setting mask for external digital NCK outputs								
1011	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9

5.7.4 Signals from fast inputs and outputs

DB2900 [FB2-A4]		Signals from fast inputs and outputs [r]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Actual value for digital NCK inputs								
0	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
Setpoint for digital NCK outputs								
4	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1

DB2900 [FB2-A4]		Signals from fast inputs and outputs [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Actual value of external digital NCK inputs								
1000	Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9
NCK setpoint for external digital NCK outputs								
1004	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9

DB3000		Mode signals to NCK [r/w]							
PLC --> NCK interface									
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
	Reset [FB1-K1]			Mode change block [FB1-K1]		Mode			
0						JOG [FB2-H1] [FB1-K1]	MDI [FB1-K1]	AUTO- MATIC [FB1-K1]	
1	Single block Type A [FB1-K1]		Type B [FB1-K1]			Machine function REF [FB1- K1,R1]			TEACH IN [FB1-K1]
2			Continuou s traversing [FB2-H1]	var. INC [FB2-H1]	10000 INC [FB2-H1]	1000 INC [FB2-H1]	100 INC [FB2-H1]	10 INC [FB2-H1]	1 INC [FB2-H1]
3									

1. Machine function:

To use the machine function signals in DB3000.DBB2, the "INC inputs in the operating-mode signal range active" signal (DB2600.DBX1.0) must be set to "1".

DB3100		Mode signals from NCK [r]							
NCK --> PLC interface									
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
0					828 READY [FB1-K1] [FB2-K3]	JOG [FB1-K1] [FB2H1]	Active mode MDI [FB1-K1]		AUTO- MATIC [FB1-K1]
1					Active machine function				TEACH IN [FB1-K1]
2		Continuou s traversing active [FB1-K1]	var. INC active [FB1-K1]	10000 INC active [FB1-K1]	1000 INC active [FB1-K1]	100 INC active [FB1-K1]	10 INC active [FB1-K1]	1 INC active [FB1-K1]	
3									

5.8 Channel signals

5.8.1 Signals to NC channel

5.8.1.1 Control signals to NC channel

DB3200		Signals to NCK channel [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0		Activate test run feedrate [FB1-V1, K1]	Activate M01 [FB1-K1]	Activate single block ¹ [FB1-K1]	Activate DRF [FB1-K1, FB2-H1]	Activate traverse forwards	Activate traverse backwards	
1	Activate program test [FB1-K1]						Enable protection zones [FB1-A3]	Activate referencing [FB1-R1]
2	7	6	5	4	3	2	1	0
3								
4	H	G	F	E	D	C	B	A
5	H	G	F	E	D	C	B	A

5.8 Channel signals

DB3200		Signals to NCK channel [r/w]							
PLC --> NCK interface									
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
6	Feedrate override active ³ [FB1-V1]	Rapid traverse override active [FB1-V1]	Path velocity limiting	Program level abort [FB1-K1]	Delete number of subroutine cycles [FB1-K1]	Delete distance-to-go [FB1-A2]	Read-in disable [FB1-K1]	Feedrate disable [FB1-V1,A3] [FB2-P2]	
7			Suppress start lock [FB1-K1]	NC stop axes plus spindle [FB1-K1] [FB2-S3,P2]	NC stop [FB1-K1]	NC stop at block limit [FB1-K1]	NC start [FB1-K1] [FB2-S3]	NC start disable [FB1-K1] [FB2-P2]	
8	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1	
9	Activate machine-related protection zone [FB1-A3]							Area 10	Area 9
10	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1	
11	Activate channel-specific protection zone [FB1-A3]							Area 10	Area 9
12									
13	Do not block tool [FB1-W1]		Deactivate workpiece counter [FB1-W1]		Activate fixed feedrate [FB1-F1] Feed 4 Feed 3 Feed 2 Feed 1				
14	No tool change commands	Jog circle	Activate associated M01 [FB1-H2]	Neg. direction for sim. contour handwheel [FB2-H1]	Sim. contour handwheel ON [FB2-H1]	Activate contour handwheel (bit/binary coded) [FB2-H1] Hand-wheel 2 Hand-wheel 1			
15	Activate skip block 9 [FB1-K1]	Activate skip block 8 [FB1-K1]	Invert contour handwheel direction [FB2-H1]						
16								Program branches (GOTOS) control	
17									
18									
19									

1. Select single-block type selection (SBL1/SBL2) using the softkey.
2. 31 positions (Gray code)
3. Even if the feedrate override is not active (=100%), the 0% position is still effective.

5.8.1.2 Control signals to axes in Work

DB3200		Signals to NCK channel [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Axis 1 in Work								
1000	Traversing keys [FB2-H1]		Rapid traverse override [FB2-H1]	Traversing key disable [FB2-H1]	Feedrate stop [FB1-V1]	Activate handwheel (bit/binary coded) ¹ [FB2-H1]		
	plus	minus					2	1
Axis 1 in Work								
1001	Machine function ² [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1002								
1003								Hand-wheel direction of rotation inverted [FB2-H1]
Axis 2 in Work								
1004	Traversing keys [FB2-H1]		Rapid traverse override [FB2-H1]	Traversing key disable [FB2-H1]	Feedrate stop [FB2-H1]	Activate handwheel (bit/binary coded) ¹ [FB2-H1]		
	plus	minus					2	1
Axis 2 in Work								
1005	Machine function ² [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1006								
1007								Invert contour hand-wheel direction [FB2-H1]

5.8 Channel signals

DB3200		Signals to NCK channel [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1008	Traversing keys [FB2-H1]		Rapid traverse override [FB2-H1]	Traversing key disable [FB2-H1]	Feedrate stop [FB1-V1]	Activate handwheel (bit/binary coded) ¹ [FB2-H1]		
	plus	minus					2	1
1009	Axis 3 in Work Machine function ² [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1010								
1011								Invert contour handwheel direction [FB2-H1]

1. The handwheel number is represented according to the \$MD_HANDWH_VDI_REPRESENTATION machine data in a bit-coded (=0) or binary-coded (=1) manner.

2. Machine function:

The machine function is only entered if the "INC inputs in the operating-mode signal range active" signal (DB2600 DBX1.0) is not set.

5.8.2 Signals from NC channel

5.8.2.1 Status signals from NC channel

DB3300		Signals from NCK channel [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0		Last action block active [FB1-K1]	M0/M1 active [FB1-K1]	Approach block active [FB1-K1]	Action block active [FB1-K1]	Forwards traverse active [FB1-K1]	Backwards traverse active [FB1-K1]	Execution from external active [FB1-K1]
1	Program test active [FB1-K1]	Transformation active [FB2-M1] [FB1-K1]	M2/M30 active [FB1-K1]	Block search active [FB1-K1]	Handwheel override active [FB2-H1]	Rev. feedrate active [FB1-V1]		Referencing active [FB1-R1]
2								
3	Channel status [FB1-K1]			Program status [FB1-K1]				
	Reset	Interrupted	Active	Aborted	Interrupted	Stopped	Waiting	Running

DB3300		Signals from NCK channel [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	NCK alarm with processing stop present [FB1-A2]	Channel-specific NCK alarm is active [FB1-A2]	Channel operational [FB1-K1] [FB2-K3]		All axes stationary [FB1-B1] [FB2-P2]	referenced [FB1-B1,R1]	Stop request [FB2-H1]	Start request [FB2-H1]
5						Contour handwheel active (bit/binary coded) [FB2-H1]		Handwheel 2 Handwheel 1
6								
7			Invert contour handwheel direction /FB2-H1]					Protection zone not guaranteed [FB1-A3]
8	Machinerelated protection zone preactivated [FB1-A3]							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
9	Machinerelated protection zone preactivated [FB1-A3]							
							Area 10	Area 9
10	Channelspecific protection zone preactivated [FB1-A3]							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
11	Channelspecific protection zone violated [FB1-A3]							
							Area 10	Area 9
12	Machinerelated protection zone violated [FB1-A3]							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
13	Machinerelated protection zone violated [FB1-A3]							
							Area 10	Area 9
14	Channelspecific protection zone violated [FB1-A3]							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
15	Channelspecific protection zone violated [FB1-A3]							
							Area 10	Area 9

5.8.2.2 Status signals, axes in Work

DB3300		Signals from NCK channel [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Axis 1 in Work								
1000	Travel command [FB2-H1]		Travel request [FB2-H1]			Handwheel active (bit/binary coded) ¹ [FB2-H1]		
	plus	minus	plus	minus			2	1
Axis 1 in Work								
1001	Active machine function [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1002								
1003								Contour-handwheel direction of rotation inverted [FB2-H1]
Axis 2 in Work								
1004	Travel command [FB2-H1]		Travel request [FB2-H1]			Handwheel active (bit/binary coded) ¹ [FB2-H1]		
	plus	minus	plus	minus			2	1
Axis 2 in Work								
1005	Active machine function [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1006								
1007								Contour-handwheel direction of rotation inverted [FB2-H1]
Axis 3 in Work								
1008	Travel command [FB2-H1]		Travel request [FB2-H1]			Handwheel active (bit/binary coded) ¹ [FB2-H1]		
	plus	minus	plus	minus			2	1
Axis 3 in Work								
1009	Active machine function [FB2-H1]							
		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1010								

DB3300		Signals from NCK channel [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1011								Contour-handwheel direction of rotation inverted [FB2-H1]

1. The handwheel number is represented according to the \$MD_HANDWH_VDI_REPRESENTATION machine data in a bit-coded (= 0) or binary-coded (= 1) manner.

5.8.2.3 Additional status signals from NC channel

DB3300		Signals from NCK channel [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000								G00 active
4001			Travel request, drive test present [FB1-A2]				Workpiece setpoint reached [FB1-K1]	External language mode active [FB1-A2]
4002		Dry run feedrate Active [FB1-K1,V1]	Associated M01/M00 Active [FB1-K1,H2]	STOP_ DELAYED				ASUB is stopped [FB1-K1]
4003	No tool change command active	DELAY FST SUPPRESS		DELAY FST				
4004				Start after block search	Boot	Operator panel Reset	Part program End	Part program Start from RESET
4005		Jog circle Active					Stop condition	StopByColl Danger

5.8 Channel signals

DB3300		Signals from NCK channel [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4006							Dormant ASUB Active [FB1-K1]	ASUB active [FB1-K1]
4007								
4008	active transformation number							
4009	Reserved							
4010	Reserved							
4011	Reserved							

5.8.2.4 Asynchronous subroutines (ASUBs): Job

DB3400 [FB1-P4]		ASUB: Job [r/w]						
		PLC --> NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								INT1 Start
1								INT2 Start
2								
3								

5.8.2.5 Asynchronous subroutines (ASUBs): Result

DB3400 [FB1-P4]		ASUB: Result [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	INT1				ASUB execution not possible	Interrupt no. not allocated	ASUB is being executed	ASUB ended
1001	INT2				ASUB execution not possible	Interrupt no. not allocated	ASUB is being executed	ASUB ended
1002								
1003								

5.8.2.6 G functions from NCK channel

DB3500 [FB1-K1,K2;W1]		G functions from NCK channel [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Active G function of group 1 (8 bit int)							
1	Active G function of group 2 (8 bit int)							
2	Active G function of group 3 (8 bit int)							
...	...							
62	Active G function of group 63 (8 bit int)							
63	Active G function of group 64 (8 bit int)							

5.9 Axis/spindle signals

5.9.1 Transferred M and S functions, axis-specific

DB3700 ... 3707		M, S functions [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	M function for spindle (DINT) [FB1-S1,H1]							
4	S function for spindle (REAL) [FB1-S1,H1]							

5.9.2 Signals to axis/spindle

5.9.2.1 Common signals to axis/spindle

DB3800 ... 3807		Signals to axis/spindle [r/w] PLC --> NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Feedrate override [FB1-V1]							
	H	G	F	E	D	C	B	A
1	Override active [FB1-H2,V1]	Position measuring system 2 [FB1-A2,A3] [FB2-S3]	Position measuring system 1 [FB1-A2,A3] [FB2-S3]	Follow up mode [FB1-A2,A3] [FB2-S3]	Axis/spindle disable [FB1-A2] [FB2-S3]	Sensor for fixed stop [FB1-F1]	Acknowledge fixed stop reached [FB1-F1]	Drivetest traverse enable [FB1-A2]

DB3800 ... 3807		Signals to axis/spindle [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2	4	3	2	1	Clamping in progress [FB1-A3]	Distance-to-go/spindle reset [FB1-A2, S1] [FB2-H1, S3]	Controller enable [FB1-A2] [FB2-P2, S3]	
3	Axis/spindle enable program test [FB1-K1]	Velocity/spindle speed limiting [FB1-A3]	Activate fixed feedrate [FB1-F1]				Enable approach to fixed stop [FB1-F1]	
4	Traversing keys [FB2-H1, S3] [FB1-R1] plus minus		Rapid traverse override [FB2-H1]	Traverse key disable [FB2-H1]	Feedrate stop/Spindle stop [FB1-A3, V1] [FB2-H1, S3]	Activate handwheel [FB2-H1]		
5		Continuous traversing	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
6								
7								Contour-handwheel direction of rotation inverted
8	Request PLC axis/spindle [FB1-K5]			Activate signal when this byte is changed [FB1-K5]				Request NC axis/spindle [FB1-K5]
9						Parameter set, servo		
10						C	B	A
11								

1. Machine function

The machine function is only entered if the signal "INC inputs in the operating-mode signal range active" (DB2600.DBX1.0) is not set.

5.9.2.2 Signals to axis

DB3800 ... 3807		Signals to axis [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Delay Ref. pt. approach [FB1-R1]			Modulo limit enabled [FB2-R2]	2. Software limit switch [FB1-A3] plus minus		Hardware limit switch [FB1-A3] plus minus	
1001					Jogging to Position [FB2-H1]	JogFix-Point-Pos 2 [FB2-H1]	JogFix-Point-Pos 1 [FB2-H1]	JogFix-Point-Pos 0 [FB2-H1]
1002							Activate program test	Suppress program test
1003								

5.9.2.3 Signals to spindle

DB3800 ... 3807		Signals to spindle [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Delete S value [FB2-S3]	No speed monitoring. for gear change.	Resynchronize spindle [FB2-S3] 2 1		Gear changed [FB1-S1]	Actual gear stage [FB1-S1] C B A		
2001		Invert M3/M4 [FB2-S3]		Resynchronize during positioning 1 [FB1-S1]				Feedrate override for spindle valid [FB1-V1] [FB2-S3]
2002	Setpoint direction of rotation [FB1-S1] counter-clockwise clockwise		Oscillation speed [FB1-S1]	Oscillation controlled by PLC [FB1-S1]				
2003	Spindle override [FB1-V1] [FB2-S3] H G F E D C B A							

5.9.2.4 Signals to PLC axis

DB3800 ... 3807		Signals to PLC axis [r/w] ¹						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Start positioning axis [FB1-P4]	Start spindle positioning [FB1-P4]	Start spindle rotation [FB1-P4]	Start spindle oscillation [FB1-P4]				
3001			Stop spindle rotation [FB1-P4]	Stop spindle oscillation [FB1-P4]				
3002	Automatic Gear selection [FB1-P4]	Constant cutting velocity [FB1-P4]	Direction of rotation same as M4 [FB1-P4]		Hand-wheel override On [FB1-P4]	Traversing dimension, inches (not metric) [FB1-P4]	Path condition	
							shortest path (DC) [FB1-P4]	incremental (IC) [FB1-P4]
3003	Indexing position [FB1-P4]						Path condition absolute positive direction (ACP) [FB1-P4]	negative direction (ACN) [FB1-P4]
3004	Position (REAL, with indexing axis: DWORD)							
3005								
3006								
3007								
3008	Feedrate (REAL), if = 0, the value is taken from machine data POS_AX_VELO							
3009								
3010								
3011								

1. Only one of signals IC, DC, ACP, ACN may be active at any one time - or none. If no signal is set, then AC is active (Absolute Coordinate).

5.9.2.5 Signals to drive

DB3800 ... 3807		Signals to axis/spindle [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000			Holding brake					
4001	Pulse enable [FB1-A2,D1]	Integrator disable speed controller [FB1-A2]	Motor selected	Motor selection B A		Parameter set selection [FB1-A2,D1] C B A		
4002								
4003								

5.9.2.6 Signals to technology functions

DB3800 ... 3807		Signals to axis/spindle [r/w]						
PLC --> NCK interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	Master/slave on [FB3-TE3]			Torque equalization controller on [FB3-TE3]				
5001								
5002								
5003	Stop HIAXMove	Stop Corr	Stop DEPBCS	Stop DEPMCS	Resume HIAXMove	Resume Corr	Resume DEPBCS	Resume DEPMCS
5004								
5005			Disable automatic synchronization [FB3-G1]	Start gantry synchronization [FB3-G1]				
5006 (spindle)				Spindle positioning	Automatic gear stage change	Setpoint direction of rotation counter-clockwise clockwise		Spindle stop
5007 (couplings)	Delete synchronism override							
5008 (SIS-TECH)								

DB3800 ... 3807		Signals to axis/spindle [r/w]						
		PLC --> NCK interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5009 (SISI-TECH)								
5010								
5011								

5.9.3 Signals from axis/spindle

5.9.3.1 General signals from axis/spindle

DB3900 ... 3907		Signals from axis/spindle [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Position reached [FB1-B1] [FB2-H1,P2] With exact stop, fine	With exact stop, coarse	Referenced/ [FB1-D1,R1,S1] [FB2-K3,S3,T1] synchron-ized 2	synchron-ized 1	Encoder limit freq. exceeded [FB1-A3,S1] 2	1		Spindle/ no axis [FB1-S1]
1	Current controller active [FB1-A2,S1]	Speed controller active [FB1-A2,S1]	Position controller active [FB1-A2,S1]	Axis/ spindle stationary ($n < n_{min}$) [FB1-A2,S1]	Follow up mode active [FB1-A2,R1]	Axis ready for operation [FB1-A2 [FB2-B3,P2,K3]	AxAlarm	Traversing requests [FB1-A2]
2		Force fixed stop limited [FB1-F1]	Fixed stop reached [FB1-D1,F1]	Activate travel to fixed stop [FB1-F1]	Measurement active [FB2-M5]	Rotational feedrate active [FB1-V1]	Handwheel override active [FB2-H1]	
3						AxStop Active [FB2-P2]		
4	Travel command [FB1-A2,A3,R1] [FB2-H1,P2] plus	minus	Travel request [FB2-H1] plus	minus		Handwheel active (bit/binary coded) [FB2-H1]	2	1
5	Active machine function [FB2-H1]							
		Contin-uous	var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
6								

DB3900 ... 3907		Signals from axis/spindle [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
7								Contour-handwheel direction of rotation inverted [FB2-H1]
8	PLC axis/spindle	Neutral axis/spindle	Axis exchange possible	New type requested from PLC				NC axis/spindle
9						Parameter set, servo		
						C	B	A
10								
11	PLC axis, permanently assigned [FB2-P2]		POS_ RESTO-[FB1-R1] RED 2 RED 1					

5.9.3.2 Signals from axis

DB3900 ... 3907		Signals from axis [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000				Modulo limit enabled active [FB2-R2]				
1001	Jog-Pos reached	Jog to position active	JogFixPoint - Pos reached [FB2-H1]			ActJogFix - PointPos [FB2-H1]		
			2	1	0	2	1	0
1002	Rotary axis in position	Indexing axis in position [FB2-T1]	Positioning axis [FB2-P2]	Path axis [FB1-K1]				Lubrication pulse [FB1-A2]
1003								VelReducedBy CollCheck

5.9.3.3 Signals from spindle

DB3900 ... 3907		Signals from spindle [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000					Change gear stage [FB1-S1]	Setpoint gear stage [FB1-S1] C B A		
2001	Actual direction of rotation, clockwise [FB1-S1]	Speed monitoring [FB2-W4]	Spindle in setpoint range [FB1-S1]	Overlay range limit violated	Geometry monitoring [FB2-W4]	Setpoint speed [FB1-S1,V1] Increased limited		Speed limit exceeded [FB1-S1]
2002	Active spindle mode [FB1-S1] Control mode Oscillation mode Positioning mode Synchronous mode [FB2-S3]				Rigid tapping [FB1-S1]		GWPS active [FB2-W4]	Const. cutting velocity active [FB1-S1]
2003			Spindle in position reached [FB1-S1]					Tool with dynamic limiting

5.9.3.4 Signals from PLC axis

DB3900 ... 3907		Signals from PLC axis [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Positioning axes active [FB2-P2]	Position reached [FB2-P2]					Fault while traversing [FB2-P2]	Axis cannot be started [FB2-P2]
3001								
3002								
3003	Fault number							

5.9.3.5 Signals from drive

DB3900 ... 3907		Signals from axis/spindle [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000			Holding brake opened	RLI activ				
4001	Pulses enabled [FB1-A2,D1]	Speed controller integrator disabled [FB1-A2,D1]	Drive ready [FB1-A2,D1]			Active parameter set [FB1-A2,D1] C B A		
4002		$n_{act} = n_{set}$ [FB1-A2,D1]	$n_{act} < n_x$ [FB1-A2,D1]	$n_{act} < n_{min}$ [FB1-A2,D1]	$M_d < M_{dx}$ [FB1-A2,D1]	Ramp-up completed [FB1-A2,D1]	Temperature pre-alarm [FB1-A2,D1] Heat sink Motor	
4003					Generator operation, minimum speed fallen below			VDClink < alarm threshold

5.9.3.6 Signals from technology functions

DB3900 ... 3907		Signals from axis/spindle [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	Master/slave active [FB3-TE3]			Master/slave equalization controller active [FB3-TE3]	Master/slave coarse [FB3-TE3]	Master/slave fine [FB3-TE3]		
5001								
5002	ESR reaction initiated [FB2-P2]	Acceleration warning threshold reached	Velocity warning threshold reached	Superimposed motion [FB2-S2]		Actual value coupling	Synchronous operation coarse fine	
5003		Max. acceleration reached	Max. velocity reached	Synchronization in progress	Axis is accelerating	Synchronism override travel	Following spindle active	Leading spindle active
5004								

5.9 Axis/spindle signals

DB3900 ... 3907		Signals from axis/spindle [r]							
		NCK --> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
5005 (gantry)	Gantry axis [FB3-G1]	Gantry leading axis [FB3-G1]	Gantry grouping is in synchronism [FB3-G1]	Synchronism ready [FB3-G1]	Gantry warning threshold exceeded [FB3-G1]	Gantry shutdown limit exceeded [FB3-G1]			
5006									
5007								Synchronism override is factored in	
5008 (grinding)	Active special axis			Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1

5.9.4 Signals from Weiss spindle

DB3900 ... 3907		Signals from axis/spindle [[r]						
[FB1-S1]		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
7000	Sensor configuration							
			Sensor S5 available	Sensor S4 available			Sensor S1 available	Sensor available
7001	Sensorkonfiguration					Status value is generated		
7002	Clamped state (sensor S1)							
7004	Analog value: Clamped state (sensor S1)							
7006	Status, digital sensors							
			Sensor S5 angular position motor shaft	Sensor S4 piston end position				
7007	Status digital sensors							

5.10 Tool management (TM)

5.10.1 User interface, loading, unloading and reloading

5.10.1.1 Acknowledgements for loading, unloading and reloading, positioning the magazine

DB4000 ... 40xx ¹ [Commissioning Manual Turning, Milling]		Signals to TM [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Acknowledgment step 7	Acknowledgment step 6	Acknowledgment step 5	Acknowledgment step 4	Acknowledgment step 3	Acknowledgment step 2	Acknowledgment step 1	Total acknowledgement
1	Acknowledgment step 15	Acknowledgment step 14	Acknowledgment step 13	Acknowledgment step 12	Acknowledgment step 11	Acknowledgment step 10	Acknowledgment step 9	Acknowledgment step 8
2	Acknowledgment step 23	Acknowledgment step 22	Acknowledgment step 21	Acknowledgment step 20	Acknowledgment step 19	Acknowledgment step 18	Acknowledgment step 17	Acknowledgment step 16
3	Reserved	Acknowledgment step 30	Acknowledgment step 29	Acknowledgment step 28	Acknowledgment step 27	Acknowledgment step 26	Acknowledgment step 25	Acknowledgment step 24
4	Reserved							
6	Reserved							
7	Reserved							
8	Reserved							
9								Acknowledge error reset
10	Reserved							
12	Reserved							
14	Reserved							
16	Reserved							

1. xx = loading position

5.10.1.2 Jobs for loading, unloading and reloading, positioning the magazine

DB4100 ... 41xx ¹ [Commissioning Manual Turning, Milling]		Signals from TM [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								Job
1				Job from NC program	Positioning	Relocating	Unloading	Loading
2	Reserved							
4	Reserved							
5	Reserved							
6	Source magazine no. (INT)							
8	Source location no. (INT)							
10	Target magazine no. (INT)							
12	Target location no. (INT)							
14 HMI → PLC								Load/ unload without moving magazine

1. xx = loading position

5.10.1.3 Feedback signal

DB4100 ... 41xx ¹ [Commissioning Manual Turning, Milling]		Signals from TM [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
100							Acknowledgment error	Acknowledgment OK
101	Reserved							
102	Reserved							
103	Reserved							
104	Error status (WORD)							
106	Reserved							
107	Reserved							
108	Acknowledgment step 7	Acknowledgment step 6	Acknowledgment step 5	Acknowledgment step 4	Acknowledgment step 3	Acknowledgment step 2	Acknowledgment step 1	Acknowledgment step
109	Acknowledgment step 15	Acknowledgment step 14	Acknowledgment step 13	Acknowledgment step 12	Acknowledgment step 11	Acknowledgment step 10	Acknowledgment step 9	Acknowledgment step 8
110	Acknowledgment step 23	Acknowledgment step 22	Acknowledgment step 21	Acknowledgment step 20	Acknowledgment step 19	Acknowledgment step 18	Acknowledgment step 17	Acknowledgment step 16
111	Reserved	Acknowledgment step 30	Acknowledgment step 29	Acknowledgment step 28	Acknowledgment step 27	Acknowledgment step 26	Acknowledgment step 25	Acknowledgment step 24

1. xx = loading position

5.10.1.4 Job status

DB4100 ... 41xx ¹ [Commissioning Manual Turning, Milling]		Job status [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
120	Reserved							
121	Reserved							
122	Reserved							
124	Current magazine no. of the tool (INT)							
126	Current location no. of the tool (INT)							
128	Magazine no., target (INT)							
130	Location no., target (INT)							

1. xx = loading position

5.10.2 User interface, tool change

5.10.2.1 Preparing and carrying out acknowledgements for tool change

DB4200 ... 42xx ¹ [Commissioning Manual Turning, Milling]		Signals to TM [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Acknowledgment step 7	Acknowledgment step 6	Acknowledgment step 5	Acknowledgment step 4	Acknowledgment step 3	Acknowledgment step 2	Acknowledgment step 1	Total acknowledgment
1	Acknowledgment step 15	Acknowledgment step 14	Acknowledgment step 13	Acknowledgment step 12	Acknowledgment step 11	Acknowledgment step 10	Acknowledgment step 9	Acknowledgment step 8
2	Acknowledgment step 23	Acknowledgment step 22	Acknowledgment step 21	Acknowledgment step 20	Acknowledgment step 19	Acknowledgment step 18	Acknowledgment step 17	Acknowledgment step 16
3	Reserved	Acknowledgment step 30	Acknowledgment step 29	Acknowledgment step 28	Acknowledgment step 27	Acknowledgment step 26	Acknowledgment step 25	Acknowledgment step 24
4	Reserved							
6	Reserved							
7	Reserved							

DB4200 ... 42xx ¹ [Commissioning Manual Turning, Milling]		Signals to TM [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
8	Reserved							
9								Acknowledge error reset
10	Reserved							
12	Reserved							
14	Reserved							
16	Reserved							
18	Reserved							
20	Reserved							
22	Reserved							
24	Reserved							

1. xx = tool holder

5.10.2.2 Prepare jobs for tool change and execute.

DB4300 ... 43xx ¹ [Commissioning Manual Turning, Milling]		Signals from TM [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								Job
1	Tool remains in spindle	Manual tool Unload	Manual tool Load	No old tool	T0	Prepare change	Change tool (initiated by: M06)	Fixed-location coded
2	Reserved							
4	Reserved							
5	Reserved							
6	Source magazine no. for new tool (INT)							

DB4300 ... 43xx ¹ [Commissioning Manual Turning, Milling]		Signals from TM [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
8	Source location no. for new tool (INT)							
10	Reserved							
12	Reserved							
14	Reserved							
16	Reserved							
18	Target magazine no. for old tool (INT)							
20	Target location no. for old tool (INT)							
22	Location type (INT)							
24	Size, left (INT)							
26	Size, right (INT)							
28	Reserved							
30	Reserved							
32	-	-	-	Tribe tool	loading	unloading	closed	Signal for tool
33	Tool has been in use	Tool fixed-location coded	Tool alternating	Pre-warning limit reached	Measuring tools	Blocked	Tool released	Active tool
34	New tool: Internal T no. of NCK (INT)							
36	Reserved (DWORD)							
40	Reserved (DWORD)							
44	User-defined parameter 1 (DWORD)							
48	User-defined parameter 2 (DWORD)							
52	User-defined parameter 3 (DWORD)							

1. xx = tool holder

5.10.2.3 Feedback signal

DB4300 ... 43xx ¹ [Commissioning Manual Turning, Milling]		Signals from TM [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
100							Acknowledgment error	Acknowledgment OK
101	Reserved							
102	Reserved							
103	Reserved							
104	Fehlerstatus (WORD)							
106	Reserved							
107	Reserved							
108	Acknowledgment step 7	Acknowledgment step 6	Acknowledgment step 5	Acknowledgment step 4	Acknowledgment step 3	Acknowledgment step 2	Acknowledgment step 1	Acknowledgment step
109	Acknowledgment step 15	Acknowledgment step 14	Acknowledgment step 13	Acknowledgment step 12	Acknowledgment step 11	Acknowledgment step 10	Acknowledgment step 9	Acknowledgment step 8
110	Acknowledgment step 23	Acknowledgment step 22	Acknowledgment step 21	Acknowledgment step 20	Acknowledgment step 19	Acknowledgment step 18	Acknowledgment step 17	Acknowledgment step 16
111	Reserved	Acknowledgment step 30	Acknowledgment step 29	Acknowledgment step 28	Acknowledgment step 27	Acknowledgment step 26	Acknowledgment step 25	Acknowledgment step 24

1. xx = tool holder

5.10.2.4 Job status

DB4300 ... 43xx ¹ [Commissioning Manual Turning, Milling]		Job status [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
120	Reserved							
121	Reserved							
122	Reserved							
124	Current magazine no. for new tool (INT)							
126	Current location no. for new tool (INT)							
128	Magazine no. for new tool, target (INT)							
130	Location no. for new tool, target (INT)							
132	Current magazine no. for old tool (INT)							
134	Current location no. for old tool (INT)							
136	Magazine no. for old tool, target (INT)							
138	Location no. for old tool, target (INT)							

1. xx = tool holder

5.11 PLC machine data

5.11.1 INT values (MD 14510 USER_DATA_INT)

DB4500		Signals from NCK [r16] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Int value (WORD/2 byte)							
2	Int value (WORD/2 byte)							
4	Int value (WORD/2 byte)							
6	Int value (WORD/2 byte)							
...	...							
60	Int value (WORD/2 byte)							
62	Int value (WORD/2 byte)							

5.11.2 HEX values (MD 14512 USER_DATA_HEX)

DB4500		Signals from NCK [r8] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Hex value (BYTE)							
1001	Hex value (BYTE)							
1002	Hex value (BYTE)							
1003	Hex value (BYTE)							
...	...							
1030	Hex value (BYTE)							
1031	Hex value (BYTE)							

5.11.3 FLOAT values (MD 14514 USER_DATA_FLOAT)

DB4500		Signals from NCK [r32] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Float value (REAL/4 byte)							
2004	Float value (REAL/4 byte)							
2008	Float value (REAL/4 byte)							
2012	Float value (REAL/4 byte)							
2016	Float value (REAL/4 byte)							
2020	Float value (REAL/4 byte)							
2024	Float value (REAL/4 byte)							
2028	Float value (REAL/4 byte)							

5.11.4 User alarm: Configuring (MD 14516 USER_DATA_PLC_ALARM)

DB4500		Signals from NCK [r8] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Alarm response/cancel criteria, alarm 700000							
3001	Alarm response/cancel criteria, alarm 700001							
3002	Alarm response/cancel criteria, alarm 700002							
...	...							
3247	Alarm response/cancel criteria, alarm 700247							

Note:

Information on PLC alarms including configuring user alarms is provided in:

Literature: "Turning and Milling Commissioning Manual"

5.12 Signals, synchronized actions

5.12.1 Signals, synchronized actions to channel

DB4600		Signals, synchronized actions to channel [r/w]						
PLC --> HMI interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	ID8	ID7	ID6	ID5	ID4	ID3	ID2	ID1
Deactivate synchronized action with ID...								
1	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9
Deactivate synchronized action with ID...								
2	ID24	ID23	ID22	ID21	ID20	ID19	ID18	ID17
Deactivate synchronized action with ID...								
3	ID32	ID31	ID30	ID29	ID28	ID27	ID26	ID25
Deactivate synchronized action with ID...								
4	ID40	ID39	ID38	ID37	ID36	ID35	ID34	ID33
Deactivate synchronized action with ID...								
5	ID48	ID47	ID46	ID45	ID44	ID43	ID42	ID41
Deactivate synchronized action with ID...								
6	ID56	ID55	ID54	ID53	ID52	ID51	ID50	ID49
Deactivate synchronized action with ID...								
7	ID64	ID63	ID62	ID61	ID60	ID59	ID58	ID57
Deactivate synchronized action with ID...								

5.12.2 Signals, synchronized actions from channel

DB4700		Signals, synchronized actions from channel [r]						
NCK --> PLC interface								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	ID8	ID7	ID6	ID5	ID4	ID3	ID2	ID1
Synchronized action with ID... can be blocked from the PLC								
1	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9
Synchronized action with ID... can be blocked from the PLC								
2	ID24	ID23	ID22	ID21	ID20	ID19	ID18	ID17
Synchronized action with ID... can be blocked from the PLC								
3	ID32	ID31	ID30	ID29	ID28	ID27	ID26	ID25
Synchronized action with ID... can be blocked from the PLC								
4	ID40	ID39	ID38	ID37	ID36	ID35	ID34	ID33
Synchronized action with ID... can be blocked from the PLC								
5	ID48	ID47	ID46	ID45	ID44	ID43	ID42	ID41
Synchronized action with ID... can be blocked from the PLC								
6	ID56	ID55	ID54	ID53	ID52	ID51	ID50	ID49
Synchronized action with ID... can be blocked from the PLC								
7	ID64	ID63	ID62	ID61	ID60	ID59	ID58	ID57
Synchronized action with ID... can be blocked from the PLC								

5.13 Reading and writing PLC variables

DB4900		PLC variables [r/w]						
		PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Offset [0]							
1	Offset [1]							
2	Offset [2]							
...	...							
4094	Offset [4094]							
4095	Offset [4095]							

The user's programming engineer (NCK and PLC) is responsible for organizing (structuring) this memory area. Every storage position in the memory can be addressed provided that the limit is selected according to the appropriate data format (i.e. a 'DWORD' for a 4byte limit, a WORD for a 2byte limit, etc.). The memory area is always accessed with the information about the data type and the position offset within the memory area.

5.14 TM functions from NC channel

5.14.1 Change signals TM functions

DB5300		TM functions [r]						
		NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0							Tool limit value reached	Tool pre-alarm limit reached
1								
2								
3								

5.14.2 Transferred tool management functions

DB5300		TM functions [r32] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	T number for tool advance warning limit (DINT)							
1004	T number for tool limit value (DINT)							
1008								
1012								

5.15 Axis actual values and distances-to-go

DB5700 ... 5704		Signals from axis/spindle [r] NCK --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Axis actual value (REAL)							
4	Axis distance-to-go (REAL)							

Note:

The axis actual values and distances-to-go can be separately requested:

- DB2600.DBX0001.1 Request axis actual values
- DB2600.DBX0001.2 Request axis distances-to-go

If the particular request is set, then the NCK supplies these values for all axes.

5.16 TM: User interface, transfer and acknowledgement step tables

5.16.1 Constant transfer-step table

DB9900 [Commissioning Manual Turning, Milling]		Constant transfer-step table [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Transfer step 1 Source magazine no. (INT)							
2	Transfer step 1 Source location no. (INT)							
4	Transfer step 1 Target magazine no. (INT)							
6	Transfer step 1 Target location no. (INT)							
8	Transfer step 2 Source magazine no. (INT)							
10	Transfer step 2 Source location no. (INT)							
12	Transfer step 2 Target magazine no. (INT)							
14	Transfer step 2 Target location no. (INT)							
...	...							
504	Transfer step 64 Source magazine no. (INT)							
506	Transfer step 64 Source location no. (INT)							
508	Transfer step 64 Target magazine no. (INT)							
510	Transfer step 64 Target location no. (INT)							

5.16.2 Variable transfer-step table

DB9901 [Commissioning Manual Turning, Milling]		Variable transfer step table [r/w]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Transfer step 101 Source magazine no. (INT)							
2	Transfer step 101 Source location no. (INT)							
4	Transfer step 101 Target magazine no. (INT)							
6	Transfer step 101 Target location no. (INT)							
8	Transfer step 102 Source magazine no. (INT)							
10	Transfer step 102 Source location no. (INT)							
12	Transfer step 102 Target magazine no. (INT)							
14	Transfer step 102 Target location no. (INT)							
...	...							
504	Transfer step 164 Source magazine no. (INT)							
506	Transfer step 164 Source location no. (INT)							
508	Transfer step 164 Target magazine no. (INT)							
510	Transfer step 164 Target location no. (INT)							

5.16.3 Acknowledgment step table

DB9902 [Commissioning Manual Turning, Mill- ing]		Acknowledgment-step table [r]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Acknowledgment step 1 Transfer step for new tool (BYTE)							
1	Acknowledgment step 1 Transfer step for old tool (BYTE)							
2	Acknowledgment step 1 Acknowledgement status (BYTE)							
3	Acknowledgment step 1 Reserved							
4	Acknowledgment step 2 Transfer step for new tool (BYTE)							
5	Acknowledgment step 2 Transfer step for old tool (BYTE)							
6	Acknowledgment step 2 Acknowledgement status (BYTE)							
7	Acknowledgment step 2 Reserved							
...	...							
116	Acknowledgment step 30 Transfer step for new tool (BYTE)							
117	Acknowledgment step 30 Transfer step for old tool (BYTE)							
118	Acknowledgment step 30 Acknowledgement status (BYTE)							
119	Acknowledgment step 30 Reserved							

5.17 Maintenance scheduler: User interface

5.17.1 Initial (start) data

DB9903 [Commissioning Manual Turning, Milling]		Initial data table [r16]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Interval 1 [h]							
2	Time of first warning 1 [h]							
4	Number of warnings to be output 1							
6	reserved 1							
8	Interval 2 [h]							
10	Time of first warning 2 [h]							
12	Number of warnings to be output 2							
14	reserved 2							
...	...							
248	Interval 32 [h]							
250	Time of first warning 32 [h]							
252	Number of warnings to be output 32							
254	reserved 32							

5.17.2 Actual data

DB9904 [Commissioning Manual Turning, Mill- ing]		Actual data table [r16]						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Interval 1 [h]							
2	Number of warnings output 1							
4	Reserved_1 1							
6	Reserved_2 1							
8	Interval 2 [h]							
10	Number of warnings output 2							
12	Reserved_1 2							
14	Reserved_2 2							
...	...							
248	Interval 32 [h]							
250	Number of warnings output 32							
252	Reserved_1 32							
254	Reserved_2 32							

5.17.3 Easy Extend Interface

DB9905		Easy Extend Interface [r/w]						
[Commissioning Manual Turning, Milling]		HMI --> PLC interface						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0						De-activate_1	activate_1	Enable_1
1								
2							Error_1	IsActive_1
3	DeviceID_1							
4						De-activate_2	activate_2	Enable_2
5								
6							Error_2	IsActive_2
7	DeviceID_2							
252						Deactivate_64	Activate_64	Enable_64
253								
254							Error_64	IsActive_64
255	DeviceID_64							

5.18 User interface for ctrl energy

5.18.1 Energy saving profile

DB9906	Ctrl energy							
[System manual Ctrl energy]	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Control signals						Set time to pre-warning limit	Immediately activate energy saving profile
1	Control signals (HMI --> PLC)							Energie-sparprofil sofort aktivieren
2	Signals to check/test the energy-saving profile						PLC user signal	Master computer signal
3	Reserved							
4	Status signal						Activation time T1 expired	Energy saving profile active
5	Reserved							
6	Actual value: Actual value T1							
8	Actual value: Actual value T2							
10	Effectiveness, profile						Disable energy saving profile	Energy-saving profile configured
11	State conditions (HMI --> PLC)					Screen change	Data transfer	Operator panel
12	State conditions (HMI --> PLC)							Maschine control panel
13	State conditions (HMI --> PLC)							NC channel 1 in reset
14								

DB9906		Ctrl energy						
[System manual Ctrl energy]								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	State conditions (HMI → PLC)							
15							PLC user signal	Master computer signal
	State conditions (HMI → PLC) Activation time T1							
16								
	State conditions (HMI → PLC) Pre-warning time T2							
18								

Additional profile instances:

Energy profile 2: DB9906.DBB20 ... DBB39

Energy profile 3: DB9906.DBB40 ... DBB59

Energy profile 4: DB9906.DBB60 ... DBB79

Energy profile 5: DB9906.DBB80 ... DBB99

Energy profile 6: DB9906.DBB100 ... DBB119

Energy profile 7: DB9906.DBB120 ... DBB139

Energy profile 8: DB9906.DBB140 ... DBB159

5.18.2 SentronPac

DB9907 [Systemhandbuch Ctrl Energy]		SentronPac						
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 PLC -> HMI					regenera- tive energy is read from the Sen- tronPac	supplied energy is read from the Sen- tronPac	Sentron- Pac repre- sents the machine	Display manual value
1								
2 HMI -> PLC								Measure- ment is running
3								
4	Manual value (REAL)							
8	Total active power (REAL)							
12	Referred active power, tariff 1 (REAL)							
16	Supplied active power, tariff 1 (REAL)							

Interface signals - detailed description

6.1 General information

Interfaces

The PLC user interface exchanges signals and data with the following units via the PLC user program:

- NCK (NC kernel),
- HMI (display unit)

Signal and data are exchanged via different data areas.

The PLC user program need not take care of the exchange which is performed automatically from the user's view.




Fig. 6-1 PLC user interface

Cyclic signal exchange

The control and status signals of the PLC/NCK interface are updated cyclically.

The signals can be subdivided into the following groups (see Fig. 6-1):

- General signals
- Mode signals
- Channel signals
- Axis/spindle signals

6.2 User alarm

6.2.1 Active alarm response

DB1600 DBX2000.0	NC start disable Signal(s) from PLC → HMI	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The NC start disable prevents a part program from being started with the NC start signal DB3200 DBX7.1 (NC start) == 1.	
Signal state 0	The NC start disable is not active.	
Special cases, errors, ...	The start of a part program selected in the channel by part program command START in another channel (program coordination) is not prevented by the interface signal: DB3200 DBX7.0 (NC start disable) == 1.	
corresponding to ...	IS "NC start"	
Note for the reader		

DB1600 DBX2000.1	Read-in disable Signal(s) from PLC → HMI	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The main run reads in no more preprocessed part program blocks. Note: The signal is only active in the AUTOMATIC and MDI modes.	
Signal state 0	The main run reads in preprocessed part program blocks.	
corresponding to ...	IS "Program status running"	
Note for the reader		

6.3 Signals from/to HMI

6.3.1 Program control signals from the HMI

DB1700 DBX0.3	DRF selected Signal(s) from HMI → PLC
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The operator has selected DRF on the operator panel front. The PLC program (basic PLC program or user program) transfers this HMI interface signal to the interface signal corresponding to the logic operation: Activate DRF. As soon as DRF is active, the DRF offset can be changed in the AUTOMATIC or MDI mode using the handwheel assigned to the axis.
Signal state 0	The operator has not selected DRF on the operator panel front.
corresponding to ...	JOG mode
Note for the reader	Activate DRF

DB1700 DBX0.5	M01 selected Signal(s) from HMI → PLC
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Activate program control M1 has been selected from the operator interface. This does not activate the function.
Signal state 0	Activate program control M1 has not been selected from the operator interface.
corresponding to ...	IS "Activate M01" IS "M0/1 active"
Note for the reader	Function Manual Basic Functions K1

DB1700 DBX0.6	Dry run feedrate selected Signal(s) to channel (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Dry run feedrate is selected. Instead of the programmed feedrate, the dry run feedrate entered in SD 42100: DRY_RUN_FEED is active. When activated from the operator panel, the dry run feedrate signal is automatically entered in the PLC interface and transferred by the PLC basic program to the PLC interface signal "Activate dry run feedrate".
Signal state 0	Dry run feedrate is not selected. The programmed feedrate is active.
corresponding to ...	IS "Activate dry run feedrate" (DB3200 DBX0.6) SD: DRY_RUN_FEED (dry run feedrate)
Note for the reader	Function Manual Basic Functions V1, K1

6.3 Signals from/to HMI

DB1700 DBX1.3	Feedrate override selected for rapid traverse Signal(s) to channel (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The feedrate override switch should also be active as rapid traverse override switch. Override values above 100% are limited to the maximum value for 100% rapid traverse override. The IS "Feedrate override for rapid traverse selected" is automatically entered from the operator panel into the PLC interface and is transferred from the basic PLC program to the PLC interface signal "Rapid traverse override active". Further, the IS "Feedrate override" (DB3200 DBB4) is copied from the basic PLC program into the IS "Rapid traverse override" (DB3200 DBB5).
Signal state 0	The feedrate override switch should not be activated as rapid traverse override switch.
Application	The signal is used when no separate rapid traverse override switch is available.
Note for the reader	Function Manual Basic Functions V1

DB1700 DBX1.7	Program test selected Signal(s) from HMI → PLC
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Program control program test has been selected from the operator interface. This does not activate the function.
Signal state 0	Program control program test has not been selected from the operator interface.
corresponding to ...	IS "Activate program test" IS "Program test active"
Note for the reader	Function Manual Basic Functions V1

DB1700 DBX2.0 to 3.1	Skip block selected Signal(s) from HMI → PLC
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Program control – skip block – has been selected from the operator interface. This does not activate the function.
Signal state 0	Program control – skip block – has not been selected from the operator interface.
corresponding to ...	IS "Activate skip block"
Note for the reader	Function Manual Basic Functions K1

DB1700 DBX7.1	NC start Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>AUTOMATIC mode:</p> <p>The selected NC program is started or continued, or the auxiliary functions that were saved during the program interruption are output.</p> <p>If data is transferred from the PLC to the NC during program status "Program interrupted," then this data is immediately processed with NC start.</p> <p>MDI mode:</p> <p>The entered block information or part program blocks are released for execution.</p>
Signal state 0 or edge change 1 → 0	No effect.
Note for the reader	Function Manual Basic Functions K1

DB1700 DBX7.3	NC stop Signal(s) to PLC (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>AUTOMATIC or MDI mode:</p> <p>Execution of the active part program in the channel is stopped. The axes (not spindles) are braked to a standstill maintaining the parameterized acceleration rates.</p> <ul style="list-style-type: none"> · Program status: Stopped · Channel status: Interrupted <p>JOG mode:</p> <p>In the JOG mode, incompletely traversed incremental paths (INC...) are executed at the next NC start.</p> <p>Note:</p> <p>If data is transferred to the NCK after NC stop (e.g. tool offset), then this data is processed with the next NC start.</p>
Signal state 0	No effect.
corresponding to ...	<p>DB3300 DBX3.2 (program status stopped)</p> <p>DB3300 DBX3.6 (channel status interrupted)</p>
Note for the reader	Function Manual Basic Functions K1

DB1700 DBX7.7	Reset Signal(s) to PLC (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The channel is reset. The initial settings are made (e.g. for G functions). The channel alarms are deleted if they are not POWER ON alarms. The "Reset" signal must be issued by the PLC (e.g. using a logic operation with the reset key on the MCP). The signal is only evaluated by the selected channel. The program status changes to "Interrupted".
Signal state 0	No effect.
corresponding to ...	DB3300 DBX3.7 (channel status reset)
Note for the reader	Function Manual Basic Functions K1

6.3.2 Signals from HMI

DB1800 DBX0.0	AUTOMATIC mode Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	AUTOMATIC mode is selected from the HMI. The signal state 1 is only available for one PLC cycle.
Signal state 0	AUTOMATIC mode is not selected by HMI.
Signal irrelevant for ...	if signal "Mode change disable"
Note for the reader	Function Manual Basic Functions M5

DB1800 DBX0.1	MDI mode Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	MDI mode is selected from the HMI. The signal state 1 is only available for one PLC cycle.
Signal state 0	MDI mode is not selected by HMI.
Signal irrelevant for ...	if signal "Mode change disable"
Note for the reader	Function Manual Basic Functions M5

DB1800 DBX0.2	JOG mode Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	JOG mode is selected from the HMI. The signal state 1 is only available for one PLC cycle.
Signal state 0	JOG mode is not selected by HMI.
Signal irrelevant for ...	if signal "Mode change disable"
Note for the reader	Function Manual Basic Functions M5

DB1800 DBX0.7	Reset
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	A reset is initiated for the channel period. All of the current programs are then in the program status "Aborted". All moving axes and spindles are decelerated to zero speed according to their acceleration ramp without contour violation. The initial settings are set (e.g. for G functions). The alarms are cleared if they are not POWER ON alarms.
Signal state 0 or edge change 1 → 0	Channel status and program execution are not influenced by this signal.
Special cases, errors, ...	An alarm that withdraws the IS "828 READY" (DB3100 DBX0.3), ensures that the channel is no longer in the reset state. In order to switch to another mode, a reset (DB1800 DBX0.7) must be initiated.
Note for the reader	

DB1800 DBX1.0	Active machine function TEACH IN Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The machine function TEACH IN is selected in the JOG mode. The signal state 1 is only available for one PLC cycle.
Signal state 0	The machine function TEACH IN is not selected.
Signal irrelevant for ...	if JOG mode is not active.
Note for the reader	Function Manual Basic Functions M5

DB1800 DBX1.2	Active machine function REF Signal(s) to PLC (HMI → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The machine function REF is selected in the JOG mode The signal state 1 is only present for one PLC cycle.
Signal state 0	The machine function REF is not selected.
Signal irrelevant for ...	if JOG mode is not active.
Note for the reader	Function Manual Basic Functions M5

6.3.3 Signals from PLC

DB1800 DBX1000.6	Commissioning archive was read in	
Edge evaluation:	Signal(s) updated:	
Meaning	Is set, if a commissioning archive or a data class file tree was read in and is present for one PLC cycle. The PLC system then deletes the signal.	

6.3.4 Signals from operator panel

DB1900 DBX0.6	Simulation active Signal(s) from HMI → PLC	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The function – Simulation – has been selected from the operator interface.	
Signal state 0	The function – Simulation – has not been selected from the operator interface.	
corresponding to ...	if JOG mode is not active.	
Note for the reader	Function Manual Basic Functions K1	

DB1900 DBX0.7	Switch over Machine/Work Signal(s) from HMI → PLC	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The coordinate system is switched over from workpiece coordinate system (Work) to machine coordinate system (Machine) or from Machine to Work. After actuation, the signal is present for 1 PLC cycle.	
Signal state 0	No effect.	
Application example	The interface signal: DB1900 DBX0.7 (switchover Machine/Work) must be transferred to the interface signal: DB1900 DBX5000.7 (actual value in Work) in order that switchover becomes effective.	
corresponding to ...	DB1900 DBX5000.7 (actual value in Work)	

6.3.5 General selection/status signals from HMI

DB1900 DBX1003.0 to .2 DBX1004.0 to .2	Axis number for handwheel 1 for handwheel 2 Signal(s) from NC (HMI → PLC)																												
Edge evaluation: No	Signal(s) updated: Cyclic																												
Significance of signal	<p>The operator can assign an axis to every handwheel directly at the operator panel. To do so, he defines the required axis (e.g. X).</p> <p>The axis number associated with the axis and the information "machine or geometry axis" (IS "machine axis") is made available as HMI interface signal in the PLC user interface.</p> <p>The interface signal "Activate handwheel" must be set for the specified axis from the PLC user program. Depending on the setting in the HMI interface signal "machine axis", either the interface for the geometry axis or for the machine axis is used.</p> <p>The following must be noted when assigning the axis identifier to the axis number:</p> <ul style="list-style-type: none"> · IS "Machine axis" = 1; i.e. the machine axis - not the geometry axis: The assignment is made via MD10000 AXCONF_MACHAX_NAME_TAB[n] (machine axis name). · IS "Machine axis" = 0; i.e. geometry axis (axis in the Work): The assignment is made via MD20060 AXCONF_GEOAX_NAME_TAB[n] (geometry axis name in the channel). The channel number assigned to the handwheel is specified using IS "Channel number geometry axis handwheel n". <p>The following codes are used for the axis number:</p> <table style="margin-left: 40px;"> <thead> <tr> <th>Bit 2</th> <th>Bit 1</th> <th>Bit 0</th> <th>Axis number</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>-</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>2</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>3</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>4</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>5</td> </tr> </tbody> </table> <p>Note: Bit 3 and bit 4 must always be kept at the value = 0..</p>	Bit 2	Bit 1	Bit 0	Axis number	0	0	0	-	0	0	1	1	0	1	0	2	0	1	1	3	1	0	0	4	1	0	1	5
Bit 2	Bit 1	Bit 0	Axis number																										
0	0	0	-																										
0	0	1	1																										
0	1	0	2																										
0	1	1	3																										
1	0	0	4																										
1	0	1	5																										
corresponding to ...	<p>IS "Machine axis" (DB1900 DBX1003.7, DB1900 DBX1004.7)</p> <p>IS "Activate handwheel" 1 to 2 / geometry axes 1, 2 (DB3200 DBX1000.0 to .2, DB3200 DBX1004.0 to .2, DB3200 DBX1008.0 to .2)</p> <p>IS "Activate handwheel" 1 to 2 (DB380x DBX4.0 to .1)</p> <p>MD10000 AXCONF_MACHAX_NAME_TAB [n] (machine axis name)</p> <p>MD20060 AXCONF_GEOAX_NAME_TAB [n] (geometry axis name in the channel)</p>																												
Note for the reader	Function Manual Basic Functions H1																												

6.3 Signals from/to HMI

DB1900 DBX1003.5 DBX1004.5	Define handwheel 1 as contour handwheel Define handwheel 2 as contour handwheel Signal(s) from NC (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The handwheel is defined as contour handwheel via the HMI.
Signal state 0	The handwheel is not defined as contour handwheel.
Application	In order that the handwheel, defined from the HMI, is effective as contour handwheel, then the IS "Activate handwheel 1/2 as contour handwheel" must also be set to "1".
corresponding to ...	DB3200 DBX14.0/.1 (activate handwheel 1/2 as contour handwheel)
Note for the reader	Function Manual Basic Functions H1

DB1900 DBX1003.6 DBX1004.6	Handwheel selected for handwheel 1 for handwheel 2 Signal(s) from NC (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The operator has selected the handwheel for the defined axis via the operator panel front (i.e. activated). The basic PLC program provides this information to the HMI interface. The basic PLC program sets the interface signal "Activate handwheel" for the defined axis to "1". The associated axis is also displayed at the HMI interface via the IS "Machine axis" and "Axis number for handwheel". As soon as the handwheel is active, the axis can be traversed in JOG mode with the handwheel: IS "Handwheel active" = 1.
Signal state 0	The operator has disabled the handwheel for the defined axis at the operator panel front. The basic PLC program provides this information to the HMI interface. This means that for the specified axis, the IS "Activate handwheel" can be set to "0" from the basic PLC program.
corresponding to ...	DB1900 DBX1003.0 - .2 (axis number for handwheel 1) DB1900 DBX1004.0 - .2 (axis number for handwheel 2) DB1900 DBX1003.7/1004.7 (machine axis for handwheel 1/2) DB380x DBX4.0/.1 (activate handwheel 1/2) DB390x DBX4.0/.1 (handwheel 1/2 active)
Note for the reader	Function Manual Basic Functions H1

DB1900 DBX1003.7 DBX1004.7	Machine axis for handwheel 1 for handwheel 2 Signal(s) from NC (HMI → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The operator has assigned an axis to the handwheel (1, 2) directly at the operator panel. This axis is a machine axis – no geometry axis (axis in the Work). For further information see IS "Axis number".
Signal state 0	The operator has assigned an axis to the handwheel (1, 2) directly at the operator panel. This axis is a geometry axis (axis in the Work). For further information see IS "Axis number".
corresponding to ...	IS "Axis number" (DB1900 DBX3.0 to .4, ff)
Note for the reader	Function Manual Basic Functions H1

6.3.6 General selection/status signals to the HMI

DB1900 DBX5000.2	OP key lock Signal(s) from PLC → HMI
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The OP keyboard is locked for the user.
Signal state 0	The OP keyboard is enabled for the user.

DB1900 DBX5000.7	Actual value in the Work Signal(s) from PLC → HMI
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC selects the display of actual values in the workpiece coordinate system (Work). This means that when the machine area is selected, the Work display is activated; i.e. the machine and the supplementary axes as well as their actual positions and distances to go are displayed in the Work in the "Position" window. The interface signal is only evaluated when it enters the basic machine screen; this means that the operator, within the machine area, can toggle as required between the particular coordinate systems using the softkeys "actual values Machine" and "actual values Work".
Signal state 0	This means that when the machine area is selected the coordinate system previously selected (Work or Machine) is reactivated and displayed.
corresponding to ...	DB1900 DBX0.7 (switchover Machine/Work)
Note for the reader	Operating manual (corresponding to the software being used)

6.4 Auxiliary function transfer from NC channel

DB2500 DBX4.0 to .4 DBX6.0 DBX8.0 DBX10.0 DBX12.0 to .2	M function Change 1 to 5 S function Change 1 T function Change 1 D function Change 1 H function Change 1 to 3 Signal(s) from channel (PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	M, S, T, D, H information was output at the interface together with a new value and the associated change signal. In this case, the change signal indicates that the corresponding value is valid. The change signals are only valid for one PLC cycle! This means that if the signal is 1, then a change is pending for this cycle.
Signal state 0	The value of the data involved is not valid.
Note for the reader	Function Manual Basic Functions H2

DB2500 DBB1000 to DBB1012	Decoded M signals: M0 - M99 Signal(s) from channel (NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The dynamic M signal bits are set by decoded M functions.
Signal state 0	For a general auxiliary function output, the dynamic M signal bits are acknowledged by the PLC system program after the user program has been completely run-through (executed once).
Application	Spindle clockwise/counterclockwise rotation, switch coolant on/off
corresponding to ...	IS "M function for the spindle (DINT), axis-specific" (DB370x DBD0)
Note for the reader	Function Manual Basic Functions H2

DB2500 DBD2000	T function 1 Signal(s) from channel (PLC)
Edge evaluation: No	Signal(s) updated: job-controlled by NCK
Signal state 1	The T function programmed in an NC block is made available here as soon as the T change signal is available. Value range of the T function: 0-32000 ; integer number The T function remains valid until it is overwritten by a new T function.
Signal state 0	· After the PLC has ramped-up. · All auxiliary functions are deleted before a new function is entered.
Application	Control of automatic tool selection.
Special cases, errors, ...	With T0, the actual tool is removed from the tool holder but not replaced by a new tool (default configuration of the machine manufacturer).
Note for the reader	Function Manual Basic Functions H2

DB2500		
DBD3000	M function 1	
DBD3008	M function 2	
DBD3016	M function 3	
DBD3024	M function 4	
DBD3032	M function 5	
DBB3004	Extended address of M function 1	
DBB3012	Extended address of M function 2	
DBB3020	Extended address of M function 3	
DBB3028	Extended address of M function 4	
DBB3036	Extended address of M function 5	
	Signal(s) from channel (PLC)	
Edge evaluation: No	Signal(s) updated: job-controlled by NCK	
Signal state 1	Up to 5 M functions programmed in an NC block are simultaneously made available here as soon as the M change signals are available. Value range of the M functions: 0 to 99; integer number Value range of the extended address: 1-2; integer number (spindle number) The M functions remain valid until they are overwritten by new M functions.	
Signal state 0	<ul style="list-style-type: none"> · After the PLC has ramped-up. · All auxiliary functions are deleted before a new function is entered. 	
Application	Control of automatic tool selection.	
corresponding to ...	IS "M function for the spindle (DINT), axis-specific" (DB370x DBD0)	
Note for the reader	Function Manual Basic Functions H2	

DB2500		
DBD4000	S function 1	
DBD4008	S function 2	
DBB4004	Extended address of S function 1	
DBB4012	Extended address of S function 2	
	Signal(s) from channel (PLC)	
Edge evaluation: No	Signal(s) updated: job-controlled by NCK	
Signal state 1	Here, an S function programmed in an NC block (speed or cutting value for G96) is provided as soon as the S change signal is available. Value range of the S function: Floating point (REAL format/4 bytes) Value range of the extended address: 1 ... 2; integer number (spindle number) The S function remains valid until it is overwritten by a new S function.	
Signal state 0	<ul style="list-style-type: none"> · After the PLC has ramped-up. · All auxiliary functions are deleted before a new function is entered. 	
Application	Control of automatic tool selection.	
corresponding to ...	IS "S function for the spindle (REAL), axis-specific" (DB370x DBD4)	
Note for the reader	Function Manual Basic Functions H2	

6.4 Auxiliary function transfer from NC channel

DB2500 DBD5000	D function 1 Signal(s) from channel (PLC)	
Edge evaluation: No	Signal(s) updated: job-controlled by NCK	
Signal state 1	The D function programmed in an NC block is made available here as soon as the D change signal is available. Value range of the D function: 0-9; integer number The D function remains valid until it is overwritten by a new D function.	
Signal state 0	<ul style="list-style-type: none"> · After the PLC has ramped-up. · All auxiliary functions are deleted before a new function is entered. 	
Application		
corresponding to ...	D0 is reserved for deselecting the actual tool offset.	
Note for the reader	Function Manual Basic Functions H2	

DB2500 DBD6000 DBD6008 DBD6016 DBW6004 DBW6012 DBW6020	H function 1 H function 2 H function 3 Extended address of H function 1 Extended address of H function 2 Extended address of H function 3 Signal(s) from channel (PLC)	
Edge evaluation: No	Signal(s) updated: job-controlled by NCK	
Signal state 1	Up to 3 H functions programmed in an NC block are simultaneously made available here as soon as the H change signals are available. Value range of the H functions: Floating point (REAL format/4 bytes) Value range of the extended address: 0 to 99; integer number The H functions remain valid until they are overwritten by new H functions.	
Signal state 0	<ul style="list-style-type: none"> · After the PLC has ramped-up. · All auxiliary functions are deleted before a new function is entered. 	
Application	Switching functions on the machine.	
Note for the reader	Function Manual Basic Functions H2	

6.5 NCK signals

6.5.1 General signals to NCK

DB2600 DBX0.1	EMERGENCY OFF Signal(s) to NC (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The NC is brought into the EMERGENCY OFF state and the EMERGENCY OFF sequence in the NC is started.
Signal state 0 or edge change 1 → 0	<ul style="list-style-type: none"> · The NC is not in the EMERGENCY OFF state · The EMERGENCY OFF state is (still) active, however, it can be reset with IS: "Acknowledge EMERGENCY OFF" and IS "Reset".
corresponding to ...	IS "Acknowledge EMERGENCY OFF" (DB2600 DBX0.2) IS "EMERGENCY OFF active" (DB2700 DBX0.1)

DB2600 DBX0.2	Acknowledge EMERGENCY OFF Signal(s) to NC (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>The EMERGENCY OFF state is only reset if IS "Acknowledge EMERGENCY OFF" is first set and then IS "Reset" (DB3000 DBX0.7) is set. It must be noted in this respect that IS "Acknowledge EMERGENCY OFF" and IS "Reset" must be set together for a long enough period until the IS "EMERGENCY OFF active" (DB2600 DBX0.1) was reset.</p> <p>By resetting the EMERGENCY OFF state, the following happens:</p> <ul style="list-style-type: none"> · IS "EMERGENCY OFF active" is reset · The controller enable is switched in · IS "Position control active" is set · IS "828-Ready" is set. · Alarm 3000 is cleared · The part program processing is aborted.
corresponding to ...	IS "EMERGENCY OFF" (DB2600 DBX0.1) IS "EMERGENCY OFF active" (DB2700 DBX0.1) IS "Reset" (DB3000 DBX0.7)

6.5 NCK signals

DB2600 DBX1.0	INC inputs in the mode signal range active Signal(s) from channel (PLC → NCK)	
Edge evaluation: No	Signal(s) updated: job-controlled by NCK	
Signal state 1 or edge change 0 → 1	The IS "1 INC", "10 INC", ..., "continuous" in the mode area are used as input signals (DB3000 DBX2.0 to .6).	
Signal state 0 or edge change 1 → 0	The IS "1 INC", "10 INC", ..., "continuous" in the axis and geometry axis area are used as input signals.	
corresponding to ...	IS "Machine function 1 INC up to continuous" in the mode area (DB3000 DBX2.0 to .6) IS "Machine function 1 INC, ..., continuous" for axis 1 in the Work (DB3200 DBX1001.0 to .6) for axis 2 in the Work (DB3200 DBX1005.0 to .6) for axis 3 in the Work (DB3200 DBX1009.0 to .6) IS "Machine function 1 INC, ..., continuous" in the axis area (DB380x DBX5.0 to .6)	
Note for the reader	Function Manual Basic Functions H2	

6.5.2 General signals from NCK

DB2700 DBX0.1	EMERGENCY OFF active Signal(s) from NC (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	The NC is in the EMERGENCY OFF state.	
corresponding to ...	IS "EMERGENCY OFF" (DB2600 DBX0.1) IS "Acknowledge EMERGENCY OFF" (DB2600 DBX0.2)	

DB2700 DBX1.0 and .1	Probe actuated Signal(s) from NC (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	Probe 1 or 2 is actuated.	
Signal state 0 or edge change 1 → 0	Probe 1 or 2 is not actuated.	
Note for the reader	Function Manual Basic Functions M5	

DB2700 DBX1.7	Inch measuring system Signal(s) from NC (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The NC operates with the inch measuring system.	
Signal state 0	The NC operates with the metric measuring system.	
Note for the reader	Function Manual Basic Functions G2	

DB2700 DBX2.3	HMI ready Signal(s) from NC (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The CPU is ready and registers itself cyclically with the NCK.
Signal state 0 or edge change 1 → 0	The CPU is not ready.
Note for the reader	Function Manual Basic Functions G2

DB2700 DBX2.6	Drive ready Signal(s) from NC (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	All existing drives signal the status drive ready (summary of axial interface signals "DRIVE ready").
Signal state 0 or edge change 1 → 0	As soon as the drive not ready status is signaled from a drive (i.e. IS "DRIVE ready" = 0).
corresponding to ...	DB390x DBX4001.5 (DRIVE ready)
Note for the reader	Function Manual Basic Functions G2

DB2700 DBX2.7	NC ready Signal(s) from NC (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The control system is ready. This interface signal is an image of the relay contact "NC Ready". This signal is set if: <ul style="list-style-type: none"> · Relay contact "NC Ready" is closed · All the voltages in the control have been established · The control is in the cyclic mode
Signal state 0 or edge change 1 → 0	The control is not ready. The relay contact "NC Ready" is open. The following faults will cause NC Ready to be canceled: <ul style="list-style-type: none"> · Undervoltage and overvoltage monitoring function has responded · Individual components are not ready (NCK CPU Ready) · NC CPU watchdog If the signal "NC Ready" goes to 0 the following measures are introduced by the control if they are still possible: <ul style="list-style-type: none"> · The controller enable signals are withdrawn (this stops the drives) · The following measures are introduced by the PLC basic program: <ul style="list-style-type: none"> – Status signals from NCK to PLC (user interface) are deleted (cleared) – Change signals for auxiliary functions are deleted – Cyclic processing of the user interface is exited The control is not ready again until after POWER ON.
Note for the reader	Function Manual Basic Functions G2

6.6 Mode signals

DB2700 DBX3.0	NCK alarm is active Signal(s) from NC (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	At least one NCK alarm is present. This is a group signal for the interface signals of all available channels: DB3300 DBX4.6 (channelspecific NCK alarm pending).
Signal state 0 or edge change 1 → 0	No NCK alarm is active.
corresponding to ...	DB3300 DBX4.6 (channelspecific NCK alarm pending) DB3300 DBX4.7 (NCK alarm with processing stop active)
Note for the reader	Function Manual Basic Functions G2

DB2700 DBX3.6	Air temperature alarm Signal(s) from NC (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The temperature monitoring has identified an ambient temperature that is too high (approx. 60 °C). Alarm 2110 "NCK temperature alarm" is output.
Signal state 0 or edge change 1 → 0	The temperature monitoring has not responded.
Note for the reader	Function Manual Basic Functions G2

6.6 Mode signals

DB3000 DBX0.0	AUTOMATIC mode Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	AUTOMATIC mode is selected by the PLC program.
Signal state 0 or edge change 1 → 0	AUTOMATIC mode is not selected by the PLC program.
Signal irrelevant for ...	if signal "Mode change disable"
corresponding to ...	IS "active AUTOMATIC mode"
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX0.1	MDI mode Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	MDI mode is selected by the PLC program.
Signal state 0 or edge change 1 → 0	MDI mode is not selected by the PLC program.
Signal irrelevant for ...	if signal "Mode change disable"
corresponding to ...	IS "active MDI mode"
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX0.2	JOG mode Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	JOG mode is selected by the PLC program.
Signal state 0 or edge change 1 → 0	JOG mode is not selected by the PLC program.
Signal irrelevant for ...	if signal "Mode change disable"
corresponding to ...	IS "active JOG mode"
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX0.4	Mode change disable Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The currently active mode (JOG, MDI or Automatic) cannot be changed.
Signal state 0	The mode can be changed.
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX0.7	Reset Signal(s) to NCK (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The channel should change into the "RESET" state. The program being executed is then in the program "Aborted" program state. All moving axes and spindles are decelerated to zero speed according to their acceleration ramp without contour violation. The initial settings are set (e.g. for G functions). The alarms are cleared if they are not POWER ON alarms.
Signal state 0 or edge change 1 → 0	Channel status and program execution are not influenced by this signal.
corresponding to ...	IS "Channel reset" IS "all channels in the Reset state"
Special cases, errors, ...	An alarm that withdraws the IS "828-Ready" ensures that the channel is no longer in the Reset state. A "Reset" must be initiated in order to be able to switch over to another mode.
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX1.0	Machine function TEACH IN Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Machine function TEACH IN is activated in the JOG mode.
Signal state 0 or edge change 1 → 0	Machine function TEACH IN is not activated.
Signal irrelevant for ...	if JOG mode is not active.
Note for the reader	Function Manual Basic Functions K1

6.6 Mode signals

DB3000 DBX1.2	Machine function REF Signal(s) to NCK (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Machine function REF is activated in the JOG mode.
Signal state 0 or edge change 1 → 0	Machine function REF is not activated.
Signal irrelevant for ...	if JOG mode is not active.
Note for the reader	Function Manual Basic Functions K1

DB3000 DBX1.6	Single block type B
Edge evaluation: No	Signal(s) updated:
Signal state 1 or edge change 0 → 1	Bit set and DB3000 DBX1.7 not set: Response across mode groups <ul style="list-style-type: none"> · Channel is stopped. · Channel receives a start command. · Channel KS stops at the end of the block. (If DB3000 DBX1.6 and DB3000 DBX1.7 are set simultaneously, it is impossible to determine which single block type is required. The control then assumes: No single block across mode groups.)
Signal state 0 or edge change 1 → 0	If bit DB3000 DBX1.6 is not set and bit DB3000 DBX1.7 is set, then it is single block type A. (If DB3000 DBX1.6 and DB3000 DBX1.7 are not set, it is impossible to determine which single block type is required. The control then assumes: No single block across mode groups).
corresponding to ...	Single block type A
Note for the reader	

DB3000 DBX1.7	Single block type A
Edge evaluation: No	Signal(s) updated:
Signal state 1 or edge change 0 → 1	DB3000 DBX1.7 set and DB3000 DBX1.6 not set: Response across modes <ul style="list-style-type: none"> · Channel is stopped. · Channel receives a start command. · Channel KS stops at the end of the block. (If DB3000 DBX1.6 and DB3000 DBX1.7 are set simultaneously, it is impossible to determine which single block type is required. The control then assumes: No single block access across modes).
Signal state 0 or edge change 1 → 0	If DB3000 DBX1.7 is not set and DB3000 DBX1.6 is set, then it is single block type B. (If DB3000 DBX1.6 and DB3000 DBX1.7 are not set, it is impossible to determine which single block type is required. The control then assumes: No single block access across modes).
corresponding to ...	Single block type B
Note for the reader	

DB3000 DBX2.0 to .6	Machine function 1 INC, 10 INC, 100 INC, 1000 INC, 10000 INC, var. INC, continuous Signal(s) to modes (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>The input range is only used if IS "INC inputs active in the mode area" (DB2600 DBX1.0) is set. These signals are valid for all axes and geometry axes.</p> <p>With the IS "INC..." it is defined by how many increments the axis moves when actuating the traversing key or when rotating the handwheel for each grid position. In this case, the JOG mode must be active. For "var. INC", the value generally applies in SD41010 JOG_VAR_INCR_SIZE.</p> <p>For "continuous" the associated axis can be traversed with the plus or minus traversing key by keeping the traversing key pressed.</p> <p>As soon as the selected machine function becomes active, this is signaled to the PLC interface (IS "Active machine function 1 INC; ..."). If several machine function signals (1 INC, INC... or "Continuous traversing") are selected at the interface simultaneously, then no machine function is activated by the control.</p> <p>Note:</p> <p>The input IS "INC..." or "continuous" to change an active machine function must be present for at least one PLC cycle. A steady-state signal is not required.</p>
Signal state 0 or edge change 1 → 0	<p>The machine function in question is not selected. No change is requested to the active machine function.</p> <p>If an axis is currently traversing an increment, this movement is also aborted if this machine function is deselected or switched over.</p>
corresponding to ...	<p>IS "INC inputs active in the mode area" (DB2600 DBX1.0)</p> <p>IS "Machine function 1 INC, ..., continuous"</p> <p>for axis 1 in the Work (DB3200 DBX1001.0 to .6)</p> <p>for axis 2 in the Work (DB3200 DBX1005.0 to .6)</p> <p>for axis 3 in the Work (DB3200 DBX1009.0 to .6)</p> <p>IS "Machine function 1 INC, ..., continuous" in the axis area (DB380x DBX5.0 to .6)</p> <p>IS "Active machine function 1 INC, ..., continuous"</p> <p>for axis 1 in the Work (DB3300 DBX1001.0 to .6)</p> <p>for axis 2 in the Work (DB3300 DBX1005.0 to .6)</p> <p>for axis 3 in the Work (DB3300 DBX1005.0 to .6)</p> <p>IS "Active machine function 1 INC, ..., continuous" in the axis area (DB390x DBX5.0 to .6)</p>
Note for the reader	Function Manual Basic Functions H1

6.6 Mode signals

DB3100 DBX0.0	Active AUTOMATIC mode Signal(s) from NCK (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	AUTOMATIC mode is active.
Signal state 0 or edge change 1 → 0	AUTOMATIC mode is not active.
Note for the reader	Function Manual Basic Functions K1

DB3100 DBX0.1	Active MDI mode Signal(s) from NCK (NCK → PLC)
Edge evaluation:	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	MDI mode is active.
Signal state 0 or edge change 1 → 0	MDI mode is not active.
Note for the reader	Function Manual Basic Functions K1

DB3100 DBX0.2	Active JOG mode Signal(s) from NCK (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	JOG mode is active.
Signal state 0 or edge change 1 → 0	JOG mode is not active.
Note for the reader	Function Manual Basic Functions K1

DB3100 DBX0.3	828 READY Signal(s) from NCK (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	This signal is set after power on and all of the voltage have been established. The mode group is now ready and part programs can be executed and axes traversed.
Signal state 0 or edge change 1 → 0	The mode group/channel is not ready. Possible causes for this are: <ul style="list-style-type: none"> · There is a critical axis or spindle alarm present · Hardware fault · Mode group incorrectly configured (machine data) If the mode group ready changes to signal state "0", then <ul style="list-style-type: none"> · the axis and spindle drives are braked down to standstill with the max. braking current. · the signals from the PLC to the NCK are brought into an inactive state (initial setting).
Special cases, errors, ...	An alarm that withdraws IS "828 READY" ensures that the channel is no longer in the reset state. A reset is required to switch over to another mode. (DB3000 DBX0.7)

Note for the reader	Function Manual Basic Functions K1
---------------------	------------------------------------

DB3100 DBX1.0	Active machine function TEACH IN Signal(s) from NCK (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Machine function TEACH IN is active within JOG.
Signal state 0 or edge change 1 → 0	Machine function TEACH IN is not active.
Note for the reader	Function Manual Basic Functions K1

DB3100 DBX1.2	Active machine function REF Signal(s) from NCK (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Machine function REF is active within JOG.
Signal state 0 or edge change 1 → 0	Machine function REF is not active.
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

6.7.1 Signals to channel

DB3200 DBX0.3	Activate DRF Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The function DRF is selected. The function can either be selected directly from the PLC user program or from the operator panel front via HMI interface signal: DB1700 DBX0.3 (DRF selected) As soon as the function DRF is active, DRF offset can be modified in the AUTOMATIC or MDI modes.
Signal state 0 or edge change 1 → 0	The DRF function is not selected.
Application	The DRF function can be specifically enabled from the PLC user program using the IS "Activate DRF".
corresponding to ...	DB1700 DBX0.3 (DRF selected)
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3200 DBX0.4	Activate single block Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	In the AUTOMATIC mode, the program is executed in the single block mode; only 1 block can be entered anyway in MDI.
Signal state 0 or edge change 1 → 0	No effect
Application	A new program can first be tested in singleblock mode in order to monitor the individual program steps more exactly.
Special cases, errors, ...	<ul style="list-style-type: none"> · When tool radius correction (offset) (G41, G42) is selected, then where necessary, intermediate blocks are inserted. · In a series of G33 blocks single block is effective only if "dry run feedrate" is selected. · For "individual block coarse", pure computation blocks are not processed in the single step, but only for "single block fine". The preselection is made by pressing the "Program control" softkey.
corresponding to ...	IS "Single block selected" IS "Program status stopped"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX0.5	Activate M01 Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	M1 programmed in the part program leads to a programmed stop when being executed in the AUTOMATIC or MDI mode.
Signal state 0 or edge change 1 → 0	M1 programmed in the part program does not lead to a programmed stop.
corresponding to ...	IS "M01 selected" (DB1700 DBX0.5) IS "M0/M1 active" (DB3300 DBX0.5)
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX0.6	Activate dry run feedrate Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>Instead of with the programmed feedrate (for G1, G2, G3, CIP, CT), the axis moves with the dry run feedrate specified using SD 42100: DRY_RUN_FEED if the dry run feedrate is greater than the one that has been programmed.</p> <p>This interface signal is evaluated at NC start when the channel was in the "Reset" state.</p> <p>When selected using the PLC, the IS "activate dry run feedrate" should be set from the PLC user program.</p>
Signal state 0 or edge change 1 → 0	The axis travels with the programmed feedrate. Effective after reset state.
Application	Testing a workpiece program with an increased feedrate.
corresponding to ...	IS "Dry run feedrate selected" (DB1700 DBX0.6) SD 42100: DRY_RUN_FEED (dry run feedrate)
Note for the reader	Function Manual Basic Functions V1

DB3200 DBX1.0	Activate referencing Signal(s) to channel (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Channel-specific referencing is started with the IS "Activate referencing". The control acknowledges a successful start with the IS "Referencing active". Each machine axis assigned to the channel can be referenced with channel-specific referencing (this is achieved internally in the control by simulating the plus/minus traversing keys). Via the axis-specific MD 34110: REFP_CYCLE_NR (axis sequence for channel-specific referencing) can be used to define the sequence in which the machine axes are referenced. If all of the axes entered in MD: REFP_CYCLE_NR have reached their reference point, then IS "all axes referenced" (DB3300 DBX4.2) is set.
Application	If the machine axes are to be referenced in a particular sequence, the following options are available: <ul style="list-style-type: none"> · The operator must observe the correct sequence when starting. · The PLC must check the sequence when starting or define it itself. · The function channel specific referencing is used.
corresponding to ...	IS "Referencing active" (DB3300 DBX1.0) IS "All axes that must have a reference point are referenced" (DB3300 DBX4.2)
Note for the reader	Function Manual Basic Functions R1

DB3200 DBX1.1	Enable protection zones Signal(s) to channel (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	When a positive edge of this signal appears, a protection zone is enabled and the active alarm cleared. Then, motion can start in the same protection zone. As a result of the start of motion, the protection zone is enabled, the IS "machine or channel-specific protection zone violated" is set, and the axis starts to move. The enable signal is not required if a motion is started that does not lead into the enabled protection zone.
Signal state 0 or edge change 1 → 0	No effect
Application example	This allows protection zones to be enabled: <ul style="list-style-type: none"> · if the actual position is within a protection zone (alarm 2 present) · if motion is to be started towards the protection zone limit (alarm 1 or 2 present)
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3200 DBX1.7	Activate the program test Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Axis disable is set internally for all axes (not spindles). Therefore the machine axes do not move when a part program block or a part program is being processed. The axis movements are simulated on the operator interface with changing axis position values. The axis position values for the display are generated from the calculated setpoints. Otherwise, the part program is executed normally.
Signal state 0 or edge change 1 → 0	The part program execution is not affected by the program test function.
corresponding to ...	IS "Program test selected" IS "Program test active"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBB2 DBX15.6 and .7	Activate skip block Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Blocks marked in the part program with a slash (/) are skipped. If there is a series of skip blocks, this signal is only active if it is present before decoding of the first block of the series, ideally before "NC start" .
Signal state 0 or edge change 1 → 0	The marked part program blocks are not skipped.
corresponding to ...	IS "Skip block selected"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX3.0	Stroke enable Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	This signal releases the punching strokes via the PLC. 1 signal: The stroke is locked, the NC may not trigger a punching stroke
Signal state 0 or edge change 1 → 0	0 signal: The stroke is enabled - as long as the enable signal is not set, the NC can perform a punching stroke

DB3200 DBX3.1	Manual stroke initiation Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or Edge change 0 → 1	This signal enables the triggering of a single stroke in manual mode. 1 signal: Manual stroke is performed
Signal state 0 or Edge change 1 → 0	0 signal: No effect

DB3200 DBX3.2	Stroke suppression Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	The signal only prevents the stroke. The machine traverses anyway. If the automatic path segmentation should be active, then this also remains active. Only the signal "Stroke initiation" is suppressed. The machine traverses in "stop and go" mode. The step length is defined via the path segmentation. 1 signal: Stroke suppression is active
Signal state 0 or Edge change 1 → 0	0 signal: Stroke suppression is not active

DB3200 DBX3.3	Stroke is not performed Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	The NC responds to this signal by immediately stopping motion. An alarm is output if motion or another action is to be interrupted due to this signal. In physical terms, the signal is identical to the signal "Stroke active" for the CNC, i.e. the system is wired in such a way that the two signals are taken to the same NC input via an "And" logic operation. 1 signal: Stroke is not performed (corresponds to the stroke enable signal)
Signal state 0 or Edge change 1 → 0	0 signal: Stroke is performed (corresponds to the stroke enable signal)

DB3200 DBX3.4	Delayed stroke Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	A "delayed stroke" can be activated using this signal. This functionally corresponds to the programming of PDELAYON. Additional PLC signals that do not correspond to the standard are not evaluated by the NCK. With the exception of the manual stroke initiation, the evaluation of signals is limited to PON active. 1 signal: Delayed stroke is active
Signal state 0 or edge change 1 → 0	0 signal: Delayed stroke is not active

DB3200 DBX3.5	Manual stroke initiation 2 Signal(s) to channel (PLC → NCK)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	This "manual stroke initiation" signal allows the operator to initiate a punching process, even when the part program is not being processed. This means that the punch is initiated, controlled from the PLC. The PLC is signaled if a stroke has been successfully initiated using the signal NCK → PLC IS "Manual stroke initiation acknowledgement" (DB3300 DBX6.1). 1 signal: Manual stroke initiation is active
Signal state 0 or edge change 1 → 0	0 signal: Manual stroke initiation is not active

6.7 Channelspecific signals

DB3200	Feedrate override		
DBB4	Signal(s) to channel (PLC → NCK)		
Edge evaluation: No	Signal(s) updated: Cyclic		
Signal state 1 or edge change 0 → 1	Gray coding for feedrate override		
	Switch setting	Code	Feedrate override factor
	1	00001	0.0
	2	00011	0.01
	3	00010	0.02
	4	00110	0.04
	5	00111	0.06
	6	00101	0.08
	7	00100	0.10
	8	01100	0.20
	9	01101	0.30
	10	01111	0.40
	11	01110	0.50
	12	01010	0.60
	13	01011	0.70
	14	01001	0.75
	15	01000	0.80
	16	11000	0.85
	17	11001	0.90
	18	11011	0.95
	19	11010	1.00
	20	11110	1.05
	21	11111	1.10
	22	11101	1.15
	23	11100	1.20
	24	10100	1.20
	25	10101	1.20
	26	10111	1.20
	27	10110	1.20
	28	10010	1.20
	29	10011	1.20
	30	10001	1.20
31	10000	1.20	
corresponding to ...	IS "Feedrate override active" (DB3200 DBX6.7)		
Note for the reader	Function Manual Basic Functions V1		

DB3200	Rapid traverse override		
DBB5	Signal(s) to channel (PLC → NCK)		
Edge evaluation: No	Signal(s) updated: Cyclic		
Signal state 1 or edge change 0 → 1	Gray coding for rapid traverse override		
	Switch setting	Code	Rapid traverse override
	1	00001	0.0
	2	00011	0.01
	3	00010	0.02
	4	00110	0.04
	5	00111	0.06
	6	00101	0.08
	7	00100	0.10
	8	01100	0.20
	9	01101	0.30
	10	01111	0.40
	11	01110	0.50
	12	01010	0.60
	13	01011	0.70
	14	01001	0.75
	15	01000	0.80
	16	11000	0.85
	17	11001	0.90
	18	11011	0.95
	19	11010	1.00
	20	11110	1.00
	21	11111	1.00
	22	11101	1.00
	23	11100	1.00
	24	10100	1.00
	25	10101	1.00
	26	10111	1.00
	27	10110	1.00
	28	10010	1.00
	29	10011	1.00
	30	10001	1.00
31	10000	1.00	
corresponding to ...	IS "Rapid traverse override active" (DB3200 DBX6.6)		
Note for the reader	Function Manual Basic Functions V1		

6.7 Channelspecific signals

DB3200 DBX6.0	Feedrate disable Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>The signal is active in one channel in all modes.</p> <ul style="list-style-type: none"> · Signal causes a feedrate disable of all of the axes that are interpolating relative to each other if no G33 (thread) is present. All axes are brought to a standstill, maintaining the path contour. When the feedrate disable is canceled (0 signal), the interrupted part program is continued. · The position control is kept, i.e. the following error is eliminated. · If a travel request is issued for an axis with an active "Feedrate disable", then this is kept. This pending travel request is executed directly when "Feedrate disable" is withdrawn. <p>If the axis is interpolating relative to others, then this also applies to these axes.</p>
Signal state 0 or edge change 1 → 0	<ul style="list-style-type: none"> · The feedrate is enabled for all axes of the channel. · If a travel request ("travel command") exists for an axis or group of axes when the "feedrate disable" is canceled, then this is executed immediately.
Special cases, errors, ...	The feedrate disable is inactive when G33 is active.
Note for the reader	Function Manual Basic Functions V1

DB3200 DBX6.1	Read-in disable Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The data transfer for the next block is locked in the interpolator. This signal is only active in the AUTOMATIC and MDI modes.
Signal state 0 or edge change 1 → 0	The data transfer for the next block in the interpolator is released. This signal is only active in the AUTOMATIC and MDI modes.
Application	<p>If the execution of the auxiliary function (e.g. during tool changes) has to be completed in order to process the next NC block, the automatic block change function must be suppressed by means of a read-in inhibit.</p> <p>1 Read in to the buffer 6 Output of the auxiliary functions 2 Block processed 7 Data transfer to the interpolator 3 Read-in inhibit signal 8 Read-in inhibit for tool changes 4 Data transfer 9 Query place of the read-in enable 5 Content of the interpolator 10 Cancel read-in inhibit</p>
corresponding to ...	IS "Program status running"
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3200 DBX6.2	Delete distance-to-go Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	IS "Delete distancetogo" for path axes is only active in AUTOMATIC mode. The rising edge of the interface signal is only effective for the axes involved in the geometry grouping. These are also stopped with a ramp stop and their distancetogo deleted (setpoint - actual value difference). Any remaining following error is still removed. The next program block is then started. Remark: IS "Delete distancetogo" does not influence the running dwell time in a program block with dwell time.
Signal state 0 or edge change 1 → 0	No effect
Signal irrelevant for ...	Positioning axes
Application example	Terminating motion because of an external signal (e.g. probe)
Special cases, errors, ...	When the axes have been stopped with IS "Delete distancetogo" the next program block is prepared with the new positions. After a "Delete distance-to-go", geometry axes thus follow a different contour to the one originally defined in the part program. If G90 is programmed in the block after "Delete distancetogo" it is at least possible to approach the programmed absolute position. On the other hand, with G91, the position originally defined in the part program is not reached in the following block.
corresponding to ...	DB380x DBX2.2 (Distance-to-go / Spindle reset)
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX6.4	Program level abort Signal(s) to channel (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	At each edge change 0 → 1 the actual program level being processed (sub-program level) is immediately aborted. Processing of the part program continues at the next higher program level from the exit point.
Signal state 0 or edge change 1 → 0	No effect
Special cases, errors, ...	The main program level cannot be interrupted with the IS, but only with the IS "Reset".
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX6.6	Rapid traverse override active Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The rapid traverse override between 0 and a maximum of 100% entered in the PLC interface is channel-specific.
Signal state 0 or edge change 1 → 0	The rapid traverse override entered at the PLC interface is ignored. When the rapid traverse override is inactive, the NC always uses 100% as the internal override factor. Note: The 1st switch position of the gray-coded interface for the value is an exception. Also here for "Rapid traverse override inactive", this override factor is used and for axes, 0% is output as override value.
Special cases, errors, ...	The rapid traverse override is inactive when G33 is active.
corresponding to ...	IS "Rapid traverse override" (DB3200 DBX5)
Note for the reader	Function Manual Basic Functions V1

DB3200 DBX6.7	Feedrate override active Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The feedrate override between 0 and a maximum of 120% entered at the PLC interface is active for the path feedrate and therefore automatically for the related axes. In JOG mode, the feedrate override acts directly on the axes.
Signal state 0 or edge change 1 → 0	The feedrate override entered at the PLC interface is ignored. When the feedrate override is inactive, the NC always uses 100% as the internal override factor. Note: The 1st switch position of the gray-coded interface for the value is an exception. Also here, for "Feedrate override inactive", this override factor is used and for axes, 0% is output as override value (acts the same as "feedrate disable").
Special cases, errors, ...	The feedrate override is inactive when G33 is active.
corresponding to ...	IS "Feedrate override" (DB3200 DBX4)
Note for the reader	Function Manual Basic Functions V1

6.7 Channelspecific signals

DB3200 DBX7.0	NC start disable Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	IS "NC start" is inactive.
Signal state 0 or edge change 1 → 0	IS "NC start" is active.
Application	This signal is used to suppress renewed program execution because, for example, there is no lubricant.
corresponding to ...	IS "NC start"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX7.1	NC start Signal(s) to channel (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	AUTOMATIC mode: The selected NC program is started or continued. If data is transferred from the PLC to the NC during program status "Program interrupted," then this data is immediately processed with NC start. MDI mode: The part program blocks that were entered are enabled for execution or are continued.
Signal state 0 or edge change 1 → 0	No effect
corresponding to ...	IS "NC start disable"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX7.2	NC stop at block limit Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The NC program being executed is stopped after the part program block being executed has been completely processed. Otherwise, as for "NC stop".
Signal state 0 or edge change 1 → 0	No effect
corresponding to ...	IS "NC stop" IS "NC stop axes plus spindles" IS "Program status stopped" IS "Channel status interrupted"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX7.3	NC stop Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The NC program being executed is immediately stopped, the actual block is not completed. Only the axes are stopped without contour violation. Distances to go are only traversed through after a new start. The program status changes to "stopped", the channel status changes to "interrupted".
Signal state 0 or edge change 1 → 0	No effect
Application	<p>The program is resumed at the point where it was interrupted with NC Start</p> <p>The diagram illustrates the following sequence of events:</p> <ul style="list-style-type: none"> The "NC Stop" interface signal transitions from low to high. At this point, the "Program is running" signal drops to low, and the "Axis is running" signal also drops to low. When the "NC Stop" signal returns to low, the "Program is running" signal returns to high, and the "Axis is running" signal returns to high. Later, the "NC Start" interface signal transitions from low to high. At this point, the "Program is running" signal drops to low, and the "Axis is running" signal also drops to low. When the "NC Start" signal returns to low, the "Program is running" signal returns to high, and the "Axis is running" signal returns to high. The "Block processed" signal transitions from low to high when the program resumes after the second stop.
Special cases, errors, ...	The signal NC stop must be active for at least one PLC cycle.
corresponding to ...	IS "NC stop at block limit" IS "NC stop axes plus spindles" IS "Program status stopped" IS "Channel status interrupted"
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3200 DBX7.4	NC stop axes plus spindles Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The NC program being executed is immediately stopped, the actual block is not completed. Distancestogo are only completed after a new start. The axes and spindle are stopped. However, these are stopped in a controlled fashion. The program status changes to stopped, the channel status changes to interrupted.
Signal state 0 or edge change 1 → 0	No effect
Signal irrelevant for ...	Channel status reset Program status interrupted
Special cases, errors, ...	<p>All axes and spindles which have not been initiated by a program or a program block (e.g. axes running on account of the traverse keys on the machine control panel), do not decelerate to a standstill when "NC Stop axes plus spindles" is applied.</p> <p>The program is resumed at the point where it was interrupted with NC Start.</p> <p>The "NC stop axes plus spindles" signal must be active for at least one PLC cycle.</p> <p>The diagram shows a sequence of events: 1. Program is running. 2. NC stop signal axes becomes active (high pulse). 3. Axis is running, Spindle is running, and Block processed signals are active. 4. NC start signal becomes active (high pulse). 5. Program is running resumes. 6. Axis is running, Spindle is running, and Block processed signals are active again. 7. NC stop signal axes becomes active again. 8. Axis is running, Spindle is running, and Block processed signals are active. 9. NC start signal becomes active again. 10. Program is running resumes. 11. Axis is running, Spindle is running, and Block processed signals are active again.</p>
corresponding to ...	IS "NC stop at block limit" IS "NC stop" IS "Program status stopped" IS "Channel status interrupted"
Note for the reader	Function Manual Basic Functions K1

DB3200 DBX13.5	Deactivate workpiece counter Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The workpiece count monitoring is deactivated with activated tool monitoring.
Signal state 0	No effect
Note for the reader	Function Manual Basic Functions W1

DB3200 DBX14.0 DBX14.1	Activate handwheel 1 as contour handwheel Activate handwheel 2 as contour handwheel Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Handwheel 1/2 is selected as contour handwheel.
Signal state 0	Handwheel 1/2 is deselected as contour handwheel.
Application	Enabling/disabling the contour handwheel can be performed in the middle of a block. When enabled, the movement is first decelerated and then traversed according to the contour handwheel. When disabled, the movement is decelerated and the NC program is continued immediately. If the NC program is to be continued only after a new NC start, then disabling the contour handwheel in the PLC user program must be logically combined with an NC stop.
Special cases, errors, ...	The signal is kept beyond an NC reset.
corresponding to ...	DB3300 DBX5.0 and 5.1 (handwheel 1/2 active as contour handwheel)
Note for the reader	Function Manual Basic Functions H1

DB3200 DBX14.3 DBX14.4	Simulation contour handwheel on Negative direction simulation contour handwheel Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Description	For enabling/disabling simulation of the contour handwheel and to define the traversing direction, these signals have to be set as follows: · Bit 3 = 0: Simulation off · Bit 3 = 1: Simulation on - Bit 4 = 0: Direction as programmed - Bit 4 = 1: Direction opposite to what was programmed
Application	During simulation the feedrate is no longer defined by the contour handwheel, but traversing occurs with the programmed feedrate along the contour. When the function is deselected, the movement is decelerated along the braking ramp. When the traversing direction is reversed, axis motion is decelerated along the braking ramp and the axis traverses in the opposite direction.
Special cases, errors, ...	The simulation is only effective in the AUTOMATIC mode and can only be enabled if the contour handwheel has been activated.
Note for the reader	Function Manual Basic Functions H1

6.7 Channelspecific signals

DB3200 DBX14.5	Activate associated M01 Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated:
Signal state 1	PLC signals the NCK that the associated M01 (auxiliary function) should be activated.
Signal state 0	Deactivate the associated M01 (auxiliary function).
corresponding to ...	DB21, ... DBX 318.5 (associated M01 active) ???
Note for the reader	Function Manual Basic Functions H1

DB3200 DBX16.0	Control program branching Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated:
Signal state 1	GOTOS in the part program initiates a return jump to the program start. The program is then processed again.
Signal state 0	GOTOS does not initiate a return jump. Program execution is continued with the next part program block after GOTOS.
corresponding to ...	MD27860 PROCESSTIMER_MODE MD27880 PART_COUNTER
Note for the reader	Function Manual Basic Functions H1

DB3200 DBX1000.0 to .1 DBX1004.0 to .1 DBX1008.0 to .1	Activate handwheel (1 and 2) for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	These PLC interface signals are used to define whether this geometry axis is assigned to handwheel 1 or 2 or is not assigned to any handwheel. Only one handwheel can be assigned to an axis at any one time. If several interface signals "activate handwheel" are set, then 'Handwheel 1' has a higher priority than 'Handwheel 2'. Note: Two geometry axes can be simultaneously traversed using handwheels 1 to 2!
Signal state 0 or edge change 1 → 0	Neither handwheel 1 or 2 is assigned to this axis.
Application	The PLC user program can use this interface signal to interlock the influence on the geometry axis when turning a handwheel.
corresponding to ...	IS "Handwheel active" 1 to 2 for axis 1 in the Work: DB3300 DBX1000.0 to .2 for axis 2 in the Work: DB3300 DBX1004.0 to .2 for axis 3 in the Work: DB3300 DBX1008.0 to .2
Note for the reader	Function Manual Basic Functions H1

DB3200 DBX1000.3 DBX1004.3 DBX1008.3	Feedrate stop for axes in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The signal is only active in the JOG mode (axes are traversed in the Work). <ul style="list-style-type: none"> · The signal triggers a feedrate stop for the axis. For a traversing axis, this signal brings it to a standstill with a controlled braking (ramp stop). No alarm is output. · The position control is kept, i.e. the following error is eliminated. · If a travel request is issued for an axis with an active "feedrate stop", then this is kept. This queued travel request is executed immediately after the "feedrate stop" has been withdrawn.
Signal state 0 or edge change 1 → 0	<ul style="list-style-type: none"> · The feedrate is enabled for the axis. · If a travel request ("travel command") is active when the "feedrate stop" is withdrawn, this is executed immediately.
Note for the reader	Function Manual Basic Functions V1

DB3200 DBX1000.4 DBX1004.4 DBX1008.4	Traversing key disable for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The plus and minus traversing keys have no effect on the geometry axes in question. It is thus not possible to traverse the geometry axis in JOG with the traversing keys on the machine control panel. If the traversing key disable is activated while traversing, the geometry axis is stopped.
Signal state 0	The plus and minus traversing keys are enabled.
Application	It is thus possible, depending on the operating state, to interlock traversing of the geometry axis in JOG mode using the traversing keys from the PLC user program.
corresponding to ...	IS "Traversing key plus" and " ... minus" for axis 1 in the Work (DB3200 DBX1000.7 and .6) for axis 2 in the Work (DB3200 DBX1004.7 and .6) for axis 3 in the Work (DB3200 DBX1008.7 and .6)
Note for the reader	Function Manual Basic Functions H1

6.7 Channelspecific signals

DB3200 DBX1000.5 DBX1004.5 DBX1008.5	Rapid traverse override for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If, together with the "Traversing key plus" or "Traversing key minus" the PLC interface signal "Rapid traverse override" is issued, then the geometry axis that is addressed traverses with the rapid traverse - intended for JOG - of the associated machine axis (e.g.: X → X1). This rapid traverse velocity is defined using MD32010 JOG_VELO_RAPID. The rapid traverse override is effective in the JOG mode for the following versions: · for continuous travel · for incremental travel If rapid traverse override is active, the velocity can be modified with the rapid traverse override switch.
Signal state 0 or edge change 1 → 0	The geometry axis traverses with the specified JOG velocity (SD41110 JOG_SET_VELO or MD32020 JOG_VELO).
Signal irrelevant for ...	· AUTOMATIC and MDI modes · Reference point approach (JOG mode)
corresponding to ...	IS "Traversing key plus" and " ... minus" for axis 1 in the Work (DB3200 DBX1000.7 and .6) for axis 2 in the Work (DB3200 DBX1004.7 and .6) for axis 3 in the Work (DB3200 DBX1008.7 and .6)
Note for the reader	Function Manual Basic Functions H1, V1

DB3200 DBX1000.7 and .6 DBX1004.7 and .6 DBX1008.7 and .6	Traversing keys plus and minus for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>The selected axis can be traversed in both directions in JOG mode using the plus and minus traversing keys.</p> <p>Incremental travel</p> <p>With signal state 1 the axis starts to traverse the set increment. If the signal changes to the 0 state before the increment is traversed, the traversing movement is interrupted. With a new signal state 1, the traversing motion is continued.</p> <p>Until the increment has been completely traversed, the axis traversing motion can be stopped and continued a multiple number of times as described above.</p> <p>Continuous traversing</p> <p>If an INC dimension has not been selected, but "continuous", then the axis traverses as long as the traversing key is kept pressed.</p> <p>If both traverse signals (plus and minus) are set at the same time, no movement occurs, or any current movement is aborted!</p> <p>The effect of the traversing keys can be disabled for every axis individually using the PLC interface signal "Traversing key disable".</p> <p>Notice:</p> <p>In contrast to machine axes, for geometry axes, only one geometry axis can be traversed at any one time using the traversing keys. Alarm 20062 is output if an attempt is made to traverse more than one axis using the traversing keys.</p>
Signal state 0 or edge change 1 → 0	No traversing
Signal irrelevant for ...	AUTOMATIC and MDI modes
Special cases, errors, ...	<p>The geometry axis cannot be traversed in JOG mode:</p> <ul style="list-style-type: none"> · if it is already being traversed via the axis-specific PLC interface (as a machine axis). · If another geometry axis is already being traversed with the traversing keys. <p>Alarm 20062 "Axis already active" is output.</p>
corresponding to ...	<p>IS "Traversing keys plus and minus" for machine axes (DB380x DBX4.7 and .6)</p> <p>IS "Traversing key disable" for axis 1 in the Work (DB3200 DBX1000.4) for axis 2 in the Work (DB3200 DBX1004.4) for axis 3 in the Work (DB3200 DBX1008.4)</p>
Note for the reader	Function Manual Basic Functions H1

6.7 Channelspecific signals

DB3200 DBX1001.0 to .6 DBX1005.0 to .6 DBX1009.0 to .6	Machine function 1 INC, 10 INC, 100 INC, 1000 INC, 10000 INC, var. INC, continuous for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) to channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	This input range is only used if IS "INC inputs active in the mode area" (DB2600 DBX1.0) is not set . Interface signals INC... is used to define how many increments the geometry axis traverses when the traversing key is pressed or the handwheel is turned one detent position. In this case, the JOG mode must be active. For "var. INC", generally the value in SD41010 JOG_VAR_INCR_SIZE applies. For "continuous", the associated geometry axis can be traversed with the plus or minus traversing key by keeping the traversing key pressed. As soon as the selected machine function becomes active, this is signaled to the PLC interface (IS "Active machine function 1 INC; ..."). If several machine function signals (1 INC, INC... or "Continuous traversing") are selected at the interface simultaneously, then no machine function is activated by the control. Note: The input IS "INC..." or "continuous" to change an active machine function must be present for at least one PLC cycle. A steady-state signal is not required.
Signal state 0 or edge change 1 → 0	The machine function in question is not selected. No request is made to change an active machine function. If an axis is currently traversing an increment, this movement is also aborted if this machine function is deselected or switched over.
corresponding to ...	IS "Active machine function 1 INC, ..." for axis 1 in the Work (DB3300 DBX1001.06) for axis 2 in the Work (DB3300 DBX1005.06) for axis 3 in the Work (DB3300 DBX1009.06) IS "INC inputs active in the mode group area" (DB2600 DBX1.0)
Note for the reader	Function Manual Basic Functions H1

6.7.2 Signals from NC channel

DB3300	Action block active
DBX0.3	Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Block search: Output of the collective auxiliary functions running.
Note for the reader	Function Manual Basic Functions K1

DB3300	Approach block active
DBX0.4	Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Block search with calculation / at contour: Approach block running
Note for the reader	Function Manual Basic Functions K1

DB3300	M0/M1 active
DBX0.5	Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The part program block is executed, the auxiliary functions are output, and <ul style="list-style-type: none"> · M0 is located in the work memory, or · M1 is in the work memory and IS "Activate M01" is active The program status changes to stopped.
Signal state 0	<ul style="list-style-type: none"> · With IS "NC start" · For a program abort as a result of a reset
Application	<p>The diagram illustrates the timing of signals during the activation of M0/M1. It shows six signals over time:</p> <ul style="list-style-type: none"> Data transfer to working memory: A narrow pulse occurring at the start of the block processing. Block processed: A wider pulse that starts after data transfer and ends when the block is finished. NC block with M0: A signal labeled 'M0' that is active during the 'Block processed' period. M change signal (1 PLC cycle time): A narrow pulse occurring at the end of the 'Block processed' period. 'M0/M1 active' interface: A signal that becomes active at the start of 'Block processed' and remains active until the end of the block. 'NC Start' interface: A signal that becomes active at the start of 'Block processed' and remains active until the end of the block.
corresponding to ...	IS "Activate M01" IS "M01 selected"
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3300 DBX0.6	Last action block active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Block search: Last block of the output with collected auxiliary functions.
Note for the reader	Function Manual Basic Functions K1


DB3300 DBX1.0	Referencing active Signal(s) from channel (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The channel-specific referencing was started using the IS: "Activate referencing" and the successful start was acknowledged using IS "Referencing active". The channel-specific referencing is running.
Signal state 0 or edge change 1 → 0	<ul style="list-style-type: none"> · Channel-specific referencing has been completed · Axis-specific referencing is running · No referencing active
Signal irrelevant for ...	Spindles
corresponding to ...	IS "Activate referencing" (DB3200 DBX1.0)
Note for the reader	Function Manual Basic Functions R1

DB3300 DBX1.2	Revolutional feedrate active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When programming of G95 (revolutional feedrate) in the JOG or automatic mode.
corresponding to ...	SD41100 JOG_REV_IS_ACTIVE (JOG: Revolutional/linear feedrate) SD42600 JOG_FEED_PER_REV_SOURCE (control revolutional feedrate in JOG) SD43300 ASSIGN_FEED_PER_REV_SOURCE (revolutional feedrate for positioning axes/spindles) MD32040 JOG_REV_VELO_RAPID (revolutional feedrate for JOG with rapid traverse override) MD32050 JOG_REV_VELO (revolutional feedrate for JOG)
Note for the reader	Function Manual Basic Functions V1

DB3300 DBX1.3	Handwheel override active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The function "Handwheel override in AUTOMATIC mode" is active for the programmed path axes. Handwheel pulses of the 1st geometry axis function as a velocity override over the programmed path feedrate.
Signal state 0	The function "Handwheel override in AUTOMATIC mode" is not active for the programmed path axes. An active handwheel override is not active if: <ul style="list-style-type: none"> · The path axes have reached the target position · The distance-to-go is deleted by the channel-specific interface signal DB21, ... DBX6.2 (delete distance-to-go) · A RESET is performed.
Note for the reader	Function Manual Basic Functions H2

DB3300 DBX1.4	Block search active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The block search function is active. It was selected and started from the operator interface.
Signal state 0	The block search function is not active.
Application	The block search function makes it possible to jump to a certain block within a part program and to start processing the part program from this block.
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3300 DBX1.5	M2/M30 active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	NC block with M2 has been completely executed. If traversing motion is also programmed in this block, the signal is only output when the target position has been reached.
Signal state 0	<ul style="list-style-type: none"> · No end of program or program abort · Status after the control has been switched on · Start of an NC Program
Application	 <p>The PLC can detect the end of program processing with this signal and react appropriately.</p>
Special cases, errors, ...	<ul style="list-style-type: none"> · The M2 and M30 functions have equal priority. Only M2 should be used. · The IS "M2/M30 active" is present as steady-state signal after the end of the program. · Not suitable for automatic follow-on functions such as workpiece counting, bar feed, etc. For these functions, M2 should be written into a separate block and the word M2 or the decoded M signal should be used. · Auxiliary functions must not be written in the last block of a program that should result in a read-in stop.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX1.6	Transformation active Signal(s) from NCK channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The NC command TRANSMIT or TRACYL is programmed in the part program. The corresponding block was executed by the NC and a transformation is now activated.
Signal state 0	No transformation active
Note for the reader	Function Manual Basic Functions M1

DB3300 DBX1.7	Program test active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Program control "Program test" is active. Axis disable is set internally for all axes (not spindles). Therefore the machine axes do not move when a part program block or a part program is being processed. The axis movements are simulated on the operator interface with changing axis position values. The axis position values for the display are generated from the calculated set-points. Otherwise, the part program is executed in the normal way.
Signal state 0	Program control program test is not active.
corresponding to ...	IS "Activate program test" IS "Program test selected"
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX3.0	Program status running Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The part program was started with IS "NC start" and is running.
Signal state 0	<ul style="list-style-type: none"> · Program stopped by M0/M1 or NC stop or mode change. · For single block mode, the block is executed. · End of program reached (M2) · Program aborted due to a reset · The actual block cannot be executed
Special cases, errors, ...	The IS "Program status running" does not change to 0 if workpiece machining is stopped due to the following events: <ul style="list-style-type: none"> · A feedrate disable or spindle disable was output · IS "Read-in disable" · Feedrate override to 0% · The spindle and axis monitoring functions respond
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3300 DBX3.1	Program status wait Signal(s) from channel (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The running program has come to a program command WAIT_M or WAIT_E in an NC block. The wait condition specified in the WAIT command for the channel or channels has not yet been fulfilled.	
Signal state 0	Program status wait is not active.	
corresponding to ...		
Note for the reader	/PG/ Programming Manual, Fundamentals	

DB3300 DBX3.2	Program status stopped Signal(s) from channel (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The NC part program has been stopped by an "NC stop", "NC stop axes plus spindles", "NC stop at the block limit", programmed M0 or M1 or single block mode.	
Signal state 0	Program status "stopped" is not present.	
corresponding to ...	IS "NC stop" IS "NC stop axes plus spindles" IS "NC stop at block limit"	
Note for the reader	Function Manual Basic Functions K1	

DB3300 DBX3.3	Program status interrupted Signal(s) from channel (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	When the mode changes from AUTOMATIC or MDI (in stopped program status) to JOG, the program status changes to "interrupted". The program can be continued at the point of interruption in AUTOMATIC or MDI mode when "NC start" is issued.	
Signal state 0	Program status interrupted is not active.	
Special cases, errors, ...	The IS "Program status interrupted" indicates that the part program can continue to be processed by restarting it.	
Note for the reader	Function Manual Basic Functions K1	

DB3300 DBX3.4	Program status aborted Signal(s) from channel (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The program has been selected but not started, or the program was aborted with a reset.	
Signal state 0	Program status interrupted is not active.	
corresponding to ...	IS "Reset"	
Note for the reader	Function Manual Basic Functions K1	

DB3300 DBX3.5	Channel status active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	In this channel <ul style="list-style-type: none"> · A part program or block is presently being executed in the automatic or MDI mode. · At least one axis is being traversed in JOG mode
Signal state 0	"Channel status interrupted" or "Channel status reset" is active.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX3.6	Channel status interrupted Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The NC part program in AUTOMATIC or MDI can be interrupted by "NC stop", "NC stop axes plus spindles", "NC stop at the block limit", programmed M0 or M1 or single block mode. With an NC start, the part program or the interrupted traversing movement can be continued.
Signal state 0	"Channel status active" or "Channel status reset" is active.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX3.7	Channel status reset Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The signal is set to 1 as soon as the channel goes into the reset state, i.e. no processing taking place.
Signal state 0	The signal is set to 0 as soon as processing takes place in the channel, e.g.: a program program is being executed or block search
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3300 DBX4.2	All axes referenced Signal(s) from channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	All axes that must have a reference point have been referenced. (Note for axes that must have a reference point: MD34110 REFP_CYCLE_NR, MD20700 REFP_NC_START_LOCK)
Signal state 0	One or more axes of the channel have not been referenced.
Special cases, errors, ...	The spindles of the channel have no effect on this IS.
corresponding to ...	IS "Referenced/synchronized 1" (DB390x DBX0.4)
Note for the reader	Function Manual Basic Functions R1

DB3300 DBX4.3	All axes stationary Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	All axes assigned to the channel are stationary with interpolator end. No other traversing motions are active.
Note for the reader	Function Manual Basic Functions B1

DB3300 DBX4.6	Channelspecific NCK alarm is active Signal(s) from channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	At least one NCK alarm is present for the channel. Thus the following group interface signal is also set: DB2700 DBX3.0 (NCK alarm is present) The PLC user program can interrogate whether processing for the channel in question has been interrupted because of an NCK channel: DB3300 DBX4.7 (NCK alarm with processing stop active).
Signal state 0	No NCK alarm is present for the channel.
corresponding to ...	DB3300 DBX4.7 (NCK alarm with processing stop active) DB2700 DBX3.0 (NCK alarm present)
Note for the reader	/DA/ Diagnostics Guide

DB3300 DBX4.7	NCK alarm with processing stop active Signal(s) from channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	At least one NCK alarm, which is causing a processing stop of the part program running in the channel, is active.
Signal state 0	There is no alarm active for the channel that is causing a processing stop.
corresponding to ...	DB2700 DBX3.0 (NCK alarm present)
Note for the reader	/DA/ Diagnostics Guide

DB3300 DBX5.0 and .1	Contour handwheel active (1, 2) Signal(s) from channel (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	These PLC interface signals signal whether this geometry axis is assigned to contour handwheel 1/2 or is not assigned to a handwheel. Only one contour handwheel can be assigned to an axis at any one time. If several interface signals: DB3200 DBX14.0 and .1 (activate contour handwheel 1/2) are set, then "contour handwheel 1" has priority over "Contour handwheel 2". If the assignment is active, the geometry axis can be traversed in JOG mode with the contour handwheel or a DRF offset can be generated in AUTO-MATIC or MDI modes.
Signal state 0	This geometry axis is not assigned to contour handwheel 1/2.
Note for the reader	/DA/ Diagnostics Guide

DB3300 DBX6.0	Stroke initiation active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated:
Signal state 1	Stroke initiation is active.
Signal state 0	Stroke initiation is not active.

DB3300 DBX6.1	Manual stroke initiation acknowledgement Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated:
Signal state 1	A manual stroke was initiated.
Signal state 0	Manual stroke was not initiated.

6.7 Channelspecific signals

DB3300 DBX8.0 to 9.1	Machine-related protection zone 1 (...10) pre-activated Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The machinerelated protection zone 1 (...10) is pre-activated in the current block. (Pre-activated in the part program.) This means that the protection zone can be activated or deactivated in the PLC user program using the interface signal: DB3200 DBX8.0 - DBX9.1 (activate machine-related protection zone 1 (...10)).
Signal state 0	The machinerelated protection zone 1 (...10) is deactivated in the current block. (De-activated in the part program.) This means that the protection zone can be set to activated or deactivated in the PLC user program using the interface signal: DB3200 DBX8.0 to DBX9.1 (activate machine-related protection zone 1 (...10)).
Corresponding to ...	DB3200 DBX8.0 - DBX9.1 (activated machine-related protection zone 1 (...10))

DB3300 DBX10.0 to 11.1	Channel-specific protection zone 1 (...10) pre-activated Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The channelspecific protection zone 1 (...10) is pre-activated in the actual block. (Pre-activated in the part program.) This means that the protection zone can be set to activated or deactivated in the PLC user program using the interface signal: DB3200 DBX10.0 - DBX11.1 (activate channel-specific protection zone 1 (...10)).
Signal state 0	The channelspecific protection zone 1 (...10) is deactivated in the actual block. (Deactivated in the part program.) This means that the protection zone can be set to activated or deactivated in the PLC user program using the interface signal: DB3200 DBX10.0 - DBX11.1 (activate channel-specific protection zone 1 (...10)).
Corresponding to ...	DB3200 DBX10.0 - DBX11.1 (activate channel-specific protection zone 1 (...10))

DB3300 DBX12.0 to 13.1	Machine-related protection zone 1 (...10) violated Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The activated, machinerelated protection zone 1 (...10) is violated in the actual block or in the actual JOG movement. The pre-activated, machinerelated protection zone 1 (...10) would be violated in the actual block if it would be activated by the PLC.
Signal state 0	The activated, machinerelated protection zone 1 (...10) is not violated in the actual block. The pre-activated, machinerelated protection zone 1 (...10) would not be violated in the actual block if it would be activated by the PLC.
Application	Before parts are moved into the working zone - this IS can be used to check as to whether the tool or workpiece is located in the machinerelated protection zone of the part to be moved in.

DB3300 DBX14.0 to 15.1	Channel-specific protection zone 1 (...10) violated Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The activated, channelspecific protection zone 1 (...10) is violated in the actual block. The pre-activated, channelspecific protection zone 1 (...10) would be violated in the actual block if it would be activated by the PLC.
Signal state 0	The activated, channelspecific protection zone 1 (...10) is not violated in the actual block. The pre-activated, channelspecific protection zone 1 (...10) would not be violated in the actual block if it would be activated by the PLC.
Application	Before parts are moved into the working zone - this IS can be used to check whether the tool or workpiece is located in the channelspecific protection zone of the part to be moved-in.

DB3300 DBX1000.0 and .1 DBX1004.0 and .1 DBX1008.0 and .1	Handwheel active (1 to 2) for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	These PLC interface signals are used to define whether this geometry axis is assigned to handwheel 1/2 or is not assigned to any handwheel. Only one handwheel can be assigned to an axis at any one time. If several interface signals "activate handwheel" are set, then 'Handwheel 1' has a higher priority than 'Handwheel 2'. If the assignment is active, then the geometry axis can be traversed using the handwheel in the JOG mode.
Signal status	This geometry axis is not assigned to handwheel 1/2.
corresponding to ...	IS "Activate handwheel" (DB3200 DBX1000.0/.1, DB3200 DBX1004.0/.1, DB3200 DBX1008.0/.1)
Note for the reader	Function Manual Basic Functions H1

6.7 Channelspecific signals

DB3300 DBX1000.5 and .4 DBX1004.5 and .4 DBX1008.5 and .4	Plus and minus travel request (for axis in the Work) Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 0	A travel command in the relevant axis direction has not been given or a traverse movement has been completed. · JOG mode: The travel command is reset depending on the actual setting "Jog or continuous mode". While traversing with the handwheel. · Under REF mode: When the reference point is reached · AUT/MDI mode: The program block has been executed (and the next block does not contain any coordinate values for the axis in question). Cancel using "RESET", etc. IS "Axis disabled" is active.
corresponding to ...	DB3300 DBX1000.7 or .6 DB3300 DBX1004.7 or .6 DB3300 DBX1008.7 or .6 (travel command plus and travel command minus)

DB3300 DBX1000.7 and .6 DBX1004.7 and .6 DBX1008.7 and .6	Travel command plus and minus for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Travel is to be executed in the axis direction involved. Depending on the mode selected, the travel command is triggered in different ways. · JOG mode: With the plus or minus traversing key · Under REF mode: With traversing key that takes the axis to the reference point · AUTO/MDI mode: A program block containing a coordinate value for the axis in question is executed.
Signal state 0	A travel command in the relevant axis direction has not been given or a traverse movement has been completed. · JOG mode: - Withdrawing the traversing key - When ending traversing with the handwheel. · Under REF mode: When the reference point is reached · AUTO/MDI mode: - The program block has been executed (and the next block does not contain any coordinate values for the axis in question) - Cancel using "RESET", etc. - IS "Axis disable" is active

Application	Releasing the clamping for axes with clamping Note: If the clamping is not released until the travel command is given, these axes cannot be operated under continuous path control!
corresponding to ...	IS "Traversing key plus" and " ...minus" for axis 1 in the Work (DB3200 DBX1000.7 and .6) for axis 2 in the Work (DB3200 DBX1004.7 and .6) for axis 3 in the Work (DB3200 DBX1008.7 and .6)
Note for the reader	Function Manual Basic Functions H1

DB3300 DBX1001.0 to .6 DBX1005.0 to .6 DBX1009.0 to .6	Active machine function 1 INC, ..., continuous for axis 1 in the Work for axis 2 in the Work for axis 3 in the Work Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC interface receives a signal stating which machine function is active in the JOG mode for the geometry axes.
Signal state 0	The machine function in question is not active.
corresponding to ...	IS "Machine function 1 INC, ..., continuous" for axis 1 in the Work (DB3200 DBX1001.06) for axis 2 in the Work (DB3200 DBX1005.06) for axis 3 in the Work (DB3200 DBX1009.06)
Note for the reader	Function Manual Basic Functions H1

DB3300 DBX4001.1	Workpiece setpoint reached Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The specified workpiece target has been reached. Depending on the setting in MD27880 PART_COUNTER: Bit 1 = 0: for \$AC_REQUIRED_PARTS equal to \$AC_ACTUAL_PARTS Bit 1 = 1: for \$AC_REQUIRED_PARTS equal to \$AC_SPECIAL_PARTS
Signal state 0	The specified workpiece target has not been reached.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX4002.0	ASUB is stopped Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The signal is set to 1 if the control stops automatically prior to the end of ASUB (interrupt in a program mode and channel status stopped).
Signal state 0	The IS is set to 0 with start and reset.
Note for the reader	Function Manual Basic Functions K1

6.7 Channelspecific signals

DB3300 DBX4002.5	Associated M01/M00 active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The IS is used to display that for a corresponding previous enable/activation, an associated M00 or M01 auxiliary function is active.
Signal state 0	No associated M00/M01 auxiliary functions active.
corresponding to ...	DB3200 DBX14.5 (activate associated M01)
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX4002.6	Dry run feedrate active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The dry run feedrate is active. Instead of the programmed feedrate, the dry run feedrate entered in setting data: SD42100 \$SC_DRY_RUN_FEED is active. When activated from the operator panel, the dry run feedrate signal is automatically entered in the PLC interface and transmitted by the PLC basic program to the PLC interface signal: DB3200 DBX0.6 (activate dry run feedrate).
Signal state 0	Dry run feedrate is not active. The programmed feedrate is active.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBB4004	PROG-EVENT-DISPLAY Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Event-controlled
Signal state 1	The event assigned to the bit has activated the "Event-driven program call" function: Bit 0 → Part program start from channel status RESET Bit 1 → End of part program Bit 2 → Operator panel reset Bit 3 → Boot Bit 4 → 1st start after search run Bit 5 - 7 → Reserved, currently always 0 Signal duration: At least one complete PLC cycle
Signal state 0	· The event assigned to the bit has not activated the "Event-driven program call" function. · The event-driven user program has expired or was cancelled with RESET.
Note for the reader	

DB3300 DBX4006.0	ASUB active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	One ASUB is active.
Signal state 0	No ASUB is active.
Note for the reader	Function Manual Basic Functions K1

DB3300 DBX4006.0	ASUB active Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	An ASUB with suppressed display update is active (refer to MD20191).
Signal state 0	No ASUB with suppressed display update is active.
corresponding to ...	MD20191 IGN_PROG_STATE_ASUP (do not display execution of the interrupt program on the OPI)
Note for the reader	Function Manual Basic Functions K1

DB3500 DBB0 - 63	Active G function of groups 1 to 64 Signal(s) from channel (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Event-controlled
Signal status > 1	A G function of the G group is active. The active G group is saved in the dual format in the byte involved, e.g. G90: 0 1 0 1 1 0 1 0
Signal state 0	No G function of the G group is active.
Special cases, errors, ...	In contrast to auxiliary functions, G functions are not output to the PLC subject to acknowledgement, i.e. processing of the part program is continued immediately after the G function output.
Note for the reader	Programming Manual, Fundamentals

6.8 Axis/spindlespecific signals




Fig. 6-2 PLC interface signals for axis monitoring

6.8.1 Transferred axis-specific M, S functions

DB370x DBD0	M function for spindle Signal(s) from axis/spindle (NCK → PLC), axis-specific
Edge evaluation:	Signal(s) updated: Cyclic
Application	<p>Generally, the M functions are output for specific channels in DB2500. In the range DB2500 DBB1000 ... these are only present for one PLC cycle; in DB2500 DBD3000 ... up to a new output.</p> <p>Selected "M functions for the spindle" are available as integer number actual value of the PLC in this IS "M function for spindle".</p> <ul style="list-style-type: none"> · M3 → Value: 3 · M4 → Value: 4 · M5 → Value: 5
corresponding to ...	IS "S function for spindle" (DB370x DBD4), axis-specific IS auxiliary function transfer from NC channel (DB2500)
Note for the reader	Function Manual Basic Functions S1

DB370x DBD4	S function for spindle Signal(s) from axis/spindle (NCK → PLC), axis-specific
Edge evaluation:	Signal(s) updated: Cyclic
Application	<p>Generally, the S function is transferred channel-specific in DB2500 DBD4000 ... as floating-point value to the PLC.</p> <p>In this IS "S function for the spindle", this output is realized to the PLC as floating-point value for specific axes:</p> <ul style="list-style-type: none"> · S... as spindle speed in rpm (programmed value) · S... as constant cutting speed in m/min or ft/min for G96 <p>The following S functions are not output here:</p> <ul style="list-style-type: none"> · S... as programmed spindle speed limiting G25 · S... as programmed spindle speed limiting G26 · S... as the dwell time in spindle revolutions
corresponding to ...	IS "M function for spindle" (DB370x DBD0), axis-specific IS "Transferred S function" (DB2500 DBD4000 ...), channel-specific
Note for the reader	Function Manual Basic Functions S1

6.8.2 Signals to axis/spindle

DB380x	Feedrate override (axis specific)		
DBB0	Signal(s) to axis (PLC → NCK)		
Edge evaluation: No	Signal(s) updated: Cyclic		
Signal state 1	The axis-specific feedrate override is entered from the PLC gray-coded.		
	Gray coding for axis-specific feedrate override		
	Switch setting	Code	Axial feedrate override factor
	1	00001	0.0
	2	00011	0.01
	3	00010	0.02
	4	00110	0.04
	5	00111	0.06
	6	00101	0.08
	7	00100	0.10
	8	01100	0.20
	9	01101	0.30
	10	01111	0.40
	11	01110	0.50
	12	01010	0.60
	13	01011	0.70
	14	01001	0.75
	15	01000	0.80
	16	11000	0.85
	17	11001	0.90
	18	11011	0.95
	19	11010	1.00
	20	11110	1.05
	21	11111	1.10
	22	11101	1.15
	23	11100	1.20
	24	10100	1.20
	25	10101	1.20
	26	10111	1.20
	27	10110	1.20
	28	10010	1.20
	29	10011	1.20
	30	10001	1.20
	31	10000	1.20
corresponding to ...	IS "Override active" (DB380x DBX1.7)		
Note for the reader	Function Manual Basic Functions V1		

DB380x DBX1.1	Acknowledge fixed stop reached Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	→ The axis presses against the fixed stop with the clamping torque → The fixed stop monitoring window is activated → A block change is performed.
Signal state 0 Edge change 1 → 0	→ The axis pushes against the fixed stop with the clamping torque → The fixed stop monitoring window is activated → No block change is performed and channel alarm "Wait: Aux fct ackn missing" is displayed. The function is aborted, the alarm "20094 axis %1 Function aborted" is output. Significance when deselecting the function "FXS = 0" using the part program: The torque limiting and the monitoring of the fixed stop monitoring window is withdrawn.
IS relevant for ...	IS "Fixed stop reached" = 1
corresponding to ...	MD37060 FIXED_STOP_ACKN_MASK (observing PLC acknowledgements for travel to fixed stop) bit 1
Note for the reader	Function Manual Basic Functions F1

DB380x DBX1.2	Sensor for fixed stop Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Fixed stop has been reached.
Signal state 0	Fixed stop has not been reached.
corresponding to ...	The signal is only active , if MD37040 FIXED_STOP_BY_SENSOR=1.
Note for the reader	Function Manual Basic Functions F1

DB380x DBX1.3	Axis/spindle disable Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>Axis disable;</p> <p>If the interface signal "Axis disable" is output - for this axis - no more set-points are output to the position controller; the axis travel is therefore disabled. The position control loop remains closed and the remaining following error is reduced to zero. A moving axis is stopped with a ramp stop.</p> <p>If an axis is moved with axis disable the actual value position display shows the setpoint position and the actual velocity value display shows the setpoint velocity even though the machine axis is not actually moving.</p> <p>With a RESET the position actual value display is set to the real actual value of the machine.</p> <p>Travel commands continue to be output to the PLC for this axis.</p> <p>If the interface signal is canceled again the associated axis can again traverse normally.</p> <p>Spindle disable:</p> <p>If the interface signal "Spindle disable" is issued, then for this spindle no more setpoints are output to the speed controller in the openloop controlled mode or to the position controller in positioning mode. The movement of the spindle is thus disabled. For a rotating spindle, the spindle is stopped corresponding to its acceleration characteristic.</p> <p>The speed actual value display displays the speed setpoint value.</p> <p>Spindle disable can only be canceled per "Reset" or with M2 followed by a program restart.</p>
Signal state 0	<p>The position setpoint values are transferred to the position controller cyclically.</p> <p>The speed setpoint values are transferred to the speed controller cyclically.</p> <p>Cancellation of the "Axis/spindle disable" does not take effect until the axis/spindle is stationary (i.e. an interpolation setpoint is no longer present).</p>
Application	The interface signal "Axis/spindle disable" is used when running-in and testing a new NC part program. In so doing, the machine axes and spindles should not execute any traversing or rotational movement.
Special cases, errors, ...	<p>If the IS "Axis/spindle disable" is active, then the interface signals: DB380x DBX2.1 (controller enable), DB380x DBX4.3 (feedrate/spindle stop) and where relevant DB380x DBX1000.0/.1 (hardware limit switch) are ineffective with reference to braking the axis/spindle.</p> <p>The axis/spindle can however be brought into the "follow up" or "hold" state (see DB380x DBX1.4 (followup mode)).</p> <p>For response together with synchronized operation, see: /FB2/ Function Manual Basic Functions; Expanded Functions; Synchronized Spindle (S3)</p>
corresponding to ...	DB3300 DBX1.7 (program test active)
Note for the reader	Function Manuals

DB380x DBX1.4	Follow-up mode Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>Followup mode is selected for the axis/spindle by the PLC.</p> <p>The means that the position setpoint continually tracks the actual value if the controller enable for the drive is withdrawn.</p> <p>As soon as the follow-up mode is effective, the interface signal: DB390x DBX1.3 (follow-up mode active) is set.</p> <p>The actual value continues to be acquired and updated. If the axis/spindle is moved from its current position by an external effect the zero speed and clamping monitoring do not issue an alarm.</p> <p>When the closedloop control system is switched-on again, a controlinternal repositioning operation is performed (REPOSA: linear approach with all axes) to the last programmed position if a part program is active.</p>
Signal state 0	<p>Followup mode is not selected (so-called holding).</p> <p>When "controller enable" is removed the previous position setpoint is kept in the control. If the axis/spindle is pushed out of position during this time a following error occurs between the position setpoint and the position actual value. This position difference is reduced to zero immediately by issuing "controller enable" so that the previous setpoint position is restored.</p> <p>Then, all the other axis movements start from the setpoint position valid before "controller enable" was removed. When the position control is switched in again the axis may make a speed setpoint jump.</p> <p>Zero speed monitoring or clamping monitoring is still active.</p> <p>In order to disable (switch-out) the zero speed monitoring, when clamping an axis, the interface signal: DB380x DBX2.3 (clamping operation running) should be set.</p>
Special cases, errors, ...	<p>If the drive controller enable is withdrawn inside the control due to faults, then the following should be carefully observed:</p> <p>Before an NC start, after the queued alarms have been successfully deleted (i.e. inside the control, the controller enable is re-issued), then "holding" should be activated. Otherwise, for an NC start and selected follow-up mode, the traversing distance of the previous NC block would not be executed due to the internal delete distance to go.</p> <p>Notice:</p> <p>When changing over from the "follow-up" state to the "hold" state and in the control mode (a controller enable is issued), a delete distance-to-go command is activated in the control. As a consequence, for example, an NC block - in which only this axis is traversed - is ended directly.</p>
corresponding to ...	DB380x DBX2.1 (controller enable)
Note for the reader	Function Manual Basic Functions R1

DB380x DBX1.5 / 1.6	Position measuring system 1 (PMS1) / Position measuring system 2 (PMS2) Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
PMS1: Signal state 1 PMS2: Signal state 0	Position measuring system 1 is used for the axis/spindle (e.g. for position control, absolute value calculation, display). If a position measuring system 2 also exists (MD30200 NUM_ENC = 2), this actual value is also acquired.
PMS1: Signal state 0 PMS2: Signal state 1	Position measuring system 2 is used for the axis/spindle (e.g. for position control, absolute value calculation, display). If a position measuring system 2 also exists, this actual value is also acquired.
PMS1: Signal state 1 PMS2: Signal state 1	As it is not possible to use both position measuring systems simultaneously for the position control of an axis/spindle, the control automatically selects position measuring system 1. If a position measuring system 2 also exists, this actual value is also acquired.
Signal state 0	<p>1 The axis is in the park position. This means that the following features are valid:</p> <ul style="list-style-type: none"> - The position measuring system is inactive. - There is no actual value acquisition. - The monitoring functions of the position measuring system have been disabled (among others, the cable connection of the measuring value encoder). <p>The reference point is ineffective: The IS "Referenced/synchronized 1/2" has signal state 0. As soon as an axis is in the parked position, the interface signals: DB390x DBX1.5 (position controller active), DB390x DBX1.6 (speed controller active) and DB390x DBX1.7 (current controller active) are set to a 0 signal.</p> <p>After parking has been completed the axis must be re-referenced (reference point approach).</p> <p>If IS "Position measuring system 1" is set to a 0 signal while the axis is moving, the axis is stopped with a ramp stop without the controller enable being internally withdrawn in the control. This is appropriate for the following situations:</p> <ul style="list-style-type: none"> - Spindle encoder no longer outputs a signal above a certain speed (no longer supplies any pulses). - Spindle encoder is decoupled mechanically because it would not be able to handle the speed. <p>As a consequence, the spindle can then continue to run in speedcontrolled mode. In order to really bring the axis/spindle to a stop, the controller enable must always be removed additionally by the PLC.</p> <p>2 The spindle does not have a position measuring system and is only speed controlled. In this case, IS "Controller enable" should be set to a 1 signal.</p>

Application	<p>1 Switching over from position measuring system 1 to position measuring system 2 (and vice versa): If the axis was referenced in both position measuring systems and in the meantime, the limit frequency of the measuring encoder used was not exceeded, i.e. IS "Referenced/synchronized 1/2" has a signal state 1, then after the switchover, a new reference point approach is not required. At switchover, the actual difference between position measuring system 1 and 2 is traversed immediately. Using MD36500 ENC_CHANGE_TOL, a tolerance bandwidth can be specified in which the deviation between the two actual values may lie at the switchover. If the actual value difference is greater than the tolerance, a switchover between the two systems does not take place and alarm 25100 "Measuring system switchover" not possible is triggered.</p> <p>2 Parking axis (i.e. no PMS is active): If the encoder has to be removed - e.g. if a rotary table has to be removed from the machine - the position measuring system monitoring is switched off in the parking position. The mounted axis/spindle encoder turns so quickly in certain applications that it can no longer maintain its electrical characteristics (edge rate-of-rise, etc.).</p> <p>3 Switching-off the measuring system: When the measuring system is switched-off, the associated IS "Referenced/synchronized 1/2" is reset.</p> <p>4 Reference point approach: The reference point approach of the axis is executed with the selected position measuring system.</p>
Special cases, errors, ...	If the "parking axis" state is active, then the interface signal "Referenced/synchronized 1/2" is ignored at NC start for this axis.
corresponding to ...	DB390x DBX0.4/.5 (referenced/synchronized 1/2) DB380x DBX2.1 (controller enable) MD36500 ENC_CHANGE_TOL (max. tolerance for the actual position value switchover) MD30200 NUM_ENCS (number of encoders)
Note for the reader	Function Manual Basic Functions G2

DB380x DBX1.7	Override active Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>Feedrate override active (for axes):</p> <ul style="list-style-type: none"> · The axis-specific feedrate override between 0 and a maximum of 120% entered in the PLC interface is used. <p>Spindle override active (for spindle):</p> <ul style="list-style-type: none"> · The spindle override - input at the PLC interface - of 50 to a maximum of 120% is taken into account.
Signal state 0	<p>The existing axis-specific feedrate override or spindle override is not active. If the feedrate override is inactive, "100%" is used as the internal override factor.</p> <p>Note:</p> <p>The 1st switch position of the gray-coded interface for the value is an exception. Also here, for "Override inactive", the override factor of the 1st switch position is used and for axes, 0% is output as override value (acts the same as "Feedrate disable"); correspondingly 50% for the spindle.</p>
Special cases, errors, ...	<ul style="list-style-type: none"> · The spindle override is always accepted with 100% in the spindle "Oscillation mode". · The spindle override acts on the programmed values before limits (e.g. G26) intervene. · The feedrate override is inactive when G33 is active.
corresponding to ...	IS "Feedrate override" and IS "Spindle override"
Note for the reader	Function Manual Basic Functions V1

DB380x DBX2.1	Controller enable Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>The position control loop of the axis/spindle is closed; the axis/spindle is in closedloop control.</p> <p>When "controller enable" is set by the PLC user program:</p> <ul style="list-style-type: none"> · Position control loop of axis is closed. · Position actual value is no longer switched to the position setpoint. · The controller enable of the drive is output. · The interface signal: DB390x DBX1.5 (position controller active) is set to a 1 signal. <p>When "controller enable" has been issued no new actual value synchronization of the axis (reference point approach) of the axis is necessary if the maximum permissible limit frequency of the axis measuring system has not been exceeded during followup mode.</p> <p>As a function of the interface signal: DB380x DBX1.4 (followup mode) it is possible to select whether or not the axis first traverses back to the earlier setpoint position (i.e. the positional deviation caused by the clamping process is moved through to eliminate the deviation).</p>
Signal state 0	<p>"Controller enable" will be/is removed.</p> <p>The interface signals: DB390x DBX1.5 (position controller active) DB390x DBX1.6 (speed controller active) DB390x DBX1.7 (current controller active) are set to a 0 signal.</p> <p>The procedure for removing "controller enable" depends on whether the axis/spindle or an axis of the geometry grouping is stationary or traversing at this point in time.</p> <ul style="list-style-type: none"> · Axis/spindle stationary: <ul style="list-style-type: none"> - Position control loop of axis is opened. - For IS "follow-on mode" = 1, the position actual value is switched to the position setpoint (i.e. the position setpoint tracks the actual position). The position actual value of the axis/spindle continues to be acquired by the control. - The controller enable of the drive is removed. · Axis/spindle traverses: <ul style="list-style-type: none"> - The axis is stopped with rapid stop. - Alarm 21612 "VDI signal controller enable reset during movement" is output. - The position control loop of the axis/spindle is opened. - Independent of IS: "Follow-up mode" at the end of braking the position actual value is switched to the position setpoint (i.e. the setpoint position is corrected to track the actual value position). The position actual value of the axis/spindle continues to be acquired by the control. IS "Followup mode" is set. <p>The axis status cannot be changed again until after RESET.</p>

6.8 Axis/spindlespecific signals

Application	<p>Using the controller enable when clamping the axis:</p> <p>The axis is positioned to the clamping position. As soon as it has stopped it is clamped and then controller enable is removed. Controller enable is removed because the axis could be mechanically pressed out of position slightly by clamping and the position controller would continuously have to work against the clamping.</p> <p>When clamping is to be withdrawn again, a controller enable signal is first set again and then the axis is freed from clamping.</p>
Special cases, errors, ...	<p>If an attempt is made to traverse the axis without controller enable, the axis remains stationary but sends a travel command to the PLC. The travel command is kept and is executed when the controller enable is re-activated.</p> <p>If the controller enable of a traversing geometry axis is removed the programmed contour cannot be maintained.</p> <p>Controller enable is automatically cancelled by the control when certain faults occur at the machine, the position measuring system or the control.</p>
corresponding to ...	<p>MD36620 SERVO_DISABLE_DELAY_TIME (switchoff delay controller enable)</p> <p>MD36610 AX_EMERGENCY_STOP_TIME (time for braking ramp when fault conditions occur)</p>
Note for the reader	Function Manual Basic Functions G2

DB380x DBX2.2	<p>Distance-to-go/Spindle reset</p> <p>Signal(s) to axis/spindle (PLC → NCK)</p>
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>Independent of MD35040 SPIND_ACTIVE_AFTER_RESET selects a spindle reset for the various spindle modes in the following fashion:</p> <p>Control mode:</p> <ul style="list-style-type: none"> · Spindle stops · Program continues to run · Spindle continues to run with subsequent M and S program commands <p>Oscillating mode:</p> <ul style="list-style-type: none"> · Oscillation is interrupted · Axes continue to run · Program continues with the actual gearbox stage · With subsequent M value and higher S value, it is possible that IS "Setpoint speed limited" (DB390x DBX2001.1) is set. <p>Positioning mode:</p> <ul style="list-style-type: none"> · Is stopped
Signal state 0 or edge change 1 → 0	No effect
corresponding to ...	<p>MD35040 SPIND_ACTIVE_AFTER_RESET (own spindle reset)</p> <p>IS "Reset" (DB3000 DBX0.7)</p> <p>IS "Delete distance to go" (DB380x DBX2.2), another name applies for the same signal, however, for an axis</p>
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2.3	Clamping in progress Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Clamping in progress. The clamping monitoring is activated.
Signal state 0	Clamping completed. The clamping monitoring function is replaced by the standstill (zero speed) monitoring.
corresponding to ...	MD36050 CLAMP_POS_TOL (clamping tolerance)
Note for the reader	Function Manual Basic Functions A3

DB380x DBX2.4 - .7	Reference point values 1 to 4 Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When the reference cam is reached, the NCK is signaled which coded reference cam is actuated. The IS must remain set until the reference point is reached or until a new coded reference cam is approached. If the machine axis has reached the reference point (axis stationary) then reference point value, pre-selected via the IS from MD34100 is accepted as new reference position in the control.
Signal state 0	No effect.
Signal irrelevant for ...	Length measurement systems with distancecoded reference marks
Application	On a machine tool with large traversing distances, four coded reference cams can be distributed over the entire distance traveled by the axis, four different reference points approached and the time required to reach a valid referenced point reduced.
Special cases, errors	If the machine axis has reached the reference point and none of the four IS are set, then reference point value 1 is automatically valid.
corresponding to ...	MD34100 REFP_SET_POS (reference point value) MD36050 CLAMP_POS_TOL (clamping tolerance)
Note for the reader	Function Manual Basic Functions R1

DB380x DBX3.1	Enable travel to fixed stop Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Meaning when the "FXS" function is selected via part program, (IS "Activate travel to fixed stop" = 1): Travel to fixed stop is enabled and the axis traverses from the start position at the programmed velocity to the programmed target position.
Signal state 0 Edge change 1 → 0	Meaning when function "FXS" is selected via part program (IS "Activate travel to fixed stop" = 1): → Travel to fixed stop is locked. → The axis remains at the start position with reduced torque. → The channel message "Wait: Aux fct ackn missing" is displayed. Meaning before the fixed stop has been reached IS "Fixed stop reached" = 0. → Travel to fixed stop is interrupted → Alarm "20094: Axis%1 function was aborted" is displayed Meaning once fixed stop has been reached IS "Fixed stop reached" = 1. Torque limiting and the monitoring of the fixed stop monitoring window are canceled.
IS irrelevant for ...	MD 37060: FIXED_STOP_ACKN_MASK (observing PLC acknowledgments for travel to fixed stop) = 0 or 2
corresponding to ...	MD 37060: FIXED_STOP_ACKN_MASK (observe PLC acknowledgments for travel to fixed stop) IS "Activate travel to fixed stop"
Note for the reader	Function Manual Basic Functions F1

DB380x DBX3.6	Velocity/spindle speed limitation Signal(s)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The NCK limits the velocity/spindle speed to the limit value set in MD35160 SPIND_EXTERN_VELO_LIMIT.
Signal state 0	No limiting active.
corresponding to ...	MD35100 SPIND_VELO_LIMIT (max. spindle speed) SD43220 SPIND_MAX_VELO_G26 (prog. spindle speed limit G26) SD43230 SPIND_MAX_VELO_LIMIT (spindle speed limit G96)
Note for the reader	Function Manual Basic Functions A3

DB380x DBX4.0 to .1	Activate handwheel (1 to 2) Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	These PLC interface signals are used to define whether this machine axis is assigned to handwheel 1 or 2 or is not assigned to any handwheel. Only one handwheel can be assigned to an axis at any one time. If several interface signals "Activate handwheel" are set, then the following priority applies: Handwheel 1 before handwheel 2. If the assignment is active, then the machine axis can be traversed using the handwheel in the JOG mode.
Signal state 0	This machine axis is neither assigned to handwheel 1 nor 2.
Application	The PLC user program can use this interface signal to interlock the influence on the axis by turning a handwheel.
corresponding to ...	IS "Handwheel 1/2 active" (DB390x DBX4.0/.1)
Note for the reader	Function Manual Basic Functions H1

DB380x DBX4.3	Feedrate stop/spindle stop (axis-specific) Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>The signal is active in all modes.</p> <p>Feedrate stop:</p> <ul style="list-style-type: none"> · The signal triggers a feedrate stop for the axis. For a traversing axis, this signal brings it to a standstill with a controlled braking (ramp stop). No alarm is output. · The signal triggers a "feedrate stop" for all path axes interpolating relative to each other when the "feedrate stop" is activated for any one of these path axes. In this case, all the axes are brought to a stop maintaining the path contour. When the feedrate stop signal is withdrawn, execution of the interrupted parts program is resumed. · The position control is kept, i.e. the following error is eliminated. · If a travel request is issued for an axis with an active "feedrate stop", then this is kept. This pending travel request is executed directly when "Feedrate stop" is withdrawn. If the axis is interpolating in relation to others, this also applies to these axes. <p>Spindle stop:</p> <ul style="list-style-type: none"> · The spindle is brought to a standstill along the acceleration characteristic. · In the positioning mode, when the "Spindle stop" signal is set positioning is interrupted. The above response applies with respect to individual axes.
Signal state 0	<p>Feedrate stop:</p> <ul style="list-style-type: none"> · The feedrate is enabled for the axis. · If a travel request ("travel command") is active when the "feedrate stop" is withdrawn, this is executed immediately. <p>Spindle stop:</p> <ul style="list-style-type: none"> · The speed is enabled for the spindle. · When "spindle stop" is withdrawn, the spindle is accelerated to the previous speed setpoint with the acceleration characteristic or, in the positioning mode, positioning is resumed.
Application	<p>Feedrate stop:</p> <p>The traversing motion of the machine axes is not started with "feedrate stop", if, for example, certain operating states exist at the machine that do not permit the axes to be moved (e.g. a door is not closed).</p> <p>Spindle stop:</p> <p>In order to change a tool.</p>
Note for the reader	Function Manual Basic Functions V1

DB380x DBX4.4	Traversing key disable Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The traversing keys plus and minus have no effect on the machine axes in question. It is thus not possible to traverse the machine axis in JOG using the traversing keys on the machine control panel. If the traversing key disable is activated during a traversing movement, the machine axis is stopped.
Signal state 0	The plus and minus traversing keys are enabled.
Application	It is thus possible, depending on the mode, to interlock manual traversing of the machine axis in JOG mode using the traversing keys from the PLC user program.
corresponding to ...	IS "Traversing key plus" and "Traversing key minus" (DB380x DBX4.7 and .6)
Note for the reader	Function Manual Basic Functions H1

DB380x DBX4.5	Rapid traverse override Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	If the PLC interface signal "Rapid traverse override" is issued together with the "Traversing key plus" or "Traversing key minus", then the machine axis involved moves with rapid traverse. MD32010 JOG_VELO_RAPID defines the rapid traverse velocity. The rapid traverse override is effective in the JOG mode for the following versions: <ul style="list-style-type: none"> · For continuous travel · For incremental travel If rapid traverse override is active, the velocity can be modified using the axis-specific feedrate override switch.
Signal state 0	The machine axis traverses with the specified JOG velocity (SD41110 JOG_SET_VELO or SD41130 or MD32020 JOG_VELO).
Signal irrelevant for ...	<ul style="list-style-type: none"> · AUTOMATIC and MDI modes · Reference point approach (JOG mode)
corresponding to ...	IS "Traversing key plus" and "Traversing key minus" (DB380x DBX4.7 and .6) IS "Axis-specific feedrate override" (DB380x DBX0)
Note for the reader	Function Manual Basic Functions H1

DB380x DBX4.7 and .6	Plus and minus traversing keys Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>The selected axis can be traversed in both directions in JOG mode using the plus and minus traversing keys.</p> <p>Incremental travel</p> <p>With signal state 1 the axis starts to traverse the set increment. If the signal changes to the 0 state before the increment is traversed, the traversing movement is interrupted. With a new signal state 1, the traversing motion is continued.</p> <p>Until the increment has been completely traversed, the axis traversing motion can be stopped and continued a multiple number of times as described above.</p> <p>Continuous traversing</p> <p>If an INC dimension has not been selected, but "continuous", then the axis traverses as long as the traversing key is kept pressed.</p> <p>If both traversing signals (plus and minus) are set at the same time there is no movement or a current movement is aborted.</p> <p>The effect of the traversing keys can be disabled for a specific axis using the the PLC interface signal "Traversing key disable".</p>
Signal state 0 or edge change 1 → 0	No traversing
Signal irrelevant for ...	AUTOMATIC and MDI modes
Application	The machine axis cannot be traversed in JOG mode if it is already being traversed via the channel-specific PLC interface (as a geometry axis). Alarm 20062 is signaled.
Special cases, ...	Indexing axes
corresponding to ...	<p>IS "Traversing key plus" and "...minus"</p> <p>for axis 1 in the Work (DB3200 DBX1000.7 and .6)</p> <p>for axis 2 in the Work (DB3200 DBX1004.7 and .6)</p> <p>for axis 3 in the Work (DB3200 DBX1008.7 and .6)</p> <p>IS "Traversing key disable" (DB380x DBX4.4)</p>
Note for the reader	Function Manual Basic Functions H1

DB380x DBX5.0 and .6	Machine function 1 INC, 10 INC, 100 INC, 1000 INC, 10000 INC, var. INC, continuous Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>This input range is only used if IS "INC inputs active in the mode group area" (DB2600 DBX1.0) is not set.</p> <p>IS "INC..." is used to define how many increments the machine axis traverses when the traversing key is pressed or the handwheel is turned one detent position. In this case, the JOG mode must be active.</p> <p>For "var. INC", the value in SD41010 JOG_VAR_INCR_SIZE is generally valid.</p> <p>For "continuous", the associated axis can be traversed using either the plus or minus traversing key by keeping the key pressed.</p> <p>As soon as the selected machine function becomes active, this is signaled at the PLC interface (IS "Active machine function 1 INC...").</p> <p>If several machine function signals (1 INC, INC... or "Continuous traversing") are selected at the interface simultaneously, then no machine function is activated by the control.</p> <p>Note:</p> <p>The input IS "INC..." or "continuous" to change an active machine function must be present for at least one PLC cycle. A steady-state signal is not required.</p>
Signal state 0	<p>The machine function in question is not selected. No request is made to change an active machine function.</p> <p>If an axis is currently traversing an increment, this movement is also aborted if this machine function is deselected or switched over.</p>
corresponding to ...	IS "Active machine function 1 INC, ..." (DB390x DBX5.06) IS "INC inputs active in the mode group area" (DB2600 DBX1.0)
Note for the reader	Function Manual Basic Functions H1

DB380x DBX1000.1 and .0	Hardware limit switches plus and minus Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>A switch can be mounted at each end of the travel range of a machine axis which will cause a signal "hardware limit switch plus or minus" to be signaled to the NC via the PLC if it is actuated.</p> <p>If the signal is recognized as set, alarm 021614 "Hardware limit switch plus or minus" is output and the axis is immediately braked. The braking type is defined using MD 36600: BRAKE_MODE_CHOICE (braking behavior with hardware limit switch).</p>
Signal state 0	Normal condition - a hardware limit switch has not responded.
corresponding to ...	MD36600 BRAKE_MODE_CHOICE (braking behavior for the hardware limit switch)
Note for the reader	Function Manual Basic Functions A3

6.8 Axis/spindlespecific signals

DB380x DBX1000.3 or .2	2. software limit switch plus or minus Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	2. software limit switch for the plus or minus direction is active. 1st software limit switch for the plus or minus direction is inactive. In addition to the 1st software limit switches (plus or minus), 2nd software limit switch (plus or minus) can be activated via these interface signals. The position is defined using MD36130 POS_LIMIT_PLUS2, MD36120 POS_LIMIT_MINUS2 (2nd software limit switch plus, 2nd software limit switch minus).
Signal state 0	1. software limit switch for the plus or minus direction is active 2nd software limit switch for the plus or minus direction is inactive
Note for the reader	Function Manual Basic Functions A3

DB380x DBX1000.7	Reference point approach deceleration Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The machine axis is positioned at the reference cam.
Signal state 0	The machine axis is positioned in front of the reference cam. An appropriately long reference cam (up to the end of the traversing range) should be used to prevent the machine axis from being located behind (after) the referencing cam.
Note for the reader	Function Manual Basic Functions R1

DB380x DBX1002.1	Activate the program test Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Activation of the program test is requested. During the program test, all motion commands of axes (not spindles) take place under "Axis disable." Notice! Because of the axis disable, the assignment of a tool magazine is not changed during program testing. The user/machine manufacturer must utilize a suitable PLC user program to ensure that the NCK-internal tool management and the actual assignment of the tool magazine remain consistent. Refer to the program example included in the PLC Toolbox.
Signal state 0	Activation of the program test is not requested.
corresponding to ...	DB1700 DBX1.7 (program test selected) DB3300 DBX1.7 (program test active)
Note for the reader	Function Manual Basic Functions K1

DB380x DBX2000.0 to .2	Actual gear stage A to C Signal(s) to axis/spindle (PLC → NCK)																												
Edge evaluation: Yes	Signal(s) updated: Cyclic																												
Signal state 1(status-controlled)	<p>If the new gearbox stage is engaged, then the PLC user sets the IS "Actual gear stage A" to "...C" and the IS "Gear is changed over". This signals to the NCK that the correct gear stage has been successfully engaged. The gear change is considered to have been completed (spindle oscillation mode is deselected), the spindle accelerates in the new gear stage to the last programmed spindle speed and the next block in the parts program can be executed.</p> <p>The actual gear stage is specified coded (ABC values). There is one parameter set for each of the 5 gear stages, which is parameterized as follows:</p> <table border="1"> <thead> <tr> <th>Parameter set No.</th> <th>Code CBA</th> <th>Data of the data set</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>-</td> <td>Data for axis mode</td> <td>Kv factor Monitoring</td> </tr> <tr> <td>1</td> <td>000 001</td> <td>Data for the 1st gear stage</td> <td>M40 speed Min/max speed Acceleration etc.</td> </tr> <tr> <td>2</td> <td>010</td> <td>Data for the 2nd gear stage</td> <td></td> </tr> <tr> <td>3</td> <td>011</td> <td>Data for the 3rd gear stage</td> <td></td> </tr> <tr> <td>4</td> <td>100</td> <td>Data for the 4th gear stage</td> <td></td> </tr> <tr> <td>5</td> <td>101 110 111</td> <td>Data for the 5th gear stage</td> <td></td> </tr> </tbody> </table>	Parameter set No.	Code CBA	Data of the data set	Content	0	-	Data for axis mode	Kv factor Monitoring	1	000 001	Data for the 1st gear stage	M40 speed Min/max speed Acceleration etc.	2	010	Data for the 2nd gear stage		3	011	Data for the 3rd gear stage		4	100	Data for the 4th gear stage		5	101 110 111	Data for the 5th gear stage	
Parameter set No.	Code CBA	Data of the data set	Content																										
0	-	Data for axis mode	Kv factor Monitoring																										
1	000 001	Data for the 1st gear stage	M40 speed Min/max speed Acceleration etc.																										
2	010	Data for the 2nd gear stage																											
3	011	Data for the 3rd gear stage																											
4	100	Data for the 4th gear stage																											
5	101 110 111	Data for the 5th gear stage																											
Special cases, errors, ...	If the PLC user signals back to the NCK with a different actual gear stage than issued by the NCK as the setpoint gear stage, the gear change is still considered to have been successfully completed and the actual gear stage A to C is activated.																												
corresponding to ...	IS "Setpoint gear stage A" to "...C" (DB390x DBX2000.0 to .2) IS "Change gear stage" (DB390x DBX2000.3) IS "Gear stage is changed over" (DB380x DBX2000.3) IS "Oscillation speed" (DB380x DBX2002.5) Parameter sets (MDs) for gear stages																												
Note for the reader	Function Manual Basic Functions S1																												

6.8 Axis/spindlespecific signals

DB380x DBX2000.3	Gear is changed over Signal(s) to axis/spindle (PLC → NCK)	
Edge evaluation: Yes	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	If the new gearbox stage is engaged, then the PLC user program sets the IS "Actual gear stage A to C" and the IS "Gear stage is changed over". This signals the NCK that the correct gear stage has been successfully engaged. The gear stage change is complete (spindle oscillation mode is deselected), the spindle accelerates in the new gear stage to the last programmed spindle speed and the next block in the parts program can be executed. The NCK resets the IS "Change gear stage" and then the PLC user program resets the IS "Gear stage is changed over".	
Signal state 0 or edge change 1 → 0	No effect	
Signal irrelevant for ...	spindle modes other than the oscillation mode	
Special cases, errors, ...	If the PLC user signals back to the NCK with a different actual gear stage than issued by the NCK as the setpoint gear stage, the gear change is still considered to have been successfully completed and the actual gear stage A to C is activated.	
corresponding to ...	IS "Actual gear stage A" to "...C" (DB380x DBX2000.0 to .2) IS "Setpoint gear stage A" to "...C" (DB390x DBX2000.0 to .2) IS "Change gear stage" (DB390x DBX2000.3) IS "Oscillation speed" (DB380x DBX2002.5)	
Note for the reader	Function Manual Basic Functions S1	

DB380x DBX2000.4 and .5	Resynchronizing spindles 1 and 2 Signal(s) from axis/spindle (PLC → NCK)	
Edge evaluation: Yes	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	The spindle should be resynchronized, as the synchronization between the position measuring system of the spindle and the 0° position has been lost.	
Signal state 0 or edge change 1 → 0	No effect.	
Signal irrelevant for spindle modes other than the control mode.	
Application	The machine has a selector switch for a vertical and horizontal spindle. Two different position measuring encoders are required, but only one actual value input is used at the control. When the system switches from the vertical to the horizontal spindle, the spindle must be resynchronized. This synchronization is triggered by the IS "Re-synchronize spindle 1 or 2".	
corresponding to ...	DB390x DBX0.4/.5 (referenced/synchronized 1/2)	
Note for the reader	Function Manual Basic Functions V1	

DB380x DBX2000.7	Delete S value Signal(s) from axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Control mode: · Spindle stops · Program continues to run · Spindle continues to run with the following S value, if M3 or M4 were active Oscillation mode, axis mode, positioning mode: Signal is inactive. However, if the open-loop control mode is selected again, a new S value must be programmed.
Signal state 0 or edge change 1 → 0	No effect.
Application	Terminating traversing motion on account of an external signal (e.g. probe).
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2001.0	Feedrate override for spindle valid (instead of spindle override) Signal(s) from axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Instead of the value for "Spindle override" the value of "feedrate override" (DB380x DBB0) is used for the spindle.
Signal state 0 or edge change 1 → 0	The value of "spindle override" is used.
corresponding to ...	IS "Spindle override" (DB380x DBB2003) IS "Feedrate override" (DB380x DBB0) IS "Override active" (DB380x DBX1.7)
Note for the reader	Function Manual Basic Functions V1

DB380x DBX2001.4	Resynchronize spindle during positioning 1 Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1	When positioning, the spindle must be re-synchronized.
Signal state 0 or edge change 1 → 0	No effect
Signal irrelevant for spindle modes other than the positioning mode
Application	The spindle has an indirect measuring system and slip may occur between the motor and clamp. If the signal=1, when positioning is started, the old reference is deleted and the zero mark is searched for again before the end position is approached.
corresponding to ...	IS "Referenced/synchronized 1" (DB390x DBX0.4)
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2001.6	Invert M3/M4 Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The direction of rotation of the spindle motor changes for the following functions: <ul style="list-style-type: none"> · M3 · M4 · M5 · SPOS from the motion; not active for SPOS from standstill
Application	The machine has a selector switch for a vertical and horizontal spindle. The mechanical design is implemented so that for the horizontal spindle, one more gearwheel is engaged than for the vertical spindle. The direction of rotation must therefore be changed for the vertical spindle if the spindle is always to rotate clockwise with M3.
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2002.4	Oscillation via PLC Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If the IS "Oscillation via PLC" is set , then with the IS "Oscillation speed", a speed is output in conjunction with the IS "Setpoint direction of rotation, clockwise and counter-clockwise).
Signal state 0 or edge change 1 → 0	If the IS "Oscillation via the PLC" is not set , then automatic oscillation is executed in the NCK using the IS "Oscillation speed". The two times for the directions of rotation are entered into MD35440 and MD35450.
Application	If the new gear stage cannot be engaged in spite of several oscillation attempts by the NCK, the system can be switched to oscillation via the PLC. Both of the times for the directions of rotation can then be altered by the PLC user program as required. This ensures that the gear stage is reliably changed - even with unfavorable gear wheel positions.
corresponding to ...	MD35440 SPIND_OSCILL_TIME_CW (oscillation time for M3direction) MD35450 SPIND_OSCILL_TIME_CCW (oscillation time for M4 direction) IS "Oscillation speed" (DB380x DBX2002.5) IS "Setpoint direction of rotation counter-clockwise" (DB380x DBX2002.7) IS "Setpoint direction of rotation clockwise" (DB380x DBX2002.6)
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2002.5	Oscillation speed Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>If the gear stage is to be changed (IS "Change gear stage" (DB390x DBX2000.3) is set), then the spindle operating mode changes to the oscillation mode.</p> <p>Depending on the instant in time that IS "Oscillation speed" is set, the spindle brakes down to standstill with different acceleration levels:</p> <ol style="list-style-type: none"> 1 The IS "Oscillation speed" is set before the IS "Change gear stage" is set by the NCK. The spindle is braked down to standstill with the acceleration when oscillating (MD35410). Oscillation starts immediately once the spindle is stationary. 2 The IS "Oscillation speed" is set after the IS "Change gear stage" is set by the NCK and after the spindle is stationary. The position controller is disabled. The spindle is braked with the acceleration in the speed controlled mode. After the IS "Oscillation speed" is set, the spindle starts to oscillate with the oscillation acceleration (MD35410). <p>If the IS "Oscillation via the PLC" (DB380x DBX2002.4) is not set, then automatic oscillation is executed in the NCK using the IS "Oscillation speed". The two times for the directions of rotation are entered into MD35440 and MD35450.</p> <p>If the IS "Oscillation via PLC" is set, then with the IS "Oscillation speed", a speed is output in conjunction with the IS "Setpoint direction of rotation, clockwise and counter-clockwise).</p>
Signal state 0	The spindle does not oscillate.
Signal irrelevant for all spindle modes except for the oscillation mode
Application	The oscillation speed is used to make it easier to engage a new gear stage.
corresponding to ...	IS oscillation via the PLC (DB380x DBX2002.4) IS setpoint direction of rotation counter-clockwise (DB380x DBX2002.7) IS setpoint of rotation clockwise (DB380x DBX2002.6)
Note for the reader	Function Manual Basic Functions S1

DB380x DBX2002.7 and .6	Setpoint direction of rotation, counter-clockwise and clockwise Signal(s) to axis/spindle (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If the IS "Oscillation via the PLC" is set, then the direction of rotation for the oscillation speed can be specified using the two IS "Setpoint direction of rotation counter-clockwise and clockwise". The times for the oscillation movement of the spindle motor are defined by setting the IS "Setpoint direction of rotation counter-clockwise and clockwise" for a corresponding length of time.
Signal irrelevant for spindle modes other than the oscillation mode
Application	see IS "Oscillation via PLC"
Special cases, errors, ...	<ul style="list-style-type: none"> · If both IS are set simultaneously, no oscillation speed is output. · If no IS is set, then an oscillation speed is not output.
corresponding to ...	IS "Oscillation via the PLC" (DB380x DBX2002.4) IS "Oscillation speed" (DB380x DBX2002.5)
Note for the reader	Function Manual Basic Functions S1

DB380x DBB2003	Spindle override Signal(s) to spindle (PLC → NCK)																																																																																																		
Edge evaluation: No	Signal(s) updated: Cyclic																																																																																																		
Signal state 1	<p>The spindle override is specified via the PLC in the Gray code. The override value determines the percentage of the programmed speed setpoint that is issued to the spindle.</p> <p>Gray coding for spindle override</p> <table border="1"> <thead> <tr> <th>Switch setting</th> <th>Code</th> <th>Spindle override factor</th> </tr> </thead> <tbody> <tr><td>1</td><td>00001</td><td>0.5</td></tr> <tr><td>2</td><td>00011</td><td>0.55</td></tr> <tr><td>3</td><td>00010</td><td>0.60</td></tr> <tr><td>4</td><td>00110</td><td>0.65</td></tr> <tr><td>5</td><td>00111</td><td>0.70</td></tr> <tr><td>6</td><td>00101</td><td>0.75</td></tr> <tr><td>7</td><td>00100</td><td>0.80</td></tr> <tr><td>8</td><td>01100</td><td>0.85</td></tr> <tr><td>9</td><td>01101</td><td>0.90</td></tr> <tr><td>10</td><td>01111</td><td>0.95</td></tr> <tr><td>11</td><td>01110</td><td>1.00</td></tr> <tr><td>12</td><td>01010</td><td>1.05</td></tr> <tr><td>13</td><td>01011</td><td>1.10</td></tr> <tr><td>14</td><td>01001</td><td>1.10</td></tr> <tr><td>15</td><td>01000</td><td>1.15</td></tr> <tr><td>16</td><td>11000</td><td>1.20</td></tr> <tr><td>17</td><td>11001</td><td>1.20</td></tr> <tr><td>18</td><td>11011</td><td>1.20</td></tr> <tr><td>19</td><td>11010</td><td>1.20</td></tr> <tr><td>20</td><td>11110</td><td>1.20</td></tr> <tr><td>21</td><td>11111</td><td>1.20</td></tr> <tr><td>22</td><td>11101</td><td>1.20</td></tr> <tr><td>23</td><td>11100</td><td>1.20</td></tr> <tr><td>24</td><td>10100</td><td>1.20</td></tr> <tr><td>25</td><td>10101</td><td>1.20</td></tr> <tr><td>26</td><td>10111</td><td>1.20</td></tr> <tr><td>27</td><td>10110</td><td>1.20</td></tr> <tr><td>28</td><td>10010</td><td>1.20</td></tr> <tr><td>29</td><td>10011</td><td>1.20</td></tr> <tr><td>30</td><td>10001</td><td>1.20</td></tr> <tr><td>31</td><td>10000</td><td>1.20</td></tr> </tbody> </table>			Switch setting	Code	Spindle override factor	1	00001	0.5	2	00011	0.55	3	00010	0.60	4	00110	0.65	5	00111	0.70	6	00101	0.75	7	00100	0.80	8	01100	0.85	9	01101	0.90	10	01111	0.95	11	01110	1.00	12	01010	1.05	13	01011	1.10	14	01001	1.10	15	01000	1.15	16	11000	1.20	17	11001	1.20	18	11011	1.20	19	11010	1.20	20	11110	1.20	21	11111	1.20	22	11101	1.20	23	11100	1.20	24	10100	1.20	25	10101	1.20	26	10111	1.20	27	10110	1.20	28	10010	1.20	29	10011	1.20	30	10001	1.20	31	10000	1.20
Switch setting	Code	Spindle override factor																																																																																																	
1	00001	0.5																																																																																																	
2	00011	0.55																																																																																																	
3	00010	0.60																																																																																																	
4	00110	0.65																																																																																																	
5	00111	0.70																																																																																																	
6	00101	0.75																																																																																																	
7	00100	0.80																																																																																																	
8	01100	0.85																																																																																																	
9	01101	0.90																																																																																																	
10	01111	0.95																																																																																																	
11	01110	1.00																																																																																																	
12	01010	1.05																																																																																																	
13	01011	1.10																																																																																																	
14	01001	1.10																																																																																																	
15	01000	1.15																																																																																																	
16	11000	1.20																																																																																																	
17	11001	1.20																																																																																																	
18	11011	1.20																																																																																																	
19	11010	1.20																																																																																																	
20	11110	1.20																																																																																																	
21	11111	1.20																																																																																																	
22	11101	1.20																																																																																																	
23	11100	1.20																																																																																																	
24	10100	1.20																																																																																																	
25	10101	1.20																																																																																																	
26	10111	1.20																																																																																																	
27	10110	1.20																																																																																																	
28	10010	1.20																																																																																																	
29	10011	1.20																																																																																																	
30	10001	1.20																																																																																																	
31	10000	1.20																																																																																																	
corresponding to ...	IS "Override active" (DB380x DBX1.7) IS "Feedrate override for spindle valid" (DB380x DBX2001.0)																																																																																																		
Note for the reader	Function Manual Basic Functions V1																																																																																																		

DB380x DBX4001.0 to .2	Parameter set selection A, B, C Signal(s) to drive (PLC → NCK)																																						
Edge evaluation: No	Signal(s) updated: Cyclic																																						
Signal state 1	<p>With bit combinations A, B and C, 8 different drive parameter sets can be selected.</p> <p>The following assignment applies:</p> <table border="1"> <thead> <tr> <th>Drive parameter set</th> <th>C</th> <th>B</th> <th>A</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>2</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>3</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>4</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>5</td> <td>1</td> <td>0</td> <td>0</td> </tr> <tr> <td>6</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>7</td> <td>1</td> <td>1</td> <td>0</td> </tr> <tr> <td>8</td> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table> <p>The switchable drive parameters are as follows:</p> <ul style="list-style-type: none"> · Current setpoint filters (lowpass, bandstop); for adaptation to the mechanic system · Motor speed normalization · Speed controller parameters · Speed setpoint filter · Speed monitoring data <p>As soon as the new drive parameter becomes effective, the drive signals this to the PLC using the interface signals: DB390x DBX4001.0 to 2 (active drive parameter set).</p>			Drive parameter set	C	B	A	1	0	0	0	2	0	0	1	3	0	1	0	4	0	1	1	5	1	0	0	6	1	0	1	7	1	1	0	8	1	1	1
Drive parameter set	C	B	A																																				
1	0	0	0																																				
2	0	0	1																																				
3	0	1	0																																				
4	0	1	1																																				
5	1	0	0																																				
6	1	0	1																																				
7	1	1	0																																				
8	1	1	1																																				
Application	<p>Drive parameter switchover can be used, for example, for the following:</p> <ul style="list-style-type: none"> · To change the gear stage · To change over the measuring circuit 																																						
Special cases, errors, ...	<p>In principle it is possible to switch over drive parameter sets at any time. However, as torque jumps can occur when switching over speed controller parameters and motor speed normalization, parameters should only be switched over when stationary at zero speed (especially when the axis is stationary).</p>																																						
corresponding to ...	DB390x DBX4001.0 to 2 (active parameter set)																																						
Note for the reader	Commissioning Manual, Turning and Milling																																						

6.8 Axis/spindlespecific signals

DB380x DBX4001.6	Speed controller integrator disable Signal(s) to drive (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	For the drive, the interface signal is used to disable the speed controller integrator. The speed controller is thus changed over from a PI to a P controller. Note: If the speed controller integrator disable is activated, compensation operations might take place in certain applications (e.g. if the integrator was already holding a load while stationary). The drive acknowledges the integrator disable: DB390x DBX4001.6 (speed controller integrator disabled)
Signal state 0	The integrator of the speed controller is enabled.
corresponding to ...	DB390x DBX4001.6 (integrator n-controller disabled)
Note for the reader	Commissioning Manual, Turning and Milling

DB380x DBX4001.7	Pulse enable. Signal(s) to drive (PLC → NCK)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Pulse enable is signaled by the PLC for this drive (axis/spindle). The pulses are only enabled if the drive signals IS: DB390x DBX4001.5 (drive ready) using a 1 signal. In this case, the interface signal: DB390x DBX4001.7 (pulses enabled) is signaled to the PLC with a 1 signal.
Signal state 0	The pulses are disabled by the PLC for this drive.
Application	Signal-oriented signal.
Special cases, errors, ...	If pulse enable is withdrawn for a moving axis/spindle the axis/spindle is not longer braked in a controlled fashion. The axis/spindle coasts down.
corresponding to ...	DB390x DBX4001.7 (pulses enabled)
Note for the reader	Commissioning Manual, Turning and Milling

DB380x DBX5000.4	Torque equalization controller on Signal(s) to drive (PLC → NCK)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Torque compensation controller is to be activated. The following conditions must be fulfilled to activate it: DB3900 DBX5000.2 (master/slave fine) = 1
Signal state 0 or edge change 1 → 0	Torque compensation controller is to be deactivated.
Note for the reader	Function Manual, Special functions TE3

DB380x DBX5004.7	Master/slave on Signal(s) to technology functions (PLC → NCK)	
Edge evaluation: Yes	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	Master-slave coupling should be activated.	
Signal state 0 or edge change 1 → 0	Master-slave coupling should be deactivated.	
Application	<p>The following conditions must be fulfilled for activation and deactivation:</p> <ul style="list-style-type: none"> · Leading and following axes under position control (DB390x DBX1.5) · Leading and following axes are at standstill (DB390x DBX1.4) · The channel of the leading and following axes is in the reset state (DB3300 DBX3.7) <p>If a condition is not fulfilled, the coupling will not be activated or deactivated. No alarm appears and the status of the coupling remains the same.</p> <p>If, at a later point, all conditions are fulfilled, the coupling will be activated or deactivated depending on the status of the signal.</p> <p>The signal is relevant for the following axis of a coupling.</p>	
Note for the reader	Function Manual, Special functions TE3	

DB380x DBX5005.4	Start gantry synchronization Signal(s) to technology functions (PLC → NCK)	
Edge evaluation: No	Signal(s) updated:	
Signal state 1	<p>Request from PLC user program to synchronize the leading axis with the assigned synchronized axes:</p> <p>MD37100 GANTRY_AXIS_TYPE (gantry axis definition)</p> <p>(i.e. all gantry axes approach the reference position of the gantry grouping in the decoupled state).</p> <p>Synchronization of the gantry axes can be started only under the following conditions:</p> <ul style="list-style-type: none"> · The REF machine function must be active: DB1800 DBX1.2 (active machine function REF) = 1 · DB390x DBX5005.5 (gantry grouping is synchronized) = 0 · DB390x DBX5005.4 (gantry synchronization ready to start) = 1 · No axis is being referenced in the appropriate NC channel: DB3300 DBX1.0 (referencing active) = 0 	
Signal state 0	<p>The PLC user program can then reset the interface signal to signal state "0", on completion of gantry synchronization (DB390x DBX5005.5 = 1).</p> <p>If the IS is continuously kept at "1", the gantry synchronization run would be started automatically as soon as the above conditions are fulfilled.</p>	
Signal irrelevant for ...	Gantry synchronized axis	
Application	<p>If the deviation between the position actual values and the reference position is greater than the gantry warning threshold after referencing of the gantry axes, automatic gantry synchronization is not started and IS "Gantry synchronization ready to start" is set to "1".</p> <p>Synchronization of the gantry axes can be started by the user or the PLC user program with IS "Start gantry synchronization".</p>	
Application		

Note for the reader	Function Manual, Special functions TE3
---------------------	--

DB380x DBX5005.5	Lock automatic synchronization Signal(s) to technology functions (PLC → NCK)
Edge evaluation: No	Signal(s) updated:
Signal state 1	No automatic synchronization.
Signal state 0	The automatic synchronization process is active.
Application	The automatic synchronization process can be interlocked using a VDI signal at the axial PLC/NC interface of the master axis. This always makes sense when the axes are not activated by default. In this case, the synchronization process should also be started explicitly.
Note for the reader	Function Manual, Special functions TE3

6.8.3 Signals from axis/spindle

DB390x DBX0.0	Spindle/no axis Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The machine axis is operated as spindle in the following spindle modes: <ul style="list-style-type: none"> · Control mode · Oscillation mode · Positioning mode · Rigid tapping <p>The IS's to the axis (DB380x DBX1000 to DB380x DBX1003) and from the axis (DB390x DBX1000 to DB390x DBX1003) are invalid.</p> <p>The IS's to the spindle (DB380x DBX2000 to DB380x DBX2003) and from the spindle (DB380x DBX2000 to DB380x DBX2003) are valid.</p>
Signal state 0 or edge change 1 → 0	The machine axis is operated as an axis. <p>The IS's to the axis (DB380x DBX1000 to DB380x DBX1003) and from the axis (DB390x DBX1000 to DB390x DBX1003) are valid.</p> <p>The IS's to the spindle (DB380x DBX2000 to DB380x DBX2003) and from the spindle (DB380x DBX2000 to DB380x DBX2003) are invalid.</p>
Application	If a spindle is sometimes also used as a rotary axis on a machine tool (lathe with spindle/Caxis or milling machine with spindle/rotary axis for rigid tapping), then the IS "Spindle/no axis" can be used to identify as to whether the machine axis is in the axis or spindle mode.
Note for the reader	Function Manual Basic Functions S1

DB390x DBX0.2	Encoder limit frequency exceeded 1 Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The limit frequency set in MD36300 ENC_FREQ_LIMIT (encoder limit frequency) has been exceeded. The reference point for the position measuring system involved has been lost (IS: Referenced/synchronized is in signal state 0). Closed-loop position control is no longer possible. Spindles continue to operate with closed-loop speed control. Axes are stopped with a fast stop (with open-circuit position control loop) along a speed setpoint ramp.
Signal state 0	The limit frequency set in MD36300 is no longer exceeded. For the edge change 1 → 0, the encoder frequency must have fallen below the value of MD36302 ENC_FREQ_LIMIT_LOW (% value of MD 36300).
Note for the reader	Function Manual Basic Functions A3

DB390x DBX0.4	Referenced/synchronized 1 Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	Axes: When being referenced, if the machine axis has reached the reference point (incremental measuring systems) or the target point (for length measuring system with distance-coded reference marks), then the machine axis is referenced and the IS "Referenced/synchronized 1" (for position measuring system 1) is set. Spindles:After "power-on", a spindle is synchronized the latest after one spindle revolution (zero mark) or when passing the BERO.
Signal state 0 or edge change 1 → 0	The machine axis/spindle with position measuring system 1 is not referenced/synchronized.
corresponding to ...	DB380x DBX0.5 (position measuring system 1)
Note for the reader	Function Manual Basic Functions R1, S1

DB390x DBX0.5	Referenced/synchronized 2 Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation:	Signal(s) updated:
Signal state 1 or edge change 0 → 1	Axes: When being referenced, if the machine axis has reached the reference point (incremental measuring systems) or the target point (for length measuring system with distance-coded reference marks), then the machine axis is referenced and the IS "Referenced/synchronized 2" (for position measuring system 2) is set. Spindles: After "power-on", a spindle is synchronized the latest after one spindle revolution (zero mark) or when passing the BERO.
Signal state 0 or edge change 1 → 0	The machine axis/spindle with position measuring system 2 is not referenced/synchronized.
corresponding to ...	DB380x DBX0.6 (position measuring system 2) MD34102 REFP_SYNC_ENCS (measuring system calibration) = 0
Note for the reader	Function Manual Basic Functions R1, S1

6.8 Axis/spindlespecific signals

DB390x DBX0.6	Position reached with exact stop coarse Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The axis is in the appropriate exact stop and no interpolator is active for the axis and <ul style="list-style-type: none"> · the control is in the reset state (reset key or end of program). · the axis was last programmed as a positioning spindle. · the path motion was terminated with NC stop. · the spindle is in positioncontrolled mode and is stationary. · the axis is switched from closed-loop speedcontrolled to closed-loop positioncontrolled mode with IS "position measuring system".
Signal state 0	The axis is not in the appropriate exact stop or the interpolator is active for the axis or <ul style="list-style-type: none"> · the path motion was terminated with NC stop. · the spindle is in the speedcontrolled mode. · the "parking" mode is active for the axis. · the axis is switched-over from the positioncontrolled to the speedcontrolled mode with using the IS "Position measuring system".
corresponding to ...	MD36000 STOP_LIMIT_COARSE (exact stop coarse)
Note for the reader	Function Manual Basic Functions B1

DB390x DBX0.7	Position reached with exact stop fine Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	See IS "Position reached with exact stop coarse".
Signal state 0	See IS "Position reached with exact stop coarse"
corresponding to ...	MD36010 STOP_LIMIT_FINE (exact stop fine)
Note for the reader	Function Manual Basic Functions B1

DB390x DBX1.1	AxAlarm Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The NCK brakes the axis/spindle along a ramp and confirms the braking operation via the OPI. At the same time, the PLC alarm is signaled with IS DB390x DBX1.1 ("Axial alarm") == 1 and the status of system variable \$AA_SNGLAX_STAT == 5.

DB390x DBX1.2	Axis ready Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated:
Meaning	The signal is fed to the PPU, to which the axis is physically connected.
Signal state 1	Axis is ready.
Signal state 0	Axis is not ready. This status is set if the channel, the mode group or the NCK have generated the alarm "Not ready".

DB390x DBX1.3	Follow up mode active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The control signals that the followup mode for the axis/spindle is active. Prerequisites for this are: <ul style="list-style-type: none"> · The controller enable for the drive has been withdrawn (either by the PLC with "controller enable" = 0 signal or inside the control for faults). · Follow-up operation is selected (either by the PLC with IS "follow-up operation" = 1 signal or in the control, e.g. when withdrawing the controller enable from an axis that is moving) The position setpoint continually tracks the actual value while the follow-up mode is active. The standstill and clamping monitoring are not active.
Signal state 0	The control signals that followup mode for the axis/spindle is not active, i.e. the above mentioned prerequisites are not fulfilled. Zero speed and clamping monitoring are active. In the "Hold" state, the IS "Follow-up mode active" has a 0 signal.
Special cases, errors, ...	Notice: A delete distancetogo is triggered internally in the control at the transition from "Follow up" to "Hold" (IS "Followup mode" = 0) or in the closed-loop control mode (IS "Controller enable" = 1).
corresponding to ...	DB380x DBX2.1 (controller enable) DB380x DBX1.4 (controller enable!)
Note for the reader	Function Manual, Special Functions; M3/T3

DB390x DBX1.4	Axis/spindle stationary ($n < n_{\min}$) Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The actual velocity of the axis or the actual speed of the spindle lies under the limit defined using the MD36060.
Signal state 0	The actual velocity of the axis or the actual spindle speed is greater than the value specified in MD36060 (standstill/zero speed range). If a travel command is present, e.g. for a spindle, then the signal is always = 0 - even if the actual speed lies below that specified in MD36060. If the IS "Axis/spindle stationary" is signaled and there is no closed-loop position control active for the spindle, then at the operator interface, an actual speed of zero is displayed and with the system variable \$AA_S[n] zero is read.

6.8 Axis/spindlespecific signals

Application	<ul style="list-style-type: none"> · Enable signal for opening a protective device (e.g. "Open door"). · The workpiece chuck or the tool clamping device is only opened when the spindle is stationary. · The oscillation mode can be switched-in during gear stage change after the spindle has been braked down to standstill. · The tool clamping device must have been closed before the spindle can be accelerated.
corresponding to ...	MD36060 STANDSTILL_VELO_TOL (maximum velocity/speed for signal "Axis/spindle stationary")
Note for the reader	Function Manual Basic Functions S1

DB390x DBX1.5	Position controller active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The control signals that the position controller is closed.
Signal state 0	The control signals that the position controller is open. If "controller enable" is withdrawn because of a fault or from the PLC user program the position controller is opened and therefore the interface signal "Position controller active" is set to a 0 signal. Spindle without position control: Signal "Position controller active" is always "0".
Application	<ul style="list-style-type: none"> · The IS "Position controller active" can be used as feedback signal for the IS "Controller enable". · The holding brake of a vertical axis must be activated as soon as the position control is no longer active. · If a spindle has been technically designed/dimensioned for the purpose, in the part program, it can be changed-over into the closed-loop position controlled mode as spindle or as axis (with SPCON or M70). In these cases, the interface signal "position controller active" is set.
Special cases, errors, ...	The IS "Position controller active" is also set for simulation axes as soon as MD30350 = 1.
corresponding to ...	DB380x DBX2.1 (controller enable) DB380x DBX1.5 (position measuring system 1) MD30350 SIMU_AX_VDI_OUTPUT (output of axis signals for simulation axes)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX1.6	Speed controller active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The control signals that the speed controller is closed.
Signal state 0	The control signals that the speed controller is open. The speed controller output is cleared.
Application	For spindles without closed-loop position control, the interface signal can be used as feedback for the IS "Controller enable".
Special cases, errors, ...	The IS "Speed controller active" is also set for simulation axes, as soon as MD30350 = 1.

corresponding to ...	DB380x DBX2.1 (controller enable) DB390x DBX1.5 (position controller active) MD30350 SIMU_AX_VDI_OUTPUT (output of axis signals for simulation axes)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX1.7	Current controller active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The control signals that the current controller is closed.
Signal state 0	The control signals that the current controller is open. The current controller output (including the feedforward quantities on the manipulated variable for the voltage) is cleared.
corresponding to ...	DB390x DBX1.5 (position controller active) DB390x DBX1.6 (speed controller active)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2.1	Handwheel override active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The function "Handwheel override in Automatic mode" is active for the programmed positioning axis (FDA[AXi]). Handwheel pulses for this axis affect the programmed axis feedrate either as path definition (FDA=0) or as velocity override (FDA > 0).
Signal state 0	The function "Handwheel override in Automatic mode" is not active for the programmed positioning axis (or concurrent positioning axis). An active handwheel override is not active if: <ul style="list-style-type: none"> · The positioning axis has reached the target position. · The distance-to-go is deleted by the axis-specific interface signal DB3200 DBX6.2 (delete distance to go). · A RESET is performed.
Note for the reader	Function Manual, Expansion Functions H1

6.8 Axis/spindlespecific signals

DB390x DBX2.2	Revolutional feedrate active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When programming G95 (revolutional feedrate) in the JOG mode or automatic mode.
corresponding to ...	SD41100 JOG_REV_IS_ACTIVE (revolutional feedrate for JOG active) SD42600 JOG_FEED_PER_REV_SOURCE (In the JOG mode revolutional feedrate for geometry axes, on which the frame with rotation acts) SD43300 ASSIGN_FEED_PER_REV_SOURCE (Revolutional feedrate for position axes/spindles) MD32040 JOG_REV_VELO_RAPID (Revolutional feedrate for JOG with rapid traverse override) MD32050 JOG_REV_VELO (revolutional feedrate for JOG)
Note for the reader	Function Manual, Expansion Functions P2 Function Manual, Special Functions M3

DB390x DBX2.3	Measurement active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The "Measuring" function is active. The instantaneous measurement status of the axis is displayed (measuring set with this axis is running).
Signal state 0	The "Measuring" function is not active.
Note for the reader	Function Manual, Expansion Functions M5

DB390x DBX2.4	Activate travel to fixed endstop Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The "Travel to fixed stop" function is active.
Signal state 0	The "Travel to fixed stop" function is not active.
Note for the reader	Function Manual Basic Functions F1

DB390x DBX2.5	Fixed stop reached Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The fixed stop was reached after selecting the "FXS" function.
Signal state 0	The fixed stop has still not been reached after selecting the "FXS" function.
Note for the reader	Function Manual Basic Functions F1

DB390x DBX4.0 to .1	Handwheel active (1 to 2) Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	These PLC interface signals provide feedback as to whether this machine axis is assigned to handwheel 1 or 2 or is not assigned to any handwheel. Only one handwheel can be assigned to an axis at any one time. If several interface signals "activate handwheel" are set, then 'Handwheel 1' has a higher priority than 'Handwheel 2'. If the assignment is active, then the machine axis can be traversed using the handwheel in the JOG mode.
Signal state 0	This machine axis is neither assigned to handwheel 1 nor 2.
corresponding to ...	DB380x DBX4.0 to .1 (activate handwheel) DB1900 DBX?, ff (handwheel selected)
Note for the reader	Function Manual Basic Functions H1

DB390x DBX4.5 and.4	Plus and minus travel request Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Travel is to be executed in the axis direction involved. Depending on the mode selected, the travel command is triggered in different ways: <ul style="list-style-type: none"> · JOG mode: Using the plus or minus traversing key · REF mode: With traversing key that takes the axis to the reference point. · AUTO/MDI mode: A program block containing a coordinate value for the axis in question is executed.
Signal state 0	A travel command in the relevant axis direction has not been given or a traverse movement has been completed. <ul style="list-style-type: none"> · JOG mode: The travel command is reset depending on the setting "Jog or continuous mode". · REF mode: When the reference point is reached. · AUTO/MDI mode: <ul style="list-style-type: none"> - The program block has been executed (and the next block does not contain any coordinate values for the axis in question). - Cancel using "RESET", etc. - IS "Axis/spindle disable" is active
Application	To release clamped axes (e.g. on a rotary table). Note: If the clamping is not released until the travel command is given, these axes cannot be operated under continuous path control!
corresponding to ...	DB380x DBX1.3 (axes/spindle disable) DB380x DBX4.7 and .6 (plus and minus traversing key) DB390x DBX4.7 and .6 (plus and minus travel command)
Note for the reader	Function Manual Basic Functions H1

6.8 Axis/spindlespecific signals

DB390x DBX4.7 and .6	Plus and minus travel command Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Travel is to be executed in the axis direction involved. Depending on the mode selected, the travel command is triggered in different ways. <ul style="list-style-type: none"> · JOG mode: With the plus or minus traversing key · Under REF mode: With traversing key that takes the axis to the reference point · AUTO/MDI mode: A program block containing a coordinate value for the axis in question is executed.
Signal state 0	A travel command in the relevant axis direction has not been given or a traverse movement has been completed. <ul style="list-style-type: none"> · JOG mode: <ul style="list-style-type: none"> - Withdrawing the traversing key. - When ending traversing with the handwheel. - Under REF mode: When the reference point is reached · AUTO/MDI mode: <ul style="list-style-type: none"> - The program block has been executed (and the next block does not contain any coordinate values for the axis in question) - Cancel using "RESET", etc. - IS "Axis disable" is active
Application	To release clamped axes (e.g. on a rotary table). Note: If the clamping is not released until the travel command is given, these axes cannot be operated under continuous path control!
corresponding to ...	IS "Traversing key plus" and "Traversing key minus" (DB380x DBX4.7 and .6)
Note for the reader	Function Manual Basic Functions H1

DB390x DBX5.0 to .6	Active machine function 1 INC, ..., continuous Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC interface receives a signal stating which JOG mode machine function is active for the machine axes.
Signal state 0	The machine function in question is not active.
corresponding to ...	IS "Machine function 1 INC, ..., continuous" (DB380x DBX5.06)
Note for the reader	Function Manual Basic Functions H1

DB390x DBB8	Axis/spindle exchange	
Edge evaluation: Yes	Signal(s) updated: Cyclic	
Signal state 1 or edge change 0 → 1	The actual axis type for this axis is displayed.	
	Bit 0:	NC axis/spindle
	Bit 1:	
	Bit 2:	
	Bit 3:	
	Bit 4:	New type requested from PLC
	Bit 5:	Axis exchange possible
	Bit 6:	Neutral axis/spindle
	Bit 7:	PLC axis/spindle
Signal state 0 or edge change 1 → 0		
corresponding to ...	IS Axis/spindle exchange MD20070 AXCONF_ASSIGN_MASTER_USED (Machine axis number valid in channel) MD30550 AXCONF_ASSIGN_MASTER_CHAN (initial setting of channel for axis exchange)	
Special cases, errors, ...		

DB390x DBX1002.0	Lubrication pulse	
	Signal(s) from axis/spindle (NCK → PLC)	
Edge evaluation: Yes	Signal(s) updated: Cyclic	
Edge change 0 → 1 or 1 → 0	As soon as the axis/spindle has traveled through the distance set in MD33050, the "lubrication pulse" interface signal is inverted and lubrication is started. The position measurement is restarted after each Power On.	
Application	The lubrication pump for the axis/spindle can be activated with IS "Lubrication pulse". Machine bed lubrication therefore depends on the distance traveled.	
corresponding to ...	MD33050 LUBRICATION_DIST (lubrication pulse distance)	
Note for the reader	Function Manual Basic Functions A2	

DB390x DBX1002.4	Path axis	
	Signal(s) from axis/spindle (NCK → PLC)	
Edge evaluation: No	Signal(s) updated: Cyclic	
Signal state 1	The axis is involved in the path (path axis).	
Signal state 0	The axis is not involved in the path.	
Note for the reader	Function Manuals	

6.8 Axis/spindlespecific signals

DB390x DBX1002.5	Positioning axis Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The NCK handles the axis as positioning axis. This means that it has: <ul style="list-style-type: none"> · its own axis interpolator (linear interpolator) · its own feedrate (F value) · its own feedrate override · exact stop (G09) at the progr. end position
Signal state 0	The axis is not a positioning axis.
Note for the reader	Function Manual, Expansion Functions P2

DB390x DBX1002.6	Indexing axis in position Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The signal is dependent on "Exact stop fine": The signal is set if "Exact stop fine" is reached. The signal is reset when exiting "Exact stop fine". <ul style="list-style-type: none"> · The indexing axis is located on an indexing position. · The indexing axis has been positioned with instructions for "Coded Position".
Signal state 0	The axis is not defined as an indexing axis. <ul style="list-style-type: none"> · The indexing axis travels: DB390x DBX4.7/6 (travel command +/-) is present. · The indexing axis is located at a position which is not an indexing position, e.g.: <ul style="list-style-type: none"> - For JOG after termination of travel movement, e.g. with RESET - in the Automatic mode: the indexing axis has, for example, approached a selected position controlled by an AC or DC instruction · The indexing axis has not been positioned with instructions for "coded position" (CAC, CACP, CACN, CDC, CIC) in the automatic mode. · The "Controller enable" signal for the indexing axis has been withdrawn: DB380x DBX2.1 (controller enable)
Application	Tool magazine: Activation of the gripper to remove the tool from the magazine is initiated as soon as the indexing axis is in position. The PLC user program must ensure this happens.
Special cases, errors, ...	<ul style="list-style-type: none"> · The axis positions entered in the indexing position table for the individual divisions can be changed using work offsets (including DRF). · If a DRF is applied to an indexing axis in AUTOMATIC mode, then interface signal "Indexing axis in position" remains active even though the axis is no longer at an indexing position.
corresponding to ...	MD30500 INDEX_AX_ASSIGN_POS_TAB (axis is an indexing axis)
Note for the reader	Function Manual, Expansion Functions T1

DB390x DBX2000.0 to .2	Setpoint gear stage A to C Signal(s) from axis/spindle (NCK → PLC)																
Edge evaluation: Yes	Signal(s) updated: Cyclic																
Signal state 1 or edge change 0 → 1	<p>A gear stage can be defined as follows:</p> <ul style="list-style-type: none"> · Permanently by the part program (M41 to M45) · Automatically by the programmed spindle speed (M40) <p>M41 to M45:</p> <ul style="list-style-type: none"> · The gear stage can be permanently defined in the part program with M41 to M45. If a gear stage is specified using M41 to M45, which is not equal to the actual (actual) gear stage, then the IS "Change gear stage" and the IS "Setpoint gear stage" A" to "...C" are set. <p>M40:</p> <ul style="list-style-type: none"> · The control automatically defines the gear stage with M40 in the part program. The control checks which gear stage is possible for the programmed spindle speed (S function). If a gear stage is selected that is not the same as the actual (actual) gear stage, then the IS "Change gear stage" and the IS "Setpoint gear stage" A" to "...C" are set. <p>The setpoint gear stage is output in coded format:</p> <table style="margin-left: 20px;"> <tr> <td>1. Gear stage</td> <td>0 0 0 (C B A)</td> </tr> <tr> <td>1st gear stage</td> <td>0 0 1</td> </tr> <tr> <td>2nd gear stage</td> <td>0 1 0</td> </tr> <tr> <td>3rd gear stage</td> <td>0 1 1</td> </tr> <tr> <td>4th gear stage</td> <td>1 0 0</td> </tr> <tr> <td>5th gear stage</td> <td>1 0 1</td> </tr> <tr> <td>invalid value</td> <td>1 1 0</td> </tr> <tr> <td>invalid value</td> <td>1 1 1</td> </tr> </table>	1. Gear stage	0 0 0 (C B A)	1st gear stage	0 0 1	2nd gear stage	0 1 0	3rd gear stage	0 1 1	4th gear stage	1 0 0	5th gear stage	1 0 1	invalid value	1 1 0	invalid value	1 1 1
1. Gear stage	0 0 0 (C B A)																
1st gear stage	0 0 1																
2nd gear stage	0 1 0																
3rd gear stage	0 1 1																
4th gear stage	1 0 0																
5th gear stage	1 0 1																
invalid value	1 1 0																
invalid value	1 1 1																
Signal irrelevant for ...	Other spindle modes except oscillation mode																
corresponding to ...	IS "Change gear stage" (DB390x DBX2000.3) IS "Actual gear stage A" to "...C" (DB380x DBX2000.0 to .2) IS "Gear stage is changed over" (DB380x DBX2000.3)																
Note for the reader	Function Manual Basic Functions S1																

DB390x DBX2000.3	Change gear stage Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	<p>A gear stage can be defined as follows:</p> <ul style="list-style-type: none"> · Permanently by the part program (M41 to M45) · Automatically by the programmed spindle speed (M40) <p>M41 to M45:</p> <ul style="list-style-type: none"> · The gear stage can be permanently defined in the part program with M41 to M45. If a gear stage is specified using M41 to M45, which is not equal to the actual (actual) gear stage, then the IS "Change gear stage" and the IS "Setpoint gear stage" A" to ...C" are set. <p>M40:</p> <ul style="list-style-type: none"> · The control automatically defines the gear stage with M40 in the part program. The control checks which gear stage is possible for the programmed spindle speed (S function). If a gear stage is selected that is not the same as the actual (actual) gear stage, then the IS "Change gear stage" and the IS "Setpoint gear stage" A" to ...C" are set. · While the signal = 1, the text "Wait for gear stage change" is displayed in the channel operating message".
Special cases, errors, ...	The IS "Change gear stage" is only set if a new gear stage is defined that is not the same as the actual gear stage.
corresponding to ...	IS "Setpoint gear stage A" to "...C" (DB390x DBX2000.0 to .2) IS "Actual gear stage A" to "...C" (DB380x DBX2000.0 to .2) IS "Gear stage has been changed over" (DB380x DBX2000.3)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2001.0	Speed limit exceeded Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If the actual speed exceeds the max. spindle speed MD35100, by more than the spindle speed tolerance MD35150, the IS "Speed limit exceeded" is set and alarm 22050 "Maximum speed reached" is output. All axes and spindles of the channel are braked.
corresponding to ...	MD35150 SPIND_DES_VELO_TOL (spindle speed tolerance) MD35100 SPIND_VELO_LIMIT (maximum spindle speed) Alarm 22050 "maximum speed reached"
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2001.1	Set speed limited (programmed speed too high) Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If a spindle speed (rpm) or a constant cutting speed (m/min or ft/min) is programmed, one of the following limits has been exceeded : <ul style="list-style-type: none"> · Maximum speed of specified gear stage · Maximum spindle speed · Speed limiting by the interface signal from the PLC · Progr. spindle speed limiting G26 · Progr. spindle speed limiting for G96 The spindle speed is limited to the maximum value.
Signal state 0 or edge change 1 → 0	If a spindle speed (rpm) or a constant cutting speed (m/min or ft/min) is programmed, no limit values were exceeded.
Application	The IS "Setpoint speed limited" can be used to determine if the programmed speed cannot be reached. The PLC user program can identify this state as not permissible and disable path feed, or it can disable the path feed or the complete channel. For IS "Spindle in setpoint range" processing is executed.
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2001.2	Setpoint speed increased (programmed speed too low) Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If a spindle speed (rpm) or a constant cutting speed (m/min or ft/min) is programmed, one of the following limits was fallen below : <ul style="list-style-type: none"> · Minimum speed of the specified gear stage · Minimum spindle speed · Speed limiting by the PLC · Progr. spindle speed limiting G25 · Progr. spindle speed limiting with G96 The spindle speed is limited to the minimum limit value.
Signal state 0 or edge change 1 → 0	If a spindle speed (rpm) or a constant cutting speed (m/min or ft/min) is programmed, no limit values were fallen below.
Application	The IS "Setpoint speed increased" can be used to detect that the programmed speed cannot be reached. The PLC user program can identify this state as not permissible and disable path feed, or it can disable the path feed or the complete channel. For IS "Spindle in setpoint range" processing is executed.
Note for the reader	Function Manual Basic Functions S1

6.8 Axis/spindlespecific signals

DB390x DBX2001.3	Geometry monitoring Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: -
Signal state 1	Error in grinding wheel geometry. There is no further response when this monitoring function responds. Reactions deemed necessary must be programmed by the PLC user.
Signal state 0	No error in grinding wheel geometry.
Application	Grinding-specific tool monitoring.
Note for the reader	Function Manual, Expansion Functions W4

DB390x DBX2001.5	Spindle in setpoint range Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The IS "Spindle in setpoint range" is used to signal whether the programmed - and if relevant - limited spindle speed is reached. In the spindle control mode, the speed setpoint (programmed speed + spindle override including limits) is compared with the actual speed. If the actual speed deviates from the setpoint speed by less than the spindle speed tolerance MD35150, then the IS "Spindle in the setpoint range" is set.
Signal state 0 or edge change 1 → 0	The IS "Spindle in setpoint range" signals whether the spindle is accelerating or braking. In the spindle control mode, the speed setpoint (programmed speed + spindle override including limits) is compared with the actual speed. If the actual speed deviates from the setpoint speed by more than the spindle speed tolerance MD35150, then the IS "Spindle in the setpoint range" is reset.
Signal irrelevant for ...	all spindle modes except for speed mode (control mode).
Application	The path feed must generally be disabled when the spindle is in the acceleration phase (programmed speed setpoint not yet reached). This can be done in the following way: <ul style="list-style-type: none"> · The IS "Spindle in the setpoint range" is evaluated and the IS "Feedrate disable" (DB3200 DBX6.0) is set. · MD35500 is set and the NCK evaluates internally as to whether the spindle is in the setpoint range. The path feed is only enabled if the spindle is within the setpoint range. Positioning axes are never stopped by this function.
corresponding to ...	MD35150 SPIND_DES_VELO_TOL (spindle speed tolerance) MD35500 SPIND_ON_SPEED_AT_IPO_START (feedrate enable with spindle in the setpoint range)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2001.6	Speed monitoring Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: -
Signal state 1	Error in grinding wheel speed. There is no further response when this monitoring function responds. Reactions deemed necessary must be programmed by the PLC user.
Signal state 0	No error in grinding wheel speed.
Application	Grinding-specific tool monitoring.
Note for the reader	Function Manual, Expansion Functions W4

DB390x DBX2001.7	Actual direction of rotation clockwise Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	If the spindle is rotating, the CLOCKWISE direction of rotation is signaled using IS "Actual direction or rotation, clockwise" = 1. The actual direction of rotation is derived from the spindle position measuring encoder.
Signal state 0 or edge change 1 → 0	If the spindle is rotating, then the COUNTER-CLOCKWISE direction of rotation is signaled using IS "Actual direction or rotation, clockwise" = 0.
Signal irrelevant for ...	<ul style="list-style-type: none"> · Spindle stationary, IS "Axis/spindle stationary" = 1 (at standstill it is not possible to evaluate a direction of rotation) · Spindles without position measuring encoder
corresponding to ...	IS "Spindle stationary" (DB390x DBX1.4)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2002.0	Constant cutting velocity active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	When programming G96 S... the constant cutting velocity function is executed. The S word is now valid as cutting value.
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2002.1	GWPS active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: -
Signal state 1	Constant grinding wheel peripheral speed (GWPS) is active. If GWPS is active, then all S value inputs from the PLC are interpreted as the grinding wheel peripheral speed.
Signal state 0	Constant grinding wheel peripheral speed (GWPS) is not active.
Application	GWPS in all modes
Note for the reader	Function Manual, Expansion Functions W4

6.8 Axis/spindlespecific signals

DB390x DBX2002.3	Rigid tapping active Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The spindle runs in the function rigid tapping (thread interpolation G331/G332). For rigid thread tapping, the spindle speed is also programmed under S... in rpm, however, the direction of rotation is stored as sign under the thread pitch. There is no response or update of any spindle-specific interface signals such as: IS "Spindle reset" IS "Synchronize spindle" IS "Invert M3/M4" IS "Spindle in the setpoint range" IS "Programmed speed too high"
Application	Certain functions should not be used during rigid tapping, such as: · Reset IS "Controller enable" (DB380x DBX2.1) · IS "Set feedrate stop" (DB380x DBX4.3) · Reset · When pressing EMERGENCY OFF while rigid tapping, then it should be taken into consideration that the tool and workpiece are form locked with one another.
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2002.4	active spindle mode synchronous mode Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The spindle is in the "Synchronous mode" spindle mode. As a consequence, the following spindle follows the movements of the leading spindle corresponding to the ratio. In synchronous operation, the monitoring functions are active for synchronous operation coarse and fine. Note: The signal is set only for the machine axis which is active as following spindle (IS "FS active" = 1)
Signal state 0	The spindle is not operated as following spindle in "synchronous mode". When switching off the coupling (deselecting synchronous mode) then the following spindle is switched into the "control mode".
corresponding to ...	IS "Synchronous operation fine" IS "Synchronous operation coarse" IS "FS active"

DB390x DBX2002.5	Active spindle positioning mode Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	When programming SPOS=... the spindle is in positioning mode.
corresponding to ...	IS "Active spindle control mode" (DB390x DBX2002.7) IS "Active spindle mode, oscillating mode" (DB390x DBX2002.6)

Note for the reader	Function Manual Basic Functions S1
---------------------	------------------------------------

DB390x DBX2002.6	Active spindle mode oscillation mode Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	The spindle is in the oscillation mode if a new gear stage was defined using the automatic gear stage selection (M40) or using M41 to M45 (IS "Change gear stage" is set). The IS "Change gear stage" is only set if a new gear stage is defined that is not the same as the actual gear stage.
corresponding to ...	IS "Active spindle control mode" (DB390x DBX2002.7) IS "Active spindle positioning mode" (DB390x DBX2002.5) IS "Change gear stage" (DB390x DBX2000.3)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2002.7	Active spindle control mode Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	With the following function, the spindle is in the control mode: Spindle direction of rotation input M3/M4 or spindle stop M5
corresponding to ...	IS "Active spindle oscillating mode" (DB390x DBX2002.6) IS "Active spindle positioning mode" (DB390x DBX2002.5)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX2003.5	Spindle in position Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: Cyclic
Signal state 1 or edge change 0 → 1	Precondition for the output of IS "Spindle in position" is reaching the IS "Exact stop fine". Additionally, the last programmed spindle position must have been reached on the setpoint side. If the spindle is already at the programmed position after a positioning, then the signal "Spindle in position" is set.
Signal state 0 or edge change 1 → 0	The IS "Spindle in position" is always reset when withdrawing IS "Exact stop fine".
Application	The interface signal is processed exclusively with the function spindle positioning. This includes: <ul style="list-style-type: none"> · SPOS, SPOSA and M19 in the part program · SPOS and M19 in synchronized actions Spindle in position for the tool change. If the tool change cycle is interrupted by the machine operator e.g. with NC stop, NC stop axis plus spindle, mode stop etc., then the correct position to which the spindle is to travel in the tool changer can be queried using the IS "Spindle in position".
Special cases, errors, ...	If the spindle is traversed after a positioning for already set "Spindle in position" signal, e.g. in the JOG mode, then this signal is deleted. If the spindle returns to its original position in the JOG mode, then the signal "Spindle in position" is set again. The last position selection is maintained.
corresponding to ...	DB390x DBX0.7 (exact stop fine)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX4001.0 to .2	Active parameter set A, B, C Signal(s) to drive (NCK → PLC)																																				
Edge evaluation: No	Signal(s) updated: Cyclic																																				
Meaning	<p>The drive signals back to the PLC which drive parameter set is presently active.</p> <p>With bit combinations A, B and C, 8 different drive parameter sets can be selected.</p> <p>The following assignment applies:</p> <table border="1"> <thead> <tr> <th>Drive parameter set</th> <th>C</th> <th>B</th> <th>A</th> </tr> </thead> <tbody> <tr><td>1</td><td>0</td><td>0</td><td>0</td></tr> <tr><td>2</td><td>0</td><td>0</td><td>1</td></tr> <tr><td>3</td><td>0</td><td>1</td><td>0</td></tr> <tr><td>4</td><td>0</td><td>1</td><td>1</td></tr> <tr><td>5</td><td>1</td><td>0</td><td>0</td></tr> <tr><td>6</td><td>1</td><td>0</td><td>1</td></tr> <tr><td>7</td><td>1</td><td>1</td><td>0</td></tr> <tr><td>8</td><td>1</td><td>1</td><td>1</td></tr> </tbody> </table>	Drive parameter set	C	B	A	1	0	0	0	2	0	0	1	3	0	1	0	4	0	1	1	5	1	0	0	6	1	0	1	7	1	1	0	8	1	1	1
Drive parameter set	C	B	A																																		
1	0	0	0																																		
2	0	0	1																																		
3	0	1	0																																		
4	0	1	1																																		
5	1	0	0																																		
6	1	0	1																																		
7	1	1	0																																		
8	1	1	1																																		
Application	<p>Drive parameter switchover can be used, for example, for the following:</p> <ul style="list-style-type: none"> · To change the gear stage · To change over the measuring circuit 																																				
corresponding to ...	DB380x DBX4001.0 to 2 (parameter set selection)																																				
Note for the reader	Commissioning Manual, Turning and Milling																																				

DB390x DBX4001.5	Drive ready Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Feedback signal from the drive to the PLC that the drive is ready.
Signal state 0	<p>The drive is not ready.</p> <p>The drive might be disabled for the following reasons:</p> <ul style="list-style-type: none"> · Drive alarm active (e.g. motor temperature has reached switchoff threshold). · DC link voltage is too low. · Drive has not yet reached the cyclic state. · Hardware fault present. · No position measuring system is active ("parking axis" state). · I/R is not switched on. <p>As soon as the drive is not ready, it is stopped (depending on the fault state either with pulse disable or fast stop) or pulses remain disabled while powering up.</p> <p>The interface signals: DB2700 DBX2.6 (drive ready) DB390x DBX1.7 (current controller active) DB390x DBX1.6 (speed controller active) are also withdrawn.</p>

Note for the reader	Commissioning Manual, Turning and Milling
---------------------	---

DB390x DBX4001.6	Speed controller integrator disable Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The request from the PLC to disable the integrator of the speed controller using the interface signal "Speed controller integrator disable" is active for the drive. The speed controller has therefore switched from a PI to a P controller.
Signal state 0	The integrator of the speed controller is enabled. The speed controller functions as a PI controller.
corresponding to ...	DB380x DBX4001.6 (speed controller integrator disable)
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4001.7	Pulses enabled Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The pulse enable for the drive is present. The axis/spindle can now be traversed.
Signal state 0	The drive pulses are disabled. Therefore, the axis/spindle cannot be traversed. The pulses are disabled as soon as there is no enable signal. Also, if the "controller enable of drive" is withdrawn, the drive is stopped with setpoint 0 (regenerative braking). Pulse disable is also triggered if there is no position measuring system ("parking axis" state). As soon as the pulses are disabled, then the following IS are also reset: DB390x DBX1.7 (current controller active) DB390x DBX1.6 (speed controller active)
Application	Signal-oriented signal.
Special cases, errors, ...	If pulse enable is withdrawn for a moving axis/spindle the axis/spindle is not longer braked in a controlled fashion. The axis/spindle coasts down.
corresponding to ...	DB380x DBX4001.7 (pulse enable)
Note for the reader	Commissioning Manual, Turning and Milling

6.8 Axis/spindlespecific signals

DB390x DBX4002.2	Ramp-up completed Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC is signaled that after a new speed setpoint input, the speed actual value has reached the speed tolerance bandwidth and has remained within this tolerance bandwidth for the specified time. Even if the speed actual value leaves the tolerance bandwidth (because of speed fluctuations resulting from load changes) the "rampup completed" signal remains.
Signal state 0	The conditions described above have not yet been fulfilled. Rampup has therefore not yet been completed.
corresponding to ...	DB390x DBX4002.6 ($n_{act} = n_{set}$) DB390x DBX4002.3 ($M_d = M_{dx}$)
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4002.2	Ramp-up completed Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC is signaled that after a new speed setpoint input, the speed actual value has reached the speed tolerance bandwidth and has remained within this tolerance bandwidth for the specified time. Even if the speed actual value leaves the tolerance bandwidth (because of speed fluctuations resulting from load changes) the "rampup completed" signal remains.
Signal state 0	The conditions described above have not yet been fulfilled. Rampup has therefore not yet been completed.
corresponding to ...	DB390x DBX4002.6 ($n_{act} = n_{set}$) DB390x DBX4002.3 ($M_d < M_{dx}$)
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4002.3	$M_d < M_{dx}$ Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The drive signals to the PLC that the torque setpoint M_d does not exceed the threshold torque M_{dx} in the steady-state condition (i.e. ramp-up completed). The torque threshold characteristic is speeddependent. While ramping-up, the IS " $M_d < M_{dx}$ " remains at 1. The signal only becomes active after ramp-up has been completed (DB390x DBX4002.2 = 1) and the signal interlock time for the threshold torque has expired.
Signal state 0	The torque setpoint M_d is greater than the threshold torque M_{dx} . If necessary, the PLC user program can initiate a response.
corresponding to ...	DB390x DBX4002.2 (ramp-up completed)
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4002.4	$n_{act} < n_{min}$ Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The drive signals to the PLC that the actual speed value n_{act} is less than the minimum speed (n_{min}).
Signal state 0	The speed actual value is higher than the minimum speed.
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4002.5	$n_{act} < n_x$ Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The drive signals to the PLC that the speed actual value n_{act} is less than the threshold speed (n_x).
Signal state 0	The speed actual value is higher than the threshold speed.
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4002.6	$n_{act} = n_{set}$ Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The PLC is signaled that after a new speed setpoint input, the speed actual value has reached the speed tolerance bandwidth and has remained within this tolerance bandwidth for the specified time. If the actual speed value then leaves the tolerance band, then contrary to the "Ramp-up completed" signal, the interface signal " $n_{act} = n_{set}$ " is set to 0.
Signal state 0	The conditions described above have not yet been fulfilled. The speed actual value is outside the speed tolerance bandwidth.
corresponding to ...	DB390x DBX4002.2 (ramp-up completed)
Note for the reader	Commissioning Manual, Turning and Milling

6.8 Axis/spindlespecific signals

DB390x DBX4002.7	Variable signaling function Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>The drive signals to the PLC that the threshold value of the quantity to be monitored has been exceeded. Using the variable signaling function, it is possible to monitor for any axis any quantity from the drive, which can be parameterized, to check if it violates a certain threshold, which can then be signaled as interface signal to the PLC.</p> <p>Monitoring: The parameterized variable is monitored to check whether it exceeds a defined threshold. In addition, a tolerance band (hysteresis) can be defined which is considered when scanning for violation of the threshold value. Further, the "threshold value exceeded" signal can be logically combined with a pull-in and drop-out delay time.</p> <p>Selection: The quantity to be monitored can be selected by entering a signal number or by entering a symbolic address.</p>
Signal state 0	<p>The drive signals the PLC that the threshold value of the quantity to be monitored has not been exceeded or the specified conditions are not fulfilled.</p> <p>If the variable signaling function is disabled the signal state "0" is output to the PLC.</p>
Application	<p>With the variable signaling function the machine tool manufacturer can monitor one additional threshold value for specific applications for each axis/spindle and evaluate the result in the PLC user program.</p> <p>Example: The interface signal "Variable signaling function" should be set to 1 when the motor torque exceeds 50% of the rated torque.</p>
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX4003.0	$V_{DClink} < V_{DClinkx}$ Signal(s) to drive (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	<p>The drive signals the PLC that the DC link voltage V_{DClink} is less than the DC link undervoltage threshold $V_{DClinkx}$.</p> <p>The DC link undervoltage threshold is defined using r0296.</p> <p>The DC link undervoltage threshold should be defined to be greater than 400 V. If the DC link voltage drops below 280 V, the unit is powered-down by the hardware.</p>
Signal state 0	The DC link voltage is less than the DC link undervoltage alarm threshold.
corresponding to ...	r0296 (DC link voltage, undervoltage threshold)
Note for the reader	Commissioning Manual, Turning and Milling

DB390x DBX5002.4	Superimposed motion Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The following spindle executes an additional motion component, that is superimposed on the motion from the coupling with the leading spindle. Example for superimposed motion of the following spindle: <ul style="list-style-type: none"> · Activating the synchronous mode with a defined angular offset between the following spindle and leading spindle. · Activating the synchronous mode for rotating leading spindle. · Changing the ratio while the synchronous mode is active. · Entering a new defined angular offset when the synchronous mode is active · Traversing the following spindle with plus or minus traversing keys or handwheel in JOG when the synchronous mode is active. As soon as the following spindle executes a superimposed motion, IS "Fine synchronism" or IS "Coarse synchronism" (depending on threshold value) may be canceled immediately.
Signal state 0	The following spindle does not traverse through any additional motion component or this has been completed.
corresponding to ...	DB390x DBX2002.4 (synchronous mode)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX5002.5	Velocity alarm threshold reached Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When the velocity of the following axis in the axis grouping of the electronic gear reaches or exceeds the percentage of the velocity entered in MD37550 , which is set in MD32000, then the signal is set to 1.
Signal state 0	The velocity of the following axis in the axis grouping of the electronic gear falls below the threshold value described above.
corresponding to ...	MD37550 EG_VEL_WARNING (threshold value, velocity alarm threshold) MD32000 MAX_AX_VELO (maximum axis velocity)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX5002.6	Acceleration alarm threshold reached Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When the acceleration of the following axis in the axis grouping of the electronic gear reaches or exceeds the percentage of the acceleration entered in MD37550, which is set in MD32300, then the signal is set to 1.
Signal state 0	The acceleration of the following axis in the axis grouping of the electronic gear falls below the threshold value described above.
corresponding to ...	MD37550 EG_VEL_WARNING (threshold value, velocity alarm threshold) MD32300 MAX_AX_ACCEL (axis acceleration)
Note for the reader	Function Manual Basic Functions S1

6.8 Axis/spindlespecific signals

DB390x DBX5002.7	ESR reaction initiated Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	Status signal The VDI signal "ESR reaction is initiated" is available as feedback signal to the PLC. The signal is set, if \$AA_ESR_STAT is > 0, i.e. if: <ul style="list-style-type: none"> · Generator mode, stopping or retraction in progress. · DC link undervoltage detected. · Generator minimum speed fallen below.
Signal state 0	ESR is not active.
Application	For safety reasons, EMERGENCY STOP interrupts the interpolation and all traversing motion, and also cancels the electronic coupling by withdrawing the controller enable signals. In applications where the coupling and traversing motion must be kept after Emergency Stop, this Emergency Stop must be delayed long enough by the PLC for the required NC or drive-side reactions to be completed. Writing in \$A_DBB allows the PLC to extensively influence the execution of the ESR reactions, if appropriate access is also integrated into the synchronized actions. The PLC has a "locking influence" on the ESR response.
Note for the reader	Function Manual Basic Functions S1

DB390x DBX5003.3	Axis is accelerating Signal(s) from axis/spindle (NCK → PLC)
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	When the acceleration of the following axis in the axis grouping of the electronic gear reaches or exceeds the percentage of the acceleration entered in MD37560, which is set in MD32300, then the signal is set to 1.
Signal state 0	The acceleration of the following axis in the axis grouping of the electronic gear falls below the response value described above.
corresponding to ...	MD37560 EG_ACC_TOL (threshold value for "accelerate axis") MD32300 MAX_AX_ACCEL (axis acceleration)
Note for the reader	Function Manual Basic Functions S1

DB390x DBX5008.0 to .5	Active infeed axes Signal(s) from axis/spindle
Edge evaluation: No	Signal(s) updated: Cyclic
Signal state 1	The axis, from which the signal is received is presently the oscillating axis and in this field, signals its active infeed axes (DBX5008.0 axis 1 is the infeed axis, DBX5008.1 axis 2 is the infeed axis, etc.)
Signal state 0	The associated axis is not an infeed axis.
corresponding to ...	DB390x DBX5004.7 (oscillation active)
Note for the reader	Function Manual, Expansion Functions P5

6.9 Tool management functions from the NC channel

DB5300 DBX0.0	Tool pre-alarm limit reached Signal(s) from channel (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: job-controlled by NCK
Signal state 1 or edge change 0 → 1	The pre-alarm limit for a tool to be monitored has been reached. The T number is provided in DB5300 DBD1000.
Signal state 0 or edge change 1 → 0	No pre-alarm limit reached
Note for the reader	Commissioning Manual, Turning and Milling

DB5300 DBX0.1	Tool limit value reached Signal(s) from channel (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: job-controlled by NCK
Signal state 1 or edge change 0 → 1	The limit value for a tool to be monitored has been reached. The T number is provided in DB5300 DBD1004.
Signal state 0 or edge change 1 → 0	No limit value reached
Note for the reader	Commissioning Manual, Turning and Milling

DB5300 DBD1000	T number for tool pre-alarm limit Signal(s) from channel (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: job-controlled by NCK
Signal state 1 or edge change 0 → 1	The T number is provided for which the tool pre-alarm limit is set.
Signal state 0 or edge change 1 → 0	No tool number signaled
Note for the reader	Commissioning Manual, Turning and Milling

DB5300 DBD1004	T number for tool limit value Signal(s) from channel (NCK → PLC)
Edge evaluation: Yes	Signal(s) updated: job-controlled by NCK
Signal state 1 or edge change 0 → 1	The T number is provided for which the tool limit value is set.
Signal state 0 or edge change 1 → 0	No tool number signaled
Note for the reader	Commissioning Manual, Turning and Milling

SINAMICS parameters

7.1 List of parameters


For a list of the SINAMICS parameters, see:

- /LH1/ SINAMICS S120/S150 List Manual

Appendix A

A

A.1 Documentation overview



Index

A

- AA_OFF_LIMIT
 - MD 43350, 410
- AA_OFF_MODE
 - MD 36750, 357
- ABS_INC_RATIO
 - MD 30260, 260
- ABSBLOCK_ENABLE
 - MD 42750, 398
- ABSBLOCK_FUNCTION_MASK
 - MD 27100, 239
- ACCEL_REDUCTION_FACTOR
 - MD 35230, 337
- ACCEL_REDUCTION_SPEED_POINT
 - MD 35220, 337
- ACCEL_REDUCTION_TYPE
 - MD 35242, 338
- ACCEL_TYPE_DRIVE
 - MD 35240, 338
- ACCESS_ACTIVATE_CTRL_E
 - MD 51071, 426
- ACCESS_CAL_TOOL_PROBE
 - MD 51070, 426
- ACCESS_CLEAR_RPA
 - MD 51046, 423
- ACCESS_EDIT_CTRL_E
 - MD 51072, 426
- ACCESS_EXEC_CMA
 - MD 11161, 62
- ACCESS_EXEC_CST
 - MD 11160, 61
- ACCESS_EXEC_CUS
 - MD 11162, 62
- ACCESS_HMI_EXIT
 - MD 9110, 21
- ACCESS_READ_GUD_LUD
 - MD 51047, 423
- ACCESS_READ_TM
 - MD 51211, 428
- ACCESS_RESET_SERV_PLANNER
 - MD 51235, 431
- ACCESS_SET_ACT_VALUE
 - MD 51063, 425
- ACCESS_SET_SOFTKEY_ACCESS
 - MD 51073, 426
- ACCESS_SHOW_SBL2
 - MD 51044, 422
- ACCESS_TEACH_IN
 - MD 51045, 422
- ACCESS_TM_MAGAZINE_POS
 - MD 51225, 430
- ACCESS_TM_TOOL_CREATE
 - MD 51216, 429
- ACCESS_TM_TOOL_DELETE
 - MD 51217, 429
- ACCESS_TM_TOOL_LOAD
 - MD 51218, 429
- ACCESS_TM_TOOL_MEASURE
 - MD 51222, 430
- ACCESS_TM_TOOL_MOVE
 - MD 51220, 429
- ACCESS_TM_TOOL_REACTIVATE
 - MD 51221, 430
- ACCESS_TM_TOOL_UNLOAD
 - MD 51219, 429
- ACCESS_TM_TOOLEGE_CREATE
 - MD 51223, 430
- ACCESS_TM_TOOLEGE_DELETE
 - MD 51224, 430
- ACCESS_WRITE_BASEFRAME
 - MD 51053, 423
- ACCESS_WRITE_CMA
 - MD 11166, 63
- ACCESS_WRITE_CST
 - MD 11165, 62
- ACCESS_WRITE_CUS
 - MD 11167, 63
- ACCESS_WRITE_CYCFRAME
 - MD 51054, 424
- ACCESS_WRITE_EXTFRAME
 - MD 51055, 424
- ACCESS_WRITE_FINE
 - MD 51062, 425
- ACCESS_WRITE_GUD_LUD
 - MD 51048, 423
- ACCESS_WRITE_MACCESS
 - MD 11171, 64
- ACCESS_WRITE_PARTFRAME
 - MD 51056, 424
- ACCESS_WRITE_PRG_COND
 - MD 51049, 423
- ACCESS_WRITE_PROGLIST
 - MD 51064, 425
- ACCESS_WRITE_PROGRAM
 - MD 51050, 423

ACCESS_WRITE_RPA
MD 51051, 423

ACCESS_WRITE_SACCESS
MD 11170, 64

ACCESS_WRITE_SEA
MD 51052, 423

ACCESS_WRITE_SETFRAME
MD 51057, 424

ACCESS_WRITE_TM_ADAPT
MD 51208, 427

ACCESS_WRITE_TM_ALL_PARAM
MD 51215, 429

ACCESS_WRITE_TM_ASSDNO
MD 51206, 427

ACCESS_WRITE_TM_EC
MD 51204, 427

ACCESS_WRITE_TM_GEO
MD 51200, 426

ACCESS_WRITE_TM_GRIND
MD 51199, 426

ACCESS_WRITE_TM_NAME
MD 51209, 428

ACCESS_WRITE_TM_SC
MD 51203, 427

ACCESS_WRITE_TM_SUPVIS
MD 51205, 427

ACCESS_WRITE_TM_TYPE
MD 51210, 428

ACCESS_WRITE_TM_WEAR
MD 51201, 426

ACCESS_WRITE_TM_WEAR_DELTA
MD 51202, 427

ACCESS_WRITE_TM_WGROUP
MD 51207, 427

ACCESS_WRITE_TOOLFRAME
MD 51058, 424

ACCESS_WRITE_TRAFRAME
MD 51059, 424

ACCESS_WRITE_UACCESS
MD 11172, 64

ACCESS_WRITE_USERFRAME
MD 51060, 424

ACCESS_WRITE_WPFRAME
MD 51061, 424

ACT_POS_ABS
MD 30250, 259

ACT_VALUE_SPIND_MODE
MD 51023, 419

ADD_MOVE_ACCEL_RESERVE
MD 20610, 164

ADISPOSA_VALUE
MD 43610, 413

ADJUST_NUM_AXIS_BIG_FONT
MD 52011, 435

ALARM_ROTATION_CYCLE
MD 9056, 20

ALLOW_G0_IN_G96
MD 20750, 170

APPROACH_FEED
MD 42120, 386

ASSIGN_FEED_PER_REV_SOURCE
MD 43300, 409

ASUP_EDIT_PROTECTION_LEVEL
MD 11612, 80

ASUP_EDITABLE
MD 11610, 79

ASUP_START_MASK
MD 11602, 78

ASUP_START_PRIO_LEVEL
MD 11604, 79

AUXFU_ASSIGN_EXTENSION
MD 22020, 184

AUXFU_ASSIGN_GROUP
MD 22000, 183

AUXFU_ASSIGN_SIM_TIME
MD 22037, 185

AUXFU_ASSIGN_SPEC
MD 22035, 185

AUXFU_ASSIGN_TYPE
MD 22010, 183

AUXFU_ASSIGN_VALUE
MD 22030, 184

AUXFU_ASSOC_M0_VALUE
MD 22254, 190

AUXFU_ASSOC_M1_VALUE
MD 22256, 190

AUXFU_D_SYNC_TYPE
MD 22250, 189

AUXFU_DL_SYNC_TYPE
MD 22252, 189

AUXFU_GROUP_SPEC
MD 11110, 60

AUXFU_H_SYNC_TYPE
MD 22230, 188

AUXFU_M_SYNC_TYPE
MD 22200, 187

AUXFU_MAXNUM_GROUP_ASSIGN
MD 11100, 59

AUXFU_PREDEF_EXTENSION
MD 22060, 186

AUXFU_PREDEF_GROUP
MD 22040, 185

AUXFU_PREDEF_SIM_TIME
MD 22090, 187

- AUXFU_PREDEF_SPEC
MD 22080, 186
- AUXFU_PREDEF_TYPE
MD 22050, 186
- AUXFU_PREDEF_VALUE
MD 22070, 186
- AUXFU_QUICK_BLOCKCHANGE
MD 22100, 187
- AUXFU_S_SYNC_TYPE
MD 22210, 188
- AUXFU_T_SYNC_TYPE
MD 22220, 188
- Auxiliary function transfer from NC channel, 554
- AX_EMERGENCY_STOP_TIME
MD 36610, 354
- AX_ESR_DELAY_TIME1
MD 37510, 374
- AX_ESR_DELAY_TIME2
MD 37511, 375
- AX_INERTIA
MD 32650, 302
- AX_JERK_ENABLE
MD 32400, 288
- AX_JERK_MODE
MD 32402, 289
- AX_JERK_TIME
MD 32410, 290
- AX_JERK_VELO
MD 32437, 292
- AX_JERK_VEL1
MD 32438, 293
- AX_MASS
MD 32652, 303
- AX_MOTION_DIR
MD 32100, 284
- AX_VELO_LIMIT
MD 36200, 350
- AXCONF_CHANAX_DEFAULT_NAME
MD 20082, 111
- AXCONF_CHANAX_NAME_TAB
MD 20080, 110
- AXCONF_GEOAX_ASSIGN_TAB
MD 20050, 107
- AXCONF_GEOAX_NAME_TAB
MD 20060, 108
- AXCONF_MACHAX_NAME_TAB
MD 10000, 22
- AXCONF_MACHAX_USED
MD 20070, 109
- AXES_SCALE_ENABLE
MD 22914, 202
- AXES_SHOW_GEO_FIRST
MD 51026, 419
- AXIS_LANG_SUB_MASK
MD 30465, 267
- AXIS_USAGE
MD 52206, 436
- AXIS_USAGE_ATTRIB
MD 52207, 436
- Axis/spindlespecific signals, 600
- ## B
- BACKLASH
MD 32450, 294
- BACKLASH_FACTOR
MD 32452, 294
- BAG_MASK
MD 11600, 77
- BASE_FUNCTION_MASK
MD 30460, 266
- BERO_DELAY_TIME_MINUS
MD 31123, 274
- BERO_DELAY_TIME_PLUS
MD 31122, 273
- BLOCK_SEARCH_MODE_MASK
MD 51028, 419
- BRAKE_MODE_CHOICE
MD 36600, 354
- ## C
- CEC_ENABLE
MD 32710, 304
- CEC_MAX_SUM
MD 32720, 304
- CEC_MAX_VELO
MD 32730, 305
- CEC_SCALING_SYSTEM_METRIC
MD 32711, 304
- CEC_TABLE_ENABLE
MD 41300, 383
- CEC_TABLE_WEIGHT
MD 41310, 384
- CENTRAL_LUBRICATION
MD 12300, 89
- CHANGE_LANGUAGE_MODE
MD 9100, 20
- Channelspecific signals, 565
- CHBFRAME_POWERON_MASK
MD 24004, 204

CHBFRAME_RESET_MASK
MD 24002, 203

CHFRND_MAXNUM_DUMMY_BLOCKS
MD 20200, 140

CHFRND_MODE_MASK
MD 20201, 141

CHSFRAME_POWERON_MASK
MD 24008, 205

CHSFRAME_RESET_CLEAR_MASK
MD 24007, 205

CHSFRAME_RESET_MASK
MD 24006, 204

CIRCLE_ERROR_CONST
MD 21000, 171

CIRCLE_ERROR_FACTOR
MD 21010, 172

CIRCLE_RAPID_FEED
MD 55230, 466

CLAMP_POS_TOL
MD 36050, 347

COMP_ADD_VELO_FACTOR
MD 32760, 306

COMPAR_ASSIGN_ANA_INPUT_1
MD 10530, 30

COMPAR_ASSIGN_ANA_INPUT_2
MD 10531, 31

COMPAR_TYPE_1
MD 10540, 31

COMPAR_TYPE_2
MD 10541, 32

COMPRESS_BLOCK_PATH_LIMIT
MD 20170, 135

COMPRESS_CONTOUR_TOL
MD 42475, 392

COMPRESS_ORI_ROT_TOL
MD 42477, 392

COMPRESS_POS_TOL
MD 33100, 310

COMPRESS_SMOOTH_FACTOR
MD 20485, 159

COMPRESS_SMOOTH_FACTOR_2
MD 20487, 159

COMPRESS_VELO_TOL
MD 20172, 136

COMPRESSOR_MODE
MD 20482, 158

CONE_ANGLE
MD 42995, 405

CONST_VELO_MIN_TIME
MD 20500, 160

CONTOUR_SAMPLING_FACTOR
MD 10682, 34

CONTOUR_TOL
MD 36400, 352

CONTOURHANDWH_IMP_PER_LATCH
MD 11322, 68

CONTPREC
MD 42450, 390

CONTROL_UNIT_LOGIC_ADDRESS
MD 13120, 91

CORNER_SLOWDOWN_CRIT
MD 42526, 397

CORNER_SLOWDOWN_END
MD 42522, 396

CORNER_SLOWDOWN_OVR
MD 42524, 396

CORNER_SLOWDOWN_START
MD 42520, 396

CORR_VELO
MD 32070, 279

COUP_SYNC_DELAY_TIME
MD 37240, 369

COUPLE_AXIS_1
MD 21300, 178

COUPLE_BLOCK_CHANGE_CTRL_1
MD 21320, 180

COUPLE_CYCLE_MASK
MD 11754, 82

COUPLE_IS_WRITE_PROT_1
MD 21340, 182

COUPLE_POS_TOL_COARSE
MD 37200, 366

COUPLE_POS_TOL_COARSE_2
MD 37202, 366

COUPLE_POS_TOL_FINE
MD 37210, 367

COUPLE_POS_TOL_FINE_2
MD 37212, 367

COUPLE_RATIO_1
MD 42300, 388

COUPLE_RESET_MODE_1
MD 21330, 181

COUPLE_VELO_TOL_COARSE
MD 37220, 368

COUPLE_VELO_TOL_FINE
MD 37230, 369

COUPLING_MODE_1
MD 21310, 179

CPREC_WITH_FFW
MD 20470, 155

CRIT_SPLINE_ANGLE
MD 42470, 391

ctrl energy, 540

CTRLOUT_LIMIT	DB1100, 486
MD 36210, 350	DB1200, 487
CTRLOUT_LIMIT_TIME	DB1400, 488
MD 36220, 350	DB1600, 489
CTRLOUT_MODULE_NR	DB1600 DBX2000.0, 544
MD 30110, 255	DB1600 DBX2000.1, 544
CTRLOUT_NR	DB1700, 491
MD 30120, 255	DB1700 DBX0.3, 545
CTRLOUT_SEGMENT_NR	DB1700 DBX0.5, 545
MD 30100, 255	DB1700 DBX0.6, 545
CTRLOUT_TYPE	DB1700 DBX1.3, 546
MD 30130, 256	DB1700 DBX1.7, 546
CUBIC_SPLINE_BLOCKS	DB1700 DBX3.0 to 3.1, 546
MD 20160, 135	DB1700 DBX3.7 ***, 547, 548
CURV_EFFECT_ON_PATH_ACCEL	DB1800, 492
MD 20602, 163	DB1800 DBX0.0, 548
CURV_EFFECT_ON_PATH_JERK	DB1800 DBX0.1, 548
MD 20603, 163	DB1800 DBX0.2, 548
CUTCOM_ACT_DEACT_CTRL	DB1800 DBX0.7, 549
MD 42494, 394	DB1800 DBX1.0, 549
CUTCOM_CLSD_CONT	DB1800 DBX1.2, 549
MD 42496, 395	DB1800 DBX1000.6, 550
CUTCOM_CORNER_LIMIT	DB1900 DBX0.6, 550
MD 20210, 142	DB1900 DBX0.7, 550
CUTCOM_CURVE_INSERT_LIMIT	DB1900 DBX1003.0 to .2, 551
MD 20230, 143	DB1900 DBX1003.7, 552, 553
CUTCOM_DECEL_LIMIT	DB1900 DBX1004.0 to .2, 551
MD 42528, 397	DB1900 DBX1004.7, 552, 553
CUTCOM_G40_STOPRE	DB1900 DBX5000.2, 553
MD 42490, 393	DB1900 DBX5000.7, 553
CUTCOM_INTERS_POLY_ENABLE	DB2500, 496
MD 20256, 144	DB2500 DBB1000 to DBB1012, 554
CUTCOM_MAX_DISC	DB2500 DBB3004, 555
MD 20220, 142	DB2500 DBB3012, 555
CUTCOM_MAXNUM_CHECK_BLOCKS	DB2500 DBB3020, 555
MD 20240, 143	DB2500 DBB3028, 555
CUTCOM_MAXNUM_DUMMY_BLOCKS	DB2500 DBB3036, 555
MD 20250, 143	DB2500 DBB4004, 555
CUTDIRMOD	DB2500 DBB4012, 555
MD 42984, 405	DB2500 DBD2000, 554
CUTMOD_ERR	DB2500 DBD3000, 555
MD 20125, 128	DB2500 DBD3008, 555
CUTMOD_INIT	DB2500 DBD3016, 555
MD 20127, 129	DB2500 DBD3024, 555
CUTTING_EDGE_DEFAULT	DB2500 DBD3032, 555
MD 20270, 144	DB2500 DBD4000, 555
	DB2500 DBD4008, 555
	DB2500 DBD5000, 556
	DB2500 DBD6000, 556
	DB2500 DBD6008, 556
	DB2500 DBD6016, 556
	DB2500 DBW6004, 556
D	
D_NO_FCT_CYCLE_NAME	
MD 11717, 81	
DB1000, 486	

DB2500 DBW6012, 556
DB2500 DBW6020, 556
DB2500 DBX10.0, 554
DB2500 DBX12.0 to .2, 554
DB2500 DBX4. 0 to .4, 554
DB2500 DBX6.0, 554
DB2500 DBX8.0, 554
DB2600, 499
DB2600 DBX0.1, 557
DB2600 DBX0.2, 557
DB2600 DBX1.0, 558
DB2700, 500
DB2700 DBX0.1, 558
DB2700 DBX1.0, 558
DB2700 DBX1.7, 558, 559, 560
DB2800, 501
DB2900, 502
DB3000, 502
DB3000 DBX0.0, 560
DB3000 DBX0.1, 560, 561
DB3000 DBX0.4, 561
DB3000 DBX0.7, 561
DB3000 DBX1.2, 561, 562
DB3000 DBX1.6, 562
DB3000 DBX1.7, 562
DB3000 DBX2.0 to .6, 563
DB3100, 503
DB3100 DBX0.0, 564
DB3100 DBX0.1, 564
DB3100 DBX0.2, 564
DB3100 DBX0.3, 564
DB3100 DBX1.2, 565
DB3200, 503
DB3200 DBB2, 568
DB3200 DBB4, 570
DB3200 DBB5, 571
DB3200 DBX0.3, 565
DB3200 DBX0.4, 566
DB3200 DBX0.5, 566
DB3200 DBX0.6, 566, 567
DB3200 DBX1.1, 567
DB3200 DBX1.7, 568
DB3200 DBX1000.0 to .1, 579, 580
DB3200 DBX1000.3, 581
DB3200 DBX1000.4, 581
DB3200 DBX1000.5, 582
DB3200 DBX1000.7 and .6, 583
DB3200 DBX1001.0 to .6, 584
DB3200 DBX1004.0 to .1, 579, 580
DB3200 DBX1004.3, 581
DB3200 DBX1004.4, 581
DB3200 DBX1004.5, 582
DB3200 DBX1004.7 and .6, 583
DB3200 DBX1005.0 to .6, 584
DB3200 DBX1008.0 to .1, 579, 580
DB3200 DBX1008.3, 581
DB3200 DBX1008.4, 581
DB3200 DBX1008.5, 582
DB3200 DBX1008.7 and .6, 583
DB3200 DBX1009.0 to .6, 584
DB3200 DBX13.5, 579
DB3200 DBX14.0 and .1, 579
DB3200 DBX14.3 and .4, 579
DB3200 DBX14.5, 580
DB3200 DBX16.0, 580
DB3200 DBX3.0, 568
DB3200 DBX3.1, 568
DB3200 DBX3.2, 569
DB3200 DBX3.3, 569
DB3200 DBX3.4, 569
DB3200 DBX3.5, 569
DB3200 DBX6.0, 572
DB3200 DBX6.1, 573
DB3200 DBX6.2, 574
DB3200 DBX6.4, 574
DB3200 DBX6.6, 575
DB3200 DBX6.7, 575
DB3200 DBX7.0, 576
DB3200 DBX7.1, 576
DB3200 DBX7.2, 576
DB3200 DBX7.3, 577
DB3200 DBX7.4, 578
DB3300, 506, 509
DB3300 DBB10, 594
DB3300 DBB12, 595
DB3300 DBB14, 595
DB3300 DBB4004, 598, 599
DB3300 DBB8, 594
DB3300 DBX0.3, 585
DB3300 DBX0.4, 585
DB3300 DBX0.5, 585
DB3300 DBX0.6, 586
DB3300 DBX1.0, 586
DB3300 DBX1.2, 586
DB3300 DBX1.3, 587
DB3300 DBX1.4, 587
DB3300 DBX1.5, 588
DB3300 DBX1.6, 588
DB3300 DBX1.7, 589
DB3300 DBX1000.0 to .1, 595
DB3300 DBX1000.5 and .4, 596
DB3300 DBX1000.7 and .6, 596
DB3300 DBX1001.0 to .6, 597
DB3300 DBX1004.0 to .1, 595

- DB3300 DBX1004.5 and .4, 596
 DB3300 DBX1004.7 and .6, 596
 DB3300 DBX1005.0 to .6, 597
 DB3300 DBX1008.0 to .1, 595
 DB3300 DBX1008.5 and .4, 596
 DB3300 DBX1008.7 and .6, 596
 DB3300 DBX1009.0 to .6, 597
 DB3300 DBX11.0 to .1, 594
 DB3300 DBX13.0 to .1, 595
 DB3300 DBX15.0 to .1, 595
 DB3300 DBX3.0, 589
 DB3300 DBX3.2, 590
 DB3300 DBX3.3, 590
 DB3300 DBX3.4, 590
 DB3300 DBX3.5, 591
 DB3300 DBX3.6, 591
 DB3300 DBX3.7, 591
 DB3300 DBX4.2, 592
 DB3300 DBX4.3, 592
 DB3300 DBX4.6, 592
 DB3300 DBX4.7, 592
 DB3300 DBX4001.1, 597, 598, 599
 DB3300 DBX5.0 and .1, 593
 DB3300 DBX6.0, 593
 DB3300 DBX6.1, 593
 DB3300 DBX9.0 to .1, 594
 DB3400, 510
 DB3500, 511
 DB3700, 511
 DB370x DBD0, 600
 DB370x DBD4, 601
 DB3800, 511
 DB380x DBB0, 602
 DB380x DBX1.1, 603
 DB380x DBX1.2, 603, 604, 605, 606
 DB380x DBX1.7, 608
 DB380x DBX1000.1 and .0, 617
 DB380x DBX1000.3 or .2, 618
 DB380x DBX1000.7, 618
 DB380x DBX2.2, 609, 610
 DB380x DBX2.3, 611
 DB380x DBX2000.0 to .2, 619
 DB380x DBX2000.3, 620
 DB380x DBX2001.0, 620, 621
 DB380x DBX2001.4, 621
 DB380x DBX2001.6, 622
 DB380x DBX2002.4, 622
 DB380x DBX2002.5, 623
 DB380x DBX2002.7 and .6, 623
 DB380x DBX2003, 624, 625, 646
 DB380x DBX3.1, 612
 DB380x DBX3.6, 613
 DB380x DBX4.0 to .1, 613
 DB380x DBX4.3, 614
 DB380x DBX4.4, 615
 DB380x DBX4.5, 615
 DB380x DBX4.7 and .6, 616
 DB380x DBX5.0 and .6, 617
 DB3900, 516
 DB390x DBB8, 637
 DB390x DBX0.0, 628
 DB390x DBX0.2, 629
 DB390x DBX0.4, 629
 DB390x DBX0.6, 630
 DB390x DBX0.7, 630
 DB390x DBX1.1, 627, 628, 630
 DB390x DBX1.2, 626, 631, 632, 633, 647, 648, 649, 650, 651, 652
 DB390x DBX2.1, 633
 DB390x DBX2.2, 634
 DB390x DBX2.3, 634
 DB390x DBX2.4, 634
 DB390x DBX2.5, 634
 DB390x DBX2000.0 to .2, 639
 DB390x DBX2000.3, 640
 DB390x DBX2001.0, 640, 642, 643
 DB390x DBX2001.1, 641
 DB390x DBX2001.2, 641
 DB390x DBX2001.5, 642
 DB390x DBX2001.7, 643
 DB390x DBX2002.0, 643
 DB390x DBX2002.3, 644
 DB390x DBX2002.4, 644
 DB390x DBX2002.5, 644
 DB390x DBX2002.6, 645
 DB390x DBX2002.7, 645
 DB390x DBX4.0 to .1, 635
 DB390x DBX4.7 to .6, 636
 DB390x DBX5.0 to .6, 636, 637, 638
 DB390x DBX5008.0 to .5, 652
 DB4100, 522
 DB4200, 524
 DB4300, 525
 DB4500, 529
 DB4600, 531
 DB4700, 531
 DB4900, 532
 DB5300, 532
 DB5300 DBD1000, 653
 DB5300 DBD1004, 653
 DB5300 DBX0.0, 653
 DB5300 DBX0.1, 653
 DB5700, 533
 DB9900, 534

DB9901, 535
DB9902, 536
DB9903, 537
DB9904, 538
DB9905, 539
DB9906, 540
DB9907, 542
DEFAULT_FEED
 MD 42110, 386
DEFAULT_ROT_FACTOR_R
 MD 42150, 387
DEFAULT_SCALE_FACTOR_AXIS
 MD 43120, 406
DEFAULT_SCALE_FACTOR_P
 MD 42140, 387
DEPTH_OF_LOGFILE_OPT
 MD 17600, 96
DEPTH_OF_LOGFILE_OPT_PF
 MD 17610, 97
DES_VELO_LIMIT
 MD 36520, 353
DIAMETER_AX_DEF
 MD 20100, 114
DISP_COORDINATE_SYSTEM
 MD 52000, 434
DISP_NUM_AXIS_BIG_FONT
 MD 52010, 435
DISP_PLANE_MILL
 MD 52005, 435
DISP_PLANE_TURN
 MD 52006, 435
DISP_RES_ANGLE
 MD 51020, 418
DISP_RES_INCH
 MD 51010, 417
DISP_RES_INCH_CUT_RATE
 MD 51014, 418
DISP_RES_INCH_FEED_P_REV
 MD 51011, 418
DISP_RES_INCH_FEED_P_TIME
 MD 51012, 418
DISP_RES_INCH_FEED_P_TOOTH
 MD 51013, 418
DISP_RES_MM
 MD 51000, 417
DISP_RES_MM_CONST_CUT_RATE
 MD 51004, 417
DISP_RES_MM_FEED_PER_REV
 MD 51001, 417
DISP_RES_MM_FEED_PER_TIME
 MD 51002, 417
DISP_RES_MM_FEED_PER_TOOTH
 MD 51003, 417
DISP_RES_ROT_AX_FEED
 MD 51022, 418
DISP_RES_SPINDLE
 MD 51021, 418
DISPLAY_AXIS
 MD 20098, 113
DISPLAY_FUNCTION_MASK
 MD 10284, 26
DISPLAY_IS_MODULO
 MD 30320, 263
DISPLAY_MODE_POSITION
 MD 10136, 24
DISPLAY_SWITCH_OFF_INTERVAL
 MD 9006, 19
DRAW_POS_TRIGGER_TIME
 MD 10690, 35
DRIFT_ENABLE
 MD 36700, 355
DRIFT_VALUE
 MD 36720, 356
DRILL_MID_MAX_ECCENT
 MD 55489, 469
DRILL_SPOT_DIST
 MD 55490, 469
DRILL_TAPPING_SET_GG12
 MD 55481, 468
DRILL_TAPPING_SET_GG21
 MD 55482, 469
DRILL_TAPPING_SET_GG24
 MD 55483, 469
DRILL_TAPPING_SET_MC
 MD 55484, 469
DRILL_VELO_LIMIT
 MD 35550, 342
DRIVE_AX_RATIO_DENOM
 MD 31050, 272
DRIVE_AX_RATIO_NUMERA
 MD 31060, 272
DRIVE_AX_RATIO2_DENOM
 MD 31064, 272
DRIVE_AX_RATIO2_NUMERA
 MD 31066, 272
DRIVE_ENC_RATIO_DENOM
 MD 31070, 273
DRIVE_ENC_RATIO_NUMERA
 MD 31080, 273
DRIVE_SIGNAL_TRACKING
 MD 36730, 356
DRIVE_TELEGRAM_TYPE
 MD 13060, 89

DRV_DIAG_DO_AND_COMP_NAMES
 MD 9107, 21
 DRY_RUN_FEED
 MD 42100, 385
 DRY_RUN_FEED_MODE
 MD 42101, 386
 DRYRUN_MASK
 MD 10704, 38
 DYN_LIMIT_RESET_MASK
 MD 32320, 288
 DYN_MATCH_ENABLE
 MD 32900, 309
 DYN_MATCH_TIME
 MD 32910, 309

E

ENABLE_ALARM_MASK
 MD 11411, 73
 ENABLE_CHAN_AX_GAP
 MD 11640, 80
 ENABLE_COORDINATE_ACS
 MD 51037, 421
 ENABLE_COORDINATE_REL
 MD 51036, 421
 ENABLE_EPS_SERVICES
 MD 9108, 21
 ENABLE_HANDWHEEL_WINDOW
 MD 51067, 425
 ENABLE_PROGLIST_MANUFACT
 MD 51043, 422
 ENABLE_PROGLIST_USER
 MD 51041, 422
 ENABLE_QUICK_M_CODES
 MD 52229, 438
 ENABLE_START_MODE_MASK_PRT
 MD 22621, 199
 ENC_ABS_BUFFERING
 MD 30270, 260
 ENC_ABS_TURNS_MODULO
 MD 34220, 320
 ENC_ACTVAL_SMOOTH_TIME
 MD 34990, 323
 ENC_CHANGE_TOL
 MD 36500, 353
 ENC_COMP_ENABLE
 MD 32700, 303
 ENC_DIFF_TOL
 MD 36510, 353
 ENC_FEEDBACK_POL
 MD 32110, 284
 ENC_FREQ_LIMIT
 MD 36300, 351
 ENC_FREQ_LIMIT_LOW
 MD 36302, 351
 ENC_GRID_POINT_DIST
 MD 31010, 270
 ENC_INPUT_NR
 MD 30230, 257
 ENC_INVERS
 MD 34320, 322
 ENC_IS_DIRECT
 MD 31040, 271
 ENC_IS_DIRECT2
 MD 31044, 271
 ENC_IS_INDEPENDENT
 MD 30242, 258
 ENC_IS_LINEAR
 MD 31000, 270
 ENC_MARKER_INC
 MD 34310, 322
 ENC_MEAS_TYPE
 MD 30244, 259
 ENC_MODULE_NR
 MD 30220, 257
 ENC_PULSE_MULT
 MD 31025, 270
 ENC_REFP_MARKER_DIST
 MD 34300, 321
 ENC_REFP_MODE
 MD 34200, 319
 ENC_REFP_STATE
 MD 34210, 320
 ENC_RESOL
 MD 31020, 270
 ENC_SERIAL_NUMBER
 MD 34230, 321
 ENC_TYPE
 MD 30240, 258
 ENC_ZERO_MONITORING
 MD 36310, 352
 energy saving profil, 540
 EQUIV_CPREC_TIME
 MD 32415, 290
 EQUIV_CURRCTRL_TIME
 MD 32800, 307
 EQUIV_SPEEDCTRL_TIME
 MD 32810, 308
 ESR_DELAY_TIME1
 MD 21380, 183
 ESR_DELAY_TIME2
 MD 21381, 183

ESR_REACTION
MD 37500, 374

EVERY_ENC_SERIAL_NUMBER
MD 34232, 321

EXACT_POS_MODE
MD 20550, 161

EXACT_POS_MODE_G0_TO_G1
MD 20552, 161

EXT_PROG_PATH
MD 42700, 398

EXTERN_DIGITS_OFFSET_NO
MD 10889, 55

EXTERN_DIGITS_TOOL_NO
MD 10888, 54

EXTERN_DOUBLE_TURRET_DIST
MD 42162, 387

EXTERN_DOUBLE_TURRET_ON
MD 10812, 50

EXTERN_FIXED_FEEDRATE_F1_F9
MD 42160, 387

EXTERN_FIXED_FEEDRATE_F1_ON
MD 22920, 203

EXTERN_FLOATINGPOINT_PROG
MD 10884, 54

EXTERN_FUNCTION_MASK
MD 20734, 168

EXTERN_G_NO_MAC_CYCLE
MD 10816, 52

EXTERN_G_NO_MAC_CYCLE_NAME
MD 10817, 52

EXTERN_G0_LINEAR_MODE
MD 20732, 168

EXTERN_GCODE_GROUPS_TO_PLC
MD 22512, 192

EXTERN_GCODE_RESET_MODE
MD 20156, 134

EXTERN_GCODE_RESET_VALUES
MD 20154, 134

EXTERN_INCREMENT_SYSTEM
MD 10886, 54

EXTERN_INTERRUPT_BITS_M96
MD 10808, 49

EXTERN_INTERRUPT_NUM_ASUP
MD 10818, 52

EXTERN_INTERRUPT_NUM_RETRAC
MD 10820, 52

EXTERN_M_NO_DISABLE_INT
MD 10806, 49

EXTERN_M_NO_MAC_CYCLE
MD 10814, 51

EXTERN_M_NO_MAC_CYCLE_NAME
MD 10815, 51

EXTERN_M_NO_SET_INT
MD 10804, 48

EXTERN_MEAS_G31_P_SIGNAL
MD 10810, 50

EXTERN_PARALLEL_GEOAX
MD 22930, 203

EXTERN_PRINT_DEVICE
MD 10830, 52

EXTERN_PRINT_MODE
MD 10831, 53

EXTERN_REF_POSITION_G30_1
MD 43340, 410

EXTERN_RIGID_TAPPING_M_NR
MD 20095, 112

EXTERN_TOOLPROG_MODE
MD 10890, 55

F

F_VALUES_ACTIVE_AFTER_RESET
MD 22410, 191

FASTIO_DIG_NUM_INPUTS
MD 10350, 27

FASTIO_DIG_NUM_OUTPUTS
MD 10360, 27

FASTIO_DIG_SHORT_CIRCUIT
MD 10361, 28

FFW_ACTIVATION_MODE
MD 32630, 301

FFW_MODE
MD 32620, 301

FGROUP_DEFAULT_AXES
MD 22420, 192

FIX_POINT_POS
MD 30600, 269

FIXED_STOP_ACKN_MASK
MD 37060, 360

FIXED_STOP_ALARM_MASK
MD 37050, 360

FIXED_STOP_ALARM_REACTION
MD 37052, 360

FIXED_STOP_BY_SENSOR
MD 37040, 359

FIXED_STOP_CONTROL
MD 37002, 357

FIXED_STOP_MODE
MD 37000, 357

FIXED_STOP_SWITCH
MD 43500, 412

FIXED_STOP_THRESHOLD
MD 37030, 359

FIXED_STOP_TORQUE
 MD 43510, 412
 FIXED_STOP_TORQUE_DEF
 MD 37010, 357
 FIXED_STOP_TORQUE_FACTOR
 MD 37014, 358
 FIXED_STOP_TORQUE_RAMP_TIME
 MD 37012, 358
 FIXED_STOP_WINDOW
 MD 43520, 412
 FIXED_STOP_WINDOW_DEF
 MD 37020, 358
 FOC_ACTIVATION_MODE
 MD 37080, 361
 FOC_STANDSTILL_DELAY_TIME
 MD 36042, 347
 FRAME_ACS_SET
 MD 24030, 206
 FRAME_ADAPT_MODE
 MD 24040, 206
 FRAME_ANGLE_INPUT_MODE
 MD 10600, 33
 FRAME_GEOAX_CHANGE_MODE
 MD 10602, 33
 FRAME_OFFSET_INCR_PROG
 MD 42440, 389
 FRAME_OR_CORRPOS_NOTALLOWED
 MD 32074, 280
 FRAME_SAA_MODE
 MD 24050, 206
 FRAME_SAVE_MASK
 MD 10617, 34
 FRAME_SUPPRESS_MODE
 MD 24020, 206
 FRAMES_ACT_IMMEDIATELY
 MD 51025, 419
 FRICT_COMP_ACCEL1
 MD 32550, 298
 FRICT_COMP_ACCEL2
 MD 32560, 298
 FRICT_COMP_ACCEL3
 MD 32570, 299
 FRICT_COMP_ADAPT_ENABLE
 MD 32510, 295
 FRICT_COMP_CONST_MAX
 MD 32520, 296
 FRICT_COMP_CONST_MIN
 MD 32530, 297
 FRICT_COMP_ENABLE
 MD 32500, 295
 FRICT_COMP_INC_FACTOR
 MD 32580, 300
 FRICT_COMP_MODE
 MD 32490, 294
 FRICT_COMP_TIME
 MD 32540, 297
 FUNCTION_MASK_DISP
 MD 52210, 437
 FUNCTION_MASK_DRILL
 MD 52216, 438
 FUNCTION_MASK_DRILL_SET
 MD 55216, 465
 FUNCTION_MASK_MILL
 MD 52214, 438
 FUNCTION_MASK_MILL_SET
 MD 55214, 465
 FUNCTION_MASK_MILL_TOL_SET
 MD 55220, 466
 FUNCTION_MASK_SIM
 MD 51226, 430
 FUNCTION_MASK_SWIVEL_SET
 MD 55221, 466
 FUNCTION_MASK_TECH
 MD 51228, 430
 MD 52212, 437
 FUNCTION_MASK_TECH_SET
 MD 55212, 465
 FUNCTION_MASK_TURN
 MD 52218, 438
 FUNCTION_MASK_TURN_SET
 MD 55218, 466

G

G0_LINEAR_MODE
 MD 20730, 167
 G0_TOLERANCE_FACTOR
 MD 20560, 162
 G00_ACCEL_FACTOR
 MD 32434, 292
 G00_JERK_FACTOR
 MD 32435, 292
 G53_TOOLCORR
 MD 10760, 48
 GANTRY_ACT_POS_TOL_ERROR
 MD 37135, 364
 GANTRY_AXIS_TYPE
 MD 37100, 361
 GANTRY_BREAK_UP
 MD 37140, 364
 GANTRY_FUNCTION_MASK
 MD 37150, 365
 GANTRY_POS_TOL_ERROR
 MD 37120, 363

GANTRY_POS_TOL_REF
MD 37130, 364

GANTRY_POS_TOL_WARNING
MD 37110, 362

GCODE_GROUPS_TO_PLC
MD 22510, 192

GCODE_GROUPS_TO_PLC_MODE
MD 22515, 192

GCODE_RESET_MODE
MD 20152, 133

GCODE_RESET_VALUES
MD 20150, 131

GEAR_CHANGE_WAIT_TIME
MD 10192, 24

GEAR_STEP_CHANGE_ENABLE
MD 35010, 324

GEAR_STEP_CHANGE_POSITION
MD 35012, 325

GEAR_STEP_MAX_VELO
MD 35110, 330

GEAR_STEP_MAX_VELO_LIMIT
MD 35130, 333

GEAR_STEP_MAX_VELO2
MD 35112, 331

GEAR_STEP_MIN_VELO
MD 35120, 332

GEAR_STEP_MIN_VELO_LIMIT
MD 35140, 334

GEAR_STEP_MIN_VELO2
MD 35122, 332

GEAR_STEP_PC_MAX_VELO_LIMIT
MD 35135, 333

GEAR_STEP_POSCTRL_ACCEL
MD 35210, 336

GEAR_STEP_POSCTRL_ACCEL2
MD 35212, 336

GEAR_STEP_SPEEDCTRL_ACCEL
MD 35200, 336

GEAR_STEP_USED_IN_AXISMODE
MD 35014, 325

General selection/status signals from the MMC, 551, 552, 553

General selection/status signals to MMC, 495

General signals from NCK, 558

General signals to NCK, 557

GEOAX_CHANGE_M_CODE
MD 22532, 193

GEOAX_CHANGE_RESET
MD 20118, 125

GUD_AREA_SAVE_TAB
MD 11140, 61

H

HANDWH_CHAN_STOP_COND
MD 20624, 165

HANDWH_GEOAX_MAX_INCR_SIZE
MD 20620, 164

HANDWH_GEOAX_MAX_INCR_VSIZE
MD 20622, 165

HANDWH_IMP_PER_LATCH
MD 11320, 68

HANDWH_MAX_INCR_SIZE
MD 32080, 281

HANDWH_MAX_INCR_VELO_SIZE
MD 32082, 282

HANDWH_REVERSE
MD 11310, 67

HANDWH_STOP_COND
MD 32084, 282

HANDWH_TRUE_DISTANCE
MD 11346, 69

HANDWH_VELO_OVERLAY_FACTOR
MD 32090, 284

HANDWHEEL_FILTER_TIME
MD 11354, 71

HANDWHEEL_INPUT
MD 11352, 70

HANDWHEEL_MODULE
MD 11351, 70

HANDWHEEL_SEGMENT
MD 11350, 70

HIRTH_IS_ACTIVE
MD 30505, 269

HMI_MONITOR
MD 9032, 19

HMI_WIDE_SCREEN
MD 9105, 20

HW_ASSIGN_DIG_FASTIN
MD 10366, 29

HW_ASSIGN_DIG_FASTOUT
MD 10368, 30

HW_SERIAL_NUMBER
MD 18030, 98

I

IGN_PROG_STATE_ASUP
MD 20191, 138

IGNORE_INHIBIT_ASUP
MD 20116, 125

IGNORE_OVL_FACTOR_FOR_ADIS
MD 20490, 160

IGNORE_SINGLEBLOCK_ASUP
MD 20117, 125

IGNORE_SINGLEBLOCK_MASK
MD 10702, 36

INDEX_AX_ASSIGN_POS_TAB
MD 30500, 267

INDEX_AX_DENOMINATOR
MD 30502, 268

INDEX_AX_LENGTH_POS_TAB_1
MD 10900, 56

INDEX_AX_LENGTH_POS_TAB_2
MD 10920, 58

INDEX_AX_MODE
MD 10940, 59

INDEX_AX_NUMERATOR
MD 30501, 268

INDEX_AX_OFFSET
MD 30503, 269

INDEX_AX_POS_TAB_1
MD 10910, 57

INDEX_AX_POS_TAB_2
MD 10930, 58

INFO_FREE_MEM_DYNAMIC
MD 18050, 99

INFO_FREE_MEM_STATIC
MD 18060, 100

INT_INCR_PER_DEG
MD 10210, 25

INT_INCR_PER_MM
MD 10200, 25

IPO_MAX_LOAD
MD 11510, 77

IPOBRAKE_BLOCK_EXCHANGE
MD 43600, 413

IS_CONCURRENT_POS_AX
MD 30450, 264

IS_ROT_AX
MD 30300, 261

IS_SD_MAX_PATH_ACCEL
MD 42502, 395

IS_SD_MAX_PATH_JERK
MD 42512, 396

IS_UNIPOLAR_OUTPUT
MD 30134, 256

IS_VIRTUAL_AX
MD 30132, 256

ISO_ENABLE_DRYRUN
MD 52804, 443

ISO_ENABLE_INTERRUPTS
MD 52802, 443

ISO_M_DRILLING_AXIS_IS_Z
MD 55800, 480

ISO_M_DRILLING_TYPE
MD 55802, 480

ISO_M_ENABLE_POLAR_COORD
MD 52800, 442

ISO_M_RETRACTION_DIR
MD 55806, 481

ISO_M_RETRACTION_FACTOR
MD 55804, 480

ISO_SCALING_SYSTEM
MD 52806, 443

ISO_SIMULTAN_AXES_START
MD 52808, 443

ISO_T_DEEPHOLE_DRILL_MODE
MD 52810, 443

ISO_T_DWELL_TIME_UNIT
MD 55810, 481

ISO_T_RETRACTION_FACTOR
MD 55808, 481

J

J_MEA_CAL_HEIGHT_FEEDAX
MD 51772, 434

J_MEA_CAL_RING_DIAM
MD 51770, 433

J_MEA_COLL_MONIT_FEED
MD 51757, 433

J_MEA_COLL_MONIT_POS_FEED
MD 51758, 433

J_MEA_FIXPOINT
MD 52750, 442

J_MEA_FUNCTION_MASK_PIECE
MD 54780, 464

J_MEA_FUNCTION_MASK_TOOL
MD 54782, 464

J_MEA_M_DIST
MD 51750, 432

J_MEA_M_DIST_MANUELL
MD 51751, 433

J_MEA_M_DIST_TOOL_LENGTH
MD 51752, 433

J_MEA_M_DIST_TOOL_RADIUS
MD 51753, 433

J_MEA_MAGN_GLAS_POS
MD 52751, 442

J_MEA_T_PROBE_APPR_AX_DIR
MD 51784, 434

J_MEA_T_PROBE_DIAM_RAD
MD 51780, 434

J_MEA_T_PROBE_MEASURE_DIST
MD 51786, 434

JOG_AND_POS_JERK_ENABLE
MD 32420, 290
JOG_AND_POS_MAX_JERK
MD 32430, 291
JOG_CONT_MODE_LEVELTRIGGRD
MD 41050, 379
JOG_FEED_PER_REV_SOURCE
MD 42600, 397
JOG_GEOAX_MODE_MASK
MD 42996, 406
JOG_INC_MODE_LEVELTRIGGRD
MD 11300, 67
JOG_INCR_SIZE_TAB
MD 11330, 68
JOG_INCR_WEIGHT
MD 31090, 273
JOG_MODE_MASK
MD 10735, 46
JOG_POSITION
MD 43320, 410
JOG_REV_IS_ACTIVE
MD 41100, 380
JOG_REV_SET_VELO
MD 41120, 382
JOG_REV_VELO
MD 32050, 278
JOG_REV_VELO_RAPID
MD 32040, 278
JOG_ROT_AX_SET_VELO
MD 41130, 382
JOG_SET_VELO
MD 41110, 381
JOG_SPIND_SET_VELO
MD 41200, 383
JOG_VAR_INCR_SIZE
MD 41010, 379
JOG_VELO
MD 32020, 277
JOG_VELO_GEO
MD 21165, 174
JOG_VELO_RAPID
MD 32010, 276
JOG_VELO_RAPID_GEO
MD 21160, 174

K

KEYBOARD_STATE
MD 9009, 19

L

LANG_SUB_NAME
MD 15700, 95
LANG_SUB_PATH
MD 15702, 95
LEADSCREW_PITCH
MD 31030, 271
LEN_AC_FIFO
MD 28264, 249
LEN_PROTOCOL_FILE
MD 11420, 74
LIFTFAST_DIST
MD 21200, 176
LIFTFAST_STOP_COND
MD 21204, 176
LIFTFAST_WITH_MIRROR
MD 21202, 176
LIMIT_CHECK_MODE
MD 20280, 145
LOOKAH_FFORM
MD 20443, 153
LOOKAH_FREQUENCY
MD 32440, 293
LOOKAH_FUNCTION_MASK
MD 20455, 154
LOOKAH_NUM_OVR_POINTS
MD 20430, 152
LOOKAH_OVR_POINTS
MD 20440, 153
LOOKAH_RELIEVE_BLOCK_CYCLE
MD 20450, 153
LOOKAH_SMOOTH_WITH_FEED
MD 20462, 154
LOOKAH_USE_VELO_NEXT_BLOCK
MD 20400, 152
LUBRICATION_DIST
MD 33050, 309
LUD_EXTENDED_SCOPE
MD 11120, 61

M

M_CODE_ALL_COOLANTS_OFF
MD 52230, 438
M_CODE_CHUCK_CLOSE
MD 52252, 440
M_CODE_CHUCK_OPEN
MD 52250, 439
M_CODE_CHUCK_OPEN_ROT
MD 52251, 440

M_CODE_COOLANT_1_AND_2_ON
MD 52233, 439

M_CODE_COOLANT_1_ON
MD 52231, 439

M_CODE_COOLANT_2_ON
MD 52232, 439

M_NO_FCT_CYCLE
MD 10715, 43

M_NO_FCT_CYCLE_NAME
MD 10716, 44

M_NO_FCT_CYCLE_PAR
MD 10718, 45

M_NO_FCT_EOP
MD 10714, 42

M_NO_FCT_STOPRE
MD 10713, 42

M19_SPOS
MD 43240, 409

M19_SPOSMODE
MD 43250, 409

MACHINE_JOG_INTERRUPT_PRIO
MD 52260, 440

MAJOG_RELEASE_PLANE
MD 55261, 467

MAJOG_SAFETY_CLEARANCE
MD 55260, 467

MAPPED_FRAME
MD 32075, 281

MAX_ACCEL_OVL_FACTOR
MD 32310, 287

MAX_AX_ACCEL
MD 32300, 287

MAX_AX_JERK
MD 32431, 291

MAX_AX_JERK_FACTOR
MD 32439, 293

MAX_AX_VELO
MD 32000, 275

MAX_BLOCKS_IN_IPOBUFFER
MD 42990, 405

MAX_INP_FEED_PER_REV
MD 55200, 465

MAX_INP_FEED_PER_TIME
MD 55201, 465

MAX_INP_FEED_PER_TOOTH
MD 55202, 465

MAX_INP_RANGE_GAMMA
MD 55231, 467

MAX_LEAD_ANGLE
MD 21090, 173

MAX_PATH_JERK
MD 20600, 162

MAX_SKP_LEVEL
MD 51029, 419

MAX_TILT_ANGLE
MD 21092, 173

MAXNUM_REPLACEMENT_TOOLS
MD 17500, 96

MAXNUM_SYNC_DIAG_VAR
MD 28241, 247

MD_TEXT_SWITCH
MD 9900, 21

MEA_ALARM_MASK
MD 54750, 463

MEA_AVERAGE_VALUE
MD 55625, 475

MEA_AVERAGE_VALUE_NUM
MD 55624, 475

MEA_CAL_EDGE_BASE_AX1
MD 54615, 447

MEA_CAL_EDGE_BASE_AX2
MD 54619, 448

MEA_CAL_EDGE_MINUS_DIR_AX1
MD 54618, 448

MEA_CAL_EDGE_MINUS_DIR_AX2
MD 54622, 449

MEA_CAL_EDGE_NUM
MD 51601, 431

MEA_CAL_EDGE_PLUS_DIR_AX1
MD 54617, 448

MEA_CAL_EDGE_PLUS_DIR_AX2
MD 54621, 448

MEA_CAL_EDGE_UPPER_AX2
MD 54620, 448

MEA_CAL_TP_NUM
MD 51602, 431

MEA_CAL_TPW_NUM
MD 51603, 431

MEA_CAL_WP_NUM
MD 51600, 431

MEA_CM_FEEDFACTOR_1
MD 54675, 456

MEA_CM_FEEDFACTOR_2
MD 54676, 456

MEA_CM_MAX_FEEDRATE
MD 54672, 455

MEA_CM_MAX_PERI_SPEED
MD 54670, 455

MEA_CM_MAX_REVOLUTIONS
MD 54671, 455

MEA_CM_MEASURING_ACCURACY
MD 54677, 457

MEA_CM_MIN_FEEDRATE
MD 54673, 456

MEA_CM_ROT_AX_POS_TOL
MD 51618, 431

MEA_CM_SPIND_ROT_DIR
MD 54674, 456

MEA_EDGE_SAVE_ANG
MD 55642, 477

MEA_EMPIRIC_VALUE
MD 55623, 474

MEA_EMPIRIC_VALUE_NUM
MD 55622, 474

MEA_FEED_CIRCLE
MD 55640, 477

MEA_FEED_FAST_MEASURE
MD 55638, 477

MEA_FEED_FEEDAX_VALUE
MD 55636, 476

MEA_FEED_MEASURE
MD 55630, 475

MEA_FEED_PLANE_VALUE
MD 55634, 476

MEA_FEED_RAPID_IN_PERCENT
MD 55632, 475

MEA_FUNCTION_MASK
MD 51740, 432
MD 52740, 442
MD 54740, 462
MD 55740, 477

MEA_FUNCTION_MASK_PIECE
MD 54760, 463

MEA_FUNCTION_MASK_TOOL
MD 54762, 464

MEA_FUNCTION_MASK_TURN
MD 54764, 464

MEA_INPUT_TOOL_PROBE_SUB
MD 54652, 455

MEA_RESULT_DISPLAY
MD 55613, 473

MEA_RESULT_OFFSET_TAB_LEN1
MD 54705, 459

MEA_RESULT_OFFSET_TAB_LEN2
MD 54706, 460

MEA_RESULT_OFFSET_TAB_LEN3
MD 54707, 460

MEA_RESULT_OFFSET_TAB_LEN4
MD 54708, 460

MEA_RESULT_OFFSET_TAB_LEN5
MD 54709, 461

MEA_RESULT_OFFSET_TAB_LEN6
MD 54710, 461

MEA_RESULT_OFFSET_TAB_RAD1
MD 54695, 457

MEA_RESULT_OFFSET_TAB_RAD2
MD 54696, 458

MEA_RESULT_OFFSET_TAB_RAD3
MD 54697, 458

MEA_RESULT_OFFSET_TAB_RAD4
MD 54698, 458

MEA_RESULT_OFFSET_TAB_RAD5
MD 54699, 459

MEA_RESULT_OFFSET_TAB_RAD6
MD 54700, 459

MEA_SIM_ENABLE
MD 55618, 474

MEA_SIM_MEASURE_DIFF
MD 55619, 474

MEA_T_PROBE_MANUFACTURER
MD 54689, 457

MEA_T_PROBE_OFFSET
MD 54691, 457

MEA_TP_AX_DIR_AUTO_CAL
MD 54632, 451

MEA_TP_CAL_MEASURE_DEPTH
MD 54634, 451

MEA_TP_EDGE_DISK_SIZE
MD 54631, 450

MEA_TP_FEED
MD 54636, 452

MEA_TP_FEED_MEASURE
MD 55628, 475

MEA_TP_STATUS_GEN
MD 54635, 451

MEA_TP_TRIG_MINUS_DIR_AX1
MD 54625, 449

MEA_TP_TRIG_MINUS_DIR_AX2
MD 54627, 449

MEA_TP_TRIG_MINUS_DIR_AX3
MD 54629, 450

MEA_TP_TRIG_PLUS_DIR_AX1
MD 54626, 449

MEA_TP_TRIG_PLUS_DIR_AX2
MD 54628, 450

MEA_TP_TRIG_PLUS_DIR_AX3
MD 54630, 450

MEA_TP_TYPE
MD 54633, 451

MEA_TPW_AX_DIR_AUTO_CAL
MD 54647, 454

MEA_TPW_CAL_MEASURE_DEPTH
MD 54649, 454

MEA_TPW_EDGE_DISK_SIZE
MD 54646, 453

MEA_TPW_FEED
MD 54651, 455

MEA_TPW_STATUS_GEN
MD 54650, 454

MEA_TPW_TRIG_MINUS_DIR_AX1
MD 54640, 452

MEA_TPW_TRIG_MINUS_DIR_AX2
MD 54642, 452

MEA_TPW_TRIG_MINUS_DIR_AX3
MD 54644, 453

MEA_TPW_TRIG_PLUS_DIR_AX1
MD 54641, 452

MEA_TPW_TRIG_PLUS_DIR_AX2
MD 54643, 453

MEA_TPW_TRIG_PLUS_DIR_AX3
MD 54645, 453

MEA_TPW_TYPE
MD 54648, 454

MEA_WP_BALL_DIAM
MD 54600, 445

MEA_WP_FEED
MD 54611, 447

MEA_WP_POS_DEV_AX1
MD 54607, 446

MEA_WP_POS_DEV_AX2
MD 54608, 447

MEA_WP_STATUS_GEN
MD 54610, 447

MEA_WP_STATUS_RT
MD 54609, 447

MEA_WP_TRIG_MINUS_DIR_AX1
MD 54601, 445

MEA_WP_TRIG_MINUS_DIR_AX2
MD 54603, 445

MEA_WP_TRIG_MINUS_DIR_AX3
MD 54605, 446

MEA_WP_TRIG_PLUS_DIR_AX1
MD 54602, 445

MEA_WP_TRIG_PLUS_DIR_AX2
MD 54604, 446

MEA_WP_TRIG_PLUS_DIR_AX3
MD 54606, 446

MEAS_PROBE_DELAY_TIME
MD 13220, 93

MEAS_PROBE_LOW_ACTIVE
MD 13200, 92

MEAS_PROBE_OFFSET
MD 13231, 94

MEAS_PROBE_SOURCE
MD 13230, 94

MEAS_TYPE
MD 13210, 93

MILL_CONT_INITIAL_RAD_FIN
MD 55460, 468

MILL_SWIVEL_ALARM_MASK
MD 55410, 467

MILL_TOL_FACTOR_FINISH
MD 55443, 468

MILL_TOL_FACTOR_ROUGH
MD 55441, 467

MILL_TOL_FACTOR_SEMIFIN
MD 55442, 467

MILL_TOL_VALUE_FINISH
MD 55448, 468

MILL_TOL_VALUE_ROUGH
MD 55446, 468

MILL_TOL_VALUE_SEMIFIN
MD 55447, 468

MIN_CURV_RADIUS
MD 42471, 392

MINFEED
MD 42460, 390

MIRROR_TOGGLE
MD 10612, 34

MIRROR_TOOL_LENGTH
MD 42900, 399

MIRROR_TOOL_WEAR
MD 42910, 399

MISC_FUNCTION_MASK
MD 30455, 264

MM_ARCLENGTH_SEGMENTS
MD 28540, 253

MM_CEC_MAX_POINTS
MD 18342, 103

MM_ENC_COMP_MAX_POINTS
MD 38000, 376

MM_EXTERN_GCODE_SYSTEM
MD 10881, 53

MM_FEED_PROFILE_SEGMENTS
MD 28535, 253

MM_IPO_BUFFER_SIZE
MD 28060, 244

MM_LOOKAH_FFORM_UNITS
MD 28533, 252

MM_LUD_VALUES_MEM
MD 28040, 244

MM_MAX_AXISPOLY_PER_BLOCK
MD 28520, 251

MM_MAX_TRACE_DATAPOINTS
MD 28180, 246

MM_MAXNUM_ALARM_ACTIONS
MD 18730, 105

MM_NUM_AC_MARKER
MD 28256, 248

MM_NUM_AC_PARAM
MD 28254, 248

MM_NUM_AC_SYSTEM_MARKER
MD 28276, 250

MM_NUM_AC_SYSTEM_PARAM
MD 28274, 250

MM_NUM_AC_TIMER
MD 28258, 248

MM_NUM_AN_TIMER
MD 18710, 105

MM_NUM_BLOCKS_IN_PREP
MD 28070, 245

MM_NUM_CP_MODUL_LEAD
MD 18452, 105

MM_NUM_CP_MODULES
MD 18450, 105

MM_NUM_DIR_IN_FILESYSTEM
MD 18310, 103

MM_NUM_FCTDEF_ELEMENTS
MD 28252, 247

MM_NUM_LUD_NAMES_TOTAL
MD 28020, 243

MM_NUM_MAGAZINE
MD 18084, 101

MM_NUM_MAGAZINE_LOCATION
MD 18086, 102

MM_NUM_REORG_LUD_MODULES
MD 28010, 243

MM_NUM_SYNC_DIAG_ELEMENTS
MD 28240, 246

MM_NUM_SYNC_ELEMENTS
MD 28250, 247

MM_NUM_SYNC_STRINGS
MD 28253, 247

MM_NUM_WORKAREA_CS_GROUPS
MD 28600, 254

MM_PATH_VELO_SEGMENTS
MD 28530, 251

MM_PROTOC_FILE_BUFFER_SIZE
MD 18374, 104

MM_PROTOC_NUM_ETP_STD_TYP
MD 28302, 251

MM_PROTOC_NUM_ETPD_OEM_LIST
MD 18372, 104

MM_PROTOC_NUM_ETPD_STD_LIST
MD 18371, 104

MM_PROTOC_NUM_FILES
MD 18370, 103

MM_PROTOC_NUM_SERVO_DATA
MD 18373, 104

MM_PROTOC_SESS_ENAB_USER
MD 18375, 104

MM_PROTOC_USER_ACTIVE
MD 28300, 251

MM_SEARCH_RUN_RESTORE_MODE
MD 28560, 253

MM_SHAPED_TOOLS_ENABLE
MD 28290, 250

MM_SYSTEM_DATAFRAME_MASK
MD 28083, 246

MM_SYSTEM_FRAME_MASK
MD 28082, 245

MM_TOOL_MANAGEMENT_MASK
MD 18080, 100

MM_TRACE_DATA_FUNCTION
MD 22714, 201

MM_TRACE_VDI_SIGNAL
MD 18794, 105

MM_TYPE_CC_TOA_PARAM
MD 18097, 102

Mode signals, 560

MODE_AC_FIFO
MD 28266, 250

MODESWITCH_MASK
MD 20114, 124

MODULO_RANGE
MD 30330, 263

MODULO_RANGE_START
MD 30340, 264

MS_ASSIGN_MASTER_SPEED_CMD
MD 37250, 370

MS_ASSIGN_MASTER_TORQUE_CTR
MD 37252, 370

MS_COUPLING_ALWAYS_ACTIVE
MD 37262, 372

MS_FUNCTION_MASK
MD 37253, 370

MS_MAX_CTRL_VELO
MD 37260, 372

MS_MOTION_DIR_REVERSE
MD 37274, 374

MS_SPIND_COUPLING_MODE
MD 37263, 373

MS_TENSION_TORQ_FILTER_TIME
MD 37266, 373

MS_TENSION_TORQUE
MD 37264, 373

MS_TORQUE_CTRL_ACTIVATION
MD 37255, 371

MS_TORQUE_CTRL_I_TIME
MD 37258, 372

MS_TORQUE_CTRL_MODE
MD 37254, 371

MS_TORQUE_CTRL_P_GAIN
MD 37256, 371

MS_TORQUE_WEIGHT_SLAVE
MD 37268, 373
MS_VELO_TOL_COARSE
MD 37270, 374
MS_VELO_TOL_FINE
MD 37272, 374

N

NAME_TOOL_CHANGE_PROG
MD 52240, 439
NC_USER_CODE_CONF_NAME_TAB
MD 10712, 42
NC_USER_EXTERN_GCODES_TAB
MD 10882, 53
NCK signals, 557
NCK_EG_FUNCTION_MASK
MD 11756, 83
NCK_LEAD_FUNCTION_MASK
MD 11750, 81
NCK_TRAIL_FUNCTION_MASK
MD 11752, 81
NUM_AC_FIFO
MD 28260, 248
NUM_DISPLAYED_CHANNELS
MD 51065, 425
NUM_ENCS
MD 30200, 257
NUM_FIX_POINT_POS
MD 30610, 269
NUM_GEAR_STEPS
MD 35090, 329
NUM_GEAR_STEPS2
MD 35092, 330

O

OEM_AXIS_INFO
MD 37800, 376
OEM_CHAN_INFO
MD 27400, 239
OEM_GLOBAL_INFO
MD 17400, 95
ONLY_MKS_DIST_TO_GO
MD 51027, 419
OPERATING_MODE_DEFAULT
MD 10720, 46
ORDER_DISPLAYED_CHANNELS
MD 51066, 425
ORI_TRAFO_ONLINE_CHECK_LIM
MD 21198, 175

ORI_TRAFO_ONLINE_CHECK_LIMR
MD 21199, 175
ORIENTATION_IS_EULER
MD 21100, 173
OVR_AX_IS_GRAY_CODE
MD 12000, 83
OVR_FACTOR_AX_SPEED
MD 12010, 83
OVR_FACTOR_FEEDRATE
MD 12030, 84
OVR_FACTOR_LIMIT_BIN
MD 12100, 87
OVR_FACTOR_RAPID_TRA
MD 12050, 85
OVR_FACTOR_SPIND_SPEED
MD 12070, 85
OVR_FEED_IS_GRAY_CODE
MD 12020, 84
OVR_FUNCTION_MASK
MD 12090, 86
OVR_RAPID_FACTOR
MD 42122, 387
OVR_RAPID_IS_GRAY_CODE
MD 12040, 84
OVR_REFERENCE_IS_MIN_FEED
MD 12082, 86
OVR_REFERENCE_IS_PROG_FEED
MD 12080, 86
OVR_SPIND_IS_GRAY_CODE
MD 12060, 85

P

PARAMSET_CHANGE_ENABLE
MD 35590, 342
PART_COUNTER
MD 27880, 241
PART_COUNTER_MCODE
MD 27882, 242
PATH_MODE_MASK
MD 20464, 154
PATH_TRANS_JERK_LIM
MD 32432, 291
PATH_TRANS_POS_TOL
MD 33120, 310
PERMANENT_FEED
MD 12202, 87
PERMANENT_ROT_AX_FEED
MD 12204, 88
PERMANENT_SPINDLE_FEED
MD 12205, 88

- PFRAME_RESET_MODE
 - MD 24010, 206
 - PLC user interface
 - Axis/spindle signals, 511
 - PLC machine data, 529
 - User alarm, 489
 - PLC_CYCLE_TIME
 - MD 10075, 23
 - PLC_DEACT_IMAGE_LADDR_IN
 - MD 12986, 89
 - PLC_DEACT_IMAGE_LADDR_OUT
 - MD 12987, 89
 - POS_AX_VELO
 - MD 32060, 279
 - POS_DYN_MODE
 - MD 18960, 106
 - POS_LIMIT_MINUS
 - MD 36100, 348
 - POS_LIMIT_MINUS2
 - MD 36120, 349
 - POS_LIMIT_PLUS
 - MD 36110, 349
 - POS_LIMIT_PLUS2
 - MD 36130, 349
 - POSCTRL_GAIN
 - MD 32200, 285
 - POSITIONING_TIME
 - MD 36020, 346
 - PREPDYN_SMOOTHING_FACTOR
 - MD 20605, 163
 - PREPDYN_SMOOTHING_ON
 - MD 20606, 164
 - PREPROCESSING_LEVEL
 - MD 10700, 35
 - PREVENT_SYNACT_LOCK
 - MD 11500, 76
 - PREVENT_SYNACT_LOCK_CHAN
 - MD 21240, 177
 - PROCESSTIMER_MODE
 - MD 27860, 240
 - PROFIBUS_ALARM_ACCESS
 - MD 13140, 91
 - PROFIBUS_CTRL_CONFIG
 - MD 37610, 375
 - PROFIBUS_SDB_NUMBER
 - MD 11240, 65
 - PROFIBUS_SDB_SELECT
 - MD 11241, 65
 - PROFIBUS_SHUTDOWN_TYPE
 - MD 11250, 66
 - PROFIBUS_TORQUE_RED_RESOL
 - MD 37620, 375
 - PROFIBUS_TRACE_ADDRESS
 - MD 13110, 90
 - PROFIBUS_TRACE_FILE_SIZE
 - MD 13112, 90
 - PROFIBUS_TRACE_START
 - MD 13113, 90
 - PROFIBUS_TRACE_START_EVENT
 - MD 13114, 91
 - PROFIBUS_TRACE_TYPE
 - MD 13111, 90
 - PROG_EVENT_IGN_INHIBIT
 - MD 20107, 115
 - PROG_EVENT_IGN_PROG_STATE
 - MD 20192, 139
 - PROG_EVENT_IGN_SINGLEBLOCK
 - MD 20106, 115
 - PROG_EVENT_IGN_STOP
 - MD 20193, 139
 - PROG_EVENT_MASK
 - MD 20108, 116
 - PROG_EVENT_MASK_PROPERTIES
 - MD 20109, 116
 - PROG_NET_TIMER_MODE
 - MD 27850, 239
 - PROG_SD_POWERON_INIT_TAB
 - MD 10709, 40
 - PROG_SD_RESET_SAVE_TAB
 - MD 10710, 41
 - PROG_TEST_MASK
 - MD 10707, 39
 - Program control signals from the HMI, 545
 - PROGRAM_CONTROL_MODE_MASK
 - MD 51039, 422
 - PROTOCOL_FILE_MODE
 - MD 11422, 74
- ## R
- RATED_OUTVAL
 - MD 32250, 286
 - RATED_VELO
 - MD 32260, 287
 - REBOOT_DELAY_TIME
 - MD 10088, 23
 - REFP_CAM_DIR_IS_MINUS
 - MD 34010, 311
 - REFP_CAM_IS_ACTIVE
 - MD 34000, 310
 - REFP_CAM_MARKER_DIST
 - MD 34093, 317
 - REFP_CAM_SHIFT
 - MD 34092, 316

- REFP_CYCLE_NR
MD 34110, 318
- REFP_MAX_CAM_DIST
MD 34030, 312
- REFP_MAX_MARKER_DIST
MD 34060, 314
- REFP_MOVE_DIST
MD 34080, 315
- REFP_MOVE_DIST_CORR
MD 34090, 315
- REFP_NC_START_LOCK
MD 20700, 167
- REFP_PERMITTED_IN_FOLLOWUP
MD 34104, 318
- REFP_SEARCH_MARKER_REVERSE
MD 34050, 313
- REFP_SET_POS
MD 34100, 317
- REFP_STOP_AT_ABS_MARKER
MD 34330, 322
- REFP_SYNC_ENCS
MD 34102, 317
- REFP_VELO_POS
MD 34070, 315
- REFP_VELO_SEARCH_CAM
MD 34020, 312
- REFP_VELO_SEARCH_MARKER
MD 34040, 312
- REPOS_MODE_MASK
MD 11470, 76
- RESET_MODE_MASK
MD 20110, 116
- REV_2_BORDER_TOOL_LENGTH
MD 52248, 439
- ROT_IS_MODULO
MD 30310, 262
- S**
- S_VALUES_ACTIVE_AFTER_RESET
MD 22400, 191
- SCALING_FACTOR_G70_G71
MD 31200, 275
- SCALING_SYSTEM_IS_METRIC
MD 10240, 25
- SD_MAX_PATH_ACCEL
MD 42500, 395
- SD_MAX_PATH_JERK
MD 42510, 396
- SEARCH_RUN_MODE
MD 11450, 75
- SERUPRO_MASK
MD 10708, 39
- SERUPRO_SPEED_FACTOR
MD 22601, 198
- SERUPRO_SPEED_MODE
MD 22600, 197
- SERVE_EXTCALL_PROGRAMS
MD 9106, 20
- SERVO_DISABLE_DELAY_TIME
MD 36620, 355
- SET_ACT_VALUE
MD 51038, 421
- SETINT_ASSIGN_FASTIN
MD 21210, 177
- SHAPED_TOOL_CHECKSUM
MD 20372, 151
- SHAPED_TOOL_TYPE_NO
MD 20370, 150
- SHOW_TOOLTIP
MD 9102, 20
- SIEM_TRACEFILES_CONFIG
MD 11294, 66
- Signal from Weiss spindle, 520
- Signals from axis/spindle, 626, 646, 647, 648, 649, 650, 651, 652
- Signals from HMI, 548, 550
- Signals from NC channel, 585
- Signals from operator panel, 550
- Signals from/to HMI, 545
- Signals to axis/spindle, 602
- Signals to channel, 565
- SIM_DISPLAY_CONFIG
MD 52290, 441
- SIM_START_POSITION
MD 53230, 443
- SIMU_AX_VDI_OUTPUT
MD 30350, 264
- SINAMICS_ALARM_MASK
MD 13150, 92
- SINGLEBLOCK2_STOPRE
MD 42200, 388
- SLASH_MASK
MD 10706, 39
- SMOOTH_CONTUR_TOL
MD 42465, 390
- SMOOTH_ORI_TOL
MD 42466, 391
- SMOOTHING_MODE
MD 20480, 156
- SOFT_ACCEL_FACTOR
MD 32433, 292

SPF_END_TO_VDI
MD 20800, 170

SPIND_ACTIVE_AFTER_RESET
MD 35040, 328

SPIND_ASSIGN_TAB
MD 42800, 398

SPIND_ASSIGN_TO_MACHAX
MD 35000, 323

SPIND_CONSTCUT_S
MD 43202, 407

SPIND_DEF_MASTER_SPIND
MD 20090, 111

SPIND_DEFAULT_ACT_MASK
MD 35030, 326

SPIND_DEFAULT_MODE
MD 35020, 326

SPIND_DES_VELO_TOL
MD 35150, 335

SPIND_DRIVELOAD_FROM_PLC1
MD 51068, 425

SPIND_DRIVELOAD_FROM_PLC2
MD 51069, 426

SPIND_EXTERN_VELO_LIMIT
MD 35160, 335

SPIND_FUNCTION_MASK
MD 35035, 327

SPIND_MAX_POWER
MD 51030, 420

SPIND_MAX_VELO_G26
MD 43220, 408

SPIND_MAX_VELO_LIMS
MD 43230, 408

SPIND_MIN_VELO_G25
MD 43210, 407

SPIND_ON_SPEED_AT_IPO_START
MD 35500, 341

SPIND_OSCILL_ACCEL
MD 35410, 340

SPIND_OSCILL_DES_VELO
MD 35400, 339

SPIND_OSCILL_START_DIR
MD 35430, 340

SPIND_OSCILL_TIME_CCW
MD 35450, 341

SPIND_OSCILL_TIME_CW
MD 35440, 341

SPIND_POSCTRL_VELO
MD 35300, 338

SPIND_POSIT_DELAY_TIME
MD 35310, 339

SPIND_POSITIONING_DIR
MD 35350, 339

SPIND_POWER_RANGE
MD 51031, 420

SPIND_RIGID_TAPPING_M_NR
MD 20094, 112

SPIND_S
MD 43200, 406

SPIND_SPEED_TYPE
MD 43206, 407

SPIND_STOPPED_AT_IPO_START
MD 35510, 342

SPIND_USER_VELO_LIMIT
MD 43235, 409

SPIND_VELO_LIMIT
MD 35100, 330

SPINDLE_CHUCK_TYPE
MD 53241, 444

SPINDLE_PARAMETER
MD 53240, 444

SPLINE_MODE
MD 20488, 159

SPOS_TO_VDI
MD 20850, 171

SPRINT_FORMAT_P_CODE
MD 10750, 47

SPRINT_FORMAT_P_DECIMAL
MD 10751, 48

STANDSTILL_DELAY_TIME
MD 36040, 346

STANDSTILL_POS_TOL
MD 36030, 346

STANDSTILL_VELO_TOL
MD 36060, 348

START_AC_FIFO
MD 28262, 249

START_MODE_MASK
MD 20112, 121

START_MODE_MASK_PRT
MD 22620, 198

STAT_DISPLAY_BASE
MD 51032, 420

STIFFNESS_CONTROL_ENABLE
MD 32640, 302

STOP_CUTCOM_STOPRE
MD 42480, 393

STOP_LIMIT_COARSE
MD 36000, 344

STOP_LIMIT_FACTOR
MD 36012, 345

STOP_LIMIT_FINE
MD 36010, 345

STOP_MODE_MASK
MD 11550, 77

STOP_ON_CLAMPING
MD 36052, 347
STROKE_CHECK_INSIDE
MD 22900, 202
SUB_SPINDLE_PARK_POS_Y
MD 52244, 439
SUB_SPINDLE_REL_POS
MD 55232, 467
SUMCORR_DEFAULT
MD 20272, 145
SUPPRESS_ALARM_MASK
MD 11410, 71
SW_OPTIONS
MD 9990, 21
SWITCH_TO_MACHINE_MASK
MD 51040, 422

T

T_M_ADDRESS_EXT_IS_SPINO
MD 20096, 113
T_NO_FCT_CYCLE_MODE
MD 10719, 45
T_NO_FCT_CYCLE_NAME
MD 10717, 44
TAILSTOCK_PARAMETER
MD 53242, 444
TARGET_BLOCK_INCR_PROG
MD 42444, 389
TCA_CYCLE_NAME
MD 15710, 95
TEACH_MODE
MD 51034, 421
TECHNOLOGY
MD 52200, 435
TECHNOLOGY_EXTENSION
MD 52201, 436
TEMP_COMP_ABS_VALUE
MD 43900, 414
TEMP_COMP_REF_POSITION
MD 43920, 415
TEMP_COMP_SLOPE
MD 43910, 414
TEMP_COMP_TYPE
MD 32750, 305
THREAD_RAMP_DISP
MD 42010, 385
THREAD_START_ANGLE
MD 42000, 384
TIME_LIMIT_NETTO_INT_TASK
MD 27920, 242
TM_FUNCTION_MASK
MD 52270, 440
TM_FUNCTION_MASK_SET
MD 54215, 444
TM_TOOL_LOAD_STATION
MD 52274, 441
TM_WRITE_LIMIT_MASK
MD 51214, 429
TM_WRITE_WEAR_ABS_LIMIT
MD 51212, 428
TM_WRITE_WEAR_DELTA_LIMIT
MD 51213, 428
TOCARR_BASE_FRAME_NUMBER
MD 20184, 137
TOCARR_CHANGE_M_CODE
MD 22530, 193
TOCARR_FINE_CORRECTION
MD 42974, 403
TOCARR_FINE_LIM_LIN
MD 20188, 138
TOCARR_FINE_LIM_ROT
MD 20190, 138
TOCARR_ROT_ANGLE_INCR
MD 20180, 136
TOCARR_ROT_ANGLE_OFFSET
MD 20182, 137
TOCARR_ROT_OFFSET_FROM_FR
MD 21186, 175
TOCARR_ROTAX_MODE
MD 20196, 140
TOFF_LIMIT
MD 42970, 403
TOFRAME_MODE
MD 42980, 403
Tool management functions from the NC channel, 653
TOOL_CARRIER_RESET_VALUE
MD 20126, 129
TOOL_CHANGE_ERROR_MODE
MD 22562, 195
TOOL_CHANGE_M_CODE
MD 22560, 194
TOOL_CHANGE_MODE
MD 22550, 194
TOOL_CHANGE_TIME
MD 10190, 24
TOOL_CORR_MODE_G43G44
MD 20380, 151
TOOL_CORR_MOVE_MODE
MD 20382, 151
TOOL_CORR_MULTIPLE_AXES
MD 20384, 152

TOOL_LENGTH_CONST
MD 42940, 401

TOOL_LENGTH_TYPE
MD 42950, 402

TOOL_MANAGEMENT_MASK
MD 20310, 145

TOOL_MANAGEMENT_TOOLHOLDER
MD 20124, 127

TOOL_MCODE_FUNC_OFF
MD 52282, 441

TOOL_MCODE_FUNC_ON
MD 52281, 441

TOOL_OFFSET_INCR_PROG
MD 42442, 389

TOOL_PARAMETER_DEF_MASK
MD 20360, 149

TOOL_RESET_NAME
MD 20122, 126

TOOL_RESET_VALUE
MD 20120, 126

TOOL_TEMP_COMP
MD 42960, 402

TOOL_TEMP_COMP_LIMIT
MD 20392, 152

TOOL_TEMP_COMP_ON
MD 20390, 152

TOOL_TIME_MONITOR_MASK
MD 20320, 148

TOOLTIP_TIME_DELAY
MD 9103, 20

TRAANG_ANGLE_1
MD 24700, 226

TRAANG_ANGLE_2
MD 24750, 228

TRAANG_BASE_TOOL_1
MD 24710, 226

TRAANG_BASE_TOOL_2
MD 24760, 229

TRAANG_PARALLEL_ACCEL_RES_1
MD 24721, 228

TRAANG_PARALLEL_ACCEL_RES_2
MD 24771, 230

TRAANG_PARALLEL_VELO_RES_1
MD 24720, 227

TRAANG_PARALLEL_VELO_RES_2
MD 24770, 229

TRACE_PATHNAME
MD 18391, 104

TRACE_SAVE_OLD_FILE
MD 18392, 104

TRACE_SCOPE_MASK
MD 22708, 200

TRACE_STARTTRACE_EVENT
MD 22700, 199

TRACE_STARTTRACE_STEP
MD 22702, 199

TRACE_STOPTRACE_EVENT
MD 22704, 199

TRACE_STOPTRACE_STEP
MD 22706, 200

TRACE_VARIABLE_INDEX
MD 22712, 200

TRACE_VARIABLE_NAME
MD 22710, 200

TRACE_VDI_AX
MD 31600, 275

TRACON_CHAIN_1
MD 24995, 236

TRACON_CHAIN_2
MD 24996, 237

TRACON_CHAIN_3
MD 24997, 238

TRACON_CHAIN_4
MD 24998, 238

TRACYL_BASE_TOOL_1
MD 24820, 231

TRACYL_BASE_TOOL_2
MD 24870, 232

TRACYL_DEFAULT_MODE_1
MD 24808, 231

TRACYL_DEFAULT_MODE_2
MD 24858, 232

TRACYL_ROT_AX_FRAME_1
MD 24805, 230

TRACYL_ROT_AX_FRAME_2
MD 24855, 232

TRACYL_ROT_AX_OFFSET_1
MD 24800, 230

TRACYL_ROT_AX_OFFSET_2
MD 24850, 231

TRACYL_ROT_SIGN_IS_PLUS_1
MD 24810, 231

TRACYL_ROT_SIGN_IS_PLUS_2
MD 24860, 232

TRAFO_AXES_IN_1
MD 24110, 209

TRAFO_AXES_IN_2
MD 24210, 210

TRAFO_AXES_IN_3
MD 24310, 212

TRAFO_AXES_IN_4
MD 24410, 214

TRAFO_AXES_IN_5
MD 24432, 216

TRAFO_AXES_IN_6
MD 24442, 218

TRAFO_AXES_IN_7
MD 24452, 220

TRAFO_AXES_IN_8
MD 24462, 222

TRAFO_AXES_IN_9
MD 24472, 224

TRAFO_CHANGE_M_CODE
MD 22534, 193

TRAFO_GEOAX_ASSIGN_TAB_1
MD 24120, 209

TRAFO_GEOAX_ASSIGN_TAB_2
MD 24220, 210

TRAFO_GEOAX_ASSIGN_TAB_3
MD 24320, 212

TRAFO_GEOAX_ASSIGN_TAB_4
MD 24420, 215

TRAFO_GEOAX_ASSIGN_TAB_5
MD 24434, 217

TRAFO_GEOAX_ASSIGN_TAB_6
MD 24444, 219

TRAFO_GEOAX_ASSIGN_TAB_7
MD 24454, 221

TRAFO_GEOAX_ASSIGN_TAB_8
MD 24464, 223

TRAFO_GEOAX_ASSIGN_TAB_9
MD 24474, 225

TRAFO_INCLUDES_TOOL_1
MD 24130, 210

TRAFO_INCLUDES_TOOL_2
MD 24230, 211

TRAFO_INCLUDES_TOOL_3
MD 24330, 213

TRAFO_INCLUDES_TOOL_4
MD 24426, 215

TRAFO_INCLUDES_TOOL_5
MD 24436, 217

TRAFO_INCLUDES_TOOL_6
MD 24446, 219

TRAFO_INCLUDES_TOOL_7
MD 24456, 221

TRAFO_INCLUDES_TOOL_8
MD 24466, 223

TRAFO_INCLUDES_TOOL_9
MD 24476, 225

TRAFO_MODE_MASK
MD 20144, 130

TRAFO_RESET_NAME
MD 20142, 130

TRAFO_RESET_VALUE
MD 20140, 130

TRAFO_TYPE_1
MD 24100, 207

TRAFO_TYPE_2
MD 24200, 210

TRAFO_TYPE_3
MD 24300, 211

TRAFO_TYPE_4
MD 24400, 214

TRAFO_TYPE_5
MD 24430, 216

TRAFO_TYPE_6
MD 24440, 218

TRAFO_TYPE_7
MD 24450, 220

TRAFO_TYPE_8
MD 24460, 222

TRAFO_TYPE_9
MD 24470, 224

Transferred axis-specific M, S functions, 600

TRANSMIT_BASE_TOOL_1
MD 24920, 234

TRANSMIT_BASE_TOOL_2
MD 24970, 236

TRANSMIT_POLE_SIDE_FIX_1
MD 24911, 234

TRANSMIT_POLE_SIDE_FIX_2
MD 24961, 235

TRANSMIT_ROT_AX_FRAME_1
MD 24905, 233

TRANSMIT_ROT_AX_FRAME_2
MD 24955, 235

TRANSMIT_ROT_AX_OFFSET_1
MD 24900, 233

TRANSMIT_ROT_AX_OFFSET_2
MD 24950, 234

TRANSMIT_ROT_SIGN_IS_PLUS_1
MD 24910, 233

TRANSMIT_ROT_SIGN_IS_PLUS_2
MD 24960, 235

TU_DISPLAY_BASE
MD 51033, 420

TURN_CONT_BLANK_OFFSET
MD 55584, 472

TURN_CONT_INTER_RETRACTION
MD 55586, 472

TURN_CONT_INTERRUPT_TIME
MD 55585, 472

TURN_CONT_MIN_REST_MAT_AX1
MD 55587, 472

TURN_CONT_MIN_REST_MAT_AX2
MD 55588, 473

TURN_CONT_RELEASE_ANGLE
MD 55580, 471
TURN_CONT_RELEASE_DIST
MD 55581, 471
TURN_CONT_TOOL_BEND_RETR
MD 55595, 473
TURN_CONT_TRACE_ANGLE
MD 55582, 472
TURN_CONT_TURN_RETRACTION
MD 55596, 473
TURN_CONT_VARIABLE_DEPTH
MD 55583, 472
TURN_FIN_FEED_PERCENT
MD 55500, 469
TURN_FIXED_STOP_DIST
MD 55550, 471
TURN_FIXED_STOP_FEED
MD 55551, 471
TURN_FIXED_STOP_FORCE
MD 55552, 471
TURN_FIXED_STOP_RETRACTION
MD 55553, 471
TURN_GROOVE_DWELL_TIME
MD 55510, 470
TURN_PART_OFF_CTRL_DIST
MD 55540, 470
TURN_PART_OFF_CTRL_FEED
MD 55541, 470
TURN_PART_OFF_CTRL_FORCE
MD 55542, 470
TURN_PART_OFF_RETRACTION
MD 55543, 471
TURN_ROUGH_I_RELEASE_DIST
MD 55506, 470
TURN_ROUGH_O_RELEASE_DIST
MD 55505, 470

U

UPLOAD_MD_CHANGES_ONLY
MD 11210, 65
USEKT_RESET_VALUE
MD 20123, 126
USER_DATA_FLOAT
MD 14514, 94
USER_DATA_HEX
MD 14512, 94
USER_DATA_INT
MD 14510, 94
USER_DATA_PLC_ALARM
MD 14516, 94

USER_FRAME_POWERON_MASK
MD 24080, 207

V

VELO_FFW_WEIGHT
MD 32610, 300
VERSION_INFO
MD 18040, 98

W

WAB_CLEARANCE_TOLERANCE
MD 20204, 142
WAB_MAXNUM_DUMMY_BLOCKS
MD 20202, 141
WAIT_ENC_VALID
MD 34800, 323
WEAR_SIGN
MD 42930, 400
WEAR_SIGN_CUTPOS
MD 42920, 399
WEAR_TRANSFORM
MD 42935, 400
WEIGHTING_FACTOR_FOR_SCALE
MD 22910, 202
WORKAREA_CHECK_TYPE
MD 30800, 269
WORKAREA_LIMIT_MINUS
MD 43430, 411
WORKAREA_LIMIT_PLUS
MD 43420, 411
WORKAREA_MINUS_ENABLE
MD 43410, 411
WORKAREA_PLUS_ENABLE
MD 43400, 410
WORKAREA_WITH_TOOL_RADIUS
MD 21020, 172
WPD_INI_MODE
MD 11280, 66
WRITE_FRAMES_FINE_LIMIT
MD 51035, 421

X

X_AXIS_IN_OLD_X_Z_PLANE
MD 21110, 174

