


## PNOZpe2p Bus-Interface

779125



Interface safety relay PNOZpower for external connection to PNOZsigma PNOZ X, PNOZmulti, PNOZelog, PSS and SafetyBUS p.