

SIEMENS

SIMATIC

Distributed I/O

Product information for the ET 200S Operating Instructions (A5E00515771-06) 08/2008

Product Information

Contents

This product information describes supplements and corrections to the ET 200S Distributed I/O System Operating Instructions, (A5E00515771-06), release 08/2008.

In the chapter: **Wiring an interface module with PROFINET IO interface (electrically)**

Note

Interface modules with PROFINET IO electronic

We recommend that you use a strain relief for the PROFINET connecting cable when using an ET 200S system under environmental conditions where it is subject to mechanical vibration or shock.

To do this you require a cable tie with a standard width of 2.5 mm or 3.6 mm. Use it to attach the PROFINET connecting cable from right where it exits the PROFINET connector to the cable bracket provided on the Interface module (on the front side directly below the PROFINET IO interface).

Siemens AG
Industry Sector
Postfach 48 48
90026 NÜRNBERG

Product information for the ET 200S Operating Instructions (A5E00515771-06) 08/2008
A5E02382347-01, 11/2008