

SIEMENS



SIMATIC

S7-1200 / S7-1500

Comparison list for programming languages based on the international mnemonics

Reference manual



Edition

12/2014

SIEMENS

Comparison list for S7-300, S7-400, S7-1200, S7-1500

Reference manual

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.
--

 WARNING
--

indicates that death or severe personal injury may result if proper precautions are not taken.

 CAUTION
--

indicates that minor personal injury can result if proper precautions are not taken.
--

NOTICE

indicates that property damage can result if proper precautions are not taken.
--

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of SIMATIC products

Note the following:

 WARNING
--

WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.
--

Trademarks

All names identified by © are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Siemens AG
Digital Factory
Postfach 48 48
90026 NÜRNBERG, Germany

Comparison list for S7-300, S7-400, S7-1200, S7-1500
12/2014

Overview of the comparison list

- Measuring runtime of instructions and program parts (see below)
- Loading objects to the CPU: which changes and which changed blocks you can load to the CPU in which operating mode. (next page)
- Overview, requirements, framework conditions and legends to the comparison list (page 7)
- Comparison list for S7-300, S7-400, S7-1200, S7-1500 including CPU 150xS software controller: Which instructions and functions can be used for which controller family. (from page 8)
- Annex: Optional instructions for SIMATIC Ident

Measuring runtime of instructions and program parts

The runtime of parts of the user program and instructions depend on numerous factors. A tabular list is therefore not possible. The **RUNTIME** (runtime measurement) instruction is used to measure the runtime of the entire program, individual blocks or command sequences. The runtime measurement starts with the first call of the RUNTIME instruction and ends with the second call.

For the runtime measurement of individual instructions, you use an OB priority >15. As a result, "Monitor online" does not falsify the runtime. You can find additional information in the SIMATIC STEP 7 online help. Enter "Runtime" in the search box.

Program example in SCL:

```
"Common_Data".opt.Last_Cycle := RUNTIME(#Tag_Memory); //Start of runtime measurement, LReal
    "speed test FB opt_DB"(ON_2:="i1",...); //Runtime measurement through RUNTIME
"Common_Data".opt.Last_Cycle := RUNTIME(#Tag_Memory); //End of runtime measurement
```

The `Last_Cycle` tag contains the time that has elapsed between the previous call and the current call of RUNTIME.

Loading objects to the CPU

The table shows which changes and which changed blocks can be loaded in which operating mode.

Very complex programs can prevent loading in RUN mode. Possible solutions:

- Use a memory card with sufficient capacity.
- Select a CPU with sufficient work memory.
- Reduce the number of changed used blocks, constants, PLC tags or data types.

Changes and blocks	S7-300	S7-400	S7-1200 as of V4.0	S7-1500 V1.7	S7-1200 V1.0 - 2.1	S7-1200 V2.2 - V3.0	S7-1500 V1.0-V1.6
Changed properties of HW components	STOP	STOP	STOP	STOP	STOP	STOP	STOP
Added HW components	STOP	STOP	STOP	STOP	STOP	STOP	STOP
New/changed text lists (Alarms)	RUN	RUN	STOP	STOP	STOP	STOP	STOP
Download number of blocks	RUN (<17)	RUN (<57)	RUN (<21)	RUN	STOP	RUN (<11)	RUN
Download PLC program to device and reset	STOP (Reset)	STOP (Reset)	STOP (Reset)	STOP (Reset)	STOP (Reset)	STOP (Reset)	STOP (Reset)
New OB	RUN	RUN	STOP	RUN	STOP	STOP	RUN
Changed OB: Code changes, change of comments	RUN	RUN	RUN	RUN	STOP	RUN	RUN
OB with changed properties (e.g. cycle time change)	RUN	RUN	STOP	RUN	STOP	STOP	RUN
Deleted OB	RUN	RUN	STOP	RUN	STOP	STOP	RUN

Changes and blocks	S7-300	S7-400	S7-1200 as of V4.0	S7-1500 V1.7	S7-1200 V1.0 - 2.1	S7-1200 V2.2 - V3.0	S7-1500 V1.0-V1.6
New FB/FC/DB/PLC data type (UDT)	RUN	RUN	RUN	RUN	STOP	RUN	RUN
Deleted FB/FC/DB/PLC data type (UDT)	RUN	RUN	RUN	RUN	STOP	RUN	RUN
Changed FB/FC: Code change, change of comments	RUN	RUN	RUN	RUN	STOP	RUN	RUN
Changed FB/FC: Interface change	STOP	STOP	RUN (Init)	RUN (Init)	STOP	STOP	RUN (Init)
Changed DB (no memory reserve configured): Name/type of tags changed, tags added or deleted	RUN (Init)	RUN (Init)	RUN (Init)	RUN (Init)	STOP	STOP	RUN (Init)
Changed DB (memory reserve configured): New tags added	--	--	RUN	RUN	--	--	RUN (Init)
Changed PLC data type (UDT)	STOP	STOP	RUN (Init)	RUN (Init)	STOP	STOP	RUN (Init)
Changed PLC tags (added, deleted, name changed)	RUN	RUN	RUN	RUN	STOP	STOP	RUN

Changes and blocks	S7-300	S7-400	S7-1200 as of V4.0	S7-1500 V1.7	S7-1200 V1.0 - 2.1	S7-1200 V2.2 - V3.0	S7-1500 V1.0-V1.6
Changed retentivity settings (bit memory area, DB area)	STOP	STOP	STOP	STOP	STOP	STOP	STOP
Motion Control technology objects: Changes to MC servo cycle clock, change from asynchronous to cyclic (and vice-versa). Changes to the HW interface of the TO	--	--	--	STOP	--	--	STOP

(init) means that the current values of the DBs are overwritten by start values during loading.

Structure of the comparison list

- **Basic instructions**
Instructions that you often use such as bit logic operations, timers, counters, mathematic functions
- **Extended instructions**
Sophisticated instructions for more options, such as date and time, interrupts, alarms, PROFInergy
- **Technological instructions (technology)**
Technological functions, such as PID control, Motion
- **Instructions for communication (communication)**
Instructions for communication, e.g. S7 Communication, Open User Communication

Validity and framework conditions

- SIMATIC STEP 7 as of Version 13, as of service pack 1
- The contents of the S7-1500 column are valid also for SIMATIC S7-1500 Software Controller CPU 150xS
- SIMATIC S7-1200 as of firmware 3.x; SIMATIC S7-1200 supports only LAD, FBD and SCL.
- STL: you have to call some instructions via CALL.

Legend

✓	Applicable
(✓)	Applicable with limitations
nn	Not necessary
<i>gray</i>	We recommend that you do not use the grayed out instructions in the S7-1200 or S7-1500, as these instructions are unsuitable for symbolic addressing or multiple instances. SIMATIC counters and timers are not recommended, as they are not multi-instance capable.
XYZ	New instruction as of SIMATIC STEP 7 V13. For this purpose, SIMATIC S7-1200 requires at least firmware 4.0 and SIMATIC S7-1500 at least firmware 1.5
XYZ	New instruction as of SIMATIC STEP 7 V13 SP1 . For this purpose, SIMATIC S7-1200 requires at least firmware 4.1 and SIMATIC S7-1500 at least firmware 1.7
XYZ	Also available as safety instruction in the optional safety package in LAD and FBD.

Instructions in the section "Basic instructions"

Instruction groups	Page	Instruction groups	Page	Instruction groups	Page
General	8	Comparator operations	13	Word logic operations	27
Bit logic operations	8	Math functions	16	Shift and rotate instructions	27
Safety functions	10	Move	17	Load and transfer	28
Timers	11	Conversion operations	20	Legacy	29
Counters	13	Program control operations	23		

S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
	General			
✓ ✓ ✓ ✓	Insert network	✓	✓	nn
✓ ✓ ✓ ✓	Insert empty box	✓	nn	nn
✓ ✓ ✓ ✓	Open branch	✓	(
✓ ✓ ✓ ✓	Close branch	✓)	
✓ ✓ ✓ ✓	Insert input	-	nn	nn
✓ ✓ ✓ ✓	Invert Boolean result	- NOT - -o		NOT
	Bit logic operations			
✓ ✓ ✓ ✓	AND logic operation	✓ &	A	&

Basic instructions				Extended instructions	Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD		STL (not S7-1200)	SCL
✓	✓	✓	✓	OR logic operation	✓	>=1	O	OR
✓	✓	✓	✓	EXCLUSIVE or operation	✓	X	X	XOR
✓	✓	✓	✓	Assignment	-()-	-[=]	=	:=
		✓	✓	Negate assignment	-(/)-	-[/=]		NOT
✓	✓	✓	✓	Reset output	-(R)	-[R]	R	nn
✓	✓	✓	✓	Set output	-(S)	-[S]	S	nn
	✓	✓		Set bit field		SET_BF	nn	nn
	✓	✓		Reset bit field		RESET_BF	nn	nn
✓	✓	✓	✓	Set/reset flip-flop		SR	nn	nn
✓	✓	✓	✓	Reset/set flip-flop		RS	nn	nn
✓	✓	✓	✓	Scan operand for positive signal edge		- P	<Operand>; FP;	nn
✓	✓	✓	✓	Scan operand for negative signal edge		- N	<Operand>; FP;	nn
		✓	✓	Set operand on positive signal edge		-(P)-		R_TRIG
		✓	✓	Set operand on negative signal edge		-(N)-		F_TRIG
✓	✓	✓	✓	Scan Boolean result for positive signal edge		P_TRIG	FP	nn
✓	✓	✓	✓	Scan Boolean result for negative signal edge		N_TRIG	FN	nn

Basic instructions				Extended instructions	Technology	Communication		
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD		STL (not S7-1200)	SCL
		✓	✓	Set tag on positive signal edge	R_TRIG			
		✓	✓	Set tag on negative signal edge	F_TRIG			
✓	✓	✓	✓	Normally open contact	- -	nn	nn	nn
✓	✓	✓	✓	Normally closed contact	- / -	nn	nn	nn
Safety functions								
✓	✓	✓	✓	Safety only: EMERGENCY STOP up to Stop category 1	ESTOP1			
✓	✓			Safety only: Two-hand monitoring	TWO_HAND			
✓	✓	✓	✓	Safety only: Two-hand monitoring with enable	TWO_H_EN			
✓	✓			Safety only: Parallel muting with two or four muting sensors	MUTING			
✓	✓	✓	✓	Safety only: Parallel muting with two or four muting sensors	MUT_P			
✓	✓	✓	✓	Safety only: 1oo2 (2v2) evaluation of two single-channel encoders combined with a discrepancy analysis	EV1oo2DI			
✓	✓	✓	✓	Safety only: Feedback monitoring	FDBACK			
✓	✓	✓	✓	Safety only: Safety door monitoring	SFDOOR			

Basic instructions				Extended instructions	Technology	Communication		
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL	
✓	✓	✓	✓	Safety only: Acknowledgment for simultaneous reintegration of all F-I/O / channels of the F-I/O of an F-runtime group after communication errors and/or F-I/O / channel errors	ACK_GL			
Timers								
IEC timers								
✓	✓	✓	✓	Generate pulse	TP		TP	
✓	✓	✓	✓	Generate on-delay	TON		TON	
✓	✓	✓	✓	Generate off-delay	TOF		TOF	
	✓	✓		Time accumulator		TONR		
	✓	✓		Time accumulator (start timer)	-(TONR)-	-[TONR]-	nn	nn
	✓	✓		Reset timer	-(RT)-	-[RT]-	RESET_TIMER	
	✓	✓		Load time duration	-(PT)-	-[PT]-	PRESET_TIMER	
	✓	✓		Generate pulse	-(TP)-	-[TP]-	nn	TP
	✓	✓		Start on-delay timer	-(TON)-	-[TON]-	SD	S_ODT
	✓	✓		Start off-delay timer	-(TOF)-	-[TOF]-	SF	S_OFFDT

Basic instructions				Extended instructions	Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD		STL (not S7-1200)	SCL
<i>Legacy</i>								
✓	✓	✓		<i>Assign pulse timer parameters and start</i>	<i>S_PULSE</i>		<i>nn</i>	<i>S_PULSE</i>
✓	✓	✓		<i>Assign extended pulse timer parameters and start</i>	<i>S_PEXT</i>		<i>nn</i>	<i>S_PEXT</i>
✓	✓	✓		<i>Assign on-delay timer parameters and start</i>	<i>S_ODT</i>		<i>nn</i>	<i>S_ODT</i>
✓	✓	✓		<i>Assign retentive on-delay timer parameters and start</i>	<i>S_ODTS</i>		<i>nn</i>	<i>S_ODTS</i>
✓	✓	✓		<i>Assign off-delay timer parameters and start</i>	<i>S_OFFDT</i>		<i>nn</i>	<i>S_OFFDT</i>
✓	✓	✓		<i>Start pulse timer</i>	<i>-(SP)</i>	<i>-[SP]</i>	<i>SP</i>	<i>nn</i>
✓	✓	✓		<i>Start extended pulse timer</i>	<i>-(SE)</i>	<i>-[SE]</i>	<i>SE</i>	<i>nn</i>
✓	✓	✓		<i>Enable timer</i>			<i>FR</i>	<i>nn</i>
✓	✓	✓		<i>Load timer value</i>			<i>L</i>	<i>nn</i>
✓	✓	✓		<i>Load BCD-coded timer value</i>			<i>LC</i>	<i>nn</i>
✓	✓	✓		<i>Reset timer</i>	<i>-(R)</i>	<i>-[R]</i>	<i>R</i>	<i>nn</i>
✓	✓	✓		<i>Start on-delay timer</i>	<i>-(SD)</i>	<i>-[SD]</i>	<i>SD</i>	<i>nn</i>
✓	✓	✓		<i>Start retentive on-delay timer</i>	<i>-(SS)</i>	<i>-[SS]</i>	<i>SS</i>	<i>nn</i>

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Counters							
IEC counters							
✓	✓	✓	✓	Count up	CTU	CTU	
✓	✓	✓	✓	Count down	CTD	CTD	
✓	✓	✓	✓	Count up and down	CTUD	CTUD	
<i>Legacy</i>							
✓	✓	✓		<i>Assign parameters and count up</i>	S_CU	nn	S_CU
✓	✓	✓		<i>Assign parameters and count down</i>	S_CD	nn	S_CD
✓	✓	✓		<i>Assign parameters and count up / down</i>	S_CUD	nn	S_CUD
✓	✓	✓		<i>Set counter value</i>	-(SC) -[SC]	nn	nn
✓	✓	✓		<i>Count up</i>	-(CU) -[CU]	CU	nn
✓	✓	✓		<i>Count down</i>	-(CD) -[CD]	CD	nn
✓	✓	✓		<i>Enable counter</i>		FR	nn
✓	✓	✓		<i>Load counter</i>		L	nn
✓	✓	✓		<i>Load BCD-coded counter value</i>		LC	nn
✓	✓	✓		<i>Reset counter</i>		R	nn
✓	✓	✓		<i>Set counter</i>		S	nn
Comparator operations							
✓	✓	✓	✓	Equal	CMP ==	== I/D/R	=
✓	✓	✓	✓	Not equal	CMP <>	<> I/D/R	<>

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Greater or equal	CMP >=	>= I/D/R	>=
✓	✓	✓	✓	Less or equal	CMP <=	<= I/D/R	<=
✓	✓	✓	✓	Greater than	CMP >	> I/D/R	>
✓	✓	✓	✓	Less than	CMP <	< I/D/R	<
		✓	✓	Value within range	IN_RANGE		nn
		✓	✓	Value outside range	OUT_RANGE		nn
		✓	✓	Check validity	- OK -		nn
		✓	✓	Check invalidity	- NOT_OK -		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Variant							
	✓	✓		Check data type of a VARIANT tag			TypeOf
	✓	✓		Check data type of an ARRAY element of a VARIANT tag			TypeOfElements
	✓	✓		Compare data type for EQUAL with the data type of a tag	EQ_Type		*)
	✓	✓		Compare data type of an ARRAY element for EQUAL with the data type of a tag	EQ_ElemType		*)
	✓	✓		Compare data type for UNEQUAL with the data type of a tag	NE_Type		*)
	✓	✓		Compare data type of an ARRAY element for UNEQUAL with the data type of a tag	NE_ElemType		*)
	✓	✓		Check for EQUALS NULL pointer	IS_NULL		*)
	✓	✓		Check for UNEQUALS NULL pointer	NOT_NULL		*)
<p>*) Application examples for SCL: IF TypeOf(...) = INT THEN ... // corresponds to EQ_Type IF TypeOfElements(...) = INT THEN ... // corresponds to EQ_ElemType IF ... <> NULL THEN ... // corresponds to NOT_NULL Other operators can also be used instead of "=", for example: "<>". Instead of "INT" you can also use any other data types or data types that you have defined, for example: "REAL", "Recipe".</p>							
	✓	✓		Check for array	IS_ARRAY		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Math functions							
		✓	✓	Calculate	CALCULATE	nn	nn
✓	✓	✓	✓	Add	ADD	+	+
✓	✓	✓	✓	Subtract	SUB	-	-
✓	✓	✓	✓	Multiply	MUL	*	*
✓	✓	✓	✓	Divide	DIV	/	/
✓	✓	✓	✓	Return remainder of division	MOD		
✓	✓	✓	✓	Create twos complement	NEG	NEGI, NEGD	nn
✓	✓	✓	✓	Create ones complement		INVI, INVD	nn
✓	✓	✓	✓	Increment	INC		nn
✓	✓	✓	✓	Decrement	DEC		nn
✓	✓	✓	✓	Form absolute value	ABS		
✓	✓	✓	✓	Get minimum	MIN		
✓	✓	✓	✓	Get maximum	MAX		
✓	✓	✓	✓	Set limit value	LIMIT		
✓	✓	✓	✓	Form square	SQR		
✓	✓	✓	✓	Form square root	SQRT		
✓	✓	✓	✓	Form natural logarithm	LN		
✓	✓	✓	✓	Form exponential value	EXP		
✓	✓	✓	✓	Form sine value	SIN		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Form cosine value		COS	
✓	✓	✓	✓	Form tangent value		TAN	
✓	✓	✓	✓	Form arcsine value		ASIN	
✓	✓	✓	✓	Form arccosine value		ACOS	
✓	✓	✓	✓	Form arctangent value		ATAN	
		✓	✓	Return fraction	FRAC		FRAC
		✓	✓	Exponentiate	EXPT	**	**
Move							
(✓)	(✓)	✓	✓	Move value S7-300/400: Only LAD and FBD	MOVE	MOVE	:=
✓	✓			Safety only: Write value indirectly to an F-DB	WR_FBD		
✓	✓			Safety only: Read value indirectly from an F-DB	RD_FBD		
		✓	✓	Move data type from ARRAY of BYTE (deserialize)		Deserialize	
		✓	✓	Move data type to ARRAY of BYTE (serialize)		Serialize	
		✓	✓	Move block		MOVE_BLK	
		✓	✓	Move block uninterruptible		UMOVE_BLK	
		✓	✓	Move block		MOVE_BLK_VARIANT	
		✓	✓	Fill block		FILL_BLK	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL		
		✓	✓	Do not fill block uninterruptible		UFILL_BLK			
		✓	✓	Swap		SWAP			
ARRAY DB									
		✓	✓	Read from ARRAY data block		ReadFromArrayDB			
		✓	✓	Write to ARRAY data block		WriteToArrayDB			
		✓	✓	Read from ARRAY data block in load memory		ReadFromArrayDBL			
		✓	✓	Write to ARRAY data block in load memory		WriteToArrayDBL			
Variant									
		✓	✓	Read out VARIANT tag value		VariantGet			
		✓	✓	Write VARIANT tag value		VariantPut			
		✓	✓	Get number of ARRAY elements		CountOfElements			

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Read/write access							
Recommendation: program symbolically							
	✓	✓		Read data in little-endian format		READ_LITTLE	
	✓	✓		Write data in little-endian format		WRITE_LITTLE	
	✓	✓		Read data in big-endian format		READ_BIG	
	✓	✓		Write data in big-endian format		WRITE_BIG	
	✓	✓		Read memory address		PEEK	
	✓	✓		Read memory bit		PEEK_BOOL	
	✓	✓		Write memory address		POKE	
	✓	✓		Write memory bit		POKE_BOOL	
	✓	✓		Write memory area		POKE_BLK	
Legacy							
Recommendation: Program symbolically							
✓	✓	✓		Move block		BLKMOV	
✓	✓	✓		Move block uninterruptible		UBLKMOV	
✓	✓	✓		Fill block		FILL	
	✓	✓		Read field Recommendation: indexed access to an array	FieldRead		
	✓	✓		Write field Recommendation: indexed access to an array	FieldWrite		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Conversion operations							
✓	✓	(✓)	✓	Convert value S7-1200/1500: is applied implicitly and therefore generally not necessary. S7-1200: not as Safety instruction	CONVERT	CONVERT	
✓	✓	✓	✓	Safety only: Convert data from BOOL data type to data of WORD data type	BO_W		
✓	✓	✓	✓	Safety only: Convert data from BOOL data type to data of WORD data type	W_BO		
✓	✓	✓	✓	Round numerical value	ROUND	RND	ROUND
✓	✓	✓	✓	Generate next higher integer from floating-point number	CEIL	RND+	CEIL
✓	✓	✓	✓	Generate next lower integer from floating-point number	FLOOR	RND-	FLOOR
✓	✓	✓	✓	Truncate numerical value	TRUNC		
		✓	✓	Scale	SCALE_X		
		✓	✓	Normalize	NORM_X		
✓	✓		✓	Convert BCD to integer (16 bit)	nn	BTI	BCD16_TO_INT
✓	✓		✓	Convert integer (16 bit) to BCD	nn	ITB	INT_TO_BCD16
✓	✓		✓	Convert BCD to integer (32 bit)	nn	BTD	BCD32_TO_INT

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Convert integer (32 bit) to BCD	nn	DTB	DINT_TO_BCD32
✓	✓	✓	✓	Convert integer (16 bit) to integer (32 bit) S7-1500: The conversion is also performed implicitly	nn	ITD	INT_TO_DINT
✓	✓	✓	✓	Convert integer (32 bit) to floating-point number; S7-1500: The conversion is also performed implicitly	nn	DTR	DINT_TO_REAL
		✓	✓	You can generally convert number formats and data types into other number formats and data types. For additional information, refer to the STEP 7 information system	CONVERT		xxx_TO_yyy
✓	✓		✓	Create ones complement integer (16 bit) S7-1500: The conversion is also performed implicitly	nn	INVI	nn
✓	✓		✓	Create ones complement double integer (32 bit); S7-1500: The conversion is also performed implicitly	nn	INVD	nn
✓	✓		✓	Negate integer (16 bit)	nn	NEGI	nn
✓	✓		✓	Negate integer (32 bit)	nn	NEGD	nn
✓	✓		✓	Negate floating-point number	nn	NEGR	nn

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓		✓	Switch bytes in the right word of accumulator 1	nn	CAW	nn
✓	✓		✓	Switch all bytes in accumulator 1	nn	CAD	nn
Variant							
		✓		Convert VARIANT to DB_ANY		VARIANT_TO_DB_ANY	
		✓		Convert DB_ANY to VARIANT		DB_ANY_TO_VARIANT	
<i>Legacy</i>							
<i>Recommendation: Program symbolically</i>							
✓	✓		✓	Convert integer into a floating-point number which is scaled in physical units between a low and a high limit (scale).	SCALE	SCALE	
✓	✓		✓	Unscale floating-point number into physical units between a low and a high limit and convert into an integer (unscale).		UNSCALE	

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Program control operations							
✓	✓	✓	✓	Run conditionally			IF... THEN...
✓	✓	✓	✓	Branch conditionally			IF... THEN... ELSE...
✓	✓	✓	✓	Branch conditionally multiple times			IF... THEN... ELSIF...
✓	✓	✓	✓	Create multiway branch, execute conditionally			CASE... OF...
✓	✓	✓	✓	Run in counting loop			FOR... TO... DO...
✓	✓	✓	✓	Run in counting loop with step width			FOR... TO... BY... DO...
✓	✓	✓	✓	Run if condition is met			WHILE... DO...
✓	✓	✓	✓	Run if condition is not met			REPEAT... UNTIL...
✓	✓	✓	✓	Recheck loop condition			CONTINUE
✓	✓	✓	✓	Exit loop immediately			EXIT
✓	✓	✓	✓	Exit block	RET	BEU	RETURN
✓	✓	✓	✓	Conditional block end		BEC	nn
✓	✓	✓	✓	Inserting a comment section		//	//, (*...*)
			✓	Only SIMATIC S7-1500 Software Controller CPU 150xS: Shut down or restart Windows and the controller		SHUT_DWN	

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Jumps							
✓	✓	✓	✓	<i>Jump</i>			<i>GOTO...</i>
✓	✓	✓	✓	Jump if RLO = 1	-(JMP) -[JMP]	JC	nn
✓	✓	✓	✓	Jump if RLO = 0	-(JMPN) -[JMPN]	JCN	nn
✓	✓	✓	✓	Jump label	LABEL	:	nn
		✓	✓	Define jump list	JMP_LIST	JL	nn
		✓	✓	Jump distributor	SWITCH		nn
✓	✓	✓	✓	Return	-(RET) -[RET]		nn
✓	✓			Safety only: Open global data block	-(OPN) -[OPN]		nn
✓	✓			Safety only: Open instance data block	-(OPNI) -[OPNI]		nn
✓	✓		✓	Unconditional jump		JU	nn
✓	✓		✓	Jump if RLO = 1 and save RLO	nn	JCB	nn
✓	✓		✓	Jump if RLO = 0 and save RLO	nn	JNB	nn
✓	✓		✓	Jump if BR = 1	nn	JBI	nn
✓	✓		✓	Jump if BR = 0	nn	JNBI	nn
✓	✓		✓	Jump if OV = 1	nn	JO	nn
✓	✓		✓	Jump if OS = 1	nn	JOS	nn
✓	✓		✓	Jump if the result is zero	nn	JZ	nn
✓	✓		✓	Jump if the result is not zero	nn	JN	nn
✓	✓		✓	Jump if the result is greater than zero	nn	JP	nn

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓		✓	Jump if the result is less than zero	nn	JM	nn
✓	✓		✓	Jump if the result is greater than or equal to zero	nn	JPZ	nn
✓	✓		✓	Jump if the result is less than or equal to zero	nn	JMZ	nn
✓	✓		✓	Jump if the result is invalid	nn	JUO	nn
✓	✓		✓	Loop	nn	LOOP	nn
Data blocks							
✓	✓		✓	Open data block in DB register		OPN	nn
✓	✓		✓	Open data block in DI register		OPNI	nn
✓	✓		✓	<i>Swap data block register</i>		<i>CDB</i>	<i>nn</i>
✓	✓		✓	<i>Load the length of a global data block into accumulator 1</i>		<i>L DBLG</i>	<i>nn</i>
✓	✓		✓	<i>Load the number of a global data block into accumulator 1</i>		<i>L DBNO</i>	<i>nn</i>
✓	✓		✓	<i>Load the length of an instance data block into accumulator 1</i>		<i>L DILG</i>	<i>nn</i>
✓	✓		✓	<i>Load the number of an instance data block into accumulator 1</i>		<i>L DINO</i>	<i>nn</i>

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Code blocks							
✓	✓		✓	Call block LAD / FBD: only with S7-300/400	CALL		nn
✓	✓		✓	<i>Conditional block call</i>		CC	nn
✓	✓		✓	<i>Unconditional block call</i>		UC	nn
Runtime control							
			✓	✓	Limit and enable password legitimation	ENDIS_PW	
✓	✓	✓	✓	Restart cycle monitoring time	RE_TRIGR		
✓	✓	✓	✓	Exit program	STP		
			✓	✓	Get error locally	GET_ERROR	
			✓	✓	Get error ID locally	GET_ERR_ID	
✓	✓			Compress CPU memory	COMPRESS		
✓	✓			Control CiR process	CiR		
			✓	✓	Initialize all retain data	INIT_RD	
✓	✓	✓	✓	Configure time delay	WAIT		
✓	✓			Change protection level	PROTECT		
			✓	✓	Measure program runtime LAD and FBD: new	RUNTIME	
✓	✓	✓	✓	Safety only: Fail-safe acknowledgment from an operator control and monitoring system	F_ACK_OP		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Word logic operations							
✓	✓	✓	✓	Create ones complement	INVERT		nn
✓	✓	✓	✓	Decode		DECO	
✓	✓	✓	✓	Encode		ENCO	
✓	✓	✓	✓	Select		SEL	
✓	✓	✓	✓	Multiplex		MUX	
				S7-300/400: SCL only			
		✓	✓	Demultiplex		DEMUX	
✓	✓	✓	✓	AND logic operation word by word	AND	AW	AND, &
✓	✓	✓	✓	OR logic operation word by word	OR	OW	OR
✓	✓	✓	✓	EXCLUSIVE OR logic operation word by word	XOR	XOW	XOR
✓	✓	✓	✓	AND logic operation double word by double word	AND	AD	AND, &
✓	✓	✓	✓	OR logic operation double word by double word	OR	OD	OR
✓	✓	✓	✓	EXCLUSIVE OR logic operation double word by double word	XOR	XOD	XOR
Shift and rotate instructions							
✓	✓	✓	✓	Rotate right		ROR	
✓	✓	✓	✓	Rotate left		ROL	

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Shift right word by word	SHR	SRW	SHR
✓	✓	✓	✓	Shift left word by word	SHL	SLW	SHL
✓	✓		✓	Shift word by word with sign		SSI	nn
✓	✓		✓	Shift double word by double word with sign		SSD	nn
✓	✓		✓	Shift right double word by double word		SRD	nn
✓	✓		✓	Shift left double word by double word		SLD	nn
✓	✓		✓	Rotate right double word by double word	SHR	RRD	SHR
✓	✓		✓	Rotate left double word by double word	SHL	RLD	SHL
✓	✓		✓	Rotate left by status bit CC 1		RLDA	nn
✓	✓		✓	Rotate right by status bit CC 1		RRDA	nn
Load and transfer the registers in STL							
Load							
✓	✓		✓	Load	nn	L	nn
✓	✓		✓	<i>Load status word in accumulator 1</i>		<i>L STW</i>	<i>nn</i>
✓	✓		✓	<i>Load AR1 with contents of accumulator 1</i>		<i>LAR1</i>	<i>nn</i>
✓	✓		✓	<i>Load AR1 with double word or area pointer</i>		<i>LAR1 <D></i>	<i>nn</i>
✓	✓		✓	<i>Load AR1 with contents of AR2</i>		<i>LAR1 AR2</i>	<i>nn</i>
✓	✓		✓	<i>Load AR2 with contents of accumulator 1</i>		<i>LAR2</i>	<i>nn</i>
✓	✓		✓	<i>Load AR2 with double word or area pointer</i>		<i>LAR2 <D></i>	<i>nn</i>

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Transfer							
✓	✓	✓		Transfer	nn	T	nn
✓	✓	✓		<i>Transfer accumulator 1 to status word</i>		<i>T STW</i>	<i>nn</i>
✓	✓	✓		<i>Switch AR1 and AR2</i>		<i>CAR</i>	<i>nn</i>
✓	✓	✓		<i>Transfer AR1 to accumulator 1</i>		<i>TAR1</i>	<i>nn</i>
✓	✓	✓		<i>Transfer AR1 to double word</i>		<i>TAR1 <D></i>	<i>nn</i>
✓	✓	✓		<i>Transfer AR1 to AR2</i>		<i>TAR1 AR2</i>	<i>nn</i>
✓	✓	✓		<i>Transfer AR2to accumulator 1</i>		<i>TAR2</i>	<i>nn</i>
✓	✓	✓		<i>Transfer AR2 to double word</i>		<i>TAR2 <D></i>	<i>nn</i>
Legacy							
✓	✓	✓		Implement sequencer		DRUM	
✓	✓			Implement sequencer		DRUM_X	
✓	✓	✓		Discrete control-timer alarm		DCAT	
✓	✓	✓		Motor control-timer alarm		MCAT	
✓	✓	✓		Compare input bits with the bits of a mask		IMC	
✓	✓	✓		Compare scan matrix		SMC	
✓	✓	✓		Lead and lag algorithm		LEAD_LAG	
✓	✓	✓		Create bit pattern for seven-segment display		SEG	
✓	✓	✓		Create tens complement		BCDCPL	
✓	✓	✓		Count number of set bits		BITSUM	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD		STL (not S7-1200)	SCL
✓	✓			Time accumulator				TONR_X	
✓	✓			Save data to shift register				WSR	
✓	✓			Shift bit to shift register				SHRB	
✓	✓			<i>Get status bit</i>		<i>Status - -</i>		A 0V	nn
✓	✓			<i>Call block</i>		-(CALL)	-[CALL]	UC	nn
✓	✓			<i>Save RLO in BR bit</i>		-(SAVE)	-[SAVE]	SAVE	nn
✓	✓			<i>Open MCR ranges</i>		-(MCR<)	-[MCR<]	MCR(nn
✓	✓			<i>Close MCR ranges</i>		-(MCR>)	-[MCR>])MCR	nn
✓	✓			<i>Enable MCR range</i>		-(MCRA)	-[MCRA]	MCRA	nn
✓	✓			<i>Disable MCR range</i>		-(MCRD)	-[MCRD]	MCRD	nn
✓	✓			<i>Set bit array</i>				SET	
✓	✓			<i>Set byte array</i>				SETI	
✓	✓			<i>Reset bit array</i>				RESET	
✓	✓			<i>Reset byte array</i>				RESETI	
✓	✓			<i>Enter substitute value</i>				REPL_VAL	
✓	✓	✓		<i>Swap content of accumulators 1 and 2</i>		nn		TAK	nn
✓	✓	✓		<i>Shift content to the next higher accumulator</i>		nn		PUSH	nn
✓	✓	✓		<i>Shift content to the next lower accumulator</i>		nn		POP	nn
✓	✓	✓		<i>Add accumulator 1 to AR1</i>		nn		+AR1	nn
✓	✓	✓		<i>Add accumulator 1 to AR2</i>		nn		+AR2	nn

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓		✓	Program display (null instruction)	<i>nn</i>	<i>BLD</i>	<i>nn</i>
✓	✓		✓	Null instruction	<i>nn</i>	<i>NOP 0</i>	<i>nn</i>
✓	✓		✓	Null instruction	<i>nn</i>	<i>NOP 1</i>	<i>nn</i>

Instructions in the section "Advanced instructions"

Instruction groups	Page	Instruction groups	Page	Instruction groups	Page
Date and time	32	Module parameter assignment	39	Recipes & data logging	43
String and Character	34	Interrupts	39	Data block functions	44
Process image	36	Alarms	41	Table functions	44
Distributed I/O	36	Diagnostics	42	Addressing	45
PROFenergy	38	Pulse	43	Additional instructions	46

S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Date and time							
✓	✓		✓	Compare time tags		T_COMP*	
✓	✓	✓	✓	Convert times and extract		T_CONV*	
✓	✓	✓	✓	Add times		T_ADD*	
✓	✓	✓	✓	Subtract times		T_SUB*	
✓	✓	✓	✓	Time difference		T_DIFF*	
✓	✓		✓	Combine times		T_COMBINE*	

* SCL: Use conversion functions x_TO_y (z. B. TIME_TO_DINT) or comparator and math functions (e.g. +, -, >, <).

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Time-of-day functions							
✓	✓	✓	✓	Set time-of-day		WR_SYS_T	
✓	✓	✓	✓	Read time-of-day		RD_SYS_T	
		✓	✓	Read local time		RD_LOC_T	
		✓	✓	Write local time		WR_LOC_T	
			✓	Synchronize slave clocks		SNC_RTCB	
✓	✓		✓	Read system time		TIME_TCK	
		✓	✓	Set time zone		SET_TIMEZONE	
✓	✓	✓	✓	Runtime meters		RTM	
✓	✓			Set runtime meters		SET_RTM	
✓	✓			Start and stop runtime meters		CTRL_RTM	
✓	✓			Read runtime meters		READ_RTM	
	✓			Set time-of-day and time-of-day status		SET_CLKS	
	✓		✓	Synchronize slave clocks		SNC_RTCB	
Local time							
✓	✓			Calculate local time		LOC_TIME	
✓	✓			Calculate local time from base time		BT_LT	
✓	✓			Calculate base time from local time		LT_BT	
✓	✓			Set time-of-day interrupt using local time		S_LTINT	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
✓	✓			Set daylight saving time/standard time without time-of-day status			SET_SW		
✓	✓			Transfer time-stamped alarms			TIMESTAMP		
	✓			Set daylight saving time/standard time with time-of-day status			SET_SW_S		
String and Character									
		✓	✓	Move character string		S_MOVE		:=	
✓	✓			Compare character strings		S_COMP		=	
✓	✓	✓	✓	Convert character string			S_CONV		
		✓	✓	Convert character string to numerical value		STRG_VAL		STRG_...	
		✓	✓	Convert numerical value to character string		VAL_STRG		..._STRG	
		✓	✓	Convert character string to Array of CHAR			Strg_TO_Chars		
		✓	✓	Convert Array of CHAR to character string			Chars_TO_Strg		
		✓	✓	Determine the maximum length of a character string			MAX_LEN		
			✓	Join multiple character strings			JOIN		
			✓	Split character array in multiple strings			SPLIT		
✓	✓	✓	✓	Convert ASCII string to hexadecimal number (conversion is included in the conversion functions, e.g. CHAR_TO_WORD)			ATH		
✓	✓	✓	✓	Convert hexadecimal number to ASCII string			HTA		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Additional instructions							
✓	✓	✓	✓	Determine the length of a character string		LEN	
✓	✓	✓	✓	Combine character strings		CONCAT	
✓	✓	✓	✓	Read the left characters of a character string		LEFT	
✓	✓	✓	✓	Read the right characters of a character string		RIGHT	
✓	✓	✓	✓	Read the middle characters of a character string		MID	
✓	✓	✓	✓	Delete characters in a character string		DELETE	
✓	✓	✓	✓	Insert characters in a character string		INSERT	
✓	✓	✓	✓	Replace characters in a character string		REPLACE	
✓	✓	✓	✓	Find characters in a character string		FIND	
Runtime information							
	✓	✓		Read out name of a tag in the input parameter		GetSymbolName	
		✓		Query combined global name of input parameter assignment		GetSymbolPath	
	✓	✓		Read out name of the block instance		GetInstanceName	
		✓		Query combined global name of the block instance		GetInstancePath	
	✓	✓		Read out name of the block		GetBlockName	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
Process image									
	✓		✓	Update the process image inputs			UPDAT_PI		
	✓		✓	Update the process image outputs			UPDAT_PO		
✓	✓		✓	Synchronize the process image inputs			SYNC_PI		
✓	✓		✓	Synchronize the process image outputs			SYNC_PO		
Distributed I/O									
DP & PROFINET									
✓	✓	✓	✓	Read data record			RDREC		
✓	✓	✓	✓	Write data record			WRREC		
✓	✓		✓	Read process image			GETIO		
✓	✓		✓	Transfer process image			SETIO		
✓	✓		✓	Read process image area			GETIO_PART		
✓	✓		✓	Transfer process image area			SETIO_PART		
✓	✓	✓	✓	Receive interrupt			RALRM		
✓	✓		✓	Enable/disable DP slaves			D_ACT_DP		
			✓	Reconfigure IO system To do this, switch modules on or off in order to, for example, flexibly run through or bridge the production steps of a manufacturing process.			ReconfigIOSystem		

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
Additional instructions									
✓	✓		✓	Read data record from I/O			RD_REC		
✓	✓		✓	Write data record to I/O			WR_REC		
✓	✓	✓	✓	Read consistent data of a DP standard slave			DPRD_DAT		
✓	✓	✓	✓	Write consistent data of a DP standard slave			DPWR_DAT		
iDevice / iSlave									
✓			✓	Receive data record			RCVREC		
✓			✓	Make data record available			PRVREC		
✓				Send interrupt			SALRM		
PROFIBUS									
✓	✓			Trigger hardware interrupt from DP standard slave			DP_PRAL		
✓	✓		✓	Synchronize DP slaves / Freeze inputs			DPSYC_FR		
✓	✓	✓	✓	Read diagnostics data from a DP slave			DPNRM_DG		
✓	✓		✓	Determine topology for DP master system			DP_TOPOL		
ASi									
✓	✓			Control ASi master behavior			ASi_3422		
✓	✓		✓	Control ASi master behavior			ASi_CTRL		

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
PROFenergy									
IO controller									
✓	✓	✓		Start and exit energy-saving mode			PE_START_END		
✓	✓	✓		Start and exit energy-saving mode / Read out status information			PE_CMD		
✓	✓	✓		Set the switching response of the power modules			PE_DS3_WRITE_ET200S		
✓	✓	✓		Start and exit energy-saving mode using WakeOnLan			PE_WOL		
iDevice / iSlave									
✓		✓		Control PROFenergy commands in the I-Device			PE_I_DEV		
✓		✓		Generate negative answer to command			PE_Error_RSP		
✓		✓		Generate answer to command at start of pause			PE_Start_RSP		
✓		✓		Generate answer to command at end of pause			PE_End_RSP		
✓		✓		Generate queried energy savings modes as answer			PE_List_Modes_RSP		
✓		✓		Generate queried energy data as answer			PE_Get_Mode_RSP		
✓		✓		Generate PEM status as answer			PE_PEM_Status_RSP		
✓		✓		Generate number of PROFenergy commands as answer			PE_Identify_RSP		

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
✓			✓	Generate list of supported measured values as answer			PE_Measurement_List_RSP		
✓			✓	Generate queried measured values as answer			PE_Measurement_Value_RSP		
Module parameter assignment									
✓	✓		✓	Read module data record			RD_DPAR		
✓			✓	Read module data record asynchronously			RD_DPARA		
✓	✓			Transfer module data records			PARM_MOD		
			✓	Read data record from configured system data			RD_DPARM		
✓	✓			Write module data record			WR_PARM		
✓	✓		✓	Transfer data record			WR_DPARM		
Interrupts									
	✓		✓	Attach an OB to an interrupt event			ATTACH		
	✓		✓	Detach an OB from an interrupt event			DETACH		
Cyclic interrupt									
	✓		✓	Set cyclic interrupt parameters			SET_CINT		
	✓		✓	Query cyclic interrupt parameters			QRY_CINT		
Time-of-day interrupt									
✓	✓	✓	✓	Set time-of-day interrupt			SET_TINT		
			✓	Set time-of-day interrupt			SET_TINTL		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Cancel time-of-day interrupt		CAN_TINT	
✓	✓	✓	✓	Enable time-of-day interrupt		ACT_TINT	
✓	✓	✓	✓	Query status of time-of-day interrupt		QRY_TINT	
Time-delay interrupt							
✓	✓	✓	✓	Start time-delay interrupt		SRT_DINT	
✓	✓	✓	✓	Cancel time-delay interrupt		CAN_DINT	
✓	✓	✓	✓	Query time-delay interrupt status		QRY_DINT	
Synchronous error events							
✓	✓		✓	Mask synchronous error events		MSK_FLT	
✓	✓		✓	Unmask synchronous error events		DMSK_FLT	
✓	✓		✓	Read out event status register		READ_ERR	
Asynchronous error event							
✓	✓		✓	Disable interrupt event		DIS_IRT	
✓	✓		✓	Enable interrupt event		EN_IRT	
✓	✓	✓	✓	Delay execution of higher priority interrupts and asynchronous error events		DIS_AIRT	
✓	✓	✓	✓	Enable execution of higher priority interrupts and asynchronous error events		EN_AIRT	
	✓			Trigger multicomputing interrupt		MP_ALM	

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Alarms							
	✓			Generate program alarm with associated values		Program_Alarm	
	✓			Get alarm status		Get_AlarmState	
	✓			Generate user diagnostics alarm that will be entered in the diagnostics buffer.		Gen_UsrMsg	
✓	✓			<i>Generate alarm message</i>		<i>ALARM_S</i>	
✓	✓			Generate alarm message with acknowledgment		ALARM_SQ	
✓	✓			Create permanently acknowledged PLC alarms D stands for Diagnostics (can be diagnosed) or also for Delete (deletable)		ALARM_D	
✓	✓			Create acknowledgeable PLC alarms D stands for Diagnostics (can be diagnosed) or also for Delete (deletable)		ALARM_DQ	
✓	✓			Determine the acknowledgment status of the last ALARM_SQ incoming alarm S stands for short and C for check		ALARM_SC	
✓	✓			Write a user diagnostics event to the diagnostics buffer Write user message		WR_USMSG	

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓				Report up to eight signal changes P stands for process (associated values)		NOTIFY_8P	
✓				Create PLC alarms without associated values for eight signals		ALARM_8	
✓				Create PLC alarms with associated values for eight signals P stands for process (associated values)		ALARM_8P	
✓				Report a signal change		NOTIFY	
✓				Create PLC alarms with acknowledgment display		ALARM	
✓				Send archive data		AR_SEND	
Additional instructions							
✓	✓			Read out dynamically assigned system resources		READ_SI	
✓	✓			Delete dynamically assigned system resources		DEL_SI	
	✓			Enable PLC alarms		EN_MSG	
	✓			Disable PLC alarms		DIS_MSG	
Diagnostics							
✓	✓	✓		Read current OB start information		RD_SINFO	
		✓		Read out runtime statistics		RT_INFO	
	✓			Determine OB program runtime		OB_RT	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
	✓			Determine current connection status			C_DIAG		
✓	✓			Read system status list			RDSYSST		
		✓	✓	Read LED status			LED		
			✓	Read out name of a module			Get_Name		
			✓	Read out information of an IO device			GetStationInfo		
		✓	✓	Read module status information of an IO system			DeviceStates		
		✓	✓	Read module status information of a module			ModuleStates		
			✓	Generate diagnostics information			GEN_DIAG		
		✓	✓	Read diagnostics information			GET_DIAG		
Pulse									
		✓		Pulse width modulation			CTRL_PWM		
Recipes & data logging									
Recipe functions									
	✓	✓		Export recipe			RecipeExport		
	✓	✓		Import recipe			RecipeImport		
Data logging									
	✓	✓		Create data log			DataLogCreate		
	✓	✓		Open data log			DataLogOpen		
	✓	✓		Write data log			DataLogWrite		

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
			✓	Empty data log			DataLogClear		
		✓	✓	Close data log			DataLogClose		
			✓	Delete data log			DataLogDelete		
		✓	✓	Data log in new file			DataLogNewFile		
Data block functions									
✓				Create data block			CREAT_DB		
			✓	Create data block			CREATE_DB		
✓				Create data block in the load memory			CREA_DBL		
✓		✓	✓	Read from data block in the load memory			READ_DBL		
✓	✓	✓	✓	Write to data block in the load memory			WRIT_DBL		
			✓	Read data block attributes			ATTR_DB		
✓	✓			Delete data block			DEL_DB		
			✓	Delete data block			DELETE_DB		
✓	✓			Test data block			TEST_DB		
Table functions									
✓	✓			Add value to table			ATT		
✓	✓			Output first value of the table			FIFO		
✓	✓			Find value in table			TBL_FIND		
✓	✓			Output last value of the table			LIFO		

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
✓	✓			Execute table instruction			TBL		
✓	✓			Copy value from table			TBL_WRD		
✓	✓			Link value logically with table element and save			WRD_TBL		
✓	✓			Calculate standard deviation			DEV		
✓	✓			Correlated data tables			CDT		
✓	✓			Link tables			TBL_TBL		
✓	✓			Collect/distribute table data			PACK		
Addressing									
		✓	✓	Determine the hardware ID from the slot			GEO2LOG		
		✓	✓	Determine the slot from the hardware ID			LOG2GEO		
		✓	✓	From the addressing of STEP 7 V5.5 SPx, determine the hardware ID			LOG2MOD		
			✓	Determine the hardware ID from an IO address			IO2MOD		
		✓	✓	Determine the IO addresses from the hardware ID			RD_ADDR		
Additional instructions									
✓	✓		✓	Determine start address of a module S7-1500: only exists to provide compatibility - not recommended			GEO_LOG		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓	✓	Determine the module slot belonging to a logical address S7-1500: only exists to provide compatibility - not recommended		LOG_GEO	
✓	✓	✓	✓	Determine the IO addresses from the hardware ID		RD_LGADR	
✓	✓	✓	✓	Determine hardware identifier from slot and offset in the user data address area		GADR_LGC	
✓	✓	✓	✓	Determine slot from hardware identifier S7-1500: only exists to provide compatibility - not recommended		LGC_GADR	
Additional instructions							
iSlave							
✓				Set network address as own iSlave		SET_ADDR	

Basic instructions

Extended instructions

Technology

Communication

Instructions in the section "Technology"

Instruction groups	Page	Instruction groups	Page	Instruction groups	Page
Counting (and measuring)	48	Function modules	49	Time-controlled inputs/outputs	50
PID control – compact PID	48	S7-300C functions	50	Motion control	51

S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Counting (and measuring)				
✓	Control fast counters		CTRL_HSC	
✓	Fast counter for counting, measuring and position detection		High_Speed_Counter	
PID control				
Compact PID				
✓	✓ Universal PID controller with integrated optimization for low hydraulic actuators		PID_Compact	
✓	✓ PID controller with integrated optimization for valves and actuators		PID_3Step	
✓	✓ Temperature controller with integrated optimization for temperature processes		PID_Temp	

Basic instructions		Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
PID basic functions							
✓	✓	✓		Continuous controller		CONT_C	
✓	✓	✓		Step controller for integrating actuators		CONT_S	
✓	✓	✓		Pulse generator for proportional actuators		PULSEGEN	
✓	✓	✓		Continuous temperature controller with pulse generator		TCONT_CP	
✓	✓	✓		Temperature controller for integrating actuators		TCONT_S	
✓	✓			Automatic optimization for a continuous controller		TUN_EC	
✓	✓			Automatic optimization for a step controller		TUN_ES	
Integrated system functions							
✓	✓			Continuous controller		CONT_C_SF	
✓	✓			Step controller for integrating actuators		CONT_S_SF	
✓	✓			Pulse generator for proportional actuators		PULSGEN_SF	
Function modules							
✓	✓			Various instructions FM modules counting / positioning / cam control / PID control / temperature control		✓	

Basic instructions		Extended instructions	Technology		Communication
S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL	
S7-300C functions					
✓	Position with analog output		ANALOG		
✓	Position with digital output		DIGITAL		
✓	Control counter		COUNT		
✓	Control frequency measurement		FREQUENC		
✓	Control pulse width modulation		Pulse		
Time-controlled inputs/outputs					
✓	Synchronize TIO module		TIO_SYNC		
✓	Read in process input signals with time stamp		TIO_IOLink_IN		
✓	Read in edges on digital input and associated time stamp		TIO_DI		
✓	Output process output signals time-controlled		TIO_IOLink_OUT		
✓	Output edges at digital output time-controlled		TIO_DQ		

Basic instructions		Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Motion control							
S7-1x00 motion control							
	✓	✓		Enable axis		MC_Power	
	✓	✓		Acknowledge error		MC_Reset	
	✓	✓		Reference axis		MC_Home	
	✓	✓		Stop axis		MC_Halt	
	✓	✓		Move axis to absolute position		MC_MoveAbsolute	
	✓	✓		Move axis to relative position		MC_MoveRelative	
	✓	✓		Traverse axis at set velocity		MC_MoveVelocity	
	✓	✓		Traverse axis in jog mode		MC_MoveJog	
	✓			Execute axis jobs as motion sequence		MC_CommandTable	
	✓			Change dynamic settings of the axis		MC_ChangeDynamic	
	✓			Write tag of positioning axis		MC_WriteParam	
	✓			Continuously read dynamic data of a positioning axis		MC_ReadParam	

Instructions in the section "Communication"

Instruction groups	Page	Instruction groups	Page	Instruction groups	Page
PROFINET and PROFIBUS	52	Fail-safe HMI Panels	55	Communication w. iSlave /iDevice	66
S7 communication	52	Modbus TCP	56	PROFINET CBA	66
Open User Communication	54	Communications processors	57	MPI communication	66
WEB server	55	S7-300C functions	65	TeleService	67

S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
PROFINET and PROFIBUS				
✓ ✓ ✓	Safety only: Fail-safe sending of data via PROFIBUS DP/PROFINET IO	SENDDP		
✓ ✓ ✓	Safety only: Fail-safe receiving of data via PROFIBUS DP/PROFINET IO	RCVDP		
S7 communication				
✓ ✓ ✓ ✓	<i>Read data from a remote CPU</i>		GET	
✓ ✓ ✓ ✓	<i>Write data to a remote CPU</i>		PUT	
✓ ✓ ✓	Send data uncoordinated		USEND	

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓		Receive data uncoordinated		URCV	
✓	✓	✓		Send data in segments		BSEND	
✓	✓	✓		Receive data in segments		BRCV	
✓				Query connection status		C_CNTRL	
✓	✓			Safety only: Fail-safe sending of data via S7 connections	SENDS7		
✓	✓			Safety only: Fail-safe receiving of data via S7 connections	RCVS7		
Additional instructions					Note: S stands for short, because only one parameter is possible		
✓	✓			Read data from a remote CPU		GET_S	
✓	✓			Write data to a remote CPU		PUT_S	
✓	✓			Send data uncoordinated		USEND_S	
✓	✓			Receive data uncoordinated		URCV_S	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
Open User Communication									
	✓	✓		Manage the communications connection and send data via Ethernet			TSEND_C		
	✓	✓		Manage the communications connection and receive data via Ethernet			TRCV_C		
		✓	✓	Manage the communications connection and transfer e-mail			TMAIL_C		
Additional instructions									
✓	✓	✓	✓	Establish communications connection			TCON		
✓	✓	✓	✓	Terminate communications connection			TDISCON		
✓	✓	✓	✓	Send data via communications connection			TSEND		
✓	✓	✓	✓	Receive data via communications connection			TRCV		
		✓	✓	Reset connection			T_RESET		
		✓	✓	Check connection			T_DIAG		
		✓	✓	Configure interface			T_CONFIG		
✓	✓			Program-controlled IP and connection configuration via SEND/RECEIVE			IP_CONFIG		
✓	✓	✓	✓	Send data via Ethernet (UDP)			TUSEND		
✓	✓	✓	✓	Receive data via Ethernet (UDP)			TURCV		

Basic instructions		Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓			Change IP configuration parameters		IP_CONF	
✓	✓			Exchange data using FETCH and WRITE via TCP		FW_TCP	
✓	✓			Exchange data using FETCH and WRITE via ISO-on-TCP		FW_IOT	
WEB server							
✓	✓	✓	✓	Synchronize user-defined Web pages		WWW	
Fail-safe HMI Panels							
✓	✓		✓	For Mobile Panel 277 F IWLAN: Communication via PROFISafe with connected device	F_FB_MP		
✓	✓		✓	For Mobile Panel 277 F IWLAN: Managing up to 4 panels in the effective range	F_FB_RNG_4		
✓	✓		✓	For Mobile Panel 277 F IWLAN: Managing up to 16 panels in the effective range	F_FB_RNG_16		
✓	✓		✓	For second-generation mobile panels: Communication via PROFISafe with connected device	F_FB_KTP_ Mobile		

Basic instructions		Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓	✓		For second-generation mobile panels: Managing panels in the effective range	F_FB_KTP_RNG		
Modbus TCP							
	✓	✓		Communicate as Modbus TCP client via PROFINET		MB_CLIENT	
	✓	✓		Communicate as Modbus TCP server via PROFINET		MB_SERVER	
✓	✓			Establish communication between a CPU with an integrated PN interface and a partner that supports the Modbus/TCP protocol.		MODBUSPN	
✓	✓			Connection management		TCP_COMM	
✓	✓			Communicate as Modbus TCP client via Ethernet		MOD_CLI	
✓	✓			Communicate as Modbus TCP server via Ethernet		MOD_SRV	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD		STL (not S7-1200)	
								SCL	
Communications processors									
Not for SIMATIC S7-1500 Software Controller CPU 150xS									
Point-to-point or PtP communication									
S7-300/400: Commands for ET200SP CM PtP									
		✓		Configured communications parameters dynamically				PORT_CFG	
✓	✓	✓	✓	Configure PtP communications port S7-300/400: only when using an ET200SP CM PtP				Port_Config	
		✓		Configure serial transmission parameters dynamically				SEND_CFG	
✓	✓	✓	✓	Configure PtP sender				Send_Config	
		✓		Configure serial receive parameters dynamically				RCV_CFG	
✓	✓	✓	✓	Configure PtP recipient				Receive_Config	
✓	✓	✓	✓	Configure protocol				P3964_Config	
				Transfer data of the send buffer				SEND_PTP	
✓	✓	✓	✓	Send data				Send_P2P	
		✓		Enable receipt of messages				RCV_PTP	

Basic instructions				Extended instructions	Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL	
✓	✓	✓	✓	Receive data		Receive_P2P		
				Delete receive buffer		RCV_RST		
✓	✓	✓	✓	Delete receive buffer		Receive_Reset		
				Query RS-232 signals		SGN_GET		
✓	✓	✓	✓	Read status		Signal_Get		
				Set RS-232 signals		SGN_SET		
✓	✓	✓	✓	Set accompanying signals		Signal_Set		
✓	✓	✓	✓	Get extended functions		Get_Features		
✓	✓	✓	✓	Set extended functions		Set_Features		
USS communication								
S7-300/400: Commands for ET200SP CM PtP								
			✓	Edit communication via USS network		USS_PORT		
✓	✓	✓	✓	Communication by means of a USS network		USS_Port_Scan		
			✓	Prepare and display data for the drive		USS_Drive		
✓	✓	✓	✓	Data exchange with the drive		USS_Drive_Control		
			✓	Read out parameters from the drive		USS_RPM		
✓		✓	✓	Read data from drive		USS_Read_Param		
			✓	Change parameters in the drive		USS_WPM		
✓	✓	✓	✓	Change data in drive		USS_Write_Param		

Basic instructions				Extended instructions				Technology				Communication							
S7-300	S7-400	S7-1200	S7-1500	Description				LAD / FBD				STL (not S7-1200)				SCL			
MODBUS (RTU)																			
S7-300/400: Commands for ET200SP CM PtP																			
			✓	Configure port on the PtP module for Modbus RTU								MB_COMM_LOAD							
✓	✓	✓	✓	Configure communications module for Modbus								Modbus_Comm_Load							
			✓	Communicate as Modbus master via PtP port								MB_MASTER							
✓	✓	✓	✓	Communicate as Modbus master								Modbus_Master							
			✓	Communicate as Modbus slave via PtP port								MB_SLAVE							
✓	✓	✓	✓	Communicate as Modbus slave								Modbus_Slave							
PtP link: CP 340																			
✓	✓			Receive data								P_RCV							
✓	✓			Send data								P_SEND							
✓	✓			Output message text with up to 4 tags on printer								P_PRINT							
✓	✓			Delete receive buffer								P_REST							
✓	✓			Read accompanying signals on the RS-232C interface								V24_STAT_340							
✓	✓			Read accompanying signals on the RS-232C interface								V24_SET_340							

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
PtP link: CP 341							
✓	✓			Receive data or make data available		P_RCV_RK	
✓	✓			Send or fetch data		P_SND_RK	
✓	✓			Output message text with up to 4 tags on printer		P_PRT341	
✓	✓			Read accompanying signals on the RS-232C interface		V24_STAT	
✓	✓			Write accompanying signals on the RS-232C interface		V24_SET	
PtP link: CP 440							
✓	✓			Receive data		RECV_440	
✓	✓			Send data		SEND_440	
✓	✓			Delete receive buffer		RES_RECV	
PtP link: CP 441							
✓	✓			Read accompanying signals on the RS-232C interface		V24_STAT_441	
✓	✓			Write accompanying signals on the RS-232C interface		V24_SET_441	

Basic instructions				Extended instructions	Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL	
MODBUS slave (RTU)								
✓	✓			Modbus slave instruction for CP 341		MODB_341		
✓	✓			Modbus slave instruction for CP 441		MODB_441		
MODBUS: CP 443								
✓	✓			Establish communication between a CP and a partner that supports the OPEN MODBUS/TCP protocol		MODBUSCP		
✓	✓			Communicate as Modbus client		MB_CPCLI		
✓	✓			Communicate as Modbus server		MB_CPSRV		
ET 200S serial interface						Note: S stands for serial		
✓	✓		✓	Receive data		S_RCV		
✓	✓		✓	Send data		S_SEND		
✓	✓		✓	Read accompanying signals on the RS-232C interface		S_VSTAT		
✓	✓		✓	Write accompanying signals on the RS-232C interface		S_VSET		
✓	✓		✓	Set data flow control using XON/XOFF		S_XON		
✓	✓		✓	Set data flow control using RTS/CTS		S_RTS		

Basic instructions				Extended instructions	Technology	Communication	
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓		✓	Set data flow control using auto. control of the RS-232C accompanying signals		S_V24	
✓	✓		✓	Modbus slave instruction for ET 200S 1SI		S_MODB	
✓	✓		✓	Send data to a USS slave		S_USST	
✓	✓		✓	Receive data from a USS slave		S_USSR	
✓	✓		✓	Initialize USS		S_USSI	
SIMATIC NET CP							
Open User Communication							
✓	✓			Transfers data to the CP for transmission via a configured connection		AG_SEND	
✓	✓			Transfers jobs to the CP to accept received data		AG_RECV	
✓	✓			Blocks the data exchange via a connection using FETCH/WRITE		AG_LOCK	
✓	✓			Diagnostics of connections		AG_UNLOCK	
✓	✓			Diagnostics of connections		AG_CNTRL	
✓	✓			Connection diagnostics, connection establishment, ping request		AG_CNTEX	

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
PROFIBUS DP							
✓	✓			Data transfer to the CP as DP master or DP slave		DP_SEND	
✓	✓			Receipt of data from the CP as DP master or DP slave		DP_RECV	
✓	✓			Request for diagnostics information		DP_DIAG	
✓	✓			Transfer of control information to the PROFIBUS CP		DP_CTRL	
PROFINET IO							
✓	✓			Data transfer to the CP as IO controller or IO device		PNIO_SEND	
✓	✓			Receipt of data from the CP as IO controller or IO device		PNIO_RECV	
✓	✓			Read data record or write data record in the IO controller		PNIO_RW_REC	
✓	✓			Alarm evaluation by the CP 343-1 as IO controller		PNIO_ALARM	

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
PROFenergy							
✓	✓			Start or end the energy-saving pause		PE_START_END_CP	
✓	✓			Extended starting or ending of the energy-saving pause		PE_CMD_CP	
✓	✓			Handling of the commands of the IO controller in the PROFenergy device		PE_I_DEV_CP	
✓	✓			Transfer of the switch setting of power modules to ET 200S		PE_DS3_Write_ET200_CP	
Additional instructions							
✓	✓			Use of a logical trigger for ERPC communication		LOGICAL_TRIGGER	
✓	✓			Setup of FTP connections from and to an FTP server		FTP_CMD	

Basic instructions		Extended instructions	Technology	Communication	
S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL	
GPRSComm:CP 1242-7					
✓	Establish connection via the GSM network		TC_CON		
✓	Terminate connection via the GSM network		TC_DISCON		
✓	Send data via the GSM network		TC_SEND		
✓	Receive data via the GSM network		TC_RECV		
✓	Transfer configuration data to CP		TC_CONFIG		
S7-300C functions					
ASCII, 3964®					
✓	Send data (ASCII, 3964®)		SEND_PTP_300C		
✓	Receive data (ASCII, 3964®)		RCV_PTP_300C		
✓	Reset input buffer (ASCII, 3964®)		RES_RCVB_300C		
RK 512					
✓	Send data (RK 512)		SEND_RK_300C		
✓	Fetch data (RK 512)		FETCH_RK_300C		
✓	Receive data and make available (RK 512)		SERVE_RK_300C		

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
Communication with iSlave							
✓	✓			Read data of a communications partner within own S7 station		I_GET	
✓	✓			Write data of a communications partner within own S7 station		I_PUT	
✓	✓			Abort connection to the communications partner within own S7 station		I_ABORT	
PROFINET CBA							
✓	✓			Update inputs of the user program interface		PN_IN	
✓	✓			Update outputs of the user program interface		PN_OUT	
✓	✓			Break DP interconnections		PN_DP	
MPI communication					Note: X stands for the MPI interface		
✓	✓			Send data to communications partner outside own S7 station		X_SEND	
✓	✓			Receive data from communications partner outside own S7 station		X_RCV	
✓	✓			Read data from communications partner outside own S7 station		X_GET	

Basic instructions		Extended instructions	Technology	Communication			
S7-300	S7-400	S7-1200	S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
✓	✓			Write data to communications partner outside own S7 station		X_PUT	
✓	✓			Abort existing connection to the communications partner outside own S7 station		X_ABORT	
TeleService							
		✓		Transfer e-mail		TM_Mail	
✓	✓			Establish remote connection to PG/PC		PG_DIAL	
✓	✓			Establish remote connection to AS		AS_DIAL	
✓	✓			Send SMS message		SMS_SEND	
✓	✓			Transfer e-mail		AS_MAIL	

Basic instructions

Extended instructions

Technology

Communication

Appendix: optional instructions

S7-300 S7-400 S7-1200 S7-1500	Description	LAD / FBD	STL (not S7-1200)	SCL
SIMATIC Ident				
✓ ✓ ✓ ✓	Read data from transponder		Read	
✓ ✓ ✓ ✓	Read out data from code reading system		Read_MV	
✓ ✓ ✓ ✓	Reset reader		Reset_Reader	
✓ ✓ ✓ ✓	Set program on the code reading system		Set_MV_Program	
✓ ✓ ✓ ✓	Write data to the transponder		Write	
Status queries				
✓ ✓ ✓ ✓	Read out status of the reader		Reader_Status	
✓ ✓ ✓ ✓	Read out status of the transponder		Tag_Status	
Extended functions				
✓ ✓ ✓ ✓	Download configuration data to the reader		Config_Download	
✓ ✓ ✓ ✓	Back up configuration data of the reader		Config_Upload	
✓ ✓ ✓ ✓	Detect transponder population		Inventory	
✓ ✓ ✓ ✓	Read out EPC memory data of a transponder		Read_EPC_Mem	
✓ ✓ ✓ ✓	Read out TID memory data of a transponder		Read_TID	
✓ ✓ ✓ ✓	Read out UID of a HF transponder		Read_UID	
✓ ✓ ✓ ✓	Switch on/off antennas of RF300 readers		Set_ANT_RF300	

Basic instructions				Extended instructions		Technology		Communication	
S7-300	S7-400	S7-1200	S7-1500	Description		LAD / FBD	STL (not S7-1200)	SCL	
✓	✓	✓	✓	Switch on/off antennas of RF620R/RF630R			Set_ANT_RF600		
✓	✓	✓	✓	Set UHF parameters in the reader			Set_Param		
✓	✓	✓	✓	Write EPC ID of a UHF transponder			Write_EPC_ID		
✓	✓	✓	✓	Write to EPC memory of a UHF transponder			Write_EPC_Mem		
✓	✓	✓	✓	Ident function for trained users with command transfer to a data structure			Advanced_CMD		
✓	✓	✓	✓	Sophisticated Ident function for experts with all commands and options			Ident_Profile		
Additional reset functions									
✓	✓	✓	✓	Reset MOBY D reader			Reset_MOBY_D		
✓	✓	✓	✓	Reset MOBY U reader			Reset_MOBY_U		
✓	✓	✓	✓	Reset MV code reader			Reset_MV		
✓	✓	✓	✓	Reset RF200 reader			Reset_RF200		
✓	✓	✓	✓	Reset RF300 reader			Reset_RF300		
✓	✓	✓	✓	Reset RF600 reader			Reset_RF600		
✓	✓	✓	✓	Reset function for experts allows universally adjustable parameters			Reset_Un		

Siemens AG
Digital Factory
Postfach 48 48
90026 Nuremberg
GERMANY

www.siemens.com/automation

Subject to change without prior notice.
A5E33285102-AB
© Siemens AG 2014