# Operating Mechanisms, Disconnect Switches, and Door-Closing Mechanisms

Catalog 9420CT9701R03/21 **2021** 



#### CONTENTS

Description Page
How to Order
Class 9422 Devices
Flange-Mounted, Variable-Depth, and Cable-Operated Disconnect Switches Page 4
Bracket-Mounted Disconnect Devices and Operating Mechanisms
Variable-Depth Mechanisms for Use with Square D Circuit Breakers Page 17
Dual Cable Operating Mechanisms for Square D Circuit Breakers
Accessories for Flange-Mounted, Variable Depth Disconnect Switches Page 31
Class 9421 Devices
Type L Circuit Breaker Mechanisms Page 25
Class 9423 Devices
Door-Closing MechanismsPage 32
Index



## Operating Mechanisms, Disconnect Switches, and Door-Closing Mechanisms How to Order

## How to Order

All Square D<sup>™</sup> switches and circuit breaker mechanisms are lockable in the Off position, and can be used to comply with OSHA requirements for an Energy Isolation Device.



To Order Specify	Catalog Number				
To Order, Spechy:	Class	Туре			
1. Class Number					
2. Type Number					
— OR —					
1. Class Number					
2. Type Number of Switch Body	9421	LN1			
<ol><li>Type Number of Shaft Extension</li></ol>					
4. Type Number of Handle Accessories					
5. Type Number of Door Interlock Plate					
6. Type Number of Any Desired Accessories					



3

9422R Circuit Breaker Mechanism

## Class 9422 Devices

## Flange-Mounted, Variable-Depth, and Cable-Operated Disconnect Switches

The Class 9422 Type TCF, TCN, TDF, TDN, TEF, and TEN disconnect switches were designed for control panel installations. These switches include common switch profile 30–100 A, interchangeable fuse clips 30–60 A, and the ability to add fuse clip kits and cable mechanisms. They are compatible with 9422A handle operators and 9423 door mechanisms, and are UL recognized and CSA certified.

	Variable Depth	Max	kimum I	Horsepo	ower Ra	tatings Fuse Clip Rating (Amperes) Non-Interchangeable		p Rating eres) hangeable	Switch for Use With Cable Operators Only. Does	Switch and Operating Mech. Only.	Switch and Mech and Handle M Overp	l Operating anism /lechanism – acked	
Disconnect Switch Size	Mounting Range Min.–Max. (in.)	AC S	ystems Vo	Volts (I Its)	lotor DC Using 2 Poles 250 V		DC Type Using 2 Poles 250 V		pe s H, J, K ses Only	Not Include Handle Mech. or Cable Operator. <sup>1</sup>	Include Handle Mechanism	Includes Type A1 Handle Mechanism	Includes Type A2 Handle Mechanism
		208 (200)	240 (230)	480 (460)	600 (575)	Max.		250 V	600 V	Туре	Туре	Туре	Туре
							None	—	_	TCN30C	TCN30	ATCN301	ATCN302
30 A	6.63–18	7.5	7.5	15	20	5	цкір	30		TCF30C	TCF30	ATCF301	_
							п, к, ј, к		30	TCF33C	TCF33	ATCF331	ATCF332
							None	_	_	—	TDN60	ATDN601	ATDN602
60 A	6.63–18	15	15	30	50	10	нкір	60	30	—	TDF60	ATDF601	ATDF602
						п, к, ј,	11, 17, 0, 17	-	60	TDF63C	TDF63	ATDF631	ATDF632
100 4	6.63-18	25	30	60	75	20	20 None	_		TEN10C	TEN10	ATEN101	_
100 A	0.00-10	20	50	50	, 5	20	H, K, J, R	100	100	TEF10C	TEF10	ATEF101	ATEF102
200–400 A						See 9	9422 TF and	TG Disconn	ect Switches	on page 6.			

<sup>1</sup> See below for cable operator ordering information.



Class 9422 Replacement/Retrofit Fuse Clip Kits

Disconnect Switch Size	Switch Type	Fuse Type	Fuse Clip Rating (A)		Line and Load Fuse Clip Kit (Includes Load Base and Fusepullers)
			250 V	600 V	Туре
	TCF30	нкј	30	_	
30 A	TCN30 TCF33	R	60	30	TC33
60.4	TONICO	H, K, J,	60	30	TC33
00 A	1 DINOU	R	-	60	TD63

#### **Class 9999 Electrical Interlocks**

Disconnect	Switch	Electrical	Interlock
Switch Size	Types	Contacts	Туре
	TCF, TCN	SPDT <sup>1</sup>	TC10
30 A	TDF, TDN TEF, TEN	DPDT <sup>2</sup>	TC20
100 A	BTCF, BTCN	SPDT <sup>1</sup>	TC11
100 //	BTDF, BTDN BTEF, BTEN	DPDT <sup>2</sup>	TC21

<sup>1</sup> 1 N.C. or 1 N.O. depending on wiring.

<sup>2</sup> 2 N.C., 2 N.O. or 1 N.O., 1 N.C. depending on wiring.

Class R Fuse Clip Kits

Disconnect	Switch Type	Fuse Type	Fuse Clip F	Rating (AIR)	Rejection Feature – Class R Kit
Switch Size			250 V	600 V	Type <sup>1</sup>
20.4	TCF30	R	30	—	RFK03
30 A	TCF33	R	60	30	RFK06
60 4	TDF60	R	60	30	RFK06
60 A	TDF63	R	—	60	RFK06H
100 A	TEF10	R	100	100	RFK10

<sup>1</sup> No Class Number required.

1

Class 9422 Disconnect Switch Cable Operators (must purchase switch separately)

01	File E52639	Disconnect	Switch Tupos		Cable Mechanisms	Cable Mechanisms with A1 Handle for Types 1, 3, 3R, 12	
	CCN: WHTY2 Switch Size	Switch Types	Total Cable Length (in.)	Length of Flexible Portion of Cable (in.)	Туре	Туре	
<b>(SÉ</b> )	File LR25490 Class 4652 04		TOF TON	36	22	CFT30	CFT31
<b>U</b> <sup>®</sup>	01833 4002 04	30 A 60 A 100 A	TCF, TCN	48	34	CFT40	—
		TEF. TEN		60	46	CFT50	CFT51
			,	120	106	—	—

Must purchase handle mechanism separately.



Dimensions for Class 9422 30 A, 60 A, and 100 A Switches

			Ы	
Switch Type	Maximum Voltage	Fuse Type Class	Dimension A (in.)	Dimension B (in.)
	30 A, 250 V	H, K, R	1.625	
30 A	30 A, 600 V	H, K, R	4.25	_
	30 A, 600 V	J	1.625	
	60 A, 250 V	H, K, R	2.25	
60 A	60 A, 600 V	H, K, R	4.75	_
	60 A, 600 V	J	1.625	
	100 A, 250 V	H, K, R		3.25
100 A	100 A, 600 V	H, K, R	-	5.25
	100 A, 600 V	J		3.25

mounting surface to disconnect switch surface. D min. = 6 5/8" D max. = 18"

#### Lug Data

Disconnect Switch Size	Wire Size Minimum–Maximum
30 A	#14–#2 Cu, #10–#2 Al
60 A	#14–#2 Cu, #10–#2 Al
100 A	#10–#0 Cu, #6–#0 Al



#### Dimensions for Class 9422 Cable Operators



Туре	Cable Length (in.)	Maximum Box Depth (in.)
CFT30	36	24
CFT50	60	36
CFT10	120	36

Dimension X (see the drawing above) is the wire bending space. It is 2.5 in. for 30 A and 60 A devices (#2 wire) and 5.12 in. for 100 A devices (#0 wire). Refer to NEC 430-10.

## Class 9422 Flange-Mounted, Variable-Depth Disconnect Switches

#### **Ordering Information**

The 9422 Type T disconnect switches are designed for variable depth, flange-mounting applications. These switches are fully compatible with 9422 handle operators and 9423 door closing mechanisms. They feature: 200 and 400 A; fusible (Classes H, K, J, or R fuses) and nonfusible; right- or left-flange mounting (except 400 A, which mounts only right), UL recognized, and CSA certified.

#### **Disconnect Switches**

	Variable	Max	imum H	lorsepo	ower Ra	tings <sup>1</sup>	Fuse Clip Rating (A) Non- Interchangeable		Fuse Clip Rating (A) Non- Interchangeable		Switch and Operating Mechanism Only —	Switch and Operating Mechanism and Handle Mechanism (Overpacked)	
Disconnect Switch Size	Mounting Range Min.–Max. (in.)	A	AC Systems Volts (Motor Volts)			DC Using 2 Poles	DC Poles 2 Poles 250 V		Type DC Using Poles 250 V		Does Not Include Handle Mechanism	Includes Type A1 Handle Mechanism	Includes Type A2 Handle Mechanism
		208 (200)	240 (230)	480 (460)	600 (575)	00 Max. 75)	250 V	600 V	Туре	Туре	Туре		
							Non-F	usible	TF1	ATF11	ATF21		
200 A	9.12–19.25 <sup>2</sup>	40	60	125	150	40	200	200 400	TF2 TF3 <sup>3</sup>	ATF12	ATF22 ATF23 <sup>3</sup>		
400 A Fixed Depth <sup>4</sup>	11.38	75	125	250	350	50	Non-Fusible		TG1 <sup>5,6</sup>	For handle	e selection,		
400 A Adj. Depth <sup>4</sup>	15.87–19.07						400	400	TG2 <sup>5,6</sup>	see pa	age 9.		

<sup>1</sup> Refers to rating of switch only.

<sup>2</sup> 9422 R extends the maximum mounting depth by 7 in.

<sup>3</sup> Accommodates Class J fuses only.

<sup>4</sup> Switches are either fixed-depth or adjustable; the handle configuration will determine installation.

<sup>5</sup> Commercially available enclosures may not accept type TG operating mechanisms. Contact enclosure manufacturer for availability of enclosures for use with these switches.

<sup>6</sup> Right-hand flange mounting only.

7 In steps of 0.63 in.

## Class R Fuses

Fusible disconnect switches on this page will accept Class R fuses as standard. A field installable rejection kit is available which, when installed, rejects all but Class R fuses. With the rejection kit and Class R fuses installed, the switch is UL component recognized for use on systems with up to 200,000 RMS symmetrical Amperes fault current available.

Switch		Fuse Cl	ip Rating	Class	Tuno	
Ampere Rating	туре	250 Vac	600 Vac	CidSS	туре	
200	TF	200 A	200 A	9999	SR4	
400	TG	400 A	400 A	9999	SR5	

### **Electrical Interlocks**

Optional accessory for use with the disconnect switches listed on this page.

For Use On Switch Type	Class	Single Pole Interlock Type	Class	Two Pole Interlock Type
TF, ATF	9999	R8	9999	R9
TG	9999	R35	9999	R36



## CCN: WHTY2

\_



	Disconnect Switch Size	Wire Size Min.–Max.
Class 4652 04	200 A	#6–300 KcmiL Cu or Al
	400 A	#4–500 KcmiL Cu

File E52639



## Class 9422 Flange-Mounted, Variable-Depth Disconnect Switches 200A Type TF

Outline dimensions and location information for 200 A disconnect switches. Non-fusible and non-interchangeable fuse-clip type fusible switches.



#### Dimension Table-in. (mm)

	S	witch Size					.1												
Туре	Am	pere Rating	Α	в	с		,.	Е	F	G	J	к	L	м	Ν	Q	R	s	т
	Sw	Fuse Clips				Min.	Max												
TF1	200	None	13.33 (339)	9.38 (238)	1.64 (42)	9.12 (232)	19.25 (489)	2.33 (59)	8.00 (203)	—	_	9.44 (240)	6.50 (165)	9.53 (242)	—	-	3.14 (80)	1.03 (26)	0.75 (19)
TF2	200	Class J 200 A 600 V	13.33 (339)	9.38 (238)	1.64 (42)	9.12 (232)	19.25 (489)	2.33 (59)	8.00 (203)	0.09 (3)	2.77 (70)	9.44 (240)	6.50 (165)	-	14.11 (358)	9.63 (245)	3.14 (80)	1.03 (26)	0.75 (19)
TF2	200	Class H, K, R 200 A 250 V	13.33 (339)	9.38 (238)	1.64 (42)	9.12 (232)	19.25 (489)	2.33 (59)	8.00 (203)	0.09 (3)	4.14 (105)	9.44 (240)	6.50 (165)	-	15.48 (393)	9.63 (245)	3.14 (80)	1.03 (26)	0.75 (19)
TF2	200	Class H, K, R 200 A 600 V	13.33 (339)	9.38 (238)	1.64 (42)	9.12 (232)	19.25 (489)	2.33 (59)	8.00 (203)	0.09 (3)	6.64 (169)	9.44 (240)	6.50 (165)	-	17.98 (457)	9.63 (245)	3.14 (80)	1.03 (26)	0.75 (19)
TF3	200	Class J 400 A 600 V	13.33 (339)	9.38 (238)	1.64 (42)	9.12 (232)	19.25 (489)	2.33 (59)	8.00 (203)	0.09 (3)	2.77 (70)	9.44 (240)	6.50 (165)	9.53 (242)	18.53 (471)	9.63 (245)	3.14 (80)	1.03 (26)	0.75 (19)

<sup>1</sup> The D dimension may be extended up to 7 in. with 9422 R2 (two required per switch).

8 03/2021





File E52639 CCN: WHTY2

## **Class 9422 Handle Mechanisms**

Handle mechanism kits are used with all disconnect switch and circuit breaker installations. The kits contain all parts necessary for mounting the handle to the flange of the enclosure. Types A1 through A4 and A9 through A10 are suitable for right- or left-hand flange mounting. Two mounting methods are offered. Types A5 through A8 are designed for right-hand mounting only.

Description	Туре
6 in. HANDLE for use with 30–200 ampere switches and all circuit breaker mechanisms For use in enclosures rated 1, 3, 3R, 4 (sheet steel), and 12 For use in enclosures rated 4X (stainless steel) All external metal parts are either stainless steel or a chrome-plated non-ferrous die casting.	A1 A2
4 in. HANDLE for use with 30–200 ampere switches and all circuit breaker mechanisms Similar to Type A1 Similar to Type A2	A3 A4
12 in. HANDLE for use with 400 Type TG1 and TG2 disconnect switches <b>ONLY</b> For installation in enclosures rated 1, 3, 3R, 4 (sheet steel), and 12 For installation in enclosures rated 4X (stainless steel)	A7 <sup>1</sup> A8 <sup>1</sup>
10 in. HANDLE for use with Type D2 remote or dual adapter kit <b>ONLY</b> Similar to Type A1 Similar to Type A2	A9 A10

<sup>1</sup> Remove the handle extension arm from the handle linkage for fixed depth operation.

#### Mounting and Outline Dimensions for Fixed Depth Operation Class 9422 A1, A2, A3, A4, A9, and A10 Handles

All dimensions are shown for right-hand flange mounting. For left-hand flange mounting, transpose all horizontal dimensions. See page 11 for information on A7 and A8 handles.



Handle Dimensions



#### Preferred Mounting Method

This method is for 16 Ga. to 0.25 in. thick enclosures. It consists of mounting the handle to the outside, and the stiffener bracket to the inside, of the enclosure and securing with two bolts, as shown in the figure below.



Handle Dimensions

Alternate Mounting Method (Square Cutout)

This method is for 16 Ga. to 0.25 in. thick enclosures. It consists of mounting the handle to the stiffener bracket with two bolts, and securing the assembly to the back side of the enclosure flange with four #10-24 screws. A separate mounting kit (Class 9422 AM-2) is required.

Dimension X is the distance from the top inside of the enclosure or other grounded metal parts (such as conduit hubs) to the upper mounting hole of the handle mechanism. See the panel drilling diagrams on page 10. Actual distances are dependent on the disconnect device being used, and should only be determined once the disconnect device is decided upon and the location on the panel determined.





Panel Drilling for Alternate Mounting Method

03/2021

1.44 37

0

## Class 9422 Flange-Mounted, Variable-Depth Disconnect Switches 400 A Type TG

Outline dimensions and general location for 400 A disconnect switches. Non-fusible and non-interchangeable fuse-clip type fusible switches.

NOTE: When selecting this switch and handle assembly, be aware that commercial enclosure manufacturers do not make a standard enclosure that will accept the TG switches. Special enclosures must be ordered from the enclosure manufacturers.

Switch Type	В	х
TG1,	11.28	16.06
TG2	(286)	(408)

B and X = Minimum to wall or barrier to ensure adequate wire bending space to lug surface when maximum wire size is used. Refer to NEC Article 430.10. For fusible and non-fusible switches, dimension D is the distance from the outside of the flange to the disconnect switch mounting surface.

For Type TG1 or TG2 with:

- Type A7 or A8 fixed-depth handle. Remove handle extension from handle linkage. D = 11.38 (289).
- Type A7 or A8 adjustable-depth handle. D min. = 15.87 (403) and D max. = 19 (483), with steps of 0.63 (16).

24.00 610

Note that copper lugs are standard on all Type TG disconnect switches.

## Type A7–A8 Handle







### **Non-Fusible and Fusible Switches**







File E52369 CCN: WHTY2

File LR25490 Class 4652 04

2



	Ν	laximum l	lorsepow	er Rating	J				Bracketed
Disconnect Switch Size	connect AC System Volts (Motor Voltage) 600 Fuse Typ		Fuse Type	Fuse Clip Rating		Mechanism and Handle			
	208 (200)	240 (230)	480 (480)	600 (600)	VDC		250 V (A)	600 V (A)	Туре
						None	_	_	BTCN30
20.4	7 5	7.5	15	20	5		30	—	BTCF30
30 A	7.5	7.5	15	20	5	п, к, ј, к	60	30	BTCF33
						J1	60	30	BTCF32
						None	—	-	BTDN60
60 4	15	15	30	50	10		60	30	—
00 A	15	15	30	50	10	п, к, ј, к	—	60	BTDF63
						J1	—	60	BTDF62
						None	—	_	—
100 A	25	30	60	75	20	H, K, J, R	100	100	BTEF10
						J1	100	100	BTEF112
						None	_	_	TFB1
200 A	40	60	125	150	40		200	200	TFB2
						J	_	400	TFB3

<sup>1</sup> Space saving design. Type J fuses mounted on the non-fused bracket.

9422BTEF11 product is for flange mount only.

## Class 9422 Bracket-Mounted Operating Mechanisms for Use with Square D Circuit Breakers

The circuit breaker operating mechanisms listed below are shipped with the external operating handle assembled to a bracket. Circuit breakers are not included and must be ordered separately. A trim plate is provided with each kit to eliminate any mounting screws from being accessible from the front and to provide an attractive installation. The operating handle is Type A1. These switches can be used with Class 9423 door closing mechanisms. For Class 9999 electrical interlock kits, see page 17.

F	or Use With	Operating Mechanism, Right Hand Flange Mounting	
Breaker or Interrupter Type	No. of Poles	Frame Size (A)	Catalog No.
FAL, FCL, FHL	2, 3	100	9422BN1
LAL, LHL	2, 3	400	9422BR1
GJL	3	75, 100	9422BG1

**NOTE:** Some enclosures may not accept the listed operating mechanisms. Contact the enclosure manufacturer.



Note: For Lug Data, see

page 5; for Electrical Interlocks, see page 17. Some enclosures may not accept the listed

operating mechanisms; contact

the enclosure manufacturer.

Designed for tall, deep enclosures where placement flexibility is required.

**Class 9422 Handle Operators** 

Class 9422 Flexible Cable Mechanisms for Use with Square D Circuit Breakers and



#### Cable Mechanisms with A1 Handle Cable Mechanism Breaker or Frame For Types 1, 3, 3R, 12 Number Interrupter Size of Poles Total Length Catalog Catalog Туре (A) (in.) No. No. 36 9422CSB30 9422CSB50 PowerPact™ 60 3 125 N/A 84 9422CSB70 в 120 9422CSB10 36 9422CSJ30 3 600 60 9422CSJ50 N/A 120 9422CSJ10 PowerPact D 36 9422CSJ304 4 600 60 9422CSJ504 N/A 120 9422CSJ104 9422CSF30 36 60 9422CSF50 PowerPact H 3 150 N/A 84 9422CSF70 120 9422CSF10 36 9422CSF30 60 9422CSF50 PowerPact J 3 250 N/A 9422CSF70 84 9422CSF10 120 36 9422CSJ30 PowerPact L 3 600 60 9422CSJ50 N/A 120 9422CSJ10 9422CMP40 48 PowerPact M 3 800 50 9422CMP50 N/A 120 9422CMP10 48 9422CMP40 PowerPact P 1200 9422CMP50 3 50 N/A 120 9422CMP10 36 9422CFA30 9422CFA31 FAL, FCL, 2, 3 100 9422CFA50 9422CFA51 60 FHL 9422CFA10 120 36 9422CLA31 9422CLA30 LAL, LHL 400 9422CLA50 2, 3 60 9422CLA51 120 9422CLA10 9422CGJ30 9422CGJ31 36 48 9422CGJ40 GJL 3 75, 100 60 9422CGJ50 \_ 120 9422CGJ10







**NOTE:** Refer to NEC Article 430-10 for minimum dimension X from circuit breaker top mounting hole to wall or barrier to ensure adequate wire bending space.

Bend radius in cable must never be less than 6 inches. Electrical clearances must be maintained between cable and live electrical parts.





9422CGJ







© 1997–2021 Schneider Electric All Rights Reserved

#### **Outline Dimensions for Flexible Cable Mechanisms**



#### **Outline Dimensions for Flexible Cable Mechanisms**

9422CKA





NEMA Cable Operating Mechanisms, PowerPact B-Frame 15-125 A





Outline Dimensions and Location Information for Class 9422 Bracket-Mounted Devices







Note: Back panel support is recommended for Types TFB1, 2, and 3. Other devices may also require support if flange is not sufficiently rigid.

Minimum Wire Bend Space for X Dimension-in. (mm)

Туре	A	х	C	D	Min. Enclosure Depth <sup>1</sup>	Fusible Device E	F
BTCN BTDN BTEN	9.50 (241)	5.50 (140)	1.88 (48)	6.56 (167)	8.0 (203)	_	6.38 (162)
BTCF BTDF BTEF	9.50 (241)	5.50 (140)	1.88 (48)	8.56 (218)	10.0 (254)	11.88 (302)	6.38 (162)
TFB1	11.5 (292)	11.75 (298)	3.88 (98)	9.50 (241)	12.0 (305)	_	13.19 (335)
TFB2 TFB3	20.0 (508)	11.75 (298)	3.88 (98)	9.50 (241)	12.0 (305)	20.0 <sup>2</sup> (508)	13.19 (335)
BN1	8.75 (222)	_	1.13 (29)	6.50 (165)	8.0 (203)		7.13 (181)
BR1	11.25 (286)	_	2.75 (70)	8.50 (216)	10.0 (254)	_	10.13 (257)

<sup>1</sup> The min. depth is greater than Dimension D since additional space is needed when mounting the mechanism.

<sup>2</sup> Fuses and fuse base assembly do not extend beyond the bracket.

Туре	Circuit Breaker Type	Ampere Rating	Standard Al/Cu Lugs Wire Range	X Min.	Optional Al/Cu Lugs Wire Range	X Min.	Optional Cu Lugs Wire Range	X Min.
BN1	FAL, FCL, FHL	15–30	1 - #14-4 Cu or 1 - #12-4 Al	2.00 (51)	1 - #14-1/0 Cu or 1 - #12-1/0 Al	5.00 (127)	1 - #14-1 Cu	3.00 (76)
BN1	FAL, FCL, FHL	35–100	1 - #14-1/0 Cu or 1 - #12-1/0 Al	5.00 (127)	1 - #14-1 Cu or 1 - #12-4 Al	2.00 (51)	1 - #14-1 Cu	3.00 (76)
BR1	LAL, LHL	125–400	1 - #1 - 600 KcmiL or 1 - #1 - 250 KcmiL	14.00 (356)	1 - 500 - 750 KcmiL	20.37 (517)	1 - #1 - 600 KcmiL Cu or 2 - #1 - 250 KcmiL Cu	14.00 (356)

**16** 03/2021

## Variable-Depth Mechanisms for Use with Square D Circuit Breakers



Designed for installation in custom built control enclosures where main or branch circuit protective devices are required. All circuit breaker operating mechanisms are suitable for either right- or left-hand flange mounting, convertible on the job.

	Use	With	O	Operating Mechanism Operating Mechanism and Handle Mechanism Includes Type A1 A2			
			Variable	Operating Mechanism	Operating Mechanism and Handle Mechanism		
Breaker or Interrupter Type	er or Interrupter No. Frame Type Poles (A)		Depth Mtg. Range Min.–Max. <sup>1</sup> (Inches)	Does Not Include Handle Mechanism	Includes Type A1 Handle Mechanism	Includes Type A2 Handle Mechanism	
				Catalog No.	Catalog No.	Catalog No.	
PowerPact B	2, 3	125	5.88–17.75	9422RB1	N/A	N/A	
PowerPact D	3	600	7.25-12.0625	9422RS1	N/A	N/A	
PowerPact H	3	150	6.51–17.88	9422RQ1	N/A	N/A	
PowerPact J	3	250	6.51–17.88	9422RQ1	N/A	N/A	
PowerPact L	3	600	7.44–18.25	9422RS1	N/A	N/A	
PowerPact M	3	800	10.50-18.90	9422RM1	N/A	N/A	
PowerPact P	3	1200	10.50-18.90	9422RM1	N/A	N/A	
FAL, FCL, FHL	2, 3	100	5.38-17.75	9422RN1	9422ARN11	9422ARN21	
LAL, LHL	2, 3	400	7.44–18.25	9422RR1	9422ARR11	9422ARR21	
GJL	3	75, 100	6.00-17.75	—	9422ARG11	9422ARG21	

For use on 9422RM, RN, RQ, RS, and RR.

Class

9999

9999

<sup>1</sup> Class 9422 Type R2 extends mounting depth by 7 in. with the exception of 9422 RM1.

Description

Single Pole, Double Throw

Double Pole. Double Throw

## Electrical Interlocks – Class 9999

#### External Electrical Interlock Kits Class 9999





#### File LR25490 Class 3211 07

#### Internal Electrical Interlocks

Circuit Breaker Type	Catalog Number	Max. per Circuit Breaker
PowerPact B	S29450	2
PowerPact H	S29450	2
PowerPact J	S29450	2
PowerPact L	S29450	2
PowerPact M	S29450	2
PowerPact P	S29450	2
GJL	AAC	1



17

Туре

R26

R27

#### **Outline Dimensions for Class 9422 Variable Depth Mechanisms**

Minimum to wall or barrier to ensure adequate wire bending space to lug surface when the maximum wire size is used with standard lugs.

Dimensions: in. (mm)





9422RS1 斧 Electrical Clearance/Wire Bending Space 14.69 (373) 8.47 (215) 0.77 (20) \_ 6.12 (156) 2.84 (72) 1.77 (45) 24 0.50 ¥ (13) **T** 0.62 (16) 册 (۵) 7.00 (178) 9.50 (241) 0 С 0.05 (1) 0.66 (17) 2.84 **1**.77 (45) \_7.46\_ (190)

Distance from outside of flange to circuit breaker mounting surface 7.44 (189) MIN, 18.25 (464) MAX











Outline Dimensions for NEMA 9422 Variable Depth Operating Mechanism, PowerPact B-Frame 15–125 A

Outline Dimensions and Location Information for 9422 RG1 GJL Circuit Breakers 15 A to 100 A



Circuit Breaker Frame Size	Туре	Width A	Min. to Wall or Barrier B	Height C	Distance to Enclosure Flange (Min.–Max.) D <sup>1</sup>	Bracket Depth E
GJL	RG1	5.00 (127)	6.00 (152)	4.75 (121)	6.00 (152) – 17.75 (451)	4.00 (102)

NOTE: To ensure adequate wire-bending space to lug surface when maximum wire size is used, refer to NEC Article 430-10.

<sup>1</sup> 9422 R2 will extend dimension by 7 in. (two required).

c 7



Outline Dimensions and Location Information for FAL and FHL Circuit Breakers (100 A Frame)

#### Dimensions-in. (mm)

Circuit Breaker Frame Size	Туре	A	в	с	D <sup>1</sup> Min.	D <sup>1</sup> Max.	E	F <sup>2</sup>	G	н	J	к	L	М	N
FAL, FHL	RN1	6.75 (171)	5.38 (137)	2.44 (62)	5.51 (140)	17.75 (451)	2.44 (62)	#8- 32(4)	5.13 (130)	4.26 (108)	8.50 (216)	1.50 (38)	2.19 (56)	0.44 (11)	3.06 (78)

NOTE: To ensure adequate wire-bending space to lug surface when maximum wire size is used, refer to NEC Article 430-10.

<sup>1</sup> 9422 R2 will extend dimension by 7 in. (two required).

<sup>2</sup> Dimension for panel drilling.





Outline Dimensions and Location Information for LAL and LHL Circuit Breakers (400 A Frame)

Dimension-in. (mm)

Circuit Breaker Frame Size	Туре	А	с	D <sup>1</sup> Min.	D <sup>1</sup> Max.	E	F	G	Н	J	к	L	М	N	Р	Q	R
LAL, LHL	RR1	10.19 (259)	3.56 (90)	7.44 (189)	18.25 (464)	3.56 (90)	1.38 (35)	9.25 (235)	6.56 (167)	2.31 (59)	0.38 (10) Dia. (4)	6.63 (168)	6.00 (152)	11.00 (279)	2.00 (51)	4.13 (105)	0.88 (22)

NOTE: To ensure adequate wire-bending space to lug surface when maximum wire size is used, refer to NEC Article 430-10.

<sup>1</sup> 9422 R2 will extend dimension 7 in. (two required).

#### Outline Dimensions for Door-Mounted Operating Mechanisms, PowerPact B-Frame 15-125 A











## Dual Cable Operating Mechanisms for Square D Circuit Breakers

Dual Cable Operating Mechanisms are designed for use with Square D brand PowerPact D, H, J, and L circuit breakers through 600 A frame sizes. The cable mechanisms allow for a single handle operator, Class 9422Ax, to operate both circuit breakers. The cable mechanism is designed especially for tall, deep enclosures where placement flexibility is required. There are numerous cable arrangements to choose from to accommodate many applications.

#### Features

- Separate cables for each circuit breaker
- Rugged metal flange handle operator
- Maximized flexibility of circuit breaker placement for existing and new applications
- Control panel can be fed from two separate supply voltages (if required)
- Dual mechanism allows both separate supply voltages to be controlled by a single handle to improve security features

Circuit Breaker Type	Cable Length in. / mm (quantity)	Catalog Number	Frame Size (max.)	
	120 in. / 3048 mm (2)	9422CSFD1		
	36 in. / 914 mm (1) 60 in. / 1524 mm (1)	—	250 A	
	60 in. / 1524 mm (1-CSF 3 pole) 60 in. / 1524 mm (1-CSF 4 pole)	9422CSFD345		
PowerPact H & J MG NSF	36 in. / 914 mm (1) 120 in. / 3048 mm (1)	9422CSFD31		
	36 in. / 914 mm (2)	9422CSFD33		
	60 in. / 1524 mm (1) 120 in. / 3048 mm (1)	—		
	60 in. / 1524 mm (2)	9422CSFD55		
	60 in. / 1524 mm (2-CSJ)	9422CSJD50 <sup>1</sup>		
	120 in. / 3048 mm (2-CSJ)	9422CSJD10 <sup>1</sup>	600 A	
PowerPact D & L	60 in. / 1524 mm and 120 in. / 3048 mm (2-CSJ)	—		
MG NSJ	120 in. / 3048 mm (1-CSF) and 120 in. / 3048 mm (1-CSJ)	9422CSFJD10	250 A	
	60 in. / 1524 mm (1-CSF) 600 A 60 in. / 1524 mm (1-CSJ)	9422CSFJD50	600 A	

<sup>1</sup> Must use the 9422AP1 or 9422AP2 operating handle with this operating mechanism.



Handle Mechanisms

## **Handle Mechanisms**

These handle mechanism kits are used with the circuit breaker variable depth and cable operating mechanisms. The kits contain all parts necessary for mounting the handle to the flange of the enclosure. Types A1/AP1 to A4 are suitable for right or left-hand flange mounting.

Type of Handle	NEMA Type Enclosure	Туре
6 in	1, 3, 3R, 4 (sheet steel), 12	A1
0 11.	4, 4X (stainless) <sup>1</sup>	A2
0 in 2	1, 3, 3R, 4 (sheet steel), 12	AP1
0 111.2	4, 4X (stainless) <sup>1</sup>	AP2
4 in	1, 3, 3R, 4 (sheet steel), 12	A3
4 111.	4, 4X (stainless) <sup>1</sup>	A4

<sup>1</sup> All external metal parts are either stainless steel or a chrome-plated non-ferrous die casting.

<sup>2</sup> Must be used with 9422RM1, 9422CMP, and 9422CSJD (dual cable mechanism) only.

NOTE: See the Digest for dimensions.





Rotary Handle Dimensions (in.)



Switch Dimensional Sketch

#### Switch Interrupting and Withstandability Ratings

Switch Rating (A)	Interrupting Rating Amperes Symmetrical 600 Vac, 3 Phase	Withstandability I <sup>2</sup> T (Amperes <sup>2</sup> seconds)
30	1,200	0.38 x 10 <sup>6</sup>
60	1,800	1.28 x 10 <sup>6</sup>
100	2.000	2.62 x 10 <sup>6</sup>
200	3,600	5.25 x 10 <sup>6</sup>

NOTE: These switches are for motor circuit applications.

#### Lug Data

Switch Rating (A)	Number Per Pole	Wire Range	Wire Type
30		AWG 14–8	Cu
60	1	AWG 14–4	Cu
100	I	AWG 14–1/0	Al - Cu
200		AWG 6–250 kcmil	Al - Cu

#### Switch Dimensions (in.)

Switch	Len	gth	Width		Mounting Hole Dimensions					Depth		
(A)	Α	в	С	D	Е	F	G	н	I	J	<b>K</b> 1	<b> </b> 2
30	75⁄ <sub>16</sub>	4 <sup>15</sup> / <sub>32</sub>	5 <sup>7</sup> ⁄8	3 <sup>15</sup> / <sub>32</sub>	6	3 <sup>15</sup> / <sub>32</sub>	11/8	<sup>13</sup> ⁄ <sub>32</sub>	5 <sup>7</sup> / <sub>16</sub>	31/4	4 <sup>3</sup> ⁄ <sub>32</sub>	4 <sup>11</sup> / <sub>32</sub>
60	75⁄ <sub>16</sub>	4 <sup>15</sup> / <sub>32</sub>	5 <sup>7</sup> ⁄8	3 <sup>15</sup> / <sub>32</sub>	6	3 <sup>15</sup> / <sub>32</sub>	11/8	<sup>13</sup> ⁄ <sub>32</sub>	5 <sup>7</sup> ⁄ <sub>16</sub>	3 <sup>1</sup> / <sub>4</sub>	4 <sup>1</sup> / <sub>32</sub>	4 <sup>11</sup> / <sub>32</sub>
100	9 <sup>27</sup> / <sub>32</sub>	5 <sup>11</sup> / <sub>32</sub>	8 <sup>3</sup> ⁄16	45⁄8	5 <sup>13</sup> ⁄16	3 <sup>13</sup> ⁄ <sub>16</sub>	2 <sup>11</sup> / <sub>16</sub>	<sup>51</sup> ⁄ <sub>64</sub>	7 <sup>5</sup> ⁄ <sub>16</sub>	4¾ <sub>16</sub>	5 <sup>23</sup> ⁄ <sub>32</sub>	4 <sup>27</sup> / <sub>32</sub>
200	12 <sup>3</sup> ⁄ <sub>16</sub>	71/32	8 <sup>3</sup> ⁄ <sub>16</sub>	45⁄8	5 <sup>13</sup> ⁄16	3 <sup>13</sup> ⁄ <sub>16</sub>	2 <sup>11</sup> / <sub>16</sub>	<sup>51</sup> ⁄ <sub>64</sub>	7 <sup>5</sup> ⁄16	4 <sup>3</sup> ⁄ <sub>16</sub>	5 <sup>23</sup> / <sub>32</sub>	4 <sup>27</sup> / <sub>32</sub>

<sup>1</sup> Maximum depth with largest fuse

<sup>2</sup> Depth, including insulating barrier on service entrance switches

Type L door-mounted, variable-depth operating mechanisms feature heavy duty, all metal construction with trip indication. All can be padlocked in the Off position when the enclosure door is open. Further, the handle assemblies can be locked Off with up to three padlocks, which also locks the door closed. The 3 in. handle accepts one

Complete kits are rated for NEMA Type 1, 3R, and 12 enclosures. A door-drilling template is supplied to facilitate

installation. The kits include a handle assembly, operating mechanism, and shaft assembly.

**Class 9421 Type L Circuit Breaker Mechanisms** 



padlock.

**Complete Kits** 

3 in. Handle Assembly



Standard Handle Assembly



**Operating Mechanism** (includes lockout)



**IEC-Style Handle** 

Complete Kit Does Not Include Circuit Breaker.			Inc Operating Standard	ludes: J Mechanism 6 in Handlo	Inc Operating Standard	ludes:   Mechanism 6 in Handlo	Includes: Operating Mechanism Short 3 in Handle		
Use With			Standard	d Shaft Kit	Long	Shaft Kit	Long Shaft Kit		
Circuit Breaker or Interrupter Type	Number of Poles	Frame Size (A)	Catalog No.	Mounting Depth <sup>1</sup> Min.–Max.	Catalog No.	Mounting Depth <sup>1</sup> Min.–Max.	Catalog No.	Mounting Depth <sup>1</sup> Min.–Max.	
PowerPact™ B	3	125	9421LB1	5.5–10.75	9421LB4	5.5–21.38	9421LB3	5.5–21.3	
PowerPact H	3	150	9421LJ1	5.5–10.75	9421LJ4	5.5–21.38	9421LJ3	5.5–21.38	
PowerPact J	3	250	9421LJ1	5.5–10.75	9421LJ4	5.5–21.38	9421LJ3	5.5–21.38	
PowerPact L	3	600	9421LD1	7.25–12.06	9421LD4	7.25–22.63	—	_	
PowerPact L (DC only)	4	1200	9421LD14	_	9421LD44	_	—	_	
PowerPact M <sup>2</sup>	3	800	9421LW1	9.0–12.5	9421LW4	9.0–23.5	_	_	
PowerPact P <sup>2</sup>	3	1200	9421LW1	9.0–12.5	9421LW4	9.0–23.5	—	—	
FAL, FCL, FHL	2, 3	100	9421LN1	5.5-10.44	9421LN4	5.5–21.0	9421LN3	5.5–21	
LAL, LHL	2, 3	400	9421LR1	6.31–10.88	9421LR4	6.31–21.5	_	_	
GJL	3	75, 100	9421LG1	5.5-10.25	_	5.5-20.88	9421LG3	5.5-20.875	

1 Mounting depth measured from circuit breaker mounting surface (control panel) to outside of enclosure door in inches.

2 Includes standard 8 in. handle 9421LHP8.

#### **Component Parts**

Component parts kits are rated for NEMA Type 1, 3, 3R, and 12 enclosures. All handle assemblies are painted (the handle is flat black and the base ring is silver).

Use With		3 in. Handle Assemblies Type 1, 3R, 12	Std. 6 in. Handle Assemblies Type 1, 3R, 12	Operating Mechanism Includes Lockout	Standard Shaft (Support Bracket Not Required)		Long Shaft (Support Bracket Included)		
Circuit Breaker or Interrupter Type	No. of Poles	Frame Size (A)	Catalog No.	Catalog No.	Catalog No.	Mounting Depth <sup>1</sup> Min.–Max.	Catalog No.	Mounting Depth <sup>1</sup> Min.–Max.	Catalog No.
PowerPact B	3	125	9421LH3	9421LH6	9421LB7	5.5–10.25	9421LS8	5.5-21.375	9421LS13
PowerPact H	3	150	9421LH3	9421LH6	9421LJ7	5.5–10.25	9421LS8	5.5-21.375	9421LS13
PowerPact J	3	250	9421LH3	9421LH6	9421LJ7	5.5–10.25	9421LS8	5.5-21.375	9421LS13
PowerPact L	3	600	—	9421LH6	9421DJ7	7.25–12.06	9421LS8	7.25-22.625	9421LS13
PowerPact L (DC only)	4	1200	—	9421LH6	9421LD74	_	-	—	
PowerPact M	3	800	—	9421LHP8	9421LW7	9.0–12.50	9421LS8	9.0–23.5	9421LS10
PowerPact P	3	1200	—	9421LHP8	9421LW7	9.0–12.50	9421LS8	9.0–23.5	9421LS10
FAL, FCL, FHL	2, 3	100	9421LH3	9421LH6	9421LF1	5.5–10.44	9421LS8	5.5–21	9421LS12
LAL, LHL	2, 3	400	—	9421LH6	9421LL1	6.31–10.88	9421LS8	6.31–21.5	9421LS10
GJL	3	75, 100	9421LH3	9421LH6	9421LG7	5.5–10.44	9421LS8	5.5–21.0	9421LS12

1 Mounting depth measured from circuit breaker mounting surface (control panel) to outside of enclosure door in inches.

	File E62922
• <b>7</b> -5	CCN: DIHS2

	3 in. Handle Assemblies Type 1, 3R, 12	Std. 6 in. Handle Assemblies Type 1, 3R, 12	8 in. Handle Assemblies Type 1, 3R, 12
Red Handle with Yellow Bezel	9421LH3RY	9421LH6RY	9421LHP8RY
(for example, 9421LH3 with 9421LH3RY)	—	—	—
Legacy Circuit Breaker Handle	_	_	9421LH8





## NEMA Type 3 and 4 Handle Assemblies

9421LC43\_DA



9421LC46

Use With		Standard Hand	dle Assemblies	Special 3 in. Version		
Circuit Breaker or	No. of	Frame Size	NEMA Type 3, 4 (Painted)	NEMA Type 3, 4, 4X (Chrome Plated)	NEMA Type 3, 4 (Painted)	NEMA Type 3, 4, 4X (Chrome Plated)
Interrupter Type	Poles	(A)	Catalog No.	Catalog No.	Catalog No.	Catalog No.
PowerPact B	3	125	9421LH46	9421LC46	9421LH43	9421LC43
PowerPact H	3	150	9421LH46	9421LC46	9421LH43	9421LC43
PowerPact J	3	250	9421LH46	9421LC46	9421LH43	9421LC43
PowerPact L	3	600	9421LH46	9421LC46	_	—
PowerPact L (DC only)	4	1200	9421LH46	9421LC46	_	—
PowerPact M	3	800	9421LHP48	9421LCP48	_	—
PowerPact P	3	1200	9421LHP48	9421LCP48	_	—
FAL, FCL, FHL	2, 3	100	9421LH46	9421LC46	9421LH43	9421LC43
LAL, LHL	2, 3	400	9421LH46	9421LC46	_	—
GJL	3	75, 100	9421LH46	9421LC46	9421LH43	9421LC43

	Std. 6 in. Handle Assemblies, Type 3, 4 (Painted)	Special 3 in. Handle Assemblies Type 3, 4 (Painted)	8 in. Handle Assemblies Type 3, 4 (Painted)
Red Handle with Yellow Bezel	9421LH46RY	9421LH43RY	9421LHP48RY
(for example, 9421LH3 with 9421LH3RY)	—	_	—
Legacy Circuit Breaker Handle	_	—	9421LH8



9421LH46





Panel Drilling for PowerPact D and L Circuit Breaker Operating Mechanisms: 9421LD1, 9421LD4, and 9421LD7



X: Minimum to wall or barrier to insure adequate wire bending space to lug surface when the maximum wire size is used. Refer to NEC 430-10.



#### **Shaft Cutting Dimensions**

Class	Turne	Shaft Length	H = Standa	ard Shaft	H = Long Shaft		
Class	туре	Formula	Min.	Max.	Min.	Max.	
9421	LJ1, LJ4, LJ7	L = H – 3.00 (76)	5.5 (138)	10.75 (273)	5.5 (138)	21.63 (543)	
9421	LD1, LD4, LD7	L = H – 4.25 (108)	7.25 (184)	12.06 (306)	7.25 (184)	22.63 (575)	
9421	LW1, LW4, LW7	L = H – 4.89 (124)	7.19 (183)	11.63 (295)	7.19 (183)	22.25 (565)	

Panel Drilling for PowerPact H and J Circuit Breaker Operating Mechanisms: 9421LJ1, 9421LJ4, and 9421LJ7

Electrical Clearance/Wire Bending Space



2.38 (61) 1.38 (35) Shaft support bracket Ο 0 0 0.28 Max. door thickness (7) H.





**Determination of Shaft Length** 



Class	Туре	Shaft Length Standard S		rd Shaft	Long Shaft	
01033	Type	Formula	Min.	Max.	Min.	Max.
9421	LG7, LG1, LG4, LG3	L = H – 2.5 (64)	5.5 (140)	10.25 (250)	5.5 (140)	20.85 (530)



Dimensions for 3.5 in. Handle Assembly

**Circuit Breakers and Circuit Interrupters** 

**Dimensions for FAL, FCL, FHL** 



Panel Drilling for FAL, FCL, FHL Circuit Breakers and Operating Mechanisms



Electrical Interlock Location – FA 9999R47 or 9999R48



† Mounting depth measured from circuit breaker mounting surface (control panel) to outside of enclosure door.

Determination of Shaft Length-in. (mm)

Class	Туро	Shaft Length	Standard Shaft		Long Shaft	
Class	туре	Formula	Min.	Max.	Min.	Max.
9421	LF1, LN1, LN3, LN4	L = H – 2.88 (73)	5.5 (140)	10.44 (265)	5.5 (140)	21.00 (533)

### Electrical Interlock Kits — Class 9999

#### External Electrical Interlock Kits Class 9999

Description	Class	Туре
Single Pole, Double Throw	9999	R47
Double Pole, Double Throw	9999	R48

For use on 9421LF1, LN1, LN3, LN4, LL1, LR1, and LR4

#### Internal Electrical Interlocks

Circuit Breaker Type	Catalog Number	Max. per Circuit Breaker
PowerPact B	S29450	2
PowerPact H	S29450	2
PowerPact J	S29450	2
PowerPact L	S29450	2
PowerPact M	S29450	2
PowerPact P	S29450	2
GJL	AAC	1



Electrical Interlock Location for LAL, LHL Circuit Breakers and Operating Mechanisms





Dimensions for LAL, LHL Circuit Breakers and Circuit Interrupters



L = Overall shaft length. H = Distance from inside of encljosure door to circuit breaker mounting surface.

t Mounting depth measured from circuit breaker mounting surface (control panel) to outside of enclosure door.

Determination of Shaft Length-in. (mm)

Class	Type	Shaft Length	Standard Shaft		Long Shaft	
01855	Type	Formula	Min.	Max.	Min.	Max.
9421	LL1, LR1, LR4	L = H – 3.13 (79)	6.31 (160)	10.88 (276)	6.31 (160)	21.50 (546)

Panel Drilling for LAL, LHL Circuit Breakers and Operating Mechanisms



## Accessories for Class 9422 Flange-Mounted, Variable-Depth Disconnect Switches

#### **Remote or Dual Adapter Kit**

For the remote or dual operation of 30, 60, 100 and 200 A disconnect switches, or GJL, FAL, FHL, LAL, and LHL circuit breakers.

**Remote Operation** — permits mounting the Class 9422 Type A9 or A10 handle mechanism at a lower level than the disconnect device it controls. This arrangement is often required where the disconnect device is mounted too high for personnel to easily reach a conventional operator.

**Dual Operation** — permits controlling two disconnect devices, one in line with and one remote from a single Class 9422 Type A9 or A10 handle mechanism.

NOTE: Class 9422 Type A9 or A10 handle and preferred mounting method must be used.

Mounting Depths for Disconnect Devices

Disconnect Device	Encle Mountir (ii	Enclosure Mounting Depth (in.)		
Circuit Breaker	Minimum	Maximum		
FAL, FCL, FHL	10.66	19.5		
LAL, LHL	12.13	19.88	N/A	
GJL	10.50	19.50		
Disconnect Switch	Minimum	Maximum	Туре	
30 A Type TCF/TCN	10.63	19.50		
60 A Type TDF/TDN	10.63	19.50		
100 A Type TEF/TEN	12.13	20.25	02	
200 A Type TF	13.13	20.81		

NOTE: Must mount switch or circuit breaker a minimum of 9 in. above or below.

#### Other Accessories

	_
	Α
Alternate Mounting Kit	



Channel/Flange Support Kit



Auxiliary Lock Plate

	Description	Class	Туре
Alternate Mounting Kit	Permits mounting Class 9422 Type A1 or A2 handle mechanisms in enclosures with flange thickness of 16 gauge to 0.5 inch.	9422	AM2
Channel/Flange Support Kit	Auxiliary kit recommended for use with 30 A and 60 A disconnect switches and FAL, FCL, FHL, KAL, and KHL circuit breaker mechanisms when these devices are to be mounted on the center channel of a multi- door enclosure or when extra rigidity for the flange is required. Supplied as standard with 100 and 200 ampere disconnect switches and LAL, LHL, Q4L, MAL, MHL, MEL, and MXL circuit breaker mechanisms.	9422	C1
Special Lugs for	Copper lugs only. Specify Form Y157. Tin-plated aluminum lugs for 400 A Type TG switch. Specify Form Y1572 (000–750 Kcmil Cu/Al wire).	Ι	
Disconnect Switches	Anderson Type VCEL compression lugs. Specify Form Y1574. <b>Exceptions: all</b> 30 A and 60 A disconnect switches are not available with compression lugs.	Ι	
	Standard operating rod for use with Class 9422 variable depth mechanisms. Included as standard in each kit.	9422	R1
Operating Rods	Extra long operating rod for use with Class 9422 variable depth mechanisms. Can be used as a substitute for the standard rod included in each kit to increase the maximum mounting depth by 7 in. (Two are required for Types ARR, RR, ART, RT, ATE, TE, ATF, TF).	9422	R2



File E52369 CCN: WHTY2



Remote operation shown (handle mechanism not included in kit)

© 1997–2021 Schneider Electric All Rights Reserved



## Class 9423 Door-Closing Mechanisms



NEMA-Style Flange Handle Disconnect Switch

Class 9423 door-closing mechanisms may be used on enclosures with door openings up to 91 inches. The door closing mechanisms are designed to be used on control enclosures and interlocked with a Class 9422 disconnect device, although they all can be used independently. Three different systems are available and their use is as recommended below. A complete system is available for interlocking all the doors of a multi-door enclosure with the master door when using the 6 in. or 8 in. vault handle mechanism.

"Master door" refers to the door of a single or multi-door enclosure which is interlocked directly with the disconnect device. The master door can be hinged on either the right or left hand side. It can be located in any position on a multi-door enclosure. "Auxiliary door" refers to the remaining door(s) of a multi-door enclosure which is (are) interlocked with the master door by means of the overhead interlocking system as illustrated on the next two pages.

#### **Selection Procedure**

- Step 1. Determine enclosure construction (such as number of doors, door height, and hinge location).
- Step 2. Determine Class 9422 disconnect device to be used—either a disconnect switch or a circuit breaker mechanism. See examples of these devices to the left.
- Step 3. Determine the location of disconnect device and handle mechanism (right- or left-hand flange or center channel).
- Step 4. Select the door closing mechanism required:

Door Closing Mechanism					
60 in. Maximum Door Opening (Recommended)		46–60 in. Door Opening (Recommended)		61–91 in. Door Opening (Recommended)	
	<ul> <li>2 Point Locking is Standard</li> <li>A Third Roller Latch Kit is Available for Three Point Locking</li> <li>For <sup>3</sup>/<sub>4</sub> in. Door Depths</li> </ul>		<ul> <li>Use on Single or Multi-Door Enclosures</li> <li>Use with Doors Hinged on Right or Left Side</li> <li>For 3/4 in. Door Depths</li> </ul>		<ul> <li>Use on Single or Multi-Door Enclosures</li> <li>Use with Doors Hinged on Right or Left Side</li> <li>For 1-1/<sub>8</sub> in. Door Depths</li> </ul>

Step 5. Select auxiliary door closing mechanisms and multi-door interlocking hardware, if required. (A complete system for interlocking all auxiliary doors of a multi-door enclosure with center channel is available for the medium and large enclosures.)



Circuit Breaker Mechanism

## Class 9423 Single Door Enclosures: NEMA Type 4 or 12 with 60 in. Maximum Opening

The door closing mechanisms listed in the table below are for use on small to medium size single door control enclosures. They are designed to be used in conjunction with Class 9422 flange mounted disconnect switches and circuit breaker operating mechanisms; however, they can be used independently as well. When used on properly designed and gasketed NEMA Type 12 enclosures, they meet NFPA 79 standards.

Description	Use On (Enclosure Type)	Use In Conjunction With	Door Latch Handle Length (in.)	Suggested Max. Door Opening	Door Depth (in.)	Туре
Two Point, Roller Latch, Door Closing Mechanism for Use on Enclosures with DOORS HINGED ON LEFT HAND SIDE.	NEMA Type 4 and 12 Sheet Steel	Class 9422 Types A1, A3, A9	4	Less than 39 in.	3⁄4	M41
			6	60 in.	3⁄4	M9 <sup>1</sup>
	NEMA Type 4 and 12 Stainless Steel	Class 9422 Types A2, A4, A10	4	Less than 39 in.	3⁄4	M24
Two Point, Roller Latch, Door Closing Mechanism for Use on Enclosures with DOORS HINGED ON RIGHT HAND SIDE.	NEMA Type 4 and 12 Sheet Steel	Class 9422 Types A1, A3, A9				
	NEMA Type 4 and 12 Stainless Steel	Class 9422 Types A2, A4, A10	4	Less than 39 in.	3⁄4	M24L
Third Roller Latch Kit for Three Point Locking. Used where 3 Point Locking is Desired or Where Door Opening is 39 in. or more.	NEMA Type 4 and 12 Sheet Steel	Class 9423 Types M4, M9, M4L, M9L	I		3⁄4	M3 <sup>1</sup>
	NEMA Type 4 and 12 Stainless Steel	Class 9423 Types M24, M24L	_	_	_	_

Type M4

Latch bar not included, but most prepunched enclosures that accept Square D operating mechanisms supply a predrilled latch bar.

<sup>1</sup> Package quantity 10.

#### **Enclosure Construction and Location Information**



## Class 9423 Vault Type for Single Or Multi-Door Enclosures: NEMA Type 12 with 61–90 in. Door Openings

The requirements are shown in the table below:

Single-Door Enclosure		Multi-Door Enclosure			
Without Interlocking	With Interlocking	Without Interlocking	With Interlocking		
1 – M8 door closing	1 – M8 door closing	For <b>each</b> door:	For Master door:	Each Auxiliary door:	
mechanism	mechanism 91 locking bar kit 1 – Type M891 locking bar kit 1 – Type M1 (use with 9422A handles)	1 – M8 door closing mechanism	1 – M8 door closing mechanism	1 – M8 door closing mechanism	
1 – Type M891 locking bar kit					
		1 – Type M891 locking bar kit	1 – Type M891 locking bar kit	1 – Type M891 locking bar kit	
			1 – Type M1 (use with 9422A handles)	Necessary quantities of Types M2 and M7 for each door (see below)	

#### Viewed from Inside Enclosure



#### TYPE M8 DOOR CLOSING MECHANISM

The Class 9423 Type M8 door closing mechanism is designed to close and seal 1.125 in. deep doors of single or multi-door NEMA Type 12 enclosures. The Type M8 can be used on doors hinged on either the left or right hand side. Recommended door openings are from 61–91 in. Vault type handle length is 8 in.

#### **TYPE M891 LOCKING BAR KITS**

The lock bar kit for the Type M8 door closing mechanism contains two lock bars and is available from stock. The bars can be cut to fit door openings through 91 in. One lock bar kit is required for each Type M8 ordered.

#### TYPE M1

The Class 9423 Type M1 mechanical interlock kit is designed to interlock a Class 9422 handle mechanism with the Type M8 door closing mechanism. This kit prevents opening the master door (or single door) with the disconnect handle in the On position, making it mandatory to use a screwdriver to gain entry to the enclosure, regardless of the disconnect handle position.

#### **Required Accessories for Auxiliary Doors**

#### TYPE M2

One Type M2 kit is required for each auxiliary door. This kit is required to interlock any auxiliary door(s) with the master door.

#### TYPE M7

The first auxiliary door requires two Type M7 kits. Additional auxiliary doors require only one Type M7 kit. The 0.25 in. diameter rod used to interconnect the M7 kits is furnished by the user. If the distance between any two Type M7 kits exceeds 36 in., an additional Type M7 kit should be installed to prevent the rod from buckling.

**NOTE:** All mechanisms listed on this page are suitable for either left or right hand mounting.

Interlocking lever extension of the flange mounted handle mechanism.
 Actual enclosure opening – not door height.

Field of boots of the second secon





## Class 9423 Door Closing Mechanisms: Single- and Multi-Door Enclosures

## Enclosure Construction and Location Information for Types M5 and M6 and Types M1 and M8

Drilling and location information shown to the left is complete for a single door enclosure with door hinged on the left side. The top drawing shows a Type M6, M5, and Class 9422 handle mechanism; the bottom drawing shows a Type M8, M1, and Class 9422 handle mechanism.

Transpose all horizontal dimensions for doors hinged on the right side.

See the next page for information on flange and channel construction.

Dimension A

For single-door enclosures and multi-door enclosures overhead interlocking system, minimum is 1 in. (25 mm). For multi-door enclosures with an overhead interlocking system, minimum is 4.5 in. (114mm). (The overhead interlocking system consists of the required number of Class 9423 Type M2 and M7 kits for interlocking the auxiliary doors with the master door. See pages 32 and 33 for more information.





Enclosure with M8, M1, and Class 9422 Handle Mechanism

Dimensions B and C—in. (mm)

Туре	Disconnect Devices	If A = 1 in., Min. B =	If A = 4.5 in., Min. B =	с	
With M6, M5	With M6, M5, and Class 9422 Handle Mechanism				
TCF, TCN	30A Disconnect Switch	3.44 (88)	2.50 (64)	3.19 (81)	
TDF, TDN	60A Disconnect Switch	3.44 (88)	2.50 (64)	3.19 (81)	
TEF, TEN	100A Disconnect Switch	5.25 (134)	2.50 (64)	3.19 (81)	
TF	200A Disconnect Switch	11.63 (296)	8.13 (207)	3.19 (81)	
TG	400A Disconnect Switch	15.07 (383)	11.57 (294)	6.75 (172)	
RN1	FAL, FHL Circuit Breaker	4.85 (124)	2.50 (64)	3.19 (81)	
With M8, M1, and Class 9422 Handle Mechanism					
TCF, TCN	30A Disconnect Switch	2.94 (75)	2.50 (64)	3.19 (81)	
TDF, TDN	60A Disconnect Switch	2.94 (75)	2.50 (64)	3.19 (81)	
TEF, TEN	100A Disconnect Switch	4.75 (121)	2.50 (64)	3.19 (81)	
TF	200A Disconnect Switch	11.13 (283)	8.13 (207)	3.19 (81)	
TG	400A Disconnect Switch	14.57 (370)	11.57 (294)	5.88 (150)	
RN1	FAL, FHL Circuit Breaker	4.35 (111)	2.50 (64)	3.19 (81)	





Figure 1











## Class 9423 Door Closing Mechanisms: Single- and Multi-Door Enclosures

#### Enclosure Construction Details for Types M1 and M8 Kits

Single- and multi-door enclosures designed to accept the Class 9423 Type M1 and/or Type M8 kits must be constructed according to the dimensions shown on this page. Imperative in the enclosure design is the door depth, which must be 1.13 in. (29 mm) as shown in Figure 1 regardless of whether a disconnect device is used.

The figures are top views of the flange or center channels with various door configurations. Transpose all dimensions for enclosures with doors closing oppositely of those shown.

#### Flange Construction

Figure 1 shows flange construction. Dimension C is 3 in. (77 mm) with a Type A7 handle on the enclosure flange. With a Class 9422 Type A1 handle mechanism on the enclosure flange, the minimum dimension for C is 3 in. (77 mm); without a Class 9422 Type A1 handle mechanism on the enclosure flange, the minimum dimension for C is 1.5 in. (39 mm).

#### **Channel Construction**

Figures 2 and 3 show the type of channel construction where two doors close on a common channel.

In Figure 2, the dimensions apply when a Type M8 kit is used on each regardless of whether a Class 9423 Type M2 auxiliary door interlock is used.

In Figure 3, the dimensions apply when a Class 9422 Type A1 handle, Class 9423 M1 kit, and a Class 9423 M2 interlock are all located on the channel. (For an alternate door closing method using a similar type of construction, refer to Class 9423 Type M25 on page 41.)

Figure 4 shows the type of channel construction where one door closes on a common channel, while another door is hinged on the common channel. For this type of channel construction, the minimum dimension for E is 3 in. (77 mm) with a Class 9422 A1 handle mechanism in the channel (with or without a Class 9423 M1 kit) or 2 in. (51 mm) without an A1 handle.

Additionally, the minimum for dimension D with this type of channel construction is 4 in. (102 mm) with a Class 9422 A1 handle mechanism in the channel (with or without a Class 9423 M5 kit) or 3 in. (77 mm) without an A1 handle.

03/2021

## Class 9423 Door Closing Mechanisms: Single- and Multi-Door Enclosures

## Type M25 Double-Door Interlock Kit

The Class 9423 Type M25 double-door interlock kit is designed for use on enclosures with two doors closing on a center channel, and which has a Class 9422 disconnect device mounted on it. The kit provides for the interlocking of both doors to the disconnect handle with one Class 9423 Type M1 kit. It also prevents the auxiliary door from being opened before the master door is opened, and without the use of a screwdriver to void a mechanical interlock.

#### Installation

A complete installation of the Type M25 interlock kit requires the following items:

- (2) Class 9423 Type M8 Vault Handles
- (2) Class 9423 Type M891 Lock Bar Kits
- (1) Class 9423 Type M1 Mechanical Interlock Kit
- (1) Class 9423 Type M25 Double-Door Interlock Kit
- (1) Class 9422 Handle Mechanism
- (1) Class 9422 Disconnect Device

#### **Enclosure Construction and Location Information**



## **Numerics**

9421DJ725	9422ATDF602 4
9421LB125	9422ATDF631 4
9421LB3 25	9422ATDF632 4
9421LB4 25	9422ATDN601 4
9421LB725	9422ATDN602 4
9421LC43 26	9422ATEF101 4
9421LC46 26	9422ATEF102 4
9421LCP48 26	9422ATEN101 4
9421LD125	9422ATF117
9421LD1425	9422ATF12 7
9421LD4 25	9422ATF21 7
9421LD4425	9422ATF227
9421LF1	9422ATF23 7
9421LG1 25	9422BG1 12
9421LG3	9422BN1 12
9421LG7 25	9422BR1 12
94211 H3 25	9422BTCE30 12
94211 H43 26	9422BTCF32 12
94211 H46 26	9422BTCF33 12
9421LH6 25	9422BTCN30 12
9421LHP48 26	9422BTOR 00 12 9422BTDE62 12
0/211 HP8 25	0/22BTDF63 12
0421111 25	0422BTD105 12
0421113 25	9422DTDN00 12 0/22BTEE11 12
042111025	9422DTEFTT 12
942 ILJ4 25	94ZZDTENTU 1Z
9421LJ725	942201
942 ILLI	9422CFA10 13
942 ILN1	9422CFA30 13
9421LN3	9422CFA31 13
9421LN4	9422CFA50 13
9421LR1	9422CFA51 13
9421LR4	9422CF1304
9421LS1025	9422CF1314
9421LS12 25	9422CF1404
9421LS13 25	9422CFT50 4
9421LS825	9422CFT51 4
9421LW1 25	9422CGJ10 13
9421LW425	9422CGJ30 13
9421LW725	9422CGJ31 13
9422A19, 23	9422CGJ40 13
9422A109	9422CGJ50 13
9422A29, 23	9422CLA10 13
9422A39, 23	9422CLA30 13
9422A49, 23	9422CLA31 13
9422A79	9422CLA50 13
9422A89	9422CLA51 13
9422A99	9422CMP10 13
9422AM2 31	9422CMP40 13
9422AP1 23	9422CMP50 13
9422AP2 23	9422CSB10 13
9422ARG11 17	9422CSB30 13
9422ARN11 17	9422CSB50 13
9422ARN21 17	9422CSB70 13
9422ARR11 17	9422CSF10 13
9422ARR21 17	9422CSF30 13
9422ATCF301 4	9422CSF50 13
9422ATCF331 4	9422CSF70 13
9422ATCF332 4	9422CSFD1 22
9422ATCN301 4	9422CSFD31 22
9422ATCN302 4	9422CSFD33 22
9422ATDF601 4	9422CSFD345 22
·	

9422CSED55 22
0422CSEID10 22
9422CSFJD50 . 22
9422CSJ10 13
9422CSJ104 13
9422CSJ30 13
9422CSJ304 13
0/2208/50 13
942203550 15
942203J304 13
9422CSJD50 22
9422R1 31
9422R2 31
9422RB1 17
9/22PM1 17
9422RN1 17
9422RQ1 17
9422RR1 17
9422RS1 17
9422TC33 4
9422TCE30 4
9422101304
94221CF30C 4
9422TCF33 4
9422TCF33C 4
9422TCN30 4
9422TCN30C 4
0422700000 4
94221003
94221 DF60 4
9422TDF63 4
9422TDF63C 4
9422TDN60 4
9422TEE10 4
04221EF10C 4
94221EF10C 4
94221EN10 4
9422TEN10C 4
9422TF17
9422TF2 7
9422TE3 7
0422TEP1 12
94221FB1 12
94221FB2 12
9422TFB3 12
9422TG17
9422TG27
9423M1 34
0422142 24
94231012
9423M24 33
9423M24L 33
9423M3 33
9423M4 33
9423M7 34
0422M9 24
94231010
942310891 34
9423M9 33
9999R26 17
9999R26 17 9999R27 17
9999R26 17 9999R27 17 9999R35
9999R26 17 9999R27 17 9999R35 7 9999R36 7
9999R26 17 9999R27 17 9999R35 7 9999R36 7
9999R26 17 9999R27 17 9999R35 7 9999R36 7 9999R47 29
9999R26 17 9999R27 17 9999R35 7 9999R36 7 9999R47 29 9999R48 29
9999R26 17 9999R27 17 9999R35 7 9999R36 7 9999R47 29 9999R48 29 9999R8 7
9999R26 17 9999R27 17 9999R35 7 9999R36 7 9999R47 29 9999R48 29 9999R8 7 9999R9 7
9999R26 17 9999R27 17 9999R35 7 9999R36 7 9999R47 29 9999R48 29 9999R8 7 9999R9 7 9999R9 7

9999SR5.	7
9999TC10	4
9999TC11	4
9999TC20	4
9999TC21	4

Α AAC .....29

D
D10S1 24
D100124
D10011124
D105224
D10S2H24
D10S324
D10S3H24
D10S424
D10S4H24
D11N024
D11N0024
D11N0C 24
D11N0C2 24
D11NC 24
D118E10 24
D113F1024
D11SF1624
D11SF424
D12C2224
D12C2324
D12C6124
D12C6224
D12CJ124
D12C.I2 24
D12CO1 24
D12CD61 24
D12CR0124
D120R0224
D12D0224
D12D2224
D12D6124
D12D6224
D12D6324
D12DJ224
D12DJ324
D12DR2124
D12DR22 24
D12DR61 24
D12DR0124
D12D10224
D12E0324
D12E2224
D12E2324
D12E6224
D12EJ324
D12ER2324
D12F0424
D12F2424
D12F63
D12F64 24
D12F.I4 24
D12EP2/ 24
DIZFR0424

R	
RFK03	4
RFK06	4
RFK06H	4
RFK10	4

S

S29450 .....29



Operating Mechanisms, Disconnect Switches, and Door-Closing Mechanisms Index



Schneider Electric USA, Inc.

800 Federal Street Andover, MA 01810 USA 888-778-2733 www.schneider-electric.us Schneider Electric, PowerPact, and Square D are trademarks and the property of Schneider Electric SE, its subsidiaries, and affiliated companies. All other trademarks are the property of their respective owners. 9420CT9701R03/21 Replaces 9420CT9701R09/15

9420CT9701R03/21 Replaces 9420CT9701R09/15 © 1997–2021 Schneider Electric All Rights Reserved